

User Manual

DA16200 Evaluation Kit

UM-WI-023

Abstract

This user manual describes how to set up and use the DA16200 Evaluation Kit, version 6.0 and higher. If you use EVK version 5.0 or lower, please see the previous version of this manual.

Contents

Abstract	1
Contents	2
Figures.....	3
Tables	4
1 Terms and Definitions.....	5
2 References	5
3 DA16200 Module EVK	6
4 Test Sequence	7
5 Wi-Fi Mode Setup	8
5.1 DA16200 Connecting the Board	8
5.2 Configure the Serial Port for UART.....	8
5.3 Setup for Station Mode	9
5.4 Setup for Soft-AP Mode	11
6 DPM Setup.....	14
6.1 What is DPM	14
6.2 Enable DPM Mode	14
6.3 Hold DPM Mode.....	15
6.4 Disable DPM Mode	16
7 Current Measurement	18
7.1 Test Setup	18
7.2 Sleep 1	18
7.3 Sleep 2	18
7.4 Sleep 3	18
8 Ping Test	20
8.1 Test Setup	20
8.2 Add ARP Record	21
8.3 Perform Ping Test	22
9 Throughput Test.....	23
9.1 Test Setup	23
9.2 Iperf Test with Client Mode	24
9.3 Iperf Test with Server Mode	25
10 DA16200 Commands.....	27
10.1 Console Commands.....	27
10.1.1 Root Commands.....	28
10.1.2 Network Commands	28
10.2 CLI Command	30
10.2.1 Overview	30
10.2.2 CLI Format.....	31
10.2.3 Common Commands.....	31
10.2.4 STA Commands	33
10.2.5 Soft-AP Commands	34
10.2.6 Advanced Commands	37

DA16200 Evaluation Kit

10.3	MROM Commands	37
10.3.1	Common Commands.....	37
10.3.2	Memory Access Commands.....	38
10.3.3	Download Commands	38
10.3.4	SFLASH Commands	38
10.3.5	Secure Commands	38
10.3.6	Additional Commands.....	38
11	Firmware Update	40
11.1	Flash MAP	40
11.2	OTP Lock Protection	41
11.3	Bootloader Image	41
11.4	System Library Image	43
11.5	Main RTOS Image	44
11.6	Download Image with Script (Macro)	46
11.7	SFDP Checking.....	48
11.8	Serial Flash Recovery	48
11.9	Serial Flash Recovery from Boot	49
11.10	Boot Index Change	51
11.11	MAC Address Checking	51
12	Country Codes.....	52
	Revision History	54

Figures

Figure 1:	Hardware Configuration	6
Figure 2:	JTAG Pin Connection.....	6
Figure 3:	Test Point for Current Measurement.....	7
Figure 4:	Check COM Ports on Device Manager	8
Figure 5:	Serial Port Setup	9
Figure 6:	Easy Setup Start	9
Figure 7:	Country Selection	10
Figure 8:	Station Mode Selection	10
Figure 9:	AP Selection.....	10
Figure 10:	Check Wi-Fi Configuration	11
Figure 11:	Wi-Fi Configuration Completed	11
Figure 12:	Soft-AP Mode Selection	12
Figure 13:	Setup AP	12
Figure 14:	AP Mode Selection.....	13
Figure 15:	AP Setup Completed.....	13
Figure 16:	Setting DPM Factor with Default	14
Figure 17:	Setting DPM Factor with User Defined	15
Figure 18:	DPM Mode Running after Reboot.....	15
Figure 19:	DPM Mode Hold	16
Figure 20:	DPM Mode Off.....	17
Figure 21:	Current Test Environment	18
Figure 22:	Current Measurement with DPM.....	19
Figure 23:	Ping Test Environment.....	20
Figure 24:	Ethernet IP Address Assign	20
Figure 25:	DA16200 IP Address Assign.....	20
Figure 26:	Check ARP Record	21
Figure 27:	Interface Name for ARP Record	21

DA16200 Evaluation Kit

Figure 28: Success ARP Record for DA16200	22
Figure 29: Ping Test with DPM.....	22
Figure 30: Iperf Test Environment.....	23
Figure 31: Iperf Test Command	23
Figure 32: Check IP Address.....	24
Figure 33: Disable Firewall for Iperf Test	24
Figure 34: Run Iperf Server on PC.....	25
Figure 35: Run Iperf Client on the DA16200	25
Figure 36: Check the IP Address of DA16200	25
Figure 37: Run Iperf Server on Terminal.....	26
Figure 38: Run Iperf Client on the Laptop	26
Figure 39: CLI Check.....	30
Figure 40: Run Macro.....	41
Figure 41: OTP Locked	41
Figure 42: Mask ROM	42
Figure 43: Bootloader Prompt on Command Window.....	42
Figure 44: Load Image File.....	42
Figure 45: System Library Prompt on Command Window	43
Figure 46: Load Image File.....	43
Figure 47: Main Image Prompt on Command Window	44
Figure 48: Load Image File.....	44
Figure 49: Factory Mode Prompt on Command Window	45
Figure 50: Load Macro	46
Figure 51: Download Bootloader.....	46
Figure 52: Download RTOS Image	47
Figure 53: Download Slib Image	47
Figure 54: SFDP	48
Figure 55: Initialize NVRAM	49
Figure 56: Recovery Point in the EVK.....	50
Figure 57: Run with BOOT Mode	50

Tables

Table 1: GPIO, SPI Selective Switch	7
Table 2: Root Commands.....	28
Table 3: Network Commands.....	29
Table 4: CLI Commands in Common Mode	31
Table 5: CLI Commands on STA Mode	33
Table 6: CLI Commands on Soft-AP Mode	34
Table 7: Advanced CLI Commands	37
Table 8: 2 MB Serial Flash Memory Map	40
Table 9: 4 MB Serial Flash Memory Map	40
Table 10: Country Codes.....	52

DA16200 Evaluation Kit

1 Terms and Definitions

DPM	Dynamic Power Management
AP	Access Point
USB	Universal Serial Bus
UART	Universal Asynchronous Receiver-Transmitter
RTC	Real Time Clock
WPS	Wi-Fi Protected Setup
SSID	Service Set Identifier
SDK	Software Development Kit
ARP	Address Resolution Protocol

2 References

- [1] DA16200, Datasheet, Dialog Semiconductor
- [2] UM-WI-002, DA16200, SDK Programmer Guide, User Manual, Dialog Semiconductor
- [3] UM-B-114, DA14531, Devkit Pro Hardware, User Manual, Dialog Semiconductor
- [4] UM-WI-012, DA16200 SPI SFlash Downloader, User Manual Rev 1v5, Dialog Semiconductor

DA16200 Evaluation Kit

3 DA16200 Module EVK

Figure 1 shows the hardware configuration of the DA16200 Module Evaluation Kit (EVK).



Figure 1: Hardware Configuration

DA16200 has the following components:

1. Main board: DA16200 module (DA16200MOD-AAC4WA32) is installed on the PCI-type main board.
2. USB Interface part.
3. DA16200MOD-AAC4WA32 Wi-Fi Module.
4. USB Port: UART0 (for debug) and UART1 (for AT command).
5. JTAG PIN: to be able to connect I-jet (a JTAG debugger from IAR). See [Figure 2](#).
 - Pin 7 on each end is keyed with a white plug, so Pin 7 should be removed on EVK



Figure 2: JTAG Pin Connection

6. Factory Reset Button: press for more than 5 seconds to initialize `nvr` data.
7. WPS Button: press to start WPS mode.
8. RTC Wake-up key: switch to wake up the board from Sleep mode.
9. RTC Power key: switch to turn the board on/off.
10. Pin (P2): selected part in red color is for current measurement. For normal operation, this pin should be shorted. See [Figure 3](#).
 - Pull out the Short Pin cap and use the jumper wire to connect to measuring equipment




Figure 3: Test Point for Current Measurement

11. GPIO, SPI selective switch: SW2, SW3, SW4 (Default: on), SW1 (Default: off). See [Table 1](#).
- For more details on how to use the pins, see the schematic of the 6.0 EVK in the manual [\[4\]](#)

Table 1: GPIO, SPI Selective Switch

Selective Switch	On	Off
SW3: GPIO 0, 1, 2, 3	Image download using SPI 1	Not defined
SW2: GPIO 4, 5	UART 1(TXD, RXD) to FT232H	UART 1 to external MCU for Test
SW1: GPIO 6, 7	Image download using SPI 2	WPS, Factory Reset
SW1: GPIO 8, 9	Image download using SPI 2	Not defined
SW4: GPIO 6, 7	WPS, Factory Reset	Not defined

4 Test Sequence

This section describes the test sequence for how we show the DA16200 benefits of the following test items:

- Current measure (Section [7](#))
 - Section [7.1](#) > Section [5.1](#), [5.2](#) > Section [7.2](#) (Sleep1), Section [7.3](#) (Sleep 2)
 - Section [7.1](#) > Section [5.1](#), [5.2](#) > Section [6](#) > Section [7.4](#)
- Ping test (Section [7](#))
- Section [5.1](#), [5.2](#), [5.3](#) > (Section [6](#)) > Section [7](#)
- Throughput test (Section [9](#))
- Section [5.1](#), [5.2](#), [5.3](#) > Section [9](#)
- SoftAP test (Section [5.4](#))
- Section [5.1](#), [5.2](#) > Section [5.4](#)
- Firmware update
- Section [5.1](#), [5.2](#) > Section [10.3](#)

DA16200 Evaluation Kit

5 Wi-Fi Mode Setup

This section describes how to set up the Station and Soft-AP modes that are supported by DA16200.

- Station: a mode that runs the 802.11 STA interface
- Soft-AP: a mode that runs the Software Access Point. The Soft-AP mode does not support full-fledged commercial level Access Point features. This mode is normally used for Provisioning

NOTE

If the customer/developer starts with a new SFLASH or a full initialized SFLASH, then the "factory" command should be run on the console after the first boot to initialize the NVRAM drive.

5.1 DA16200 Connecting the Board

This section describes the installation procedure for the drivers, the configuration of the serial port, and all necessary steps to verify the connection with the PC as well as solutions to any problems that may occur.

On first connection to a host PC with Microsoft Windows as an operating system, the system detects several devices and automatically installs all necessary drivers. If not automatically installed, then get the driver from the following URL: http://www.ftdichip.com/Drivers/CDM/CDM21224_Setup.zip.

There are two virtual COM ports created by the Windows driver. The first COM port (lower number, COM35 in this example) provides a UART interface for debugging or firmware download between the PC and the DA16200. The second (higher number, COM36 in this example) is used for ATCOMMAND. See [Figure 4](#).




Figure 4: Check COM Ports on Device Manager

5.2 Configure the Serial Port for UART

On a Windows Host, the utility **Tera Term** is used to fully validate the connection to the DA16200 EVK. **Tera Term** is a free software terminal emulator (communication program) that supports multiple communication including serial port connections. Download **Tera Term** from <https://tssh2.osdn.jp>. Run the **teraterm-x.yy.exe** executable and follow the installation wizard.

DA16200 Evaluation Kit

To make sure that the communication between the DA16200 EVK and the host PC is properly established, the UART connection between the two nodes needs to be verified. For that purpose, do the following steps:

1. Connect the DA16200 EVK to the PC via USB cable to USB Port.
2. Check if the host discovered two serial ports as shown in [Figure 4](#). The second is connected to UART (see [Section 5.1](#)).
3. Open **Tera Term** from the Windows Start menu.
4. In the **Tera Term: New connection** dialog box:
 - a. Select **Serial**.
 - b. Select the COM Port to use.
 - c. Click **OK**.
5. Select **Setup > Serial Port** and configure your UART port with the parameters as shown in [Figure 5](#).
6. Open the Lowest COM port number assigned to the DA16200 EVK (see [Figure 4](#)), to figure out which port number is used by Windows by running the Device Manager. Make sure that the UART is configured as shown in [Figure 5](#).




Figure 5: Serial Port Setup

5.3 Setup for Station Mode

Use Easy Setup to configure the Wi-Fi functions of DA16200 via a Wi-Fi configuration wizard:

1. Run command `setup`.
2. From here on, the setup query statements continue. So please answer the questions as described in the following steps.
3. Stop all services for the setting. Are you sure? [Yes/No]: type **Yes**
See [Figure 6](#).

```
[/DA16200] # setup
Stop all services for the setting.
Are you sure ? [Yes/No] : y
```

Figure 6: Easy Setup Start

4. COUNTRY CODE? [Quit] (Default KR): type **US** for testing
See [Figure 7](#).

DA16200 Evaluation Kit



Figure 7: Country Selection

5. MODE? [1/2/Quit] (Default Station): type 1
See Figure 8.




Figure 8: Station Mode Selection

6. SELECT SSID? (1~30/Manual/Quit) : type 1
See Figure 9.
- Select the SSID of the AP to which you want to connect. If there is no AP that you want to connect to, please press **Enter** to rescan.
For example: SSID **ACST_AC_TEST2** is selected for testing.



Figure 9: AP Selection

- PSK-KEY (ASCII characters 8~63 or hexadecimal characters 64)? [Quit]
: ***** type the password that matches the encryption method of the selected AP.
- WIFI CONFIGURATION CONFIRM? [Yes/No/Quit]: type Y. See Figure 10.
- IP Connection Type? [Automatic IP/Static IP/Quit]: type A
IP is automatically assigned by DHCP.
- IP CONFIGURATION CONFIRM? [Yes/No/Quit]: type Y
- SNTP Client enable: type N
If time synchronization is not needed, then there is no need to run the SNTP Client.
- Dynamic Power Management? [Yes/No/Quit]: type N
See section 6.1 for more information about DPM.

DA16200 Evaluation Kit

```

=====
SSID      : ACST_AC_TEST2
AUTH      : WPA/WPA2
ENCRYPTION: TKIP/AES(CCMP)
PSK KEY   : acstac12
KEY TYPE   : ASCII
Hidden AP : Not connect
=====
WIFI CONFIGURATION CONFIRM ? [Yes/No/Quit] : Y

IP Connection Type ? [Automatic IP/Static IP/Quit] : A

IP Connection Type: Automatic IP

IP CONFIGURATION CONFIRM ? [Yes/No/Quit] : Y

SNTP Client enable ? [Yes/No/Quit] : N

FCI Dynamic Power Management ? [Yes/No/Quit] : N

```

Figure 10: Check Wi-Fi Configuration

- Once all settings are made as shown in Figure 10, the configuration is saved and the system will reboot as shown in Figure 11.

```

*****
*          DA16200 SDK Information
* -----
*
* - CPU Type       : Cortex-M4 (80MHz)
* - OS Type        : ThreadX 5.7
* - Serial Flash   : 2 MB
* - SDK Version    : V2.3.5.0 GEN
* - F/W Version    : RTOS-GEN01-01-14709-000000
* - F/W Build Time : Jun 24 2021 13:07:35
* - Boot Index     : 0
*
*****

>>> Enable BOR circuit ...

System Mode : Station Only (0)
>>> DA16x Supp Ver2.7 - 2020_07
>>> Wi-Fi mode : b/g/n -> b/g (for DPM)
>>> MAC address (sta0) : d4:3d:39:10:dd:12
>>> sta0 interface add OK
>>> Start STA mode...
RTC switched to XTAL
>>> Network Interface (wlan0) : UP
>>> Associated with 2c:4d:54:dc:c8:90

Connection COMPLETE to 2c:4d:54:dc:c8:90

-- DHCP Client WLAN0: SEL(3)
-- DHCP Client WLAN0: REQ(4)
-- DHCP Client WLAN0: BOUND(5)
   Assigned addr : 192.168.100.35
   netmask       : 255.255.255.0
   gateway       : 192.168.100.1
   DNS addr      : 192.168.100.1

   DHCP Server IP : 192.168.100.1
   Lease Time     : 24h 00m 00s
   Renewal Time   : 20h 00m 00s

```

Figure 11: Wi-Fi Configuration Completed

5.4 Setup for Soft-AP Mode

The setup for the Soft-AP mode is almost the same as for the STA mode. You can also use Easy Setup to set up the Soft-AP mode. Do the following:

- At the prompt, run the command `setup`.
- From here on, the setup query statements continue. So please answer the questions as described in the following steps.

DA16200 Evaluation Kit

3. MODE? [1/2/Quit] (Default Station): type **2**
See [Figure 12](#).

```
SYSMODE(WLAN MODE) ?
1. Station
2. Soft-AP
MODE ? [1/2/Quit] (Default Station) : 2
```

Figure 12: Soft-AP Mode Selection

4. SSID? (Default 16200_9FFFFF): **TEST AP**. See [Figure 13](#).
 - a. Choose the SSID you want to use.
5. CHANNEL? [1~11, Auto:0/QUIT]: press **[ENTER]**
6. AUTHENTICATION? [1/3/4/5/QUIT]: type **4**
 - o WPA2-PSK is recommended
7. ENCRYPTION? [1/2/3/Quit]: type **2**
8. PSK-KEY (ASCII characters 8~63 or hexadecimal characters 64)? [Quit]:
: ***** Enter the password you want to use.

```

[SOFT-AP CONFIGURATION]
SSID ? <Default DA16280 9FF9EB> : TEST AP
CHANNEL ? [1~11, Auto:0/Quit] <Default Auto> :
AUTHENTICATION ?
1. OPEN
2. WEP<Unsupported>
3. WPA-PSK
4. WPA2-PSK <Recommend>
5. WPA/WPA2-PSK
AUTHENTICATION ? [1/3/4/5/Quit] : 4
ENCRYPTION ?
1. TKIP <OPTION> <Unsupported WML11N Mode>
2. AES<CCMP>
3. TKIP/AES<CCMP>
ENCRYPTION ? [1/2/3/Quit] : 2
PSK-KEY<ASCII characters 8~63 or Hexadecimal characters 64> ? [Quit:
11234567891123456789112345678911234567891123456789112345678911234]

```

Figure 13: Setup AP

- ```
9. Do you want to set advanced Wi-Fi configuration? [No/Yes/Quit] (Default No): type N
 See Figure 14.
10. WIFI CONFIGURATION CONFIRM? [Yes/No/Quit]: type Y
11. IP ADDRESS? [Quit] (Default 10.0.0.1): press [ENTER]
12. SUBNET? [Quit] (Default 255.255.255.0): press [ENTER]
13. GATEWAY? [Quit] (Default 10.0.0.1): press [ENTER]
14. DNS? [Quit] (Default 8.8.8.8): press [ENTER]
15. IP CONFIGURATION CONFIRM? [Yes/No/Quit]: type Y
16. DHCP SERVER CONFIGURATION? [Yes/No/Quit]: type Y
17. DHCP SERVER LEASE IP Count (MAX 10)? [Quit] (Default 10): press [ENTER]
18. DHCP SERVER LEASE TIME (60 ~ 86400 SEC)? [Quit] (Default 1800): press [ENTER]
19. DHCP SERVER CONFIGURATION CONFIRM? [Yes/No/Quit]: type Y
```

## DA16200 Evaluation Kit

```

Do you want to set advanced WIFI configuration? [No/Yes/Quit] (Default No) : N

=====
SSID : TEST AP
CHANNEL : AUTO(AC3)
AUTH : WPA2
ENCRYPTION: AES(128)
PSK KEY : 12345678
KEY TYPE : ASCII
WIFI MODE : 11b/g/n
=====
WIFI CONFIGURATION CONFIRM? [Yes/No/Quit] : Y

=====
IP ADDRESS? [Quit] (Default 10.0.0.1) :
SUBNET? [Quit] (Default 255.255.255.0) :
GATEWAY? [Quit] (Default 10.0.0.1) :
DNS? [Quit] (Default 8.8.8.8) :

=====
[WLAN0]
IP ADDRESS: 10.0.0.1
SUBNET: 255.255.255.0
GATEWAY: 10.0.0.1
DNS: 8.8.8.8
=====
IP CONFIGURATION CONFIRM? [Yes/No/Quit] : Y

=====
DHCP SERVER CONFIGURATION? [Yes/No/Quit] : Y

=====
DHCP SERVER LEASE (IP Count(MAX 10)) [Quit] (Default 10) :
DHCP SERVER LEASE TIME(60 ~ 86400 SEC) [Quit] (Default 1800) :

=====
[DHCP SERVER]
START IP: 10.0.0.2
END IP: 10.0.0.11
DNS: 8.8.8.8
LEASE TIME: 1800
=====
DHCP SERVER CONFIGURATION CONFIRM? [Yes/No/Quit] : Y

```

Figure 14: AP Mode Selection

```

* DA16200 SDK Information
* -----
*
* - CPU Type : Cortex-M4 (80MHz)
* - OS Type : ThreadX 5.7
* - Serial Flash : 2 MB
* - SDK Version : V2.3.5.0 GEN
* - F/W Version : RTOS-GEN01-01-14709-000000
* : SLIB-GEN01-01-14709-000000
* - F/W Build Time : Jun 24 2021 13:07:35
* - Boot Index : 0
*

>>> Enable BOR circuit ...

System Mode : Soft-AP (1)
Starting DHCP(S/WLAN1)
>>> DA16x Supp Ver2.7 - 2020_07
>>> Add SoftAP Interface (softap1) ...
>>> MAC address (softap1) : d4:3d:39:10:dd:13
>>> softap1 interface add OK
>>> AP Operating Channel: AUTO
>>> Soft-AP ACS : ideal ch is 13
>>> Network Interface (wlan1) : UP
>>> BSS Isolate : Disable

Soft-AP is Ready (d4:3d:39:10:dd:13)

```

Figure 15: AP Setup Completed

Once all settings are made, the configuration is saved and the system reboots.

A message is printed that Soft-AP mode started successfully. See [Figure 15](#).

## DA16200 Evaluation Kit

## 6 DPM Setup

### 6.1 What is DPM

DPM (Dynamic Power Management) is a synthesis of breakthrough ultra-low-power technologies that enable extremely low power operation in the DA16200. DPM shuts down every microelement of the chip that is not in use, which allows a near-zero level of power consumption when not actively transmitting or receiving data. Such low-power consumption can provide a battery life of one year or more, depending on the application. DPM also enables ultra-low-power transmission and receive modes when the SoC needs to be awake to exchange information with other devices. Advanced algorithms enable to stay asleep until the exact required moment to wake up to transmit or receive.

### 6.2 Enable DPM Mode

To enable the DPM mode:

1. Do the steps in section 5.1 until step 12: **Dynamic Power Management? [Yes/No/Quit]**.
2. At prompt **Dynamic Power Management? [Yes/No/Quit]**: type **Y**. See Figure 16.
  - a. To use the default DPM factor, **DPM factors: Defaults? [Yes/No/Quit]**, type **Y**
  - b. **DPM CONFIGURATION CONFIRM [Yes/No/Quit]**: type **Y**

#### NOTE

TIM wakeup count in 10 dtim is the default value. This means:  $10dtim \times 102.4 = 1,024 \text{ ms} = 1\text{sec}$  @ DTIM = 1 (in case that AP DTIM = 3, 10dtim is 921.6 ms)

Wake-up from sleep state takes place every second to check for a receive packet.

```
Dialog DPM <Dynamic Power Management> ? [Yes/No/Quit] : Y
DPM factors : Defaults ? [Yes/No/Quit] : Y
=====
DPM MODE : Enable
Keep Alive Time : 30000 ms
User Wakeup Time : 0 sec.
TIM Wakeup Count : 10 dtim
=====
DPM CONFIGURATION CONFIRM ? [Yes/No/Quit] : Y
```

Figure 16: Setting DPM Factor with Default

- c. To use the user-defined DPM factor, **DPM factors: Defaults? [Yes/No/Quit]**, type **N**. See Figure 17.
  - i. **DPM Keep Alive Time (0~600000 ms)? [Quit] (Default 30000 ms)**: press **[ENTER]** or type value within the range
  - ii. **DPM User Wakeup Time (0~86400 Sec.)? [Quit] (Default 0 Sec.)**: press **[ENTER]** or type value within the range
  - iii. **DPM TIM Wakeup Count (1~65535 dtim)? [Quit] (Default 10)**: press **[ENTER]** or type value within the range
  - iv. **DPM CONFIGURATION CONFIRM [Yes/No/Quit]**: type **Y**

## DA16200 Evaluation Kit

```
Dialog DPM <Dynamic Power Management> ? [Yes/No/Quit] : Y
DPM factors : Defaults ? [Yes/No/Quit] : N
DPM Keep Alive Time<0~600000 ms> ? [Quit] <Default 30000 ms> :
DPM User Wakeup Time<0~86400 Sec.> ? [Quit] <Default 0 Sec.> :
DPM TIM Wakeup Count<1~65535 dtim> ? [Quit] <Default 10> :
=====
DPM MODE : Enable
Keep Alive Time : 30000 ms
User Wakeup Time: 0 sec.
TIM Wakeup Count: 10 dtim
=====
DPM CONFIGURATION CONFIRM ? [Yes/No/Quit] : Y
```

Figure 17: Setting DPM Factor with User Defined

- After reboot, DA16200 will enter DPM sleep. The print message >>> Start DPM Power-Down!!! means that DA16200 has entered DPM Sleep. See Figure 18.

```
Connection COMPLETE to 88:36:6c:42:79:6c
-- DHCP Client WLAN0: SEL
-- DHCP Client WLAN0: REQ
-- DHCP Client WLAN0: BOUND
 Assigned addr : 192.168.0.64
 netmask : 255.255.255.0
 gateway : 192.168.0.1
 DNS addr : 168.126.63.1
 DHCP Server IP : 192.168.0.1
 Lease Time : 02h 00m 00s
 Renewal Time : 01h 40m 00s
>>> Start DPM Power-Down !!!
```

Figure 18: DPM Mode Running after Reboot

**NOTE**

As soon as the system has entered DPM Sleep (After “>>> Start DPM Power-Down !!!” is printed on Console), any user input via UART console will not work, because UART interface gets down when DPM Sleep is entered.

### 6.3 Hold DPM Mode

As described in the Note above, user input is not possible after DPM Sleep is entered, which is normal. To exit this state and start over with `setup`, do the following:

- Copy the string `dpm hold` to the clipboard.
  - For example: open Notepad, type `dpm hold`, and then copy (Ctrl + C) the command string.
- Use RTC\_PWR\_KEY to power off (move to OFF position).
- Use RTC\_PWR\_KEY to power on (move to ON position).
- Before the message >>> Start DPM Power-Down !!! is printed on the console, do the following:
  - With the `dpm hold` string copied, right-click in the terminal window to paste the string.
  - Immediately press the **ENTER** key.
  - Once this procedure is done quickly and successfully, the message DPM Sleep Manager HOLD... is printed. See Figure 19.
  - If the DPM mode does not stop successfully, you may need to retry several times.
- Run `setup` again to configure DA16200 in a different mode.



```

* DA16200 SDK Information
* -----
*
* - CPU Type : Cortex-M4 (80MHz)
* - OS Type : ThreadX 5.7
* - Serial Flash : 2 MB
* - SDK Version : V2.3.5.0 GEN
* - F/W Version : RTOS-GEN01-01-14709-000000
* : SLIB-GEN01-01-14709-000000
* - F/W Build Time : Jun 24 2021 13:07:35
* - Boot Index : 0
*

>>> Enable BOR circuit ...

System Mode : Station Only (0)
>>> DA16x Supp Ver2.7 - 2020_07
>>> Wi-Fi mode : b/g/n -> b/g (for DPM)
>>> MAC address (sta0) : d4:3d:39:10:dd:12
>>> sta0 interface add OK
>>> Start STA mode...
RTC switched to XTAL
>>> Network Interface (wlan0) : UP
>>> Associated with 2c:4d:54:dc:c8:90

Connection COMPLETE to 2c:4d:54:dc:c8:90

-- DHCP Client WLAN0: SEL(3)
-- DHCP Client WLAN0: REQ(4)
dpm hold

- DPM Sleep Manager HOLD ...
[DA16200] #
[DA16200] # -- DHCP Client WLAN0: BOUND(5)
Assigned addr : 192.168.100.35
netmask : 255.255.255.0
gateway : 192.168.100.1
DNS addr : 192.168.100.1

DHCP Server IP : 192.168.100.1
Lease Time : 24h 00m 00s
Renewal Time : 20h 00m 00s

```

Figure 19: DPM Mode Hold

## 6.4 Disable DPM Mode

Though we make DPM enabled during `setup`, we can disable DPM mode with command `dpm off` at the prompt. DA16200 will reboot and connect to AP as shown in [Figure 20](#).



## DA16200 Evaluation Kit

```

[/DA16200] #
[/DA16200] # dpm off

>>> Network Interface (wlan0) : DOWN
[wpa_supplicant_event_disassoc] CTRL-Event-DISCONNECTED bssid=2c:4d:54:dc:c8:90
generated=1

>>> P.TIM is relocated to RETMEM (0x20f835c0, 4)
[dpm_init_retmemory] DPM INIT CONFIGURATION(1)

DPM Wakeup source is 0x1

* DA16200 SDK Information
* -----
*
* - CPU Type : Cortex-M4 (80MHz)
* - OS Type : ThreadX 5.7
* - Serial Flash : 2 MB
* - SDK Version : V2.3.5.0 GEN
* - F/W Version : RTOS-GEN01-01-14709-000000
* - SLIB-GEN01-01-14709-000000
* - F/W Build Time : Jun 24 2021 13:07:35
* - Boot Index : 0
*

>>> Enable BOR circuit ...

System Mode : Station Only (0)
>>> DA16x Supp Ver2.7 - 2020_07
>>> MAC address (sta0) : d4:3d:39:10:dd:12
>>> sta0 interface add OK
>>> Start STA mode...
>>> Network Interface (wlan0) : UP
>>> Associated with 2c:4d:54:dc:c8:90

Connection COMPLETE to 2c:4d:54:dc:c8:90

-- DHCP Client WLAN0: SEL(3)
-- DHCP Client WLAN0: REQ(4)
-- DHCP Client WLAN0: BOUND(5)
 Assigned addr : 192.168.100.35
 netmask : 255.255.255.0
 gateway : 192.168.100.1
 DNS addr : 192.168.100.1

 DHCP Server IP : 192.168.100.1
 Lease Time : 24h 00m 00s
 Renewal Time : 12h 00m 00s

```

Figure 20: DPM Mode Off

## DA16200 Evaluation Kit

## 7 Current Measurement

For more detailed information on Sleep mode, see section “Low Power Operation Mode” in DA16200 Datasheet [1]. To measure the current waveform, connect EVK's current measurement point (P2) with the measurement instrument (KEYSIGHT 14585A).

### 7.1 Test Setup

Figure 21 shows a typical test setup environment.



Figure 21: Current Test Environment

### 7.2 Sleep 1

To measure the Sleep 1 current, use RTC\_PWR\_KEY to power off (move to OFF position). See Section 3, number 9. See Figure 22.

### 7.3 Sleep 2

To measure the Sleep 2 current, the following command is required:

1. Use RTC\_PWR\_KEY to power on (move to on position). See section 3, number 9.
2. Type command `factory` to make DA16200 use the default setting.
3. The board will reboot.
4. At prompt, run command `sleep 2 time(sec) [/DA16200/SYS.HAL] # sleep 2 time(sec)`
  - For instance, `[/DA16200/SYS.HAL] # sleep 2 10`
  - It will sleep for a set amount of time (10 seconds), and then reboot and wake up.

### 7.4 Sleep 3

1. Do the steps in Section 6.2 until step 3.
  - When you run the DA16200 with DPM settings, DA16200 will run DPM Sleep, wake up for Beacon check and Keep Alive according to the configured DTIM

For example: the current waveform in Figure 22 shows settings DTIM 10 (about 1sec @ AP DTIM=1) and Keep Alive 30s.

Sleep 3 current means current between RX or between RX and TX.




Figure 22: Current Measurement with DPM

## DA16200 Evaluation Kit

### 8 Ping Test

DA16200 has command `ping` to verify communication test (Ping Test) during DPM mode.

#### 8.1 Test Setup

For a communication test (Ping Test) there are two stations—DA16200 and Laptop—and an Access Point (AP) required. Both must be connected to the same subnetwork AP. See [Figure 23](#).

DA16200 must be connected to the AP via WI-FI, and the laptop must be connected to the AP with an Ethernet cable. After configuration, DA16200 will be in DPM Sleep mode (Sleep 3). Then DA16200 can wake up from sleep mode when unicast packets are sent while remaining in sleep mode most of the time.

In this test, a Ping application that runs on the laptop acts as a network peer that sends a unicast packet to DA16200. This is to check if DA16200 in DPM Sleep mode can successfully wake up and receive the unicast packets in real-time.



**Figure 23: Ping Test Environment**

1. Run the command window (CMD) as administrator.
2. Type command `ipconfig` to see what the IP address is of the laptop. See [Figure 24](#).  
For example: the laptop's IP is 192.168.0.65, and the Default Gateway IP is 192.168.0.1

```
Connection-specific DNS Suffix . :
Link-local IPv6 Address : fe80::9809:ccc1:b552:e47f%19
IPv4 Address. : 192.168.0.65
Subnet Mask : 255.255.255.0
Default Gateway : 192.168.0.1
```

**Figure 24: Ethernet IP Address Assign**

3. Run the DA16200 terminal window and set DA16200 in Station mode (see [Section 5.3](#)).
  - For example: the assigned IP of DA16200 is 192.168.0.66. See [Figure 25](#)

```
Connection COMPLETE to 88:36:6c:42:79:6c
-- DHCP Client WLAN0: SEL
-- DHCP Client WLAN0: REQ
-- DHCP Client WLAN0: BOUND
 Assigned addr : 192.168.0.66
 netmask : 255.255.255.0
 gateway : 192.168.0.1
 DNS addr : 168.126.63.1

 DHCP Server IP : 192.168.0.1
 Lease Time : 02h 00m 00s
 Renewal Time : 01h 40m 00s
```

**Figure 25: DA16200 IP Address Assign**

## DA16200 Evaluation Kit

### 8.2 Add ARP Record

This section describes how to add a DHCP-assigned IP address to the ARP table and to change that IP address from a dynamic to a static IP address.

Since retransmission logic is not included in the higher protocol (TCP/UDP), an additional ARP record is required for ping tests between the laptop and the DA16200 operating in DPM sleep mode.

1. Use command `arp -s 192.168.0.66 ec-9f-f9-32` to add an ARP record manually.

#### NOTE

When you set the ARP cache to static with command `arp -s` on higher versions of Windows, you may get an error like Failed to add ARP entry, Access is denied.

It is recommended to use command `netsh` to change the network settings.

2. Do the following steps to change the ARP record to a static IP address.
3. Use command `arp -a` to view the ARP table of the network interface. See [Figure 26](#).
  - For example: `C:\WINDOWS\system32>arp -a`

```
Interface: 192.168.0.65 --- 0x13
Internet Address Physical Address Type
192.168.0.1 88-36-6c-42-79-6c dynamic
192.168.0.66 ec-9f-0d-9f-f9-32 dynamic
192.168.0.255 ff-ff-ff-ff-ff-ff static
224.0.0.2 01-00-5e-00-00-02 static
224.0.0.22 01-00-5e-00-00-16 static
224.0.0.251 01-00-5e-00-00-fb static
224.0.0.252 01-00-5e-00-00-fc static
239.255.255.250 01-00-5e-7f-ff-fa static
255.255.255.255 ff-ff-ff-ff-ff-ff static
```

Figure 26: Check ARP Record

4. Use command `netsh interface show interface` to find the interface name. See [Figure 27](#).
  - For example: `C:\WINDOWS\system32>netsh interface show interface`

```
C:\WINDOWS\system32>netsh interface show interface

Admin State State Type Interface Name

Enabled Connected Dedicated Ethernet
Enabled Disconnected Dedicated Wi-Fi
```

Figure 27: Interface Name for ARP Record

5. Use the interface name found for DA16200 to set the ARP cache to static with command `C:\WINDOWS\system32> netsh interface ipv4 add neighbors "<Interface Name>" "<IP>" "<MAC>"`. See [Figure 28](#).
  - For example: `C:\WINDOWS\system32> netsh interface ip add neighbors "Ethernet" "192.168.0.66" "ec-9f-0d-9f-f9-32"`
6. Use command `arp -a` on the laptop to check if the ARP cache is configured correctly. See [Figure 28](#).
  - For example: `C:\WINDOWS\system32>arp -a`
  - DA16200's IP address 192.168.0.66 is added to ARP table as a static type

## DA16200 Evaluation Kit

```
C:\WINDOWS\system32>netsh interface ip add neighbors "Ethernet" "192.168.0.66" "ec-9f-0d-9f-f9-32"

C:\WINDOWS\system32>arp -a

Interface: 192.168.0.65 --- 0x13
Internet Address Physical Address Type
192.168.0.1 88-36-6c-42-79-6c dynamic
192.168.0.66 ec-9f-0d-9f-f9-32 static
192.168.0.255 ff-ff-ff-ff-ff-ff static
224.0.0.2 01-00-5e-00-00-02 static
224.0.0.22 01-00-5e-00-00-16 static
224.0.0.251 01-00-5e-00-00-fb static
224.0.0.252 01-00-5e-00-00-fc static
239.255.255.250 01-00-5e-7f-ff-fa static
255.255.255.255 ff-ff-ff-ff-ff-ff static
```

Figure 28: Success ARP Record for DA16200

7. Use command `arp -d` or `netsh interface ip delete arpcache` to initialize the ARP cache.


### 8.3 Perform Ping Test

Ping application is a simple generic application provided by Network Stack for network management purposes. Its main purpose is to check if a node is alive in the same subnetwork. Ping just sends out a request once and then waits for a reply. Ping prints the result only if a Reply packet arrives from the peer.

1. Make DPM enable. See Section 6.2.
2. Run a ping on the Laptop. See Figure 29.

For example: `C:\WINDOWS\system32>ping 192.168.0.66 -t`

Next, DA16200 wakes up and receives the ping message, sends a reply, and goes to DPM sleep again.



```
C:\WINDOWS\system32>ping 192.168.0.66 -t
Pinging 192.168.0.66 with 32 bytes of data:
Reply from 192.168.0.66: bytes=32 time=12ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Reply from 192.168.0.66: bytes=32 time=25ms TTL=128
Request timed out.

Ping statistics for 192.168.0.66:
 Packets: Sent = 22, Received = 21, Lost = 1 (4% loss)
 Approximate round trip times in milliseconds:
 Minimum = 25ms, Maximum = 252ms, Average = 533ms
 Control=0

Wakeup source is 0x82
>>> TIM STATUS: 0x00000001
>>> TIM : UC

>>> Start DPM Power-Down !!!
rwnx_send_set_ps_mode PS TIME (us) 139636

Wakeup source is 0x82
>>> TIM STATUS: 0x00000001
>>> TIM : UC

>>> Start DPM Power-Down !!!
rwnx_send_set_ps_mode PS TIME (us) 139642

Wakeup source is 0x82
>>> TIM STATUS: 0x00000001
>>> TIM : UC
```

Figure 29: Ping Test with DPM

#### NOTE

If you have multiple network interfaces enabled, then put the `arp` entry under the specific interface.  
 For example: `arp -s 192.168.20.52 aa-ff-00-88-66-80 -S 192.168.100.100`  
 192.168.100.100 is the interface from which the ping command should be sent. In this case, specifying the network interface is required in the ping command.  
 For example: `ping 192.168.20.52 -S 192.168.100.100`



## DA16200 Evaluation Kit

## 9 Throughput Test

DA16200 has command `iperf` to measure the packet transfer performance. This is known as the throughput test. To do the throughput test, prepare the DA16200 to operate in Station mode (see Section 5.1) without using DPM (see Section 6.4). This section shows the throughput test with the use of a TCP client/server protocol.

## 9.1 Test Setup



Figure 30: Iperf Test Environment

The Iperf tool should be ready on your laptop. **Iperf Version 2.0.9** is recommended.

To set up the Iperf tool, do the following:

1. Download Iperf from <https://iperf.fr/iperf-download.php>.
2. Create a folder called **Iperf** in path **C:\**
3. Unzip the downloaded file and move the contents to the Iperf folder.
4. Prepare the DA16200 to operate in Station mode. See Sections 5.1 to 5.3.
5. Use command `iperf` or `iperf -h` to see the available options in Iperf. See Figure 31.
  - For example: `[/DA16200/NET] # iperf`

```
[/DA16200] # net
Command-list is changed, "NET"
[/DA16200/NET] # iperf
Usage: iperf [-i [NLAND|NLANI]] [-s|-c host][options]
iperf [-h] [-v]

Client/Server:
-i # interface [NLAND|NLANI]
-u # use UDP rather than TCP
-p # server port to listen on/connect to
-w # TCP window size (4 ~ 64K)
-f [kmKM] format to report: Kbits, Mbits, KBytes, MBytes
-d # finish service
ex) iperf -d -c -u : udp client
iperf -d -c : tcp client
iperf -d -u : udp server
iperf -d : tcp server

Server specific:
-s # run in server mode
-T # Rx Time Out Min:1 sec, 'F' Forever

Client specific:
-c <host> run in client mode, connecting to <host>
-t # time in seconds to transmit for (default 10 secs)
-l # PacketSize option (UDP default 1470, IPv6 1440 TCP 1000)
-n # UDP Tx packet number
-S # WMM TOS option
[224|192]
[184|160|152|144|136]
[112|96|80]
[88|72|56|40|32]
-P # Pair index (0,1,2)
[default Max, Step 1~100 Mbps]
-O # use Main Packet Pool

Miscellaneous:
-m # Print MIB info(debug only)
1 counter reset
2 counter retention
-h # print this message
-v # print version
[/DA16200/NET] #
```

Figure 31: Iperf Test Command

## DA16200 Evaluation Kit

## 9.2 Iperf Test with Client Mode

To set up the Iperf test with Client mode, do the following:

1. Connect the laptop you want to use as a server to the AP.
2. In the CMD window, use the command `ipconfig/all` to find the IP address. See [Figure 32](#).

```

Ethernet adapter Ethernet:

Connection-specific DNS Suffix . :
Description : Realtek PCIe GBE Family Controller
Physical Address. : 58-20-B1-40-45-B3
DHCP Enabled. : Yes
Autoconfiguration Enabled : Yes
Link-local IPv6 Address : fe80::9809:ccc1:b552:e47f%19(Preferred)
IPv4 Address. : 192.168.123.5(Preferred)
Subnet Mask : 255.255.255.0
Lease Obtained. : Saturday, August 24, 2019 9:27:47 AM
Lease Expires : Saturday, August 24, 2019 11:27:46 AM
Default Gateway : 192.168.123.254
DHCP Server : 192.168.123.254
DHCPv6 IAID : 89661617
DHCPv6 Client DUID. : 00-01-00-01-23-3E-21-DA-58-20-B1-40-45-B3
DNS Servers : 168.126.63.1
 168.126.63.2
NetBIOS over Tcpip. : Enabled

```

Figure 32: Check IP Address

**NOTE**

The IP address can be different depending on the home AP setting.

3. For stable Iperf testing, run the Windows Security APP to turn off the network firewall. It is recommended to disable the laptop from all network firewalls before attempting a test. See [Figure 33](#).




Figure 33: Disable Firewall for Iperf Test



## DA16200 Evaluation Kit

- In the CMD window, move to the directory where Iperf is installed, and type `iperf -s` to configure the TCP server.

```
C:\#iperf>iperf -s

Server listening on TCP port 5001
TCP window size: 208 KByte (default)

```

**Figure 34: Run Iperf Server on PC**

### NOTE

When you see the message as shown in [Figure 34](#), the Iperf test is ready to start.

- In the DA16200 console window, run the Iperf test with Client mode. See [Figure 35](#).
  - For example: `[/DA16200/NET] #iperf -I wlan0 -c 192.168.123.5 -t 5 -i 1`
    - The format of the command type is:
    - `iperf -I [INTERFACE] [-s/-c] [DESTINATION IP] (-u) -i [INTERVAL TIME] -t [TEST TIME]`

```
[/DA16200/NET] # iperf -I wlan0 -c 192.168.123.5 -t 5 -i 1
[/DA16200/NET] #
[TCP] Transmit Test (Client) ==> 192.168.123.5:5001
```

| TCP_TX | No      | [Interval] | [Transfer]    | [Bandwidth]      | [Dst IP:Port]      |
|--------|---------|------------|---------------|------------------|--------------------|
| TCP_TX | 0001    | 0.00- 1.00 | 2.043 MBytes  | 17.146 Mbits/sec | 192.168.123.5:5001 |
| TCP_TX | 0002    | 1.00- 2.00 | 2.110 MBytes  | 17.706 Mbits/sec | 192.168.123.5:5001 |
| TCP_TX | 0003    | 2.00- 3.00 | 2.074 MBytes  | 17.403 Mbits/sec | 192.168.123.5:5001 |
| TCP_TX | 0004    | 3.00- 4.00 | 2.110 MBytes  | 17.706 Mbits/sec | 192.168.123.5:5001 |
| TCP_TX | 0005    | 4.00- 5.00 | 2.081 MBytes  | 17.461 Mbits/sec | 192.168.123.5:5001 |
| TCP_TX | [Total] | 0.00- 5.01 | 10.443 MBytes | 17.487 Mbits/sec | 192.168.123.5:5001 |

**Figure 35: Run Iperf Client on the DA16200**

## 9.3 Iperf Test with Server Mode

A server mode test should be run with a configuration that is opposite to that of client mode. In this case, the DA16200 is prepared as a server. The laptop becomes a client and sends data to the DA16200.

- In the DA16200 console window, check the assigned IP address for DA16200 as shown in [Figure 36](#).

```
Connection COMPLETE to b8:55:10:e0:98:0a
-- DHCP Client WLAN0: SEL
-- DHCP Client WLAN0: REQ
-- DHCP Client WLAN0: BOUND
 Assigned addr : 192.168.123.6
 netmask : 255.255.255.0
 gateway : 192.168.123.254
 DNS addr : 168.126.63.1

 DHCP Server IP : 192.168.123.254
 Lease Time : 02h 00m 00s
 Renewal Time : 01h 00m 00s
```

**Figure 36: Check the IP Address of DA16200**

## DA16200 Evaluation Kit

- Run the Iperf test with Server mode on the DA16200 console window. See [Figure 37](#).

- For example: [/DA16200/NET] # iperf -I wlan0 -s

```
[/DA16200/NET] # iperf -I wlan0 -s
iPerf Server(TCP): Ready
[/DA16200/NET] #
```

```
[TCP] Receive Test (Server)
TCP_RX:[No] [Interval] [Transfer] [Bandwidth]
TCP_RX:[Total] 0.00- 5.12 9.750 MBytes 15.974 Mbits/sec 192.168.123.5:50625
```

**Figure 37: Run Iperf Server on Terminal**

- In the CMD window, run the Iperf test with Client mode. See [Figure 38](#).

- For example: C:\iperf>iperf -c 192.168.123.6 -t 5 -i 1

```
C:\iperf>iperf -c 192.168.123.6 -t 5 -i 1

Client connecting to 192.168.123.6, TCP port 5001
TCP window size: 208 KByte (default)

[3] local 192.168.123.5 port 50625 connected with 192.168.123.6 port 5001
[ID] Interval Transfer Bandwidth
[3] 0.0- 1.0 sec 2.12 MBytes 17.8 Mbits/sec
[3] 1.0- 2.0 sec 1.88 MBytes 15.7 Mbits/sec
[3] 2.0- 3.0 sec 2.00 MBytes 16.8 Mbits/sec
[3] 3.0- 4.0 sec 1.88 MBytes 15.7 Mbits/sec
[3] 4.0- 5.0 sec 1.88 MBytes 15.7 Mbits/sec
[3] 0.0- 5.0 sec 9.75 MBytes 16.3 Mbits/sec
```

**Figure 38: Run Iperf Client on the Laptop**

## DA16200 Evaluation Kit

### 10 DA16200 Commands

The DA16200 has various console commands to operate its functions. The UART0 interface connects the console with a serial terminal tool. Some commands in the following sections may be disabled according to the SDK's features configuration.

#### 10.1 Console Commands

The DA16200 console commands are categorized as follows:

- **root**
  - [/DA16200] #
- **mem**
  - [/DA16200/MEM] #
- **sys**
  - [/DA16200/SYS] #
- **nvr**
  - [/DA16200/NVRAM] #
- **net**
  - [/DA16200/NET] #
- **user**
  - [/DA16200/USER] #

Use command `help` or `?` (Question mark) to list the available commands and options.

There is a function to display the console command history, and up to five commands can be saved. Use the following keys and characters to access the history function:

- `↑` or `↓` (arrow key) on your keyboard: show the command history one by one
- `!` (Exclamation mark): view the list of the command history
- `!` (Exclamation mark) + Number: select and execute one previous command in the list

It is possible to move between categories. Use these options:

- `top`: move to the highest rank, Root
- `up`: move to one step upper rank category
- Category command (for example `sys`, `nvr`, `net`): move to the category. To run each command of each category, go to the category first, or prefix the category name to the command as shown in the example:
  - `net`
  - `net.ifconfig`

## DA16200 Evaluation Kit

## 10.1.1 Root Commands

Table 2: Root Commands

| Command    | Parameters                                                     | Description                                                                                                                                                                                                                                                                                                                                                                                      |
|------------|----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| help /?    | (none)                                                         | Display help information for the corresponding category                                                                                                                                                                                                                                                                                                                                          |
| up         | (none)                                                         | Move up one rank category                                                                                                                                                                                                                                                                                                                                                                        |
| top        | (none)                                                         | Move to the Root category                                                                                                                                                                                                                                                                                                                                                                        |
| factory    | (none)                                                         | Factory reset for all settings                                                                                                                                                                                                                                                                                                                                                                   |
| ps         | (none)                                                         | Display thread information                                                                                                                                                                                                                                                                                                                                                                       |
| setup      | (none)                                                         | DA16200 general function setting wizard (Easy Setup)<br>Make step-by-step configuration settings for elements such as SYSMODE, WI-FI, and NETWORK                                                                                                                                                                                                                                                |
| reboot     | (none)<br>[mode]                                               | Reboot <ul style="list-style-type: none"> <li>• por: POR rebooting</li> </ul>                                                                                                                                                                                                                                                                                                                    |
| reset      | (none)                                                         | Reset to the Bootloader prompt                                                                                                                                                                                                                                                                                                                                                                   |
| ver        | (none)                                                         | Display SDK version and system information                                                                                                                                                                                                                                                                                                                                                       |
| time       | [option]                                                       | Display or set the current time <ul style="list-style-type: none"> <li>• time set [YYYY-MM-DD] [hh:mm:ss]: set date and time</li> <li>• time zone [-hh:mm]: set time zone</li> <li>• time boot: display booting time</li> <li>• time uptime: display booting duration</li> <li>• time help: display help</li> </ul>                                                                              |
| getwlanmac | (none)                                                         | Display the MAC address for network interfaces                                                                                                                                                                                                                                                                                                                                                   |
| setwlanmac | [xx:xx:xx:xx:xx:xx<br>  xx-xx-xx-xx-xx-xx<br>xx  xxxxxxxxxxxx] | Set up the MAC address for network interfaces<br>For example: setwlanmac aa:bb:cc:00:00:02   aa-bb-cc-00-00-02   aabbcc000002                                                                                                                                                                                                                                                                    |
| dpm        | [options]                                                      | Set DPM condition <ul style="list-style-type: none"> <li>• on   off: DPM feature enable or disable</li> <li>• status: DPM Status print</li> <li>• rtm: view DPM backup data</li> <li>• rtc: view DPM RTC timer</li> <li>• debug [level]: turn DPM debug on/off <ul style="list-style-type: none"> <li>◦ level = 1(MSG_ERROR), 2(MSG_INFO), 3(MSG_DEBUG), 4(MSG_EXCESSIVE)</li> </ul> </li> </ul> |

## 10.1.2 Network Commands

To move to the network command category, type the command `net`.

## DA16200 Evaluation Kit

Table 3: Network Commands

| Command   | Parameter                                                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-----------|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ifconfig  | (none)<br>[interface wlan0 wlan1]<br>[options]                                                        | <p>Display or set the basic network setting and status</p> <ul style="list-style-type: none"> <li>• ifconfig: display basic network settings information</li> <li>• ifconfig -a: display details of all network interfaces</li> <li>• ifconfig [wlan0 wlan1]: display details of a network interface</li> <li>• ifconfig [wlan0 wlan1] [ipaddress] [subnet] [gateway]: set static IP addresses to a network interface</li> <li>• ifconfig [wlan0 wlan1] dhcp: enable/disable DHCP to a network interface</li> <li>• ifconfig [wlan0 wlan1] [up down]: go up/down a network interface</li> <li>• ifconfig [wlan0 wlan1] [start stop renew release]: DHCP client command</li> <li>• ifconfig [wlan0 wlan1] [dns] [DNS ServerIP]: set DNS server address (static IP) to a network interface</li> <li>• ifconfig help: display help</li> </ul> |
| ping      | -I [interface wlan0 wlan1]<br>[domain ip] -n<br>[count] -l<br>[size] -w<br>[timeout] -i<br>[interval] | <p>Ping test to the target address with a certain option</p> <ul style="list-style-type: none"> <li>• [interface wlan0 wlan1]: <ul style="list-style-type: none"> <li>◦ Network interface. With no designated interface, an interface for a subnet band of the same destination IP address is designated</li> </ul> </li> <li>• [count]: the count of ping tests</li> <li>• [size]: the size of data to be transmitted (max: 10000)</li> <li>• [timeout]: waiting time for a response to the transmitted message (min: 10 ms)</li> <li>• [interval]: waiting time for message transmission (min: 10 ms)</li> <li>• [-6]: ping test with an IPv6 address</li> </ul> <p>For example: ping 172.16.0.1 -l 1024 -n 10 -w 1000 -i 1000<br/>ping -6 fe80::1:2 -I wlan0</p>                                                                        |
| arp       | [interface]<br>[options]                                                                              | <p>Display the ARP table of a network interface</p> <ul style="list-style-type: none"> <li>• a: display the ARP table of every interface</li> <li>• d: delete all ARP tables</li> <li>• Help: Help display</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| arp send  | [interface]<br>[dst ipaddress]                                                                        | <p>Transmit the ARP request message of the target IP</p> <p>For example: arp send wlan0 10.0.0.1</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| garp send | [interface]<br>[option]                                                                               | <p>Transmit a GARP message with the option:</p> <ul style="list-style-type: none"> <li>• 0: normal garp</li> <li>• 1: check IP conflict</li> </ul> <p>For example: arp send wlan0</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

## DA16200 Evaluation Kit

| Command | Parameter                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| dhcpcd  | [interface]<br>[options]                    | DHCP server setting <ul style="list-style-type: none"> <li>• boot [on off]: automatic start setting with a certain interface</li> <li>• range &lt;Start IP ADDRESS&gt; &lt;END IP Address&gt;: IP lease band setting (max 10)</li> <li>• lease_time &lt;Integer&gt;: lease time setting (min 60 sec)</li> <li>• dns &lt;IP Address&gt;: lease IP DNS server address setting</li> <li>• response_delay &lt;Integer&gt;: time of response delay</li> <li>• status: display DHCP Server status</li> <li>• lease [0 1]: display IP lease table               <ul style="list-style-type: none"> <li>◦ Display tables including un-allotted tables when flag = 1</li> </ul> </li> </ul> |
| iperf   | -I [interface]<br>[-s -c host]<br>[options] | Setup Iperf client/server                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| cli     | [options]                                   | Refer to the CLI section                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| debug   | [options]                                   | Execute various types of debug commands <ul style="list-style-type: none"> <li>• arp [on off]: arp debug message output on/off</li> <li>• dhcpcd [level]: DHCP Server debug level setting (level = 0~2 default 0)</li> <li>• dhcpc [level]: DHCP Client debug level setting (level = 0~5 default 1)</li> <li>• umac [on off] mask: debug umac 1 0x4</li> </ul>                                                                                                                                                                                                                                                                                                                     |
| act     | [on   off]                                  | Start or stop DPM Auto Configuration                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

## 10.2 CLI Command

### 10.2.1 Overview

The DA16200 supplicant plays a key role in providing users with Wi-Fi functionality. Major functions include IEEE 802.11 management frame, various security functions (WPA and RSN by IEEE 802.11i), and CLI (Command Line Interface) to control DA16200 Wi-Fi performance.

The CLI in DA16200 can execute commands in the network command state.

For example, in the Station mode, the network information of the DA16200 is obtained with CLI command: [/DA16200/NET] cli status. See [Figure 39](#).

```

[/DA16200] # net
Command-List is changed, "NET"
[/DA16200/NET] # cli status
sta0
mac_address=ec:9f:0d:9f:ff:fe
bssid=88:86:6c:42:79:6c
ssid=ACST_AC_TEST2
id=0
mode=STATION
pairwise_cipher=CCMP
group_cipher=CCMP
key_mgmt=WPA2-PSK
channel=1
wpa_state=COMPLETED
handshake_state=3
[/DA16200/NET] #

```

Figure 39: CLI Check

## DA16200 Evaluation Kit

### 10.2.2 CLI Format

There are four CLI formats (Type A~D):

- Read/Write Parameter (Type A)
  - Read: [/DA16200/NET] # cli [CLI]
  - Write: [/DA16200/NET] # cli [CLI] <VALUE>
- Write Only Parameter (Type B)
  - [/DA16200/NET] # cli [CLI] <VALUE> or cli [CLI] <OPTION> <VALUE>
- Read Only Parameter (Type C)
  - [/DA16200/NET] # cli [CLI] or cli [CLI] <OPTION>
- Execution Parameter (Type D)
  - [/DA16200/NET] # cli [CLI] or cli [CLI] < OPTION>

### 10.2.3 Common Commands

**Table 4: CLI Commands in Common Mode**

| CLI            | Parameter | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| status         | (none)    | Get the main information on the interface being operated at DA16200<br>For example: [/DA16200/NET] # cli status                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| save_config    | (none)    | Save all parameters modified through CLI and so forth in NVRAM<br>(Saved values become applicable after a reboot) (D)<br>For example: [/DA16200/NET] # cli save_config<br>* Information saved in NVRAM may be inquired with the following command:<br>For example:<br>[/DA16200/NVRAM] # printenv<br>Total length (95)<br>country_code (STR,03) ..... KR<br>SYSMODE (STR,02) ..... 0<br>0: NETMODE (STR,02) ..... 1<br>NO_Profile (STR,02) ..... 1<br>NO_ssid (STR,16) ..... "ACST AC TEST1"                                                                                                                                                                                                                      |
| select_network | <mode>    | Execute a motion in a certain mode (STA access, AP operation, and so on) (D) <ul style="list-style-type: none"> <li>● &lt;mode&gt; STA: 0   AP: 1</li> </ul> For example: [/DA16200/NET] # cli select_network 0 <ul style="list-style-type: none"> <li>● Implement STA access</li> </ul> * For a certain mode through the select_network CLI, execute the following tasks first: <ul style="list-style-type: none"> <li>● add_network (profile generation)</li> <li>● SSID generation through set_network</li> <li>● For AP operation, set up the frequency and country code values with command set_network</li> <li>● For Security, generate WPA or WEP key values with command set_network (option)</li> </ul> |
| add_network    | <mode>    | Generate a specific mode (STA, AP) Profile (access information table) (D)<br><mode>: 0(STA)   1(AP)<br>For example: [/DA16200/NET] # cli add_network 1 <ul style="list-style-type: none"> <li>● Generate a profile for AP Mode</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

## DA16200 Evaluation Kit

| CLI            | Parameter                       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------------|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| remove_network | <mode>                          | <p>Delete a certain mode (STA, AP) profile (D)</p> <p>&lt;mode&gt;: 0(STA)   1(AP)</p> <p>For example: [/DA16200/NET] # cli remove_network 1</p> <ul style="list-style-type: none"> <li>Delete a profile for AP Mode</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| set_network    | <mode><br><variable><br><value> | <p>Set parameter values for a specific mode (STA, AP) (B)</p> <p>&lt;mode&gt;: 0(STA)   1(AP)</p> <p>&lt;variable&gt;: a specific parameter</p> <ul style="list-style-type: none"> <li>ssid: [STA] Operation SSID for AP SSID / [AP] AP interface to be connected</li> <li>psk: passphrase or PSK values</li> <li>proto: for WPA use, set up the version (&lt;WPA(=WPA1)&gt;   &lt;RSN(=WPA2)&gt;   &lt;WPA RSN&gt;)</li> <li>key_mgmt: key management mode (&lt;NONE&gt;   &lt;WPA_PSK&gt;   &lt;WPA-EAP&gt;)</li> <li>pairwise: unicast data message encryption mode (&lt;TKIP&gt;   &lt;CCMP&gt;   &lt;TKIP CCMP&gt;)</li> <li>group: broadcast data message encryption mode (&lt;TKIP&gt;   &lt;CCMP&gt;   &lt;TKIP CCMP&gt;)</li> <li>wep_key#: WEP key (#:0~3) values</li> <li>wep_tx_keyidx: WEP key index to be used</li> <li>frequency: [AP] Operation Frequency (MHz)</li> <li>mode: Operation Mode &lt;0(STA)&gt;   &lt;2(AP)&gt;</li> <li>Wi-Fi_mode: &lt;0(BGN)&gt;   &lt;1(GN)&gt;   &lt;2(BG)&gt;   &lt;3(N)&gt;   &lt;4(G)&gt;   &lt;5(B)&gt;</li> <li>beacon_int: [AP] Beacon transport interval</li> <li>dtim_period: [AP] DTIM interval</li> <li>ap_power: [AP] Output Power (dBm)</li> <li>isolate: 'Isolate' Use (&lt;0(off)&gt;   &lt;1(on)&gt;)</li> <li>-disabled: automatic profiling prevented upon rebooting (&lt;0(off)&gt;   &lt;1(on)&gt;)</li> </ul> <p>&lt;value&gt;: settings for a certain variable</p> <p>For example: [/DA16200/NET] # cli set_network 1 ssid 'DA16200_AP'</p> <ul style="list-style-type: none"> <li>For DA16200 AP operation, SSID= DA16200_AP setting</li> </ul> <p>For example: [/DA16200/NET] # cli set_network 1 beacon_int 200</p> <ul style="list-style-type: none"> <li>For DA16200 AP operation, Beacon interval 20 ms setting</li> </ul> <p>For example: [/DA16200/NET] # cli set_network 0 key_mgmt WPA_PSK</p> <ul style="list-style-type: none"> <li>For DA16200 STA operation, access in the WPA PSK security mode</li> </ul> <p>* A profile needs to be generated with command add_network so that a profile can be set with command set_network (with no profile, 'FAIL')</p> |
| get_network    | <mode><br><variable>            | <p>Get specific parameter values for a specific mode (STA, AP) (C)</p> <p>&lt;mode&gt;: 0(STA)   1(AP)</p> <p>&lt;variable&gt;: a specific parameter</p> <p>For example: [/DA16200/NET] # cli set_network 0 ssid</p> <ul style="list-style-type: none"> <li>Inquiry of an object subject to DA16200 STA access ("TEST_BED_AP")</li> </ul> <p>For example: [/DA16200/NET] # cli set_network 1 psk</p> <ul style="list-style-type: none"> <li>For DA16200 AP operation, inquiry of the PSK password setting</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |



## DA16200 Evaluation Kit

| CLI     | Parameter | Description                                                                                                                                                                                                                                                                                                                                                      |
|---------|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| country | <value>   | Set a country related to channel operation (A)<br><value>: Country Code that meets ISO 3166-1 alpha-2 standards<br>Default: KR<br>For example: [/DA16200/NET] # cli country US<br><ul style="list-style-type: none"> <li>Set the Country Code to US</li> </ul> For example: [/DA16200/NET] # cli country<br><ul style="list-style-type: none"> <li>KR</li> </ul> |
| flush   | (none)    | For every interface (STA, AP), DA16200 deletes the Profile and closes DA16200 service operation (D)                                                                                                                                                                                                                                                              |

## 10.2.4 STA Commands

Table 5: CLI Commands on STA Mode

| Command        | Parameters       | Description                                                                                                                                                                                                                                                                                                                                                                                  |
|----------------|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| scan           | (none) or <freq> | Active scanning (Probe Request Broadcast) (D)<br>For <freq> inputs, it is possible to scan APs of a certain frequency range (MHz) only (option)<br>For example: [/DA16200/NET] # cli scan<br><ul style="list-style-type: none"> <li>Scans all channels that correspond to the current country setting</li> </ul>                                                                             |
| disconnect     | (none)           | Disconnect the accessed AP (D)<br>For example: [/DA16200/NET] # cli disconnect<br><ul style="list-style-type: none"> <li>OK (With no AP being accessed, 'FAIL')</li> </ul>                                                                                                                                                                                                                   |
| roam           | (none) or <oper> | Roaming On/Off and Roaming status inquiry (A)<br><oper> run: On   stop: Off<br>Default: Roaming Off<br>For example: [/DA16200/NET] # cli roam<br><ul style="list-style-type: none"> <li>Roaming = STOP, Threshold = -65</li> <li>Usage: cli roam [run/stop]</li> </ul> For example: [/DA16200/NET] # cli roam stop<br><ul style="list-style-type: none"> <li>Roaming function-off</li> </ul> |
| roam_threshold | <value>          | Roaming triggering RSSI value (dBm) setting (B)<br><value>: Roaming threshold RSSI (dBm)<br>Default: -65 (dBm)<br>For example: [/DA16200/NET] # cli roam_threshold -85<br><ul style="list-style-type: none"> <li>Set the roaming threshold to -85 dBm</li> </ul>                                                                                                                             |

## DA16200 Evaluation Kit

## 10.2.5 Soft-AP Commands

Table 6: CLI Commands on Soft-AP Mode

| Command        | Parameter | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ap             | <option>  | <p>AP interface beginning/closing/restarting (Applicable with no reboot after main info modification of AP interface SSID, PSK, and so forth) (D)</p> <p>&lt;option&gt;: start   stop   restart</p> <p>For example: [/DA16200/NET] # cli ap start</p> <ul style="list-style-type: none"> <li>AP interface initiating (If it is being operated, 'FAIL')</li> </ul> <p>For example: [/DA16200/NET] # cli ap stop</p> <ul style="list-style-type: none"> <li>AP interface closing (If not being operated, 'FAIL')</li> </ul> <p>For example: [/DA16200/NET] # cli set_network 1 ssid 'DA16200_AP2'</p> <p>For example: [/DA16200/NET] # cli ap restart</p> <ul style="list-style-type: none"> <li>Modify SSID of the interface of AP being operated</li> </ul> <p>For example: [/DA16200/NET] # cli set_network 1 pairwise TKIP</p> <p>For example: [/DA16200/NET] # cli ap restart</p> <ul style="list-style-type: none"> <li>Modify the AP interface encryption mode to TKIP</li> </ul> |
| ap_chan_switch | <Ch.>     | <p>Modify the AP interface operation channel (B)</p> <p>&lt;Ch.&gt;: AP operation channel (1~14) or frequency (MHz)</p> <p>For example: [/DA16200/NET] # cli ap_chan_switch 3</p> <ul style="list-style-type: none"> <li>Modify the AP interface channel to 3 (242 MHz)</li> </ul> <p>For example: [/DA16200/NET] # cli ap_chan_switch 11 2462</p> <ul style="list-style-type: none"> <li>Modify the AP interface channel to 11 (2462 MHz)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| ap_status      | (none)    | <p>Get main information about the interface at DA16200 (C)</p> <p>For example:</p> <pre>[/DA16200/NET] # cli ap_status state=ENABLED phy=fc9k_phy0 freq=2472 num_sta_non_erp=0 num_sta_no_short_slot_time=0 num_sta_no_short_preamble=0 olbc=0 num_sta_ht_no_gf=0 num_sta_no_ht=0 num_sta_ht_20_mhz=0 num_sta_ht40_intolerant=0 olbc_ht=0 ht_op_mode=0x0 cac_time_seconds=0 cac_time_l</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

## DA16200 Evaluation Kit

| Command        | Parameter                                                                                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------|--------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| all_sta        | (none)                                                                                     | <p>Output the list information of STA being accessed to the AP interface (C)</p> <p>For example:</p> <pre>[/DA16200/NET] # cli all_sta 50:77:05:DB:C4:3E flags=[AUTH] [ASSOC] [AUTHORIZED] [SHORT_PREAMBLE] [WMM aid=1 capability=0x431 listen_interval=10 mode = 802.11n timeout_next=0 rx_packets=632 tx_packets=9 rx_bytes=67451 tx_bytes=4767 connected_time=77 sta_count=1</pre>                                                                                                                                                                                                                               |
| deauthenticate | <addr>                                                                                     | <p>The deauthenticate message is transmitted to the access STA with a certain MAC address to cancel the access (D)</p> <p>&lt;addr&gt;: MAC address of the access STA</p> <p>For example: [/DA16200/NET] # cli deauthenticate aa:ff:01:00:00:00</p> <ul style="list-style-type: none"> <li>Transmit the de-authentication message to STA whose MAC address is AA:FF:01:00:00:00</li> </ul>                                                                                                                                                                                                                          |
| disassociate   | <addr>                                                                                     | <p>The disassociation message is transmitted to the access STA with a certain MAC address to cancel the access (D)</p> <p>&lt;addr&gt;: MAC address of the access STA</p> <p>For example: [/DA16200/NET] # cli disassociate aa:ff:01:00:00:00</p> <ul style="list-style-type: none"> <li>Transmit the disassociation message to STA whose MAC address is AA:FF:01:00:00:00</li> </ul>                                                                                                                                                                                                                               |
| wmm_enabled    | <value>                                                                                    | <p>WMM function availability setting and inquiry (A)</p> <p>&lt;value&gt;: On: 1   Off: 0</p> <p>Default: Off</p> <p>For example: [/DA16200/NET] # cli wmm_enabled 1</p> <ul style="list-style-type: none"> <li>Use the WMM function</li> </ul>                                                                                                                                                                                                                                                                                                                                                                     |
| wmm_ps_enabled | <value>                                                                                    | <p>WMM-PS function availability setting and inquiry (A)</p> <p>&lt;value&gt;: On: 1   Off: 0</p> <p>Default: Off</p> <p>For example: [/DA16200/NET] # cli wmm_ps_enabled 1</p> <ul style="list-style-type: none"> <li>Use the WMM-PS function</li> </ul>                                                                                                                                                                                                                                                                                                                                                            |
| wmm_params     | <target><br><category><br><AIFS><br><CWmin><br><CWmax><br><Burst (AP) or TxOP Limit (STA)> | <p>Set up details of DA16200 AP or STA's certain category WMM parameters (B)</p> <p>&lt;target&gt;: ap   sta</p> <p>&lt;category&gt;: be(best-effort)   bk(background)   vi(video)   vo(voice)</p> <p>For example: [/DA16200/NET] # cli wmm_params ap be 3 15 63 10</p> <ul style="list-style-type: none"> <li>For WMM AP's best-effort category, AIFS = 3, CWmin = 15, CWmax = 63, and Burst = 10</li> </ul> <p>For example: [/DA16200/NET] # cli wmm_params sta vo 4 7 15 60</p> <ul style="list-style-type: none"> <li>For WMM STA's voice category, AIFS = 4, CWmin = 7, CWmax = 15, TXOP_Limit = 60</li> </ul> |

## DA16200 Evaluation Kit

| Command           | Parameter        | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------------------|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| all_wmm           | (none)           | Inquiry of all parameters that can be set up by means of wmm_params CLI (C) (See example)<br>For example: [/DA16200/NET] # cli all_wmm                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| acl_mac           | <addr>           | Add the MAC address to the Access Control Management List (B)<br><addr>: AP MAC Address<br>For example: [/DA16200/NET] # cli acl_mac AA:FF:01:00:00:06<br><ul style="list-style-type: none"> <li>Add MAC address AA:FF:01:00:00:06 to ACL</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Acl               | <oper><br><addr> | Set up, delete, or inquire the use of ACL (A)<br><oper>: allow   deny   clear   delete (If none, inquire of it)<br><addr>: AP MAC Address (only when oper = "delete")<br>[/DA16200/NET] # cli acl [allow/deny/clear/delete mac_address]<br>For example: [/DA16200/NET] # cli acl<br>For example: [/DA16200/NET] # cli acl allow<br><ul style="list-style-type: none"> <li>Access allowed only for AP Lists in ACL</li> </ul> For example: [/DA16200/NET] # cli acl deny<br><ul style="list-style-type: none"> <li>Access denied only for AP Lists in ACL</li> </ul> For example: [/DA16200/NET] # cli acl clear<br><ul style="list-style-type: none"> <li>Entire ACL clear</li> </ul> For example: [/DA16200/NET] # cli delete aa:ff:01:00:00:08<br><ul style="list-style-type: none"> <li>Delete AA:FF:01:00:00:08 from ACL</li> </ul> |
| ap_max_inactivity | <value>          | If there is no data frame exchange of accessed STA during the time setting, disconnect the STA (A)<br><value>: inactivity timeout (sec)<br>Default: 300 (sec.)<br>For example: [/DA16200/NET] # cli ap_max_inactivity 600<br><ul style="list-style-type: none"> <li>Disconnect the access STA with no data frame exchange for 600 seconds</li> </ul> For example: [/DA16200/NET] # cli ap_max_inactivity 0<br><ul style="list-style-type: none"> <li>Uncheck data frame exchange of the accessed STA</li> </ul> For example: [/DA16200/NET] # cli ap_max_inactivity<br><ul style="list-style-type: none"> <li>Read ap_max_inactivity value</li> </ul>                                                                                                                                                                                   |
| ap_send_ka        | <value>          | A function to send 'keep-alive' NULL packets to the accessed STA at intervals of 30 seconds and check ACK receipts (A)<br><value>: On: 1   Off: 0<br><ul style="list-style-type: none"> <li>On: if the STA accessed to DA16200 AP interface goes out of coverage or is closed abnormally, the disconnect will occur after the 'ap_max_inactivity timeout' passes</li> <li>Off: if there is no constant data frame exchange with the STA accessed to DA16200 AP interface for ap_max_inactivity timeout, then disconnect.</li> </ul> Default: 0 (not used)<br>For example: [/DA16200/NET] # cli ap_send_ka 1<br><ul style="list-style-type: none"> <li>ap_send_ka=1</li> </ul>                                                                                                                                                           |

## DA16200 Evaluation Kit

| Command    | Parameter | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ap_rts     | <value>   | <p>For AP mode operation, set up the RTS Threshold value to be used (A)</p> <p>&lt;value&gt;: The standard for the size of packets that use the RTS Control Frame (bytes)</p> <p>Default: 2437 (bytes)</p> <p>For example: [/DA16200/NET] # cli ap_rts 1000</p> <ul style="list-style-type: none"> <li>Use RTS for transmission of 1000 bytes or larger frames</li> <li>ap_rts=1000</li> </ul> <p>For example: [/DA16200/NET] # cli ap_rts</p> <ul style="list-style-type: none"> <li>ap_rts=2437</li> </ul> |
| greenfield | <value>   | <p>Enable/Disable use of Greenfield</p> <p>&lt;value&gt;: On: 1   Off: 0</p> <p>If Greenfield is on, DA16200 uses 11n HT mode only. In that case, 11b, 11g info and STA access are not allowed</p> <p>Default: 0 (not used)</p> <p>For example: [/DA16200/NET] # cli greenfield 1</p> <ul style="list-style-type: none"> <li>Use the Greenfield function</li> <li>greenfield=1</li> </ul> <p>For example: [/DA16200/NET] # cli greenfield</p> <ul style="list-style-type: none"> <li>greenfield=0</li> </ul> |

## 10.2.6 Advanced Commands

Table 7: Advanced CLI Commands

| Command | Parameters | Description                                                                                                                                                                                        |
|---------|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| wps_pbc | (none)     | Run WPS PBC (Push Button Configuration)                                                                                                                                                            |
| wps_pin | <pin>      | <p>Run WPS PIN method</p> <p>&lt;pin&gt; pin code (any: generate a random code)</p> <p>For example: [/DA16200/NET] # cli wps_pin 27833513</p> <p>For example: [/DA16200/NET] # cli wps_pin any</p> |

## 10.3 MROM Commands

## 10.3.1 Common Commands

Table 8: Common Commands in MROM

| Command | Parameters       | Description                                             |
|---------|------------------|---------------------------------------------------------|
| !       | (none)           | None                                                    |
| reboot  | (none)<br>[mode] | <p>Reboot</p> <p>por: POR rebooting</p>                 |
| reset   | (none)           | Reset to the Bootloader prompt                          |
| ver     | (none)           | Display version of MaskRom                              |
| help /? | (none)           | Display help information for the corresponding category |
| boot    | [address]        | <p>booting</p> <p>address: booting address</p>          |

## DA16200 Evaluation Kit

## 10.3.2 Memory Access Commands

Table 8: Memory Access Commands in MROM

| Command | Parameters             | Description       |
|---------|------------------------|-------------------|
| brd     | [addr] [length]        | byte read memory  |
| bwr     | [addr] [data] [length] | byte write memory |
| wrd     | [addr] [length]        | word read memory  |
| wwr     | [addr] [data] [length] | word write memory |
| lrd     | [addr] [length]        | long read memory  |
| lwr     | [addr] [data] [length] | long write memory |

## 10.3.3 Download Commands

Table 8: Download Commands in MROM

| Command | Parameters                            | Description                                                                 |
|---------|---------------------------------------|-----------------------------------------------------------------------------|
| loady   | [addr] [sector_size] [format]<br>boot | Download image to SFLASH<br>boot: '0' address                               |
| ymodem  | [addr] [size]<br>sfdp                 | Download image to RAM<br>sfdp: download sfdp to 0xf80040 (retention memory) |

## 10.3.4 SFLASH Commands

Table 8: SFLASH Commands in MROM

| Command | Parameters            | Description                                                                       |
|---------|-----------------------|-----------------------------------------------------------------------------------|
| sflash  | [op] [start] [length] | Sflash access<br>op: read, write, erase<br>start: start address<br>length: length |

## 10.3.5 Secure Commands

Table 8: Secure Commands in MROM

| Command | Parameters                     | Description                                                                                      |
|---------|--------------------------------|--------------------------------------------------------------------------------------------------|
| sbrom   | [target] [bootaddress] [debug] | Secure boot command<br>target: sflash<br>boot address: 0 (boot) or a000(rtos)<br>debug: anything |
| socid   | (none)                         | Display socid(secure soc id)                                                                     |

## 10.3.6 Additional Commands

Table 8: Additional Commands in MROM

| Command | Parameters      | Description                  |
|---------|-----------------|------------------------------|
| bmcfg   | [op] [bootmode] | Boot mode config<br>Not used |

## DA16200 Evaluation Kit

| Command | Parameters                              | Description                                                                     |
|---------|-----------------------------------------|---------------------------------------------------------------------------------|
| oops    | [op] [value]...                         | Oops configuration<br>Not used                                                  |
| dbgt    | [op]<br>[op] [value0]...                | Debug mode configuration<br>Not used                                            |
| floady  | [addr] [sector_size] [format]<br>[boot] | Fast download image to sflash<br>Not used                                       |
| rs485   | [offset] [id]                           | Download image with rs485<br>Not used                                           |
| clock   | [new clock]                             | System clock setting                                                            |
| setsfl  | [mode]                                  | Select sflash<br>Mode: 0 (stacked sflash), 1 (external sflash)<br>Used '1' only |

## DA16200 Evaluation Kit

## 11 Firmware Update

The security features of DA16200 support Secure Boot, to avoid booting with fake or untrusted images and to protect against being hacked. The DA16200 SoC includes a security hardware block called CryptoCell-312 (CC312). With proper security keys and certificates installed (in OTP and images), the DA16200 can boot in a secure mode.

DA16200 requires three images. With a serial terminal tool, each image can be loaded individually into DA16200.

- <Bootloader image>: also known as Second Bootloader
  - DA16200\_[image\_type]-[vendor]-[major]-[minor]-[customer\_ver]\_[sflash\_model].img
    - [Image\_type]: Bootloader (BOOT), Main, or System library (SLIB)
    - [vendor]: Internal use by vendor
    - [major]: Major version
    - [minor]: Minor version or SDK patch version
    - [customer\_ver]: User-configurable customer version
    - [sflash\_model]: sflash model or type used
  - For example: DA16200\_BOOT\_GEN01-01-XXXXX\_IS25WP016D.img
- <System Library image>: includes RF drivers and libraries for DPM
  - For example: DA16200\_SLIB\_GEN01-01-XXXX-000000.img
- <Main image>: includes RTOS and applications
  - For example: DA16200\_RTOS\_GEN01-01-XXXX-000000.img

### 11.1 Flash MAP

DA16200 provides two images: #0 and #1. It is possible to use these regions for each image set and change the index of the booting image set. The default value of the Boot Index points to #0.

**Table 8: 2 MB Serial Flash Memory Map**

| Address     | Item                   | Size   |
|-------------|------------------------|--------|
| 0x0000_0000 | 2nd Bootloader         | 36 kB  |
| 0x0000_9000 | Boot Index             | 4 kB   |
| 0x0000_A000 | RTOS #0                | 924 kB |
| 0x000F_1000 | SLIB #0 (RamLib + TIM) | 52 kB  |
| 0x000F_E000 | RTOS #1                | 924 kB |
| 0x001E_5000 | SLIB #1 (RamLib + TIM) | 52 kB  |

**Table 9: 4 MB Serial Flash Memory Map**

| Address     | Item                   | Size    |
|-------------|------------------------|---------|
| 0x0000_0000 | 2nd Bootloader         | 36 kB   |
| 0x0000_9000 | Boot Index             | 4 kB    |
| 0x0000_A000 | RTOS #0                | 1536 kB |
| 0x0018_A000 | SLIB #0 (RamLib + TIM) | 64 kB   |
| 0x0020_0000 | RTOS #1                | 1536 kB |
| 0x0038_0000 | SLIB #1 (RamLib + TIM) | 64 kB   |



## DA16200 Evaluation Kit

## 11.2 OTP Lock Protection

To protect OTP and download firmware safely, lock the OTP before firmware download:

1. In MROM, select **macro**.
2. Select **mrom\_otp\_lock\_check.ttl**




Figure 40: Run Macro

3. See a message box that notifying the OTP lock is done.




Figure 41: OTP Locked

4. Download firmware safely.

## 11.3 Bootloader Image

<Bootloader image> is also known as the second bootloader, which is the first thing loaded into memory for a factory-created DUT (for example with an empty flash).

Know that this image has SFDP information, which is important sflash type information, so always load this image before other images are loaded.

## DA16200 Evaluation Kit

If you get a new SDK, then always load the <Bootloader image> first.

1. Power on the DA16200 board.
2. At the [/DA16200] prompt, type `reset` to go to the Mask ROM prompt [MROM]. See Figure 42.




Figure 42: Mask ROM

3. At the [MROM] prompt, type `loady boot`. See Figure 43.

```
[MROM] loady boot
Load Addr: 000f6684
To cancel a session, press Ctrl+X
Load Y-Modem (Load Offset:f6684)
CC
xyzModem - CRC mode, 7(SOH)/29(STX)/0(CAN) PKTs, 9 retries, err:Timed o
ut
Total Size = 0x00007070 = 28784 Bytes
[MROM]
```

Figure 43: Bootloader Prompt on Command Window

4. Choose menu **File > Transfer > YMODEM > Send** to select the image file for the **Bootloader**. See Figure 44.
  - For example: DA16200\_BOOT\_GEN01-01-XXXX-\_IS25WP016D.img
  - The result is printed at the end of the transfer  
Please ignore any messages like “err:..”




Figure 44: Load Image File

## DA16200 Evaluation Kit

### 11.4 System Library Image

The <System Library image> includes system libraries, RF drivers, and libraries to operate the DPM.

1. At the [MROM] prompt, type `loady f1000` to load a <System Library image> in boot index #0. See Figure 45.

#### NOTE

DA16200 has a different address based on Flash size and boot index.

The System Library address map register depends on the flash memory size. Currently, DA16200 EVK uses 2 MB SFLASH MAP even though there is SFLASH 4 MB memory on the module. Therefore, the address must be 0xf1000 for boot index 0 or 0x1e5000 for boot index 1. In this case, at the [MROM] prompt, type `loady f1000` or `loady 1e5000`

So, if a customer uses 4 MB SFLASH MAP for the application, the address must be 0x18a000 for boot index 0 or 0x380000 for boot index 1. In this case, at the [MROM] prompt, type `loady 18a000` for boot index #0 or `loady 380000` for boot index #1

For more details, please refer to DA16200 SDK Programmer Guide [2].

```
[MROM] loady f1000
Load Addr: 000f6684
To cancel a session, press Ctrl+X
Load Y-Modem (Load Offset:f6684)
CC
xyzModem - CRC mode, 3(SOH)/29(STX)/0(CAN) PKTs, 5 retries, err:Timed o
ut
Total Size = 0x000072a0 = 29344 Bytes
```

Figure 45: System Library Prompt on Command Window

2. Choose menu **File > Transfer > YMODEM > Send** to select the <System Library image> file. See Figure 46.
  - For example: DA16200\_SLIB\_GEN01-XX-YYYY-ZZZZZZ.img




Figure 46: Load Image File

## DA16200 Evaluation Kit

### 11.5 Main RTOS Image

This <Main image> contains RTOS, Wi-Fi libraries, and system/user applications.

1. At the [MROM] prompt, type `loady a000`. See [Figure 47](#).

#### NOTE

DA16200 has a different address based on flash size and boot index.

The System Library address map register depends on the flash memory size. Currently, DA16200 EVK uses 2 MB SFLASH MAP even though there is SFLASH 4 MB memory on the module. Therefore, the address must be 0xa000 for boot index 0 or 0xfe000 for boot index 1. In this case, at the [MROM] prompt, type `loady a000` or `loady fe000`.

So, if the customer uses a 4 MB SFLASH MAP for the application, the address must be 0xa000 for boot index 0 or 0x200000 for boot index 1. In this case, at the [MROM] prompt, type `loady a000` for boot index #0 or `loady 200000` for boot index #1.

For more details, please refer to DA16200 SDK Programmer Guide [\[2\]](#).

```
[MROM] loady a000
Load Addr: 000f6684
To cancel a session, press Ctrl+X
Load Y-Modem (Load Offset:f6684)
CC
xyzModem - CRC mode, 1(SOH)/828(STX)/0(CAN) PKTs, 7 retries, err:Timed out
Total Size = 0x000cee80 = 847488 Bytes
[MROM]
```

Figure 47: Main Image Prompt on Command Window

2. Choose menu **File > Transfer > YMODEM > Send** to select the <Main image> file. See [Figure 48](#).
  - For example: DA16200\_RTOS\_GEN01-XX-YYYY-ZZZZZZ.img




Figure 48: Load Image File

3. If the three images are loaded, then at the [MROM] prompt, type `boot` to boot your images.
4. Run `factory reset` as shown in [Figure 49](#).

## DA16200 Evaluation Kit

```

[/DA16200] # factory
FACTORY RESET [N/y/?] y

Start Factory-Reset ...

Rebooting....

>>> Network Interface (wlan0) : DOWN
[wpa_supplicant_event_disassoc] CTRL-EVENT-DISCONNECTED bssid=2c:4d:54
_generated=1

>>> P.TIM is relocated to RETMEM (0x20f835c0, 4)
[dpm_init_retmemory] DPM INIT CONFIGURATION(1)

DPM Wakeup source is 0x0

* DA16200 SDK Information
* -----
*
* - CPU Type : Cortex-M4 (80MHz)
* - OS Type : ThreadX 5.7
* - Serial Flash : 2 MB
* - SDK Version : V2.3.5.0 GEN
* - F/W Version : RTOS-GEN01-01-14709-000000
* : SLIB-GEN01-01-14709-000000
* - F/W Build Time : Jun 24 2021 13:07:35
* - Boot Index : 0
*

>>> Enable BOR circuit ...

System Mode : Station Only (0)
>>> DA16x Supp Ver2.7 - 2020_07
>>> MAC address (sta0) : d4:3d:39:10:dd:12
>>> sta0 interface add OK
>>> Start STA mode...

```

Figure 49: Factory Mode Prompt on Command Window

Now everything is done.

## DA16200 Evaluation Kit

## 11.6 Download Image with Script (Macro)

You can download all images automatically with the use of a script.

1. In the **Control** menu, select **Macro**.
2. In the **MACRO: Open macro** dialog window, choose a .ttl file. See Figure 50.




Figure 50: Load Macro

3. The download starts with the bootloader image. See Figure 51.




Figure 51: Download Bootloader

4. Download RTOS image. See Figure 52.

## DA16200 Evaluation Kit




Figure 52: Download RTOS Image

- Download the SLIB Image. See [Figure 53](#).




Figure 53: Download Slib Image

- DA16200 will boot automatically after all images are downloaded.



## DA16200 Evaluation Kit

## NOTE

TTL command references

send : Sends data.

Format : send <data1> <data2>....

sendln : Sends data with new-line.

Format : sendln <data1> <data2>....

waitln : Waits a line that contains string.

Format : waitln <string1> [<string2> ...]

mpause : Pauses.

Format : mpause <time>, milliseconds

getdir : Gets the current working directory for MACRO.

Format : getdir <strvar>

strconcat : Appends a string.

Format : strconcat <strvar> <string>

ymodemsend : Sends a file from the host with the YMODEM protocol.

Format : ymodemsend <filename>

## 11.7 SFDP Checking

SFDP information of SFLASH is added to the boot loader image. When the boot loader image loads into the DA16200, SFDP information is copied to the Retention Memory.

However, under certain conditions, the ROM of the DA16200 has the task to clear the contents of Retention Memory. If the SFDP information in the Retention Memory is deleted due to certain conditions, the bootloader image should be loaded again. In this case, we recommend that the **boot loader image** and the **other two image files** (RTOS and SLIB) are loaded again.

If the images load normally, then use command [/DA16200] # brd f80000 100 to check if the SFDP information is copied to the Retention Memory. See Figure 54.

Example code to read the Retention Memory and check if SFDP is alive:

- [/DA16200] # brd f80000 100



Figure 54: SFDP

## 11.8 Serial Flash Recovery

When the serial flash is replaced, the flash memory map is changed, or if you think that the flash memory is corrupted, then follow the steps below to re-initialize or recover sflash and check the process:

1. Boot DA16200.
2. At the [/DA16200] # prompt, run the command `reset`



## DA16200 Evaluation Kit

- At [MROM] prompt, run command `sflash info` to read serial flash information.

For example, SFLASH: ef601615

This is the flash product ID of W25Q32JW. See also the IDs below.

W25Q32JWSNIQ: ef601615

IS25WP016D: 9d701514

IS25LQ032B: 9d401615s


- Run command `ymodem sfdp`.
- In the `build\SBOOT\SFDP` folder, find the Flash SFDP file which is corresponding to Flash ID as W25Q32JW.bin.
- Run command [MROM] `sflash erase 0 200000` to erase the entire flash for recovery.

### NOTE

This command can take a long time to complete. Please wait until the [MROM] prompt appears again.

- Reload all images in the specified order for serial flash recovery.
  - [MROM] `loady boot`
  - [MROM] `loady f1000`
  - [MROM] `loady a000`
- Run command `boot` to boot DA16200. The image version is printed.
- Initialize NVRAM for Serial Flash Recovery with the following commands:

```
[/DA16200] #
[/DA16200] # nvram
[/DA16200/NVRAM] # nvedit erase sflash
[/DA16200/NVRAM] # nvedit clear
[/DA16200/NVRAM] # nvcfg update sflash
update , sflash completed
[/DA16200/NVRAM] # nvedit load sflash
nvedit , load completed
[/DA16200/NVRAM] #
```



```
[/DA16200] # nvr
Command-List is changed, "NVRAM"
[/DA16200/NVRAM] # nvedit erase sflash
[/DA16200/NVRAM] # nvedit clear
[/DA16200/NVRAM] # nvcfg update sflash
update , sflash completed
[/DA16200/NVRAM] # nvedit load sflash
nvedit , load completed
```

Figure 55: Initialize NVRAM

## 11.9 Serial Flash Recovery from Boot

If there are any memory conflicts during updating the image or errors while building the SDK, then it cannot run DA16200. In this case, you cannot do anything in the command window. You must force the DA16200 to enter boot mode:

- Use RTC\_PWR\_KEY to power off (move to OFF position):
  - Connect the two pins. Pin 17(F\_CLK) and pin 18(GND) in the header Pin (J3) of the external connector of EVK. See [Figure 56](#).

## DA16200 Evaluation Kit

- b. F\_CLK is connected to Pin 21 of the module connector.



Figure 56: Recovery Point in the EVK

2. Use RTC\_PWR\_KEY to power on (move to ON position):
  - a. Boot DA16200. Turn the power on when the two pins are connected.
  - b. Disconnect the two pins. Pin 17 (F\_CLK) and pin 18 (GND).
3. See the DA16200 go into the **BOOT** mode. See Figure 57.
4. At the [BOOT] # prompt, run command `reset`.
5. Do the steps in Section 11.8 from step 3.

```

[OOOPS Dump : c0f0]]
[[Hard Fault]]
--RTC Time : 00000000.00003693

Register-Dump
R0 : 00093990, R1 : 00000000, R2 : 020c7668, R3 : 000ccdc8
R4 : 000cb5a4, R5 : 000f7c84, R6 : 000f84b4, R7 : 00000000
R8 : 00000000, R9 : 00000000, R10 : 000cb5a4, R11 : 000f84b4
R12 : 0000063c, SP : 000cce48, LR : 00002ccf, PC : 0018ba2e
PSR : 61000000, EXC : ffffffff

Fault Status
SHCSR : 00000000, CFSR : 00080000, HFSR : 40000000
DFSR : 00000000, MMFAR : e000ed34, BFAR : e000ed38
AFSR : 00000000

FC9K SysInfo
SICS[0] = 04300000
SICS[1] = 00000000
SICS[2] = 00000000
SICS[3] = 00000000
SICS[4] = 00000000
SICS[5] = 01234de2

Stack
Stack-Dump (48)
[0x000cce48] : 000cce5c 0008d650 00000000 000f84f6 000f84f9 00000000 00092a98 00080778
[0x000cce68] : 00080748 000f84d8 00000176 000f84ba 000f84e9 000f84f3 00000000 00000000
[0x000cce88] : 00000000 000f84f6 000f84f9 00000000 000f8544 000f84ff 000f851b 00000000
[0x000cce88] : 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000
[0x000cce88] : 00000000 00000000 00010800 00040000 00000018 00000000 00080778 000f7c78
[0x000cce88] : 00000000 00000000 00000000 00183b69 000ccf38 000f7c78 000cb5a4 00000000

Thread: umac_fc9k
stack_ptr : 000ccef8
stack_base: 000cc790
stack_end : 000ccf8b
stack_high: 000cccf8
max_usage : 00000094
suspend : 00000000

Thread Stack (32)
[0x000cccf8] : 000cccf8 000f7c78 000cb5a4 00000000 00000000 00000000 00000000 00000010
[0x000ccf18] : 00000010 00000000 00000000 00091e40 00000006 0000265b 00003fa2 00093928
[0x000ccf38] : 00139414 00000000 00091e70 00000000 00000000 000cc790 00000000 00138a98
[0x000ccf58] : 000f7c78 00000000 00091e40 00080774 00080778 00003805 00000000 00000000
Image Code, CRC Failed (9fc87af6 - 09aa010e, 23200)!!
Boot Err: wrong image [40000000](01)

* FC1 FC9K MaskROM BootLoader
* Cortex-M4 (XTAL 40000 KHz, Sys 120000 KHz)
* Console Baud Rate : 0 (00000000)
* HW Version Num. : fc905010
* Build Option : RomALL
* RoSDK Date & Time : Mar 13 2019 13:05:45
* Build Date & Time : Mar 13 2019 13:11:24
* http://www.fc1.co.kr

[BOOT] #

```

Figure 57: Run with BOOT Mode

## DA16200 Evaluation Kit

### 11.10 Boot Index Change

To change the boot index, you must change the boot index number and then reboot. After the reboot is complete, verify that the version printed at boot and the **boot\_idx** values have changed.

The following console commands can change the boot index:

```

• boot_idx 0 // to boot with boot index 0
• boot_idx 1 // to boot with boot index 1
[/DA16200] # boot_idx 1 // or boot_idx_0
[/DA16200] # reboot

>>> Network Interface (wlan0) : DOWN
[wpasupplicant_event_disassoc] CTRL-EVENT-DISCONNECTED bssid=aa:ab:ac:ad:ae:af
reason=3 locally_generated=1
[wpasupplicant_ev_disassoc_fin] Disconnect event - remove keys
RaLIB is relocated to RETMEM (20f815c0, 564, 12904718, 12904718)
P.TIM is relocated to RETMEM (20f835c0, 3)
dpm_init_retmemory::316 DPM INIT CONFIGURATION(1)

Wakeup source is 0x0

* DA16200 SDK Information
* -----
*
* - CPU Type : Cortex-M4 (80 MHz)
* - OS Type : ThreadX 5.7
* - Serial Flash : 16 Mbits (2 MBytes)
* - SDK Type : Generic v1.0.0
* - F/W Version : RTOS-GEN01-01-7140-000000
* : SLIB-GEN01-01-7089-000000
* - F/W Build Time : Jul 5 2019 17:35:59
* - Boot Index : 1
*

```

### 11.11 MAC Address Checking

By default, a MAC address is programmed in the OTP. However, if for some reason there is no MAC address or it is cleared.

For example: [/DA16200] # setwlanmac aa:ff:00:00:00:00

At prompt [/DA16200] # type command getwlanmac to check where the MAC address was written. One of the following lines is displayed: MAC TYPE: OTP MAC or NVRAM MAC. See example:

```

[/DA16200] # getwlanmac

MAC TYPE: OTP MAC

WLAN0 - EC:9F:0D:9F:F9:34
WLAN1 - EC:9F:0D:9F:F9:35

```

#### NOTE

Each EVK should have a unique address, and the last number of address must be even.

## 12 Country Codes

Table 10: Country Codes

| Code | Country              | Code | Country        | Code | Country                  | Code | Country             |
|------|----------------------|------|----------------|------|--------------------------|------|---------------------|
| AD   | Andorra              | EC   | Ecuador        | LC   | Saint Lucia              | RE   | Reunion             |
| AE   | United Arab Emirates | EE   | Estonia        | LI   | Liechtenstein            | RO   | Romania             |
| AF   | Afghanistan          | EG   | Egypt          | LK   | Sri Lanka                | RS   | Serbia              |
| AI   | Anguilla             | ES   | Spain          | LS   | Lesotho                  | RU   | Russia              |
| AL   | Albania              | ET   | Ethiopia       | LT   | Lithuania                | RW   | Rwanda              |
| AM   | Armenia              | EU   | Europe         | LU   | Luxembourg               | SA   | Saudi               |
| AR   | Argentina            | FI   | Finland        | LV   | Latvia                   | SE   | Sweden              |
| AS   | Samoa                | FM   | Micronesia     | MA   | Morocco                  | SG   | Singapore           |
| AT   | Austria              | FR   | France         | MC   | Monaco                   | SI   | Slovenia            |
| AU   | Australia            | GA   | Gabon          | MD   | Moldova                  | SK   | Slovakia            |
| AW   | Aruba                | GB   | United Kingdom | ME   | Montenegro               | SN   | Senegal             |
| AZ   | Azerbaijan           | GD   | Grenada        | MF   | Saint Martin             | SR   | Suriname            |
| BA   | Bosnia               | GE   | Georgia        | MH   | Marshall Islands         | SV   | El Salvador         |
| BB   | Barbados             | GF   | French Guiana  | MK   | Macedonia                | SY   | Syria               |
| BD   | Bangladesh           | GH   | Ghana          | MN   | Mongolia                 | TC   | Turks Caicos        |
| BE   | Belgium              | GL   | Greenland      | MO   | Macao                    | TD   | Chad                |
| BF   | Burkina Faso         | GP   | Guadeloupe     | MP   | Northern Mariana Islands | TG   | Togo                |
| BG   | Bulgaria             | GR   | Greece         | MQ   | Martinique               | TH   | Thailand            |
| BH   | Bahrain              | GT   | Guatemala      | MR   | Mauritania               | TN   | Tunisia             |
| BL   | Barthelemy           | GU   | Guam           | MT   | Malta                    | TR   | Turkey              |
| BM   | Bermuda              | GY   | Guyana         | MU   | Mauritius                | TT   | Trinidad and Tobago |
| BN   | Brunei               | HK   | Hong Kong      | MV   | Maldives                 | TW   | Taiwan              |
| BO   | Bolivia              | HN   | Honduras       | MW   | Malawi                   | TZ   | Tanzania            |
| BR   | Brazil               | HR   | Croatia        | MX   | Mexico                   | UA   | Ukraine             |
| BS   | Bahamas              | HT   | Haiti          | MY   | Malaysia                 | UG   | Uganda              |
| BT   | Bhutan               | HU   | Hungary        | NG   | Nigeria                  | UK   | United Kingdom      |
| BY   | Belarus              | ID   | Indonesia      | NI   | Nicaragua                | US   | USA                 |
| BZ   | Belize               | IE   | Ireland        | NL   | Netherlands              | UY   | Uruguay             |
| CA   | Canada               | IL   | Israel         | NO   | Norway                   | UZ   | Uzbekistan          |
| CF   | Central Africa       | IN   | India          | NP   | Nepal                    | VA   | Vatican City        |

## DA16200 Evaluation Kit

| Code | Country          | Code | Country             | Code | Country                 | Code | Country                    |
|------|------------------|------|---------------------|------|-------------------------|------|----------------------------|
| CH   | Switzerland      | IR   | Iran                | NZ   | New Zealand             | VC   | St. Vincent and Grenadines |
| CI   | Ivory Coast      | IS   | Iceland             | OM   | Oman                    | VE   | Venezuela                  |
| CL   | Chile            | IT   | Italy               | PA   | Panama                  | VI   | Virgin Islands, US         |
| CN   | China            | JM   | Jamaica             | PE   | Peru                    | VN   | Vietnam                    |
| CO   | Colombia         | JO   | Jordan              | PF   | Polynesia               | VU   | Vanuatu                    |
| CR   | Costa Rica       | JP   | Japan               | PG   | Papua New Guinea        | WF   | Wallis and Futuna Islands  |
| CU   | Cuba             | KE   | Kenya               | PH   | Philippines             | WS   | Samoa                      |
| CX   | Christmas Island | KH   | Cambodia            | PK   | Pakistan                | YE   | Yemen                      |
| CY   | Cyprus           | KN   | St. Kitts and Nevis | PL   | Poland                  | YT   | Mayotte                    |
| CZ   | Czech            | KP   | North Korea         | PM   | St. Pierre and Miquelon | ZA   | South Africa               |
| DE   | Germany          | KR   | South Korea         | PR   | Puerto Rico             | ZW   | Zimbabwe                   |
| DK   | Denmark          | KW   | Kuwait              | PT   | Portugal                | ALL  | ALL                        |
| DM   | Dominica         | KY   | Cayman Islands      | PW   | Palau                   |      |                            |
| DO   | Dominican Rep    | KZ   | Kazakhstan          | PY   | Paraguay                |      |                            |
| DZ   | Algeria          | LB   | Lebanon             | QA   | Qatar                   |      |                            |

## Revision History

| Revision | Date        | Description                                                                                                                                     |
|----------|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| 2.1      | 24-Jun-2021 | Added a description of MROM commands.<br>Added description to use new SFLASH in Section 5                                                       |
| 2.0      | 09-Feb-2021 | Removed Section 7.5 Current Measurement with PRO-SB Power Meter and SmartSnippets                                                               |
| 1.9      | 07-Jan-2021 | Added OPT lock protection in Section 11.2                                                                                                       |
| 1.8      | 24-Jul-2020 | Small textual changes and updated figures based on SDK v2.1.1.0                                                                                 |
| 1.7      | 04-May-2020 | Updated figures based on EVK 7.0 revision                                                                                                       |
| 1.6      | 14-Nov-2019 | Small textual changes in updates done in version 1.5                                                                                            |
| 1.5      | 04-Nov-2019 | Added boot index configuration in Section 11.1, 11.3, 11.4, and 11.8                                                                            |
| 1.4      | 15-Oct-2019 | Updated Layout<br>Removed Draft status                                                                                                          |
| 1.3      | 14-Oct-2019 | Error correction at page 9, 10, 48 and 50<br>Added explanation to use 2MB SFLASH MAP and 4MB SFLASH MAP at page 45<br>Added reference at page 6 |
| 1.2      | 20-Sep-2019 | Error correction<br>Add detailed description for test<br>Section 4 added to show test sequence<br>Section 10, Section 11 moved to the end       |
| 1.1      | 23-Aug-2019 | Error correction                                                                                                                                |
| 1.0      | 17-Jul-2019 | Initial Version                                                                                                                                 |

## DA16200 Evaluation Kit

### Status Definitions

| Status                  | Definition                                                                                                                   |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------|
| DRAFT                   | The content of this document is under review and subject to formal approval, which may result in modifications or additions. |
| APPROVED<br>or unmarked | The content of this document has been approved for publication.                                                              |

### Disclaimer

Unless otherwise agreed in writing, the Dialog Semiconductor products (and any associated software) referred to in this document are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of a Dialog Semiconductor product (or associated software) can reasonably be expected to result in personal injury, death or severe property or environmental damage. Dialog Semiconductor and its suppliers accept no liability for inclusion and/or use of Dialog Semiconductor products (and any associated software) in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Information in this document is believed to be accurate and reliable. However, Dialog Semiconductor does not give any representations or warranties, express or implied, as to the accuracy or completeness of such information. Dialog Semiconductor furthermore takes no responsibility whatsoever for the content in this document if provided by any information source outside of Dialog Semiconductor.

Dialog Semiconductor reserves the right to change without notice the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications. Notwithstanding the foregoing, for any automotive grade version of the device, Dialog Semiconductor reserves the right to change the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications, in accordance with its standard automotive change notification process.

Applications, software, and semiconductor products described in this document are for illustrative purposes only. Dialog Semiconductor makes no representation or warranty that such applications, software and semiconductor products will be suitable for the specified use without further testing or modification. Unless otherwise agreed in writing, such testing or modification is the sole responsibility of the customer and Dialog Semiconductor excludes all liability in this respect.

Nothing in this document may be construed as a license for customer to use the Dialog Semiconductor products, software and applications referred to in this document. Such license must be separately sought by customer with Dialog Semiconductor.

All use of Dialog Semiconductor products, software and applications referred to in this document is subject to Dialog Semiconductor's [Standard Terms and Conditions of Sale](http://www.dialog-semiconductor.com), available on the company website ([www.dialog-semiconductor.com](http://www.dialog-semiconductor.com)) unless otherwise stated.

Dialog, Dialog Semiconductor and the Dialog logo are trademarks of Dialog Semiconductor Plc or its subsidiaries. All other product or service names and marks are the property of their respective owners.

© 2021 Dialog Semiconductor. All rights reserved.

### RoHS Compliance

Dialog Semiconductor's suppliers certify that its products are in compliance with the requirements of Directive 2011/65/EU of the European Parliament on the restriction of the use of certain hazardous substances in electrical and electronic equipment. RoHS certificates from our suppliers are available on request.

## Contacting Dialog Semiconductor

**United Kingdom (Headquarters)**  
Dialog Semiconductor (UK) LTD  
Phone: +44 1793 757700

**Germany**  
Dialog Semiconductor GmbH  
Phone: +49 7021 805-0

**The Netherlands**  
Dialog Semiconductor B.V.  
Phone: +31 73 640 8822

**Email:**  
[enquiry@diasemi.com](mailto:enquiry@diasemi.com)

**North America**  
Dialog Semiconductor Inc.  
Phone: +1 408 845 8500

**Japan**  
Dialog Semiconductor K. K.  
Phone: +81 3 5769 5100

**Taiwan**  
Dialog Semiconductor Taiwan  
Phone: +886 281 786 222

**Web site:**  
[www.dialog-semiconductor.com](http://www.dialog-semiconductor.com)

**Hong Kong**  
Dialog Semiconductor Hong Kong  
Phone: +852 2607 4271

**Korea**  
Dialog Semiconductor Korea  
Phone: +82 2 3469 8200

**China (Shenzhen)**  
Dialog Semiconductor China  
Phone: +86 755 2981 3669

**China (Shanghai)**  
Dialog Semiconductor China  
Phone: +86 21 5424 9058