



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

---

# **RMS CAN Protocol**

**Revision 3.9**



## Table of Contents

|           |   |           |
|-----------|---|-----------|
| <b>1.</b> | <b>INTRODUCTION.....</b>                          | <b>3</b>  |
| 1.1       | CAN EEPROM PARAMETERS OVERVIEW .....              | 3         |
| 1.2       | CAN DIAGNOSTIC PARAMETERS OVERVIEW.....           | 7         |
| 1.3       | CAN FORMAT .....                                  | 10        |
| 1.4       | DATA FORMATS .....                                | 11        |
| 1.5       | CAN DATABASE FILE .....                           | 12        |
| <b>2.</b> | <b>CAN MESSAGES .....</b>                         | <b>13</b> |
| 2.1       | BROADCAST MESSAGES .....                          | 13        |
| 2.2       | COMMAND MESSAGE.....                              | 25        |
| 2.2.1     | <i>Inverter Enable Safety Options.....</i>        | <i>26</i> |
| 2.2.2     | <i>CAN Message Sequence Example .....</i>         | <i>27</i> |
| 2.2.3     | <i>Sign Convention for Torque and Speed .....</i> | <i>29</i> |
| 2.3       | PARAMETER MESSAGES .....                          | 30        |
| 2.3.1.    | <i>Parameter Message Format.....</i>              | <i>31</i> |
| 2.3.2.    | <i>Parameter Address Ranges .....</i>             | <i>31</i> |
| 2.3.3.    | <i>Command Parameters.....</i>                    | <i>32</i> |
| 2.3.4.    | <i>EEPROM Parameters.....</i>                     | <i>33</i> |
|           | <b>REVISION HISTORY .....</b>                     | <b>46</b> |



## 1. Introduction

This document defines the CAN protocol used by the RMS PM controllers.

The PM controllers have two CAN interfaces (CAN A and CAN B). The controller is configured to communicate only over CAN A, currently CAN B is reserved for future use.

The CAN interface has multiple purposes:

- Direct control of the motor
- Adjust EEPROM parameters
- Diagnostics and monitoring

### 1.1 CAN EEPROM Parameters Overview

RMS CAN communication is set up with a default rate of 250 K baud. The available baud rates include 125K, 250K, 500K, and 1M. The terminator resistor is available and active by default. RMS CAN is configurable through parameters that are available through the RMS GUI<sup>1</sup> application as well as CAN. GUI parameters have the same name as mentioned in this document with the exception that they end with the keyword “EEPROM”. Following parameters are used to configure RMS CAN:

- **Inverter Command Mode:**

This parameter gives the option to operate PM controller unit in either VSM mode or CAN mode. In VSM mode, RMS GUI is the main interface to monitor and modify parameters. The inverter takes messages from the Vehicle State Machine which is operated from the various inputs and outputs of the inverter such brake, accelerator pedal, etc. In VSM mode, broadcast messages are still sent out over the CAN lines. In CAN mode, both GUI and CAN interfaces are active and can be used to monitor and modify parameters. However, any inputs from the vehicle state machine will be ignored.

0 = CAN Mode

1 = VSM Mode (Default)

- **CAN ID Offset:**

---

<sup>1</sup> Please refer to the document “Programming EEPROM Parameters using GUI”.



This parameter allows the user to choose their own set of contiguous CAN message identifiers starting with the value in CAN ID Offset. This offset covers a range of 0 – 0x7C0. The default offset is 0x0A0. The default range is 0x0A0 – 0x0CF. This feature is especially useful when there are more than one PM controllers on the same CAN network. While setting base address for a controller, it must be made sure that the address range for controllers does not contain overlapping addresses.

- **CAN Extended Message Identifier**

This parameter allows switching between CAN standard and extended message identifiers.

- 0 = Standard CAN Messages (11-bit identifiers)
- 1 = Extended CAN Messages (29-bit identifiers)

- **CAN J1939 Option Active**

This parameter allows switching to J1939 format in extended mode. This parameter works in conjunction with 'CAN Extended Message Identifier' parameter above.

- 0 = Extended CAN Messages (if CAN Extended Message Identifier is set to 1, otherwise it will be standard messaging).
- 1 = Extended CAN Messages in SAE J1939 Format

RMS provides a limited functionality for J1939 protocol with the following fixed parameters:

|                |                        |
|----------------|------------------------|
| Priority       | = 3 (011b)             |
| Data Page      | = 0                    |
| PDU Format     | = 0xFF                 |
| PDU Specific   | = <b>CAN ID Offset</b> |
| Source Address | = 0x01                 |

For example, if CAN ID Offset is set to 0xA0, the J1939 CAN message will be broadcast as 0xCFFA001 and so on. The heartbeat command message should be sent out as 0xCFFA000, where the source address of the sending node is assumed to be 0x00.

Please refer to the section, *1.3 CAN Format* to learn about how to send out a torque or a speed command using the heartbeat command message.



- **CAN Term. Resistor Present:**

In order to use CAN communication, the CAN bus needs to be terminated with a 120 Ohm resistor. RMS PM controller units are equipped with this resistor which is activated through this parameter.

0 = Term. Resistor not active

1 = Term. Resistor active (Default)

If CAN Terminator Resistor is deactivated, it may be necessary to use the GUI interface only<sup>2</sup> since CAN communication may fail without a terminator resistor.

- **CAN Command Message Active:**

RMS CAN requires a “heartbeat” command message to be sent at least once every half a second. This command message controls the inverter, motor direction, and torque or speed. In the absence of a regular broadcast of this message, PM controller will assume there is a problem and will flag a fault unless the fault has been deactivated by setting this parameter to 0.

0 = The command message 0xC0 is **not** sent at least once in half a second.

1 = The command message 0xC0 is sent once every half a second (Default)

- **CAN Bit Rate:**

250Kbps is the default bit rate. Bus speed can be changed using CAN parameter command message. However, changing this parameter requires a power reset on PM controller unit since bus speed is setup only at the initialization of CAN modules in the microcontroller. Also, this input is restricted to valid baud rates. The 4 options for valid baud rate are:

|      |                      |
|------|----------------------|
| 125  | = 125Kbps            |
| 250  | = 250 Kbps (Default) |
| 500  | = 500 Kbps           |
| 1000 | = 1Mbps              |

---

<sup>2</sup> Please refer to the document “Programming EEPROM Parameters using GUI”.



- **CAN Active Messages Word:**

This parameter is used to enable/disable CAN Broadcast Messages<sup>3</sup>. This parameter is represented as two parameters, CAN Active Messages (Low Word) and CAN Active Messages (High Word) in RMS GUI. Each bit represents a CAN Message broadcast status as follows:

0 = CAN Messages broadcast disabled

1 = CAN Message broadcast enabled (Default)

Please refer to the table of CAN Broadcast Messages in section 2.1 for details on how to enable/disable each message.

- **CAN Diagnostic Data Transmit Active:**

This parameter is used to enable/disable the broadcast of the diagnostic data.

0 = CAN Diagnostic Data broadcast disabled

1 = CAN Diagnostic Data broadcast enabled (Default)

Please refer to the document, CAN Diagnostic Data, for more details on this feature.

- **CAN Inverter Enable Switch Active:**

This parameter is used in CAN mode only.

1 = DIN1 digital input is taken into consideration and the inverter will only be enabled if both DIN1 and inverter command are active. If either one is inactive, the inverter will be disabled.

0 = DIN1 will have no effect on enabling or disabling the inverter (Default)

- **CAN Timeout:**

This parameter is used in CAN mode only. This parameter is set as a multiple of 3 msec. For example, the default value is set to 333 which is equivalent to the actual timeout value of 1 second (333 x 3msec). This parameter delays setting the CAN Timeout fault for the amount of time it represents.

---

<sup>3</sup> Please refer to the section 2.1 - Broadcast Messages.



## 1.2 CAN Diagnostic Parameters Overview

RMS CAN communication also provides a couple of diagnostic parameters that can be monitored through the GUI. These parameters are shadow parameters of the actual CAN Error and Status register.

- **CAN Status Register:**

The Status register is displayed in real time in the GUI. This is a shadow byte that reflects the actual CAN register. This shadow register is updated every 3 msec.

| CAN Status Word | Description  |
|-----------------|--|
| 0x0001          | <b>Transmit Mode (TM):</b><br>The CAN module is in transmit mode. This bit reflects what the CAN module is actually doing regardless of mailbox configuration.<br>1: The CAN module is transmitting a message<br>0: The CAN module is not transmitting a message   |
| 0x0002          | <b>Receive Mode (RM):</b><br>The CAN module is in receive mode. This bit reflects what the CAN module is actually doing regardless of mailbox configuration.<br>1: The CAN module is receiving a message<br>0: The CAN module is not receiving a message   |
| 0x0004          | <b>Power Down Acknowledge (PDA):</b><br>1: The CAN module has entered the power-down mode<br>0: Normal operation   |
| 0x0008          | <b>Change Configuration Enable (CCE):</b><br>This bit displays the configuration access right. This bit is set after a latency of one clock cycle.<br>1: The CPU has write access to the configuration registers<br>0: The CPU is denied write access to the configuration registers   |
| 0x0010          | <b>Suspend Mode Acknowledge (SMA):</b><br>This bit is set after a latency of one clock cycle—up to the length of one frame—after the suspend mode was activated. The suspend mode is activated with the debugger tool when the circuit is not in run mode.<br>1: The module has entered suspend mode<br>0: The module is not in suspend mode |
| 0x0020          | <b>Warning Status (EW):</b><br>1: One of the two error counters (CANREC or CANTEC) has reached the warning level of 96.<br>0: Values of both error counters (CANREC and CANTEC) are less than 96.  |
| 0x0040          | <b>Error Passive (EP):</b><br>1: CAN module is in error-passive mode. CANTEC has reached 128<br>0: The CAN module is in error-active mode  |



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

---

|        |   |
|--------|---|
| 0x0080 | <p><b>Buss Off (BO):</b></p> <p>The CAN module is in bus-off state.</p> <p>1: There is an abnormal rate of errors on the CAN bus. This condition occurs when the transmit error counter (CANTEC) has reached the limit of 256. During Bus Off, no messages can be received or transmitted. The bus-off state can be exit by clearing the CCR bit in CANMC register or if the Auto Bus On (ABO) (CANMC.7) bit is set after 128 * 11 receive bits have been received. After leaving Bus Off, the error counters are cleared.</p> <p>0: Normal operation</p> |
|--------|---|





- **CAN Fault Register:**

The Faults register is also a shadow register. However, once a CAN fault occurs, shadow register will continue to display it through the GUI. The shadow faults can be cleared by setting Clear Fault Command to 0<sup>4</sup>.

| CAN Faults Word | Description  |
|-----------------|--|
| 0x01            | <b>Acknowledge Error (ACKE):</b><br>1: The CAN module received no acknowledge<br>0: All messages have been correctly acknowledged  |
| 0x02            | <b>Stuff Error (SE):</b><br>1: A stuff bit error occurred.<br>0: No stuff bit error occurred.  |
| 0x04            | <b>Cyclic Redundancy Check Error (CRCE):</b><br>1: The CAN module received a wrong CRC.<br>0: The CAN module never received a wrong CRC.   |
| 0x08            | <b>Stuck at Dominant 1 Error (SA1):</b><br>The SA1 bit is always at 1 after a hardware reset, a software reset, or a Bus-Off condition. This bit is cleared when a recessive bit is detected on the bus.<br>1: The CAN module never detected a recessive bit.<br>0: The CAN module detected a recessive bit. |
| 0x10            | <b>Bit Error (BE):</b><br>1: The received bit does not match the transmitted bit outside of the arbitration field or during transmission of the arbitration field, a dominant bit was sent but a recessive bit was received.<br>0: No bit error detected.  |
| 0x20            | <b>Form Error (FE):</b><br>1: A form error occurred on the bus. This means that one or more of the fixed-form bit fields had the wrong level on the bus.<br>0: No form error detected; the CAN module was able to send and receive correctly.  |

---

<sup>4</sup> Please refer to "RMS PM Software User Manual" section 11.6.2 – Clear Faults Command.



### 1.3 CAN Format

The CAN protocol conforms to CAN 2.0A (11 bit identifiers) as well as CAN 2.0B (29 bit identifiers)<sup>5</sup>. CAN Messages are transmitted at a default rate of 250kbps<sup>6</sup>. All messages have a data length code (DLC) of 8 bytes and follow little-endian format which implies that the least significant byte is stored at the lowest address. For example, if the command message is setup to turn the inverter on in CAN Speed mode with a speed command of 500 RPM the data bytes should look like this:

| Data Byte 0 | Data Byte 1 | Data Byte 2 | Data Byte 3 | Data Byte 4 | Data Byte 5 | Data Byte 6 | Data Byte 7 |
|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| 44          | 1           | 244         | 1           | 0           | 1           | 0           | 0           |

- Torque Command: Sent as a value in N.m. times 10.  
For example, 30 Nm should be entered as  $300 = (1 \times 256) + 44$ 
  - Data Byte 0 = 44 (Low byte)
  - Data Byte 1 = 1 (High byte)
- Speed Command: Sent as a value in RPM.  
For example, 500 RPM is entered as  $500 = (1 \times 256) + 244$ 
  - Data Byte 2 = 244 (Low byte)
  - Data Byte 3 = 1 (High byte)
- Direction Command
  - Data Byte 4 = 0 (Clockwise = Reverse)
  - Data Byte 4 = 1 (Anticlockwise = Forward)
- Inverter Run Command
  - Data Byte 5 = 0 (Disable Inverter)
  - Data Byte 5 = 1 (Enable Inverter)

Each data frame is 89 bits long thus at 250kbps the bus can handle a maximum of 2808 messages per second.

<sup>5</sup> Please refer to "CAN Extended Message Identifier" in section 1 - Introduction.

<sup>6</sup> Please refer to "CAN Bit Rate" in section 1 - Introduction.



## 1.4 Data Formats

Each message contains one or more items. Each item is formatted and scaled per the definitions below:

| Format                      | Description   | Range                          |
|-----------------------------|---|--------------------------------|
| Temperature                 | Signed integer,<br>actual temperature (in °C) times 10  | -3276.8 to +3276.7 °C          |
| Low Voltage                 | Signed integer,<br>actual voltage (in Volts) times 100  | -327.68 to +327.67 volts       |
| Torque                      | Signed integer,<br>actual torque (in N.m) times 10  | -3276.8 to +3276.7 N-m         |
| High Voltage                | Signed integer,<br>actual voltage (in Volts) times 10   | -3276.8 to +3276.7 volts       |
| Current                     | Signed Integer,<br>actual current (in Amps) times 10  | -3276.8 to +3276.7 amps        |
| Angle                       | Signed integer,<br>actual angle (in degrees) times 10   | 0.0 to ±359.9 degrees          |
| Angular velocity<br>(Speed) | Signed integer,<br>actual velocity (in RPM)   | -32768 to +32767 rpm           |
| Boolean                     | Unsigned byte,<br>1 = true/on, 0 = false/off  | 0 or 1                         |
| Frequency                   | Signed integer,<br>actual frequency (in Hz) times 10  | -3276.8 to +3276.7 Hz          |
| Power                       | Signed integer,<br>actual power (in kW) times 10  | -3276.8 to +3276.7 kW          |
| Time                        | Unsigned long integer or Unsigned integer.<br>These are scaled values in counts that can be calculated by using their respective Scale Factors. For each Scale Factor, see the description column for that parameter. | NA                             |
| Flux                        | Signed integer,<br>actual flux (in Webers) times 1000   | -32.768 to 32.767 Webers       |
| Proportional Gain           | Unsigned integer,<br>actual gain (unit-less) times 100 OR<br>actual gain (unit-less) times 10000  | 0 – 655.35<br>OR<br>0 – 6.5535 |
| Integral Gain               | Unsigned integer,<br>Actual gain (unit-less) times 10000  | 0 – 6.5535                     |
| Derivative Gain             | Unsigned integer,<br>actual gain (unit-less) times 100  | 0 – 655.35                     |
| Low-pass Filter Gain        | Unsigned integer,<br>Actual gain (unit-less) times 10000  | 0 – 6.5535                     |
| Per-unit Value              | These are scaled values that can be calculated by using their respective Scale Factors. For each Scale Factor, see the description column for that parameter.   | NA                             |
| ADC Count                   | The value for ADC counts as read directly by the registers of a microcontroller.  | 0 - 4095                       |



## 1.5 CAN Database File

Each firmware is provided with a specific CAN database file. The database file can be matched with the firmware file through the date code in *yyyymmdd* format. The database file is located under “Firmware” folder. It also located under “Tools\CAN Tools” folder of the RMS online repository with box.net.

A CAN database file stores information for a given CAN network. For example, it includes information about CAN nodes, messages, and data bytes for each message. A CAN database file has a .dbc extension and can be used with several CAN data loggers such CANTrace, CANalyzer, CANoe, etc to log CAN data.

This file can also be edited by the user with his/her choice of a CAN database editor. RMS has used Kvaser’s Database Editor (DbEdit) to create and edit the CAN database file. Kvaser’s DbEdit tool can be downloaded using the following link:

[http://www.kvaser.com/index.php?option=com\\_php&Itemid=288&lang=&swprod=1cf9896f527dc55dc8a219a048c6c149&ean=7330130003514](http://www.kvaser.com/index.php?option=com_php&Itemid=288&lang=&swprod=1cf9896f527dc55dc8a219a048c6c149&ean=7330130003514)

The user guide for Kvaser’s database editor can be directly downloaded using the following link:

[www.kvaser.cn/support/pdf/kvaser\\_database\\_editor\\_users\\_manual.pdf](http://www.kvaser.cn/support/pdf/kvaser_database_editor_users_manual.pdf)



## 2. CAN Messages

### 2.1 Broadcast Messages

Broadcast messages are sent by the PM controller continuously irrespective of VSM or CAN command mode. The table below shows the messages that are broadcast and the frequency at which they are sent. The addresses below are default addresses and can be changed using the Read/Write Parameter Command message (see section Parameter Messages). This would be specifically useful in case of more than one PM controller units on a CAN network. While setting base address for a controller, it must be made sure that the address range for controllers does not contain overlapping addresses.

A parameter 'CAN Active Messages Word' with parameter address 148 is defined to enable/disable CAN Broadcast Messages. This is a 32-bit parameter that is further divided into two 16-bit parameters, CAN Active Messages Low Word and CAN Active Messages High Word. Each bit in this parameter represents a CAN Message broadcast status as follows:

0 = CAN Messages broadcast disabled

1 = CAN Message broadcast enabled

The controller broadcasts the following messages:

| Address | Frequency | Content  | CAN Active Messages (High Word) | CAN Active Messages (Low Word) |
|---------|-----------|--|---------------------------------|--------------------------------|
| 0x0A0   | 10 Hz     | Temperatures #1                                      | 0x0000                          | 0x0001                         |
| 0x0A1   | 10 Hz     | Temperatures #2                                      | 0x0000                          | 0x0002                         |
| 0x0A2   | 10 Hz     | Temperatures #3                                      | 0x0000                          | 0x0004                         |
| 0x0A3   | 100 Hz    | Analog Inputs Voltages                               | 0x0000                          | 0x0008                         |
| 0x0A4   | 100 Hz    | Digital Input Status                                 | 0x0000                          | 0x0010                         |
| 0x0A5   | 100 Hz    | Motor Position Information                           | 0x0000                          | 0x0020                         |
| 0x0A6   | 100 Hz    | Current Information                                  | 0x0000                          | 0x0040                         |
| 0x0A7   | 100 Hz    | Voltage Information                                  | 0x0000                          | 0x0080                         |
| 0x0A8   | 100 Hz    | Flux Information                                     | 0x0000                          | 0x0100                         |
| 0x0A9   | 10 Hz     | Internal Voltages                                    | 0x0000                          | 0x0200                         |
| 0x0AA   | 10 Hz     | Internal States                                      | 0x0000                          | 0x0400                         |
| 0x0AB   | 10 Hz     | Fault Codes  | 0x0000                          | 0x0800                         |
| 0x0AC   | 100 Hz    | Torque & Timer Information                           | 0x0000                          | 0x1000                         |
| 0x0AD   | 100 Hz    | Modulation Index & Flux Weakening Output Information | 0x0000                          | 0x2000                         |
| 0x0AE   | 10 Hz     | Firmware Information                                 | 0x0000                          | 0x4000                         |
| 0x0AF   | 100 Hz    | Diagnostic Data                                      | 0x0000                          | 0x8000                         |



All of the above messages are in standard 11-bit format. The addresses in extended 29-bit and J1939 format are listed below:

| Standard 11-bit Format | Extended 29-bit Format | J1939 Format |
|------------------------|------------------------|--------------|
| 0x0A0                  | 0x0A0 X                | 0x0CFFA001   |
| 0x0A1                  | 0x0A1 X                | 0x0CFFA101   |
| 0x0A2                  | 0x0A2 X                | 0x0CFFA201   |
| 0x0A3                  | 0x0A3 X                | 0x0CFFA301   |
| 0x0A4                  | 0x0A4 X                | 0x0CFFA401   |
| 0x0A5                  | 0x0A5 X                | 0x0CFFA501   |
| 0x0A6                  | 0x0A6 X                | 0x0CFFA601   |
| 0x0A7                  | 0x0A7 X                | 0x0CFFA701   |
| 0x0A8                  | 0x0A8 X                | 0x0CFFA801   |
| 0x0A9                  | 0x0A9 X                | 0x0CFFA901   |
| 0x0AA                  | 0x0AA X                | 0x0CFFAA01   |
| 0x0AB                  | 0x0AB X                | 0x0CFFAB01   |
| 0x0AC                  | 0x0AC X                | 0x0CFFAC01   |
| 0x0AD                  | 0x0AD X                | 0x0CFFAD01   |
| 0x0AE                  | 0x0AE X                | 0x0CFFAE01   |
| 0x0AF                  | 0x0AF X                | 0x0CFFAF01   |

Extended format is often denoted by the letter 'X'. However, based on the CAN logger, this format may be represented differently. Please refer to the manual for the CAN logger that is used.

J1939 messages have the following fixed configuration:

- Priority = 3
- PDU Format = 0xFF
- PDU Specific = CAN ID Offset EEPROM
- Source Address = 1



## Enabling/Disabling Broadcast of CAN Messages

As an example, in order to disable Temperature #1, #2 and #3 messages in the above table, the parameter command message should be configured as follows:

| Data Byte 7<br>(Low Byte)     | Data Byte 6<br>(Low Byte) | Data Byte 5<br>(High Byte)   | Data Byte 4<br>(Low Byte) | Data Byte 3 | Data Byte 2 | Data Byte 1       | Data Byte 0 |
|-------------------------------|---------------------------|------------------------------|---------------------------|-------------|-------------|-------------------|-------------|
| CAN Active Messages High Word |                           | CAN Active Messages Low Word |                           | Reserved    | R/W Command | Parameter Address |             |
| 255<br>(0xFF)                 | 255<br>(0xFF)             | 255<br>(0xFF)                | 248<br>(0xF8)             | 0           | 1           | 0                 | 148         |

**Data Byte 4** controls the following messages:

Bit 0: Temperature #1  
Bit 1: Temperature #2  
Bit 2: Temperature #3  
Bit 3: Analog Input Voltages  
Bit 4: Digital Input Status  
Bit 5: Motor Position Information  
Bit 6: Current Information  
Bit 7: Voltage Information

In little-endian format, Byte 4 can be looked at as: Bit 7 - Bit 6 - Bit 5 - ... - Bit 1 - Bit 0

To enable all messages above, Byte 4 should be set to 0xFF (all bits set to 1).  
To disable temperature messages, Byte 4 should be set to 0xF8 (Bit 0, 1, and 2 are set to 0)  
To disable Motor position information, Byte 4 should be set to 0xDF (Bit 5 set to 0)

**Data Byte 5** controls the following messages:

Bit 0: Flux Information  
Bit 1: Internal Voltages  
Bit 2: Internal States  
Bit 3: Fault Codes  
Bit 4: Torque & Timer Information  
Bit 5: Not used  
Bit 6: Not used  
Bit 7: Not used



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

---

**Data Byte 6** has no messages assigned yet:

Bit 0: Not used  
Bit 1: Not used  
Bit 2: Not used  
Bit 3: Not used  
Bit 4: Not used  
Bit 5: Not used  
Bit 6: Not used  
Bit 7: Not used

**Data Byte 7** controls the following messages but user cannot disable any of those messages:

Bit 0: Not used  
Bit 1: Not used  
Bit 2: Not used  
Bit 3: Not used  
Bit 4: Not used  
Bit 5: Parameter Response Message  
Bit 6: Parameter Command Message  
Bit 7: CAN Command Message (Heartbeat command continuously broadcast)

**Note:**

Higher nibble of Data Byte 7 contains CAN Command Messages that should never be disabled. Hence, it will always return a hex value of Fx, where x can be any hex number between 0 and F (15).





## Broadcast Message Definitions

### 0x0A0 – Temperatures #1

| Byte # | Name                          | Format      | Description                         |
|--------|-------------------------------|-------------|-------------------------------------|
| 0,1    | Module A Temperature          | Temperature | Temperature of IGBT Module, Phase A |
| 2,3    | Module B Temperature          | Temperature | Temperature of IGBT Module, Phase B |
| 4,5    | Module C Temperature          | Temperature | Temperature of IGBT Module, Phase C |
| 6,7    | Gate Driver Board Temperature | Temperature | Temperature of Gate Driver Board    |

### 0x0A1 – Temperatures #2

| Byte # | Name                      | Format      | Description                                     |
|--------|---------------------------|-------------|---|
| 0,1    | Control Board Temperature | Temperature | Temperature of Control Board.                   |
| 2,3    | RTD #1 Temperature        | Temperature | Temperature read from RTD input #1              |
| 4,5    | RTD #2 Temperature        | Temperature | Temperature read from RTD Input #2              |
| 6,7    | RTD #3 Temperature        | Temperature | Temperature read from RTD Input #3, Gen 2 only. |

### 0x0A2 – Temperatures #3 & Torque Shudder

| Byte # | Name               | Format      | Description   |
|--------|--------------------|-------------|---|
| 0,1    | RTD #4 Temperature | Temperature | Temperature read from RTD Input #4, Gen 2 only                |
| 2,3    | RTD #5 Temperature | Temperature | Temperature read from RTD Input #5, Gen 2 only                |
| 4,5    | Motor Temperature  | Temperature | Filtered temperature value from the motor temperature sensor. |
| 6,7    | Torque Shudder     | Torque      | A value of torque used in shudder compensation.               |

### 0x0A3 – Analog Input Voltages

| Byte # | Name            | Format      | Description                |
|--------|-----------------|-------------|----------------------------|
| 0,1    | Analog Input #1 | Low Voltage | Voltage on Analog Input #1 |
| 2,3    | Analog Input #2 | Low Voltage | Voltage on Analog Input #2 |
| 4,5    | Analog Input #3 | Low Voltage | Voltage on Analog Input #3 |
| 6,7    | Analog Input #4 | Low Voltage | Voltage on Analog Input #4 |



#### 0x0A4 – Digital Input Status

| Byte # | Name             | Format  | Description                                      |
|--------|------------------|---------|--|
| 0      | Digital Input #1 | Boolean | Status of Digital Input #1, Forward switch       |
| 1      | Digital Input #2 | Boolean | Status of Digital Input #2, Reverse switch       |
| 2      | Digital Input #3 | Boolean | Status of Digital Input #3, Brake switch         |
| 3      | Digital Input #4 | Boolean | Status of Digital Input #4, REGEN Disable Switch |
| 4      | Digital Input #5 | Boolean | Status of Digital Input #5, Ignition switch      |
| 5      | Digital Input #6 | Boolean | Status of Digital Input #6, Start switch         |

#### 0x0A5 – Motor Position Information

| Byte # | Name                        | Format           | Description  |
|--------|-----------------------------|------------------|--|
| 0,1    | Motor Angle (Electrical)    | Angle            | The electrical angle of the motor as read by the encoder or resolver.  |
| 2,3    | Motor Speed                 | Angular velocity | The measured speed of the motor  |
| 4,5    | Electrical Output Frequency | Frequency        | The actual electrical frequency of the inverter.   |
| 6,7    | Delta Resolver Filtered     | Angle            | This is used in calibration of resolver angle adjustment. The range of this parameter is $\pm 180^\circ$ . Values between $180^\circ$ and $360^\circ$ are shown as negative angle. For example, $270^\circ$ is equal to $-90^\circ$ , and $190^\circ$ is equal to $-170^\circ$ . |

#### 0x0A6 – Current Information

| Byte # | Name            | Format  | Description                            |
|--------|-----------------|---------|--|
| 0,1    | Phase A Current | Current | The measured value of Phase A current. |
| 2,3    | Phase B Current | Current | The measured value of Phase B current  |
| 4,5    | Phase C Current | Current | The measured value of Phase C current  |
| 6,7    | DC Bus Current  | Current | The calculated DC Bus current.         |

#### 0x0A7 – Voltage Information

| Byte # | Name             | Format       | Description   |
|--------|------------------|--------------|---|
| 0,1    | DC Bus Voltage   | High Voltage | The actual measured value of the DC bus voltage.                        |
| 2,3    | Output Voltage   | High Voltage | The calculated value of the output voltage, in peak line-neutral volts. |
| 4,5    | Phase AB Voltage | High Voltage | Measured value of the voltage between Phase A and Phase B               |
| 6,7    | Phase BC Voltage | High Voltage | Measured value of the voltage between Phase B and Phase C               |



## 0xA8 – Flux Information

| Byte # | Name          | Format  | Description             |
|--------|---------------|---------|-------------------------|
| 0,1    | Flux command  | Flux    | The commanded flux      |
| 2,3    | Flux feedback | Flux    | The estimated flux      |
| 4,5    | Id feedback   | Current | D-axis current feedback |
| 6,7    | Iq feedback   | Current | Q-axis current feedback |

## 0x0A9 – Internal Voltages

| Byte # | Name                   | Format      | Description                       |
|--------|------------------------|-------------|-----------------------------------|
| 0,1    | 1.5V Reference voltage | Low Voltage | One of the low voltage references |
| 2,3    | 2.5V Reference voltage | Low Voltage | One of the low voltage references |
| 4,5    | 5.0V Reference voltage | Low Voltage | One of the low voltage references |
| 6,7    | 12V System voltage     | Low Voltage | One of the low voltage references |

## 0x0AA – Internal States

| Byte # | Name           | Format   | Description  |
|--------|----------------|----------|--|
| 0,1    | VSM State      | Internal | 0 = VSM Start State<br>1 = Pre-charge Init State<br>2 = Pre-charge Active State<br>3 = Pre-charge Complete State<br>4 = VSM Wait State<br>5 = VSM Ready State<br>6 = Motor Running State<br>7 = Blink Fault Code State<br><br>14 = Shutdown in Process – in key switch mode 1, user has turned the key switch to off position.<br><br>15 = Recycle Power State – user must recycle power when the unit is in this state. |
| 2      | Inverter State | Internal | 0 = Power on State<br>1 = Stop State<br>2 = Open Loop State<br>3 = Closed Loop State<br>4 = Wait State<br>5, 6, 7 = <i>Internal states</i><br>8 = Idle Run State<br>9 = Idle Stop State<br>10,11,12 = <i>Internal states</i>   |



|             |                                 |          |   |
|-------------|---------------------------------|----------|---|
| 3           | Relay State                     | Internal | Bit 0: Relay 1 Status<br>Bit 1: Relay 2 Status<br>Bit 2: Relay 3 Status<br>Bit 3: Relay 4 Status  |
| 4 – Bit0    | Inverter Run Mode               | Internal | 0 = Torque Mode<br>1 = Speed Mode   |
| 4 – Bits5-7 | Inverter Active Discharge State | Internal | Current Inverter Active Discharge State:<br>000 (0) = Discharge Disabled<br>001 (1) = Discharge Enabled, waiting<br>010 (2) = Performing Speed Check<br>011 (3) = Discharge Actively occurring<br>100 (4) = Discharge Completed<br>All other states are reserved for future use.  |
| 5           | Inverter Command Mode           | Internal | 0 = CAN Mode<br>1 = VSM Mode<br><br>When in CAN Mode the inverter takes commands from the CAN messages. When in VSM Mode the inverter takes messages from the Vehicle State Machine which is operated from the various input and outputs of the inverter.   |
| 6 - Bit0    | Inverter Enable State           | Internal | 0 = Inverter is disabled<br>1 = Inverter is enabled   |
| 6 – Bit7    | Inverter Enable Lockout         | Internal | 0 = Inverter can be enabled<br>1 = Inverter cannot be enabled<br><br>This feature is added so that the inverter cannot be accidentally enabled. This feature requires that before sending out an Inverter Enable command, the user must send out a Inverter Disable command. Once the inverter sees a Disable command, the lockout is removed and PM can receive the Inverter Enable command. |
| 7           | Direction Command               | Internal | 1 = Forward<br>0 = Reverse, if inverter is enabled<br>Stopped, if inverter is disabled  |

#### 0x0AB – Fault Codes

| Byte # | Name | Format | Description |
|--------|------|--------|-------------|
|--------|------|--------|-------------|



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

---

|     |               |          |                             |
|-----|---------------|----------|-----------------------------|
| 0,1 | POST Fault Lo | Internal | Each bit represents a fault |
| 2,3 | POST Fault Hi | Internal | Each bit represents a fault |
| 4,5 | Run Fault Lo  | Internal | Each bit represents a fault |
| 6,7 | Run Fault Hi  | Internal | Each bit represents a fault |



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

## POST Faults

| CAN Byte | CAN Bit | POST Fault                       | Fault Word | Byte Value |
|----------|---------|----------------------------------|------------|------------|
| Byte 0   | 0       | Hardware Gate/Desaturation Fault | 00000001   | 1          |
|          | 1       | HW Over-current Fault            | 00000002   | 2          |
|          | 2       | Accelerator Shorted              | 00000004   | 4          |
|          | 3       | Accelerator Open                 | 00000008   | 8          |
|          | 4       | Current Sensor Low               | 00000010   | 16         |
|          | 5       | Current Sensor High              | 00000020   | 32         |
|          | 6       | Module Temperature Low           | 00000040   | 64         |
|          | 7       | Module Temperature High          | 00000080   | 128        |
| Byte 1   | 8       | Control PCB Temperature Low      | 00000100   | 1          |
|          | 9       | Control PCB Temperature High     | 00000200   | 2          |
|          | 10      | Gate Drive PCB Temperature Low   | 00000400   | 4          |
|          | 11      | Gate Drive PCB Temperature High  | 00000800   | 8          |
|          | 12      | 5V Sense Voltage Low             | 00001000   | 16         |
|          | 13      | 5V Sense Voltage High            | 00002000   | 32         |
|          | 14      | 12V Sense Voltage Low            | 00004000   | 64         |
|          | 15      | 12V Sense Voltage High           | 00008000   | 128        |
| Byte 2   | 16      | 2.5V Sense Voltage Low           | 00010000   | 1          |
|          | 17      | 2.5V Sense Voltage High          | 00020000   | 2          |
|          | 18      | 1.5V Sense Voltage Low           | 00040000   | 4          |
|          | 19      | 1.5V Sense Voltage High          | 00080000   | 8          |
|          | 20      | DC Bus Voltage High              | 00100000   | 16         |
|          | 21      | DC Bus Voltage Low               | 00200000   | 32         |
|          | 22      | Pre-charge Timeout               | 00400000   | 64         |
|          | 23      | Pre-charge Voltage Failure       | 00800000   | 128        |
| Byte 3   | 24      | EEPROM Checksum Invalid          | 01000000   | 1          |
|          | 25      | EEPROM Data Out of Range         | 02000000   | 2          |
|          | 26      | EEPROM Update Required           | 04000000   | 4          |
|          | 27      | Reserved                         | 08000000   | 8          |
|          | 28      | Reserved                         | 10000000   | 16         |
|          | 29      | Reserved                         | 20000000   | 32         |
|          | 30      | Brake Shorted                    | 40000000   | 64         |
|          | 31      | Brake Open                       | 80000000   | 128        |



## RUN Faults

| CAN Byte | CAN Bit | RUN Fault  | Fault Word | Byte Value |
|----------|---------|--|------------|------------|
| Byte 4   | 32      | Motor Over-speed Fault                                 | 00000001   | 1          |
|          | 33      | Over-current Fault                                     | 00000002   | 2          |
|          | 34      | Over-voltage Fault                                     | 00000004   | 4          |
|          | 35      | Inverter Over-temperature Fault                        | 00000008   | 8          |
|          | 36      | Accelerator Input Shorted Fault                        | 00000010   | 16         |
|          | 37      | Accelerator Input Open Fault                           | 00000020   | 32         |
|          | 38      | Direction Command Fault                                | 00000040   | 64         |
|          | 39      | Inverter Response Time-out Fault                       | 00000080   | 128        |
| Byte 5   | 40      | Hardware Gate/Desaturation Fault                       | 00000100   | 1          |
|          | 41      | Hardware Over-current Fault                            | 00000200   | 2          |
|          | 42      | Under-voltage Fault                                    | 00000400   | 4          |
|          | 43      | CAN Command Message Lost Fault                         | 00000800   | 8          |
|          | 44      | Motor Over-temperature Fault                           | 00001000   | 16         |
|          | 45      | Reserved   | 00002000   | 32         |
|          | 46      | Reserved   | 00004000   | 64         |
|          | 47      | Reserved   | 00008000   | 128        |
| Byte 6   | 48      | Brake Input Shorted Fault                              | 00010000   | 1          |
|          | 49      | Brake Input Open Fault                                 | 00020000   | 2          |
|          | 50      | Module A Over-temperature Fault <sup>7</sup>           | 00040000   | 4          |
|          | 51      | Module B Over-temperature Fault <sup>7</sup>           | 00080000   | 8          |
|          | 52      | Module C Over-temperature Fault <sup>7</sup>           | 00100000   | 16         |
|          | 53      | PCB Over-temperature Fault <sup>7</sup>                | 00200000   | 32         |
|          | 54      | Gate Drive Board 1 Over-temperature Fault              | 00400000   | 64         |
|          | 55      | Gate Drive Board 2 Over-temperature Fault <sup>7</sup> | 00800000   | 128        |
| Byte 7   | 56      | Gate Drive Board 3 Over-temperature Fault <sup>7</sup> | 01000000   | 1          |
|          | 57      | Current Sensor Fault                                   | 02000000   | 2          |
|          | 58      | Reserved   | 04000000   | 4          |
|          | 59      | Reserved   | 08000000   | 8          |
|          | 60      | Reserved   | 10000000   | 16         |
|          | 61      | Reserved   | 20000000   | 32         |
|          | 62      | Resolver Not Connected                                 | 40000000   | 64         |
|          | 63      | Inverter Discharge Active                              | 80000000   | 128        |

<sup>7</sup> This is a new fault used only for Gen-3 board which is used in all PM150 units.



#### 0x0AC – Torque & Timer Information

| Byte #  | Name             | Format              | Description  |
|---------|------------------|---------------------|--|
| 0,1     | Commanded Torque | Torque              | The commanded torque.  |
| 2,3     | Torque Feedback  | Torque              | The estimated motor torque based on motor parameters and feedbacks.                      |
| 4,5,6,7 | Power on Timer   | (Counts x .003) sec | This timer is updated every 3 msec. This timer will roll-over in approximately 5 months. |

#### 0x0AD – Modulation Index & Flux Weakening Output Information

| Byte # | Name                  | Format         | Description   |
|--------|-----------------------|----------------|---|
| 0,1    | Modulation Index      | Per-unit Value | This is the modulation index. The scale factor is x100. To get the actual modulation index divide the value by 100. |
| 2,3    | Flux Weakening Output | Current        | This is the current output of the flux regulator.   |
| 4,5    | Id command            | Current        | The commanded D-axis current  |
| 6,7    | Iq command            | Current        | The commanded Q-axis current  |

#### 0x0AE – Firmware Information

| Byte # | Name                          | Format | Description  |
|--------|-------------------------------|--------|--|
| 0,1    | EEPROM Version / Project Code | NA     | This is an EEPROM version that is assigned to each RMS project. For factory use only!            |
| 2,3    | Software Version              | NA     | This is the software version with major and minor release values.                                |
| 4,5    | Date Code (mmdd)              | NA     | This is the portion of date code that displays month and date information in <i>mmdd</i> format. |
| 6,7    | Date Code (yyyy)              | NA     | This is the portion of date code that displays year information in <i>yyyy</i> format.           |

#### 0x0AF – Diagnostic Data

| Byte #  | Name | Format | Description |
|---|------|--------|-------------|
| Please refer to the manual, "Download Diagnostic Data" for details. |      |        |             |





## 2.2 Command Message

The Command Message is used to transmit data to the controller. This message is sent from a user-supplied external controller to the PM controller. The Control Message (0x0C0) is used to operate the PM controller via the CAN interface.

0x0C0 – Command Message (Data Length = 8 bytes)

| Byte.Bit | Name                   | Format           | Description   |
|----------|------------------------|------------------|---|
| 0,1      | Torque Command         | Torque           | Torque command used when in torque mode.  |
| 2,3      | Speed Command          | Angular Velocity | Speed command used when in speed mode.  |
| 4        | Direction              | Boolean          | 0 = CW,<br>1 = CCW as viewed from the shaft end of the motor.   |
| 5.0      | Enable                 | Boolean          | 0 = Inverter Off,<br>1 = Inverter On  |
| 5.1      | Discharge <sup>8</sup> | Boolean          | 0 = Disable Discharge,<br>1 = Enable Discharge  |
| 6,7      | Commanded Torque Limit | Torque           | If set to 0, the default torque limits sets in the EEPROM parameters are used. If set to a positive number then the Motor and Regen Torque limits are set to the torque value sent. |

This message should be continuously broadcast at 500 milliseconds rate or faster.

If the Command Message is not received faster than the CAN TimeOut time and the Command Message Active Parameter is set to 1 then a CAN Command Message Lost fault will be generated.

When in CAN mode the Command messages should be sent to the controller before the inverter is powered on. If they are not then the Command message Lost fault will have to be cleared up on power up.

Note: Commanded Torque Limit feature was added in software version 1953. For previous versions of software these two bytes should be set to 0 and do not have any function.

---

<sup>8</sup> Please refer to the document, "RMS Inverter Discharge Process".



---

## **2.2.1 Inverter Enable Safety Options**

### **2.2.1.1 Inverter Enable Lockout:**

This feature is added so that the inverter cannot be accidentally enabled. This feature requires that before sending out an Inverter Enable command, the user must send out a Inverter Disable command. Once the inverter sees a Disable command, the lockout is removed and PM can receive the Inverter Enable command.

### **2.2.2.2 Inverter Enable Safety Switch:**

A new EEPROM parameter, CAN Inverter Enable Switch Active EEPROM, is added as a safety option.

Setting this parameter to 1 will take DIN1 digital input into consideration and the inverter will only be enabled if both DIN1 and inverter command are active. If DIN1 or Inverter Enable Command is inactive, the inverter will be disabled.

If CAN Inverter Enable Switch Active EEPROM is set to 0, DIN1 will have no effect on enabling or disabling the inverter.

### **2.2.2.3 Sudden Reversal of the Direction Command:**

This safety feature keeps the user from changing the direction command while the inverter is enabled. If the direction command is changed suddenly when the inverter is still enabled, inverter is disabled without triggering any faults. Also, the lockout condition is set again which will force the user to send an Inverter Disable command before re-enabling it.



## 2.2.2 CAN Message Sequence Example

Here is an example of sending out torque commands to the inverter in 'CAN' mode with run mode required to be 'Torque'. These two EEPROM parameters can be set via GUI after powering up the inverter.

For the message sequence example described below, following assumptions hold true:

| GUI EEPROM Parameter             | Default Value | Description             |
|----------------------------------|---------------|-------------------------|
| Inv_Cmd_Mode_EEPROM(CAN=0_VSM=1) | 0             | CAN mode                |
| Run_Mode_EEPROM(Trq=0_Spd=1)     | 0             | Torque mode             |
| CAN_ID_Offset_EEPROM             | 0xA0          | Default CAN ID offset   |
| CAN_TimeOut_(/3ms)_EEPROM        | 333           | 1 second timeout period |



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

| Message Type | CAN ID | Byte 0 | Byte 1 | Byte 2         | Byte 3 | Byte 4 | Byte 5 | Byte 6 | Byte 7 | Description  |
|--------------|--------|--------|--------|----------------|--------|--------|--------|--------|--------|--|
| Rxd          | 0xAA   | 4      | 0      | 9              | 0      | 0      | 0      | 128    | 0      | Torque mode is active. Lockout is enabled.   |
| Txd          | 0xC0   | 0      | 0      | 0              | 0      | 0      | 0      | 0      | 0      | Send out inverter disable command to release lockout.<br>This command should have been set up to be transmitted at a rate of 500 ms or faster before the inverter is powered up.             |
| Txd          | 0xC0   | 100    | 0      | x <sup>9</sup> | x      | 1      | 1      | x      | x      | Enable the inverter with a torque command of +10 Nm in forward direction.  |
| Txd          | 0xC0   | 200    | 0      | x              | x      | 1      | 1      | x      | x      | Set the torque to +20 Nm (motoring) in forward direction.  |
| Txd          | 0xC0   | 156    | 255    | x              | x      | 1      | 1      | x      | x      | Set the torque to -10 Nm (regenerative) in forward direction.  |
| Txd          | 0xC0   | X      | x      | x              | x      | 1      | 0      | x      | x      | Disable the inverter before changing the direction.<br>If the direction is changed without disabling the inverter first. The inverter will be automatically disabled as a safety precaution. |
| Txd          | 0xC0   | 100    | 0      | x              | x      | 0      | 1      | x      | x      | Set the command to +10 Nm (motoring) in reverse direction.   |

<sup>9</sup> "x" indicates a DON'T CARE value



### 2.2.3 Sign Convention for Torque and Speed

When using the PM inverter in CAN mode, it is important to make sure that commands are entered properly to move the motor in the intended direction. Following description provides details on speed command, speed feedback, torque command, torque feedback and direction command and the possible outcome in each scenario.

#### 2.2.3.1 CAN Speed command:

The Speed Command is a signed number. If the speed command is positive then the direction will be the direction of the direction command bit. If the Speed Command is negative then the direction will be opposite of the direction of the direction command bit.

#### 2.2.3.2 CAN Torque command:

##### **For a forward direction command:**

- Positive torque command will give a positive torque feedback and is motoring for positive speed.
- Negative torque command will give a negative torque feedback and is regen for positive speed.
- Positive torque command will give a positive torque feedback and is regen for negative speed.
- *A negative torque command should not be allowed if already going negative speed.*

##### **For reverse direction command:**

- Positive torque command will give a negative torque feedback & is motoring for negative speed.
- Negative torque command will give a positive torque feedback and is regen for negative speed.
- Positive torque command will give a negative torque feedback and is regen for positive speed.
- *A negative torque command should not be allowed if already going positive speed.*



## 2.3 Parameter Messages

The Parameter Messages (0x0C1 and 0x0C2) are used to read and write parameters in the PM controller. These parameters have many different functions. Some parameters are used to set non-volatile information (EEPROM data). Some are used to change functionality. Some are used to monitor various operating parameters that are not part of the broadcast messages.

To write a parameter use message 0x0C1 with byte #2 set to 1 (write). The PM controller will then respond with message 0x0C2 and if successful byte #2 will be set to 1.

To read a parameter use message 0x0C1 with byte #2 to set 0 (read). The PM controller will then respond with message 0x0C2 containing the requested data.

Both parameter messages contain 4 bytes for the data that is read or written. Some parameters will only occupy a single byte. If the data occupies less than 4 bytes it will be loaded into byte #4 first, followed by #5, and so on.

If the parameter address is not recognized then the controller parameter response message (0x0C2) will contain 0 in both bytes 0 and 1 of the return data.



### 2.3.1. Parameter Message Format

0x0C1 – Read / Write Parameter Command – sent to PM

| Byte # | Name              | Format                     | Description  |
|--------|-------------------|----------------------------|--|
| 0,1    | Parameter Address | Unsigned int               | Each command is identified by a unique address. Refer to sections, 'Command Parameters' and 'EEPROM Parameters' for each parameters address. |
| 2      | R/W Command       | Boolean                    | 0 = read, 1 = write  |
| 3      | Reserved          | NA                         | NA   |
| 4,5    | Data              | See "Data Formats" section | Data should be entered as dictated in "Data Formats" section.  |
| 6,7    | Reserved          | NA                         | NA   |

0x0C2 – Read / Write Parameter Response – response from PM

| Byte # | Name              | Format                     | Description  |
|--------|-------------------|----------------------------|--|
| 0,1    | Parameter Address | Unsigned int               | Each command is identified by a unique address. Refer to sections, 'Command Parameters' and 'EEPROM Parameters' for each parameters address. Will return 0,0 if parameter address is not recognized. |
| 2      | Write Success     | Boolean                    | 0 = not written, 1 = success   |
| 3      | Reserved          | NA                         | NA   |
| 4,5    | Data              | See "Data Formats" section | Response data is in the format dictated in "Data Formats" section.   |
| 6,7    | Reserved          | NA                         | NA   |

### 2.3.2. Parameter Address Ranges

The parameters are categorized in several general categories. Some parameters are read-only, and some can be written and read.

| Address Range | Category    | Description  |
|---------------|-------------|--|
| 0 – 99        | General     | This address range contains general parameters for control and monitoring  |
| 100 – 499     | User EEPROM | This address range is for EEPROM variables. These can only be written when the PM controller is not operating the motor. |



### 2.3.3. Command Parameters

| Address | Name                          | Format                          | Description  |
|---------|-------------------------------|---------------------------------|--|
| 1       | Relay Command                 | Unsigned integer<br>(0 – 65535) | 0xAA00: Normal Run mode<br>0x55nn: External Relay Control mode<br><br>Please see description below.  |
| 10      | Flux command                  | Flux                            | Modify the flux command.   |
| 11      | Resolver PWM<br>Delay Command | Unsigned integer<br>(0 – 6250)  | This command is used in calibration of the timing of the A/D reading of the resolver. It is used in determining the peak of the sine wave coming from the resolver. Its default value is 1100.   |
| 12      | Gamma Adjust GUI<br>Command   | Degrees                         | This is a calibration parameter used in the alignment of the magnetic field of the motor with the resolver. This command parameter behaves the same way as its equivalent GUI Command parameter. |
| 20      | Fault Clear                   | Boolean                         | Writing a 0 to this parameter clears any active faults. This command can be sent through CAN in CAN as well as VSM mode.   |

#### Relay Command

This command is used to control relay outputs. The Gen 2 units (older PM100 units) have 4 relay outputs. Gen 3 units, newer PM100, all PM150/250, have 6 relay outputs.

In order to control a relay, the inverter needs to be put into “External Relay Control” mode. This is achieved by setting byte 5 to 0x55. For byte 4, each bit corresponds to a relay. Bit 0 corresponds to relay 1 and bit 1 corresponds to relay 2. Similarly, bit 7 corresponds to relay 8 as shown in the table below. Note, the hardware does not currently support 8 relays.

| Byte 5 | Byte 4                  |
|--------|-------------------------|
| 0x55   | R8 R7 R6 R5 R4 R3 R2 R1 |

For example, if the user wants to turn on relay 3, he/she needs to set the data field of the parameter command messages to 0x5504. Similarly, if relay 1 and 2 need to be turned on, a command of 0x5503 must be sent.

Setting the data byte 5 to a value other than 0x55 will kick the inverter out of the “External Relay Control” mode and in to the “Normal Run” mode. The default value for normal run mode is 0xAA.





## 2.3.4. EEPROM Parameters

These Parameters are sent using the command message format described in 0x0C1 to modify the EEPROM parameters used by the PM controller. These parameters can only be written when the motor is not enabled. Each parameter will be stored in non-volatile memory at the time of programming. When the power is recycled the parameter will become effective and used by the inverter. Parameters highlighted in yellow will take immediate effect.

All EEPROM parameters can also be modified through the GUI interface.

### 2.3.4.1 Motor Configuration<sup>10</sup>

| Address | Name                | Format                         | Description   |
|---------|---------------------|--------------------------------|---|
| 150     | Motor Parameter Set | Unsigned char<br>(0 – 255)     | This represents a set of parameter that is used for each type of motor.   |
| 151     | Resolver PWM Delay  | Unsigned integer<br>(0 – 6250) | This is used in calibration of the timing of the A/D reading of the resolver. It is used in determining the peak of the sine wave coming from the resolver.   |
| 152     | Gamma Adjust        | Degrees                        | This is a calibration parameter used in the alignment of the magnetic field of the motor with the resolver. It will automatically default to the correct value when the motor type is changed.  |
| 154     | Sin Offset          | Low Voltage                    | Please refer to the manual, “RMS Encoder Calibration for SIN_COS Encoder”.  |
| 155     | Cos Offset          | Low Voltage                    |   |
| 156     | Sin ADC Offset      | ADC Count                      | This feature is dependent on the hardware version of the PM unit. In some cases, the resolver sine and cosine outputs may require adjustments for improved signals. These offsets are added as ADC counts to calibrate the sin and cosine signals directly. |
| 157     | Cos ADC Offset      | ADC Count                      |   |

<sup>10</sup> For a detailed process on how to configure a specific motor, please refer to the document “Setting up the PM for XYZ Motor”, where XYZ refers to the specific motor for individual customer.



#### 2.3.4.2 System Configuration

| Address | Name                  | Format           | Description   |
|---------|-----------------------|------------------|---|
| 140     | Pre-charge Bypassed   | Boolean          | 0 = Pre-charge is in effect<br>1 = Pre-charge is bypassed   |
| 142     | Inverter Run Mode     | Boolean          | 0 = Torque Mode<br>1 = Speed Mode   |
| 143     | Inverter Command Mode | Boolean          | This parameter gives the option to operate PM unit in either VSM mode or CAN mode. In VSM mode, GUI is the main interface to monitor and modify parameters. The inverter takes messages from the Vehicle State Machine which is operated from the various inputs and outputs of the inverter such brake, accelerator pedal, etc. In VSM mode, broadcast messages are still sent out over the CAN lines. In CAN mode, both GUI and CAN interfaces are active and can be used to monitor and modify parameters. However, any inputs from the vehicle state machine will be ignored.<br>0 = CAN Mode<br>1 = VSM Mode (Default) |
| 149     | Key Switch Mode       | Unsigned integer | Added alternate key switch modes. This allows different types of ignition for vehicles.<br><br>0 = Allows a simple on/off switch for powering up the inverter.<br><br>1 = Provides the functionality of a more traditional ignition switch with momentary START signal that powers up the inverter and keeps it powered until the ignition switch is turned off.<br><br>Key Switch Mode is only effective in VSM Mode. CAN mode remains unaffected. However, the parameter can be updated through both GUI and CAN.   |
| 170     | Relay Output Command  | Unsigned integer | Sets whether the Relay outputs have their normal function or are under CAN control. See the Software manual for more information.   |



### 2.3.4.3 CAN Configuration

| Address | Name                            | Format           | Description  |
|---------|---------------------------------|------------------|--|
| 141     | CAN ID Offset                   | Unsigned integer | This parameter allows the user to choose their own set of contiguous CAN message identifiers starting with the value in CAN ID Offset. This offset covers a range of 0 – 0x7C0. The default offset is 0x0A0. The default range is 0x0A0 – 0x0CF. This feature is especially useful when there are more than one PM controllers on the same CAN network. While setting base address for a controller, it must be made sure that the address range for controllers does not contain overlapping addresses.       |
| 144     | CAN Extended Message Identifier | Boolean          | This parameter allows switching between CAN standard and extended message identifiers.<br>0 = Standard CAN Messages<br>1 = Extended CAN Messages   |
| 171     | CAN J1939 Option Active         | Boolean          | This parameter allows switching between extended message identifiers with or without SAE J1939 format.<br>0 = J1939 formatting is not active<br>1 = J1939 formatting is active   |
| 145     | CAN Term Resistor Present       | Boolean          | In order to use CAN communication, the CAN bus needs to be terminated with a 120 Ohm resistor. RMS PM units are equipped with this resistor which is activated through this parameter.<br>0 = Term. Resistor not active<br>1 = Term. Resistor active (Default)<br>If CAN Terminator Resistor is deactivated, it may be necessary to use the GUI interface only <sup>11</sup> since CAN communication may fail without a terminator resistor.   |
| 146     | CAN Command Message Active      | Boolean          | RMS CAN requires a “heartbeat” command message. This command message controls the inverter, motor direction, and torque or speed. In the absence (time set by CAN TimeOut parameter) of a regular broadcast of this message, PM unit will assume there is a problem and will flag a fault unless the fault has been deactivated by setting this parameter to 0.<br>0 = The command message 0xC0 is <b>not</b> sent every half a second.<br>1 = The command message 0xC0 is sent every half a second. (Default) |

<sup>11</sup> Please refer to the document “Programming EEPROM Parameters using GUI”.



|     |                                     |                                 |  |
|-----|-------------------------------------|---------------------------------|--|
| 147 | CAN Bit Rate                        | Unsigned integer                | 250Kbps is the default bit rate. Bus speed can be changed using CAN parameter command message. However, changing this parameter requires a power reset on PM unit since bus speed is setup only at the initialization of CAN modules in the microcontroller. Also, This input is restricted to valid baud rates. The 4 options for valid baud rate are:<br>125 = 125Kbps<br>250 = 250 Kbps (Default)<br>500 = 500 Kbps<br>1000 = 1Mbps |
| 148 | CAN Active Messages Word            | Unsigned long integer (32-bits) | This parameter is used to enable/disable CAN Broadcast Messages. Each bit represents a CAN Message broadcast status as follows:<br><br>0 = CAN Messages broadcast disabled<br>1 = CAN Message broadcast enabled (Default)<br><br>Please refer to the table of CAN Broadcast Messages in section 2.1 for details on how to enable/disable each message.   |
| 158 | CAN Diagnostic Data Transmit Active | Boolean                         | This parameter is used to enable/disable the broadcast of the diagnostic data.<br>0 = CAN Diagnostic Data broadcast disabled<br>1 = CAN Diagnostic Data broadcast enabled (Default)<br>Please refer to the document, CAN Diagnostic Data, for more details on this feature.  |
| 159 | CAN Inverter Enable Switch Active   | Boolean                         | 1 = DIN1 digital input is taken into consideration and the inverter will only be enabled if both DIN1 and inverter command are active. If either one is inactive, the inverter will be disabled.<br><br>0 = DIN1 will have no effect on enabling or disabling the inverter (Default)   |
| 172 | CAN TimeOut                         | Unsigned integer                | This parameter sets how long before the CAN timeout error is set. The timeout is only active if the CAN Command Message Active is set to 1. The time is set in counts of 3ms. So for example setting a value of 333 will give a timeout time of 1 second.  |



#### 2.3.4.4 Current

| Address | Name             | Format    | Description   |
|---------|------------------|-----------|---|
| 100     | Iq Limit         | Current   | This parameter sets the Q-axis current limit.   |
| 101     | Id Limit         | Current   | This parameter sets the D-axis current limit.   |
| 107     | Ia Offset EEPROM | ADC Count | The offset values are in ADC counts. Each offset should be set to 2048 which is the 0-Amps mid-point. |
| 108     | Ib Offset EEPROM |           |   |
| 109     | Ic Offset EEPROM |           |   |

#### 2.3.4.5 Voltage & Flux

| Address | Name                   | Format       | Description  |
|---------|------------------------|--------------|--|
| 102     | DC Voltage Limit       | High Voltage | This parameter sets the over-voltage limit to protect the unit. This limit should be set based on total voltage provided by the power supply/battery pack. This parameter does not generate any faults.  |
| 103     | DC Voltage Hysteresis  | High Voltage | This is the hysteresis value used to bring the inverter out of the over-voltage condition. Most of the time, the default value is sufficient and this value seldom needs to be changed.  |
| 104     | DC Under-voltage Limit | High Voltage | This parameter sets the under-voltage limit. This limit should be set based on total voltage provided by the power supply/battery pack. A fault is generated when the voltage drops below this limit. To disable the under-voltage fault, set this limit to 0. |
| 106     | Vehicle Flux Command   | Flux         | This parameter sets the back EMF (flux) constant for the motor. It will automatically default to the correct value when the motor type is changed. Most of the time, the default value is sufficient and this value seldom needs to be changed.                |



#### 2.3.4.6 Temperature

| Address | Name                      | Format      | Description   |
|---------|---------------------------|-------------|---|
| 112     | Inverter Over-Temperature | Temperature | This parameter sets the Inverter temperature limit. The temperature is set in degrees Celsius times 10 (85°C is set as 850). If the temperature exceeds this value then the inverter will turn off and declare a fault.   |
| 113     | Motor Over-Temperature    | Temperature | This parameter sets the Motor temperature limit (if the motor has a temperature sensor). The temperature is set in degrees Celsius times 10 (150°C is set as 1500). If the temperature exceeds this value then the inverter will turn off and declare a fault.  |
| 114     | Zero Torque Temperature   | Temperature | Temperature threshold where the torque is zero. This value should be less than <code>Mtr_OverTemp_Limit_EEPROM(C)_x_10</code> .   |
| 115     | Full Torque Temperature   | Temperature | This is the temperature threshold where the full torque is operational. This parameter affects the calculation of torque capability. Based on the calculation of the slope and offset of the line from <code>Full_Torque_Temp_EEPROM(C)_x_10</code> to <code>Zero_Torque_Temp_EEPROM(C)_x_10</code> , the new torque capability is reduced by a factor of $(\text{slope} * \text{Motor Temperature} + \text{offset})$ . This parameters should be less than <code>Zero_Torque_Temp_EEPROM(C)_x_10</code> which should be less than <code>Mtr_OverTemp_Limit_EEPROM(C)_x_10</code> . |
| 203     | RTD Selection             | Boolean     | This parameter allows the user to select either 100 Ohms or 1000 Ohms for RTD1 and RTD2 (Gen 3 units only).<br><br>Bit 0 = 0 -> RTD1 is 1000 Ohms<br>= 1 -> RTD1 is 100 Ohms<br><br>Bit 1 = 0 -> RTD2 is 1000 Ohms<br>= 1 -> RTD2 is 100 Ohms   |



#### 2.3.4.7 Accelerator Pedal<sup>12</sup>

| Address | Name                | Format      | Description   |
|---------|---------------------|-------------|---|
| 120     | ACCEL Pedal Low     | Low Voltage | This parameter sets a limit below which the torque command is 0. This should be set to a value that is lower than the lowest possible acceleration position but higher than 0. If the accelerator input goes below this value, torque command is set to 0, the inverter will turn off and declare the ACCEL SHORTED fault.  |
| 121     | ACCEL Pedal Min     | Low Voltage | This parameter sets a limit such that between that limit and ACCEL Pedal Low, torque command is set to a constant value set through REGEN Torque Limit.   |
| 122     | ACCEL Coast Low     | Low Voltage | This parameter sets a limit such that between that limit and ACCEL Pedal Min, torque command is linear from REGEN Torque Limit to 0.  |
| 123     | ACCEL Coast High    |             | This parameter sets a limit such that between that limit and ACCEL Coast Low, torque command is 0.  |
| 124     | ACCEL Pedal Max     | Low Voltage | This parameter sets a limit such that between that limit and ACCEL Coast High, torque command is linear from 0 to Motor Torque Limit. Normally, this will be the driving range.   |
| 125     | ACCEL Pedal High    | Low Voltage | This parameter sets a limit such that between that limit and ACCEL Pedal Max, torque command is set to a constant value of Motor Torque Limit. This should be set to a value that is higher than the highest possible acceleration position but less than 500. If the accelerator input goes above this value, torque command is set to 0, the inverter will turn off and declare the ACCEL OPEN fault. |
| 132     | Accel Pedal Flipped | Boolean     | This parameter determines if the pedal increases in value as it is pressed or behaves the other way around. If the pedal increases in voltage as it is pressed use a value of 0 (not flipped). If the pedal decreases in voltage as it is pressed use a value of 1 (flipped).   |

<sup>12</sup> Please refer to the document "RMS PM Software User Manual" for more details.



#### 2.3.4.8 Torque<sup>13</sup>

| Address | Name                 | Format               | Description  |
|---------|----------------------|----------------------|--|
| 129     | Motor Torque Limit   | Torque               | This parameter sets the upper limit of the torque that can be commanded by the controller in motoring mode. However, if the current limit of the drive is reached before the torque command has been achieved the controller will limit on the current first. If this happens the operator will feel an additional amount of unused pedal range at the top end.  |
| 130     | REGEN Torque Limit   | Torque               | This parameter sets the upper limit of torque that is commanded when the accelerator pedal is released. Normally this value would be set to a small percentage of the available motor braking torque, to simulate engine braking. This value only sets the torque limit when the pedal is released with no brake applied. The torque applied when the brake is active is set by a separate parameter (Braking Torque Limit). |
| 131     | Braking Torque Limit | Torque               | This parameter sets the amount of the torque applied when the brake is active.   |
| 164     | Kp Torque            | Proportional Gain    | This parameter sets the proportional gain for the torque regulator. This is a times 10000 value. Multiply the value within the valid range by 10000 before programming. Input is restricted to a valid range as indicated in the format table.   |
| 165     | Ki Torque            | Integral Gain        | Integral gain for the torque regulator. This is a times 10000 value. Multiply the value within the valid range by 10000 before programming. Input is restricted to valid range as indicated in the format table.   |
| 166     | Kd Torque            | Derivative Gain      | Derivative gain for the torque regulator. This is a times 100 value. Multiply the value within the valid range by 100 before programming. Input is restricted to valid range as indicated in the format table.   |
| 167     | Klp Torque           | Low-Pass Filter Gain | Low-pass filter gain for the torque regulator. This is a times 10000 value. Multiply the value within the valid range by 10000 before programming. Input is restricted to valid range as indicated in the format table.  |

<sup>13</sup> Please refer to the document "RMS PM Software User Manual" for more details.





7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

---

|     |                   |        |  |
|-----|-------------------|--------|--|
| 168 | Torque Rate Limit | Torque | This parameter sets the filtering for the torque command. During filtering, the change in torque command is limited to this value. The smaller this value is the slower the ramp for the torque command will be and vice versa. This parameter is limited between 0.1 and 25 Nm. |
|-----|-------------------|--------|--|



#### 2.3.4.9 Speed<sup>14</sup>

| Address | Name             | Format               | Description  |
|---------|------------------|----------------------|--|
| 111     | Motor Over-speed | Angular Velocity     | This parameter sets the over-speed value for the motor. If motor speed exceeds this value, inverter will turn off and declare the MOTOR OVERSPEED fault.   |
| 128     | Max Speed        | Angular Velocity     | The parameter sets the maximum allowable speed. If the speed is above this value the torque command will be reduced to zero.   |
| 126     | REGEN Fade Speed | Angular Velocity     | The parameters sets at which the amount of REGEN torque available is reduced.  |
| 127     | Break Speed      | Angular Velocity     | The parameter sets the speed at which the maximum torque command is reduced to compensate for a reduction of available torque due to field weakening.  |
| 160     | Kp Speed         | Proportional Gain    | Proportional gain for the speed regulator. Input is restricted to valid range as indicated in the format table.  |
| 161     | Ki Speed         | Integral Gain        | Integral gain for the speed regulator. Input is restricted to valid range as indicated in the format table.  |
| 162     | Kd Speed         | Derivative Gain      | Derivative gain for the speed regulator. Input is restricted to valid range as indicated in the format table.  |
| 163     | Klp Speed        | Low-Pass Filter Gain | Low-pass filter gain for the speed regulator. Input is restricted to valid range as indicated in the format table.   |
| 169     | Speed Rate Limit | Speed                | This parameter sets the filtering for the speed command. During filtering, the change in speed command is limited to this value. The smaller this value is the slower the ramp for the speed command will be and vice versa. This parameter is limited between 100 and 5100 RPM. |

<sup>14</sup> Please refer to the document "RMS PM Software User Manual" for more details.



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

#### 2.3.4.10 Shudder Compensation<sup>15</sup>

| Address | Name                        | Format           | Description  |
|---------|-----------------------------|------------------|--|
| 187     | Shudder Compensation Enable | Boolean          | 0: Shudder compensation feature is disabled.<br>1: Shudder compensation feature is enabled.  |
| 188     | Kp Shudder                  | Counts x 100     | This parameter provides shudder compensation gain. It is entered as a x 100 value.   |
| 189     | TCLAMP Shudder              | Torque           | This parameter provides maximum compensation torque.   |
| 190     | Shudder Filter Frequency    | Frequency        | This parameter provides the frequency value for the shudder filter.  |
| 191     | Shudder Speed Fade          | Angular velocity | The parameter provides a value such that from 0 speed to this value, the shudder compensation begins to fade from 0 to shudder torque, and vice versa. |
| 192     | Shudder Speed Low           | Angular velocity | The parameter provides the value at which the shudder compensation begins to fade to 0.  |
| 193     | Shudder Speed High          | Angular velocity | The parameter provides the value at which the shudder compensation is 0.   |

<sup>15</sup> Please refer to the document “Shudder Compensation Manual” for more details.



### 2.3.4.11 Brake Pedal

| Address | Name                 | Format                  | Description  |
|---------|----------------------|-------------------------|--|
| 180     | Brake Mode           | Boolean                 | <p>This parameter is used to switch mode as follows:</p> <p>0: Brake switch mode allows using brake as a binary switch input. Also, this mode activates the 'Automatic REGEN Torque Ramp Down' feature using the EEPROM Parameter REGEN Ramp Period.</p> <p>1: Brake Pot mode allows using brake as a variable input between 0 – 5 volts. This mode activates the 'Automatic REGEN Torque Ramp Down' feature using EEPROM parameters from address 181 – 184 below.</p> |
| 181     | Brake Low            | Low Voltage             | This parameter is used in Brake mode 1. This parameter sets the lower limit of the brake pot below which brake short fault is set.   |
| 182     | Brake Min            | Low Voltage             | This parameter is used in Brake mode 1. This parameter sets the minimum limit for calculating the braking torque.  |
| 183     | Brake Max            | Low Voltage             | This parameter is used in Brake mode 1. This parameter sets the maximum limit for calculating the braking torque.  |
| 184     | Brake High           | Low Voltage             | This parameter is used in Brake mode 1. This parameter sets the high limit above which brake open fault is set.  |
| 185     | REGEN Ramp Period    | (Counts x 0.001)<br>sec | This parameter is used in Brake mode 0. This value of time is entered in milliseconds. This is the time in which REGEN torque value ramps down to the braking torque limit.  |
| 186     | Brake Pedal Flipped  | Boolean                 | <p>0: Brake pedal reads 0 V when completely released and 5 V when completely pressed.</p> <p>1: Brake pedal reads opposite to the above.</p>   |
| 199     | Brake Input Bypassed | Boolean                 | <p>This parameter decides if the brake input should be ignored or not in VSM mode:</p> <p>0: Do not ignore brake input (process as usual)</p> <p>1: Ignore brake input (brake is considered OFF)</p>   |



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

#### 2.3.4.12 Reserved (for future use)

| Address      | Name     | Format   | Suggested Category         |
|--------------|----------|----------|----------------------------|
| 153, 194-198 | Reserved | Reserved | For factory use only       |
| 105          | TBD      | TBD      | Voltage, or Flux           |
| 110          | TBD      | TBD      | Speed                      |
| 116-119      | TBD      | TBD      | Temperature                |
| 133-139      | TBD      | TBD      | Accelerator Pedal or Speed |
| 173-179      | TBD      | TBD      | System Configuration       |
| 200-499      | TBD      | TBD      | TBD                        |



## Revision History

| Version | Description of Versions / Changes  | Responsible Party | Date       |
|---------|--|-------------------|------------|
| 0.1     | Initial version  | Chris Brune       | 9/30/2009  |
| 0.2     | <ul style="list-style-type: none"><li>Moved Inverter Command Mode (CAN Mode Type) and Inverter Run Mode from 0x0C0 – Command Message to 0x0AA – Internal States</li><li>Added more EEPROM parameters.</li></ul>  | Azam Khan         | 11/17/2009 |
| 0.3     | <ul style="list-style-type: none"><li>For Parameter Messages, changed the range of General and User EEPROM parameters from 1 – 99 and 100 – 500 to 0 – 99 and 100 – 499 respectively.</li><li>Added a broadcast rate of 5 msec for the command message (0x0C0).</li><li>Added messages 105, 106, and 145</li><li>Changed messages 110 and 141 to be reserved for future use.</li></ul> | Azam Khan         | 11/30/2009 |
| 0.4     | <ul style="list-style-type: none"><li>Changed message 104 to “Reserved” for future use.</li><li>Changed Message 141 to “CAN ID Offset” and added its description in Broadcast Messages section and also in System Configuration table.</li><li>Added message 146 as “Restricted” for factory use only.</li></ul>   | Azam Khan         | 12/02/2009 |
| 0.5     | <ul style="list-style-type: none"><li>Added a new address 147 for CAN Bit Rate in table “System Configuration” for Parameter Messages.</li><li>Updated the description column for Motor Parameter Set to add more motor types.</li></ul>   | Azam Khan         | 01/25/2010 |
| 0.6     | <ul style="list-style-type: none"><li>Added an example on the use of little-endian format for CAN data bytes</li></ul>   | Azam Khan         | 01/27/2010 |
| 0.7     | <ul style="list-style-type: none"><li>Added a new address 113 for Motor Over-temperature in table Fault Limits for Parameter Messages.</li><li>Added Motor Temperature to the broadcast message 0x0A2.</li><li>Added speed regulator gains</li></ul>   | Azam Khan         | 02/18/2010 |
| 0.8     | <ul style="list-style-type: none"><li>Added Speed Regulator Gains (section 2.3.4.6)</li><li>Updated section 1.2 with the formats of Speed Regulator Gains.</li><li>Corrected the description for Fault Clear in section 2.3.3.</li></ul>   | Azam Khan         | 02/22/2010 |
| 0.9     | <ul style="list-style-type: none"><li>Added a new address 148 for CAN Active Messages Word in System Configuration table in Parameter Messages section.</li><li>Updated section 2.1 Broadcast Messages with details on how to enable/disable broadcast messages.</li><li>Added Power-on Timer to the broadcast msg 0x0AC.</li></ul>  | Azam Khan         | 03/24/2010 |



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

|     |  |           |            |
|-----|--|-----------|------------|
| 1.0 | <ul style="list-style-type: none"><li>Updated description for Digital Input Status in Broadcast Messages (Message ID 0x0A4)</li><li>Added a new address 149 for Key Switch Mode in System Configuration table in Parameter Messages section.</li></ul>   | Azam Khan | 04/14/2010 |
| 1.1 | <ul style="list-style-type: none"><li>Added a new address 170 for Pre-charge Output in System Configuration table in Parameter Messages section.</li></ul>   | Azam Khan | 04/26/2010 |
| 1.2 | <ul style="list-style-type: none"><li>Added more description on how to disable CAN broadcast messages in section "2.1 Broadcast Messages".</li></ul>   | Azam Khan | 04/27/2010 |
| 1.3 | <ul style="list-style-type: none"><li>Added Delta Resolver Filtered to the broadcast message 0x0A5.</li><li>Added a new broadcast message 0x0AD to send Modulation Index and Flux Weakening Output information.</li><li>Added Inverter Enable State and Direction Command to byte 6 and 7 respectively, to the broadcast message 0x0AA.</li></ul>  | Azam Khan | 06/29/2010 |
| 1.4 | <ul style="list-style-type: none"><li>Added Id- and Iq-commands to the broadcast message 0x0AD.</li><li>Updated the format for modulation index in message 0x0AD.</li></ul>  | Azam Khan | 08/10/2010 |
| 1.5 | <ul style="list-style-type: none"><li>Changed the description and range for parameters with the format, Angle.</li></ul>   | Azam Khan | 11/24/2010 |
| 1.6 | <ul style="list-style-type: none"><li>Rearranged EEPROM parameter sections into categories based on the type of parameters.</li><li>Described CAN configuration in more detail and also added it to the introduction section.</li></ul>  | Azam Khan | 12/1/2010  |
| 1.7 | <ul style="list-style-type: none"><li>Added two more parameters in section CAN Configuration:<ul style="list-style-type: none"><li>CAN Extended Message Identifiers</li><li>CAN J1939 Option Active</li></ul></li><li>Added two new EEPROM parameter sections:<ul style="list-style-type: none"><li>Shudder compensation</li><li>Brake Pedal</li></ul></li><li>Updated the format table for Kp, Ki, Kd, and Klp gains.</li></ul> | Azam Khan | 1/19/2011  |
| 1.8 | <ul style="list-style-type: none"><li>In section 2.3.1, changed the number of data bytes from 4 bytes (4, 5, 6, 7) to 2 bytes (4, 5).</li><li>Added a new section on "CAN Diagnostics Parameter Overview" in section 1.</li></ul>  | Azam Khan | 3/15/2011  |
| 1.9 | <ul style="list-style-type: none"><li>Corrected the example on page 10 for the direction command which is supposed to be on Byte 4 and Inverter command on Byte 5.</li></ul>   | Azam Khan | 4/4/2011   |



7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

|     |  |           |            |
|-----|--|-----------|------------|
| 2.0 | <ul style="list-style-type: none"><li>Updated section 1.3, CAN Format, to elaborate CAN command using example values.</li><li>Updated section 2.1, Broadcast Messages, Message 0xAC to show the correct resolution for the Power on Timer.</li><li>Added description for several EEPROM parameters.</li><li>Clarified that the CAN Command Message must be broadcast every 500 msec or faster.</li></ul> | Azam Khan | 6/1/2011   |
| 2.1 | <ul style="list-style-type: none"><li>Added a new section 1.5 for the CAN Database file.</li></ul>   | Azam Khan | 6/20/2011  |
| 2.2 | <ul style="list-style-type: none"><li>Added Resolver PWM Delay Command and Gamma Adjust GUI Command to provide the Resolver Calibration Process through CAN.</li><li>Updated section 2.3.4 EEPROM Parameters on how EEPROM parameters are programmed.</li><li>Added Inverter Enable Lockout bit to message ID 0x0AA in section 2.1, Broadcast Messages.</li></ul>  | Azam Khan | 9/11/2011  |
| 2.3 | <ul style="list-style-type: none"><li>Added a new torque parameter, 'Torque Rate Limit' that controls the ramp rate for torque command.</li></ul>  | Azam Khan | 12/07/2011 |
| 2.4 | <ul style="list-style-type: none"><li>Added two new messages 0xAE (Firmware information) and 0xAF (diagnostic data).</li><li>Added a new parameter CAN Diag Data Tx Active that controls the broadcast of diagnostic data.</li><li>Updated section 2.1 to show all faults with different assignment views.</li></ul>   | Azam Khan | 9/6/2012   |
| 2.5 | <ul style="list-style-type: none"><li>Added the "discharge" command to the heartbeat command message.</li></ul>  | Azam Khan | 11/5/2012  |
| 2.6 | <ul style="list-style-type: none"><li>Updated section 1.1: Added a new EEPROM parameter CAN Inverter Enable Switch EEPROM.</li><li>Added a new section 2.2.1, Inverter Enable Safety Options</li><li>Updated section 2.3.4.3, CAN Configuration for the new EEPROM parameters, CAN Inverter Enable Switch EEPROM.</li></ul>  | Azam Khan | 12/5/2012  |
| 2.7 | <ul style="list-style-type: none"><li>SWRP 1805</li><li>Updated broadcast message 0x0AB for the two new faults, "Resolver Not Connected" and "Inverter Discharge Active".</li></ul>  | Azam Khan | 12/13/2012 |
| 2.8 | <ul style="list-style-type: none"><li>Added description regarding the limited J1939 CAN Messaging option in section 1.1.</li></ul>   | Azam Khan | 02/05/2013 |
| 2.9 | <ul style="list-style-type: none"><li>Updated section 2.2.1 Inverter Enable Safety Options with the safety feature "Sudden Reversal of the Direction Command".</li></ul>   | Azam Khan | 6/21/2013  |
| 3.0 | <ul style="list-style-type: none"><li>Added CAN message IDs in extended and J1939 format.</li></ul>  | Azam Khan | 7/8/2013   |
| 3.1 | <ul style="list-style-type: none"><li>Updated section, Command Parameter, for issuing relay commands (Address 1). This change in the method of controlling relays is effective for firmware release 1909 and later.</li></ul>  | Azam Khan | 10/22/2013 |





7929 SW Burns Way  
Suite B  
Wilsonville, OR

Phone: 503 344-5085  
Fax: 503 682-9014  
[sales@rinehartmotion.com](mailto:sales@rinehartmotion.com)

|     |   |             |            |
|-----|---|-------------|------------|
| 3.2 | <ul style="list-style-type: none"><li>Added a new section 2.2.2 to provide example to the user regarding an example of CAN message sequence.</li><li>Added section 2.2.3 which explains the sign convention for torque and speed commands.</li><li>Highlighted EEPROM parameters that will take effect immediately as opposed to the parameters that take effect after power cycle.</li></ul> | Azam Khan   | 11/07/2013 |
| 3.3 | Updated the section, 1.4 Data Formats to cover each data type to its full range.  | Azam Khan   | 04/02/2014 |
| 3.4 | Corrected the CAN byte numbers for Run Faults to be 4, 5, 6, and 7 and adjusted bit numbers accordingly.  | Azam Khan   | 04/15/2014 |
| 3.5 | Corrected the value of -10 Nm to be $(255 \times 256) + 156$ instead of $(255 \times 256) + 246$ (which is equal to -1 Nm).   | Azam Khan   | 07/28/2014 |
| 3.6 | Removed the references to the GUI addresses. GUI addresses are correct in the defsyms files and may change based on the availability of memory. Mentioning these addresses in the documentation is redundant.   | Azam Khan   | 8/12/2014  |
| 3.7 | Added CAN Timeout count EEPROM parameter (implemented in firmware 1935). Clarification added to the command message formatting. Added some clarification to the parameter message.  | Chris Brune | 12/12/2014 |
| 3.8 | Updated the Internal States Message (0xAA) to show the Inverter Active Discharge state parameter (byte 4, bits 5 thru 7).   | Chris Brune | 3/9/2015   |
| 3.9 | Corrected issue with the number of relay outputs. Added information about Commanded Torque Limit. Corrected information about sign of Speed command. Moved Motor Temperature foldback parameters to the Temperature section.  | Chris Brune | 8/26/2015  |