


Quick Reference Guide

Workstations on Wheels (WOWs) – Checking & Changing Batteries

Checking the charge of the battery

- 1) There are two locations on the monitor where the user can check the current battery charge level.
- 2) In the bottom right corner of the monitor, there is a battery icon. Click on this icon and a window will appear with all three batteries and their charge percentages.
- 3) The battery indicator lights on the top left of the monitor can also be used to check the battery power of the WOW.
 - **Blue** indicates that the battery is charged
 - **Flashing Blue** indicates that the battery is charging
 - **Orange** indicates that the battery is low
 - **Flashing Orange** indicates that the battery is critically low



Changing the battery

- 1) Lower the height of the WOW to ensure the batteries can be reached at an acceptable level.
- 2) Standing behind the WOW, locate the battery slot on the top of the WOW screen. Press down on the battery slot door to reveal the batteries.
- 3) Remove one battery at a time and ensure you start with the **far right battery** as the battery packs drain from right to left (when looking at the WOW from the rear).



Warning! Do not remove all 3 batteries at the same time or the unit will shut down!




- 4) Pull up on the **black ribbon** to remove the battery from the computer.

- 5) Check the battery power by locating a **white button & battery icon** in the corner. Press the white button firmly, and the indicator light will appear displaying the level of charge.



- 6) Gently place the low charge battery into the charging station with the battery pin slots on the same side as the indicator light on the charging station.



- 7) Place a freshly charged battery into the WOW by ensuring that the **battery label is facing the rear** of the computer and that the pin slots are aligned.



Warning! Do not force the battery into the charging station or the WOW as the pins will break!