

G1 X10 Y10	move to X10 Y10
G28	go home
G94	switch to Rectangular coordinate system
G95	switch to Angle coordinate system
M3	pen down
M3S20	pen move to 20°
M5	pen up
M4 L10 T40	Set up default pen down angle (L) default pen up angle(T)
M203 X2000 Y2000	max feedrate
M201 X1000 Y1000	acceleration
M205 X0.8	motor jerk
M503	View parameters
M501	load EEPROM parameters
M502	Restore factory settings
M500	Save current settings,use this instruction for modification of each parameter
M369 X10 Y10	set current position to X10 Y10
M370	set current position to X0 Y0,same as M369 X0 Y0