

Extruder fan can't run

Usually the bolt or the wire above the fan press it, and cause the obstruction and the fan can't run.

