

Y axis not moving properly

When there is problem for y axis movement, we have to check the places below with arrow whether they are tight or not. If they are loose, you should use hex wrench we sent to you to tighten them.

There are totally 12 set screws, 4 screws and 3 belts you have to make sure they are tight.







