

User Manual

Contents

Content

1. Features	6
2. Product marking	6
3. Ordering information	7
4. Conventions	8
5. Quick start	9
(a) Getting started	9
(b) System requirements	9
(c) Development toolchains	9
(d) NUCLEO-L476RG bootloader limitations	10
(e) Hardware configuration variants	11
6. Hardware layout and configuration	12
(a) Cuttable PCB	16
(b) Embedded ST-LINK/V2-1	16
i. Driver	17
ii. ST-LINK/V2-1 firmware upgrade	17
iii. Using the ST-LINK/V2-1 to program and debug the STM32 on board	18
iv. Using ST-LINK/V2-1 to program and debug an external STM32 application	18
(c) Power supply and power selection	20
i. Power supply input from the USB connector	20
ii. External power supply inputs: VIN and E5V	21
iii. External power supply input: +3.3V	22
iv. External power supply output	22
(d) LEDs	23
(e) Push-buttons	23
(f) JP6 (IDD)	23
(g) OSC clock	24
i. OSC clock supply	24

ii. OSC 32 kHz clock supply	25
(h) USART communication	25
(i) Solder bridges	26
(j) Extension connectors	27
(k) Arduino connectors	37
(l) ST morpho connector	53
7. Appendix A Electrical schematics	63
8. Revision history	67