

Add and Activate License:

Under **Management->Software Activation->Licenses** from the dropdown menu select "**Add**", enter the amount of licenses that you want to add and press "**Set Count**".

Management

- Summary
- SNMP
- HTTP-HTTPS
- IPSEC
- Telnet-SSH
- Serial Port
- Local Management Users
- User Sessions
- Logs
- Mgmt Via Wireless
- Cloud Services
- Software Activation**
 - Licenses
 - License Usage
 - License Type
- Tech Support

Licenses

Add License

License Count **Set Count**

License	Type	Time(expires)	RTU Count	Status
ap_count	Evaluation	12 weeks, 5 days	200	Active, Not-In-Use
ap_count (adder)	Permanent	No Expiry	1	Inactive

End User License Agreement window will pop. **Accept** it every time wish to add/delete licenses.

End User License Agreement (EULA)

IMPORTANT: PLEASE READ THIS END USER LICENSE AGREEMENT CAREFULLY. DOWNLOADING, INSTALLING OR USING CISCO OR CISCO-SUPPLIED SOFTWARE CONSTITUTES ACCEPTANCE OF THIS AGREEMENT.

Enabling additional access points supported by this controller product may require the purchase of supplemental or "adder" licenses. You may remove supplemental licenses from one controller and transfer to another controller in the same product family. NOTE: licenses embedded in the controller at time of shipment are not transferrable.

By clicking "I AGREE" (or "I ACCEPT") below, you warrant and represent that you have purchased sufficient supplemental licenses for the access points to be enabled.

All supplemental licenses are subject to the terms and conditions of the Cisco end user license agreement (http://www.cisco.com/en/US/docs/general/warranty/English/EU1KEN_.html), together with any applicable supplemental end user license agreements, or SEULA's.

Pursuant to such terms, Cisco is entitled to confirm that your access point enablement is properly licensed.

If you do not agree with any of the above, do not proceed further and CLICK DECLINE below.

I Accept **Decline**