

# MICROSAR CAN State Manager

|  |  |
|--|--|
|  |  |
|  |  |

## 1 Document Information

## 1.1 History

| Author | Date | Version | Remarks                                    |
|--------|------|---------|--|
|        |      |         |  |
|        |      |         |  |
|        |      |         |  |
|        |      |         |  |
|        |      |         |  |
|        |      |         |  |
|        |      |         |  |
|        |      |         |  |
|        |      |         | CANSM_E_SETTRANSCEIVERMODE                 |
|        |      |         | Disable Pdu Group      BusOff Notification |


|  |  |  |                        |
|--|--|--|------------------------|
|  |  |  |                        |
|  |  |  | →                      |
|  |  |  |                        |
|  |  |  |                        |
|  |  |  |                        |
|  |  |  |                        |
|  |  |  |                        |
|  |  |  | CANSM_EXCLUSIVE_AREA_4 |
|  |  |  |                        |

1.2 Reference Documents

| No. | Title | Version |
|-----|-------|---------|
|     |       |         |
|     |       |         |
|     |       |         |
|     |       |         |
|     |       |         |

|  |  |  |
|--|--|--|
|  |  |  |
|  |  |  |
|  |  |  |

### 1.3 Scope of the Document

|   |                    |
|---|--------------------|
|  | <b>Please note</b> |
|---|--------------------|

## Contents

|          |                                     |           |
|----------|-------------------------------------|-----------|
| <b>1</b> | <b>Document Information .....</b>   | <b>2</b>  |
| <b>2</b> | <b>Component History .....</b>      | <b>11</b> |
| <b>3</b> | <b>Introduction .....</b>           | <b>12</b> |
| <b>4</b> | <b>Functional Description .....</b> | <b>14</b> |
| <b>5</b> | <b>Integration .....</b>            | <b>24</b> |
| <b>6</b> | <b>API Description .....</b>        | <b>28</b> |

|          |                            |           |
|----------|----------------------------|-----------|
| <b>7</b> | <b>Configuration .....</b> | <b>36</b> |
|----------|----------------------------|-----------|

|          |   |           |
|----------|---|-----------|
| <b>8</b> | <b>AUTOSAR Standard Compliance.....</b> | <b>47</b> |
|----------|---|-----------|

|          |   |           |
|----------|---|-----------|
| <b>9</b> | <b>Glossary and Abbreviations .....</b> | <b>49</b> |
|----------|---|-----------|

|           |                     |           |
|-----------|---------------------|-----------|
| <b>10</b> | <b>Contact.....</b> | <b>51</b> |
|-----------|---------------------|-----------|

## Illustrations



GENy - [ GENy3-CAN-CAN-CAN-haupt-SwitchesOn.gny : CanSM]

File Edit View Configuration Window Help

ECU: DUT

- Components
  - Can\_CanoeemuCanoe
  - CanIf
  - CanSM
    - Channels
      - Channel0
      - Channel1
      - Channel2
    - Com
    - ComM
    - Dcm
    - Diagnostic Configuration
    - GenTool\_GenyAsrBase
    - GenTool\_GenyPluginAsrIfEcuConfigFile
    - GenTool\_GenyPluginConfigDocumentor
    - Hw\_CanoeemuCnu

Configurable Options

| CanSM                   |                                       |
|-------------------------|---------------------------------------|
| Common                  |                                       |
| Configuration Variant   | Variant 3 (Post-build Configuration)  |
| Version Info Api        | <input checked="" type="checkbox"/>   |
| Dev Error Detect        | <input checked="" type="checkbox"/>   |
| Prod Error Detect       | <input checked="" type="checkbox"/> * |
| User Configuration File | * ...                                 |
| Miscellaneous           |                                       |
| Main Fct Cycle Time [s] | 0.01 *                                |
| Hw Repetition           | 5 *                                   |
| Partial Networks        | <input checked="" type="checkbox"/> * |
| BswM ComMode Indication | <input checked="" type="checkbox"/> * |
| Ecu Passive Mode        | <input checked="" type="checkbox"/>   |

Postbuild Configuration

Foot Build Config Start Address 0x0

| Components | ECU: DUT                            | Channel0                            | Channel1                            | Channel2                            |
|------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| CanIf      | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| CanNm      | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| CanSM      | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| CanTp      | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| CanTrcv    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| CanXcp     | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Com        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| ComM       | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Dcm        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Det        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| EcuM       | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Hw_Can     | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| IPduMple   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Ilu        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Ilu_Dir    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| PduR       | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Vmm        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Vcp        | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| zBrs_Emb   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |

Navigation Tree

Item Selected: CanSM

Errors (0)

Generated Files

## Tables


## 2 Component History

| New Features |
|--------------|
|              |
|              |
|              |
|              |
|              |

### 3 Introduction

|  |  |      |
|--|--|------|
| <b>Supported AUTOSAR Release*:</b>       |  |      |
| <b>Supported Configuration Variants:</b> |  |      |
| <b>Vendor ID:</b>                        |  |      |
| <b>Module ID:</b>                        |  | 0x8C |


#### 3.1 Architecture Overview



Vector MICROSAR Product

Service by Vector

\* Option included in LINIF



## 4 Functional Description

### 4.1 Features

| Feature |
|---------|
|         |
|         |
|         |
|         |
|         |
|         |
|         |
|         |
|         |
|         |
|         |

| Feature |
|---------|
|         |
|         |
|         |

### 4.2 Initialization

CanSM\_Init

CanSM\_InitMemory(void)


CanSM\_Init



**Info**

## **4.3 State Machines**

### **4.3.1 Network Mode State Machine**



## Initial

CanSM\_Init

CANSM\_NO\_COMMUNICATION

## Transition Check

Hw Repetition

CANSM\_E\_MODE\_CHANGE\_NETWORK\_x



**CANSM\_NO\_COMMUNICATION**

**CANSM\_FULL\_COMMUNICATION**

**CANSM\_SILENT\_COMMUNICATION**

|                          |                          |
|--------------------------|--------------------------|
|                          | CANSM_NO_COMMUNICATION   |
| CANSM_FULL_COMMUNICATION |                          |
|                          | CANSM_FULL_COMMUNICATION |
| CANSM_NO_COMMUNICATION   |                          |



**CANSM\_BOR\_IDLE**

CANSM\_FULL\_COMMUNICATION

**CANSM\_BOR\_CHECK\_INIT**

TxEnsured

CANSM\_BOR\_NO\_BUS\_OFF

CANSM\_BOR\_TXOFF\_L1

**CANSM\_BOR\_NO\_BUS\_OFF**

CANSM\_FULL\_COMMUNICATION

DEM\_EVENT\_STATUS\_PASSED

CANSM\_BOR\_TXOFF\_L1

**CANSM\_BOR\_TXOFF\_L1, CANSM\_BOR\_TXOFF\_L2**

Level 2 recovery time

CANSM\_BOR\_CHECK\_Lx

ComM\_BusSM\_ModeIndication

CanSM\_GetCurrentComMode

**CANSM\_BOR\_CHECK\_L1, CANSM\_BOR\_CHECK\_L2**

TxEnsured

CANSM\_BOR\_NO\_BUS\_OFF

Counter L1 to L2

CANSM\_BOR\_TXOFF\_L1

CANSM\_BOR\_TXOFF\_L2.

L2 error counter

DEM\_EVENT\_STATUS\_FAILED

## Bus-off notification functions Appl\_CanSM\_BusOffBegin and Appl\_CanSM\_BusOffEnd

```

                                Appl_CanSM_BusOffBegin

CANSM_BOR_CHECK_L1    CANSM_BOR_CHECK_L2

Appl_CanSM_BusOffEnd

                                BusOffBegin

                                _BOR_NO_BUS_OFF

TxEnsured

                                Appl_CanSM_BusOffBegin

                                Appl_CanSM_BusOffEnd

```



### Info



### Caution

```

                                Appl_CanSM_BusOffBegin

```



### Caution

```

                                Appl_CanSM_BusOffEnd
CANSM_EXCLUSIVE_AREA_4

```

## 4.4 XCP notification function

## 4.5 ECU passive mode

## 4.6 Main Function

## 4.7 Communication Modes

CanSM\_RequestComMode.

## 4.8 Communication Mode Polling

ComM\_BusSM\_ModeIndication.

CanSM\_GetCurrentComMode

## 4.9 Error Handling

### 4.9.1 Development Error Reporting

Det\_ReportError()  
CANSM\_DEV\_ERROR\_DETECT

STD\_ON

0x8C

| Service ID | Service                                   |
|------------|---|
| 0x00       | CANSM_INIT_SERVICE_ID                     |
| 0x01       | CANSM_GETVERSIONINFO_SERVICE_ID           |
| 0x02       | CANSM_REQUESTCOMMODE_SERVICE_ID           |
| 0x03       | CANSM_GETCURRENTCOMMODE_SERVICE_ID        |
| 0x04       | CANSM_CONTROLLERBUSOFF_SERVICE_ID         |
| 0x05       | CANSM_MAINFUNCTION_SERVICE_ID             |
| 0x06       | CANSM_PREVENTBUSSLEEPATSTARTUP_SERVICE_ID |

|         |  |  |  |  |  |  |  |  |
|---------|--|--|--|--|--|--|--|--|
| Check   |  |  |  |  |  |  |  |  |
| Service |  |  |  |  |  |  |  |  |

## 5 Integration

### 5.1 Brief Instruction

```
>
>
> CanSM_InitMemory
> CanSM_PreventBusSleepAtStartUp
> CanSM_Init
>
> CanSM_RequestComMode
>
> CanSM_MainFunction
```

### 5.2 Scope of Delivery

### 5.9





## 5.4 Compiler Abstraction and Memory Mapping

| Compiler Abstraction<br>Definitions    |                  |                     |             |             |            |
|--|------------------|---------------------|-------------|-------------|------------|
| Memory Mapping<br>Sections             | CANSM_VAR_NOINIT | CANSM_VAR_ZERO_INIT | CANSM_CONST | CANSM_PBCFG | CANSM_CODE |
| CANSM_START_SEC_VAR_NOINIT_UNSPECIFIED | ■                |                     |             |             |            |
| CANSM_STOP_SEC_VAR_NOINIT_UNSPECIFIED  |                  |                     |             |             |            |
| CANSM_START_SEC_VAR_ZERO_INIT_8BIT     |                  | ■                   |             |             |            |
| CANSM_STOP_SEC_VAR_ZERO_INIT_8BIT      |                  |                     |             |             |            |
| CANSM_START_SEC_VAR_NOINIT_8BIT        | ■                |                     |             |             |            |
| CANSM_STOP_SEC_VAR_NOINIT_8BIT         |                  |                     |             |             |            |
| CANSM_START_SEC_CONST_8BIT             |                  |                     | ■           |             |            |
| CANSM_STOP_SEC_CONST_8BIT              |                  |                     |             |             |            |
| CANSM_START_SEC_CONST_32BIT            |                  |                     | ■           |             |            |
| CANSM_STOP_SEC_CONST_32BIT             |                  |                     |             |             |            |
| CANSM_START_SEC_CONST_UNSPECIFIED      |                  |                     | ■           |             |            |
| CANSM_STOP_SEC_CONST_UNSPECIFIED       |                  |                     |             |             |            |
| CANSM_START_SEC_PBCFG                  |                  |                     |             | ■           |            |
| CANSM_STOP_SEC_PBCFG                   |                  |                     |             |             |            |
| CANSM_START_SEC_CODE                   |                  |                     |             |             | ■          |
| CANSM_STOP_SEC_CODE                    |                  |                     |             |             |            |

## 5.5 Critical Areas

>  
>  
>

```
> CANSM_EXCLUSIVE_AREA_1
CanSM_MainFunction()
CanSM_RequestComMode()    CanSM_SetEcuPassive()

> CANSM_EXCLUSIVE_AREA_2
CanSM_RequestComMode()
CanSM_MainFunction()    CanSM_SetEcuPassive()

> CANSM_EXCLUSIVE_AREA_3
CanSM_SetEcuPassive()
CanSM_RequestComMode()    CanSM_MainFunction ()
```

```
> CANSM_EXCLUSIVE_AREA_4
CanSM_MainFunction()    CanSM_RequestComMode()
```

1.

2.

3.

```
> CANSM_EXCLUSIVE_AREA_5
CanSM_MainFunction()    CanSM_RequestComMode()
```


1.

2.

3.

## 6 API Description

### 6.1 Interfaces Overview



### 6.2 Type Definitions

| Type Name | C-Type | Description | Value Range            |
|-----------|--------|-------------|------------------------|
|           |        |             | CANSM_UNINITED         |
|           |        |             | CANSM_NO_COMMUNICATION |

| Type Name | C-Type | Description | Value Range                |
|-----------|--------|-------------|----------------------------|
|           |        |             | COMM_NO_COMMUNICATION      |
|           |        |             | CANSM_SILENT_COMMUNICATION |
|           |        |             | COMM_SILENT_COMMUNICATION  |
|           |        |             | CANSM_FULL_COMMUNICATION   |
|           |        |             | COMM_FULL_COMMUNICATION    |
|           |        |             | CANSM_BOR_IDLE             |
|           |        |             | CANSM_BOR_CHECK            |
|           |        |             | CANSM_BOR_NO_BUS_OFF       |
|           |        |             | CANSM_BOR_TXOFF_L1         |
|           |        |             | CANSM_BOR_CHECK_L1         |
|           |        |             | CANSM_BOR_TXOFF_L2         |
|           |        |             | CANSM_BOR_CHECK_L2         |

### 6.3 Services Provided by CanSM

| Return value   | Function name        | Function parameter |
|----------------|----------------------|--------------------|
| void           | CanSM_Init           |                    |
| void           | CanSM_GetVersionInfo |                    |
| Std_ReturnType | CanSM_RequestComMode |                    |

|                |                                |  |
|----------------|--------------------------------|--|
| Void           | CanSM_SetEcuPassive            |  |
| Std_ReturnType | CanSM_GetCurrentComMode        |  |
| void           | CanSM_ControllerBusOff         |  |
| void           | CanSM_MainFunction             |  |
| Std_ReturnType | CanSM_PreventBusSleepAtStartup |  |

### 6.3.1 CanSM\_InitMemory

| Prototype                       |  |  |
|---------------------------------|--|--|
| void CanSM_InitMemory( void )   |  |  |
| Parameter                       |  |  |
|                                 |  |  |
| Return code                     |  |  |
|                                 |  |  |
| Functional Description          |  |  |
| CanSm_IsInitialized FALSE       |  |  |
| Particularities and Limitations |  |  |
| ■                               |  |  |
|                                 |  |  |
| ■                               |  |  |

### 6.3.2 CanSM\_Init

| Prototype                         |   |
|-----------------------------------|---|
|                                   | <code>void CanSM_Init( void )</code>                              |
|                                   | <code>void CanSM_Init( const CanSM_ConfigType* ConfigPtr )</code> |
| Parameter                         |   |
| ConfigPtr                         |   |
| Return code                       |   |
|                                   |   |
| Functional Description            |   |
|                                   |   |
| Particularities and Limitations   |   |
| <div><div></div><div></div></div> |   |

|   |
|---|
|   |
| ■ |

### 6.3.3 CanSM\_MainFunction

| Prototype                                     |  |
|---|--|
| <code>void CanSM_MainFunction( void );</code> |  |
| Parameter                                     |  |
|   |  |
| Return code                                   |  |
|   |  |
| Functional Description                        |  |
|   |  |
| Particularities and Limitations               |  |
| ■   |  |
| ■   |  |
|   |  |
| ■   |  |

### 6.3.4 CanSM\_RequestComMode

| Prototype  |  |
|--|--|
| <code>Std_ReturnType CanSM_RequestComMode( NetworkHandleType NetworkHandle, ComM_ModeType ComM_Mode )</code> |  |
| Parameter  |  |
| NetworkHandle  |  |
| ComM_Mode  |  |
| Return code  |  |
| ReturnType   |  |
| Functional Description   |  |
|  |  |
| Particularities and Limitations  |  |
| ■  |  |
| ■  |  |
|  |  |
| ■  |  |

### 6.3.5 CanSM\_SetEcuPassive

| Prototype  |  |
|--|--|
| void CanSM_SetEcuPassive( boolean CanSM_EcuPassiveMode ) |  |
| Parameter  |  |
| CanSM_EcuPassiveMode                                     |  |
| Return code  |  |
|  |  |
| Functional Description                                   |  |
|  |  |
| Particularities and Limitations                          |  |
| ■  |  |
|  |  |
| ■  |  |

### 6.3.6 CanSM\_GetCurrentComMode

| Prototype   |  |
|---|--|
| Std_ReturnType CanSM_GetCurrentComMode( NetworkHandleType<br>NetworkHandle, ComM_ModeType* ComM_ModePtr ) |  |
| Parameter   |  |
| NetworkHandle   |  |
| ComM_ModePtr  |  |
| Return code   |  |
| ReturnType  |  |
| Functional Description  |  |
|   |  |
| Particularities and Limitations   |  |
| ■   |  |
|   |  |
| ■   |  |

### 6.3.7 CanSM\_GetVersionInfo

| Prototype  |  |
|--|--|
| void CanSM_GetVersionInfo( Std_VersionInfoType * VersionInfo ) |  |
| Parameter  |  |
| VersionInfo  |  |
| Return code  |  |
|  |  |



| Functional Description          |
|---------------------------------|
|                                 |
| Particularities and Limitations |
| ■                               |
|                                 |
| ■                               |

### 6.3.8 CanSM\_PreventBusSleepAtStartup

| Prototype  |
|--|
| Std_ReturnType CanSM_PreventBusSleepAtStartup( NetworkHandleType CanSM_NetworkHandle ) |
| Parameter  |
| NetworkHandleType  |
| Return code  |
| Std_ReturnType   |
| Functional Description   |
|  |
| Particularities and Limitations  |
| ■  |
|  |
| ■  |

## 6.4 Services used by CanSM

| Component | API |
|-----------|-----|
|           |     |
|           |     |
|           |     |
|           |     |

| Component | API |
|-----------|-----|
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |
|           |     |

## 6.5 Callback Functions

### 6.5.1 CanSM\_ControllerBusOff

| Prototype  |  |
|--|--|
| <code>void CanSM_ControllerBusOff( uint8 Controller )</code> |  |
| Parameter  |  |
| Controller   |  |
| Return code  |  |
|  |  |
| Functional Description                                       |  |
|  |  |
| Particularities and Limitations                              |  |
| ■  |  |
|  |  |
| ■  |  |

### 6.5.2 Appl\_CanSM\_BusOffBegin

| Prototype   |
|---|
| <code>void Appl_CanSM_BusOffBegin( NetworkHandleType CanSm_NetworkHandle, CanSM_BorCounterType CanSM_BusOffNotificationCounter )</code> |

| Parameter                       |  |
|---------------------------------|--|
| NetworkHandleType               |  |
| CanSM_BusOffNotificationCounter |  |
| Return code                     |  |
| -                               |  |
| Functional Description          |  |
|                                 |  |
| Particularities and Limitations |  |


## 7 Configuration



### 7.1 Configuration with GENy

#### 7.1.1.1 Basic

Components, CanSM



### 7.1.2 Activation of the CAN State Manager

CanSM  
System Configuration  
Configuration    Add Channel

Component Selection


| Software Components        | ECU: DUT                            | Channel0                            | Channel1                            | Channel2                            |
|----------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| CanIf                      | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| CanSM                      | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| CanTp                      | <input type="checkbox"/>            | <input type="checkbox"/>            | <input type="checkbox"/>            | <input type="checkbox"/>            |
| CanTrcv_Generic1           | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input type="checkbox"/>            | <input checked="" type="checkbox"/> |
| Can_CanoeemuCanoe          | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Com                        | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| ComM                       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Hw_CanoeemuCpu             | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| PduR                       | <input type="checkbox"/>            | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Vmm                        | <input type="checkbox"/>            | <input type="checkbox"/>            | <input type="checkbox"/>            | <input type="checkbox"/>            |
| zBrs_EmbeddedRunTimeSystem | <input type="checkbox"/>            | <input type="checkbox"/>            | <input type="checkbox"/>            | <input type="checkbox"/>            |

System Configuration

Component Selection

Generated Files

CanSM      Com      ComM



Info

View | OnScreen Help


Help | Help topics

7.1.3    General Settings

Main Fct Cycle Time



Caution



| Attribute Name        | Configuration Variant | Value Type | Values  | Description |
|-----------------------|-----------------------|------------|---------|-------------|
| Configuration Variant |                       |            | 1       |             |
| Version Info Api      |                       |            | STD_OFF |             |
| Dev Error Detect      |                       |            | STD_OFF |             |
| Prod Error Detect     |                       |            | STD_OFF |             |

| Attribute Name              | Configuration Variant | Value Type | Values         | Description                                    |
|-----------------------------|-----------------------|------------|----------------|--|
| User Configuration File     |                       |            | -              |  |
|                             |                       |            |                |  |
| Main Fct Cycle Time [s]     |                       |            | <b>0.0100</b>  |  |
| Hw Repetition               |                       |            | <b>5</b>       |  |
| Partial Networks            |                       |            | <b>STD_OFF</b> |  |
| BswM ComMode Indication     |                       |            | <b>STD_OFF</b> |  |
| Ecu Passive Mode            |                       |            | <b>STD_OFF</b> |  |
| BusOff Notification         |                       |            | <b>STD_OFF</b> | Appl_CanSM_BusOffBegin<br>Appl_CanSM_BusOffEnd |
| Disable DM during SilentCom |                       |            | <b>STD_OFF</b> | CANSM_SILENT_COMMUNICATION                     |
|                             |                       |            |                |  |
|                             |                       |            |                |  |






## Info


Component Selection

### 7.1.4 Network Settings

### 7.1.5 General CAN Channel Specific Settings



| Attribute Name     | Configuration Variant | Value Type | Values       | Description  |
|--------------------|-----------------------|------------|--------------|--|
| Partial Network Ch |                       |            | <b>false</b> | If Enabled then the CanSM changes the shutdown sequence to the needs of the partial network feature. The global switch has to be enabled, too. |




| Attribute Name         | Configuration Variant | Value Type | Values       | Description        |
|------------------------|-----------------------|------------|--------------|--------------------|
| Disable Tx Pdu Group   |                       |            | <b>false</b> |                    |
| Tx PDU Group Id        |                       |            | -            |                    |
| Initialize Tx Pdu Data |                       |            | <b>false</b> |                    |
| Disable Rx Pdu Group   |                       |            | <b>false</b> | Com_IpduGroupStart |
| Rx PDU Group Id        |                       |            | -            |                    |
| Initialize Rx          |                       |            | <b>false</b> |                    |

| Attribute Name | Configuration Variant | Value Type | Values | Description        |
|----------------|-----------------------|------------|--------|--------------------|
| Pdu Data       |                       |            |        | Com_IpduGroupStart |

Groups


IPdu



Com

7.1.6 Bus-off Recovery State Machine Configuration

Bus Off Settings



| Attribute Name             | Configuration Variant | Value Type | Values       | Description  |
|----------------------------|-----------------------|------------|--------------|--|
| Bor Time Tx Ensured Ch [s] |                       |            | <b>5.000</b> | The entered value is multiplied by the Cycle Time. The result has to be covered by the 16 bit integer range are allowed. E.g. if the Cycle Time is set 0.010 only values between 0.0 and 655.3500 are allowed. |
| Bor Counter L1 To L2 Ch    |                       |            | <b>5</b>     |  |
| Bor Time L1 Ch [s]         |                       |            | <b>1.000</b> | The entered value is multiplied by the Cycle Time. The result has to be covered by the 16 bit integer range are allowed. E.g. if the Cycle Time is set 0.010 only values between 0.0 and 655.3500 are allowed. |
| Bor Time L2 Ch             |                       |            | <b>3.000</b> |  |

| Attribute Name                        | Configuration Variant | Value Type | Values  | Description   |
|---------------------------------------|-----------------------|------------|---------|---|
| [s]                                   |                       |            |         | The entered value is multiplied by the Cycle Time. The result have to be covered by the 16 bit integer range are allowed. E.g. if the Cycle Time is set 0.010 only values between 0.0 and 655.3500 are allowed. |
| Bor Counter L2<br>Err Ch              |                       |            | 8       |   |
| Bor Disable Rx<br>Dl Monitoring<br>Ch |                       |            | STD_OFF |   |

**Info**

Bor Counter L1 To L2 Ch

**Info**

L2 Err Ch

Bor Counter L1 To L2 Ch

Bor Counter

Bor Counter L1 To L2 Ch

### 7.1.7 Values from other BSW Modules

CANSM\_E\_BUSOFF\_NETWORK\_<X>



**Example**

## 8 AUTOSAR Standard Compliance

### 8.1 Additions / Extensions

#### 8.1.1 Additional Error Handling in the Network Mode State Machine

#### 8.1.2 API CanSM\_InitMemory()

#### 8.1.3 Error Code

> CANSM\_E\_PARAM\_CONTROLLER

> CANSM\_E\_MODE\_CHANGE

> CANSM\_E\_SETTRANSCEIVERMODE

#### 8.1.4 Configuration Options

>

> Rx deadline monitoring

> Rx deadline monitoring

#### 8.1.5 API CanSM\_PreventBusSleepAtStartup()

#### 8.1.6 ECU passive mode

#### 8.1.7 Bus-off notification

#### 8.1.8 Support for XCP shutdown

### 8.1.9 No mode notification during CanSM\_Init

CANSM\_INIT

CANSM\_NO\_COMMUNICATION

### 8.1.10 Partial Networks

### 8.1.11 BswM ComMode Indication

- CANSM\_BSWM\_NO\_COMMUNICATION
- CANSM\_BSWM\_SILENT\_COMMUNICATION
- CANSM\_BSWM\_FULL\_COMMUNICATION
- CANSM\_BSWM\_BUS\_OFF

### 8.1.12 Multiple Identity

### 8.1.13 Additional Dem error

>

Hw Repetition

>

### 8.1.14 Additional bus-off recovery in state silent

## 8.2 Limitations

### 8.2.1 Controllers



## 9 Glossary and Abbreviations

### 9.1 Glossary

| Term | Description |
|------|-------------|
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |
|      |             |

### 9.2 Abbreviations

| Abbreviation | Description |
|--------------|-------------|
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |
|              |             |



## 10 Contact

[www.vector-informatik.com](http://www.vector-informatik.com)