

Omc Classic Integration Manual

Project BMW AUTOSAR 4 Core Rel. 3
 Author BMW AG
 Release Date 2017-12-14
 Version 5.2.0
 Status Release
 Hotline +49 89 382 - 32233
 Contact bac@bmw.de
<https://asc.bmw.com/jira/browse/BSUP> (extern)
<https://asc.bmwgroup.net/jira/browse/BSUP> (intern)

Revision History

Version	Date	Description
5.2.0	2017-12-14	BAC-6565: document callback mechanism to establish intrinsic safety (AllowModeChange and OmcOperatingModeCallout)
5.1.1	2017-10-12	Version Update
5.1.0	2017-08-10	Version Update
5.0.0	2017-06-29	Initial version for SP2021

Company

Bayerische
 Motoren Werke
 Aktiengesellschaft

Postal address

BMW AG
 80788 München

Office address

Forschungs- und
 Innovationszentrum
 (FIZ)
 Hufelandstr. 1
 80937 München

Telephone

Switchboard
 +49 89 382-0

Internet

www.bmwgroup.com

Table of Contents

1	Introduction	4
1.1	Functional overview	4
2	Related documentation	5
3	Limitations	6
4	Software Architecture	7
4.1	Dependencies on AUTOSAR modules	7
4.1.1	RTE	7
4.1.2	Det	7
4.1.3	Dcm	7
4.1.4	Dem	7
4.1.5	Nvm	7
4.2	Dependencies to other modules	7
5	Integration	8
5.1	Configuration of other Modules	8
5.1.1	Dcm	8
5.1.1.1	Read Data By Identifier	8
5.1.1.2	Routine Control	8
5.1.2	NvM	8
5.1.3	Dem	9
5.1.3.1	Enable Condition	9
5.1.3.2	Event	9
5.1.4	BswM	9
5.1.5	Det	9
5.2	Provided Interfaces	10
5.2.1	OmcOperatingMode and OmcExtendedOperatingMode	10
5.2.2	OmcModesCalloutsResult	10
5.3	Required Interfaces	10
5.3.1	OmcModesCallouts	10
5.4	Configuration	10
5.4.1	OmcGeneral	10
5.4.1.1	OmcDevErrorDetect	10
5.4.1.2	OmcOperatingModeCallout	11
5.5	Configuration of the RTE	11
5.5.1	Event Mapping	11
5.5.2	Data Mapping	11
5.5.2.1	Dcm	11
5.5.2.2	Det	11
5.5.3	Dem	11
5.5.4	NvM	11
5.5.5	BswM	11
5.5.6	Exclusive Areas	12
5.6	Software Integration	12
5.6.1	Startup/Initialization	12

5.6.2	Normal Operation_____	12
5.6.3	Shutdown/Deactivation_____	12

1 Introduction

This Integration Manual describes the basis functionality, API and the configuration and integration of the BMW System Function Omc.

Functional overview

The main objective of the Omc functionality is to maintain the current Operating Mode of an ECU.

This means:

- Allowing the change of the current Operating Mode via diagnostic request
- Saving the current Operating Mode to Non Volatile RAM (NVRAM)
- Enabling/disabling Dem (more concrete: Setting/Unsetting a enable condition)
- Providing the current Operating Mode to other software components.

The Omc module distinguishes the following vehicle operating modes:

- NORMAL
- ASSEMBLY
- TRANSPORT
- FLASH

Note that in different documents these modes are sometimes called "energy modes" sometimes called "operating modes". Although both terms are equivalent, we strictly use the term operating mode.

2 Related documentation

References

3 Limitations

No limitations are known.

4 Software Architecture

Dependencies on AUTOSAR modules

The current version of the Module Omc depends on the following BSW modules:

RTE

As a software component, the Omc module uses Rte client/server communication to communicate with other SWCs and BSW. Additionally the scheduling is done by the Rte.

Det

In case Det usage is enabled in the Omc configuration, Omc will report development errors by using the Det functionality.

Dcm

The Dcm will call functionality of the Omc module when a RDBI for the operating mode or the extended operating mode has been received. The corresponding R-ports of the Dcm for these two identifiers must be connected with the corresponding P-ports of the Omc.

Dem

The Omc use the operation SetEventStatus of the CSI DiagnosticMonitor to set an Event via Rte. It also uses the ClientServer Interface of service EnableCondition.

Nvm

The Omc relies on services provided by the Nvm to store its persistent data regarding the current operating mode and current extended operating mode.

Dependencies to other modules

Omc does not have dependencies to other modules.

5 Integration

Configuration of other Modules

The following modules shall be configured, before this module can be generated, compiled and linked.

Dcm

Read Data By Identifier

[] [Two Read Data By Identifier commands shall be configured within Dcm (22 10 0A and 22 10 0E).
](DK_T3_736, DK_T3_762, FZM_SC_SYS_PA_335, DK_T3_1255)

- DcmDspDataSize shall be set to 8
- DcmDspDataUsePort shall be set to USE_DATA_SYNCH_CLIENT_SERVER
- DID shall be configured to be read in all sessions and security levels

Routine Control

[] [Two Routine Control commands shall be configured within Dcm (31 01 0F 0C and 31 01 10 03).
](DK_T3_720, DK_T3_725, DK_T3_727, DK_T3_729, DK_T3_751, FZM_SC_SYS_PA_334, FZM_SC_SYS_PA_334)

- DcmDspRoutineFixedLength shall be true
- DcmDspRoutineUsePort shall be true
- Only DcmDspStartRoutineIn shall be configured
 - DcmDspRoutineSignalLength shall be set to 8
 - DcmDspRoutineSignalPos shall be set to 0

NvM

The Omc needs a Nvm block to store the operating mode:

[] [

- block size shall be set to 2 bytes
- Ram block address shall be set to Omc_NvData
- Rom block address shall be set to Omc_DefaultNvData
- NvmBlockManagementType shall be set to NVM_BLOCK_NATIVE
- NvmBlockUseCrc shall be disabled
- NvmSelectBlockForReadall shall be set to true

](DK_T3_743, FZM_SC_SYS_PA_169, FZM_SC_SYS_PA_329, FZM_SC_SYS_PA_171, FZM_SC_SYS_PA_331)

Dem

Enable Condition

A EnableCondition for Omc shall be configured within Dem.

This EnableCondition shall be referenced by all EnableConditionGroups in the system, that depend on this EnableCondition.

Example: At BMW the permission to report communication error relevant Dem events depends on the state of different sources (operating mode, diagnostic state and Stm centralErrorLock). Each of these sources is connected to its own EnableCondition and all these conditions are combined in one EnableConditionGroup.

At the end, all Dem Events that represent communication errors shall reference this EnableGroup via their DemEnableConditionGroupRef parameter.

Event

An Dem event shall be configured for Omc.

□ [

- DTC value shall be set to $0x020000 + 0x100 * \text{ECU_Address}$
- Event destination: primary origin
- Event kind: DEM_EVENT_KIND_SWC
- A Clear Event Allowed port shall be configured via Rte
- Operation Cycle: this event shall reference an operation cycle which is started before OmcMode is INIT and stays in this state until OmcMode is STOP.

](DK_T3_711)

BswM

The BswM controls the states of the Omc module.

- BswMModeRequestPort for the Omc operation mode
- BswMRules to switch the Omc operation mode
- BswMRteSwitch actions for the Omc operation mode

Det

A Omc entry shall be added to the Software Component List from Det.

Provided Interfaces

OmcOperatingMode and OmcExtendedOperatingMode

The Omc provides two RTE Modes which indicate the operating and extended operating mode which are currently active.

OmcModesCalloutsResult

This interface may be used by the user if OmcOperatingModeCallout is set to true when the interfaces AllowOpModeSwitch or OpModeSwitchCancelled returns RUNNING.

The user may indicate over this interface using the following operations:

- OpModeSwitchAllowedResult: shall be called if AllowOpModeSwitch returned *E_{RUNNING}* to inform the Omc if a mode or extended mode switch is allowed or not. *OpModeSwitchCancelledAck* shall be called if *OpModeSwitchCancelled* returned *E_{RUNNING}* to inform the Omc that the mode or extended mode switch has been cancelled.

Required Interfaces

OmcModesCallouts

The user has to provide this interface if the parameter OmcOperatingModeCallout is set to true.

The following two operations shall be implemented:

- AllowOpModeSwitch: is called by Omc during a diagnose request to change the operating or extended operating mode. The user will be able to accept or deny this request.
- OpModeSwitchCancelled: if the interface AllowOpModeSwitch has been called and the operating or extended operating mode change is not performed the user is informed over this interface that the change has been cancelled. This may happen e.g. if an error occurs while trying to store the new operating mode in non volatile memory.

Configuration

OmcGeneral

This container contains the configuration parameters of the Omc

OmcDevErrorDetect

Activate/Deactivate the Development Error Detection and Notification.

If set to true: Development Error Detection and Notification activated. If set to false: Development Error Detection and Notification deactivated.

OmcOperatingModeCallout

Activate/Deactivate an user callback to be able to accept or deny a mode or extended mode change. If set to true: The application provides one or more instances of the service AllowModeChange. The user may control over this interface if mode or extended mode change is allowed or not. The user is only called to allow or not a mode or extended mode change only if the mode change has already be accepted by StdDiag. If set to false: Omc decides with StdDiag if a mode or extended mode change allowed is or not.

Configuration of the RTE

Event Mapping

The followings runnable entities shall be mapped:

- Init
- RollbackModeChange

Data Mapping

Dcm

- The port ControlEnergySavingState shall be connected to the Dcm generated RoutineServices_<xxx> see 6.1 Dcm, Routine Control.
- The port ControlExtendedEnergySavingState shall be connected to the Dcm generated RoutineServices_<xxx> see 6.1 Dcm, Routine Control.
- The port EnergySavingState shall be connected to the Dcm generated DataServices_<xxx> see 6.1 Dcm, Read Data By Identifier
- The port ExtendedEnergySavingState shall be connected to the Dcm generated DataServices_<xxx> see 6.1 Dcm, Read Data By Identifier.

Det

- The port DETServicePort shall be connected to the Det generated service port see 6.1 Dem, Det.

Dem

- The port ClearEventAllowedPort shall be connected to the Dem generated clear event allowed port see 6.1 Dem, Event.
- The port operatingModeEvent shall be connected to the Dem generated Diagnostic Monitor port see 6.1 Dem, Event.

NvM

- The port NvMServicePort shall be connected to the NvM generated service port see 6.1. NvM.

BswM

- The port notificationOMCModePort shall be connected to the BswM generated mode switch port see 6.1 BswM.
- The prot requestOmcModePort shall be connected to the BswM generated mode request port see 6.1. BswM.

Exclusive Areas

Omc uses one Exclusive Area called Mode.

Software Integration**Startup/Initialization**

The NvM ReadAll shall be complete before the Omc mode OMC_INITIALIZED is requested. The initialization is complete when the mode switch to OMC_INITIALIZED (triggered by Omc) is completed. While in OMC_INITIALIZED the integrator shall decide the best moment to BswM to request OMC_RUNNING. After requesting OMC_RUNNING Omc will switch the mode to OMC_RUNNING. When the switch is completed the Omc will be running. To request a specific state the user shall use the port LifeCycleRequest.

Normal Operation**Shutdown/Deactivation**

The BswM shall request the Omc Mode to OMC_STOPPED to stop the Omc SW-C. The module is stopped when the mode switch to OMC_STOPPED (triggered by Omc) is completed.