

Pin Connection

Servo & Arduino:

- Vcc to Vcc
- GND to GND
- Signal Pin to Pin3

IR1 & Arduino:

- Out to A2
- Vcc to Vcc
- GND to GND

IR2 & Arduino:

- Out to A3
- Vcc to Vcc
- GND to GND

Display & Arduino:

- GND to GND
- Vcc to VCC
- SDA to A4
- SCL to A5

RFID & Arduino:

- GND to GND
- 3.3V to 3.3V
- Reset to Pin9
- SDA to Pin10
- SCK to Pin13
- MOSI to Pin11
- MISO to Pin12