

SEL-267-0, -2 Relay

Phase and Ground Directional Overcurrent Relay With Recloser and Fault Locator

Instruction Manual

20071030



SCHWEITZER ENGINEERING LABORATORIES, INC.





WARNING: This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.



AVERTISSEMENT: Cet équipement est expédié avec des mots de passe par défaut. A l'installation, les mots de passe par défaut devront être changés pour des mots de passe confidentiels. Dans le cas contraire, un accès non-autorisé à l'équipement pourrait être possible. SEL décline toute responsabilité pour tout dommage résultant de cet accès non-autorisé.

© 1997-2007 by Schweitzer Engineering Laboratories, Inc. All rights reserved.

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission. SEL products appearing in this document may be covered by US and Foreign patents.

Schweitzer Engineering Laboratories, Inc. reserves all rights and benefits afforded under federal and international copyright and patent laws in its products, including without limitation software, firmware, and documentation.

The information in this manual is provided for informational use only and is subject to change without notice. Schweitzer Engineering Laboratories, Inc. has approved only the English language manual.

This product is covered by the standard SEL 10-year warranty. For warranty details, visit www.selinc.com or contact your customer service representative.

PM267-01

SEL-267, -2 INSTRUCTION MANUAL

TABLE OF CONTENTS

SECTION 1: INTRODUCTION

SECTION 2: SPECIFICATIONS

SECTION 3: COMMUNICATIONS

SECTION 4: EVENT REPORTING

SECTION 5: INSTALLATION

SECTION 6: MAINTENANCE AND TESTING

SECTION 7: APPENDICES

Appendix A: Firmware and Manual Versions

Appendix B: Internal and Logic Diagrams

**Appendix C: ONEBUS: Program to Compute Test Set Settings
for Testing Distance Relays**

Appendix D: Modem Communications

SETTING SHEETS

SEL-267 RELAY COMMAND SUMMARY

TABLE OF CONTENTS

SECTION 1: INTRODUCTION.....	1-1
Overview.....	1-1
Conventional Terminal Block Model.....	1-1
Plug-In Connector Model.....	1-1
Basic Protective Capabilities	1-1
Phase and Three-Phase Faults.....	1-2
Ground Faults.....	1-2
Overload Alarm or Protection.....	1-2
Reclosing.....	1-3
General Information.....	1-3
Conventional Terminal Block Model.....	1-3
Plug-In Connector Model.....	1-4
ACB Phase Rotation Option	1-4
Kilometer Option	1-4

SECTION 1: INTRODUCTION

OVERVIEW

Conventional Terminal Block Model

The SEL-267 Phase and Ground Directional Overcurrent Relay with Recloser and Fault Locator may be applied to protect transmission, subtransmission, and distribution lines.

The features of the SEL-267 Relay include:

- Directional Overcurrent Protection for Phase and Ground Faults
- Versatile User-Programmable Logic
- Three-Shot Reclosing with Fuse-Saving Capability
- Fault Locating
- Event Recording
- Automatic Self-Testing
- Metering, Including Demand
- Target Indicators for Faults and Testing
- Time Code Input
- Front and Rear Panel Communication Ports for Local and Remote Access

Plug-In Connector Model

- All Features of the Standard Terminal Block Model
- High Current Interrupting Output Contacts
- Quick Connect/Release Hardware for Real-Panel Terminals
- Time Code Input Access on All Rear Communications Ports

BASIC PROTECTIVE CAPABILITIES

The SEL-267 Relay provides complete directional overcurrent protection for faults of all types. The demand ammeter, with its programmable threshold and time constant, offers overload protection and alarm functions.

Analog inputs from current and voltage transformers are delivered to the protective relaying elements and saved for additional features, such as metering and fault locating.

The relay elements process the analog data. Intermediate logic is performed, including directional supervision of overcurrent elements and grouping of user-selectable elements.

The states of the intermediate results and other data are recorded in the Relay Word.

Logic for tripping, closing, and other purposes uses the Relay Word data. Most of that logic is programmable by logic masks.

Phase and Three-Phase Faults

Phase fault protection consists of three instantaneous phase overcurrent elements and a time-overcurrent element. The three overcurrent elements are directionally supervised by the phase directional element for both three-phase and phase-to-phase faults. To securely discriminate between forward- and reverse-direction faults, the torque threshold of the phase directional element must be exceeded for faults in either direction before fault direction is declared.

Each of the directionally supervised outputs of the overcurrent elements drive timers. The Relay Word contains the instantaneous nondirectional outputs (50P1, 50P2, 50P3), the instantaneous directional outputs (67P1, 67P2, 67P3), and the definite-time delayed outputs (Z1PT, Z2PT, Z3PT). The direction of 67P3/Z3PT may be reversed. The directionality for all three elements may also be disabled (67NE=N, 67PE=N).

A time-overcurrent element (51P) with selectable curve shapes is provided. It may be directionally supervised if desired.

Ground Faults

Ground fault protection consists of three instantaneous residual-overcurrent elements (50N1, 50N2, 50N3) and a residual time-overcurrent element (51N).

Direction is determined by either a negative-sequence directional element or a dual-polarized zero-sequence element. Settings are provided to select either negative-sequence polarization or zero-sequence polarization of the ground overcurrent elements. To securely discriminate between forward- and reverse-direction faults, the directional elements have a torque threshold which must be exceeded in either direction before the fault direction relay function block diagram is declared. The directionally supervised instantaneous elements are designated 67N1, 67N2, and 67N3. They drive timers whose outputs are Z1GT, Z2GT, and Z3GT.

The direction of 67N3/Z3GT may be reversed to assist in blocking schemes, weak-infeed schemes, and local bus protection for looped or double-feed circuits. Directionality may also be disabled for all three elements.

The curve shape of the time-overcurrent element is user-selectable. This element is either non-directional or forward-reaching, as enabled.

Overload Alarm or Protection

The demand ammeter feature of the SEL-267 Relay has a programmable time constant and a settable threshold. When demand (maximum of the three phases) reaches the setpoint, a bit (DCTH) in the Relay Word is set. By programming a mask, this bit may be routed to one of the programmable outputs for an alarm, to initiate tripping, or perform any other desired function. Since the demand interval (time constant) is settable, it may be programmed to match the time constant of a protected apparatus, e.g., transformer, reactor, or line.

Reclosing

A three-shot reclosing relay is provided. Reclosing may be initiated or cancelled for any conditions recorded in the Relay Word, and is accomplished by programming the Reclose Initiate and Reclose Cancel masks.

The Shot 1 (SH1) bit is included in the Relay Word for fuse saving schemes. The SH1 bit asserts after the first reclose in a reclose sequence and remains asserted during the following reclose shots. You may program one of the four programmable output contacts with the SH1 bit. This programmable output may then be used to energize the Block Trip (BT) input of the SEL-267 Relay. The elements in the SEL-267 MTB mask can then be programmed to be blocked from tripping during the next reclose attempts thus creating a fuse-saving scheme.

GENERAL INFORMATION

Conventional Terminal Block Model

Communications functions provide remote and local examination of a wide range of data, including the voltages and currents presented to the instrument, relay settings, and a history of the twelve most recent events. Relay settings may be entered and modified remotely. The relay also allows circuit breaker control via the communications channels. A secure two-level password access scheme protects settings and circuit breaker control. An alarm contact output monitors the relay and may be used to alert personnel of an unauthorized access attempt.

The SEL-267 Relay includes a fault locator which uses fault type, pre-fault, and fault conditions to provide an accurate fault location without the need for communications channels, special instrument transformers, or source impedances, even during conditions of substantial load flow and fault resistance.

The relay generates a detailed event report after every fault. This report includes all data needed to quantitatively examine the prefault, fault, and postfault voltages and currents. Parameters such as fault current sensed by the relay, relay response time, and total fault clearing time can easily be determined. The event report includes the distance to the fault, fault type, and the state of all relay elements during the event. Each event is time-tagged by a self-contained clock. In addition to the automatic generation of this report for faults, operators may generate a report upon command, or by asserting one of several control inputs to the instrument. This allows users to trigger the report from other equipment, such as oscillographic starting units or other relaying systems. The SEL-267 Relay retains the twelve most recent event reports. A user may recall any of these reports on command.

Phasor diagrams of the voltages and currents showing pre-fault, fault, and post-fault conditions can be constructed from the fault report. This accurate information is useful in verifying short-circuit and load-flow calculations, verifying transmission line constants, and measuring voltage and current unbalance. It can also be used to check the input connections for proper phase-sequence rotation and polarity.

This instrument is designed to provide long-term accuracy and availability. Amplitude-dependent measurements are made with respect to an internal voltage reference which is stable and precise. Extensive self-testing functions monitor the voltage reference. Long-term phase stability is guaranteed, since all phase-shifting operations are performed by precise time delays controlled from a quartz-crystal oscillator.

Plug-In Connector Model

The general information presented for the Conventional Terminal Block model relay fully applies to the Plug-In Connector model. In addition, the following information applies strictly to the Plug-In Connector model.

Custom wiring harnesses can be prewired, which enables quick and easy relay installation. The Plug-In Connectors attach to dc power, CT and PT inputs, and contact inputs and outputs. CT secondaries are automatically shorted inside the Plug-In Connector when removed from the relay. During in-service testing, spare connectors can be wired to auxiliary test equipment and plugged directly into the relay. The actual source and I/O connectors may simply be unplugged before each test and reconnected afterwards. If there is a need to replace a relay, the connectors can be unplugged and reconnected to the new relay in a matter of minutes. There is no need for a wiring check because the connections were verified at installation and no wiring was disturbed during the replacement process.

High-current interrupting contacts are standard on the SEL-267 Plug-In Connector model. These contacts use an electromechanical relay with solid state circuitry to interrupt dc currents far in excess of a typical contact output. No SCRs are employed in this circuitry. The circuit is designed to make 30 Adc, carry 6 Adc, and interrupt 10 Adc. The circuit can interrupt 10 A four times in one second, and then must be allowed to cool for two minutes to prevent thermal damage.

ACB Phase Rotation Option

The SEL relay instruction manuals are written for standard ABC phase rotation applications. If your SEL relay is ordered with the ACB phase rotation option, references made in the instruction manual to voltage and current phase angle should be noted accordingly. The firmware identification number (FID) may be used to verify whether your relay was ordered with ABC or ACB rotation.

All current and voltage inputs are connected to the SEL relay rear panel as shown in the instruction manual.

Kilometer Option

The SEL-267 Relay instruction manual is written for fault locations in terms of miles. If your SEL-267 Relay is ordered with the kilometer line length option, references made in the instruction manual to miles should be substituted with kilometers.

One exception to the straight substitution of kilometers for miles is the reference in the instruction manual to the effect of shunt capacitance on the fault location calculation. The line length equation and associated paragraphs, corrected for a 100-kilometer line, should read:

Shunt capacitance of the transmission line is not taken into account. The capacitance causes the fault location to appear less remote by, approximately, a factor of $1/\cos(bL)$, where bL is the line length in radians at 60Hz. One wavelength at 60 Hz is 4989 kilometers. For example, the line length of a 100-kilometer line in radians, is:

$$(100/4989) * 2 * 3.14159 = 0.1260 \text{ radians}$$

The indication neglecting capacitance is about $\cos(0.1260) = 0.992$ times the actual fault location, or about 0.8 kilometers short for a fault at the remote end of a 100-kilometer line.

TABLE OF CONTENTS

SECTION 2: SPECIFICATIONS2-1

General Specifications	2-1
Relay Standards and Input Parameters Common to All SEL-267 Models	2-4
Directional Overcurrent Protection for Phase Faults	2-4
Directional Residual-Overcurrent Protection for Ground Faults	2-4
Automatic Reclosing.....	2-4
Fault Location	2-4
Metering	2-4
Event Reporting	2-5
Self-Testing	2-5
Detailed Specifications	2-5
Phase Overcurrent (secondary values).....	2-5
Ground Overcurrent (secondary values)	2-5
Demand Overcurrent.....	2-6
Directional Elements.....	2-6
Zero-Sequence Directional Element	2-6
Three-Shot Reclosing Relay	2-6
Hardware Description	2-6
Mechanical Features	2-7
Signal Processing.....	2-8
Introduction.....	2-8
Input Descriptions.....	2-8
Serial Interfaces.....	2-8
Input Power	2-8
Contact Inputs	2-9
Direct Trip (DT).....	2-9
Direct Close (DC) Input	2-9
Permissive Trip (PT)	2-9
Block Trip (BT).....	2-9
Circuit Breaker Monitor (52A)	2-9
External Trigger for Event Report (ET).....	2-9
Potential Inputs	2-10
Current Inputs	2-10
Input Configurations and Specifications (Conventional Terminal Block Model)	2-10
Serial Interfaces.....	2-10
Contact Inputs	2-11
Input Configurations and Specifications (Plug-In Connector Model)	2-11
Serial Interfaces.....	2-11
Input Power	2-12
Contact Inputs	2-12
Potential Inputs.....	2-13
Current Inputs.....	2-13
Relay Output Descriptions.....	2-13
TRIP Output	2-13
CLOSE Output	2-13
ALARM Output	2-13
Programmable Outputs (A1, A2, A3, A4).....	2-13
Output Configurations and Specifications (Conventional Terminal Block Model).....	2-14

Plug-In Connector Model.....	2-14
Definition of Logic Variables	2-15
Logic Description	2-15
Relay Elements	2-15
Timers	2-15
Enables From Setting Procedure.....	2-16
Contact Inputs	2-16
Contact Outputs.....	2-16
Intermediate Logic	2-16
Relay Word.....	2-17
Output Equations	2-19
Reclosing Relay	2-20
DC Input Operates as Reclose Enable for the SEL-267-2 Relay Model.....	2-20
Targets	2-20
Self-Tests	2-21
Offset.....	2-21
Power Supply	2-21
Random-Access Memory.....	2-22
Read-Only Memory	2-22
Analog-to-Digital Converter.....	2-22
Master Offset.....	2-22
Settings.....	2-22
Setting Procedure	2-23
Event Report	2-23
Fault Locator.....	2-24
Directional Elements.....	2-26
Time-Overcurrent Elements and Curves.....	2-26
Time-Overcurrent Curve Equations.....	2-27

TABLES

Table 2.1: Port Pin Assignments for Conventional Terminal Block Model.....	2-10
Table 2.2: Input Parameters for Conventional Terminal Block Model	2-11
Table 2.3: Port Pin Assignments for Plug-In Connector Model	2-12
Table 2.4: Input Parameters for the Plug-In Connector Model.....	2-12
Table 2.5: Relay Outputs for Conventional Terminal Block Model.....	2-14
Table 2.6: Relay Outputs for Plug-In Connector Model.....	2-14
Table 2.7: Relay Word.....	2-18
Table 2.8: Relay Word Bit Summary.....	2-18
Table 2.9: Front Panel Target Conditions for Illumination.....	2-20
Table 2.10: Power Supply Self-Test Limits.....	2-21
Table 2.11: Self-Test Summary	2-22

FIGURES

Figure 2.1: Hardware Block Diagram.....2-7

Figure 2.2: Programmable Trip Logic Diagram2-19

Figure 2.3: Moderately Inverse Curves.....2-28

Figure 2.4: Inverse Curves2-28

Figure 2.5: Very Inverse Curves2-28

Figure 2.6: Extremely Inverse Curves2-28

SECTION 2: SPECIFICATIONS

GENERAL SPECIFICATIONS

<u>Voltage Inputs</u>	115 volts phase-to-phase, three-phase, 4-wire connection
<u>Current Inputs</u>	5 A per phase nominal 15 A per phase continuous 500 A for one second thermal rating
<u>Output Contacts</u>	Conventional Terminal Blocks 30 A make per IEEE C37.90:1989 6 A continuous carry MOV protection provided Plug-In Connectors (High-Current Interrupting) 30 A make per IEEE C37.90:1989 6 A continuous carry 330 Vdc MOV for different surge protection Pickup/dropout time: <5 ms Breaking Capacity: 10 A 24, 48, and 125 Vdc (L/R = 40 ms) 250 Vdc (L/R = 20 ms) Cyclic Capacity: 10 A 4 cycles in 1 second, followed by 2 minutes idle for the thermal dissipation Pickup/Dropout time: <5 ms
<u>Optoisolated Inputs</u>	Conventional Terminal Blocks The following optoisolated inputs draw 4 mA when nominal control voltage is applied (relays equipped with conventional terminal blocks): 24 Vdc: 15–30 Vdc 48 Vdc: 30–60 Vdc 250 Vdc: 150–300 Vdc Fixed “Level-Sensitive” inputs are provided on relays with 125 Vdc optoisolated inputs. The 125 Vdc optoisolated inputs each draw 6 mA when nominal voltage is applied. The inputs operate as shown below: 125 Vdc: on for 100–150 Vdc; off below 75 Vdc Plug-In Connectors Fixed “Level-Sensitive” inputs are provided on relays with 48/125 Vdc optoisolated inputs. The 48/125 Vdc optoisolated inputs each draw 6 mA when nominal voltage is applied. The inputs operate as shown below: 5 mA at nominal voltage: 48 Vdc: on for 38–60; off below 29 Vdc 6 mA at nominal voltage: 125 Vdc: on for 100–150 Vdc; off below 75 Vdc
<u>Power Supply</u>	24/48 Volt: 20–60 Vdc; 12 watts 125/250 Volt: 85–350 Vdc or 85–264 Vac; 12 watts
<u>Dimensions</u>	See Figure 5.8.

<u>Dielectric Strength</u>	V, I inputs: 2500 Vac for 10 seconds Other: 3000 Vdc for 10 seconds (excludes EIA-232 and time code input)
<u>Operating Temperature</u>	–40° to 158°F (–40° to 70°C)
<u>Interference Tests</u>	IEEE C37.90 SWC Test (type tested) IEC 255-6 Interference Test (type tested)
<u>Impulse Tests</u>	IEC 255-5 0.5 Joule, 5000 Volt Test (type tested)
<u>RFI Tests</u>	Type tested in field from a quarter-wave antenna driven by 20 watts at 150 MHz and 450 MHz, randomly keyed on and off one meter from relay.
<u>Unit Weight</u>	12 pounds (5.5 kg), SEL-267 Relay
<u>Shipping Weight</u>	17 pounds (7.7 kg), SEL-267 Relay, including one instruction manual
<u>Environmental Type Tests</u>	<p>IEEE C37.90-1989 <i>IEEE Standards for Relays and Relay Systems Associated with Electrical Power Apparatus, Section 8: Dielectric Tests</i> Severity Level: 2500 Vac on analog inputs; 3000 Vdc on power supply, contact inputs and contact outputs</p> <p>IEEE C37.90.1-1989 <i>IEEE Standard Surge Withstand Capability (SWC) Tests for Protective Relays and Relay Systems</i> Severity Level: 3.0 kV oscillatory, 5.0 kV fast transient</p> <p>IEEE C37.90.2 (Issued for trial use December 1987) <i>IEEE Trial-Use Standard, Withstand Capability of Relay Systems to Radiated Electromagnetic Interference from Transceivers</i> Severity Level: 10 V/m</p> <p><u>Exceptions:</u></p> <p>5.5.2 (2) Performed with 200 frequency steps per octave 5.5.3 Digital Equipment Modulation Test not performed 5.5.4 Test signal turned off between frequency steps to simulate keying</p> <p>IEC 68-2-1 Fifth Edition-1990 <i>Environmental testing, Part 2: Tests - Test Ad: Cold</i> Severity Level: 16 hours at –40°C</p> <p>IEC 68-2-2 Fourth Edition-1974 <i>Environmental testing, Part 2: Tests - Test Bd: Dry heat</i> Severity Level: 16 hours at +85°C</p> <p>IEC 68-2-30 Second Edition-1980 <i>Basic environmental testing procedures, Part 2: Tests - Test Db and guidance: Damp heat, cyclic (12 + 12-hour cycle)</i> Severity Level: 55°C, 6 cycles</p>

IEC 255-5 First Edition-1977

Electrical relays, Part 5: Insulation tests for electrical relays,

Section 6: Dielectric Tests

Severity Level: Series C (2500 Vac on analog inputs; 3000 Vdc on power supply, contact inputs and contact outputs)

Section 8: Impulse Voltage Tests

Severity Level: 0.5 Joule, 5000 volt

IEC 255-21-1 First Edition-1988

Electrical relays, Part 21: Vibration, shock, bump, and seismic tests on measuring relays and protection equipment, Section One - Vibration tests (sinusoidal)

Severity Level: Class 1

IEC 255-21-2 First Edition-1988

Electrical relays, Part 21: Vibration, shock, bump, and seismic tests on measuring relays and protection equipment, Section Two - Shock and bump tests

Severity Level: Class 1

IEC 255-22-1 First Edition-1988

Electrical disturbance tests for measuring relays and protection equipment, Part 1: 1 MHz burst disturbance tests

Severity Level: 2.5 kV peak common mode, 1.0 kV peak differential mode

IEC 255-22-3:1989

Electrical relays, Part 22: Electrical disturbance tests for measuring relays and protection equipment, Section Three - Radiated electromagnetic field disturbance tests

Exceptions:

4.3.2.2 Frequency sweep approximated with 200 frequency steps per octave

IEC 801-2 Second Edition-1991-04

Electromagnetic compatibility for industrial-process measurement and control equipment, Part 2: Electrostatic discharge requirements

Severity Level: 4

IEC 801-3

Electromagnetic compatibility for industrial process measurement and control equipment, Part 3: Radiated electromagnetic field requirements

Severity Level: 10 V/m

Exceptions:

9.1 Frequency sweep approximated with 200 frequency steps per octave.

IEC 801-4 First Edition-1988

Electromagnetic compatibility for industrial process measurement and control equipment, Part 4: Electrical fast transient/burst requirements

Severity Level: 4 (4 kV on power supply, 2 kV on inputs and outputs)

RELAY STANDARDS AND INPUT PARAMETERS COMMON TO ALL SEL-267 MODELS

Directional Overcurrent Protection for Phase Faults

- Nine phase overcurrent elements in three groups.
- Three timers, one per group.
- Polyphase time-overcurrent element with selectable curve shapes.
- Phase directional element operates from negative-sequence and positive-sequence quantities. The negative-sequence voltamperes are weighted four times the positive-sequence voltamperes.

Directional Residual-Overcurrent Protection for Ground Faults

- Three definite-time elements.
- One time-overcurrent element with selectable curve shapes.
- Negative- and zero-sequence directional elements for ground faults.
- Zero-sequence element is dual polarized.

Automatic Reclosing

For selectable fault types (3 shots).

Fault Location

Fault location is computed using event reports stored following each fault. The algorithm compensates for prefault current, improving accuracy for high-resistance faults.

Metering

All metered quantities are displayed in primary units.

- Voltage:** Phase-neutral voltages are measured, scaled to primary, and displayed upon command. Calculated phase-to-phase voltages are also displayed.
- Current:** Each phase current is measured, scaled to primary, and displayed on command. Calculated phase-to-phase currents are also displayed.
- Demand:** Current demand is computed with a 5 to 60 minute time constant. To see the current demand, issue a **METER** command. Peak demand is determined and stored, and is resettable by command. A demand threshold setting is provided. When the demand exceeds the setting, the DCTH bit in the Relay Word is set. This bit can be used for tripping, annunciation, alarm, etc.
- Power:** MW and MVAR are determined by a three-phase, four-wire calculation.

Event Reporting

The relay retains a data record with current, voltage, relay element, and input/output contact information for each of the 12 most recent faults. The report may also be triggered by command or contact closure. When tripping occurs after the end of the event report, a second report is triggered at tripping.

Self-Testing

- Analog ac channel offset errors
- Stall timer monitors processor
- Power supply voltage checks
- Setting checks
- RAM, ROM, and A/D converter tests

DETAILED SPECIFICATIONS

Phase Overcurrent (secondary values)

- 51P Phase time-overcurrent element
Selectable curve shape (4 curves)
Time Dial: 0.50 to 15.00 in steps of 0.01
Pickup: 1 to 12.6 A, ± 0.05 A $\pm 2\%$ of setting
- 50A1, 50B1, 50C1 Zone 1 phase overcurrent elements (50P1).
- 50A2, 50B2, 50C2 Zone 2 phase overcurrent elements (50P2).
- 50A3, 50B3, 50C3 Zone 3 phase overcurrent elements (50P3).
Pickup: 1 to 25 times 51P pickup

Timers are provided for each zone:

Zone 1 Timer: 0–60 cycles in 0.25 cycle steps
Zone 2 Timer: 0–2000 cycles in 0.25 cycle steps
Zone 3 Timer: 0–2000 cycles in 0.25 cycle steps

Ground Overcurrent (secondary values)

- 51N Residual time-overcurrent element
Selectable curve shape (4 curves)
Time dial: 0.50 to 15.00 in steps of 0.01
Pickup: 0.25 to 6.3 A, ± 0.05 A $\pm 2\%$ of setting
- 50N1, 50N2, 50N3 residual-overcurrent elements.
Pickup: 0.2 to 47 times 51N pickup
Timers are provided for 50N1, 50N2, and 50N3:
Zone 1 Timer: 0–60 cycles in 0.25 cycle steps
Zone 2 Timer: 0–2000 cycles in 0.25 cycle steps
Zone 3 Timer: 0–2000 cycles in 0.25 cycle steps

Demand Overcurrent

- DCTH Phase demand overcurrent element.
Pickup: 51PP \leq 4.0 A, secondary; 0.7 to 60.2 A, secondary
51PP > 4.0 A, secondary; 0.2 to 14.9 times 51PP setting, where 51PP is the phase-time overcurrent element pickup setting. See Meter function description.

Directional Elements

- Phase directional element:
Angle: MTA (maximum torque angle) setting (47–90 degrees in 1 degree steps).
Sensitivity: 1 VA of positive-sequence and 0.25 VA of negative-sequence at MTA
Memory: Eight cycles
- Negative-sequence directional element:
Angle: MTA setting (47–90 degrees in 1 degree steps).
Sensitivity: Proportional to 51P pickup for $4A < 51PP < 12.6A$:
0.35VA at 12.6 A pickup at MTA
0.11VA at 4.0 A pickup and below at MTA

Zero-Sequence Directional Element

- Voltage polarization:
Angle: MTA setting (47–90 degrees in 1 degree steps).
Sensitivity: (0.125 volts) X (51N pickup setting) at MTA in units of zero-sequence volts times residual amps, and $V_0 > 0.17V$.
- Current polarization:
Angle: Zero degrees
Sensitivity: (0.5 amps) X (51N pickup setting), at zero degrees, in units of residual amps squared, and $I_{pol} > 0.5$ amps.

Note: The MTA setting is common to all three directional elements.

Three-Shot Reclosing Relay

79OI1 open interval 1,
79OI2 open interval 2,
79OI3 open interval 3:
Timer ranges: 0–10,000 cycles in 0.25 cycle steps. A setting of 0 disables that shot and successive shots.
79RS reset interval:
Timer range: 60–8,000 cycles in 0.25 cycle steps

HARDWARE DESCRIPTION

Figure 2.1 illustrates the major parts of the relay. Current and voltage inputs are isolated by magnetic input transformers. The signals are low-pass filtered, sampled by sample/hold amplifiers, and multiplexed to a programmable-gain amplifier. The amplifier output drives an analog-to-digital converter. Each analog channel is sampled four times per power-system cycle.

The microcomputer consists of an eight-bit microprocessor, ROM (read-only memory) for program storage, RAM (random-access memory) for data storage, and EEPROM (electrically erasable programmable ROM) for storing the relay settings. The EEPROM saves settings even during power loss. Input/output (I/O) devices connected to the microcomputer bus provide for the control of the output relays, targets, and monitor inputs such as the state of the breaker 52A contact. Other I/O devices provide communications for setting, reporting fault location, and other purposes. The relay includes an input for time code which allows users to synchronize the internal time clock with an external source of time code.

Mechanical Features

The majority of the SEL-267 Relay components are contained on a drawout assembly. The only components remaining in the relay housing are the instrument transformers and the switching power supply.




Figure 2.1: Hardware Block Diagram

SIGNAL PROCESSING

The relay low-pass filters all analog input channels to remove high frequency components. Next it samples each channel four times per power-system cycle. After low-pass filtering, the relay digitally filters each sample with the CAL digital filter method. The CAL filter eliminates dc offset and reduces the decaying exponential offset that may be present on the input signal following a fault.

The digital filter has the properties of a double differentiator smoother and requires only addition and subtraction of data samples. Let the latest four samples of one channel be X1, X2, X3, and X4. Then the digital filter is defined:

$$P = X1 - X2 - X3 + X4.$$

This filter eliminates dc offsets. When all samples are set to the same value, the filter output is zero. It also eliminates ramps, which you may verify by setting the samples equal to 1, 2, 3, and 4. Again, the output is zero.

Every quarter cycle, the relay computes a new value of P for each input. The current value of P combines with the previous value (renamed Q) to form a Cartesian coordinate pair. This pair represents the input signal as a phasor (P, Q). The relay processes these phasor representations of the input signals.

INTRODUCTION

This section describes all SEL-267 Relay inputs and outputs, relay elements, and the logic equations which relate them.

It also describes the self-tests and how they affect system operation.

INPUT DESCRIPTIONS

All connections to the SEL-267 Relay are made on the rear panel, except for one serial port connection. Front- and rear-panel drawings are included in **Section 5: Installation**.

Serial Interfaces

Connectors labeled Port 1, Port 2R, and Port 2F provide EIA-232 serial-data interfaces. Port 1 is normally used for remote communications via a modem, while Port 2R is used for local communications with an SEL-2020, SEL-PRTU, SEL-DTA, or SEL-RD. Port 2F is a second connector for Port 2, located on the front panel. Port 2F is typically used for temporary communication with the relay via a portable terminal.

Input Power

Terminals (44 and 45) should be connected to a source of control voltage. The relay power requirement is approximately 12 watts. Terminal 46 connects to the instrument frame, and should be wired to the relay rack ground reference.

Contact Inputs

Six input circuits are provided. They are listed below with terminal numbers in parentheses.

Direct Trip (DT)	(17,18)	Direct Close (DC)	(23,24)
Permissive Trip (PT)	(19,20)	52A Monitor (52A)	(25,26)
Block Trip (BT)	(21,22)	External Trigger (ET)	(27,28)

To assert an input, nominal control voltage is applied to the appropriate terminal pair. Polarity is unimportant. Input functions are explained below.

Direct Trip (DT)

Assertion of the DT input causes the TRIP output to close immediately and unconditionally if so enabled (see **LOGIC MTU** command). It also cancels any reclose initiation or reclose sequence if so enabled in the MRC mask (see the **LOGIC MRC** command) and triggers an event report. The TRIP output remains closed as long as the DT input is asserted and drops out about 0.5 cycle after the DT input deasserts or approximately 60 ms after the TRIP output first closed, whichever is later. Applications include reclose cancel, test trip, and Direct Underreaching Transfer Trip (DUTT) schemes. The **OPEN** command has the same effect as the DT input.

Direct Close (DC) Input

The Direct Close (DC) input for the SEL-267-2 Relay is redefined as a recloser enable and no longer serves as a direct close input. When the DC input is asserted, the recloser is enabled. The recloser is disabled when the DC input is deasserted.

Permissive Trip (PT)

The PT input is normally used in permissive transfer tripping schemes. When it asserts, an event is triggered, and additional tripping conditions are allowed as selected in the logic setting procedure (see the **LOGIC MPT** command).

Block Trip (BT)

The BT input is normally used in blocking and fuse-saving schemes. When it is not asserted, selected tripping conditions are allowed (see the **LOGIC MTB** command). This input also triggers an event report.

Circuit Breaker Monitor (52A)

The 52A input indicates the state of the breaker. The 52A is used by the tripping and closing functions and in the reclosing relay.

External Trigger for Event Report (ET)

An event report is triggered whenever the external trigger input is asserted. Asserting this input does not influence the protective functions in any way.

Potential Inputs

The potential inputs should be driven from a set of three line potential transformers with their primaries connected in a grounded-wye configuration and their secondaries connected in 4-wire wye. The relay contains a set of three input transformers connected in 4-wire wye. Since the SEL-267 Relay includes zero-sequence voltage polarization, it is necessary to connect the neutral input terminal to the star point of the PT secondaries. The nominal voltage rating is 115 volts line-to-line or 67 volts line-to-neutral.

Note that the SEL-267 Relay determines the zero-sequence voltage from the three voltage inputs VA, VB, and VC, so a separate V0 input is not needed.

Terminal number assignments for the potentials are:

Phase A	(37)
Phase B	(38)
Phase C	(39)
Neutral point	(40)

The PT secondary star point should be grounded only once, preferably at the PT location. A second ground of the neutral wiring causes ground potential differences to appear in the PT secondary measurements as a neutral shift.

Current Inputs

The rating of the input current transformers in the relay is 5 A nominal, 15 A continuous, and 500 A for one second.

Terminal number assignments for the current circuits are:

IA-dot, IA	(29,30)	A-phase current
IB-dot, IB	(31,32)	B-phase current
IC-dot, IC	(33,34)	C-phase current
IP-dot, IP	(35,36)	Zero-sequence polarizing current (if needed)

Input Configurations and Specifications (Conventional Terminal Block Model)

Serial Interfaces

+5 Vdc, +12 Vdc, and –12 Vdc signals are available from Port 1 and Port 2R when jumpers 12, 14, and 13 are bridged, respectively. Contact SEL before using these power supply outputs because exceeding the current capacity of the power supply may result in damage. Table 2.1 shows the pinout for the serial interface ports.

Table 2.1: Port Pin Assignments for Conventional Terminal Block Model

Pin	Port 1, Port 2R	Port 2F	Description
1	N/C or +5 Vdc	N/C	May be enabled by bridging JMP12 on the main board.
2	RXD	RXD	Receive data input.
3	TXD	TXD	Transmit data output.

Pin	Port 1, Port 2R	Port 2F	Description
4	N/C or +12 Vdc	N/C	May be enabled by bridging JMP14 on the main board.
5	GND	GND	
6	N/C or –12 Vdc	N/C	May be enabled by bridging JMP13 on the main board.
7	RTS	RTS	The SEL-267 Relay asserts this line under normal conditions. When the received-data buffer is full, the line is deasserted, and asserts again when the buffer has sufficient room to receive more data. Connected devices should monitor RTS (usually with their CTS input) and stop transmission whenever the line deasserts. If transmission continues, data may be lost.
8	CTS	CTS	The SEL-267 Relay monitors CTS, and transmits characters only if CTS is asserted.
9	GND	GND	Ground for ground wires and shields.

Contact Inputs

Table 2.2 shows the contact input electrical specifications.

Table 2.2: Input Parameters for Conventional Terminal Block Model

Logic Input Rating	Contact Input Range		Current at Nominal Voltage
24 Vdc	15–30 Vdc		4 mA
48 Vdc	30–60 Vdc		4 mA
250 Vdc	150–300 Vdc		4 mA
	Will Assert	Will Not Assert	
125 Vdc	> 100 Vdc	< 75 Vdc	6 mA

Input Configurations and Specifications (Plug-In Connector Model)

Serial Interfaces

+5 Vdc, +IRIG-B, and –IRIG-B signals are available from Port 1 and Port 2R when jumpers 12, 14, and 13 are bridged, respectively. Contact SEL before using these power supply outputs because exceeding the current capacity of the power supply may result in damage. Table 2.3 shows the pinout for the serial interface ports.

Table 2.3: Port Pin Assignments for Plug-In Connector Model

Pin	Port 1, Port 2R	Port 2F	Description
1	N/C or +5 Vdc	N/C	May be enabled by bridging JMP12 on the main board.
2	RXD	RXD	Receive data input.
3	TXD	TXD	Transmit data output.
4	N/C or +IRIG-B	N/C	May be enabled by bridging JMP14 on the main board.
5	GND	GND	
6	N/C or -IRIG-B	N/C	May be enabled by bridging JMP13 on the main board.
7	RTS	RTS	The SEL-267 Relay asserts this line under normal conditions. When the received-data buffer is full, the line is deasserted, and asserts again when the buffer has sufficient room to receive more data. Connected devices should monitor RTS (usually with their CTS input) and stop transmission whenever the line deasserts. If transmission continues, data may be lost.
8	CTS	CTS	The SEL-267 Relay monitors CTS, and transmits characters only if CTS is asserted.
9	GND	GND	Ground for ground wires and shields.

Input Power

A separate power connector is supplied with the wiring harness. Harnesses can be ordered with #18 to #14 AWG conductors (#14 AWG standard).

Contact Inputs

The connectors supplied with the wiring harness can accommodate #20 to #12 AWG (single conductor) and #20 to #14 AWG (two conductors). Table 2.4 shows the contact input electrical specifications.

Table 2.4: Input Parameters for the Plug-In Connector Model

Logic Input Rating	Contact Input Range		Current at Nominal Voltage
24 Vdc	15–30 Vdc		4 mA
250 Vdc	150–300 Vdc		4 mA
	Will Assert	Will Not Assert	
48 Vdc	> 38.4 Vdc	< 28.8 Vdc	5 mA
125 Vdc	> 100 Vdc	< 75 Vdc	6 mA

Potential Inputs

The potential input Plug-In Connector accepts #18 to #14 AWG conductor (#14 AWG standard).

Current Inputs

The plug-in current input connector accepts #16 to #10 AWG conductor (#12 AWG standard). This connector will automatically short CT secondaries when removed from the relay.

RELAY OUTPUT DESCRIPTIONS

Eight output relays are provided. Four of the eight output relays perform fixed functions. The remaining four can be programmed with the **LOGIC** command.

TRIP Output

This output closes for any number of user-selected conditions. The conditions are grouped as follows: unconditional, subject to PT input assertion, subject to the absence of BT input, and subject to the breaker being open. The TRIP output never closes for less than the duration of the TDUR setting. After this interval, it opens when the fault condition ceases and the overcurrent elements in Relay Word Row 1 have dropped out or when the TARGET RESET button is pressed. The latter facilitates relay testing without using a breaker simulator.

CLOSE Output

This output closes for reclose operations, assertion of the DC input, and in response to the **CLOSE** command. It opens when the 52A input is asserted or after the reclosing relay reset interval, whichever occurs first.

The DC (Direct Close) input on the SEL-267-2 Relay does not function as a direct close input—see explanation in the following *Reclosing Relay* subsection.

ALARM Output

The ALARM output closes for the following conditions:

- Three unsuccessful Level 1 access attempts: 1-second pulse
- Any Level 2 access attempt: 1-second pulse
- Self-test failures: permanent contact closure or 1-second pulse, as directed by self-test.

The ALARM output also closes momentarily when operators change settings or enter a date with a different year than the one currently stored in EEPROM (see the **DATE** command).

Programmable Outputs (A1, A2, A3, A4)

These four outputs may be assigned to any combination of the bits in the Relay Word.

Output Configurations and Specifications (Conventional Terminal Block Model)

All contact outputs are rated for circuit breaker tripping duty. Table 2.5 shows the output contact configurations.

Table 2.5: Relay Outputs for Conventional Terminal Block Model

Output Relay	Terminal No.	Contact Type
TRIP	(1, 2) (3, 4)	a
CLOSE	(5, 6)	*a or b
A1	(7, 8)	*a or b
A2	(9, 10)	*a or b
A3	(11, 12)	*a or b
A4	(13, 14)	*a or b
ALARM	(15, 16)	a or b*

*Indicates factory default

The positions of jumpers JMP4 through JMP11 (soldered) can be changed to convert the above contacts from Type a to Type b or from Type b to Type a. Jumper JMP3 can be positioned such that A4 asserts when ALARM asserts.

Plug-In Connector Model

All contact outputs in the Plug-In Connector model are high current interrupting contacts. These contacts are capable of interrupting 10 Adc at 125 Vdc with an L/R of 40 ms. These contacts are polarity sensitive; the positive voltage must be applied to the even-numbered contact output terminals. The connectors can accommodate #20 to #12 AWG conductors. Jumper JMP3 can be positioned such that A4 asserts when ALARM asserts. Table 2.6 shows the output contact configurations.

Table 2.6: Relay Outputs for Plug-In Connector Model

Output Relay	Terminal No.	Contact Type
TRIP	(1, 2) (3, 4)	a
CLOSE	(5, 6)	a
A1	(7, 8)	a
A2	(9, 10)	a
A3	(11, 12)	a
A4	(13, 14)	a
ALARM	(15, 16)	b

DEFINITION OF LOGIC VARIABLES

The output relay states of the SEL-267 Relay depend on the following:

- Relay elements
- Contact-monitoring inputs
- Setting parameters
- Logic programming
- Commands received over communications link
- Status of self-tests

Since so many binary variables are involved, we define the functioning with Boolean logic equations. The logic variables involved are defined in the following section. Elements available in the Relay Word appear in boldface.

LOGIC DESCRIPTION

Relay Elements

Single-phase overcurrent relays	50A1 50B1 50C1	Nondirectional
	50A2 50B2 50C2	Nondirectional
	50A3 50B3 50C3	Nondirectional
Polyphase time-overcurrent relay (driven by maximum phase current)		
pickup	51PP	Torque Control or nondirectional
trip	51PT	Torque Control or nondirectional
Residual time-overcurrent relay		
pickup	51NP	Torque Control or nondirectional
trip	51NT	Torque Control or nondirectional
Residual instantaneous-overcurrent	50N1	Nondirectional
Residual instantaneous-overcurrent	50N2	Nondirectional
Residual instantaneous-overcurrent	50N3	Nondirectional
Phase directional	32PQ	32PQF=forward; 32PQR=reverse
Negative-sequence directional	32Q	32QF=forward; 32QR=reverse
Zero-sequence dual pol. directional	32D	32DF=forward; 32DR=reverse

Note: The 32D is equivalent to 32V with 32VE enabled and 32IE disabled. The 32D is equivalent to 32I with 32IE enabled and 32VE disabled. The 32D is dual polarized when both 32VE and 32IE are enabled.

Timers

Z1GTMR	Zone 1 ground timer timeout operated by 67N1	(Z1DG setting)
Z2GTMR	Zone 2 ground timer timeout operated by 67N2	(Z2DG setting)
Z3GTMR	Zone 3 ground timer timeout operated by 67N3	(Z3DG setting)
Z1PTMR	Zone 1 phase timer timeout operated by 67P1	(Z1DP setting)
Z2PTMR	Zone 2 phase timer timeout operated by 67P2	(Z2DP setting)
Z3PTMR	Zone 3 phase timer timeout operated by 67P3	(Z3DP setting)

52BT	Time delayed inverse of 52A	(52BT setting)
79OI1	Reclosing relay first open interval expired	(79OI1 setting)
79OI2	Reclosing relay second open interval expired	(79OI2 setting)
79OI3	Reclosing relay third open interval expired	(79OI3 setting)
79RS	Reclosing relay reset interval timer expired	(79RS setting)

Enables From Setting Procedure

ZONE3 = F	Zone 3 is forward
ZONE3 = R	Zone 3 is reverse
32QE	Enables 32Q
32VE	Enables voltage polarization of 32D
32IE	Enables current polarization of 32D
67NE	Enables directional torque control for 67N1 , 67N2 , and 67N3
67PE	Enables directional torque control for 67P1 , 67P2 , and 67P3
51NTC	Selects torque control for 51N
51PTC	Selects torque control for 51P

Contact Inputs

DT	Direct trip
PT	Permissive transfer trip
BT	Block trip
DC*	Direct close
52	Circuit breaker monitor
EXT	External trigger for event report

* The DC (Direct Close) input on the SEL-267-2 Relay does not function as a direct close input—see explanation in the following *Reclosing Relay* subsection.

Contact Outputs

TRIP	Circuit breaker trip
CLOSE	Circuit breaker close
A1	Programmable output 1
A2	Programmable output 2
A3	Programmable output 3
A4	Programmable output 4
ALARM	System alarm

INTERMEDIATE LOGIC

The logic equations below represent combinations of the relay elements and other conditions. In the following equations the “*” indicates logical “and”, while the “+” indicates logical “or”. Elements available in the Relay Word appear in boldface.

50P3	=	50A3 + 50B3 + 50C3	Zone 3 phase fault
50P2	=	50A2 + 50B2 + 50C2	Zone 2 phase fault
50P1	=	50A1 + 50B1 + 50C1	Zone 1 phase fault

GF	=	51NP + 50N1 + 50N2 + 50N3	Ground fault
PF	=	51PP + 50P1 + 50P2 + 50P3	Phase fault
DFP	=	32PQF * PF	Phase forward direction
DRP	=	32PQR * PF	Phase reverse direction
D3P	=	DFP	if ZONE3 is forward
D3P	=	DRP	if ZONE3 is reverse
67P3	=	[D3P + NOT(67PE)] * 50P3	Zone 3 directional phase overcurrent element, reversible
67P2	=	[DFP + NOT(67PE)] * 50P2	Zone 2 directional phase overcurrent element
67P1	=	[DFP + NOT(67PE)] * 50P1	Zone 1 directional phase overcurrent element
DFG	=	32QF * 32QE * (PF + GF) + 32DF * (32IE + 32VE) * GF + NOT(32QE + 32IE + 32VE)	Ground forward direction
DRG	=	32QR * 32QE * (PF + GF) + 32DR * (32IE + 32VE) * GF	Ground reverse direction
D3G	=	DFG	if ZONE3 is forward
D3G	=	DRG	if ZONE3 is reverse
67N3	=	[D3G + NOT(67NE)] * 50N3	Zone 3 directional ground-overcurrent element, reversible
67N2	=	[DFG + NOT(67NE)] * 50N2	Zone 2 directional ground-overcurrent element
67N1	=	[DFG + NOT(67NE)] * 50N1	Zone 1 directional ground-overcurrent element
Z3PT	=	67P3 * Z3PTMR	Zone 3 timeout-phase
Z2PT	=	67P2 * Z2PTMR	Zone 2 timeout-phase
Z1PT	=	67P1 * Z1PTMR	Zone 1 timeout-phase
Z3GT	=	67N3 * Z3GTMR	Zone 3 timeout-ground
Z2GT	=	67N2 * Z2GTMR	Zone 2 timeout-ground
Z1GT	=	67N1 * Z1GTMR	Zone 1 timeout-ground

RELAY WORD

Relay elements and intermediate logic results are represented in a 32-bit Relay Word (grouped into four 8-bit words). The user selects bits in this word to perform the desired functions for controlling outputs and initiating or canceling reclose. The selected bits are stored in masks for each function. You can program the bits in these masks with the **LOGIC** command.

Table 2.7 shows the Relay Word for the relay.

Table 2.7: Relay Word

51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3
DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3
51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT
ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH

Table 2.8 explains the meaning of each bit in the Relay Word.

The use of the Relay Word and programmable masks provides application flexibility without rewiring panels or changing jumpers on circuit boards.

Table 2.8: Relay Word Bit Summary

51NP	-	Residual time-overcurrent element pickup
50N1	-	Residual instantaneous-overcurrent element (nondirectional)
50N2	-	Residual instantaneous-overcurrent element (nondirectional)
50N3	-	Residual instantaneous-overcurrent element (nondirectional)
51PP	-	Phase time-overcurrent element pickup
50P1	-	Zone 1 phase instantaneous-overcurrent element (nondirectional)
50P2	-	Zone 2 phase instantaneous-overcurrent element (nondirectional)
50P3	-	Zone 3 phase instantaneous-overcurrent element (nondirectional)
DFP	-	Direction forward—phase fault
67N1	-	Zone 1 ground directional overcurrent element (directional as enabled)
67N2	-	Zone 2 ground directional overcurrent element (directional as enabled)
67N3	-	Zone 3 ground directional overcurrent element (directional as enabled)
DFG	-	Direction forward—ground fault
67P1	-	Zone 1 phase directional overcurrent element (directional as enabled)
67P2	-	Zone 2 phase directional overcurrent element (directional as enabled)
67P3	-	Zone 3 phase directional overcurrent element (directional as enabled)
51NT	-	Ground time-overcurrent trip (directional as enabled)
Z1GT	-	Zone 1 timeout-ground
Z2GT	-	Zone 2 timeout-ground
Z3GT	-	Zone 3 timeout-ground
51PT	-	Phase time-overcurrent trip (directional as enabled)
Z1PT	-	Zone 1 timeout-phase
Z2PT	-	Zone 2 timeout-phase
Z3PT	-	Zone 3 timeout-phase
ALRM	-	System alarm
TRIP	-	Circuit breaker trip
TC	-	Trip (OPEN) command
DT	-	Direct trip from DT input
52BT	-	Time delayed inverse of 52A
SH1	-	Shot 1 reclosing detector
TOCP	-	Time-overcurrent pickup indicator (51PP + 51NP)
DCTH	-	Demand current threshold exceeded

OUTPUT EQUATIONS

The logic for controlling the TRIP, A1, A2, A3, and A4 output relays is programmable for flexibility and testing. The logic is programmed by setting masks for various conditions applied to the general Relay Word.

The Programmable Trip Logic is shown in Figure 2.2.




Figure 2.2: Programmable Trip Logic Diagram

The general form for each output equation follows:

Let R = Relay Word

MTU = mask for trip (unconditional)

MPT = mask for trip (permissive trip)

MTB = mask for trip (with no blocking)

MTO = mask for trip (with breaker open)

Then: **TRIP** = R * MTU
 + R * MPT * PT
 + R * MTB * NOT (BT)
 + R * MTO * 52BT

close **TRIP** contact = **TRIP**

open **TRIP** contact = NOT (**TRIP**) * [NOT(Any element in Relay Word Row 1 picked up) + (TARGET RESET button pushed)] * [Trip Duration timer expired (TDUR)]

close CLOSE contact = (DC + 79OI1 + 79OI2 + 79OI3 + **CLOSE** command) * NOT (52A)

open CLOSE contact = NOT (CLOSE) + 79RS

The DC (Direct Close) input on the SEL-267-2 Relay does not function as a direct close input—see explanation in the following **Reclosing Relay** subsection.

$A1 = R * MA1$
 $A2 = R * MA2$
 $A3 = R * MA3$
 $A4 = R * MA4$

The “*” symbol indicates logical “and”, while the “+” indicates logical “or”.

RECLOSING RELAY

The reclosing relay provides up to three shots of automatic reclosing for selectable fault types and relay elements contained in the 32-bit Relay Word. The programmable logic provides access to the internally derived reclose initiate and cancel signals. The relay also accepts either external initiation or cancellation of reclosing. The three open intervals and the reset timer are individually settable through the **SET** command.

To provide flexibility in applying the SEL-267 Relay to various reclosing schemes, the conditions for reclose initiation and cancellation are selected similarly to the output relay programming:

$RI = R * MRI$ MRI selects reclose initiate conditions from the Relay Word
 $RC = R * MRC$ MRC selects reclose cancel conditions from the Relay Word

where MRI is the mask for reclose initiation, and MRC is the mask for reclose cancellation.

The open intervals do not begin until the TRIP output deasserts. Since the TRIP output never asserts for less than the TDUR timer setting, the open interval may start several milliseconds after the fault has actually cleared and the breaker opened.

Reclose is automatically canceled when the circuit breaker is observed to trip with no fault condition present or for faults during the open interval of any shot.

DC Input Operates as Reclose Enable for the SEL-267-2 Relay Model

The DC (Direct Close) optoisolated input (terminals 23, 24) on the SEL-267-2 Relay does not function as a direct close input—its function is redefined as a reclose enable input. For the SEL-267-2 Relay, energize the DC (Direct Close) optoisolated input to enable reclosing (de-energize to disable reclosing).

TARGETS

The front panel targets illuminate for the conditions are shown in Table 2.9.

Table 2.9: Front Panel Target Conditions for Illumination

Target LED	Conditions for Illumination
PH1	Zone 1 phase involvement
G1	Zone 1 ground involvement
PH2	Zone 2 phase involvement
G2	Zone 2 ground involvement
PH3	Zone 3 phase involvement

Target LED	Conditions for Illumination
G3	Zone 3 ground involvement
51P	Phase time-overcurrent involvement
51N	Residual time-overcurrent involvement

The targets display the latest relay element condition at the time of tripping. For example, zone targets illuminate if the current setting for that zone of protection is exceeded when tripping occurs. If a new fault occurs, the targets show the new fault.

To clear the targets, press the TARGET RESET button. All eight indicators illuminate for approximately one second as a lamp test. If they do not, the relay is disabled due to a self-test failure. After a new fault occurs, the targets are cleared before the new fault targets are presented, so targets show the most recent fault. Pressing the TARGET RESET button unlatches the TRIP output from the 52A input. This feature is useful during relay testing and minimizes the risk of installing the relay with the TRIP output asserted.

SELF-TESTS

The relay runs a variety of self-tests. Some tests have warning and failure states; others only have failure states. The relay generates a report after any change in self-test status.

The relay closes the ALARM contacts after any self-test fails. When it detects certain failures, the relay disables the breaker control functions and places the relay output driver port in an input mode. No outputs may be asserted when the instrument is in this configuration. The relay runs all self-tests on power up and before enabling new settings. During normal operation, it performs self-tests at least every few minutes.

Offset

The relay measures the offset voltage of each analog input channel and compares the value against fixed limits. It issues a warning when offset is greater than 50 millivolts in any channel and declares a failure when offset exceeds 75 millivolts. Offset levels for all channels appear in the STATUS command format.

Power Supply

Power supply voltages are limit-checked. Table 2.10 summarizes voltage limits.

Table 2.10: Power Supply Self-Test Limits

Supply	Warning Thresholds		Failure Thresholds	
+5 V	+5.3 V	+4.7 V	+5.4 V	+4.6 V
+15 V	+15.8 V	+14.2 V	+16.2 V	+13.8 V
-15 V	-15.8 V	-14.2 V	-16.2 V	-13.8 V

The relay transmits a STATUS command response for any self-test failure or warning. A +5 volt supply failure de-energizes all output relays and blocks their operation. A ± 15 volt supply failure

disables protective relay functions while control functions remain intact. The ALARM relay remains closed after a power supply failure.

Random-Access Memory

The relay checks random-access memory (RAM) to ensure that each byte can be written to and read from. There is no warning state for this test. If the relay detects a problem, it transmits a STATUS command message with the socket designation of the affected RAM IC. A RAM failure disables protective and control functions and closes the ALARM output relay contacts.

Read-Only Memory

The relay checks read-only memory (ROM) by computing a checksum. If the computed value does not agree with the stored value, the relay declares a ROM failure. It transmits a STATUS command response with the socket designation of the affected ROM IC. A ROM failure disables protective and control functions and closes the ALARM output relay contacts.

Analog-to-Digital Converter

The analog-to-digital converter (A/D) changes voltage signals derived from power system voltages and currents into numbers for processing by the microcomputer. The A/D test verifies converter function by checking conversion time. The test fails if conversion time is excessive or a conversion starts and never finishes. There is no warning state for this test.

Though an A/D failure disables protective functions, control functions remain intact. The relay transmits a STATUS command response and closes the ALARM relay contacts.

Master Offset

The master offset (MOF) test checks offset in the multiplexer/analog to digital converter circuit. A grounded input is selected and sampled for dc offset. The warning threshold is 50 mV; failure threshold is 75 mV. A failure pulses the ALARM contact closed for one second.

Settings

The relay stores two images of the system settings in nonvolatile memory. These are compared when the relay is initially set and periodically thereafter. If the images disagree, the setting test fails and the relay disables all protective and control functions. It transmits the STATUS message to indicate a failed test. The ALARM relay remains closed after a setting failure.

Table 2.11 shows relay actions for any self-test condition: warning (W) or failure (F).

Table 2.11: Self-Test Summary

Self Test	Limits	Status Message	Protection Disabled	Control Disabled	Alarm Output
RAM	----	F	YES	YES	permanent contact assertion
ROM	----	F	YES	YES	permanent contact assertion
SETTINGS	----	F	YES	YES	permanent contact assertion

Self Test	Limits	Status Message	Protection Disabled	Control Disabled	Alarm Output
A/D	----	F	YES	NO	permanent contact assertion
+5 V	± 0.3 V ± 0.4 V	W F	NO YES	NO YES	no ALARM contact assertion permanent contact assertion
± 15 V	± 0.8 V ± 1.2 V	W F	NO YES	NO NO	no ALARM contact assertion permanent contact assertion
CHANNEL OFFSETS	50 mV 75 mV	W F	NO NO	NO NO	no ALARM contact assertion one second contact pulse
MASTER OFFSET	50 mV 75 mV	W F	NO NO	NO NO	no ALARM contact assertion one second contact pulse

SETTING PROCEDURE

You may enter the settings for the SEL-267 Relay with the **SET** and **LOGIC** commands via the serial interfaces. The settings are stored in nonvolatile memory, so they are retained when the power is off.

The **SET** and **LOGIC** command descriptions explain how to enter settings.

EVENT REPORT

The SEL-267 Relay records an eleven cycle event report following any of these elements picking up:

67N1	67P1	51N
67N2	67P2	51P
67N3	67P3	

Event reports are also recorded due to assertion of the following inputs and execution of the following commands:

External Trigger input	Permissive Trip input
Direct Trip input	Block Trip input
OPEN command	TRIGGER command

A second report is triggered for the same fault if the trip occurs after the first report expires, so the beginning and end of each fault for which the relay trips is recorded. However, if the TRIP output first asserts at or less than seven cycles after the first report is triggered, then a second event report is not generated. (Note that reports are triggered at the 16th quarter cycle of data.)

Timing of the triggering instant is recorded to the nearest quarter-cycle, so that the duration of long faults can be computed from the time the first report is triggered by the fault, and the time the second report is triggered by the trip. The reported event time corresponds to the 16th quarter cycle of the event report in all cases. The event report contains voltages, currents, system settings, and other information. Event reports are described in detail in *Section 4: Event Reporting*.

Execution of the **CLOSE** command does not trigger an event. Direct close, by asserting the **DIRECT CLOSE** input, does not trigger an event.

The twelve most recent event reports are stored in memory and may be retrieved using the **EVENT** command. A short history of the twelve most recent events is available using the **HISTORY** command.

FAULT LOCATOR

The SEL-267 Relay fault locator is automatically triggered by any of several events. These events include pickup of certain relay elements, assertion of certain contact inputs or outputs, and user-entered commands. However, the fault locator can be either enabled or disabled with the **LOCAT** setting in the setting procedure.

Specifically, the triggering events are:

- (1) RELAY ELEMENTS (high-level trigger)
Ground overcurrent Zones 1, 2, or 3 (67N1, 67N2, 67N3)
Phase overcurrent Zones 1, 2, or 3 (67P1, 67P2, 67P3)
Ground time-overcurrent 51N pickup
Phase time-overcurrent 51P pickup
- (2) CONTACT INPUTS (rising-edge trigger)
External Trigger
Direct Trip
Permissive Trip
Block Trip
- (3) CONTACT OUTPUTS (rising-edge trigger)
Trip
- (4) USER ENTERED COMMANDS (rising-edge trigger)
TRIGGER
OPEN

Note that the fault locator is triggered by the relay elements in a level-sensitive manner. That is, additional event reports are not generated when additional relay elements pick up. Only the first relay element of any contiguous sequence triggers an event report.

Furthermore, all triggering relay elements must drop out for at least four cycles before they may initiate another event report. (This helps eliminate triggering multiple records for boundary faults.)

All other triggering events are rising-edge sensitive, meaning that for these events, additional reports are generated even while any or all relay elements remain picked up. This strategy permits, for example, the recording of fault clearing even when it occurs long after the initial event report is completed.

The fault location is always determined for event records in which any triggering relay elements are picked up, providing they are not picked up in the first seven rows of pre-fault data, or only in the last five rows of the event report. Furthermore, whenever the locator is able to determine the fault location, the corresponding record is labeled according to fault type, regardless of what actually triggered the event report. On the other hand, event records taken when no triggering relay elements are picked up are labeled as follows:

“EXT” for reports triggered externally via input contacts or by the **TRIGGER** command

or

“TRIP” for reports triggered by the assertion of the “TRIP” output contact.

The actual fault location algorithm is composed of two steps. First the fault type must be determined, and then the location calculated.

For the event reports, the fault type is determined largely independently of the relay element operations. Only the indicated zone is determined by relay elements, whereas the involved phases are determined by fault current comparison. (This is different from the TARGET data, which is completely derived from relay element operations.)

The compared currents are taken from the two rows at the middle of the stored fault data. If the uncompensated current magnitudes are in large ratios between phases (4:1 or more), then the fault type becomes immediately apparent as single- or two-phase. If not, the same current is load compensated by the two corresponding prefault current rows in the first cycle of the event report. If these fault current component magnitudes are in moderate ratios (1.5:1 or more), then the fault type is taken as single- or two-phase, or if the ratios are all less than 1.5, then the fault type is taken as three-phase. The explicit fault classification logic is as follows, where “T” values are uncompensated midfault currents, and “If” values are midfault currents compensated for load, yielding true fault current components:

IF	($I_{\max} > 4.0 \cdot I_{\text{med}}$)	THEN Single-phase
ELSE IF	($I_{\text{med}} > 4.0 \cdot I_{\min}$)	THEN Two-phase
ELSE IF	($I_{f\max} > 1.5 \cdot I_{f\text{med}}$)	THEN Single-phase
ELSE IF	($I_{f\text{med}} > 1.5 \cdot I_{f\min}$)	THEN Two-phase
ELSE IF	(none of the above)	THEN Three-phase.

This algorithm is largely immune to load and system grounding variations.

Once the fault type is determined, the fault locator employs the Takagi algorithm to locate the fault. Using both pre-fault and fault data, it compensates for the errors introduced by fault resistance in the presence of load flow. On the other hand, if no pre-fault data are provided by the event record, the SEL-267 Relay gives a location based on a simple reactance measurement.

The fault locator depends on accurate transmission line parameters and instrument transformer ratios. Pay special attention to these potential sources of difficulty:

- Instrument transformer ratio errors due to overburden by other devices
- Capacitive potential transformer capacitor value
- Transmission line parameter errors

Although the fault-location computation takes several seconds, faults in quick succession, such as those that occur in a reclosing sequence, are handled. This is because the fault data are stored, and subsequently processed, in turn. As an example, suppose three faults occur within a few seconds. The data from the faults are stored as they occur. The fault-location computations begin with the first (oldest) fault and proceed until all three faults are processed. Each of the summary event reports is transmitted as soon as the corresponding fault location is available.

Shunt capacitance of the transmission line is not taken into account. The capacitance causes the fault location to appear more remote by, approximately, a factor of $1/\cos(bL)$, where bL is the

line length in radians at 60 Hz. One wavelength at 60 Hz is 3,100 miles. For example, the line length of a 100-mile line in radians is calculated:

$$(100/3100) * 2 * 3.14159 = 0.2027 \text{ radians.}$$

The indication neglecting capacitance is about $\cos(0.2027) = 0.98$ times the actual location, or about 2 miles short for a fault at the far end of a 100-mile line.

When compensation using shunt reactors is employed, and when the measured current equals the reactor current plus the line current, the shunt reactors reduce the errors due to neglecting the shunt capacitance of the transmission line.

DIRECTIONAL ELEMENTS

The SEL-267 Relay contains three directional elements, applied as shown below:

Fault Type	Criterion	Directional Element
ABC AB, BC, CA, ABG, BCG, CAG	50A3+50B3+50C3	phase directional (32PQ)
AG, BG, CG	Depends on 32VE, 32IE, and 32QE	zero-sequence or negative-sequence settings only

The directional elements are phasor-product derived. For the negative-sequence element, the product is negative-sequence voltage times negative-sequence current, adjusted by the maximum torque angle (MTA) setting.

For the zero-sequence element, the product is the residual current adjusted by the MTA setting times the sum of the residual voltage plus polarizing current shifted in phase by the MTA setting.

The phase directional element is the positive-sequence voltage (eight cycles of memory polarization) times the positive-sequence current minus four times the negative-sequence voltage times the negative-sequence current, adjusted by the MTA setting.

TIME-OVERCURRENT ELEMENTS AND CURVES

The 51N and 51P time-overcurrent elements provide directional-forward or nondirectional protection. The trip (51NT and 51PT) states for both elements are available in the Relay Word for programming into any masks. The TOCP (time-overcurrent pickup) bit in the Relay Word is formed by either the 51N pickup or 51P pickup or both (51NP + 51PP).

You can select the time dial and the curve shape with the setting procedure. Four curve shapes are available. The curves and equations are provided at the end of this section.

The 51N and 51P characteristic is formed by a recursive sum of the magnitude or magnitude-squared of the residual current for the 51N or maximum phase current for the 51P, adjusted by the pickup setting for the appropriate element.

The time dial setting determines the limit the recursive sum must reach for a trip.

TIME-OVERCURRENT CURVE EQUATIONS

Let t = operating time in seconds,
TD = time dial setting,
M = multiples of pickup.

Curve 1—Moderately Inverse

$$t_M = TD \left[0.157 + \frac{0.668}{M-1} \right]$$

Curve 2—Inverse

$$t_M = TD \left[0.180 + \frac{5.95}{M^2-1} \right]$$

Curve 3—Very Inverse

$$t_M = TD \left[0.0963 + \frac{3.88}{M^2-1} \right]$$

Curve 4—Extremely Inverse

$$t_M = TD \left[0.0352 + \frac{5.67}{M^2-1} \right]$$




Figure 2.3: Moderately Inverse Curves




Figure 2.4: Inverse Curves




Figure 2.5: Very Inverse Curves




Figure 2.6: Extremely Inverse Curves

TABLE OF CONTENTS

SECTION 3: COMMUNICATIONS.....3-1

Introduction.....	3-1
Serial Port Connections and Configurations.....	3-1
Communications Protocol.....	3-3
Command Characteristics	3-4
Startup	3-5
Command Format	3-6
Command Descriptions.....	3-6
Access Level 0 Command.....	3-6
ACCESS.....	3-6
Access Level 1 Commands	3-7
2ACCESS.....	3-7
DATE [mm/dd/yy]	3-7
EVENT [n]	3-7
HISTORY	3-8
IRIG.....	3-9
METER [n].....	3-10
QUIT	3-10
SHOWSET	3-11
STATUS.....	3-13
TARGETS [n] [k].....	3-14
TIME [hh:mm:ss].....	3-15
TRIGGER	3-15
Access Level 2 Commands	3-15
CLOSE	3-15
LOGIC [n].....	3-15
OPEN	3-17
PASSWORD (1 or 2) [PASSWORD].....	3-17
SET [n].....	3-18

TABLES

Table 3.1: Port Pin Assignments for Conventional Terminal Block Model.....	3-2
Table 3.2: Port Pin Assignments for Plug-In Connector Model	3-3
Table 3.3: Logic Settings Examination.....	3-12

SECTION 3: COMMUNICATIONS

INTRODUCTION

The SEL-267 Relay is set and operated via serial communications interfaces connected to a terminal and/or modem, an SEL-2020 Communications Processor, or an SEL Protective Relay Terminal Unit. Communications serve these purposes:

The relay receives and executes relay/fault locating settings.

The relay transmits messages in response to changes in system status, such as self-test warnings.

The relay generates an event record for any of the following conditions:

- A fault
- Assertion of the EXTERNAL TRIGGER input
- Assertion of the DIRECT TRIP input
- Assertion of the PERMISSIVE TRIP input
- Assertion of the BLOCK TRIP input
- In response to the TRIGGER command
- Assertion of the TRIP output

No event record is made for assertion of the DIRECT CLOSE input, assertion of the 52A input, or execution of the **CLOSE** command.

The relay responds to commands spanning all functions of the instrument, such as metering, setting the clock, and performing control operations.

Two access levels with separate passwords protect against unauthorized access through the communications ports.

It is impossible to disable any relaying or control functions via communications, unless a user enters erroneous or improper settings using the **SET** or **LOGIC** command.

SERIAL PORT CONNECTIONS AND CONFIGURATIONS

The relay is equipped with two EIA-232 serial communications ports. Port 2 has 9-pin connectors on both the front and rear panels, designated Port 2F and Port 2R, respectively.

Port 2R, located on the relay rear panel, is typically used with an SEL-DTA Display/Transducer Adapter, SEL-RD Relay Display, or local printer. Port 2F is always available for short-term local communications with a portable computer or printing terminal. Simply plug the device into the front panel port. The relay automatically discontinues communications with Port 2R and addresses Port 2F. When testing or data retrieval is complete, unplug the temporary device from Port 2F. The relay automatically resumes communication with the device connected to Port 2R.

Serial communications Port 1 and the Auxiliary Input for demodulated IRIG-B time-code input remain on the rear panel of the relay.

Communications port baud rate jumpers are located along the front edge of the circuit board. To select a baud rate for Port 1 or Ports 2, remove the relay front panel. The jumpers are visible near the center of the relay drawout assembly, to the right of the target LEDs. Carefully move the

jumpers using needle-nosed pliers. Available baud rates are 300, 600, 1200, 2400, 4800, and 9600 baud.



CAUTION

Do not select two baud rates for the same port, as this can damage the relay baud rate generator. The relay is shipped with Port 1 set to 300 baud and Port 2F/2R set to 2400 baud.

The serial data format is:

- eight data bits
- two stop bits
- no parity bit

This format cannot be altered.

The port pin assignments and signal definitions are shown in Table 3.1.

Table 3.1: Port Pin Assignments for Conventional Terminal Block Model

Pin	Port 1, Port 2R	Port 2F	Description
1	N/C or +5 Vdc	N/C	May be enabled by bridging JMP12 on the main board.
2	RXD	RXD	Receive data input.
3	TXD	TXD	Transmit data output.
4	N/C or +12 Vdc	N/C	May be enabled by bridging JMP14 on the main board.
5	GND	GND	
6	N/C or -12 Vdc	N/C	May be enabled by bridging JMP13 on the main board.
7	RTS	RTS	The SEL-267 Relay asserts this line under normal conditions. When the received-data buffer is full, the line is deasserted, and asserts again when the buffer has sufficient room to receive more data. Connected devices should monitor RTS (usually with their CTS input) and stop transmission whenever the line deasserts. If transmission continues, data may be lost.
8	CTS	CTS	The SEL-267 Relay monitors CTS, and transmits characters only if CTS is asserted.
9	GND	GND	Ground for ground wires and shields.

Table 3.2: Port Pin Assignments for Plug-In Connector Model

Pin	Port 1, Port 2R	Port 2F	Description
1	N/C or +5 Vdc	N/C	May be enabled by bridging JMP12 on the main board.
2	RXD	RXD	Receive data input.
3	TXD	TXD	Transmit data output.
4	N/C or +IRIG-B	N/C	May be enabled by bridging JMP14 on the main board.
5	GND	GND	
6	N/C or –IRIG-B	N/C	May be enabled by bridging JMP13 on the main board.
7	RTS	RTS	The SEL-267 Relay asserts this line under normal conditions. When the received-data buffer is full, the line is deasserted, and asserts again when the buffer has sufficient room to receive more data. Connected devices should monitor RTS (usually with their CTS input) and stop transmission whenever the line deasserts. If transmission continues, data may be lost.
8	CTS	CTS	The SEL-267 Relay monitors CTS, and transmits characters only if CTS is asserted.

COMMUNICATIONS PROTOCOL

Communications protocol consists of hardware and software features. Hardware protocol includes the control line functions described above. This section also describes a software protocol designed for manual and automatic communications.

1. All commands received by the SEL-267 Relay must be of the form:

<command><CR> or <command><CRLF>

Thus, a command transmitted to the SEL-267 Relay should consist of the command name, followed by either a carriage return or a carriage return and a line feed. When entering commands, you may truncate to the first three characters. Upper or lower case characters may be used without distinction for all command entries except passwords.

2. All messages transmitted by the SEL-267 Relay are of the following format:

```

<STX><MESSAGE LINE 1><CRLF>
<MESSAGE LINE 2><CRLF>
.
.
.
<LAST MESSAGE LINE><CRLF><PROMPT><ETX>

```

That is, each message begins with the start-of-transmission character (ASCII 02), and ends with the end-of-transmission character (ASCII 03), and each line of the message includes a carriage return and line feed at its end.

Note: The <Enter> key on most keyboards is configured to send the ASCII character 13 (^M) for a carriage return. This manual instructs you to press the <Enter> key after commands, which should send the proper ASCII code to the relay.

3. The SEL-267 Relay indicates the volume of data in its received-data buffer by an XON/XOFF protocol.

XON (ASCII hex 11) is transmitted by the SEL-267 Relay when the buffer drops below 25 percent full. The SEL-267 Relay also asserts the RTS output.

XOFF (ASCII hex 13) is transmitted when the buffer fills above 75 percent full. The SEL-267 Relay deasserts the RTS output when the buffer is approximately 95 percent full. Automatic transmitting sources should monitor for the XOFF character and suspend transmission so that they won't overwrite the buffer. Transmission should resume when the XON character is received.

4. An XON/XOFF procedure may be used to control data transmission by the SEL-267 Relay. When the SEL-267 Relay receives XOFF while transmitting, it pauses until an XON character is received. If no message is being transmitted when XOFF is received, the SEL-267 Relay blocks transmission of any message presented to its transmitting buffer. The message will be transmitted when XON is received.

Reception of the CAN character (ASCII hex 18) aborts a pending transmission. This is useful in terminating unwanted transmissions.

5. Control characters can be sent from most keyboards using the following keystrokes:

XON:	<Ctrl+Q>	(hold down the Control key and press Q)
XOFF:	<Ctrl+S>	(hold down the Control key and press S)
CAN:	<Ctrl+X>	(hold down the Control key and press X)

COMMAND CHARACTERISTICS

The SEL-267 Relay responds to commands sent to either serial communications interface. A two-level password system provides security against unauthorized access.

When the relay is first turned on, the instrument is in Access Level 0 and honors only the **ACCESS** command. It responds "Invalid command" or "Invalid access level" to any other entries.

Most commands may be used in Access Level 1, which is entered with the **ACCESS** command and the first password. This password is factory-set to OTTER, and may be changed with the **PASSWORD** command (Access Level 2).

Critical functions such as circuit breaker control and changing settings may be executed only from Access Level 2. You may enter Access Level 2 using the **2ACCESS** command and the second password. The Level 2 password is factory-set to TAIL, and may be changed with the **PASSWORD** command.

Startup

After the relay is turned on, the instrument transmits the following message to the port designated as the “automatic” port:

```
Example 69 kV Line           Date: 1/1/90      Time: 01:01:01
SEL-167
=
```

You should also hear the ALARM relay pull in, opening its “b” contact. The instrument is shipped with Port 2 designated as the automatic port; you may use the SET command and the AUTO setting to select either Port 1, 2, or both for the transmission of automatic responses from the SEL-267 Relay (see *SET command* in this section).

To enter Level 1, type the following on a terminal connected to Port 2:

```
=ACCESS <Enter>
```

The response is:

```
Password: ? @@@@@@
```

Enter the Level 1 password, e.g., **OTTER** and press **<Enter>**. The response is:

```
Example 69 kV Line           Date: 10/10/91   Time: 01:01:44
Level 1
=>
```

The equal sign and greater-than sign represent the Access Level 1 prompt. Any Level 1 command can be executed from this prompt.

Use a similar procedure to enter Access Level 2:

Type **2ACCESS <Enter>** and listen for the ALARM relay to drop out and pull in. This command always pulses the ALARM relay contact for about one second, indicating an attempt at Level 2 Access. Enter the proper password, e.g., **TAIL**, when you receive the second password prompt. After you enter the second password, the relay opens access to Level 2, as indicated by the following message and the Level 2 prompt:

```

Example 69 kV Line           Date: 10/10/91   Time: 01:01:50

Level 2
=>>

```

Any Level 1 or Level 2 command may be executed from this prompt.

Command Format

Commands consist of three or more characters; you may truncate commands to the first three characters to expedite entry. Upper or lower case characters may be used without distinction for all command entries except passwords.

Items enclosed in square brackets [...] are optional.

Arguments must be separated from the command by spaces, commas, semicolons, colons, or slashes.

Commands may be entered any time after an appropriate prompt is displayed.

COMMAND DESCRIPTIONS

Access Level 0 Command

ACCESS

Use **ACCESS** to enter the system from the Level 0 prompt (=). After typing **ACCESS <Enter>**, a prompt for the Level 1 password appears. Type the first password, and press **<Enter>**. The factory-set Level 1 password is OTTER, but should ultimately be changed by the end-user with the **PASSWORD** command from Access Level 2.

Successful access is indicated by the display example shown below:

```

=ACCESS <Enter>
Password: ? OTTER <Enter>

Example 69 kV Line           Date: 10/10/91   Time: 01:02:05

Level 1
=>

```

The => prompt indicates that you have reached Access Level 1.

After three successive failed access attempts, the ALARM contact is pulsed closed for one second. This feature can be used to alert operations personnel that possible unauthorized access is being attempted if the ALARM contact is connected to a monitoring system such as SCADA.

Access Level 1 Commands

2ACCESS

Use 2ACCESS to continue from Level 1 to Level 2. Type **2ACCESS <Enter>** to display the prompt for the Level 2 password. Enter the second password in the same manner as the first and press **<Enter>**. The factory-set Level 2 password is TAIL, but should ultimately be changed by the end-user with the **PASSWORD** command.

Successful access is indicated by the display example shown below:

```
=>2ACCESS <Enter>
Password: ? TAIL <Enter>

Example 69 kV Line          Date: 10/10/91    Time: 01:02:13

Level 2
=>>
```

The =>> prompt signifies that Access Level 1 and 2 commands may be entered. The ALARM contact is pulsed closed for one second (if no alarm condition exists, such as self-test failure) for any Level 2 access attempt, successful or otherwise.

DATE [mm/dd/yy]

To display the current date stored in the internal calendar/clock, type **DATE <Enter>**. To set the date, type **DATE mm/dd/yy <Enter>**.

To set the date to February 28, 1990, enter:

DATE 2/28/90 <Enter>

The SEL-267 Relay responds by setting the date, pulsing closed the ALARM, and the storing the year in EEPROM.

EVENT [n]

You may view event records using an event report. To display the event report for the nth event, type **EVENT n <Enter>**. The parameter n is 1 for the most recent event and 12 for the oldest event stored in the SEL-267 Relay memory. If n is not specified, the report defaults to one.

To inspect the newest report type **EVENT 1 <Enter>**, or **EVE <Enter>**. The report provides the relay identifier string, date, and time the event occurred. The next part of the event report displays eleven cycles of data for the five current channels (IPOL, IR, IA, IB, and IC), three voltage channels (VA, VB, and VC), and the states of the internal relay elements, outputs, and inputs. Next, the report shows the type of event, fault location in miles, primary ohms to the fault location, duration, and the maximum phase current measured at the midpoint of the fault. When a fault causes a trip, the fault targets are shown as well. The relay and logic settings are displayed at the end of the report.

Recall (from the *Communications Protocol* description) that you may use the **<Ctrl+X>** (cancel) sequence to terminate any transmission from the SEL-267 Relay, **<Ctrl+S>** to pause, and **<Ctrl+Q>** to continue. These are useful in reviewing or terminating an event report.

When the event buffers are cleared by a control power interruption, all event data are lost. If the buffer is empty when an event is requested, the relay returns this message:

Invalid event

Section 4: Event Reporting provides a sample event report and explanation.

HISTORY

This command displays the date, time, and type of event for each of the twelve most recent events. If the event is a fault, the distance, duration, current, and fault targets (if the fault caused a trip) are also shown. An example of the display is provided below:

```
=>HISTORY <Enter>
```

Example 69 kV Line		Date: 10/10/91	Time: 11:12:12				
#	DATE	TIME	TYPE	DIST	DUR	CURR	TARGETS
1	2/28/90	11:11:28.829	AGT	54.23	10.50	366.5	51N
2	2/28/90	11:11:28.429	AG	54.10	7.50	365.7	
3	2/28/90	11:09:50.141	BC	9.05	4.00	1320.9	P1
4	2/28/90	11:08:58.787	BC	8.98	4.75	1155.9	G1
5							
6							
7							
8							
9							
10							
11							
12							

```
=>
```

Note that only four events have occurred since the relay was set or powered on.

Each event report is time-tagged to the nearest quarter-cycle (4.17 ms) and referenced to the 16th row of data in the report. All reports trigger at row 16. Thus, the duration of a long fault that triggers a report when the fault occurs and a second report when TRIP occurs is calculated using the difference between the two report times.

The TYPE column provides an abbreviated indication of event type found in the report. This is the same data presented as EVENT in the event summary automatically generated for each fault.

For faults, the indication includes phase involvement information. The phase involvement is determined independently from relay elements. Phase involvement is determined solely from uncompensated and load compensated current magnitudes at the midpoint of the first contiguous relay pickup sequence in the event report. See **Fault Locator** in **Section 2: Specifications** for algorithmic details.

The phase involvement is indicated as one of:

AG	:	For A-phase to ground faults
BG	:	For B-phase to ground faults
CG	:	For C-phase to ground faults
AB	:	For A-B two-phase faults
BC	:	For B-C two-phase faults
CA	:	For C-A two-phase faults

ABG : For A-B two-phase to ground faults
BCG : For B-C two-phase to ground faults
CAG : For C-A two-phase to ground faults
ABC : For three-phase faults

For event reports triggered by the assertion of the TRIP output, the TYPE designation is appended with a “T”. This aids in determining clearing times for faults which persist beyond the end of the first event report. For example, if the SEL-267 Relay trips for a BG fault after completing the initial report, the second report shows “BGT” for TYPE.

For events other than faults, the TYPE indication is either “TRIP” or “EXT”. The TYPE shows “TRIP” when the SEL-267 Relay generates an event report in response to assertion of the TRIP output, which results from execution of the OPEN command during no-fault conditions. For all other events, TYPE shows “EXT”, indicating a report generated in response to some external stimulus such as the assertion of the ET (External Trigger), PT (Permissive Trip), BT (Block Trip), or DT (Direct Trip) inputs or by execution of the **TRIGGER** command.

The DIST column presents the equivalent distance to a fault in miles. This is calculated using either the Takagi algorithm or a reactance measurement, depending on whether pre-fault data are available in the event report. For some boundary faults of long duration with sporadic relay operation, the fault-locator may not be able to locate the fault for every report generated. The DIST column can display “999999” in such cases (while this behavior can be contrived under test conditions, it is extremely rare in actual practice).

The column labeled DUR gives a measure of the fault duration. This is calculated using the first pickup of a Zone 1, 2, 3, 51N, or 51P relay element until the first dropout of all said relay elements. In other words, it is the duration of the first contiguous pickup of relay elements found in the long event report converted to units of cycles.

The CURR column shows the magnitude of the maximum phase-current measured at the middle of the fault in primary amperes.

The TARGETS column shows fault targets for faults which cause a trip to occur. If no trip occurred for the fault or the event is not a fault, this column is blank. These targets are the same as SEL-267 Relay front panel targets.

IRIG

The **IRIG** command directs the relay to read the demodulated IRIG-B time-code input if present at J201 on the rear panel.

If the time code is successfully read, the interval clock/calendar time and date are updated to the time-code reading, and the relay transmits a message consisting of relay ID string, date, and time. An example of a successful read is shown below.

```
=>IRIG <Enter>
Example 69 kV Line      Date: 10/10/91   Time: 15:05:22
=>
```

If no time-code signal is present at the AUX port or if the time code cannot be successfully decoded, the relay sends the error message “IRIGB DATA ERROR.” An unsuccessful read causes the following output:

```
=>IRIG <Enter>
IRIGB DATA ERROR

=>
```

Note: When the relay is connected to a time-code signal via the AUX port it is normally unnecessary to synchronize using this command; the relay synchronizes automatically every few minutes. The command is provided as a test and setup feature, to avoid waiting for automatic synchronization during test and installation.

METER [n]

The currents, demand currents, peak demand currents, voltages, and real and reactive power are displayed in primary quantities of amperes, kilovolts, megawatts, and megavars. An example is shown below.

```
=>METER <Enter>

Example 69 kV Line           Date: 10/10/91    Time: 13:27:05

      A      B      C      AB      BC      CA
I (A) 105 102 104 180 177 182
D (A) 100 100 100
PD (A) 107 105 105
V (kV) 40.0 39.9 40.1 69.3 69.2 69.4

P (MW) 12.45
Q (MVAR) -0.08

=>
```

P and Q are positive when the power flow is out from the bus and into the line.

The optional command parameter *n* selects the number of times meter data are displayed. To view a series of eight meter readings type **METER 8 <Enter>**.

Peak demand currents are reset when the optional command parameter *n* is selected as R. The command **METER R** resets the peak demand currents to the present demand current level.

QUIT

The **QUIT** command returns control to Access Level 0 from Access Level 1 or 2 and resets the targets to the Relay Targets (TAR 0). The terminal displays the relay I.D., date, and time. Use this command when you finish communicating with the SEL-267 Relay to prevent unauthorized access. Note that control returns to Access Level 0 automatically after a settable interval of no activity. See the TIME1 and TIME2 settings of the **SET** command.

SHOWSET

Use **SHOWSET** to inspect the settings of the SEL-267 Relay. The command displays the current relay and logic settings. Settings cannot be entered or modified with this command; they are entered using the **SET** and **LOGIC** commands in Access Level 2.

An example of the output from executing **SHOWSET** appears below.

```
=>SHOWSET <Enter>

Settings for: Example 69 kV Line

R1  =49.83   X1  =56.32   R0  =56.07   X0  =143.07   LL=60.00
CTR =60.00   PTR =600.00   MTA =49.00   LOCAT=Y     DATC =15
DCTH =120.00 790I1=40.00   790I2=60.00 790I3=80.00 79RS=240.00
51PP =120.00 51PTD=1.00   51PC =2     51PTC=N
50P1 =1158.00 50P2 =516.00 50P3 =210.00
Z1DP =0.00   Z2DP =160.00  Z3DP =30.00
51NP =30.00  51NTD=2.00  51NC =2     51NTC=N
50N1 =1008.00 50N2 =450.00 50N3 =30.00
Z1DG =0.00   Z2DG =30.00  Z3DG =10.00 TDUR=9.00
52BT =30     ZONE3=R     67NE =Y     67PE =Y
32QE =N      32VE =Y     32IE =Y
TIME1=5      TIME2=0     AUTO =2     RINGS=3

Logic settings:

MTU  MPT  MTB  MT0  MA1  MA2  MA3  MA4  MRI  MRC
44   44   00   77   44   00   00   00   00   00
44   66   00   77   66   00   00   00   44   00
FF   FF   00   FF   FF   00   80   08   00   BB
30   00   00   30   00   01   00   00   00   30

=>
```

A brief line-by-line description of the settings follows:

- Line 1: Positive- and zero-sequence impedances of the transmission line (primary ohms), and the line length (miles) for which the impedances are given.
- Line 2: Current and voltage transformer ratios, maximum torque angle for the directional elements, fault locator enable, and demand ammeter time constant.
- Line 3: Demand current threshold, three reclosing open interval delays and one reset delay.
- Line 4: Phase time-overcurrent pickup, time dial, curve, and torque control by direction.
- Line 5: Pickup settings for the three phase overcurrent elements.
- Line 6: Zone 1, 2, and 3 time delays for the phase overcurrent elements.
- Line 7: Residual time-overcurrent pickup, time dial, curve, and torque control enable.
- Line 8: Zone 1, 2, and 3 residual instantaneous-overcurrent element pickup thresholds.
- Line 9: Zone 1, 2, and 3 time delays for ground faults; minimum trip duration timer.
- Line 10: 52B time delay, Zone 3 direction selection, and the enables for directionality of the ground and phase instantaneous elements.
- Line 11: The enables for the negative-sequence directional, voltage polarized zero-sequence directional, and current polarized zero-sequence directional elements.

Line 12: Port 1 and 2 time-outs, the autoport for automatically transmitted messages, and the number of rings after which the modem will automatically answer.

The **SET** command provides a complete description of the settings.

The **LOGIC** command description has a detailed explanation of the logic settings. Each column in the logic settings display shows the masks for the four rows of the Relay Word as follows:

Row 1, of any column:	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3
Row 2, of any column:	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3
Row 3, of any column:	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT
Row 4, of any column:	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH

Logic settings appear in hexadecimal format. Table 3.3 shows the equivalencies between hexadecimal (hex) and binary numbers to facilitate examination of the logic settings display.

Table 3.3: Logic Settings Examination

Hexadecimal	Binary
0	0000
1	0001
2	0010
3	0011
4	0100
5	0101
6	0110
7	0111
8	1000
9	1001
A	1010
B	1011
C	1100
D	1101
E	1110
F	1111

For example, consider row 2 of mask MA1, which is set to 66 hex format. Using the table to convert 66 to binary:

66 -> 0110 0110.

Now build row 2 of the Relay Word for mask MA1 as follows:

DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3
0	1	1	0	0	1	1	0
_____		6	_____		6	_____	

STATUS

The **STATUS** command allows inspection of the self-test status. The relay also automatically executes this command whenever a self-test enters a warning or failure state, transmitting a STATUS report to the port selected for automatic transmissions (see AUTO setting of the SET procedure).

The STATUS report format is shown below.

```

=>STATUS <Enter>

Example 69 kV Line           Date: 10/10/91   Time: 01:04:56

SELF TESTS

W=Warn  F=Fail
  IP  IR  IA      IB      IC      VA      VB      VC
OS 0   0   2 2    4      -2      -2      -2
PS 4.99      15.14    -14.85
RAM  ROM      A/D    MOF      SET
OK OK      OK  OK      OK
=>

```

The OS row indicates measured offset voltages for the eight analog channels. They are expressed in millivolts at the system point immediately ahead of the programmable-gain amplifier. Warning and failure thresholds are 50 and 75 millivolt deviations from zero, respectively.

An out-of-tolerance offset is indicated by a W (warning) or F (failure) following the displayed offset value.

The PS row indicates voltages for the three power supplies. Suffixes of W or F indicate warning or failure states of power supply voltage tests. Warning and failure levels are deviations by 0.3 and 0.4 volts for the 5-volt supply and 0.8 and 1.2 volts for the 15 volt supplies.

The last two rows report status for five tests. If a RAM or ROM test fails, the IC socket number of the defective part is indicated in place of OK.

The A/D self-test checks the A/D conversion time. If it exceeds a threshold, the test fails and protective functions are disabled. The MOF test checks the offset in the MUX-PGA-A/D circuit when a grounded input is selected. It has the same warning and failure thresholds as the offset tests.

The SET self-test compares two copies of the settings stored in nonvolatile memory. Failure of this test disables relay and control functions.

TARGETS [n] [k]

This command selects the information displayed on the front-panel target LEDs and communicates the state of selected LEDs.

When relay power is turned on, the LED display indicates the functions marked on the front panel. The LEDs default to displaying fault information shown in the RELAY TARGETS row of the following table.

Using the **TARGET** command, you may select any one of seven sets of data listed below to be printed and displayed on the front panel LEDs.

LED:	1	2	3	4	5	6	7	8	
n									
0	PH1	G1	PH2	G2	PH3	G3	51P	51N	RELAY TARGETS
1	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3	RELAY WORD ROW #1
2	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3	RELAY WORD ROW #2
3	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT	RELAY WORD ROW #3
4	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH	RELAY WORD ROW #4
5	52AT		ET	52A	DC	BT	PT	DT	CONTACT INPUTS
6		TRIP	CLOS	A1	A2	A3	A4	ALRM	CONTACT OUTPUTS

These selections are useful in testing, checking contact states, and remotely reading targets. “1” indicates an asserted element; “0” indicates an deasserted element.

The ALRM (ALARM) bit in target 4 (RELAY WORD ROW #4) and target 6 (CONTACT OUTPUTS) asserts for the **ACCESS** command, **2ACCESS** command, and self-test failures. It does not assert for the **SET**, **LOGIC**, **PASSWORD**, and **DATE** commands. This differs from the ALARM output relay, which asserts for all the above conditions.

The optional command parameter *k* selects the number of times the target data are repeatedly displayed for a given choice of parameter *n*. To see a series of ten readings of Relay Word Row #4, type **TARGET 4 10 <Enter>**.

Be sure to return the target function to display the fault targets, so field personnel do not misinterpret the displayed data. The **TAR 0** command displays fault targets.

Pressing the TARGET RESET button on the front panel clears the TAR 0 data and lights all target LEDs for approximately one second as a lamp test. Further, pressing the TARGET RESET button unlatches the TRIP output from the 52A input. This feature is useful during relay testing and minimizes the risk of re-installing the relay with the TRIP output asserted. The lamp test fails if the relay is disabled due to a self-test failure.

The front panel targets can be reset to TAR 0 and cleared remotely or locally using the **TARGET** command. Type **TARGET R <Enter>** to reset and clear the targets.

TIME [hh:mm:ss]

To check the internal clock, type **TIME <Enter>**. To set the clock, type **TIME** followed by the desired setting and **<Enter>**. Separate the hours, minutes, and seconds with colons, semicolons, spaces, commas or slashes. For example, to set the clock to 23:30:00, enter: **TIME 23 30 00 <Enter>** or **TIME 23:30:00 <Enter>**, etc.

A quartz crystal oscillator provides the time base for the internal clock. The SEL-267 Relay time-code input may be used to synchronize its clock to an external clock with a demodulated IRIG-B time-code output.

TRIGGER

Type **TRIGGER <Enter>** to generate an event record. The relay transmits a response of “Triggered.” The computer formats the just-triggered record (after a short delay), and a summary of the record is displayed.

The **TRIGGER** command is useful when inspecting phasor voltages and currents. When the SEL-267 Relay is first installed, execute the **TRIGGER** command, draw the phasors (*Section 4: Event Reporting* explains how to do this), and check for the proper polarity and phase-sequence of the inputs.

Event records may also be generated without control action by asserting the EXTERNAL TRIGGER input.

Access Level 2 Commands

All commands are available from Access Level 2. However, the commands listed below are available only from Access Level 2. Recall that any attempt, successful or otherwise, to enter Access Level 2 causes the ALARM relay to assert for one second.

CLOSE

The CLOSE output relay may be closed by executing the **CLOSE** command or asserting the DIRECT CLOSE input as long as the 52A input is not asserted. The CLOSE output relay remains closed until the 52A input is asserted (indicating that the circuit breaker is closed) or until the reclose reset internal time (79RS) expires.

To close the circuit breaker using this command, type **CLOSE <Enter>**. The prompting message “Close BREAKER (Y/N) ?” is displayed. Answering **Y <Enter>** yields a second prompting string: “Are you sure (Y/N) ?”. Typing **Y <Enter>** closes the CLOSE output relay as long as 52A is not asserted. The message “Breaker CLOSED” is transmitted once the breaker closes or if it is already closed (as determined by the state of the 52A input). Answering **N <Enter>** to either of the above prompts aborts the closing operation and transmits the message “Aborted”.

The **CLOSE** command aborts unless the remote open/close jumper (JMP104) is in place on the main circuit board.

LOGIC [n]

The logic command programs a series of masks used for controlling the outputs and reclosing operations of the SEL-267 Relay.

The parameter *n* specifies a mask to program and can be any of the following:

- MTU – Mask for unconditional trip
- MPT – Mask for trip with permissive-trip input asserted
- MTB – Mask for trip with block-trip input deasserted
- MTO – Mask for trip with breaker open
- MA1 – Mask for A1 relay control
- MA2 – Mask for A2 relay control
- MA3 – Mask for A3 relay control
- MA4 – Mask for A4 relay control
- MRI – Mask for reclose initiate
- MRC – Mask for reclose cancel

The logic programming procedure requires entry of changes to the mask, or pressing **<Enter>** to indicate no change. Each of the masks listed above is split into sections corresponding to the four rows of the Relay Word as follows:

```
Relay Word Row #1  51NP  50N1  50N2  50N3  51PP  50P1  50P2  50P3
Relay Word Row #2  DFP   67N1  67N2  67N3  DFG   67P1  67P2  67P3
Relay Word Row #3  51NT  Z1GT  Z2GT  Z3GT  51PT  Z1PT  Z2PT  Z3PT
Relay Word Row #4  ALRM  TRIP  TC   DT   52BT  SH1  TOCP  DCTH
```

When all data are provided for each row of the Relay Word, the new logic settings are displayed and a prompt issued requesting your approval to enable the SEL-267 Relay with the new logic settings. Answering “Y” enters the new data, pulses the ALARM contact closed momentarily, and clears event buffers. “N” retains the old settings.

When executed, the logic command displays a header for each row of the Relay Word (as shown above) and the present logic masking for that particular mask. The relay displays a question mark prompt and waits for input. Enter only ones and zeros without spaces as input; one selects and zero deselects a member of a Relay Word. Press **<Enter>** if the entry is satisfactory. If you wish to change any member of a group, all eight members must be input, even if no change is needed for some members. If an error occurs during input of new data, the existing settings and question mark prompt are redisplayed to allow corrections.

An example below shows the removal of the Z3PT bit from the MTU logic mask.

```

=>>LOG MTU <Enter>
1 selects, 0 deselects.

51NP 50N1 50N2 50N3 51PP 50P1 50P2 50P3
0    1    0    0    0    1    0    0
? <Enter>
DFP 67N1 67N2 67N3 DFG 67P1 67P2 67P3
0    1    0    0    0    1    0    0
? <Enter>
51NT Z1GT Z2GT Z3GT 51PT Z1PT Z2PT Z3PT
1    1    1    1    1    1    1    1
? 11111110 <Enter>
1    1    1    1    1    1    1    0
? <Enter>
ALRM TRIP TC DT 52BT SH1 TOCP DCTH
0    0    1    1    0    0    0    0
? <Enter>

New MTU :

51NP 50N1 50N2 50N3 51PP 50P1 50P2 50P3
0    1    0    0    0    1    0    0
DFP 67N1 67N2 67N3 DFG 67P1 67P2 67P3
0    1    0    0    0    1    0    0
51NT Z1GT Z2GT Z3GT 51PT Z1PT Z2PT Z3PT
1    1    1    1    1    1    1    0
ALRM TRIP TC DT 52BT SH1 TOCP DCTH
0    0    1    1    0    0    0    0

OK (Y/N) ? Y <Enter>
Enabled

EXAMPLE 69 KV LINE                      Date: 1/1/90          Time: 01:37:25

=>>

```

OPEN

The TRIP output relay closes in response to the **OPEN** command. The TRIP relay remains closed until the overcurrent elements in Relay Word Row #1 have dropped out. In all cases the TRIP output remains asserted at least TDUR cycles. If TDUR = 0, the **OPEN** command is aborted.

To open the power circuit breaker by command, type **OPEN <Enter>**. The prompt “Open BREAKER (Y/N) ?” is transmitted. Answering **Y <Enter>** yields a second prompt: “Are you Sure (Y/N) ?”. Answering **Y <Enter>** again causes the TRIP output relay to close as described above. Answering **N <Enter>** to either prompt aborts the **OPEN** command with the message “Aborted”.

The **OPEN** command aborts unless the remote open/close jumper (JMP104) is in place on the main circuit board.

PASSWORD (1 or 2) [PASSWORD]

To inspect the passwords, type **PASSWORD <Enter>**.

To change the password for Access Level 1 to BIKE enter:

PASSWORD 1 BIKE <Enter>

The SEL-267 Relay responds by setting the password, pulsing closed the ALARM relay, and transmitting the response “Set”.

AFTER ENTERING NEW PASSWORDS, EXECUTE **PASS <Enter>** TO INSPECT THEM. MAKE SURE THEY ARE WHAT YOU INTENDED. BE SURE TO WRITE DOWN THE PASSWORDS AFTER CHANGING THEM.

Passwords can be any length up to six numbers, letters, or any other printable character except the delimiters (space, comma, semicolon, colon, slash). Upper and lower case letters are treated as different characters. Examples of valid, distinct passwords include:

- OTTER
- otter
- Ot3456
- +TAIL+
- !@#\$\$%^
- SEL-267
- 123456
- 12345.
- 12345
- ab1CDE

If passwords are lost or you need to operate the SEL-267 Relay without password protection, install Jumper JMP103 on the main circuit board (no password protection). With no password protection, you may gain access without knowing the passwords and execute the **PASSWORD** command to discover or change the “forgotten” passwords.

SET [n]

The setting procedure involves answering prompting messages with new data or pressing **<Enter>** to indicate no change. When all data are provided, the new settings are displayed and a prompt issued requesting your approval to enable the SEL-267 Relay with the new settings. When you complete all desired setting changes, it is not necessary to scroll through the remaining settings. Type **END <Enter>** after the last setting change to proceed to the new settings display and enable prompt. The END statement should not be used for the relay ID setting. Use **<Ctrl+X>** to abort the set procedure instead.

Error messages indicate when the entered data result in out-of-range settings. If no error messages are received, the relay is enabled with the new settings, the ALARM contact closes momentarily, and the event buffer is cleared.

The optional command parameter *n* can be one of the setting descriptors (except for the ID setting). The setting descriptor is the abbreviated description of the setting (e.g., 50P1 is the setting descriptor for the Zone 1 phase overcurrent element). See the following list for more descriptors. All settings prior to the one specified are skipped when the parameter *n* is input. For example, typing **SET Z3DP <Enter>** will skip to the Z3DP setting and start the set procedure there.

The following data are required to set the relay:

R1, X1	(pos. seq. primary impedance of line 0–9999 ohms)
R0, X0	(zero seq. " " " " 0–9999 ohms)
LL	Line length (0.1–999 miles)

CTR	CT ratio (e.g., for 600/5, enter 120) (1–5000)
PTR	PT ratio (e.g., 1200/1, enter 1200) (1–10,000)
MTA	Maximum torque angle for directional elements (47–90 degrees)
LOCAT	Do you want the fault locator enabled? (Y or N)
DATC	Demand ammeter time constant (5–60 minutes)
DCTH	Demand current threshold (25–50,000 primary amperes)
79OI1	Reclosing relay open interval 1 (3 to 10,000 cycles; 0 disables reclosing for intervals 1, 2 and 3)
79OI2	Reclosing relay open interval 2 (3 to 10,000 cycles; 0 disables reclosing for intervals 2 and 3)
79OI3	Reclosing relay open interval 3 (3 to 10,000 cycles; 0 disables reclosing for interval 3)
79RS	Reclosing relay reset time (60 to 8,000 cycles)
51PP	Phase time-overcurrent pickup (0.25–50,000 primary amperes)
51PTD	Phase time-overcurrent time dial (0.5–15)
51PC	Phase time-overcurrent curve index. Choices are as follows: Use 1 to select a moderately inverse curve Use 2 to select an inverse curve Use 3 to select a very inverse curve Use 4 to select an extremely inverse curve
51PTC	Do you want phase time-overcurrent directional torque control? (Y or N)
50P1	Zone 1 phase overcurrent element pickup (0.25–50,000 primary amperes)
50P2	Zone 2 phase overcurrent element pickup (0.25–50,000 primary amperes)
50P3	Zone 3 phase overcurrent element pickup (0.25–50,000 primary amperes)
Z1DP	Zone 1 delay for phase and three-phase faults (0–60 cycles in 3 cycle steps)
Z2DP	Zone 2 delay for phase and three-phase faults (0–2000 cycles in 3 cycle steps)
Z3DP	Zone 3 delay for phase and three-phase faults (0–2000 cycles in 3 cycle steps)
51NP	Residual time-overcurrent pickup (0.25–50,000 primary amperes)
51NTD	Residual time-overcurrent time dial (0.5–15)
51NC	Residual time-overcurrent curve index. Choices are as follows: Use 1 to select a moderately inverse curve Use 2 to select an inverse curve Use 3 to select a very inverse curve Use 4 to select an extremely inverse curve
51NTC	Do you want residual time-overcurrent directional torque control? (Y or N)
50N1	Zone 1 residual instantaneous-overcurrent (0.25–50,000 primary amperes)
50N2	Zone 2 residual instantaneous-overcurrent (0.25–50,000 primary amperes)
50N3	Zone 3 residual instantaneous-overcurrent (0.25–50,000 primary amperes)
Z1DG	Zone 1 delay for ground faults (0–60 cycles in 3 cycle steps) e.g., enter 10.25 for a delay of 103 cycles.
Z2DG	Zone 2 delay for ground faults (0–2000 cycles in 3 cycle steps)
Z3DG	Zone 3 delay for ground faults (0–2000 cycles in 3 cycle steps)
TDUR	Minimum Trip Duration timer (0–2000 cycles in 3 cycle steps)

52BT	52B time delay (0.5 to 10,000 cycles in 3 cycle steps)
ZONE3	Zone 3 direction (F = forward or R = reverse)
67NE	Do you want directional torque control for the residual instantaneous-overcurrent elements? (Y or N)
67PE	Do you want directional torque control for the phase instantaneous-overcurrent elements? (Y or N)
32QE	Do you want negative-sequence directional supervision of the ground-overcurrent elements? (Y or N)
32VE	Do you want zero-sequence voltage-polarization for the directional element enabled? (Y or N)
32IE	Do you want zero-sequence current-polarization for the directional element enabled? (Y or N)
TIME1	Timeout for Port 1 (0–30 minutes)
TIME2	Timeout for Port 2 (0–30 minutes)
AUTO	Autoport (Port 1 or 2, or 3 for both Ports 1 and 2)
RINGS	The number of rings after which the modem connected to Port 1 answers (1–30 rings)

Refer to the functional description and be sure the settings you choose result in relay performance appropriate to your application.

As you enter settings, they are compared with setting limits above. Then the relay computes internal settings from your entries and checks to ensure that they fall within the specified range.

For example, let CTR = 1000 and 50N1 = 1. Each of these settings is admissible alone, but together they result in a secondary pickup setting of 1 mA, which is out of range. Internal setting error messages indicate out-of-range settings after you enable the new settings (refer to **Section 2: Specifications** for the secondary ranges of the relay elements).

The AUTO setting selects Port 1, 2, or both of the two serial ports for automatically transmitted messages. The table below shows the effect of each possible setting:

<u>AUTO SETTING</u>	<u>AUTOMATIC MESSAGE DESTINATION PORT</u>
1	1
2	2
3	1 and 2

SEL-267 RELAY COMMAND SUMMARY

Access Level 0

ACCESS Answer password prompt (if password protection is enabled) to gain access to Access Level 1. Three unsuccessful attempts pulses ALARM relay.

Access Level 1

2ACCESS Answer password prompt (if password protection is enabled) to gain access to Access Level 2. This command always pulses the ALARM relay.

DATE Shows or sets date. **DAT 2/3/89** sets date to Feb. 3, 1989. **DATE** pulses ALARM relay momentarily when year entered differs from year stored. The month and date settings are overridden when IRIG-B synchronization occurs.

EVENT Shows event record. **EVE 1** shows long form of most recent event.

HISTORY Shows DATE, TIME, EVENT TYPE, FAULT LOCATION, DURATION, CURRENT, and TARGETS for the 12 most recent faults.

IRIG Force immediate execution of time-code synchronization task.

METER Shows primary current, demand current, peak demand, voltage, and real and reactive power. **METER** runs once. **METER n** runs *n* times. **METER R** resets the peak demand currents.

QUIT Returns to Access Level 0 and resets targets to target 0.

SHOWSET Shows the relay and logic settings. This command does not affect the settings. The logic settings are shown in hexadecimal format for each mask.

STATUS Shows self-test status.

TARGETS Shows data and sets target lights as follows:

TAR 0: Relay Targets

TAR 2: RELAY WORD #2

TAR 4: RELAY WORD #4

TAR 6: Contact Outputs

TAR 1: RELAY WORD #1

TAR 3: RELAY WORD #3

TAR 5: Contact Inputs

TAR R: Clears targets and returns to TAR 0

Be sure to return to TAR 0 when done, so LEDs display fault targets.

TIME Sets or displays time. **TIM 13/32/00** sets clock to 1:32:00 PM. IRIG-B synchronization overrides this setting.

TRIGGER Triggers and saves an event report. (Type of event is EXT).

Access Level 2

CLOSE Closes circuit breaker, if allowed by jumper setting.

LOGIC Sets or displays logic masks MTU, MPT, MTO, MTB, MRI, MRC, MA1–MA4. ALARM relay closes while new settings are being computed, and event buffers are cleared.

OPEN	Opens circuit breaker, if allowed by jumper setting.
PASSWORD	Shows or sets passwords. Pulses the ALARM relay momentarily when new passwords are set. PAS 1 OTTER sets Level 1 password to OTTER. PAS 2 TAIL sets Level 2 password to TAIL.
SET	Initiates setting procedure. ALARM relay closes while new settings are being computed, and event buffers are cleared.

Use the following to separate commands and their parameters: space, comma, semicolon, colon, slash.

TABLE OF CONTENTS

SECTION 4: EVENT REPORTING	4-1
Introduction.....	4-1
Example Event Report	4-2
Interpretation of Voltage and Current Data	4-2
Relay Elements Status Indicators.....	4-4

SECTION 4: EVENT REPORTING

INTRODUCTION

The SEL-267 Relay transmits a summary event report in response to several events and saves a full event report in its memory. The summary report includes the identifier message entered at the beginning of the setting procedure as well as date, time, and type of event. If the event is a fault, the report displays fault location in miles, secondary ohms, fault duration, and a maximum fault current measurement. The report includes fault targets if the fault caused a trip (a setting permits disabling the fault locator).

The summary report is automatically transmitted from the designated automatic port (refer to AUTO setting) regardless of access level, as long as that port has not timed out. If the automatic transmissions are monitored by a dedicated channel or printed on a dedicated printer, enter zero for the timeout interval of the appropriate port (refer to TIME1, TIME2 settings).

The full report contains current and voltage information from which phasor diagrams of the pre-fault, fault, and post-fault conditions may be constructed. It also contains status points spanning the states of all relay elements, inputs, and outputs. These are useful in reviewing fault duration, relay element responses, arrival time of transfer-trip signaling with respect to local relay response, etc.

The full report is not transmitted automatically due to its length (about one page). You may request a full report with the **EVENT** command, e.g., **EVENT 1**.

The twelve most recent events are stored in SEL-267 Relay volatile memory. These data are retained as long as the control power remains on. This differs from the relay settings, which are retained in nonvolatile memory. Settings are retained until changed by the **SET** command, regardless of control power cycling. You may quickly review stored events with the **HISTORY** command.

Event reporting is triggered by any of the following:

Fault in any zone	Assertion of EXTERNAL TRIGGER
Input Assertion of DIRECT TRIP input	Execution of OPEN command
Assertion of BLOCK TRIP input	Execution of TRIGGER command
Assertion of PERMISSIVE TRIP input	

Another event report is triggered for the same fault if the trip occurs after the end of the first report.

Event reporting is not triggered by any of the following:

Assertion of DIRECT CLOSE Input	Changes to the 52A input
Execution of the CLOSE command	

See *Fault Locator* in **Section 2: Specifications** for more explicit information on event report triggering.

EXAMPLE EVENT REPORT

A full event report is provided at the end of this section. This sample event report was generated in response to a simulated fault on the Example 69 kV Line described in Initial Checkout in **Section 6: Maintenance and Testing**. The report details an A-to-ground fault 9 miles away. Test set settings were computed using the BASIC program in Appendix C and assume a source impedance of 0.2 of the total line impedance. For this test, the SEL-267 Relay currents and voltages were provided by a Doble F-2000 Test System. A latching relay was used to simulate the circuit breaker action and to provide a contact whose state is sensed by the SEL-267 Relay 52A input.

The settings for the test set appear below.

VA	VB	VC	IA	
28.71	76.59	68.45	19.18	volts or amps
0	-125	129	-59	degrees

In primary units of kilovolts and amperes, the voltages and currents are:

VA	VB	VC	IA	
17.2	46.0	41.1	1151	kilovolts or amperes

These were obtained using the potential and current transformer ratios assumed in the Example 69 kV Line. Note that these ratios are displayed at the end of the report:

$$\text{PTR} = 600.00 \qquad \text{CTR} = 60.00$$

The following paragraphs describe the response of the SEL-267 relay to this simulated fault using information from the full event report.

INTERPRETATION OF VOLTAGE AND CURRENT DATA

The voltage and current data provided in the event report are determined using the secondary quantities presented to the rear panel of the SEL-267 Relay through the processing steps outlined below.

- The input analog signals are filtered by two-pole low-pass filters with cutoff frequencies of about 85 Hz.
- The filtered analog signals are sampled four times per power system cycle and converted into numerical values.
- The sampled data are processed by digital filters which remove dc and ramp components. The unit sample response of these filters is:

$$1, -1, -1, 1$$

This filter has the property of a double differentiator-smoother.

- The digital filter output data are scaled into primary quantities using the current and potential transformer ratios entered in the setting procedure. Since the samples are taken four times per power system cycle and the four most recent samples are processed through the digital

filter every quarter-cycle, successive outputs of the filter arrive every 90 degrees. So, with respect to the present value of the filter output, the previous value was taken one quarter-cycle earlier and appears to be leading the present value by 90 degrees.

These filter output values can be used to represent the signals as phasors:

The PRESENT value of the output is the X-component of the phasor.

The PREVIOUS value of the output is the Y-component of the phasor.

It may seem confusing to refer to the older data as the leading component of the phasor. The following example may help. Consider a sinewave with zero phase shift with respect to $t = 0$ and a peak amplitude of 1. Now consider two samples, one taken at $t = 0$, and the other taken 90 degrees later. They have values 0 and 1, respectively. By the above rules, the phasor components are $(X,Y) = (1,0)$. Now consider a cosine function. Its samples, taken at the same time instants, are 1 and 0, while its phasor representation is $(0,1)$. The phasor $(0,1)$ leads the phasor $(1,0)$ by 90 degrees, and this agrees with the 90-degree lead of the cosine function with respect to the sine function.

To construct a phasor diagram of voltages and currents, select a pair of adjacent rows in a region of interest on the event report, e.g., pre-fault, fault, or post-fault. On Cartesian coordinates, plot the lower row (more recent data) as the X-components and the upper row (older data) as the Y-components. Complete phasor diagrams may be rotated to the preferred angle of reference. The effective value of any phasor equals the square root of the sum of the squares of its components.

Note that moving forward one quarter-cycle causes all phasors to rotate 90 degrees, as can be seen by plotting the phasor diagram using rows 1 and 2, then rows 2 and 3.

For example, refer to the first and second rows of cycle 6 of data in the full report:

<u>Currents</u>					<u>Voltages</u>		
IPOL	IR	IA	IB	IC	VA	VB	VC
0	-1024	-1024	0	1	-1.1	-35.6	33.4 (Y-component)
0	526	526	0	0	17.2	-28.6	-23.7 (X-component)

These were taken near the “middle” of the fault, as can be judged from the action of residual-overcurrent elements.

Convert these to polar form (magnitude and angle):

<u>Currents</u>					<u>Voltages</u>		
IPOL	IR	IA	IB	IC	VA	VB	VC
0	1151	1151	0	0	17.2	45.7	41.0 (magnitude)
*	-63	-63	*	*	-4	-129	125 (angle)
*	-59	-59	*	*	0	-125	129 (angle + 4)

In the third row, 4 degrees are added to all angles of the second row to assign the phase-A voltage phasor as the zero degree reference. The magnitude and shifted angles can be compared to the test set settings given earlier. Angle measurement errors are 1 degree or less, while magnitude errors are less than 1 percent.

The event report indicates a fault current of 1154.4 amperes primary, which concurs with the 1151-ampere test set current as referred to primary.

The indicated fault location is 9.02 miles. The “actual” fault location is 9.00 miles. The error is 9.02 – 9.00, or 0.02 mile, less than 1.0 percent of the actual fault location for this example.

RELAY ELEMENTS STATUS INDICATORS

The columns headed “Relays” indicate the states of all relay elements. Active states of the various relay elements are indicated by designator symbols corresponding with the relay element names. Inactive states are indicated by periods placed in the columns. The entries for active relay elements are shown below.

50P: Phase overcurrent elements	: 1=50P1 2=50P2 3=50P3	high-set picked up medium-set low-set
67P: Directional phase overcurrent elements	: 1=67P1 2=67P2 3=67P3	high-set picked up medium-set low-set
51P: Phase time-overcurrent element	: P=51PP : T=51PT	element picked up trip threshold reached
50N: Residual-overcurrent elements	: 1=50N1 2=50N2 3=50N3	high-set picked up medium-set low-set
67N: Directional ground-overcurrent units	: 1=67N1 2=67N2 3=67N3	high-set picked up medium-set low-set
51N: Residual time-overcurrent element	: P=51NP : T=51NT	element picked up trip threshold reached

The states of all output and input contacts are shown in the next two column groups, headed “Outputs” and “Inputs”. Assertion of any output or input contact is indicated by an asterisk (*) in the corresponding column; nonassertion is indicated by a period. The contents of the columns are:

OUTPUTS

TP : TRIP output
 CL : CLOSE output
 A1 : PROGRAMMABLE output #1
 A2 : PROGRAMMABLE output #2
 A3 : PROGRAMMABLE output #3
 A4 : PROGRAMMABLE output #4
 AL : ALARM output

INPUTS

DT : DIRECT TRIP input
PT : PERMISSIVE TRIP input
BT : BLOCK TRIP input
DC : DIRECT CLOSE input
52A : BREAKER AUXILIARY 52A SWITCH input
ET : EXTERNAL TRIGGER (for event report) input

In the example event report, the first element to detect the fault picks up in the third quarter-cycle of the fourth cycle of the event report.

This is the low-set residual-overcurrent element (50N3), as indicated by the “3” in the 50N column. For almost every actual fault, the first element(s) to pick up will be found near the sixteenth row of data.

In the seventeenth row of the report, the Zone 3 phase overcurrent element picks up, as indicated by the “3” in the 50P column. The Zone 2 residual-overcurrent element picks up in the eighteenth row, as indicated by the “2” in the 50N column. In the next quarter-cycle, the 67N2 element picks up and the A1 programmable output asserts. For the example settings, the A1 output is programmed to generate an over-reaching permissive signal for a POTT scheme, so it asserts as soon as any Zone 2 directional element picks up.

In the twenty-first quarter-cycle, the Zone 1 residual-overcurrent element (50N1) picks up. The TRIP output asserts in response, because the 50N1 element was selected in the UNCONDITIONAL TRIP MASK (MTU) of the LOGIC settings.

The 52A contact input monitors the latching relay (circuit breaker simulator) state. This input deasserts in the 24th row of the report, indicating that the latching relay had changed to the “open” state about one cycle after tripping was initiated.

Fault duration can be estimated from the total time the relay elements are picked up. In the Sample Event Report, relay elements were picked up for a total of nineteen quarter-cycles, or 4.75 cycles. This value is reported near the bottom of the report: Duration: 4.75.

See the **HISTORY** command description for further explanation of the data in this report.

SAMPLE EVENT REPORT

Example 69 kV Line					Date: 3/23/90		Time: 08:45:09.366			
FID=SEL-167-R400-V656mp12-D900323										
Currents (amps)				Voltages (kV)			Relays	Outputs	Inputs	
IPOL	IR	IA	IB	IC	VA	VB	VC	565565 071071 PPNNN	TCAAAAA PL1234L	DPBD5E TTTC2T A
0	0	0	0	1	-2.6	-33.1	36.0*
0	0	1	0	0	40.0	-22.3	-17.8*
0	0	0	0	-1	2.6	33.1	-36.0*
0	0	-1	0	0	-40.0	22.3	17.8*
0	0	-1	0	1	-2.6	-33.1	36.0*
0	0	1	0	0	40.0	-22.3	-17.8*
0	0	1	0	-1	2.6	33.1	-36.0*
0	0	-1	0	0	-40.0	22.3	17.8*
0	0	-1	0	1	-2.6	-33.1	36.0*
0	0	1	0	0	40.0	-22.2	-17.8*
0	0	1	0	-1	2.6	33.2	-36.0*
0	0	-1	0	0	-40.0	22.2	17.8*
0	0	-1	0	1	-2.6	-33.2	36.0*
0	0	1	0	0	38.8	-22.8	-18.4*
0	37	37	0	-1	0.4	33.2	-35.9	...3..*
0	-7	-8	0	0	-30.6	25.4	20.9	...3..*
0	-420	-418	0	1	0.3	-34.2	34.8	3..3..*
0	246	248	0	0	20.8	-27.9	-23.2	3..2..*
0	886	886	0	-1	1.0	35.4	-33.6	2..22..*
0	-506	-505	0	0	-17.6	28.5	23.7	22.22..	...*
0	-1024	-1024	0	1	-1.1	-35.6	33.4	22.12..	*.*...	...*
0	526	526	0	0	17.2	-28.6	-23.7	22.11..	*.*...	...*
0	1025	1024	0	-1	1.1	35.6	-33.4	22.11..	*.*...	...*
-1	-527	-526	0	-1	-17.1	28.6	23.8	22.11..	*.*...	...*
1	-1025	-1025	0	1	-1.1	-35.6	33.4	12.11..	*.*...
1	526	526	0	1	18.3	-28.0	-23.2	11.11..	*.*...
-1	1012	1012	0	-1	3.2	35.6	-33.4	22.11..	*.*...
0	-530	-530	0	0	-26.5	25.3	20.7	22.11..	*.*...
0	-631	-629	0	1	-3.9	-34.6	34.6	22.22..	*.*...
0	289	289	-1	0	36.4	-22.8	-18.5	22.22..	*.*...
0	166	162	1	-1	2.5	33.4	-35.8	3..3..	*.*...
0	-32	-32	1	0	-39.5	22.2	18.0	...3..	*.*...
0	-24	-22	-1	1	-2.4	-33.2	35.9	...3..	*.*...
0	3	4	-1	0	40.0	-22.2	-17.9	*.*...
0	4	3	1	-1	2.4	33.2	-35.9	*.*...
0	-1	-1	1	0	-40.0	22.1	17.9	*.*...
0	-1	-1	-1	1	-2.4	-33.2	35.9
0	0	1	-1	0	40.0	-22.1	-17.9
0	0	1	1	-1	2.4	33.2	-35.9
0	0	-1	1	0	-40.0	22.1	18.0
0	0	-1	-1	1	-2.4	-33.2	35.9
0	0	1	0	0	40.0	-22.1	-18.0
0	0	1	0	-1	2.4	33.3	-35.9
0	0	-1	0	0	-40.0	22.1	18.0
Event : AG Location : 9.02 mi 1.13 ohms sec Duration: 4.75 Flt Current: 1154.4 Targets: G1										
R1 =49.83	X1 =56.32	R0 =56.07	X0 =143.07	LL =60.00						
CTR =60.00	PTR =600.00	MTA =49.00	LOCAT=Y	DATC =15						
DCTH =120.00	79011=40.00	79012=60.00	79013=80.00	79RS =240.00						
51PP =120.00	51PTD=1.00	51PC =2	51PTC=N							
50P1 =1158.00	50P2 =516.00	50P3 =210.00								
Z1DP =0.00	Z2DP =160.00	Z3DP =30.00								
51NP =30.00	51NTD=2.00	51NC =2	51NTC=N							
50N1 =1008.00	50N2 =450.00	50N3 =30.00								
Z1DG =0.00	Z2DG =30.00	Z3DG =10.00	TDUR =9.00							
52BT =30	ZONE3=R	67NE =Y	67PE =Y							
32QE =N	32VE =Y	32IE =Y								
TIME1=5	TIME2=0	AUTO =2	RINGS=3							
Logic settings:										
MTU	MPT	MTB	MTO	MA1	MA2	MA3	MA4	MRI	MRC	
44	44	00	77	44	00	00	00	00	00	
44	66	00	77	66	00	00	00	44	00	
FF	FF	00	FF	FF	00	80	08	00	BB	
30	00	00	30	00	01	00	00	00	30	

EXPLANATION OF EVENT REPORT

Example 69 kV Line

Date: 10/01/91

Time: 08:45:09.366

FID=SEL-267-R400-V656mp12-D900323

		Currents (amps)			Voltages (kV)			Relays	Outputs	Inputs
IPOL	IR	IA	IB	IC	VA	VB	VC	565565 071071 PPNNN	TCAAAA PL1234L	DPBD5E TTTC2T A
0	886	886	0	-1	1.0	35.4	-33.6	2..22.	..*....*.
0	-506	-505	0	0	-17.6	28.5	23.7	22.22.	..*....*.
0	-1024	-1024	0	1	-1.1	-35.6	33.4	22.12.	*.*....*.
0	526	526	0	0	17.2	-28.6	-23.7	22.11.	*.*....*.
0	1025	1024	0	-1	1.1	35.6	-33.4	22.11.	*.*....*.
-1	-527	-526	0	-1	-17.1	28.6	23.8	22.11.	*.*....*.

Event : AG Location : 9.02 mi 1.13 ohms sec
Duration: 4.75 Flt Current: 1154.4 Targets: G1

R1 =49.83	X1 =56.32	R0 =56.07	X0 =143.07	LL =60.00
CTR =60.00	PTR =600.00	MTA =49.00	LOCAT=Y	DATC =15
DCTH =120.00	790I1=40.00	790I2=60.00	790I3=80.00	79RS =240.00
51PP =120.00	51PTD=1.00	51PC =2	51PTC=N	
50P1 =1158.00	50P2 =516.00	50P3 =210.00		
Z1DP =0.00	Z2DP =160.00	Z3DP =30.00		
51NP =30.00	51NTD=2.00	51NC =2	51NTC=N	
50N1 =1008.00	50N2 =450.00	50N3 =30.00		
Z1DG =0.00	Z2DG =30.00	Z3DG =10.00	TDUR =9.00	
52BT =30	ZONE3=R	67NE =Y	67PE =Y	
32QE =N	32VE =Y	32IE =Y		
TIME1=5	TIME2=0	AUTO =2	RINGS=3	

Currents and voltages are in primary amps and kV. Rows are 1/4 cycle apart. Time runs down page. Obtain phasor RMS value and angle using any entry as Y-component, and the entry immediately underneath as the X-component. For example, from bottom rows, IAY = 1024, IAX = -526. Therefore, IA = 1151 amps RMS primary, at an angle of $\text{ATAN}(1024/-526) = 117$ degrees, with respect to the sampling clock.

<FID> Row 2 shows the Firmware Identification Data. This line varies according to version.

<Relays> Columns show states of internal relay elements ---- Designators

50P : phase overcurrent	: 50P1, 50P2, 50P3	----> 1,2,3
67P : directional phase overcurrent	: 67P1, 67P2, 67P3	----> 1,2,3
51P : phase time-overcurrent	: 51PT	----> T
50N : inst ground overcurrent	: 50N1, 50N2, 50N3	----> 1,2,3
67N : directional ground overcurrent	: 67N1, 67N2, 67N3	----> 1,2,3
51N : ground time-overcurrent	: 51NT	----> T

<Outputs> Columns show states of output contacts: ON = "*" , OFF = "."
TP=TRIP, CL=CLOSE, A1-A4=PROGRAMMABLE, AL=ALARM

<Inputs> Columns show states of input contacts:
DT=DIRECT TRIP, PT=PERMISSIVE TRIP, BT=BLOCK TRIP, DC=DIRECT
CLOSE, 52A=PCB A-CONTACT, ET=EXTERNAL TRIGGER (event report)

<Event> Event type is one of AG,BG,CG = single-phase, AB,BC,CA = 2-phase
ABG,BCG,CAG = 2-phase to ground, ABC = 3-phase followed by a
"T" if a TRIP triggered the report

Other indications are TRIP = triggered by TRIP output
and EXT = externally or otherwise triggered

<Location> Distance to fault in miles. Indeterminate distance is 999999.

<Ohms Sec> Distance to fault in secondary ohms. Indeterminate ohms is 9999.

<Duration> Fault duration determined from relay element(s) pickup time

<Flt Current> Max phase current (primary amps) taken near middle of fault

<Targets> The targets indicate the relay elements that caused the trip.
 These targets are the same as the targets displayed on the front panel of the SEL-267 via the TARGET 0 command. The targets field indicates any combination of the following:

- P1: Zone 1 phase fault
- G1: Zone 1 ground fault
- P2: Zone 2 phase fault
- G2: Zone 2 ground fault
- P3: Zone 3 phase fault
- G3: Zone 3 ground fault
- 51P: Phase time-overcurrent trip
- 51N: Residual time-overcurrent trip

R1,X1,R0,X0 Primary series impedance settings for transmission line
 LL Line length corresponding to specified line impedances
 CTR, PTR Current and potential transformer ratios (XTR:1)
 MTA Maximum torque angle for the directional elements
 LOCAT Enable or disable fault locator (Y/N)
 DATC Demand ammeter time constant
 DCTH Demand current threshold
 790I1,2,3,RS Three-shot recloser Open and Reset intervals
 51PP,TD,C,TC Phase time-overcurrent pickup, Time-Dial, Curve, Torque Control
 50P1,2,3 Phase inst-overcurrent pickup settings zones 1, 2 and 3
 Z1DP,2,3 Zones 1, 2 and 3 timer settings for 3- and 2-phase faults
 51NP,TD,C,TC GND time-overcurrent Pickup, Time-Dial, Curve, Torque Control
 50N1,2,3 Ground inst-overcurrent pickup settings zones 1, 2 and 3
 Z1DG,2,3 Zone timers for ground faults
 TDUR Minimum Trip Duration Timer
 52BT 52B delay setting (for switch-onto-fault coordination)
 ZONE3 Directional orientation of all zone 3 elements (Fwd/Rvs)
 67NE,PE Ground and phase fault torque control enables
 32QE,VE,IE Ground fault directionality from (V2,I2), or (V0/IP,I0)
 TIME1,2 Communications port timeout intervals (automatic log-off)
 AUTO Port assignment for automatic message transmissions
 RINGS Number of rings to wait before modem answers telephone
 <Logic Settings> See LOGIC command for a description of mask setting.

TABLE OF CONTENTS

SECTION 5: INSTALLATION5-1

Conventional Terminal Block Model	5-1
Mounting.....	5-1
Frame Ground Connection.....	5-1
Power Connections	5-1
Secondary Circuits	5-1
Control Circuits.....	5-1
Communications Circuits.....	5-2
Jumper Selection	5-2
Baud Rate Selection Jumpers	5-2
Password Protection Jumpers	5-2
Remote Trip/Close Enable Jumper	5-2
A4 Output Contact Jumper.....	5-2
Output Contact Soldered Wire Jumpers	5-3
Communication Port External Power Jumpers	5-3
EIA-232 and IRIG-B Installation.....	5-3
9-Pin Connector Pin Number Convention.....	5-3
EIA-232 Cables	5-4
IRIG-B Input Description.....	5-5
Plug-In Connector Model	5-6
Mounting.....	5-6
Frame Ground Connection.....	5-6
Power Connections	5-6
Secondary Circuits	5-6
Control Circuits.....	5-7
Communications Circuits.....	5-7
Jumper Selection	5-7
Baud Rate Selection Jumpers	5-7
Password Protection Jumpers	5-8
Remote Trip/Close Enable Jumper	5-8
A4 Output Contact Jumper.....	5-8
Output Contact Soldered Wire Jumpers	5-8
Communication Port External Power Jumpers	5-8
Jumper Installation Instructions	5-8
EIA-232 and IRIG-B Installation.....	5-9
9-Pin Connector Pin Number Convention.....	5-9
EIA-232 Cables	5-10
IRIG-B Input Description.....	5-12
Installation Checkout	5-12

TABLES

Table 5.1: Pin Definitions	5-5
----------------------------------	-----

FIGURES

Figure 5.1:	SEL-267 External AC Current and Voltage Connection.....	5-14
Figure 5.2:	Communication and Clock Connections (One Unit at One Location)	5-14
Figure 5.3:	Communication and Clock Connections (Multiple Units at One Location).....	5-15
Figure 5.4:	Communications Diagram for Connection to the SEL-DTA	5-15
Figure 5.5:	SEL-267 Conventional Terminal Block Model DC External Connection Diagram (Typical).....	5-16
Figure 5.6:	SEL-267 Polarity-Sensitive Plug-In Connector Model DC External Connection Diagram (Typical).....	5-16
Figure 5.7:	SEL-267 Conventional Terminal Block Model Horizontal Front- and Rear-Panel Drawing.....	5-17
Figure 5.8:	Relay Dimensions and Drill Plan.....	5-18
Figure 5.9:	SEL-267 Relay Panel Cut-Out and Drill Plan for Panel Mount Models (Horizontal Mounting Shown; Dimensions also Apply to Vertical Mounting).....	5-19
Figure 5.10:	SEL-267 Plug-In Connector Model Horizontal Front- and Rear-Panel Drawing	5-20

SECTION 5: INSTALLATION

CONVENTIONAL TERMINAL BLOCK MODEL

Mounting

The SEL-267 Relay is designed for mounting by its front vertical flange in a 19-inch vertical relay rack. It may also be mounted semi-flush in a switchboard panel. Four #10 screws should be used for mounting. Figure 5.7 shows the front- and rear-panel drawings. Figure 5.8 and Figure 5.9 show the relay dimensions, panel cutout, and drill diagrams for the Conventional Terminal Block model relay.

Frame Ground Connection

Terminal 46 on the rear panel must be connected to frame ground for safety and performance. These terminals connect directly to the chassis ground of the instrument.

Power Connections

Terminals 44 and 45 on the rear panel must be connected to a source of control voltage. Control power passes through these terminals to the fuse, continues through a surge filter, and connects to the switching power supply. The control power circuitry is isolated from the frame ground.

Secondary Circuits

The SEL-267 Relay presents a very low burden to the secondary current and potential circuits. Each current circuit is independent of the others; there is no interconnection of current circuits inside the instrument. When current polarization is not desired or required, Terminals 35 and 36 may be left open-circuited.

The SEL-267 Relay requires 4-wire wye potentials because it includes the option of zero-sequence voltage polarization of the ground relaying functions. It is not possible to directly apply the SEL-267 Relay to circuits where line-to-line potential transformers are used. Please consider the SEL-267D or SEL-221D for such applications.

Control Circuits

The control inputs are dry. To assert the 52A input, control voltage must be applied to the 52A input terminals. Each input is individually isolated, and a terminal pair is brought out for each input. There are no internal connections between control inputs.

Control outputs are dry relay contacts rated for tripping duty. Each contact is protected by a metal-oxide varistor.

Communications Circuits

Connections to the two EIA-232 serial communications ports are made via the two 9-pin connectors labeled Port 1 and Port 2R on the rear panel and Port 2F on the front panel. Pins 5 and 9 connect directly to frame (chassis) ground. **These connections should not be relied upon for safety grounding since their current-carrying capacity is less than control-power short-circuit current and protection levels.**

The communications circuits are protected by low-energy, low-voltage MOVs and passive RC filters. Communications circuit difficulties can be minimized by keeping the length of the EIA-232 cables as short as possible. Lengths of 12 feet or less are recommended; in no case should the cable length exceed 100 feet. SEL recommends shielded communications cable for lengths in excess of 10 feet. Modems are required for communications over long distances.

Route the communications cables well away from the secondary and control circuits. Do not bundle the communications wiring with secondary or control circuit wiring. Noise could be coupled into the communications wiring from the control or secondary wiring. This noise could exceed the communications logic thresholds, introducing communications errors. The IRIG-B clock cable should also be routed away from control wiring and secondary circuits.

Jumper Selection

The jumpers described below are located on the front edge of the main board (J6). They are easily accessed by removing the top cover or pulling the drawout assembly out from the front.

Baud Rate Selection Jumpers

Jumper block J6 provides EIA-232 baud rate selection. The available baud rates are 300, 600, 1200, 2400, 4800, and 9600. To select a baud rate for a particular port, place the jumper so it connects the pin labeled with the desired port to a pin labeled with the desired baud rate.



Do not select two baud rates for the same port. This can damage the relay baud rate generator.

Password Protection Jumpers

When Jumper JMP103 is in place the password protection is disabled. This feature is useful if passwords are not required or when passwords are forgotten.

Remote Trip/Close Enable Jumper

You may execute remote trip/close commands when jumper JMP104 is in place. If Jumper JMP104 is removed, attempts to use the **OPEN** or **CLOSE** commands result in an "Aborted" message.

A4 Output Contact Jumper

With jumper JMP3 in the A4 position, the A4 output contact operates per logic mask setting MA4. With jumper JMP3 in the ALARM position, the A4 output contact is driven by the same signal that operates the dedicated ALARM output contact.

Output Contact Soldered Wire Jumpers

All the output contacts can be configured as “a” or “b” contacts with soldered wire jumpers JMP4 through JMP11 (each jumper has positions A and B). The output contact/soldered wire jumper correspondence is as follows:

<u>Output Contact</u>	<u>Jumper</u>
TRIP (terminals 1,2)	JMP11
TRIP (terminals 3,4)	JMP10
CLOSE	JMP9
A1	JMP8
A2	JMP7
A3	JMP6
A4	JMP5
ALARM	JMP4

Communication Port External Power Jumpers


DC power is available from Port 1 to Port 2R to power external devices. Jumpers must be selected to route dc power to the rear panel connectors. The internal jumpers are near Port 1 and are labeled as follows: JMP12 = +5 V; JMP13 = +12V; JMP14 = -12V. Use caution to ensure the dc current requirement of the external equipment does not exceed the relay power supply specifications. Only route dc power to the rear ports if required for your application.

EIA-232 and IRIG-B Installation

This section contains specific information concerning pinouts of the communications ports.

A pin definition of the 9-pin port connectors and cabling information for the EIA-232 ports appears below. Several types of EIA-232 cables are given. These and other cables are available from SEL. Cable configuration sheets are also available at no charge for a large number of devices. Contact the factory to request configuration sheets.


9-Pin Connector Pin Number Convention




(female chassis connector, as viewed from outside panel)

EIA-232 Cables


Cable 234A




Cable 222




Cable 231



Cable 239
Data and IRIG-B



Cable 272A
Data Only



- * DTE = Data Terminal Equipment (Computer, Terminal, Printer, etc.)
 ** DCE = Data Communications Equipment (Modem, etc.)

IRIG-B Input Description

The port labeled J201/AUX INPUT is intended for the demodulated IRIG-B time code input. The pin definitions are shown in Table 5.1.

Table 5.1: Pin Definitions

Pin	Name	Description
1	+5	*
2	IRIGIN HI	Positive IRIG-B input
3	IRIGIN LOW	Negative IRIG-B input
4	+12	*
6	-12	*
5, 9	GND	Ground for ground wires and shields

* Consult the factory before using these power supply outputs.

The current drive for an IRIG-B “one” is 10 to 20 mA. The input circuit consists of a 56-ohm resistor in series with the photodiode input of an optical isolator. The photodiode has a forward voltage drop of about 1.8 volts. The input may be driven directly by the output of a TTL-level driver with sufficient current capability. Inputs may also be driven in a current loop from a higher-voltage driver.

The IRIG-B serial format consists of a one-second-long, 100-pulse code divided into fields. The SEL-267 Relay decodes the second, minute, hour and day fields.

When IRIG-B data acquisition is activated either manually (with the **IRIG** command) or automatically, two consecutive frames are taken. The older frame is updated by one second and the two frames are compared. If they do not agree, the data are considered erroneous and discarded.

Automatic execution is invoked about once every five minutes, except near midnight on New Year's Eve. At this time IRIG-B data acquisition is halted so the system clock may implement the year change without interference from the IRIG-B clock.

This port accepts the demodulated version of the IRIG-B time code. An IRIG-B demodulator (SEL-IDM) is available from SEL to convert a modulated IRIG-B into 11 sources of demodulated IRIG-B.

PLUG-IN CONNECTOR MODEL

Mounting

The SEL-267 Relay is designed for mounting by its front vertical flange in a 19-inch vertical relay rack. It may also be mounted semi-flush in a switchboard panel. Four #10 screws should be used for mounting. Figure 5.10 shows the front- and rear-panel drawings. Figure 5.8 and Figure 5.9 show the relay dimensions, panel cutout, and drill diagrams for the Plug-in Connector model relay.

Frame Ground Connection

Terminal 46 on the rear panel must be connected to frame ground for safety and performance. These terminals connect directly to the chassis ground of the instrument.

Power Connections

Terminals 44 and 45 on the rear panel must be connected to a source of control voltage. Control power passes through these terminals to the fuse, continues through a surge filter, and connects to the switching power supply. The control power circuitry is isolated from the frame ground. A power connector is provided with the wiring harness to connect to terminals 44 and 45. The connector is available with #18 to #14 AWG conductor.

Secondary Circuits

The SEL-267 Relay presents a very low burden to the secondary current and potential circuits. Each current circuit is independent of the others; there is no interconnection of current circuits inside the instrument. When current polarization is not desired or required, Terminals 35 and 36 may be left open-circuited.

The current connector supplied with the wiring harness is a shorting type connector. When removed from the relay, the connector automatically shorts CT secondaries. The connector can be ordered with #16 to #10 AWG conductors.

The SEL-267 Relay requires 4-wire wye potentials because it includes the option of zero-sequence voltage polarization of the ground relaying functions. It is not possible to directly apply the SEL-267 Relay to circuits where line-to-line potential transformers are used. Please consider the SEL-267D or SEL-221D for such applications.

A PT connector is supplied with the wiring harness. The connector can be ordered with #18 to #14 AWG conductors.

Control Circuits

The control inputs are dry. To assert the 52A input, control voltage must be applied to the 52A input terminals. Each input is individually isolated, and a terminal pair is brought out for each input. There are no internal connections between control inputs.

Control outputs are dry relay contacts rated for 30 Adc make, 6 Adc carry, and 10 Adc interrupt with an L/R = 40 ms at 125 Vdc. The contacts can interrupt 10 A, L/R = 40 ms, 125 Vdc four times in one second, after which the contact must be allowed to cool for two minutes. Each contact is protected by a metal-oxide varistor. Note, the contacts are polarity sensitive.

Communications Circuits

Connections to the two EIA-232 serial communications ports are made via the two 9-pin connectors labeled Port 1 and Port 2R on the rear panel and Port 2F on the front panel. Pins 5 and 9 connect directly to frame (chassis) ground. **These connections should not be relied upon for safety grounding, since their current-carrying capacity is less than control-power short-circuit current and protection levels.**

The communications circuits are protected by low-energy, low-voltage MOVs and passive RC filters. Communications circuit difficulties can be minimized by keeping the length of the EIA-232 cables as short as possible. Lengths of 12 feet or less are recommended; in no case should the cable length exceed 100 feet. SEL recommends shielded communications cable for lengths in excess of 10 feet. Modems are required for communications over long distances.

Route the communications cables well away from the secondary and control circuits. Do not bundle the communications wiring with secondary or control circuit wiring. Noise could be coupled into the communications wiring from the control or secondary wiring. This noise could exceed the communications logic thresholds, introducing communications errors. The IRIG-B clock cable should also be routed away from control wiring and secondary circuits.

Jumper Selection

The jumpers described below are located on the front edge of the main board (J6). They are easily accessed by removing the top cover or pulling the drawout assembly out from the front.

Baud Rate Selection Jumpers

Jumper block J6 provides EIA-232 baud rate selection. The available baud rates are 300, 600, 1200, 2400, 4800, and 9600. To select a baud rate for a particular port, place the jumper so it connects the pin labeled with the desired port to a pin labeled with the desired baud rate.

Caution: Do not select two baud rates for the same port. This can damage the baud rate generator.

Password Protection Jumpers

When Jumper JMP103 is in place, the password protection is disabled. This feature is useful if passwords are not required or when passwords are forgotten.

Remote Trip/Close Enable Jumper

You may execute remote trip/close commands when jumper JMP104 is in place. If Jumper JMP104 is removed, attempts to use the **OPEN** or **CLOSE** commands result in an “Aborted” message.

A4 Output Contact Jumper

With jumper JMP3 in the A4 position, the A4 output contact operates per logic mask setting MA4. With jumper JMP3 in the ALARM position, the A4 output contact is driven by the same signal that operates the dedicated ALARM output contact.

Output Contact Soldered Wire Jumpers

All the output contacts can be configured as “a” or “b” contacts with soldered wire jumpers JMP4 through JMP11 (each jumper has positions A and B). The output contact/soldered wire jumper correspondence is as follows:

<u>Output Contact</u>	<u>Jumper</u>
TRIP (terminals 1,2)	JMP11
TRIP (terminals 3,4)	JMP10
CLOSE	JMP9
A1	JMP8
A2	JMP7
A3	JMP6
A4	JMP5
ALARM	JMP4

Communication Port External Power Jumpers

DC power is available from Port 1 to Port 2R to power external devices. Jumpers must be selected to route dc power to the rear panel connectors. The internal jumpers are near Port 1 and are labeled as follows: JMP12 = +5 V; JMP13 = +12V; JMP14 = -12V. Use caution to ensure the dc current requirement of the external equipment does not exceed the relay power supply specifications. Only route dc power to the rear ports if required for your application.

Jumper Installation Instructions

The power available from these ports is limited and should be used only for SEL-RDs, SEL-DTAs, dc-powered modems, or other low-wattage devices approved by SEL.

The power is available on either Port 1 or Port 2R. Port 2F, located on the front of the relay, does NOT have power available.

To install jumpers for supplying power through the rear EIA RS-232-C ports on all SEL-200 series relays (**except** SEL-279 and SEL-279H Relays), perform the following steps:


1. Remove the relay top cover or withdraw the main circuit board.
2. Locate jumpers JMP12 (+5 Vdc), JMP13 (+12 Vdc) and JMP14 (–12 Vdc) near the AUX INPUT connector.
3. Remove and install the needed jumpers in the “on” position.
4. Replace the top cover or re-insert the main circuit board. (Ensure that the board is correctly seated and the cables to the power supply and input transformers are reconnected.)

EIA-232 and IRIG-B Installation

This section contains specific information concerning pinouts of the communications ports.

A pin definition of the 9-pin port connectors and cabling information for the EIA-232 ports appears below. Several types of EIA-232 cables are given. These and other cables are available from SEL. Cable configuration sheets are also available at no charge for a large number of devices. Contact the factory to request configuration sheets.


9-Pin Connector Pin Number Convention




(female chassis connector, as viewed from outside panel)

EIA-232 Cables


Cable 234A




Cable 222




Cable 231




Cable 239
Data and IRIG-B



Cable 272A
Data Only



Cable 273A
Enhanced Data and IRIG-B



- * DTE = Data Terminal Equipment (Computer, Terminal, Printer, etc.)
- ** DCE = Data Communications Equipment (Modem, etc.)
- † When JMP13 and JMP14 are bridged

IRIG-B Input Description

The port labeled J201/AUX INPUT is intended for the demodulated IRIG-B time code input. The pin definitions are shown in Table 5.1.

Ports 1 and 2R may be configured to accept demodulated IRIG-B input. When JMP13 and JMP14 are bridged, pins 6 and 4 will accept –IRIG-B and +IRIG-B, respectively. See Table 2.3 for port pinouts.

The current drive for an IRIG-B “one” is 10 to 20 mA. The input circuit consists of a 56-ohm resistor in series with the photodiode input of an optical isolator. The photodiode has a forward voltage drop of about 1.8 volts. The input may be driven directly by the output of a TTL-level driver with sufficient current capability. Inputs may also be driven in a current loop from a higher-voltage driver.

The IRIG-B serial format consists of a one second long, 100 pulse code divided into fields. The SEL-267 Relay decodes the second, minute, hour and day fields.

When IRIG-B data acquisition is activated either manually (with the **IRIG** command) or automatically, two consecutive frames are taken. The older frame is updated by one second and the two frames are compared. If they do not agree, the data are considered erroneous and discarded.

Automatic execution is invoked about once every five minutes, except near midnight on New Year's Eve. At this time IRIG-B data acquisition is halted so the system clock may implement the year change without interference from the IRIG-B clock.

This port accepts the demodulated version of the IRIG-B time code. An IRIG-B demodulator (SEL-IDM) is available from SEL to convert a modulated IRIG-B into eleven sources of demodulated IRIG-B.

Installation Checkout

The following suggestions may be used or combined with your normal practice. In no case should a recommendation be followed unless it is allowed by the rules of your normal practice.

A portable terminal or computer is a convenient tool for providing local communications with the SEL-267 Relay during checkout in the field. Such a device should be connected to Port 2R or Port 2F for checkout (with Port 2 being designated as the automatic port using the AUTO setting in the **SET** command).

1. Apply control power and make sure the terminal displays the startup message. If not, set AUTO = 2, using the **SET** command on Access Level 2. Check the settings with the **ACCESS** and **SHOWSET** commands. Use the **TIME** and **DATE** commands to set the clock and date.
2. Apply three-phase voltages. Execute the **METER** command and verify that the readings are accurate. If not, be sure the correct PT ratio was entered and recall that displayed values are in primary line-to-neutral and line-to-line kV.
3. Use the **TRIGGER** command to save an event record. Type the **EVENT 1** command and examine the triggered event record. Referring to the top row of data as the “Y” components and the next row as the “X” components, plot the three voltage phasors to ensure that they are 120 degrees apart, of reasonable magnitudes, and rotating in the positive-sequence direction. The zero-sequence voltage Y and X components (times a factor of three) are the total of the

three Y components and the total of the three X components. These sums should be near zero if balanced three-phase potentials are present.

4. Use the **TARGET** command to check the state of all contact inputs and outputs. For example, if the connections to the circuit breaker 52A contact are made when the circuit breaker is closed, the **TARGET** command with option 5 should show a one (1) under the 52A heading (type **TARGET 5 <Enter>**).
5. Proceed to Access Level 2 with the **2ACCESS** command and appropriate password. Be sure that the ALARM relay contacts close and open when the **2ACCESS** command is executed (The ALARM pulse will not be detectable if the ALARM contacts are permanently asserted due to any other alarm condition).
6. The tripping function may be tested in any of three ways. First, be sure the circuit breaker can be tripped by the SEL-267 Relay when you execute the **OPEN** command. Be sure the TC bit is set in the MTU mask. Second, the circuit breaker should trip when you assert the DIRECT TRIP input, assuming that the DT bit is selected in the MTU mask. The TRIP output relay opens in both of these cases after the 52A input is deasserted, indicating that the circuit breaker has indeed opened. This function of monitoring the 52A contact ensures that the output relay does not inadvertently open while trip coil current is flowing in response to a control operation. Third, the circuit breaker should trip when you apply voltages and currents representing a fault condition for which the relay should respond. Here, the TRIP relay asserts regardless of the state of the 52A contact. It opens when the 52A input is deasserted AND fault conditions no longer exist. The TRIP output always remains closed for at least 60 ms.
7. There are two ways to close the circuit breaker: executing the **CLOSE** command or asserting the DIRECT CLOSE input. The CLOSE output relay asserts for either of these conditions if the 52A input is deasserted (indicating that the circuit breaker is open). The CLOSE relay deasserts when the 52A input is asserted or when the reclosing relay reset interval expires, whichever occurs first.

Note: The DC (Direct Close) optoisolated input (terminals 23, 24) on the SEL-267-2 Relay does not function as a direct close input—its function is redefined as a reclose enable input.
8. If the PERMISSIVE TRIP and BLOCK TRIP inputs are used, they should also be checked for proper operation (see the LOGIC MPT and LOGIC MTB settings). An event report should be generated for assertion of either the PT or BT inputs.
9. Asserting the EXTERNAL TRIGGER input should trigger the relay to record an event record. It does not affect the protective relaying functions in any way.
10. Use the **STATUS** command to inspect the self-test status. You may wish to save the reading as part of an “as-left” record.

When local checkout is complete, communications with the instrument via a remote interface (if used) should be tested. Be sure, in particular, that the automatic port is properly assigned, and that desired timeout intervals are selected for each port. Also, be sure to record password settings.






Figure 5.1: SEL-267 External AC Current and Voltage Connection




DWG. NO. 1005-101

Figure 5.2: Communication and Clock Connections (One Unit at One Location)




DWG. NO. 1005-102

Figure 5.3: Communication and Clock Connections (Multiple Units at One Location)



DWG. NO. A7-0413

Figure 5.4: Communications Diagram for Connection to the SEL-DTA




SEL-267-2 Relay Model Difference:

The DC (Direct Close) optoisolated input (terminals 23, 24) on the SEL-267-2 Relay does not function as a direct close input – its function is redefined as a reclose enable input. For the SEL-267-2 Relay, energize the DC (Direct Close) optoisolated inputs to enable reclosing (de-energize to disable reclosing).

DWG: 1267-2-01

Figure 5.5: SEL-267 Conventional Terminal Block Model DC External Connection Diagram (Typical)




The output contacts are polarity-dependent in the plug-in connector model (note "+" indication on the output contact terminals on the rear panel of the plug-in connector model).

SEL-267-2 Relay Model Difference:

The DC (Direct Close) optoisolated input (terminals 23, 24) on the SEL-267-2 Relay does not function as a direct close input – its function is redefined as a reclose enable input. For the SEL-267-2 Relay, energize the DC (Direct Close) optoisolated inputs to enable reclosing (de-energize to disable reclosing).


DWG: 1267-2-02

Figure 5.6: SEL-267 Polarity-Sensitive Plug-In Connector Model DC External Connection Diagram (Typical)



DIMENSION	MAIN BOARD ONLY (2U)	ONE I/O BOARD (3U)	TWO I/O BOARD (4U)
A	3.47" (88.1mm)	5.22" (132.6mm)	6.97" (177.0mm)
B	3.00" (76.2mm) 1.75" (44.5mm) optional	2.25" (57.2mm)	4.00" (101.6mm)


Figure 5.8: Relay Dimensions and Drill Plan



RELAY	DIM A	DIM B	DIM C
2U HIGH	3.00" (76.2mm)	3.60" (91.4mm)	4.90" (124.5mm)
3U HIGH	2.25" (57.2mm)	5.35" (135.9mm)	6.65" (168.9mm)
4U HIGH	4.00" (101.6mm)	7.10" (180.3mm)	8.40" (213.4mm)

NOTE:

Figure 5.9: SEL-267 Relay Panel Cut-Out and Drill Plan for Panel Mount Models (Horizontal Mounting Shown; Dimensions also Apply to Vertical Mounting)



DWG. 11113

Figure 5.10: SEL-267 Plug-In Connector Model Horizontal Front- and Rear-Panel Drawing

TABLE OF CONTENTS

SECTION 6: MAINTENANCE AND TESTING6-1

Initial Checkout.....	6-1
Equipment Required	6-1
Checkout Procedure	6-1
Low-Level Test Interface.....	6-3
Functional Tests.....	6-6
Setting Test	6-6
METER Test	6-6
Directional Element Checking	6-7
Overcurrent Element Checking.....	6-8
Testing the Input Circuits.....	6-8
Testing the Serial Ports	6-8
Testing the IRIG-B Time-Code Input	6-8
Testing the Power Supply Voltages	6-8
Calibration	6-9
Troubleshooting Guide	6-9
Inspection Procedure.....	6-9
Troubleshooting Table	6-9
All Front Panel LEDs Dark when TARGET RESET Button is Pushed	6-9
System Does Not Respond to Commands	6-10
Tripping Output Relay Remains Closed Following Fault.....	6-10
No Prompting Message Issued to Terminal Upon Power-Up.....	6-10
System Does Not Respond to Faults	6-10
Terminal Displays Meaningless Characters.....	6-11
Self-Test Failure: +5 Volts.....	6-11
Self-Test Failure: +15 Volts.....	6-11
Self-Test Failure: -15 Volts	6-11
Self-Test Failure: Offset.....	6-11
Self-Test Failure: ROM Checksum.....	6-11
Self-Test Failure: RAM	6-11
Self-Test Failure: A/D Converter.....	6-11
Stall Relay Closed (Alarm)	6-11
Factory Assistance	6-12

TABLES

Table 6.1: Fault Listings	6-4
Table 6.2: Fault Results	6-5

FIGURES

Figure 6.1: Low-Level Test Interface for the Conventional Terminal Block Model.....	6-4
---	-----

SECTION 6: MAINTENANCE AND TESTING

INITIAL CHECKOUT

The initial checkout of the SEL-267 Relay is intended to familiarize you with the instrument and ensure that all functions are operational.

Equipment Required

The following equipment is necessary for initial checkout of the SEL-267 Relay.

- Computer or dumb terminal with EIA-232 serial interface.
- Interconnecting cable between terminal and SEL-267 Relay.
- Source of control power.
- Source of three-phase voltages and at least two currents.
- Plug-in mating connectors/wiring harness (for plug-in connector models only).

Checkout Procedure

In the following procedure, you will use several of the SEL-267 Relay commands. **Section 3: Communications** provides full explanations of all commands. However, the following information should allow you to complete the checkout without referring to the detailed descriptions.

Inspect the instrument for physical damage such as dents or rattles.

Connect a computer terminal to Port 2R on the rear panel of the SEL-267 Relay. The terminal should be configured to 2400 baud, eight data bits, two stop bits, and no parity. Be sure your terminal is compatibly configured. **Section 3: Communications** provides additional details concerning port configuration. Baud rate selection is described in EIA-232 Jumpers in **Section 5: Installation**.

Connect a frame ground to terminal 46 on the rear panel. Connect control power to terminals 44 and 45.

Turn on the power and push the Target Reset button. All eight target LEDs should illuminate for a lamp test and to indicate no self-test failures. If not, be sure that power is present and check the fuse or fuses.

The following message should appear on the terminal:

```
-----  
Example 69 kV Line           Date: 10/10/91   Time: 01:01:01  
  
SEL-267  
=
```

The ALARM relay should pull in, holding its “b” contacts (terminals 15 and 16) open. If the relay pulls in but no message is received, check the terminal configuration. If neither occurs, turn off the power and refer to Troubleshooting Guide in this section.

The equal sign is a prompt indicating that communications with the SEL-267 Relay are at Access Level 0, the lowest of three access levels to the SEL-267 Relay. The only command allowed at this level is **ACCESS**, which admits you to Access Level 1, as described below.

Type the command **ACCESS** and press **<Enter>**. At the prompt, enter the password **OTTER** and press **<Enter>**. The prompt **=>** should appear, indicating that you have established communications at Access Level 1.

The SEL-267 Relay is shipped with demonstration settings which you may inspect using the **SHOWSET** command. Type **SHOWSET** and press **<Enter>** to view these settings. The terminal should display the following:

```

=>SHOWSET <Enter>

Settings for: Example 69 kV Line

R1  =49.83    X1  =56.32    R0  =56.07    X0  =143.07    LL  =60.00
CTR =60.00    PTR  =600.00    MTA =49.00    LOCAT=Y      DATC=15
DCTH=120.00   790I1=40.00   790I2=60.00   790I3=80.00   79RS=240.00
51PP=120.00   51PTD=1.00     51PC =2      51PTC=N
50P1=1158.00  50P2 =516.00   50P3 =210.00
Z1DP=0.00     Z2DP =160.00   Z3DP =30.00
51NP=30.00    51NTD=2.00     51NC =2      51NTC=N
50N1=1008.00  50N2 =450.00   50N3 =30.00
Z1DG=0.00     Z2DG =30.00    Z3DG =10.00   TDUR =9.00
52BT=30       ZONE3=R        67NE =Y      67PE =Y
32QE=N        32VE =Y       32IE =Y
TIME1=5       TIME2=0       AUTO =2      RINGS=3

Logic settings:
MTU  MPT  MTB  MTO  MA1  MA2  MA3  MA4  MRI  MRC
44   44   00   77   44   00   00   00   00   00
44   66   00   77   66   00   00   00   44   00
FF   FF   00   FF   FF   00   80   08   00   BB
30   00   00   30   00   01   00   00   00   30

```

A brief line-by-line description of the settings follows:

- Line 1: Positive- and zero-sequence impedances of the transmission line (primary ohms) and line length (miles) for which the impedances are given.
- Line 2: Current and voltage transformer ratios, maximum torque angle for the directional elements, fault locator enable, and demand ammeter time constant.
- Line 3: Demand current threshold, three reclosing open interval delays, and one reset delay.
- Line 4: Phase time-overcurrent pickup, time dial, curve, and torque control by direction.
- Line 5: Pickup settings for the three phase overcurrent elements.
- Line 6: Zone 1, 2, and 3 time delays for the phase overcurrent elements.
- Line 7: Residual time-overcurrent pickup, time dial, curve, and torque control enable.
- Line 8: Zone 1, 2, and 3 residual instantaneous-overcurrent element pickup thresholds.
- Line 9: Zone 1, 2, and 3 time delays for ground faults; minimum trip duration timer.
- Line 10: 52B time delay, Zone 3 direction selection, and the enables for directionality of the ground and phase instantaneous elements.

Line 11: This enables for the negative-sequence directional, voltage polarized zero-sequence directional, and current polarized zero-sequence directional elements.

Line 12: Port 1 and 2 timeouts, the autoport for automatically transmitted messages, and the number of rings after which the modem automatically answers.

A complete description of the settings appears under the **SET** command.

The description of the **LOGIC** command includes a detailed explanation of the logic settings. Each column in the logic settings display shows the masks for the Relay Word as follows:

Row 1, of any column: 51NP 50N1 50N2 50N3 51PP 50P1 50P2 50P3

Row 2, of any column: DFP 67N1 67N2 67N3 DFG 67P1 67P2 67P3

Row 3, of any column: 51NT Z1GT Z2GT Z3GT 51PT Z1PT Z2PT Z3PT

Row 4, of any column: ALRM TRIP TC DT 52BT SH1 TOCP DCTH

Logic settings are shown in hexadecimal format. The **SHOWSET** command description in *Section 3: Communications* includes a table and example of hexadecimal to binary conversion.

Disconnect the power from the relay and connect a source of three-phase voltages to the SEL-267 Relay at terminals 37 through 40. Apply 67 volts per phase (line-to-neutral) in positive-sequence. Wye-connect the two current sources to generate balanced positive-sequence currents. Connect A and B current sources to the dotted A and B current input terminals (29 and 31 respectively) of the SEL-267 Relay. Connect the undotted A and B current input terminals (30 and 32) both to the undotted C current input terminal (34). Connect the dotted C current input terminal (33) to both the A and B current source returns. Set the A-phase current source to 1 ampere, at the same angle as the A-phase voltage. Set the B-phase current source to 1 ampere, at the same angle as the B-phase voltage.

Reenergize the relay, execute the **ACCESS** command, and enter the password **OTTER** again.

Use the **METER** command to measure voltages and currents. With applied voltages of 67 volts per phase and a potential transformer ratio of 600:1, the line to neutral voltages displayed should be 40.2 kV. With applied currents of 1.0 ampere per phase and a current transformer ratio of 60, the currents displayed should be 60 amperes. Further, all line-to-line quantities should be balanced, differing from the line-to-neutral measurements by a factor of 1.73.

Test the digital relay/fault locator with the voltages and currents listed in the following chart. They were obtained assuming a source impedance of 0.2 times the total 60-mile line impedance and single-end feed for faults at the indicated locations and types. Appendix C provides a BASIC program which you may find helpful when computing test set settings.

LOW-LEVEL TEST INTERFACE

The SEL-267 Relay has low-level test interface between the calibrated input module and the separately-calibrated processing module. You may test the relay in either of two ways: conventionally, by applying ac current signals to the relay inputs; or by applying low magnitude ac voltage signals to the low-level test interface. Access the test interface by removing the relay front panel.

Figure 6.1 shows the interface connections. This drawing also appears on the inside of the relay front panel. Remove the ribbon cable between the two modules to access the outputs of the input module and the inputs to the processing module (relay main board).

You can test the relay processing module using signals from the SEL-RTS Low-Level Relay Test System. Never apply voltage signals greater than 20 volts peak-peak to the low-level test interface. Figure 6.1 shows the signal scaling factors.

You can test the input module two different ways:

- Measure the outputs from the input module with an accurate voltmeter, and compare the readings to accurate instruments in the relay input circuits, or
- replace the ribbon cable, execute the **METER** command, and compare the relay readings to accurate instruments in the relay input circuits.




Figure 6.1: Low-Level Test Interface for the Conventional Terminal Block Model

On the plug-in connector model, the low-level interface uses a 34-position connector rather than a 20-position connector. The input module output has been changed from J2 to J1. Pins 21–30 are no connects, pins 31 and 32 are +15 Vdc, and pins 33 and 34 are –15 Vdc.

The fault listings in Table 6.1 should cause certain combinations of output relays to remain closed and front panel LEDs to remain illuminated as long as the fault condition persists. Table 6.2 shows the results.

Table 6.1: Fault Listings

LOCATION	TYPE	VA	VB	VC	IA	IB	IC	UNITS
9 miles	AG	28.71	76.59	68.45	19.18	0	0	V or A
		0	–124.5	129.3	–58.70	0	0	Degrees
	BC	67.00	41.72	41.72	0	22.05	22.05	V or A
		0	–143.4	143.4	0	–138.5	41.50	Degrees
36 miles	AG	50.25	71.14	67.41	8.39	0	0	V or A
		0	–122.1	124.1	–58.70	0	0	Degrees
	BC	67.00	54.92	54.92	0	9.64	9.64	V or A
		0	–127.6	127.6	0	–138.5	41.50	Degrees

LOCATION	TYPE	VA	VB	VC	IA	IB	IC	UNITS
54 miles	AG	54.80	70.00	67.26	6.10	0	0	V or A
		0	-121.6	123.0	-58.70	0	0	Degrees
	BC	67.00	58.10	58.10	0	7.01	7.01	V or A
		0	-125.2	125.2	0	-138.5	41.50	Degrees

Table 6.2: Fault Results

Location	Type	Output Relays	Target LEDs
9 miles	AG	TRIP, A1, A2, A3, A4	G1
9 miles	BC	TRIP, A1, A2, A4	P1
36 miles	AG	TRIP, A1, A2, A3, A4	51N
36 miles	AG	TRIP, A1, A2, A4	51P
54 miles	AG	TRIP, A1, A2, A3, A4	51N
54 miles	BC	TRIP, A1, A2, A4	51P

The output relay A1 at terminals (7 and 8) is set to key permissive trip for any Zone 1 fault, directionally supervised Zone 2 fault, and time delayed trip element. From the table, output relay A1 should close for all faults.

The A2 output relay on terminals (9 and 10) monitors the demand current threshold. Since the demand current exceeds the demand current threshold, the A2 output relay operates for all of the faults shown in the first table.

The A3 output relay on terminals (11 and 12) monitors the residual time-overcurrent trip (51NT). Since the fault condition persists longer than the 51N time delay, the output relay A3 operates for any of the ground faults shown in the first table as determined by the settings.

The output relay A4 at terminals (13 and 14) is set to monitor the phase time-overcurrent trip (51PT). The polyphase time-overcurrent relay element operates on the largest phase current magnitude. Therefore, the A4 output asserts for both phase and ground faults as shown in the table.

Command Descriptions in **Section 3: Communications** provides a detailed description of the programming of the output relays A1 through A4 and six other logic masks (MRC, MRI, etc.).

The Zone 1 ground fault target (G1) illuminated for the ground fault at 9 miles because the Zone 1 ground overcurrent relay element caused the trip (Z1DG set to zero or instantaneous trip for the example 69 kV line). The displayed targets generally disclose the relay element that caused the trip to occur for the fault. The fault targets are automatically cleared by the next fault, before the new fault targets are presented.

Each fault generates a short event report. Type **EVENT 1** and press **<Enter>** to display a full event report for the last fault. The report provides an eleven cycle record of the currents, voltages, relay element states, and states of all contact inputs and outputs. The twelve newest reports are saved.

This checkout procedure demonstrates only a few of the features of the SEL-267 Relay. Study **Section 2: Specifications**, **Section 3: Communications**, and **Section 4: Event Reporting** in this manual to obtain a complete understanding of the capabilities of the SEL-267 Relay. For additional test procedures, refer to **Appendix C**.

FUNCTIONAL TESTS

Setting Test

To make sure the relay accepts settings, perform the following steps:

1. Gain Level 2 Access (see **ACCESS** and **2ACCESS** commands).
2. Type **SET** and press **<Enter>**.
3. Change one setting. For example, change the maximum torque angle (MTA) from 49 to 60 degrees.
4. Type **END <Enter>** to complete the setting procedure. When you receive the “OK (Y or N) ?” prompt, answer **YES <Enter>**. The ALARM contact should close for several seconds while the relay computes internal settings, unless an alarm condition exists (i.e., self-test failure).
5. Use **SHOWSET** to inspect the settings; make sure your change was accepted.
6. Use **SET** and **SHOWSET** again to restore and check the settings.
7. Type **LOG MTU <Enter>**.
8. Change one bit.
9. Complete the logic setting procedure.
10. Type **LOG MTU <Enter>** again, and make sure the bit change is present. Restore the setting, and use **SHOWSET** to check the original setting.

METER Test

This single-phase test checks the magnitude accuracy and phase balance.

1. Connect the voltage input terminals VA, VB, and VC. Apply 50 Vac from the terminals to the neutral point.
2. Connect the current inputs in series and apply a current of five amperes through the three inputs. One way to do so without a test set is to derive this current using a resistor and a stepdown transformer energized from the same source. When the instruments provide 50 ac input to the voltage inputs, the phase angle between the current and the voltage is nearly zero.
3. Use the **METER** command to inspect the measured voltages, currents, and power. Voltages VA, VB, and VC should equal the applied voltage times the potential transformer ratio setting. With the Example 69 kV Line settings, you should obtain:

$$= VB = VC = 50 * 600 = 30 \text{ kV. } (\pm 0.5 \%)$$

Voltages VAB, VBC, and VCA should be less than 0.3 kV.

Similarly, currents IA, IB, and IC should equal the applied current times the current transformer ratio. With the Example 69 kV Line settings, you should obtain:

$$A = IB = IC = 5 * 60 = 300 \text{ A. } (\pm 1 \%)$$

Difference currents IAB, IBC, and ICA should be less than 6 amperes.

The power reading should be:

$$V_A * I_A + V_B * I_B + V_C * I_C = 27 \text{ MW.}$$

The reactive power reading should be less than 0.24 MVAR.

Directional Element Checking

Type **TAR 2 <Enter>** (**TARGETS** command) to observe Relay Word Row #2 with the DFP and DFG bits for testing the negative-sequence element. The DFP bit status is displayed on the first LED from the left. The DFG bit status is displayed on the fifth LED from the left.

The negative-sequence element may be checked as follows:

Apply $V_A = 30$ volts, $V_B = 0$, and $V_C = 0$. This results in an applied $V_2 = 10$ volts.

Apply $I_A = 3$ amperes, corresponding to a negative-sequence current of one ampere.

Move the phase of the current with respect to the voltage, and observe the boundary of the directional element at $MTA \pm 90$ degrees.

The voltage-polarized part of the zero-sequence element is checked identically to the negative-sequence element, except the DFG bit is used for indication. Type **TARGET 2 <Enter>** to display Relay Word Row #2.

Apply the same voltages and currents used for the negative-sequence element test. This yields an applied $V_0 = 10$ volts and I_0 of 1 ampere.

Move the phase of the current with respect to the voltage, and observe the boundary of the zero-sequence directional element at $MTA \pm 90$ degrees.

The current polarization is checked by turning off the voltage and applying a second current source to the polarizing current input (IP). Use an amplitude of 3 amperes and move the phase of I_A with respect to IP. Maximum torque is at zero degrees, so you should observe the boundary of the characteristic at ± 90 degrees.

Observe the DFP bit to check the positive-sequence element. Apply the following balanced three-phase voltages to the relay:

	VA	VB	VC
MAGNITUDE	67	67	67 (volts)
ANGLE	0	-120	120 (degrees)

Use an amplitude of 5 amperes for I_A and move the phase of I_A with respect to the balanced three-phase currents. Observe the boundary of the positive-sequence directional element at $MTA \pm 90$ degrees.

Overcurrent Element Checking

Type **TARGET 1 <Enter>** to check pickup of the 50N1, 50N2, and 50N3 residual-overcurrent elements. The command displays Relay Word Row #1 with the overcurrent element bits on the target LEDs.

Apply current to one phase, and observe the pickup and dropout of each element.

Check the pickup and dropout of the phase overcurrent elements in a similar manner by typing **TARGET 1 <Enter>** to display the 50P1, 50P2, and 50P3 bits on the LEDs. Apply current to one phase, and observe the pickup and dropout of each element.

Check the pickup of residual time-overcurrent element (51NP) and phase time-overcurrent element (51PP) with the 51NP and 51PP bits in Relay Word Row #1. Type **TARGET 1 <Enter>** to check these pickups. Apply current to one phase (close in magnitude to the set pickup) and observe the pickup and dropout of the elements.

Testing the Input Circuits

1. Use the **TARGETS** command to set the LEDs to follow the contact inputs. Type **TAR 5 <Enter>**.
2. Apply control voltage to each input and observe that the corresponding target LED turns on. Event reports should be triggered whenever you energize the DT, PT, BT, and ET inputs.

Testing the Serial Ports

The Initial Checkout procedure assumes that you connect a terminal to Port 2. Set the baud rate of Port 1 to the same value as that of Port 2 and switch your terminal from Port 2 to Port 1. Make sure you can communicate through this port.

Testing the IRIG-B Time-Code Input

1. Connect a source of demodulated IRIG-B time code to the Auxiliary Port of the SEL-267 Relay with a series resistor to monitor the current. Adjust the source to obtain an “ON” current of about 10 mA.
2. Execute the **IRIG** command, and make sure the SEL-267 Relay clock displays the correct date and time.

Note: For a convenient, inexpensive test of the IRIG-B port, use a recording of the IRIG-B signal passed through a simple demodulator. Please contact the factory for further details.

Testing the Power Supply Voltages

1. Execute the **STATUS** command and inspect the voltage readings for the +5 and ± 15 volt supplies.
2. At the Auxiliary Port, use a voltmeter to read the +5 and ± 12 volt outputs. The 12-volt outputs are derived from the 15-volt supplies using three-terminal regulators. Refer to Table 5.1 or the relay rear panel for port pinout.

3. Compare the +5 volt readings from the status report and the voltmeter. The voltage difference should be less than 50 mV, and both readings should be within 0.15 volts of five volts.
4. The 12-volt supplies should be within 0.5 volt of their nominal values.

CALIBRATION

Each SEL relay is factory calibrated. If you suspect that the relay is out of calibration, please contact the factory.

TROUBLESHOOTING GUIDE

Inspection Procedure

The following inspection procedure should be completed before the system is disturbed. After you finish the inspection procedure, proceed to *Troubleshooting Table* in this section.

- Measure and record control power voltage present at terminals 44 and 45.
- Check to see that the power is on, but do not turn system off if it is on.
- Measure and record the voltage present at all control inputs.
- Measure and record the state of all output relays.
- Inspect the cabling to the serial communications ports and be sure that a communications device is connected to at least one communications port.

TROUBLESHOOTING TABLE

All Front Panel LEDs Dark when TARGET RESET Button is Pushed

- Power is off.
- Blown fuse.
- Input power not present.
- Self-test failure.
- Target command improperly set.

Note: For 1, 2, 3, and 4, the ALARM relay contacts should be closed.

System Does Not Respond to Commands

- Communications device not connected to system.
- SEL-267 Relay or communications device at incorrect baud rate or other communication parameter incompatibility, including cabling error.
- Internal connector loose or disconnected.
- System is currently processing event record (wait several seconds).
- System is attempting to transmit information, but cannot due to handshake line conflict (check communications cabling).
- System is in the XOFF state, halting communications (type <Ctrl+Q> to put system in XON state).

Tripping Output Relay Remains Closed Following Fault

- Tripping condition still present.
- Output relay contacts burned closed.
- Failure of main board.

No Prompting Message Issued to Terminal Upon Power-Up

- Terminal not connected to system.
- Wrong baud rate.
- Improper connection of terminal to system.
- Other port designated as the AUTOMATIC port (see AUTO setting in the **SET** command).
- Port time-out interval set to a value other than zero.
- Failure of main board.

System Does Not Respond to Faults

- Relay improperly set. Review your settings with the **SET** and **LOGIC** commands.
- Improper test set settings.
- CT or PT input cable wiring error. Check input voltages and currents with **METER** command and **TRIGGER** and **EVENT** sequence.
- Analog input cable between transformer and main board loose or defective.
- Check built-in-test status with **STATUS** command.

Terminal Displays Meaningless Characters

- Baud rate incorrectly set. Check terminal configuration (see *Section 3: Communications*).

Self-Test Failure: +5 Volts

- Power supply +5 volt output out of tolerance. See **STATUS** command.
- A/D converter failure.

Self-Test Failure: +15 Volts

- Power supply +15 volt output out of tolerance. See **STATUS** command.
- A/D converter failure.

Self-Test Failure: -15 Volts

- Power supply -15 volt output out of tolerance. See **STATUS** command.
- A/D converter failure.

Self-Test Failure: Offset

- Offset drift (adjust offsets).
- A/D converter drift.
- Loose ribbon cable from transformers to main board.

Self-Test Failure: ROM Checksum

- EEPROM failure (replace EEPROMs).

Self-Test Failure: RAM

- Failure of static RAM IC (replace RAM).

Self-Test Failure: A/D Converter

- A/D converter failure.
- RAM error not detected by RAM test.

Stall Relay Closed (Alarm)

- Power is off.
- Blown fuse.
- Power supply failure.

- Improper EEPROMs or EEPROM failure.
- Main board failure.

FACTORY ASSISTANCE

We appreciate your interest in SEL products. If you have questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 USA
Telephone: +1.509.332.1890
Fax: +1.509.332.7990
Internet: www.selinc.com

TABLE OF CONTENTS

APPENDIX A: FIRMWARE AND MANUAL VERSIONS..... A-1

Firmware	A-1
Determining the Firmware Version in Your Relay	A-1
Instruction Manual	A-2

APPENDIX B: INTERNAL LOGIC DIAGRAMS.....B-1

APPENDIX C: ONEBUS: PROGRAM TO COMPUTE TEST SET SETTINGS FOR TESTING DISTANCE RELAYSC-1

APPENDIX D: MODEM COMMUNICATIONSD-1

TABLES

Table A.1: Firmware Revision History	A-1
Table A.2: Instruction Manual Revision History	A-2

FIGURES

Figure B.1: SEL-267 Conventional Terminal Block Model Main Board Troubleshooting Test Points and Jumper Locations.....	B-1
Figure B.2: SEL-267 Plug-In Connector Model Main Board Troubleshooting Test Points and Jumper Locations	B-2

APPENDIX A: FIRMWARE AND MANUAL VERSIONS

FIRMWARE

Determining the Firmware Version in Your Relay

To find the firmware revision number in your relay, obtain an event report (which identifies the firmware) using the **EVENT** command. This is an FID number with the Part/Revision number in bold:

FID=**SEL-167-R407**-656mp1z2-D931026

For a detailed explanation of the Firmware Identification Number (FID) refer to *Section 4: Event Reporting*. This manual covers SEL relays that contain firmware bearing the following part numbers and revision numbers:

Table A.1: Firmware Revision History

Firmware Part/Revision No.	Description of Firmware
Board 100 (Rev 4)/200 SEL-167-R409-980417 SEL-167-R508-980417 SEL-167-R608-980417	60 Hz, 5 Amp, Mi, ABC Rotation 60 Hz, 5 Amp, Km, ABC Rotation 60 Hz, 5 Amp, Mi, ACB Rotation
Board 100 (Rev 3) SEL-167-R113-980417 SEL-167-R208-980417 SEL-167-R309-980417	60 Hz, 5 Amp, Mi, ABC Rotation 60 Hz, 5 Amp, Km, ABC Rotation 60 Hz, 5 Amp, Mi, ACB Rotation
Board 100 (Rev 4)/200 SEL-167-R408 SEL-167-R507 SEL-167-R607	60 Hz, 5 Amp, Mi, ABC Rotation 60 Hz, 5 Amp, Km, ABC Rotation 60 Hz, 5 Amp, Mi, ACB Rotation
Board 100 (Rev 3) SEL-167-R112 SEL-167-R207 SEL-167-R308	60 Hz, 5 Amp, Mi, ABC Rotation 60 Hz, 5 Amp, Km, ABC Rotation 60 Hz, 5 Amp, Mi, ACB Rotation
Board 100 (Rev 4)/200 SEL-167-R407 SEL-167-R506 SEL-167-R606	60 Hz, 5 Amp, Mi, ABC Rotation 60 Hz, 5 Amp, Km, ABC Rotation 60 Hz, 5 Amp, Mi, ACB Rotation
Board 100 (Rev 3) SEL-167-R111 SEL-167-R206 SEL-167-R307	60 Hz, 5 Amp, Mi, ABC Rotation 60 Hz, 5 Amp, Km, ABC Rotation 60 Hz, 5 Amp, Mi, ACB Rotation

INSTRUCTION MANUAL

The date code at the bottom of each page of this manual reflects the creation or revision date.

Table A.2 lists the instruction manual release dates and a description of modifications. The most recent instruction manual revisions are listed at the top.

Table A.2: Instruction Manual Revision History

Revision Date	Summary of Revisions
This manual differs from the previous version as follows:	
20071030	<ul style="list-style-type: none"> – Moved Manual Change Information to Appendix A.
This manual differs from the previous version as follows:	
20000207	<ul style="list-style-type: none"> – Explained the operation of the DC (Direct Close) input on the SEL-267-2 Relay model in various places in the manual – its function is redefined as a reclose enable input (see especially the Reclosing Relay subsection in Section 2: Specifications). – Corrections to Figure 5.5: SEL-267 Conventional Terminal Block Model DC External Connection Diagram (Typical) and Figure 5.6: SEL-267 Polarity-Sensitive Plug-In Connector Model DC External Connection Diagram (Typical). – Added Figure 5.9: SEL-267 Relay Panel Cut-Out and Drill Plan for Panel Mount Models (Horizontal Mounting Shown; Dimensions also Apply to Vertical Mounting) for panel mount models. – Section 2 and Section 5—all pages reissued.
This manual differs from the previous version as follows:	
990611	<ul style="list-style-type: none"> – Incorporated “ACB Phase Rotation Option” and “Kilometer Option” addenda into Section 1: Introduction. – Updated Output Contacts in Section 2: Specifications to include Plug-In Connectors Option (High-Current Interrupting Output Contacts) specifications. – Incorporated “New SEL-200-Series Optical Isolator Logic Input Rating” addendum into Section 2: Specifications. – Removed General Specifications: Plug-In Connector Model subsection from Section 2: Specifications. – Incorporated “Direct Close Input” addendum into Section 2: Specifications. The heading now reads, “Direct Close (DC) Input”. – Incorporated “Jumper Installation Instructions” addendum into Section 5: Installation. – Updated Figure 5.8: SEL-267 (Shallow) Relay Dimensions, Panel Cutout, and Drill Diagrams for Conventional Terminal Block Model and changed figure caption to read Relay Dimensions and Drill Plan. – Removed Figure 5.10: SEL-267 (Shallow) Relay Dimensions, Panel Cutout, and Drill Diagrams for Plug-In Connector Model.

* Information about changes to earlier versions of the SEL-267, -2 Instruction Manual is not available.




Figure B.1: SEL-267 Conventional Terminal Block Model Main Board Troubleshooting Test Points and Jumper Locations




Figure B.2: SEL-267 Plug-In Connector Model Main Board Troubleshooting Test Points and Jumper Locations

APPENDIX C: ONEBUS: PROGRAM TO COMPUTE TEST SET SETTINGS FOR TESTING DISTANCE RELAYS

The BASIC program in this note determines voltages and currents which would appear on distance relay terminals for ground and phase faults on a radial system with source impedance at the same angle as line impedance. It is useful in determining test voltage and current settings for SEL distance relays and fault locating equipment.

The program was initially designed to run on a TRS-80 Model 100 briefcase computer but may be installed on virtually any personal computer or laptop.

The program first prompts you for the positive- and zero-sequence impedances of the transmission line. Enter the data in secondary ohms for the entire length of the protected line.

Next, you may enter fault resistance, which is used in the ground-fault computations.

Enter source impedance as a per-unit value with a base of the previously-entered transmission line data. For example, if the radial system has a source impedance of about ten percent of the entered line impedance, enter 0.1 for the per-unit distance from the source to the bus.

Specify the distance from the bus to the fault as a fraction of the total line length. To obtain the voltages and currents for a fault one-half the way down the line from the bus, enter 0.5 for the distance from the bus to the fault.

After you enter this data, the program begins computations. The display then shows voltages and currents for both an AG and BC fault. These data can be entered into any active test source.

The bottom line of the display offers you a choice of entering new impedance data (I), changing the distance from the source to the bus (B), specifying a new fault location (F), or quitting (Q).

```

1  REM SCHWEITZER ENGINEERING LABORATORIES, INC.
2  REM 2350 NE Hopkins Court
3  REM Pullman, WA 99163-5603
4  REM
10 REM COMPUTE DOBLE SETTINGS FOR A ONE-BUS
SYSTEM
20 REM HOMOGENEOUS SYSTEM
30 REM SOURCE VOLTS= 67 L-N
40 REM
50 REM ENTER IMPEDANCES FOR 100% OF LINE
60 INPUT "ENTER Z1: R,X";R1,S1
70 INPUT "ENTER Z0: R,X";R0,S0
75 INPUT "ENTER RF FOR GND FLTS";RF
80 REM
90 REM ENTER BUS LOC. FROM SOURCE
100 INPUT "DIST SOURCE TO BUS (PU OF LINE)";S
120 INPUT "DIST BUS TO FAULT (PU OF LINE)";F
130 REM
140 REM PHASE A TO GROUND
150 REM COMPUTE POS SEQ CURRENT
160 X = RO+2*R1: Y = S0+2*S1
170 R3 = R1-RO: S3 = S1-S0
180 AR=1/(S+F): AI=0
190 BR=X : BI=Y
195 BR=BR+3*RF/(S+F)
200 GOSUB 2000
210 I = RR : J = RI
220 IA = 3*67*I: JA=3*67*J
225 IB=0:JB=0:IC=0:JC=0
230 AR=X:AI=Y:BR=I:BI=J
232 GOSUB 1000
234 UA=67*(1-S*RR):VA=67*(-S*RI)
240 AR=R3 :AI=S3
250 BR=I :BI=J
260 GOSUB 1000
270 TR=S*RR :TS=S*RI
280 UB=67*(-0.5+TR)
290 VB=67*(-SQR(3)/2+TS)
300 UC=67*(-0.5+TR)
310 VC=67*(SQR(3)/2+TS)
315 FF$="A-G"
320 GOSUB 4041
500 REM B-C FAULT
510 AR=1: AI=0
520 BR=2*R1*(S+F):BI=2*S1*(S+F)
530 GOSUB 2000
540 I=RR:J=RI
550 IA=0:JA=0
560 AR=I:AI=J:BR=0:BI=-67*SQR(3)
570 GOSUB 1000
580 IB=RR:JB=RI:IC=-IB:JC=-JB
590 UA=67:VA=0
600 AR=I:AI=J:BR=S*R1:BI=S*S1
610 GOSUB 1000
620 AR=RR:AI=RI:BR=0:BI=SQR(3)

630 GOSUB 1000
635 TR=RR:TS=RI
640 UB=67*(-0.5+TR)
650 VB=67*(-SQR(3)/2+TS)
660 UC=67*(-0.5+TR)
670 VC=67*(0.5*SQR(3)-TS)
675 FF$="B-C"
680 GOSUB 4041
900 INPUT "IMP BUS FAULT OR QUIT (I,B,F,Q)";A$
910 IF A$ = "I" THEN GOTO 50
920 IF A$ = "B" THEN GOTO 75
930 IF A$ = "F" THEN GOTO 120 ELSE GOTO 999
999 END
1000 REM MULT SUBROUTINE
1010 REM AR,AI * BR,BI = RR,RI
1020 RR=AR*BR-AI*BI
1030 RI=AI*BR+AR*BI
1040 RETURN
2000 REM DIVISION SUBROUTINE
2010 REM AR,AI / BR,BI = RR,RI
2020 D = BR*BR + BI*BI
2030 RR = AR*BR + AI*BI
2040 RR = RR/D
2050 RI = BR*AI - AR*BI
2060 RI = RI/D
2070 RETURN
3000 REM RECT TO POLAR CONV
3010 REM AR,AI, TO RH, TH
3020 PI = 3.14159265358
3030 IF (AR=0 AND AI=0) THEN RH=0: TH=0: RETURN
3040 IF (AR=0 AND AI>0) THEN RH=AI: TH=90: RETURN
3050 IF (AR=0 AND AI<0) THEN RH=-AI: TH=-90: RETURN
3060 IF (AR>0) THEN TH=(180/PI)*ATN(AI/AR)
3070 IF (AR<0) THEN TH=(180/PI)*ATN(AI/AR)+180
3080 IF TH>180 THEN TH = TH-360
3090 RH=SQR(AR*AR+AI*AI)
3100 RETURN
4041 AR=UA:AI=VA:GOSUB 3000
4042 UA=RH:VA=TH
4043 AR=UB:AI=VB:GOSUB 3000
4044 UB=RH:VB=TH-VA
4045 AR=UC:AI=VC:GOSUB 3000
4046 UC=RH:VC=TH-VA
4047 AR=IA:AI=JA:GOSUB 3000
4048 IA=RH:JA=TH-VA
4049 AR=IB:AI=JB:GOSUB 3000
4050 IB=RH:JB=TH-VA
4055 AR=IC:AI=JC:GOSUB 3000
4060 IC=RH:JC=TH-VA
4061 VA=0
4100 PRINT " VA VB VC IA IB IC"
4130 PRINT USING"###.## ";UA;UB;UC;IA;IB;IC,
4132 PRINT FF$
4140 PRINT USING"##### ";VA;VB;VC;JA;JB;JC
4150 RETURN

```


APPENDIX D: MODEM COMMUNICATIONS

The SEL-267 Relay interfaces directly with a commercial grade Hayes-compatible telephone modem for automatic-answer dial-up communications applications. A field installation with an SEL-267 Relay and a modem can be accessed by telephone with another modem and a computer or terminal.

The modem connects to Port 1 with a cable available from SEL. The modem is normally powered from 120 Vac, but a dc-powered modem is available which can be powered from the SEL-267 Relay. Please contact SEL for further details.

The SEL-267 Relay responds to control messages sent by the modem. These are RING, CONNECT, NO CARRIER, ERROR, and OK. The responses ensure that the modem is programmed to answer after the number of rings specified for RINGS in the **SET** command.

Keep the following points in mind when applying and using the SEL-267 Relay and a modem in an automatic-answer scheme:

- Modem setting considerations:
- Modem must be compatible with the Hayes “AT” command set.
- Modem must be set to auto answer.
- Modem must not echo commands sent to it.
- Modem must send responses to commands with verbose (English words) result codes.
- Modem must automatically or manually set communications parameters to 8 data bits, 2 stop bits, and no parity.
- Always use a finite timeout interval, so that if communications are disturbed, the SEL-267 Relay has a chance to reconfigure the modem and clear its communications buffers of data and control characters. An interval of five minutes is recommended (see the TIME1 setting). When the Port 1 timeout occurs the SEL-267 Relay sends a command to the modem to hang up. This feature helps prevent accumulation of a large telephone toll when no activity is sensed by the SEL-267 Relay during the timeout interval.
- Be careful about the number of rings programmed for the RINGS setting. It can be as many as 30, but large numbers result in long delays.
- Some communications devices allow the use of an XON/XOFF communications protocol. In general, the SEL-267 Relay functions quite well with these. However, these devices can occasionally leave the SEL-267 Relay in the XOFF state upon hanging up. This is a problem because you must wait your timeout interval before the XOFF state is cancelled automatically by the SEL-267 Relay. In the XOFF state, the SEL-267 Relay cannot respond to the modem; it has been told to remain silent. If you call the SEL-267 Relay and do not get a prompt, send an XON (<Ctrl+Q>).
- For the same reason, do not hang up after you have stopped a transmission using XOFF (<Ctrl+S>). If you wish to terminate a lengthy transmission, use <Ctrl+X>.
- When the modem answers the telephone, the SEL-267 Relay forces it into its control state to ensure proper initialization. To do so, the SEL-267 Relay sends the following string immediately after establishing the connection:

AT+++

- Wait for the SEL-267 Relay prompt before typing commands. If no prompt appears, send an XON or press **<Enter>**.
- If modem power is turned off and back on, many modems "forget" the number of rings to wait before answering. The SEL-267 Relay programs the modem with this information. After power is restored, the modem will answer the first call on the first ring. For subsequent calls, it will answer after the number of rings programmed with the RINGS setting until power is interrupted again. The SEL-267 Relay retains the number of rings in its nonvolatile memory, so control power interruptions do not disturb the setting.

SETTINGS SHEETS FOR THE SEL-267 RELAY

Page 1 of 7
Date _____

SUBSTATION _____ CIRCUIT _____

BREAKER _____ DEVICE NO. _____

FUNCTION _____

MAKE _____ C.T. SETTING _____

MODEL/STYLE NO. _____ P.T. SETTING _____

PART # _____ SOFTWARE VERSION _____

SERIAL # _____ POWER SUPPLY _____ Vac/Vdc LOGIC INPUT _____ Vdc

SECONDARY INPUTS: V/Ø = 67L-N, NOMINAL AMPS = 5, Hz = 60

HEXADECIMAL REPRESENTATION

MASK: MTU (UNCONDITIONAL TRIP)

	SETTING							
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH

MASK: MPT (PERMISSIVE TRIP)

	SETTING							
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH

SETTINGS SHEETS FOR THE SEL-267 RELAY

Page 2 of 7
Date _____

MASK: MTB (BLOCK TRIP)

									SETTING
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3	
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3	
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT	
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH	

HEXADECIMAL
REPRESENTATION

MASK: MTO (SWITCH ONTO FAULT)

									SETTING
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3	
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3	
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT	
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH	

MASK: MA1 (A1 CONTACT)

									SETTING
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3	
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3	
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT	
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH	

SETTINGS SHEETS FOR THE SEL-267 RELAY

Page 3 of 7
Date _____

MASK: MA2 (A2 CONTACT)

									SETTING
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3	
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3	
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT	
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH	

MASK: MA3 (A3 CONTACT)

									SETTING
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3	
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3	
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT	
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH	

HEXADECIMAL REPRESENTATION

MASK: MA4 (A4 CONTACT)

									SETTING
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3	
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3	
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT	
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH	

SETTINGS SHEETS FOR THE SEL-267 RELAY

Page 4 of 7
Date _____

MASK: MRI (RECLOSE INITIATE)

	SETTING							
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH

MASK: MRC (RECLOSE CANCEL)

	SETTING							
ROW #1: RELAY WORD BINARY REPRESENTATION	51NP	50N1	50N2	50N3	51PP	50P1	50P2	50P3
ROW #2: RELAY WORD BINARY REPRESENTATION	DFP	67N1	67N2	67N3	DFG	67P1	67P2	67P3
ROW #3: RELAY WORD BINARY REPRESENTATION	51NT	Z1GT	Z2GT	Z3GT	51PT	Z1PT	Z2PT	Z3PT
ROW #4: RELAY WORD BINARY REPRESENTATION	ALRM	TRIP	TC	DT	52BT	SH1	TOCP	DCTH

BINARY HEXADECIMAL

0000	*	0
0001	*	1
0010	*	2
0011	*	3
0100	*	4
0101	*	5
0110	*	6
0111	*	7
1000	*	8
1001	*	9
1010	*	A
1011	*	B
1100	*	C
1101	*	D
1110	*	E
1111	*	F

ACCESS Command passwords: (6 Characters excluding
"SPACE, COMMA, SEMI-COLON and
SLASH")

LEVEL 0: "=" **ACCESS <Enter>**
PASSWORD:

LEVEL 1: "=>" **2ACCESS <Enter>**
PASSWORD:

LEVEL 2: "=>>" ENTER SETTINGS PER MATRIX TABLE

NOTE: FOR NEW RELAYS BEGIN WITH LEVEL 1 PASSWORD =
OTTER AND LEVEL 2 PASSWORD = TAIL. WHEN IN
LEVEL 2 MODIFY PASSWORDS VIA PASSWORD 1 AND 2
COMMANDS.

SETTINGS SHEETS **FOR THE SEL-267 RELAY**

Page 5 of 7
Date _____

DESCRIP.	POS-SEQ. IMPEDANCE		ZERO-SEQ. IMPEDANCE		LINE LENGTH*
RANGE	0-9999 (PRI. OHMS)		0-9999 (PRI. OHMS)		0.1-999 MILES
ABBREV. SETTING	R1	X1	R0	X0	LL
DESCRIP.	C. T. RATIO	P. T. RATIO	MAX. TORQUE ANGLE	ENABLE FAULT LOCATOR	DEMAND AMMETER TIME CONSTANT
RANGE	1-5000:1	1-10,000:1	47°-90°	(Y OR N)	5-60 MINUTES
ABBREV. SETTING	CTR	PTR	MTA	LOCAT	DATC
DESCRIP.	DEMAND CURRENT THRESHOLD	RECL. OPEN INTERVAL 1	RECL. OPEN INTERVAL 2	RECL. OPEN INTERVAL 3	RECL. RESET TIME
RANGE	0.25-50,000 AMP PRI.	0-10,000 CYCLES (1/4 CYCLE STEPS)	0-10,000 CYCLES (1/4 CYCLE STEPS)	0-10,000 CYCLES (1/4 CYCLE STEPS)	60-8,000 CYCLES (1/4 CYCLE STEPS)
ABBREV. SETTING	DCTH	79OI1	79OI2	79OI3	79RS
DESCRIP.	PHASE TIME O/C PICKUP (1 A-12.6 A sec.)	PHASE TIME O/C TIME DIAL	PHASE TIME O/C CURVE SHAPE	PHASE TIME O/C TORQUE CONTROL	
RANGE	0.25-50,000 AMP PRI.	0.5-15 (0.01 STEPS)	1, 2, 3, OR 4	(Y OR N)	
ABBREV. SETTING	51PP	51PTD	51PC	51PTC	
DESCRIP.	ZONE 1 PHASE O/C PICKUP (1 A-25 x 51PP)	ZONE 2 PHASE O/C PICKUP (1 A-25 x 51PP)	ZONE 3 PHASE O/C PICKUP (1 A-25 x 51PP)		
RANGE	0.25-50,000 AMP PRI.	0.25-50,000 AMP PRI.	0.25-50,000 AMP PRI.		
ABBREV. SETTING	50P1	50P2	50P3		
DESCR.	ZONE 1 ØØ & 3Ø TIMER	ZONE 2 ØØ & 3Ø TIME-STEP BACKUP TIMER	ZONE 3 ØØ & 3Ø TIME-STEP BACKUP TIMER		
RANGE	0-60 CYCLES (1/4 CYCLE STEPS)	0-2000 CYCLES (1/4 CYCLE STEPS)	0-2000 CYCLES (1/4 CYCLE STEPS)		
ABBREV. SETTING	Z1DP	Z2DP	Z3DP		

SETTINGS SHEETS **FOR THE SEL-267 RELAY**

Page 6 of 7
Date _____

DESCR.	GND TIME O/C PICKUP	GND TIME O/C TIME DIAL	GND TIME O/C CURVE SHAPE	GND TIME O/C TORQUE CONTROL	
RANGE	(0.25–6.3A SEC) 0.25–50,000 AMP PRI.	0.5–15 (0.01 STEPS)	1, 2, 3, OR 4	(Y OR N)	
ABBREV. SETTING	51NP	51NTD	51NC	51NTC	
DESCR.	ZONE 1 GND INST. O/C	ZONE 2 GND INST. O/C	ZONE 3 GND INST. O/C		
RANGE	(0.2A–47x51NP) 0.25–50,000 AMP PRI.	(0.2A–47x51NP) 0.25–50,000 AMP PRI.	(0.2A–47x51NP) 0.25–50,000 AMP PRI.		
ABBREV. SETTING	50N1	50N2	50N3		
DESCR.	ZONE 1 GND TIMER	ZONE 2 GND TIME-STEP BACKUP TIMER	ZONE 3 GND TIME-STEP BACKUP TIMER	MINIMUM TRIP DURATION TIMER	
RANGE	0-60 CYCLES (1/4 CYCLE STEPS)	0-2000 CYCLES (1/4 CYCLE STEPS)	0-2000 CYCLES (1/4 CYCLE STEPS)	0-2000 CYCLES (1/4 CYCLE STEPS)	
ABBREV. SETTING	Z1DG	Z2DG	Z3DG	TDUR	
DESCR.	52BT TIME DELAY	ZONE 3 DIRECTION	GND INSTANT. O/C TORQUE CONTROL	PHASE INSTANT. O/C TORQUE CONTROL	
RANGE	0.5–10,000 CYCLES	(F OR R)	(Y OR N)	(Y OR N)	
ABBREV. SETTING	52BT	ZONE3	67NE	67PE	
DESCR.	GND O/C NEGATIVE-SEQ. POLAR.	GND O/C ZERO-SEQ. VOLTAGE POLAR.	GND O/C ZERO-SEQ. CURRENT POLAR.		
RANGE	(Y OR N)	(Y OR N)	(Y OR N)		
ABBREV. SETTING	32QE	32VE	32IE		
DESCR.	PORT #1 TIMEOUT	PORT #2 TIMEOUT	AUTOMATIC MESSAGE TRANSMIT AUTOPORT SELECTION	# RINGS AFTER WHICH MODEM ANSWERS	
RANGE	0–30 MINUTES	0–30 MINUTES	PORT 1, 2, OR 3 (BOTH)	1–30	
ABBREV. SETTING	TIME1	TIME2	AUTO	RINGS	

**SETTINGS SHEETS
FOR THE SEL-267 RELAY**

Page 7 of 7
Date _____

* Line Length = Station #1 (relay location) to Station #2; the full distance in miles between stations.

NOTE: Length can also be represented in metric units, primary or secondary ohms, etc., but conversion to miles would be required.

Comments: _____

Settings recommended by _____

Settings approved by _____

Settings approved by _____

Settings performed by _____

Test printout required. ☐ Yes ☐ No Substation _____

SEL-267 RELAY COMMAND SUMMARY

Access Level 0

ACCESS Answer password prompt (if password protection is enabled) to gain access to Access Level 1. Three unsuccessful attempts pulses ALARM relay.

Access Level 1

2ACCESS Answer password prompt (if password protection is enabled) to gain access to Access Level 2. This command always pulses the ALARM relay.

DATE Shows or sets date. **DAT 2/3/89** sets date to Feb. 3, 1989. **DATE** pulses ALARM relay momentarily when year entered differs from year stored. The month and date settings are overridden when IRIG-B synchronization occurs.

EVENT Shows event record. **EVE 1** shows long form of most recent event.

HISTORY Shows DATE, TIME, EVENT TYPE, FAULT LOCATION, DURATION, CURRENT, and TARGETS for the 12 most recent faults.

IRIG Force immediate execution of time-code synchronization task.

METER Shows primary current, demand current, peak demand, voltage, and real and reactive power. **METER** runs once. **METER n** runs *n* times. **METER R** resets the peak demand currents.

QUIT Returns to Access Level 0 and resets targets to target 0.

SHOWSET Shows the relay and logic settings. This command does not affect the settings. The logic settings are shown in hexadecimal format for each mask.

STATUS Shows self-test status.

TARGETS Shows data and sets target lights as follows:

TAR 0: Relay Targets

TAR 2: RELAY WORD #2

TAR 4: RELAY WORD #4

TAR 6: Contact Outputs

TAR 1: RELAY WORD #1

TAR 3: RELAY WORD #3

TAR 5: Contact Inputs

TAR R: Clears targets and returns to TAR 0

Be sure to return to TAR 0 when done, so LEDs display fault targets.

TIME Sets or displays time. **TIM 13/32/00** sets clock to 1:32:00 PM. IRIG-B synchronization overrides this setting.

TRIGGER Triggers and saves an event report. (Type of event is EXT).

Access Level 2

CLOSE Closes circuit breaker, if allowed by jumper setting.

LOGIC Sets or displays logic masks MTU, MPT, MTO, MTB, MRI, MRC, MA1–MA4. ALARM relay closes while new settings are being computed, and event buffers are cleared.

OPEN	Opens circuit breaker, if allowed by jumper setting.
PASSWORD	Shows or sets passwords. Pulses the ALARM relay momentarily when new passwords are set. PAS 1 OTTER sets Level 1 password to OTTER. PAS 2 TAIL sets Level 2 password to TAIL.
SET	Initiates setting procedure. ALARM relay closes while new settings are being computed, and event buffers are cleared.

Use the following to separate commands and their parameters: space, comma, semicolon, colon, slash.

EXPLANATION OF EVENT REPORT

Example 69 kV Line

Date: 10/01/91

Time: 08:45:09.366

FID=SEL-267-R400-V656mp12-D900323

		Currents (amps)			Voltages (kV)			Relays	Outputs	Inputs
IPOL	IR	IA	IB	IC	VA	VB	VC	565565 071071 PPNNN	TCAAAA PL1234L	DPBD5E TTTC2T A
0	886	886	0	-1	1.0	35.4	-33.6	2..22.	..*....*.
0	-506	-505	0	0	-17.6	28.5	23.7	22.22.	..*....*.
0	-1024	-1024	0	1	-1.1	-35.6	33.4	22.12.	*.*....*.
0	526	526	0	0	17.2	-28.6	-23.7	22.11.	*.*....*.
0	1025	1024	0	-1	1.1	35.6	-33.4	22.11.	*.*....*.
-1	-527	-526	0	-1	-17.1	28.6	23.8	22.11.	*.*....*.

Event : AG Location : 9.02 mi 1.13 ohms sec
Duration: 4.75 Flt Current: 1154.4 Targets: G1

R1 =49.83	X1 =56.32	R0 =56.07	X0 =143.07	LL =60.00
CTR =60.00	PTR =600.00	MTA =49.00	LOCAT=Y	DATC =15
DCTH =120.00	790I1=40.00	790I2=60.00	790I3=80.00	79RS =240.00
51PP =120.00	51PTD=1.00	51PC =2	51PTC=N	
50P1 =1158.00	50P2 =516.00	50P3 =210.00		
Z1DP =0.00	Z2DP =160.00	Z3DP =30.00		
51NP =30.00	51NTD=2.00	51NC =2	51NTC=N	
50N1 =1008.00	50N2 =450.00	50N3 =30.00		
Z1DG =0.00	Z2DG =30.00	Z3DG =10.00	TDUR =9.00	
52BT =30	ZONE3=R	67NE =Y	67PE =Y	
32QE =N	32VE =Y	32IE =Y		
TIME1=5	TIME2=0	AUTO =2	RINGS=3	

Currents and voltages are in primary amps and kV. Rows are 1/4 cycle apart. Time runs down page. Obtain phasor RMS value and angle using any entry as Y-component, and the entry immediately underneath as the X-component. For example, from bottom rows, IAY = 1024, IAX = -526. Therefore, IA = 1151 amps RMS primary, at an angle of $\text{ATAN}(1024/-526) = 117$ degrees, with respect to the sampling clock.

<FID> Row 2 shows the Firmware Identification Data. This line varies according to version.

<Relays> Columns show states of internal relay elements ---- Designators

50P : phase overcurrent	: 50P1, 50P2, 50P3	----> 1,2,3
67P : directional phase overcurrent	: 67P1, 67P2, 67P3	----> 1,2,3
51P : phase time-overcurrent	: 51PT	----> T
50N : inst ground overcurrent	: 50N1, 50N2, 50N3	----> 1,2,3
67N : directional ground overcurrent	: 67N1, 67N2, 67N3	----> 1,2,3
51N : ground time-overcurrent	: 51NT	----> T

<Outputs> Columns show states of output contacts: ON = "*" , OFF = "."
TP=TRIP, CL=CLOSE, A1-A4=PROGRAMMABLE, AL=ALARM

<Inputs> Columns show states of input contacts:
DT=DIRECT TRIP, PT=PERMISSIVE TRIP, BT=BLOCK TRIP, DC=DIRECT
CLOSE, 52A=PCB A-CONTACT, ET=EXTERNAL TRIGGER (event report)

<Event> Event type is one of AG,BG,CG = single-phase, AB,BC,CA = 2-phase
ABG,BCG,CAG = 2-phase to ground, ABC = 3-phase followed by a
"T" if a TRIP triggered the report

Other indications are TRIP = triggered by TRIP output
and EXT = externally or otherwise triggered

<Location> Distance to fault in miles. Indeterminate distance is 999999.

<Ohms Sec> Distance to fault in secondary ohms. Indeterminate ohms is 9999.

<Duration> Fault duration determined from relay element(s) pickup time

<Flt Current> Max phase current (primary amps) taken near middle of fault

<Targets> The targets indicate the relay elements that caused the trip.
 These targets are the same as the targets displayed on the front panel of the SEL-267 via the TARGET 0 command. The targets field indicates any combination of the following:

- P1: Zone 1 phase fault
- G1: Zone 1 ground fault
- P2: Zone 2 phase fault
- G2: Zone 2 ground fault
- P3: Zone 3 phase fault
- G3: Zone 3 ground fault
- 51P: Phase time-overcurrent trip
- 51N: Residual time-overcurrent trip

R1,X1,R0,X0 Primary series impedance settings for transmission line
 LL Line length corresponding to specified line impedances
 CTR, PTR Current and potential transformer ratios (XTR:1)
 MTA Maximum torque angle for the directional elements
 LOCAT Enable or disable fault locator (Y/N)
 DATC Demand ammeter time constant
 DCTH Demand current threshold
 790I1,2,3,RS Three-shot recloser Open and Reset intervals
 51PP,TD,C,TC Phase time-overcurrent pickup, Time-Dial, Curve, Torque Control
 50P1,2,3 Phase inst-overcurrent pickup settings zones 1, 2 and 3
 Z1DP,2,3 Zones 1, 2 and 3 timer settings for 3- and 2-phase faults
 51NP,TD,C,TC GND time-overcurrent Pickup, Time-Dial, Curve, Torque Control
 50N1,2,3 Ground inst-overcurrent pickup settings zones 1, 2 and 3
 Z1DG,2,3 Zone timers for ground faults
 TDUR Minimum Trip Duration Timer
 52BT 52B delay setting (for switch-onto-fault coordination)
 ZONE3 Directional orientation of all zone 3 elements (Fwd/Rvs)
 67NE,PE Ground and phase fault torque control enables
 32QE,VE,IE Ground fault directionality from (V2,I2), or (V0/IP,I0)
 TIME1,2 Communications port timeout intervals (automatic log-off)
 AUTO Port assignment for automatic message transmissions
 RINGS Number of rings to wait before modem answers telephone
 <Logic Settings> See LOGIC command for a description of mask setting.

SEL-267 RELAY COMMAND SUMMARY

Access Level 0

ACCESS Answer password prompt (if password protection is enabled) to gain access to Access Level 1. Three unsuccessful attempts pulses ALARM relay.

Access Level 1

2ACCESS Answer password prompt (if password protection is enabled) to gain access to Access Level 2. This command always pulses the ALARM relay.

DATE Shows or sets date. **DAT 2/3/89** sets date to Feb. 3, 1989. **DATE** pulses ALARM relay momentarily when year entered differs from year stored. The month and date settings are overridden when IRIG-B synchronization occurs.

EVENT Shows event record. **EVE 1** shows long form of most recent event.

HISTORY Shows DATE, TIME, EVENT TYPE, FAULT LOCATION, DURATION, CURRENT, and TARGETS for the 12 most recent faults.

IRIG Force immediate execution of time-code synchronization task.

METER Shows primary current, demand current, peak demand, voltage, and real and reactive power. **METER** runs once. **METER n** runs *n* times. **METER R** resets the peak demand currents.

QUIT Returns to Access Level 0 and resets targets to target 0.

SHOWSET Shows the relay and logic settings. This command does not affect the settings. The logic settings are shown in hexadecimal format for each mask.

STATUS Shows self-test status.

TARGETS Shows data and sets target lights as follows:

TAR 0: Relay Targets

TAR 2: RELAY WORD #2

TAR 4: RELAY WORD #4

TAR 6: Contact Outputs

TAR 1: RELAY WORD #1

TAR 3: RELAY WORD #3

TAR 5: Contact Inputs

TAR R: Clears targets and returns to TAR 0

Be sure to return to TAR 0 when done, so LEDs display fault targets.

TIME Sets or displays time. **TIM 13/32/00** sets clock to 1:32:00 PM. IRIG-B synchronization overrides this setting.

TRIGGER Triggers and saves an event report. (Type of event is EXT).

Access Level 2

CLOSE Closes circuit breaker, if allowed by jumper setting.

LOGIC Sets or displays logic masks MTU, MPT, MTO, MTB, MRI, MRC, MA1–MA4. ALARM relay closes while new settings are being computed, and event buffers are cleared.

OPEN	Opens circuit breaker, if allowed by jumper setting.
PASSWORD	Shows or sets passwords. Pulses the ALARM relay momentarily when new passwords are set. PAS 1 OTTER sets Level 1 password to OTTER. PAS 2 TAIL sets Level 2 password to TAIL.
SET	Initiates setting procedure. ALARM relay closes while new settings are being computed, and event buffers are cleared.

Use the following to separate commands and their parameters: space, comma, semicolon, colon, slash.

EXPLANATION OF EVENT REPORT

Example 69 kV Line

Date: 10/01/91

Time: 08:45:09.366

FID=SEL-267-R400-V656mp12-D900323

		Currents (amps)			Voltages (kV)			Relays	Outputs	Inputs
IPOL	IR	IA	IB	IC	VA	VB	VC	565565 071071 PPNNN	TCAAAA PL1234L	DPBD5E TTTC2T A
0	886	886	0	-1	1.0	35.4	-33.6	2..22.	..*....*.
0	-506	-505	0	0	-17.6	28.5	23.7	22.22.	..*....*.
0	-1024	-1024	0	1	-1.1	-35.6	33.4	22.12.	*.*....*.
0	526	526	0	0	17.2	-28.6	-23.7	22.11.	*.*....*.
0	1025	1024	0	-1	1.1	35.6	-33.4	22.11.	*.*....*.
-1	-527	-526	0	-1	-17.1	28.6	23.8	22.11.	*.*....*.

Event : AG Location : 9.02 mi 1.13 ohms sec
Duration: 4.75 Flt Current: 1154.4 Targets: G1

R1 =49.83	X1 =56.32	R0 =56.07	X0 =143.07	LL =60.00
CTR =60.00	PTR =600.00	MTA =49.00	LOCAT=Y	DATC =15
DCTH =120.00	790I1=40.00	790I2=60.00	790I3=80.00	79RS =240.00
51PP =120.00	51PTD=1.00	51PC =2	51PTC=N	
50P1 =1158.00	50P2 =516.00	50P3 =210.00		
Z1DP =0.00	Z2DP =160.00	Z3DP =30.00		
51NP =30.00	51NTD=2.00	51NC =2	51NTC=N	
50N1 =1008.00	50N2 =450.00	50N3 =30.00		
Z1DG =0.00	Z2DG =30.00	Z3DG =10.00	TDUR =9.00	
52BT =30	ZONE3=R	67NE =Y	67PE =Y	
32QE =N	32VE =Y	32IE =Y		
TIME1=5	TIME2=0	AUTO =2	RINGS=3	

Currents and voltages are in primary amps and kV. Rows are 1/4 cycle apart. Time runs down page. Obtain phasor RMS value and angle using any entry as Y-component, and the entry immediately underneath as the X-component. For example, from bottom rows, IAY = 1024, IAX = -526. Therefore, IA = 1151 amps RMS primary, at an angle of $\text{ATAN}(1024/-526) = 117$ degrees, with respect to the sampling clock.

<FID> Row 2 shows the Firmware Identification Data. This line varies according to version.

<Relays> Columns show states of internal relay elements ---- Designators

50P : phase overcurrent	: 50P1, 50P2, 50P3	----> 1,2,3
67P : directional phase overcurrent	: 67P1, 67P2, 67P3	----> 1,2,3
51P : phase time-overcurrent	: 51PT	----> T
50N : inst ground overcurrent	: 50N1, 50N2, 50N3	----> 1,2,3
67N : directional ground overcurrent	: 67N1, 67N2, 67N3	----> 1,2,3
51N : ground time-overcurrent	: 51NT	----> T

<Outputs> Columns show states of output contacts: ON = "*" , OFF = "."
TP=TRIP, CL=CLOSE, A1-A4=PROGRAMMABLE, AL=ALARM

<Inputs> Columns show states of input contacts:
DT=DIRECT TRIP, PT=PERMISSIVE TRIP, BT=BLOCK TRIP, DC=DIRECT
CLOSE, 52A=PCB A-CONTACT, ET=EXTERNAL TRIGGER (event report)

<Event> Event type is one of AG,BG,CG = single-phase, AB,BC,CA = 2-phase
ABG,BCG,CAG = 2-phase to ground, ABC = 3-phase followed by a
"T" if a TRIP triggered the report

Other indications are TRIP = triggered by TRIP output
and EXT = externally or otherwise triggered

<Location> Distance to fault in miles. Indeterminate distance is 999999.

<Ohms Sec> Distance to fault in secondary ohms. Indeterminate ohms is 9999.

<Duration> Fault duration determined from relay element(s) pickup time

<Flt Current> Max phase current (primary amps) taken near middle of fault

<Targets> The targets indicate the relay elements that caused the trip.
 These targets are the same as the targets displayed on the front panel of the SEL-267 via the TARGET 0 command. The targets field indicates any combination of the following:

- P1: Zone 1 phase fault
- G1: Zone 1 ground fault
- P2: Zone 2 phase fault
- G2: Zone 2 ground fault
- P3: Zone 3 phase fault
- G3: Zone 3 ground fault
- 51P: Phase time-overcurrent trip
- 51N: Residual time-overcurrent trip

R1,X1,R0,X0 Primary series impedance settings for transmission line
 LL Line length corresponding to specified line impedances
 CTR, PTR Current and potential transformer ratios (XTR:1)
 MTA Maximum torque angle for the directional elements
 LOCAT Enable or disable fault locator (Y/N)
 DATC Demand ammeter time constant
 DCTH Demand current threshold
 790I1,2,3,RS Three-shot recloser Open and Reset intervals
 51PP,TD,C,TC Phase time-overcurrent pickup, Time-Dial, Curve, Torque Control
 50P1,2,3 Phase inst-overcurrent pickup settings zones 1, 2 and 3
 Z1DP,2,3 Zones 1, 2 and 3 timer settings for 3- and 2-phase faults
 51NP,TD,C,TC GND time-overcurrent Pickup, Time-Dial, Curve, Torque Control
 50N1,2,3 Ground inst-overcurrent pickup settings zones 1, 2 and 3
 Z1DG,2,3 Zone timers for ground faults
 TDUR Minimum Trip Duration Timer
 52BT 52B delay setting (for switch-onto-fault coordination)
 ZONE3 Directional orientation of all zone 3 elements (Fwd/Rvs)
 67NE,PE Ground and phase fault torque control enables
 32QE,VE,IE Ground fault directionality from (V2,I2), or (V0/IP,I0)
 TIME1,2 Communications port timeout intervals (automatic log-off)
 AUTO Port assignment for automatic message transmissions
 RINGS Number of rings to wait before modem answers telephone
 <Logic Settings> See LOGIC command for a description of mask setting.