

SEL-701

Motor Protection Relay

Instruction Manual

20151002



SCHWEITZER ENGINEERING LABORATORIES, INC.



⚠ DANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

⚠ WARNING

Overtightening the mounting nuts may permanently damage the relay chassis.

⚠ WARNING

Be sure to carefully align the front panel with the relay chassis during reassembly. If the front panel is not well aligned with the chassis, you may bend connector pins, causing the relay to fail.

⚠ WARNING

This device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

⚠ WARNING

Before working on a CT circuit, first apply a short to the secondary winding of the CT.

⚠ CAUTION

Do not connect external voltages to the relay contact inputs. Because the contact inputs are internally wetted, permanent damage to the relay or external equipment may result from connecting external voltage to a relay contact input.

⚠ CAUTION

The relay contains devices sensitive to Electrostatic Discharge (ESD). When working on the relay with the front panel removed, work surfaces and personnel must be properly grounded or equipment damage may result.

⚠ DANGER

Débrancher tous les raccordements externes avant d'ouvrir cet appareil. Tout contact avec des tensions ou courants internes à l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.

⚠ AVERTISSEMENT

Une pression excessive sur les écrous de montage peut endommager de façon permanente le chassis du relais.

⚠ AVERTISSEMENT

Assurez-vous d'aligner soigneusement le panneau frontal avec le châssis du relais en cours de remontage. Si le panneau du relais n'était pas bien aligné avec le châssis, vous pourriez plier les broches du connecteur, entraînant une panne du relais.

⚠ AVERTISSEMENT

Cet appareil est expédié avec des mots de passe par défaut. A l'installation, les mots de passe par défaut devront être changés pour des mots de passe confidentiels. Dans le cas contraire, un accès non-autorisé à l'équipement peut être possible. SEL décline toute responsabilité pour tout dommage résultant de cet accès non-autorisé.

⚠ AVERTISSEMENT

Avant de travailler sur un circuit TC, placez d'abord un court-circuit sur l'enroulement secondaire du TC.

⚠ ATTENTION

Ne pas raccorder de tensions externes sur les bornes des entrées de contact. Parce que les contacts sont trempés au mercure, des dommages permanents peuvent résulter pour le relais ou l'équipement externe à la suite du raccordement d'une tension externe à une entrée de contact du relais.

⚠ ATTENTION

Le relais contient des pièces sensibles aux décharges électrostatiques. Quand on travaille sur le relais avec les panneaux avant ou du dessus enlevés, toutes les surfaces et le personnel doivent être mis à la terre convenablement pour éviter les dommages à l'équipement.

© 1999–2015 by Schweitzer Engineering Laboratories, Inc. All rights reserved.

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission. SEL products appearing in this document may be covered by US and Foreign patents.

Schweitzer Engineering Laboratories, Inc. reserves all rights and benefits afforded under federal and international copyright and patent laws in its products, including without limitation software, firmware, and documentation.

The information in this manual is provided for informational use only and is subject to change without notice. Schweitzer Engineering Laboratories, Inc. has approved only the English language manual.

This product is covered by the standard SEL 10-year warranty. For warranty details, visit www.selinc.com or contact your customer service representative.

PM701-01

Table of Contents

List of Tables	v
List of Figures	ix
Section 1: Introduction and Specifications	
Introduction	1.1
Typographic Conventions	1.2
SEL-701 Relay Models	1.3
SEL-701 Relay Applications	1.4
SEL-701 Relay Protection Features	1.4
SEL-701 Relay Monitoring and Reporting Features	1.5
Relay Part Number	1.5
SEL-701 Relay Serial Number and Compliance Labels	1.7
Specifications	1.8
Section 2: Installation	
Panel Cut and Drill Plans	2.1
Relay Mounting	2.2
Relay Rear-Panel Diagram	2.3
Example AC Wiring Diagrams	2.5
Relay Connections	2.7
SEL-2600 RTD Modules	2.15
Section 3: PC Software	
Overview	3.1
Setup	3.2
Terminal	3.3
Settings Database Management and Drivers	3.4
Settings	3.5
Event Analysis	3.8
Meter and Control	3.10
Help	3.11
Section 4: Settings Calculations	
Introduction	4.1
Application Data	4.2
General Data	4.3
Basic Motor Protection	4.6
RTD-Based Protection	4.23
Voltage-Based Protection (Relay Models 0701001X and 0701011X)	4.28
Output Configuration	4.32
Serial Port Settings	4.38
Sequential Events Recorder (SER) Settings	4.39
Section 5: Front-Panel Operations	
Front-Panel Layout	5.1
Normal Front-Panel Display	5.2
Front-Panel Automatic Messages	5.3
Front-Panel Menus and Operations	5.3
Front-Panel Main Menu	5.6

Section 6: ASCII Serial Port Operation

Introduction	6.1
You Will Need... ..	6.1
Connect Your PC to the Relay	6.2
Configure Your Terminal Emulation Software.....	6.3
Using Terminal Commands.....	6.3
Serial Port Access Levels	6.4
Command Summary	6.5
Command Explanations.....	6.6
Serial Port Automatic Messages.....	6.21

Section 7: Commissioning

Introduction	7.1
Relay Commissioning Procedure	7.1
Selected Functional Tests	7.5

Section 8: Metering and Monitoring

Introduction	8.1
Power Measurement Conventions	8.4
Load Profiling.....	8.5
Motor Operating Statistics.....	8.6
Motor Start Report.....	8.8
Motor Start Trending	8.9

Section 9: Event Analysis

Introduction	9.1
Front-Panel Target LEDs	9.1
Front-Panel Messages.....	9.2
History Data and Event Summaries	9.3
Event Reports	9.4
Sequential Events Recorder (SER) Report.....	9.8
Example Event Report.....	9.10
Example Sequential Events Recorder (SER) Report.....	9.12

Section 10: Maintenance and Troubleshooting

Routine Maintenance Checks	10.1
Self-Testing.....	10.2
Troubleshooting Procedure.....	10.4
Power Supply Fuse Replacement	10.5
Real-Time Clock Battery Replacement	10.6
Firmware Upgrade Installation.....	10.6
Factory Assistance.....	10.9

Appendix A: Firmware and Manual Versions

Firmware.....	A.1
Instruction Manual.....	A.3

Appendix B: SELogic Control Equations and Relay Logic

Introduction	B.1
Relay Functional Overview	B.2
Relay Word Bits.....	B.3
SELOGIC Control Equations	B.6
Factory Default Logic Settings.....	B.8
Front-Panel Display Message Configuration	B.9
Nondedicated SELOGIC Control Equation Variable Settings	B.10
Latch Control Switch Settings.....	B.10

Stop/Trip Logic.....	B.12
Breaker Auxiliary Contact SELOGIC Control Equation Setting.....	B.14
Start and Emergency Restart Logic	B.14
ACCESS2 SELOGIC Control Equation Setting	B.15
TARR SELOGIC Control Equation Setting	B.16
Speed Switch SELOGIC Control Equation Setting	B.16
Event Triggering SELOGIC Control Equation	B.16
Contact Output Control	B.16
Remote Control Switches	B.17
Selected Relay Logic Diagrams	B.18

Appendix C: Modbus RTU Communications Protocol

Introduction	C.1
Modbus RTU Communications Protocol	C.1
01h Read Coil Status Command.....	C.3
02h Read Input Status Command.....	C.3
03h Read Holding Registers Command	C.4
04h Read Input Registers Command.....	C.5
05h Force Single Coil Command	C.5
06h Preset Single Register Command	C.6
07h Read Exception Status Command	C.6
08h Loopback Diagnostic Command	C.7
10h Preset Multiple Registers Command	C.7
Controlling Output Contacts and Remote Bits Using Modbus	C.8
Reading the Relay Status Using Modbus	C.9
User-Defined Modbus Data Region	C.10
Reading Event Data Using Modbus	C.10
Modbus Register Map	C.11

Appendix D: SEL Communications Processors

Introduction	D.1
Fast Binary Message Lists.....	D.1
Fast Binary Message Definitions.....	D.2
A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages.....	D.6
Compressed ASCII Commands.....	D.12
CSTATUS Command	D.15
CHISTORY Command.....	D.15
CEVENT Command.....	D.16
CME E Command	D.17
CME M Command	D.18
CME T Command	D.19

Appendix E: Motor Thermal Element

Introduction	E.1
Purpose of Motor Thermal Protection	E.2
The Basic Thermal Element	E.3
Motor Starting Protection	E.6
Motor Running Protection.....	E.7
Percent Thermal Element Capacity Values	E.9
Motor Starting Thermal Capacity.....	E.9
Thermal Element Trip-Time Equations.....	E.10

Appendix F: SEL-701 Relay Settings Sheets

Relay Settings	F.1
Voltage-Based Protection	F.10
Output Configuration.....	F.13
Serial Port Settings	F.16
Sequential Events Recorder Settings (SET R)	F.17

Glossary

Index

SEL-701 Relay Command Summary

List of Tables

Table 1.1	Typographic Conventions.....	1.2
Table 1.2	SEL-701 Relay Models	1.3
Table 1.3	SEL-701 Relay Part Number Creation Table	1.6
Table 2.1	Typical Maximum RTD Lead Length	2.13
Table 3.1	SEL Software Solutions	3.1
Table 3.2	ACSELERATOR QuickSet Software	3.1
Table 3.3	File/Tools Menus	3.6
Table 3.4	Help	3.11
Table 4.1	Identifier Settings	4.3
Table 4.2	CT Configuration Settings	4.3
Table 4.3	Phase Rotation, Nominal Frequency Settings	4.3
Table 4.4	VT Configuration Settings	4.4
Table 4.5	Alarm Contact Setting.....	4.5
Table 4.6	Thermal Element Configuration Settings, Setting Method = RATING	4.7
Table 4.7	Thermal Element Configuration Settings, Setting Method = GENERIC	4.8
Table 4.8	Generic Thermal Limit Curve Tripping Times From Reset vs. Multiples of Full Load Amps, Curves 1–10 (Thermal Limit Times in Seconds)	4.10
Table 4.9	Generic Thermal Limit Curve Tripping Times From Reset vs. Multiples of Full Load Amps, Curves 15, 20, 25, 30, 35, 40, 45 (Thermal Limit Times in Seconds).....	4.11
Table 4.10	Thermal Element Configuration Settings, Setting Method = USER	4.11
Table 4.11	3000 HP Motor Thermal Limit Times	4.14
Table 4.12	Thermal Capacity Alarm Setting.....	4.15
Table 4.13	Thermal Capacity to Start Settings.....	4.15
Table 4.14	Motor Cooling Time Settings.....	4.16
Table 4.15	Overcurrent Element Settings	4.17
Table 4.16	Jogging Block Element Settings	4.19
Table 4.17	Load-Jam Function Settings.....	4.19
Table 4.18	Load-Loss Element Settings, No Voltage Option	4.20
Table 4.19	Load-Loss Element Settings, With Voltage Option	4.20
Table 4.20	Current Unbalance Element Settings	4.21
Table 4.21	Phase Reversal Tripping Setting.....	4.22
Table 4.22	Speed Switch Tripping Time Delay Setting	4.22
Table 4.23	Breaker Failure Element Settings.....	4.22
Table 4.24	RTD Configuration Settings	4.23
Table 4.25	RTD Location Settings	4.23
Table 4.26	RTD Type Settings	4.24
Table 4.27	RTD Alarm and Trip Temperature Settings	4.25
Table 4.28	RTD Resistance versus Temperature.....	4.27
Table 4.29	Under- and Overvoltage Settings, Phase-to-Phase Potentials	4.28
Table 4.30	Under- and Overvoltage Settings, Phase-to-Neutral Potentials	4.28
Table 4.31	Reactive Power Element Settings.....	4.30
Table 4.32	Underpower Element Settings.....	4.31
Table 4.33	Power Factor Element Settings	4.31
Table 4.34	Frequency Element Settings.....	4.32
Table 4.35	Analog Output Settings	4.32
Table 4.36	Front-Panel Configuration Settings.....	4.33
Table 4.37	Display Message Settings.....	4.33
Table 4.38	Output Contact Fail-Safe, Trip Duration, and Starting Lockout Settings	4.34
Table 4.39	Antibackspin Setting	4.35
Table 4.40	Factory Logic Settings	4.35
Table 4.41	SET P Serial Port Settings, Protocol = ASCII	4.38
Table 4.42	SET P Rear-Panel Serial Port Settings, Protocol = MOD	4.39
Table 4.43	SET R SER Trigger Settings	4.40
Table 4.44	Default SER Trigger Setting Relay Word Bits Definitions.....	4.40

Table 4.45	SET R SER Enable Alias Settings	4.41
Table 4.46	SET R SER Alias Settings	4.42
Table 5.1	Front-Panel Automatic Message	5.3
Table 5.2	Front-Panel Pushbutton Functions	5.4
Table 6.1	Pin Functions and Definitions for the SEL-701 Relay EIA-232 Serial Ports	6.3
Table 6.2	SEL-701 Relay Serial Communication Default Settings	6.3
Table 6.3	Serial Port Control Characters.....	6.4
Table 6.4	SEL-701 Serial Port Command Summary	6.5
Table 6.5	SEL-701 Relay Control Subcommands	6.8
Table 6.6	Event Commands	6.9
Table 6.7	EVE Command Examples.....	6.9
Table 6.8	LDP Command Options	6.10
Table 6.9	MSR General Command Format.....	6.13
Table 6.10	PULSE Command Format	6.14
Table 6.11	SER Command Options	6.15
Table 6.12	Serial Port SET Commands.....	6.16
Table 6.13	SET Command Editing Keystrokes.....	6.16
Table 6.14	SET Command Format.....	6.16
Table 6.15	SHOW Command Options.....	6.17
Table 6.16	STATUS Command Options	6.18
Table 6.17	TARGET Command Options	6.19
Table 6.18	Front-Panel LEDs and the TAR 0 Command.....	6.19
Table 6.19	SEL-701 Relay Word and Corresponding TAR Command	6.20
Table 6.20	Serial Port Automatic Messages	6.21
Table 7.1	Serial Port Commands that Clear Relay Data Buffers	7.4
Table 7.2	Test Source Connections for Different Relay Configurations.....	7.5
Table 7.3	Phase Current Measuring Accuracy	7.6
Table 7.4	Neutral Current Measuring Accuracy	7.7
Table 7.5	Current Unbalance Measuring Accuracy	7.7
Table 7.6	Thermal Element Expected Trip Times	7.8
Table 7.7	Analog Output Test	7.9
Table 7.8	100-Ohm Platinum RTD Type (RTDs 1–6)	7.9
Table 7.9	100-Ohm Platinum RTD Type (RTDs 7–12)	7.10
Table 7.10	120-Ohm Nickel RTD Type (RTDs 1–6)	7.10
Table 7.11	120-Ohm Nickel RTD Type (RTDs 7–12)	7.10
Table 7.12	100-Ohm Nickel RTD Type (RTDs 1–6)	7.11
Table 7.13	100-Ohm Nickel RTD Type (RTDs 7–12)	7.11
Table 7.14	10-Ohm Copper RTD Type (RTDs 1–6)	7.11
Table 7.15	10-Ohm Copper RTD Type (RTDs 7–12)	7.12
Table 7.16	Power Measuring Accuracy Test Values, Wye Voltages	7.12
Table 7.17	Power Measuring Accuracy Test Values, Delta Voltages.....	7.13
Table 8.1	Measured Values	8.2
Table 8.2	Demand Meter Values	8.2
Table 8.3	Max/Min Recorded Values.....	8.3
Table 8.4	Thermal Meter Values	8.3
Table 8.5	RTD Input Status Messages	8.4
Table 8.6	Energy Meter Values	8.4
Table 8.7	Load Profile Data	8.5
Table 9.1	SEL-701 Relay Front-Panel Target LED Definitions.....	9.1
Table 9.2	Event Triggers	9.4
Table 9.3	Event Commands	9.5
Table 9.4	EVE Command Options.....	9.5
Table 9.5	Compressed ASCII Event Commands	9.5
Table 9.6	CEVENT Command	9.6
Table 9.7	Event Report Current and Voltage Columns	9.6
Table 9.8	Output, Input, and Element Event Report Columns.....	9.7
Table 9.9	Retrieving SER Reports	9.9
Table 9.10	Example Sequential Events Recorder (SER) Event Report Explanations	9.12

Table 10.1	Data Capture.....	10.2
Table 10.2	Relay Self-Tests.....	10.3
Table 10.3	Relay Enabled Front-Panel LED Dark.....	10.4
Table 10.4	Cannot See Characters on Relay Front-Panel Display Screen.....	10.4
Table 10.5	Relay Does Not Accurately Measure Voltages or Currents	10.4
Table 10.6	Relay Does Not Respond to Commands From Device Connected to Serial Port.....	10.4
Table 10.7	Relay Does Not Respond to Faults	10.5
Table A.1	Firmware Revision History	A.1
Table A.2	Instruction Manual Revision History	A.3
Table B.1	SEL-701 Relay Word Bits.....	B.3
Table B.2	Relay Word Bit Definitions for SEL-701	B.3
Table B.3	SELOGIC Control Equation Operators	B.6
Table B.4	Remote Control Switch	B.17
Table C.1	Modbus Query Fields	C.1
Table C.2	SEL-701 Relay Modbus Function Codes.....	C.2
Table C.3	SEL-701 Relay Modbus Exception Codes.....	C.2
Table C.4	01h Read Coil Status Command	C.3
Table C.5	02h Read Input Status Command.....	C.4
Table C.6	03h Read Holding Registers Command.....	C.4
Table C.7	04h Read Input Registers Command.....	C.5
Table C.8	05h Force Single Coil Command.....	C.5
Table C.9	SEL-701 Relay Command Coils	C.5
Table C.10	06h Preset Single Register Command.....	C.6
Table C.11	07h Read Exception Status Command.....	C.6
Table C.12	08h Loopback Diagnostic Command.....	C.7
Table C.13	10h Preset Multiple Registers Command.....	C.7
Table C.14	SEL-701 Relay Modbus Command Region.....	C.8
Table C.15	Modbus Command Codes	C.8
Table C.16	Relay Self-Test Result in Bit Definition.....	C.9
Table C.17	Assign Event Report Channel Using Address 03A2h.....	C.10
Table C.18	Modbus Register Map	C.11
Table D.1	Binary Message List.....	D.1
Table D.2	ASCII Configuration Message List.....	D.2
Table D.3	A5C0 Relay Definition Block	D.2
Table D.4	A5C1 Fast Meter Configuration Block	D.3
Table D.5	A5D1 Fast Meter Data Block.....	D.6
Table D.6	A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages.....	D.6
Table D.7	A5D2/A5D3 Demand/Peak Demand Fast Meter Message	D.8
Table D.8	A5CE Fast Operate Configuration Block.....	D.9
Table D.9	A5E0 Command	D.10
Table D.10	A5E3 Command.....	D.10
Table D.11	Compressed ASCII Commands	D.12

This page intentionally left blank

List of Figures

Figure 1.1	SEL-701 Relay Functional Description	1.3
Figure 1.2	SEL-701 Relay Applications.....	1.4
Figure 1.3	SEL-701 Relay Serial Number Label.....	1.7
Figure 1.4	SEL-701 Relay Compliance Label.....	1.7
Figure 2.1	SEL-701 Relay Dimension Diagram.....	2.1
Figure 2.2	SEL-701 Relay Panel Mounting Detail.....	2.2
Figure 2.3	Relay Rear Panel	2.3
Figure 2.4	SEL-701 Relay Left- and Right-Side Panel Drawings.....	2.4
Figure 2.5	Example AC Wiring Diagram, Four-Wire Wye Voltages and Ground CT	2.5
Figure 2.6	Example AC Wiring Diagram, Open-Delta Voltages and Residual IN Connection	2.6
Figure 2.7	Example AC Voltage Wiring Diagram, Single Phase-to-Phase Voltage	2.6
Figure 2.8	Example AC Voltage Wiring Diagram, Single Phase-to-Neutral Voltage	2.7
Figure 2.9	Ground CT Placement.....	2.8
Figure 2.10	Contact Output Factory Default Wiring Diagram	2.9
Figure 2.11	Trip Contact Fail-Safe, NonFail-Safe Wiring Options.....	2.10
Figure 2.12	Optional Motor Start Wiring Using Factory Default Settings for Output Contact OUT3 ...	2.11
Figure 2.13	Contact Input Factory Default Wiring Diagram.....	2.11
Figure 2.14	Analog Output Wiring.....	2.12
Figure 2.15	RTD Input Wiring	2.13
Figure 2.16	Rear-Panel EIA-485 Serial Port Connections	2.15
Figure 3.1	Serial Port Communication Dialog Box	3.2
Figure 3.2	Serial Port Communication Parameters Dialog Box	3.2
Figure 3.3	Tools Menu.....	3.3
Figure 3.4	Device Response to the ID Command	3.3
Figure 3.5	Selection of Drivers.....	3.6
Figure 3.6	Update Part Number.....	3.6
Figure 3.7	New Setting Screen	3.7
Figure 3.8	Composite Screens for Retrieving Event	3.8
Figure 3.9	Saving the Retrieved Event	3.9
Figure 3.10	Device Overview Screen	3.10
Figure 4.1	Phase Rotation Settings.....	4.4
Figure 4.2	Generic Thermal Limit Curves, Cold Motor (SF=1.01)	4.9
Figure 4.3	3000 HP Example Motor Cold Thermal Limit Curve.....	4.13
Figure 4.4	Ground Fault Currents Using a Window CT.....	4.18
Figure 4.5	Loss-of-Potential (LOP) Logic.....	4.30
Figure 4.6	Factory Tripping Logic.....	4.36
Figure 4.7	Factory Contact Output Logic.....	4.37
Figure 4.8	Factory Contact Input Logic	4.37
Figure 4.9	Factory Event Triggering Logic	4.38
Figure 5.1	SEL-701 Relay Front Panel.....	5.1
Figure 5.2	Default Meter Display Screen.....	5.2
Figure 5.3	Default Display Message Screen.....	5.2
Figure 5.4	Front-Panel Pushbuttons.....	5.3
Figure 5.5	Access Level Security Padlock Symbol	5.4
Figure 5.6	Password Entry Screen.....	5.5
Figure 5.7	Activate Front-Panel Display	5.6
Figure 5.8	Front-Panel Main Menu	5.7
Figure 5.9	Main Menu: Start Motor Function	5.7
Figure 5.10	Main Menu: Emergency Restart Function	5.7
Figure 5.11	Main Menu: Stop Motor Function	5.8
Figure 5.12	Main Menu: Reset Trip and Targets Function.....	5.8
Figure 5.13	Main Menu: Set Relay Function	5.8
Figure 5.14	Set Relay/Relay Elements Function.....	5.9
Figure 5.15	Set Relay/SER Setting Categories.....	5.9

Figure 5.16	Set Relay/Front Serial Port Settings.....	5.10
Figure 5.17	Set Relay/Rear Serial Port Settings.....	5.10
Figure 5.18	Set Relay/Date Function.....	5.10
Figure 5.19	Set Relay/Time Function.....	5.11
Figure 5.20	Set Relay/Password Function.....	5.11
Figure 5.21	Main Menu: Meter Values Function.....	5.11
Figure 5.22	Meter Values Display Functions	5.12
Figure 5.23	Meter Values Reset Functions.....	5.12
Figure 5.24	Main Menu: History Data Function	5.12
Figure 5.25	History Data/Display History Function.....	5.12
Figure 5.26	History Data/Clear History Function	5.13
Figure 5.27	Main Menu: Motor Statistics Function	5.13
Figure 5.28	Motor Statistics/Motor Use Data Function	5.13
Figure 5.29	Motor Statistics/Average and Peak Data Function.....	5.13
Figure 5.30	Motor Statistics/Trip and Alarm Data Function.....	5.14
Figure 5.31	Motor Statistics/Reset Statistics Function.....	5.14
Figure 5.32	Main Menu: Status of Relay Function	5.14
Figure 5.33	Main Menu: View Relay Word Function	5.14
Figure 5.34	Main Menu: Pulse Out Contact Function.....	5.15
Figure 5.35	Pulse Output Contact Menu Function	5.15
Figure 5.36	Main Menu: Reset Thermal Model Function.....	5.15
Figure 5.37	Main Menu: Reset Learned Param Function.....	5.15
Figure 5.38	Reset Learned Param/Reset Cooling Time Function	5.16
Figure 5.39	Reset Learned Param/Reset Start Therm Cap Function.....	5.16
Figure 6.1	Cable C234A Pinout.....	6.2
Figure 6.2	DB-9 Connector Pinout for EIA-232 Serial Ports.....	6.2
Figure 6.3	HELP Command Response.....	6.7
Figure 6.4	2AC Command Example.....	6.7
Figure 6.5	ANA Command Example	6.8
Figure 6.6	DATE Command Example	6.9
Figure 6.7	HISTORY Command Example.....	6.9
Figure 6.8	METER Command Example	6.11
Figure 6.9	METER D Command Example.....	6.11
Figure 6.10	METER E Command Example.....	6.11
Figure 6.11	METER M Command Example.....	6.12
Figure 6.12	METER T Command Example.....	6.12
Figure 6.13	PULSE Command Example.....	6.15
Figure 6.14	RLP Command Example.....	6.15
Figure 6.15	SHOW Command Example	6.17
Figure 6.16	STATUS Command Example.....	6.18
Figure 6.17	TARGET Command Example.....	6.19
Figure 6.18	TIME Command Example	6.20
Figure 6.19	TRIGGER Command Example.....	6.20
Figure 7.1	Three-Phase AC Connection Test Signals.....	7.3
Figure 7.2	Open-Delta AC Potential Connection Test Signals.....	7.3
Figure 7.3	Three Voltage Source and Three Current Source Test Connections	7.5
Figure 7.4	Two Voltage Source and Three Current Source Test Connections.....	7.6
Figure 8.1	Power Measurement Conventions	8.4
Figure 8.2	LDP Command Response	8.5
Figure 8.3	MOTOR Command Example.....	8.7
Figure 8.4	Motor Start Report Example	8.9
Figure 8.5	Motor Start Trending Report Example.....	8.10
Figure 9.1	Example Event Report	9.11
Figure 9.2	Example Sequential Events Recorder (SER) Event Report	9.12
Figure B.1	Relay Processing Order.....	B.2
Figure B.2	Result of Falling-Edge Operator on a Deasserting Underfrequency Element	B.7
Figure B.3	Factory Default Logic Settings.....	B.9
Figure B.4	SELOGIC Control Equation Variable Timer Logic.....	B.10

Figure B.5	Traditional Latching Relay.....	B.10
Figure B.6	Latch Control Switches Drive Latch Bits LT1 through LT4	B.11
Figure B.7	Stop/Trip Logic	B.13
Figure B.8	Start Logic	B.14
Figure B.9	Remote Control Switches Drive Remote Bits RB1 through RB4.....	B.17
Figure B.10	Undervoltage Element Logic.....	B.18
Figure B.11	Underpower Element Logic	B.18
Figure B.12	Current Unbalance Element Logic.....	B.19
Figure B.13	Phase Reversal Element Logic	B.20
Figure B.14	Overcurrent Element Logic	B.21
Figure B.15	Power Factor Elements Logic	B.22
Figure B.16	Overvoltage Element Logic.....	B.22
Figure B.17	Over/Underfrequency Element Logic	B.23
Figure B.18	Load-Jam Elements Logic.....	B.23
Figure B.19	Load-Loss Logic; No Voltage Option	B.24
Figure B.20	Load-Loss Logic; Voltage Option Included	B.24
Figure B.21	Reactive Power Elements Logic.....	B.25
Figure B.22	Speed Switch Tripping Logic.....	B.25
Figure B.23	Breaker Failure Logic.....	B.26
Figure B.24	Motor State Logic.....	B.26
Figure E.1	Motor Thermal Limit Characteristic Plotted With Motor Starting Current	E.3
Figure E.2	Electrical Analog of a Thermal System	E.3
Figure E.3	Typical Induction Motor Current, Torque, and Rotor Resistance versus Slip.....	E.4
Figure E.4	Motor Starting Thermal Element	E.6
Figure E.5	Motor Running Thermal Element With Resistance and Trip Level Undefined	E.7
Figure E.6	Calculating the Normal Operating Energy Using Locked Rotor Trip Times.....	E.7
Figure E.7	Motor Running Thermal Element	E.8

This page intentionally left blank

Section 1

Introduction and Specifications

Introduction

The SEL-701 Motor Protection Relay is designed to protect three-phase, medium voltage motors. The basic relay provides locked rotor, overload, unbalance, and short-circuit protection functions. You can select options that add voltage-based and RTD-based protection and monitoring capabilities. All relay models offer innovative monitoring functions, such as:

- Motor Start Reports and Motor Start Trend Data
- Load Profiling
- Motor Operating Statistics
- Event Reports and Summaries
and a Sequential Events Record (SER)
- Complete Suite of Accurate Metering Functions

This manual contains the information you need to select, install, set, test, operate, and maintain any SEL-701 Relay. You probably will not need to review the whole book to perform the specific tasks that are your responsibility. The following is an overview of the sections in this instruction manual:

Section 1: Introduction and Specifications. Describes how to locate information in this instruction manual; describes the basic features and functions of the SEL-701 Relay; shows how to create an SEL-701 Relay part number; lists the SEL-701 Relay specifications.

Section 2: Installation. Describes how to mount and wire the SEL-701 Relay; illustrates wiring connections for various applications.

Section 3: PC Software. Describes the features, installation methods, and types of help available with ACSELERATOR QuickSet® SEL-5030 Software.

Section 4: Settings Calculations. Describes how to calculate and record settings for basic motor protection, RTD-based protection functions, and voltage-based functions.

Section 5: Front-Panel Operations. Explains the features and use of the SEL-701 Relay front panel, including front-panel command menu, default displays, and automatic messages.

Section 6: ASCII Serial Port Operation. Describes how to connect the SEL-701 Relay to a PC for communication; shows serial port connector pinouts; lists and defines serial port commands.

Section 7: Commissioning. Describes the relay commissioning procedure; provides protection element test procedures.

Section 8: Metering and Monitoring. Describes the operation of metering functions, load profiling function, motor operating statistics function, motor start reports, and motor start trending function.

Section 9: Event Analysis. Describes front-panel target LED operation, trip-type front-panel messages, event summary data, standard 15-cycle event reports, and Sequential Events Recorder (SER) report.

Section 10: Maintenance and Troubleshooting. Describes relay self-test alarms, relay troubleshooting, and power supply fuse replacement; provides firmware upgrade instructions.

Appendix A: Firmware and Manual Versions. Lists the current relay firmware version and details differences between the current and previous versions.

Appendix B: SELOGIC Control Equations and Relay Logic. Discusses the relay word, SELOGIC control equations, motor stop and start logic, local and remote control switches, and front-panel display configuration; provides tables detailing all Relay Word bits and their definitions.

Appendix C: Modbus RTU Communications Protocol. Describes the Modbus protocol support provided by the SEL-701 Relay.

Appendix D: SEL Communications Processors. Describes commands implemented to support the SEL communications processors.

Appendix E: Motor Thermal Element. Contains a fundamental description of the SEL-701 Relay's thermal element. Describes interpretation of % Thermal Capacity and Thermal Capacity Used to Start quantities.

Appendix F: SEL-701 Relay Settings Sheets Example. Contains completed relay settings sheets containing factory default settings and blank settings sheets you can photocopy and complete to record settings for the SEL-701 Relay.

Briefly describes the serial port commands that are described in detail in *Section 6: ASCII Serial Port Operation*.

Typographic Conventions

Table 1.1 Typographic Conventions

Example	Description
OTTER	Commands you type appear in bold/uppercase.
<Enter>	Computer keys you press appear in bold/brackets.
{ENTER}	Relay front-panel buttons you press appear in bold/curly brackets.
Set Relay\Front Port	Front-panel menu functions you select in sequence are shown with a backslash [\] between the main menu selection and subsequent selections.
SEL-701 Relay	Relay serial port command responses.
<i>Section 1: Introduction and Specifications</i>	Manual section and heading names are shown in italics.
SEL-701 MOTOR RELAY	Relay front-panel display information and examples.

SEL-701 Relay Models

This instruction manual covers the SEL-701 Relay models listed in *Table 1.2*.

Table 1.2 SEL-701 Relay Models

SEL-701 Model Number	Internal RTD Inputs	Voltage Inputs	Current Inputs
0701000XXX	No	No	IA, IB, IC, IN
0701010XXX	11	No	IA, IB, IC, IN
0701001XXX	No	Wye or Delta	IA, IB, IC, IN
0701011XXX	11	Wye or Delta	IA, IB, IC, IN

Refer to *Relay Part Number* on *page 1.5* for more information on creating an SEL-701 Relay part number. When differences between the SEL-701 Relay models in *Table 1.2* are explained, model numbers are referenced for clarity.




Figure 1.1 SEL-701 Relay Functional Description

SEL-701 Relay Applications




Figure 1.2 SEL-701 Relay Applications

SEL-701 Relay Protection Features

The SEL-701 Relay offers a full range of elements for motor protection, including:

- Flexible motor thermal element (49) that provides integrated protection for locked rotor, running overload, unbalanced current/negative-sequence current heating, and repeated or frequent starts
- Phase, neutral, residual, and negative-sequence overcurrent (50) elements for tripping due to motor or cable short circuits
- Load-loss and load-jam protection
- Antijogging protection (66) function using minimum time between starts and number of starts per hour limit functions
- Unbalance current (46) element and phase reversal (47) element protection

- Optional RTD inputs through an 11-input internal RTD option or through purchase of an SEL-2600 series RTD module. The SEL-2600 series RTD module connects to the relay through a fiber-optic cable and provides 12 RTD inputs plus an additional contact input. Select the RTD type for each input from a list of four popular types
- Optional voltage inputs that support four-wire wye, open-delta, or single-phase voltage inputs and provide voltage-based protection and metering functions. Added functions include over- and undervoltage elements, loss-of-potential (LOP) element, over- and underfrequency elements, underpower elements, reactive power elements, power factor elements, plus power and energy metering
- Support to control contactors or medium-voltage motor circuit breakers
- Fail-safe and nonfail-safe settings for relay output contacts

SEL-701 Relay Monitoring and Reporting Features

In addition to the protection functions outlined earlier, the SEL-701 Relay offers advanced measuring and monitoring capabilities not found in other motor relays, including:

- Extensive metering capabilities that provide real-time operating data
- Configurable front-panel display that replaces separate panel meters
- A load profiling function that records currents, voltages, and RTD temperatures every 15 minutes for over 30 days
- Event and SER reports that offer detailed information about electrical faults
- Motor start reporting that shows current, voltage, and thermal element values through 60 seconds of motor start. Use this information to validate transformer and cable sizing and confirm motor starting simulations
- Motor start trending that shows average accelerating times, maximum currents, and minimum voltages for each of the past eighteen 30-day periods
- SELOGIC control equations that allow you to customize the operation of contact inputs and outputs for your specific applications, if necessary

Relay Part Number

To obtain a quotation or place an order for an SEL-701 Relay, it is helpful to have a relay part number. The following information helps you create a part number for the SEL-701 Relay and provides some additional information that you may wish to include when you place your relay order.

Create a Relay Part Number

The SEL-701 Relay part number has the following form:

0 7 0 1 0 **a b X c X**

The answers to the questions listed in *Table 1.3* will determine the value of options a, b, and c.

Table 1.3 SEL-701 Relay Part Number Creation Table

	Question	Then
1	Does your application require 11 internal RTD inputs? a) Yes b) No	a = 1 a = 0
2	Does your application require ac voltage inputs? a) Yes b) No	b = 1 b = 0
3	Does your application require conformally coated circuit boards? a) Yes b) No	c = 2 c = X

EXAMPLE 1.1 SEL-701 Relay Part Number Creation

The part number 0701011X2X describes an SEL-701 Relay equipped with internal RTD inputs, with ac voltage inputs, and conformally-coated circuit boards.

Formula	0701	0	a	b	X	c	X
Part No.	0701	0	1	1	X	2	X

All SEL-701 Relays are equipped with 1 A and 5 A nominal CT inputs, a broad operating range power supply (20–250 \pm 20% Vdc <15 VA or 95–240 \pm 10% Vac 50/60 Hz), a single analog current output with settable range, six (6) self-wetted contact inputs, and four (4) programmable Form C contact outputs. Refer to the *Specifications* on *page 1.8* for more product operating range information.

Communication Cables

Remember to order required serial communication cables with the relay.

- Use SEL Cable C234A or a null-modem cable to connect the relay front-panel serial port to a PC 9-pin serial port for setting upload and download and for other activities during relay installation and operation. This cable is **not** included with the relay. You can purchase this cable separately from SEL or build your own using the cable pinout shown in *Connect Your PC to the Relay* in *Section 6: ASCII Serial Port Operation*.
- Use fiber-optic cable C805Z010VVX0003 (3 meters) to connect the relay rear-panel fiber-optic receiver port to an SEL-2600 series RTD module. You can purchase this and other lengths of cable directly from SEL.
- Use the free SEL-5801 Cable SELECTOR software (available for free download at the SEL web site, www.selinc.com) to help determine the other communication cables you need for a particular application.

Place a Request for Quotation or Order

You may order an SEL-701 Relay from your local SEL Sales Representative or International Distributor Office, one of SEL's Regional Technical Service Centers, or directly from the factory. Contact the SEL factory by telephone at (509) 332-1890 or by fax at (509) 332-7990.

SEL-701 Relay Serial Number and Compliance Labels

Figure 1.3 and Figure 1.4 show the serial number label and compliance label for the SEL-701 Relay. The serial number label and compliance label are affixed to the top of the relay chassis.




Figure 1.3 SEL-701 Relay Serial Number Label




Figure 1.4 SEL-701 Relay Compliance Label

Specifications

Compliance

Designed and manufactured under an ISO 9001 certified quality management system

UL Recognized to U.S. and Canadian safety standards (NKC2, NKCR8)

CE Mark

Standard Relay Features and Functions

Phase Current Inputs

Nominal Current, I_{NOM} :	1 A or 5 A
Range:	$0.05-20.00 \cdot I_{NOM}$
Burden:	0.14 VA @ 5 A, 5 A tap 0.06 VA @ 1 A, 1 A tap
Continuous:	$3 \cdot I_{NOM}$
200 s Thermal:	$10 \cdot I_{NOM}$
10 s Thermal:	$20 \cdot I_{NOM}$
1 Second Thermal:	$50 \cdot I_{NOM}$
Measuring Error:	$\pm 1\%, \pm 0.01 \cdot I_{NOM}$

Neutral/Ground Current Input

Nominal Current, I_{NOM} :	1 A or 5 A
Range:	$0.005-2.000 \cdot I_{NOM}$
Burden:	0.28 VA @ 5 A, 5 A tap 0.19 VA @ 1 A, 1 A tap
Continuous:	$3.0 \cdot I_{NOM}$
1 Second Thermal:	$50.0 \cdot I_{NOM}$
Measuring Error:	$\pm 1\%, \pm 0.01 \cdot I_{NOM}$

Motor Thermal Model

Locked Rotor Time:	1.0–240.0 s
Locked Rotor Current:	$0.5-16.0 \cdot I_{NOM}$
Service Factor:	1.01–1.5
Setting Modes:	45 standard curve shapes Nameplate ratings Custom curve shape
Pickup Error:	$< \pm 1\%, \pm 0.01 \cdot I_{NOM}$
Timing Error:	$\pm 2.5\%, \pm 25$ ms for currents > 1.1 times multiples of pickup

Independent Stop/Run Cooling Rates

Thermal estimate retained through relay power cycle.

Overcurrent Elements (Phase, Residual, Negative-Sequence)

Setting Range:	$0.05-20.00 \cdot I_{NOM}$
Time Delays:	0.00–400.00 s
Transient Overreach:	$< 5\%$ of pickup

Neutral/Ground Overcurrent Element

Setting Range:	$0.005-2.000 \cdot I_{NOM}$
Time Delays:	0.00–400.00 s
Transient Overreach:	$< 5\%$ of pickup

Current Unbalance Element

Alarm and Trip Elements	
Setting Range:	2%–80%
Time Delays:	0.00–400.00 s
Error:	$< \pm 1\%, \pm 0.01 \cdot I_{NOM}$

Definitions

For $I_{av} > FLA$

$$UB\% = 100\% \cdot |I_m - I_{av}| / I_{av}$$

For $I_{av} < FLA$

$$UB\% = 100\% \cdot |I_m - I_{av}| / FLA$$

where:

I_{av} = Avg phase current

I_m = Phase most different from I_{av}

FLA = Motor rated full load amps

Load-Loss/Load-Jam Function

Load-Loss Alarm and Trip	
Setting Range:	$0.10-1.00 \cdot FLA$
Load-Jam Trip	
Setting Range:	$0.5-6.0 \cdot FLA$
Time Delays:	0.40–400.00 s

Starts Per Hour, Time Between Starts

Maximum Starts/Hour:	1–15 starts
Minimum Time Between Starts:	1–150 minutes
Start data retained through relay power cycle.	

Phase Reversal Tripping

Phase reversal tripping based on current or optional voltage inputs.

Meter Accuracy

Current Metering:	$< \pm 1\%, \pm 0.01 \cdot I_{NOM}$
Demand Current Metering:	$< \pm 1\%$
Opt. Voltage Metering:	$< \pm 1\%, \pm 0.2$ V
Opt. Power Metering:	$\pm 2\%$
Opt. Power Factor Metering:	$< \pm 1.5\%$
Opt. Frequency Metering:	± 0.01 Hz
Opt. kW, kVA, kVAR Demand:	$\pm 2\%$

Analog Output

Single Analog Current Output

Settable Range:	0–1 mA, 0–20 mA, 4–20 mA
-----------------	--------------------------------

Max. Load: 8 k or 400 ohms

Error: $\pm 1.0\%$, Full Scale

Select from:

%FLA, % Thermal Cap, Hottest RTD, Avg phase current, Max. phase current

Contact Inputs

6 Self-Wetted Contact Inputs, Programmable Function

Contact Outputs

1 Trip Contact, 3 Programmable Contacts, 1 Relay Self-Test Alarm

Form C Contacts

Make/Carry/Interrupt Ratings

Make:	30 A	
Carry:	6 A	
Interrupt:	250 Vac	8 A Resistive
	24 Vdc	0.75 A, L/R = 40 ms
	48 Vdc	0.50 A, L/R = 40 ms
	125 Vdc	0.30 A, L/R = 40 ms
	250 Vdc	0.20 A, L/R = 40 ms

Serial PortsFront-Panel
EIA-232 Port: 300–19200 baud

ASCII text communication

Rear Panel

ASCII
EIA-232 port: 300–19200 baudOr Modbus®
EIA-485 port: 300–19200 baud

EIA-485 port isolation: 500 V

Optional Features and Functions**Optional Phase Voltage Inputs**

Nominal Voltage: 0–300 Vac

Four-Wire Wye or Open-Delta Voltages

Burden: <2 VA at 300 V

Measuring Error: $\pm 1\%$, ± 0.2 V**Over/Undervoltage Elements**

Setting Range: 1–300 Vac

Two Phase Overvoltage Elements

Two Phase Undervoltage Elements

One Residual Overvoltage Element

Power Factor Element

Alarm and Trip Levels

Setting Range: 0.05–0.99 pf

Time Delays: 0.00–400.00 s

Measuring Error: $< \pm 1.5\%$ **Reactive Power Element**

Alarm and Trip Levels

Setting Range: 30–2000 VAR, 5 A tap
6–400 VAR, 1 A tap

Time Delays: 0.00–400.00 s

Measuring Error: $< \pm 2\%$ **Underpower Element**

Alarm and Trip Levels

Setting Range: 30–2000 W, 5 A tap
6–400 W, 1 A tap

Time Delays: 0.40–400.00 s

Measuring Error: $< \pm 2\%$ **Over/Underfrequency Elements**

Three Settable Levels

Setting Range: 20.00–70.00 Hz

Time Delays: 0.00–400.00 s

Error: ± 0.01 Hz**Optional Internal RTD Inputs**

11 Internal RTD Inputs

Monitor Winding, Bearing, Ambient, or Other Temperatures

PT100, Ni100, Ni120, and Cu10 RTD-Types Supported, Field Selectable

Measuring Range: -50° to $+250^{\circ}\text{C}$ **Trip and Alarm Temperatures**Setting Range: 0° – 250°C Error: $< \pm 2^{\circ}\text{C}$

Open and Short Circuit Detection

Trip Voting

Thermal Model Biasing

Motor Cooling Time Learning

Optional External RTD Module

12 Remote RTD Inputs

Trip, Alarm, and Thermal Features as with Internal RTDs

Up to 500 m Away Using Fiber-Optic Cable

Adds Remote Speed Switch Input

Reporting Functions**Event Summaries/Event Reports**

14 Latest Summaries and 15-Cycle Oscillographic Records

Resolution: 4 or 16 samples/cycle

Load Profile Function

Stores up to 17 quantities every 15 minutes for 48 days (without voltage option) or 34 days (with voltage option).

Sequential Events Records

512 Latest Time-Tagged Events

Motor Start Reports

5 Latest Starts

Report Length: 3600 cycles

Quantities stored every 5 cycles during and immediately after each start.

Motor Start Trend

Stores 30-day averages of starting data for each of the past eighteen 30-day periods.

Ratings, Type Tests, and Certifications**Operating Temperature Range** -40°C to $+85^{\circ}\text{C}$ -40°F to $+185^{\circ}\text{F}$ **Power Supply Voltage Range**20–250 $\pm 20\%$ Vdc95–240 $\pm 10\%$ Vac 50/60 Hz < 15 VA Total BurdenHold-Up Time: 50 ms @ 125 Vdc
150 ms @ 120 Vac

Elevation

Up to 2000 m above mean sea level

Dimensions

Refer to *Figure 2.1* for relay dimensions

Weight

2.7 kg (6 lb)

Terminal Connections

Current, Voltage, and Power Inputs Terminal Block Tightening Torque:

Minimum:	0.9 Nm (8 in-lb)
Maximum:	1.4 Nm (12 in-lb)

Compression Plug Tightening Torque:

Minimum:	0.4 Nm (3.5 in-lb)
Maximum:	0.6 Nm (5.3 in-lb)

Type Tests

Front Panel:	NEMA12/IP54
Dielectric:	IEC 255-5: 1977 IEEE C37.90: 1989, 2500 Vac on analogs, contact inputs, and contact outputs; 3100 Vdc on power supply, 2200 Vdc on EIA- 485 communications port
Environmental:	IEC 68-2-1: 1990 IEC 68-2-2: 1974
Damp Heat Cycle:	IEC 68-2-30 : 1980
Electrostatic Discharge:	EN 61000-4-2: 1995, Level 4 IEC 255-22-2: 1996, Level 4
Radio Frequency Immunity:	IEC 801-3: 1984 IEC 255-22-3: 1989 ENV 50140: 1994 IEEE C37.90.2: 1987, 10 V/m
1 MHz Burst:	IEC 255-22-1: 1988
Vibration:	IEC 255-21-1: 1988
Endurance:	Class 1
Response:	Class 2
Shock and Bump:	IEC 255-21-2: 1988
Bump:	Class 1
Shock Withstand:	Class 1
Shock Response:	Class 2
Seismic:	IEC 255-21-3: 1993, Level 2

Section 2

Installation

Panel Cut and Drill Plans

Figure 2.1 shows the mechanical and panel cutout dimensions of the SEL-701 Relay.

DANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock and death.

Guard against accidental contact with relay rear terminals by mounting the relay in an approved enclosure or by using any of the following methods:

- Locate the relay in a room, vault, or similar enclosure that is accessible only to qualified persons.
- Locate the relay on a suitable balcony, gallery, or platform that is elevated and accessible only to qualified persons.
- Use suitable permanent, substantial partitions or screens arranged so that only qualified persons have access to the space within reach of live parts. Locate and size any openings in partitions or screens so that neither people nor conducting objects are likely to come into accidental contact with live parts.

PANEL-MOUNT CHASSIS




Figure 2.1 SEL-701 Relay Dimension Diagram

Relay Mounting

⚠ WARNING
Overtightening the mounting nuts may permanently damage the relay chassis.

Mount the relay in the prepared panel cutout using the four mounting studs and the locknuts provided. Tighten the four nuts until snug (10–15 in-lb torque); be careful not to overtighten. Tightening these nuts causes the rubber weather seal to compress in the channel, pressing against the panel and sealing the cutout.

After mounting the relay, you may remove the protective film that covers the rear panel. This film is meant to protect the relay finish during installation and is not required by the relay in operation.




Figure 2.2 SEL-701 Relay Panel Mounting Detail

Wire Sizes and Insulation


Wire sizes for grounding (earthing), current, voltage, and contact connections are dictated by the terminal blocks and expected load currents. You may use the following table as a guide in selecting wire sizes:

Connection Type	Minimum Wire Size	Maximum Wire Size
Grounding (Earthing) Connection	18 AWG (0.8 mm ²)	14 AWG (2.1 mm ²)
Current Connection	16 AWG (1.3 mm ²)	12 AWG (4 mm ²)
Potential (Voltage) Connection	18 AWG (0.8 mm ²)	14 AWG (2.1 mm ²)
Contact I/O	18 AWG (0.8 mm ²)	14 AWG (2.1 mm ²)
Other Connection	18 AWG (0.8 mm ²)	14 AWG (2.1 mm ²)

You should use wire with 0.4 mm thick insulation for high voltage connections to allow for contact between adjacent wires. If possible, use 0.4 mm insulated wires for all connections.

Relay Rear-Panel Diagram

All relay electrical connections, except the front-panel EIA-232 connections, are made at the relay rear panel, shown in *Figure 2.3*. The relay rear panel is designed with two 45° sections, illustrated in *Figure 2.4*. These cutaway areas provide additional clearance for swing-panel mounting. The relay sides include drawings that indicate the factory default function of each relay terminal and typical wiring diagrams.



i3119b

Figure 2.3 Relay Rear Panel




Figure 2.4 SEL-701 Relay Left- and Right-Side Panel Drawings

Example AC Wiring Diagrams




Figure 2.5 Example AC Wiring Diagram, Four-Wire Wye Voltages and Ground CT




Figure 2.6 Example AC Wiring Diagram, Open-Delta Voltages and Residual IN Connection




Figure 2.7 Example AC Voltage Wiring Diagram, Single Phase-to-Phase Voltage




Figure 2.8 Example AC Voltage Wiring Diagram, Single Phase-to-Neutral Voltage

Relay Connections

Input Power Connections

DANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

The SEL-701 Relay power supply has a broad operating range that can accept ac or dc inputs.

Power Supply Operating Range:

- 95–240 $\pm 10\%$ Vac 50/60 Hz
- 20–250 $\pm 20\%$ Vdc
- <15 VA, typical

The relay power supply is fused internally. If the fuse operates, make sure that the cause of the fuse operation has been isolated and corrected before replacing the fuse and returning the relay to service. See *Section 10: Maintenance and Troubleshooting* for instructions on how to replace the power supply fuse.

Replacement Power Supply Fuse Ratings: T 2 A/250 V, high breaking capacity.

Relay Chassis Ground Connection

Terminals D01 and D10 are the chassis ground terminals. At least one of these terminals must be solidly connected to the cabinet ground bus for correct relay operation and personal safety.

Current Transformer Inputs

The SEL-701 Relay is equipped with four current transformer inputs: IA, IB, IC, and IN. Each input can accept either 1 A nominal or 5 A nominal CT secondary inputs.

The relay sequence current and power measurements are sensitive to the polarity of current applied to the relay. Make sure that the current connections observe the polarity markings shown in *Figure 2.5* and *Figure 2.6*. Connect the CT nonpolarity lead to the COM CT terminal. Connect the CT polarity lead to the 5 A or 1 A input, depending on the secondary rating of the CT.

The SEL-701 phase instantaneous overcurrent elements normally operate using the output of a cosine filter algorithm. During heavy fault currents when the relay detects severe CT saturation, the overcurrent elements can operate on the adaptive current algorithm.

The adaptive current algorithm is only used for phase instantaneous overcurrent elements if and only if the corresponding pickup setting is greater than eight times the nominal phase current. No other overcurrent elements use the adaptive current algorithm.

Based on the level of a "harmonic distortion index," the adaptive current is either the output of the cosine filter or the output of the bipolar peak detector. When the harmonic distortion index exceeds the fixed threshold that indicates severe CT saturation, the adaptive current is the output of the bipolar peak detector. When the harmonic distortion index is below the fixed threshold, the adaptive current is the output of the cosine filter.

The cosine filter provides excellent performance in removing dc offset and harmonics. However, the bipolar peak detector has the best performance in situations of severe CT saturation when the cosine filter magnitude estimation is significantly degraded. Combining the two filters provides an elegant solution for ensuring dependable phase instantaneous overcurrent element operation.

Ground Current Transformer Input

The relay IN input can be connected in either of two ways, as shown in *Figure 2.5* and *Figure 2.6*. The preferred method is the ground CT method in *Figure 2.5*. Connecting the IN input residually, as in *Figure 2.6*, requires you to select a relatively high overcurrent element pickup setting to avoid tripping due to false residual current caused by CT saturation during high starting current. The IN connection shown in *Figure 2.5* is preferred and provides for a lower ratio flux-balance CT that avoids saturation and provides greater ground fault sensitivity.

When you use a ground CT, its placement is critical and depends on the type of cable used to connect the motor to the source. As *Figure 2.9* shows, using unshielded cable requires that the CT be placed between the neutral connection to ground and the motor, with the neutral lead included in the CT window. With shielded cable, the shield connection to ground must pass through the CT window.




Figure 2.9 Ground CT Placement

Contact Outputs

The SEL-701 Relay is equipped with five Form C contact outputs. Each one provides a normally opened and a normally closed contact. The contacts are rated to switch 8 A resistive at 250 Vac. For dc operation, the contacts are rated for tripping duty, according to IEEE standards.

The contact positions indicated in *Figure 2.10* and on the relay chassis are the positions the contacts are in when the relay is de-energized. The relay self-test ALARM contact always operates in a fail-safe mode; you can use relay settings to program the remaining outputs for fail-safe operation. When you set an output to operate in fail-safe mode, the relay holds the contact in an energized position continuously, then de-energizes the contact to trip. The contact is also de-energized if the relay input power is removed. The connections shown in *Figure 2.10* are suitable for use with a motor contactor when trip fail-safe operation is desired.

When you set an output to operate in nonfail-safe mode, the relay energizes the contact to trip. The contacts do not change position when relay input power is removed.

NOTE: When you select trip fail-safe operation, the relay will automatically trip the motor when input power is removed from the relay or if the relay fails. This is desirable if the protected motor is more valuable than the process the motor supports. If the process is more valuable than the motor, disable trip fail-safe operation and make appropriate wiring modifications. See Output Contact Fail-Safe, Trip Duration, and Starting Lockout Settings on page 4.34 in Section 4: Settings Calculations for additional information on fail-safe settings.




Figure 2.10 Contact Output Factory Default Wiring Diagram

Figure 2.11 shows various wiring methods for fail-safe and nonfail-safe wiring to control breakers and contactors.




Figure 2.11 Trip Contact Fail-Safe, NonFail-Safe Wiring Options

The relay output contacts are fully programmable using the relay settings described in *Appendix B: SELOGIC Control Equations and Relay Logic*. For many applications, the factory default configuration will provide the desired performance.

The factory configuration for OUT1 provides an alarm for selected protection elements such as the motor thermal element, load loss element, current unbalance element, and power element alarms. The normally open output contact of OUT1 closes if it detects any of these alarm conditions.

The factory configuration for OUT2 provides an alarm for RTD-based functions. The relay closes the normally open output contact if an RTD alarm temperature is exceeded, if the RTD Bias alarm picks up, if RTD leads short or open, or if the relay loses communication with an SEL-2600 series RTD module. This output is inactive if the relay is not equipped with RTD inputs.

Output OUT3 can be used to start the motor using the factory default settings as shown in *Figure 2.12*.

The ALARM normally closed output contact is a fail-safe contact. This contact opens while the relay is in service and closes when:

- Input power is removed.
- Three incorrect Access Level 2 passwords are entered.
- Successful Access Level 2 admission is achieved.
- The relay fails.




Figure 2.12 Optional Motor Start Wiring Using Factory Default Settings for Output Contact OUT3

Contact Inputs

CAUTION

Do not connect external voltages to the relay contact inputs. Because the contact inputs are internally wetted, permanent damage to the relay or external equipment may result from connecting external voltage to a relay contact input.

NOTE: COMs C02, C05 and C08 are interconnected inside the relay

The SEL-701 Relay is equipped with six internally wetted contact inputs. The relay supplies 28 Vdc wetting voltage for each input so you only need to connect a dry contact, switch, or jumper to the input.

The contact input functions are fully programmable using the relay settings described in *Appendix B: SELOGIC Control Equations and Relay Logic*.

For many applications, the factory default configuration shown in *Figure 2.13* and described below will provide the desired performance.




Figure 2.13 Contact Input Factory Default Wiring Diagram

- Input IN1 is configured to monitor the motor breaker or contactor 52B contact, if available. When not available, set 52A = 0 using SELOGIC.
- Input IN2 is configured for direct tripping. When the contact connected to IN2 closes, the relay will trip to shut down the motor.
- Input IN3 is configured for a speed switch. If you want speed switch tripping, connect the speed switch contact to IN3 or to the contact input on an SEL-2600 series RTD module. See

NOTE: The relay does not require that this input be used for Level 2 access. You can also enter the appropriate relay password using the serial port or front panel to gain entry to Access Level 2. Shorting the IN4 input makes password entry unnecessary; this is useful if the Access Level 2 password is lost.

Analog Output

NOTE: Connection of dc voltage to the analog output terminals could result in damage to the relay.

Speed Switch Tripping in Section 4: Settings Calculations for additional information regarding the speed switch tripping function.

- Input IN4 is configured for Access Level 2 control. You can connect a key switch to this input. When the switch contact is closed, you can use relay Access Level 2 commands to change relay settings or control output contacts.
- Input IN5 is configured to enable an emergency restart. The Emergency Restart function resets the relay thermal model and overrides all other starting lockout functions to allow an immediate motor start.
- Input IN6 is not applied in the factory default settings.

The SEL-701 Relay single analog output provides a dc current level signal proportional to any one of several relay measurements. Relay settings described in *Analog Output Settings in Section 4: Settings Calculations* allow you to select the analog output range (0–1 mA, 0–20 mA, or 4–20 mA). Connect the relay output to the input of your PLC or panel meter.

The maximum load for the analog output depends on the selected output range. When you select 0–20 mA or 4–20 mA, the maximum load is 400 ohms. When you select 0–1 mA, the maximum load is 8000 ohms.

As shown in *Figure 2.14*, connect the analog output cable shield to ground at terminal B03 (SHLD), or at the PLC or meter location. Do not connect the shield to ground at both locations.




Figure 2.14 Analog Output Wiring

Internal RTD Connections (Relay Models 0701010X and 0701011X)

The SEL-701 Relay is available with 11 optional internal RTD inputs.

When the relay is equipped with internal RTD inputs, you can enter relay settings that define the type, location, trip, and alarm temperatures for each input individually. RTDs can measure the temperature of the motor stator windings, motor or load bearings, ambient temperature, or other temperatures. The relay can accurately measure temperature represented by 100-ohm platinum, 100-ohm nickel, 120-ohm nickel, or 10-ohm copper RTDs, but does not support temperature measurement using thermistors or thermocouples.

The relay supports three-lead RTDs, providing terminals for +, –, and common leads. For best lead-resistance compensation, all three leads should be the same length and wire gauge. Maximum lead resistance is 25 ohms for platinum and nickel RTDs and 3 ohms for copper RTDs.

Table 2.1 shows typical maximum RTD lead lengths for various wire gauges.

Table 2.1 Typical Maximum RTD Lead Length

RTD Lead AWG	Platinum or Nickel RTD	Copper RTD
24	950 ft (290 m)	110 ft (34 m)
22	1500 ft (455 m)	180 ft (54 m)
20	2400 ft (730 m)	290 ft (88 m)
18	3800 ft (1155 m)	450 ft (137 m)

Use shielded cable for the RTD connections, with the shield connected to ground at the relay. As shown in *Figure 2.15*, two shield connection terminals, A01 and A30, are provided for grounding at the relay. You may also connect shield wires to the common connection terminals, A04, A09, A14, A19, A24, and A29, which are internally connected to the relay chassis.

NOTE: All COMs and shields are internally connected to the relay chassis.




Figure 2.15 RTD Input Wiring

AC Voltage Connections (Relay Models 0701001X and 0701011X)

NOTE: The SEL-701 Relay calculates system frequency for the over- and underfrequency elements using the A-N or A-B voltage. When single-phase voltage is applied, make sure that either the A-N or A-B voltage is connected to the relay.

NOTE: SEL-701 Relays with voltage option will track frequency only if voltage is applied to the relay.

EIA-232 Communication Cables

EIA-485 Communication Cables

NOTE: When you enable Modbus protocol for the rear-panel serial port, the relay disables the EIA-232 serial port and enables the EIA-485 serial port.

The SEL-701 Relay is available with optional voltage inputs and associated metering, protection, and reporting functions. When your relay is equipped to measure voltages, you can connect the relay in any of the following ways:

- Three-phase, four-wire, wye-connected voltages, 0–300 Vac, phase-to-neutral
- Three-phase, three-wire, open-delta connected voltages, 0–300 Vac, phase-to-phase
- Single phase-to-neutral, 0–300 Vac
- Single phase-to-phase, 0–300 Vac

Refer to *Figure 2.5* through *Figure 2.8* for examples of each type of connection.

The connection method shown in *Figure 2.7* may allow you to use the motor control voltage transformer to supply the phase-to-phase voltage for the relay. If the control voltage transformer is connected to the bus for the protected motor and the transformer is connected A-B, you can connect the ac control voltage to the relay voltage inputs, as shown in *Figure 2.7*. Using this connection method, the relay voltage measurement accuracy is dependent on the control voltage transformer ratio accuracy, regulation, and loading. However, this accuracy may be satisfactory for your application.

The SEL-701 Relay tracks frequency from 20–70 Hz. In relay models 0701000X and 0701010X, the relay tracks frequency using the current waveform, while relay models 0701001X and 0701011X use the voltage applied to the VA channel to track the frequency.

The SEL-701 Relay is equipped with 9-pin EIA-232 serial port connectors on the front and rear panels. The front-panel port is always available for connection to a local PC for setting entry or information download. Use SEL Cable C234A (pinout shown in *Connect Your PC to the Relay* in *Section 6: ASCII Serial Port Operation*) or a null-modem cable for direct connection to a local PC serial port.

The rear-panel EIA-232 serial port is available when you disable Modbus® protocol support by relay settings. You can connect the relay rear-panel port to a local PC, a modem, or an SEL-2032, SEL-2030, or SEL-2020 communications processor. Fiber-optic cable modems are also available for communication at distances greater than 50 feet (15.2 meters). Use the SEL-5801 Cable SELECTOR software (available for free download at the SEL web site, www.selinc.com) to determine the correct metallic or fiber-optic cable for your particular application. If you prefer to build your own, this software also shows the cable pinout for metallic cables.

The SEL-701 Relay is equipped with a rear-panel EIA-485 serial port connector which operates using Modbus protocol when you enable that feature by relay settings. Connect the SEL-701 Relay EIA-485 port to a Modbus Master device as shown in *Figure 2.16*.




Figure 2.16 Rear-Panel EIA-485 Serial Port Connections

SEL-2600 RTD Modules

RTD Connection

The SEL-701 Relay is compatible with the SEL-2600 RTD modules, which monitor up to 12 RTD inputs and a single contact input. The modules use a fiber-optic cable to communicate temperature measurements and contact status back to the relay.

You may connect any of the four supported RTD types to any of the 12 available RTD inputs. The SEL-2600 RTD modules have RTD input requirements similar to the SEL-701 Relay, as described in *Internal RTD Connections (Relay Models 0701010X and 0701011X)* on page 2.12. The modules do not require settings. Refer to the instruction manual of the applicable model for details.

You can locate the module up to 1600 feet (500 meters) from the relay, near the protected motor.

Fiber-Optic Connection

Connect the SEL-2600 (V-Pin option) RTD module Fiber-Optic TX port to the SEL-701 Fiber-Optic RX port using a single fiber-optic cable (SEL part number C805Z010VVX0003 for a 3-meter length cable). Other lengths, heavy-duty jacketed, and waterproof heavy-duty jacketed cables are also available. The maximum cable length allowed is 1600 feet (500 meters).

This page intentionally left blank

Section 3

PC Software

Overview

SEL provides many PC software solutions (applications) to support the SEL-701 Motor Protection Relay and other SEL devices. SEL-701 software solutions are listed in *Table 3.1*.

Table 3.1 SEL Software Solutions

Part Number	Product Name	Description
SEL-5010	SEL-5010 Relay Assistant Software	This application uses a database to manage a connection directory and settings of multiple devices.
SEL-5807	SEL-701 PC Software	Supports SEL-701 firmware revisions R112 and lower.
SEL-5030	ACSELERATOR QuickSet® SEL-5030 Software	See <i>Table 3.2</i> . Supports SEL-701 firmware versions R112 and higher.
SEL-5040	ACSELERATOR Report Server™ SEL-5040 Software	This application automatically retrieves, files, and summarizes reports.
SEL-5601	ACSELERATOR Analytic Assistant™ SEL-5601 Software	Converts SEL Compressed ASCII event report files to oscillography
SEL-5801	SEL-5801 Cable Selector Software	Selects the proper SEL cables for your application

This section describes how to get started with ACSELERATOR QuickSet and the SEL-701. ACSELERATOR QuickSet is a powerful setting, event analysis, and measurement tool that aids in setting, applying, and using the SEL-701. *Table 3.2* shows the suite of ACSELERATOR QuickSet applications provided for the SEL-701.

Table 3.2 ACSELERATOR QuickSet Software

Rules Based Settings Editor	Provides on-line or off-line device settings that include interdependency checks. Use this feature to create and manage settings for multiple devices in a database.
HMI	Provides a summary view of device operation. Use this feature to simplify commissioning testing.
Event Analysis	Provides oscillography and other event analysis tools.
Setting Database Management	ACSELERATOR QuickSet uses a database to manage the settings of multiple devices.
Terminal	Provides a direct connection to the SEL device. Use this communication method to interface directly with the device.
Help	Provides general ACSELERATOR QuickSet and relay-specific ACSELERATOR QuickSet context help.

Setup

Follow the steps outlined in *Section 2: Installation* to prepare the SEL-701 for use. Perform the following steps to initiate communications:

- Step 1. Connect the appropriate communications cable between the SEL-701 and the PC.
- Step 2. Apply power to the SEL-701.
- Step 3. Start ACSELERATOR QuickSet.

Communications

ACSELERATOR QuickSet uses relay EIA-232 rear communications **Port R** or **Port F** (front panel) to communicate with the SEL-701. Perform the following steps to configure ACSELERATOR QuickSet to communicate effectively with the relay.

- Step 1. Select **Communications** from the ACSELERATOR QuickSet main menu bar, as shown in *Figure 3.1*.




Figure 3.1 Serial Port Communication Dialog Box

- Step 2. Select the **Parameters** submenu to display the screen shown in *Figure 3.2*.




Figure 3.2 Serial Port Communication Parameters Dialog Box

- Step 3. Configure the PC port to match the relay communications settings.

- Step 4. Configure ACSELERATOR QuickSet to match the SEL-701 default settings by entering Access Level 1 and Access Level 2 passwords in the respective text boxes.
- Step 5. If a telephone modem is chosen from the relay text box, enter the dial-up telephone number in the **Phone Number** text box.
- Step 6. Exit the menus by clicking **OK** when finished.

Terminal

Terminal Window

Select **Tools > Terminal** on the ACSELERATOR QuickSet main menu bar to open the terminal window (shown in *Figure 3.3*).




Figure 3.3 Tools Menu

The terminal window is an ASCII interface with the relay. This is a basic terminal emulation, including file transfer capabilities. Many third-party terminal emulation programs are available with file transfer encoding schemes. Open the terminal window by either clicking **Tools > Terminal** or by pressing **<Ctrl+T>**. Verify proper communications with the relay by opening a terminal window, pressing **<Enter>** a few times, and verifying that a prompt is received. If a prompt is not received, verify proper setup.

Terminal Logging

To create a file that contains all terminal communications with the relay, select **Terminal Logging** in the **Log** menu and specify a file at the prompt. ACSELERATOR QuickSet records communications events and errors in this file. Click **Log > Connect Log** to view the log. Clear the log by selecting **Log > Clear Connection Log**.

Drivers and Part Number

After clicking **Tools > Terminal**, access the relay at Access Level 1. Issue the **ID** command to receive an identification report, as shown in *Figure 3.4*.

```
=>ID <Enter>
"FID=SEL-701-X205-V11xxx-Z004002-D20060925", "0A48"
"BFID=SELBT-701-R102-V0-Z000000-D19991123", "0981"
"DEVID=SEL-701", "03C2"
"DEVCODE=35", "030F"
"PARTNO=0701011xxx", "0543"
"CONFIG=111120", "0389"
=>
```

Figure 3.4 Device Response to the ID Command

Locate and record the Z number (Z004002) in the FID string. The first portion of the Z number (Z004...) determines the ACSELERATOR QuickSet relay settings driver version when you are creating or editing relay settings files.

The use of the Device Editor driver version will be discussed in more detail later in this section—see *Settings Editor (Editor Mode)* on page 3.7. Compare the part number (PARTNO=0710XXXXXX) with the Model Option Table (MOT) to ensure the correct relay configuration.

Settings Database Management and Drivers

ACSELERATOR QuickSet uses a database to save relay settings and contains sets of all settings files for each relay specified in the Database Manager. Choose appropriate storage backup methods and a secure location for storing database files.

Active Database

Change the active database to the one that needs to be modified by selecting **File > Active Database** on the main menu bar.

Database Manager

Select **File > Database Manager** on the main menu bar to create new databases and manage records within existing databases.

Settings Database

- Step 1. Open the Database Manager to access the database. Click **File > Database Manager**. A dialog box appears.
The default database file already configured in ACSELERATOR QuickSet is Relay.rdb. This database contains example settings files for the SEL products with which you can use ACSELERATOR QuickSet.
- Step 2. Enter descriptions for the database and for each relay or relay in the database in the **Database Description** and **Settings Description** dialog boxes.
- Step 3. Enter special operating characteristics that describe the relay settings in the **Settings Description** dialog box. These can include the protection scheme settings and communications settings.
- Step 4. Highlight one of the relays listed in **Settings in Database** and select the **Copy** option button to create a new collection of settings.
ACSELERATOR QuickSet prompts for a new name. Be sure to enter a new description in **Settings Description**.

Copy/Move Settings Between Databases

- Step 1. Select the **Copy/Move Settings Between Databases** tab to create multiple databases with the **Database Manager**; these databases are useful for grouping similar protection schemes or geographic areas.
- Step 2. Click the **Open B** option button to open a relay database.
- Step 3. Type a filename and click **Open**.
 - a. Highlight a device or setting in the **A** database,
 - b. select **Copy** or **Move**, and click the > button to create a new device or setting in the **B** database.
- Step 4. Reverse this process to take devices from the **B** database to the **A** database. **Copy** creates an identical device that appears in

both databases. **Move** removes the device from one database and places the device in another database.

Create a New Database, Copy an Existing Database

To create and copy an existing database of devices to a new database:

- Step 1. Click **File > Database Manager** and select the **Create New Database** button. ACSELERATOR QuickSet prompts you for a file name.
- Step 2. Type the new database name (and location if the new location differs from the existing one) and click **Save**. ACSELERATOR QuickSet displays the message `Settings [path and filename] was successfully created`.
- Step 3. Click **OK**.

To copy an exiting database of devices to a new database:

- Step 1. Click **File > Database Manager** and select the **Copy/Move Settings Between Databases** tab in the **Database Manager** dialog box.
ACSELERATOR QuickSet opens the last active database and assigns it as **Database A**.
- Step 2. Click the **Open B** button; ACSELERATOR QuickSet prompts you for a file location.
- Step 3. Type a new database name, click the **Open** button, and click **Yes**; the program creates a new empty database. Load devices into the new database as in **Copy/Move Settings Between Databases**.

Settings

ACSELERATOR QuickSet offers the capability of creating settings for one or more SEL-701 relays. Store existing relay settings downloaded from SEL-701 relays with ACSELERATOR QuickSet, creating a library of relay settings, then modify and upload these settings from the settings library to an SEL-701. ACSELERATOR QuickSet makes setting the relay easy and efficient. However, you do not have to use ACSELERATOR QuickSet to configure the SEL-701; you can use an ASCII terminal or a computer running terminal emulation software. ACSELERATOR QuickSet provides the advantages of rules-based settings checks, operator control and metering HMI, event analysis, and help.

Settings Editor

The Settings Editor shows the relay settings in easy-to-understand categories. The SEL-701 settings structure makes setting the relay easy and efficient. Settings are grouped logically, and relay elements that are not used in the selected protection scheme are not accessible. ACSELERATOR QuickSet shows all of the settings categories in the settings tree view. The settings tree view remains constant whether settings categories are enabled or disabled. However, any disabled settings are dimmed when accessed by clicking an item in the tree view.

Settings Menu

ACSELERATOR QuickSet uses a database to store and manage SEL relay settings. Each unique relay has its own record of settings. Use the **File** menu to **Open** an existing record, create and open a **New** record, or **Read** relay settings from a connected SEL-701 and then create and open a new record.

Use **Tools** menu to **Convert** and open an existing record. The record will be opened in the **Setting Editor** as a **Setting Form** (template) or in **Editor Mode**.

Table 3.3 File/Tools Menus

Menus	Description
<<, >>	Use these navigation menu buttons to move from one category to the next
New	Open a New record
Open	Open an existing record
Read	Read device settings and then create and open a new record
Convert	Convert and open an existing record

File > New

Selecting the **New** menu item creates new settings files. ACSELERATOR QuickSet makes the new settings files from the driver that you specify in the **Settings Editor Selection** dialog box. ACSELERATOR QuickSet uses the Z number in the FID string to create a particular version of settings. To get started making SEL-701 settings with the **Settings Editor** in the **Editor Mode**, select **File > New** from the main menu bar, and SEL-701 and 004 from the **Settings Editor Selection** window as shown in *Figure 3.5*.




Figure 3.5 Selection of Drivers

After the relay model and settings driver selection, ACSELERATOR QuickSet presents the **Relay Part Number** dialog box. Use this dialog box to configure the Relay Editor to produce settings for a relay with options determined by the part number, as shown in *Figure 3.6*. Press **OK** when finished.




Figure 3.6 Update Part Number

Figure 3.7 shows the **Settings Editor** screen. View the bottom of the Settings Editor window to check the **Settings Driver** number. Compare the ACSELERATOR QuickSet Settings Driver number and the first portion of the Z number in the FID string (select **Tools > Meter & Control > Status**). These numbers must match. ACSELERATOR QuickSet uses this first portion of the Z number to determine the correct **Settings Editor** to display.




Figure 3.7 New Setting Screen

File > Open

The **Open** menu item opens an existing device from the active database folder. ACSELERATOR QuickSet prompts for a device to load into the **Settings Editor**.

File > Read

When the **Read** menu item is selected, ACSELERATOR QuickSet reads the device settings from a connected device. As ACSELERATOR QuickSet reads the device, a **Transfer Status** window appears. ACSELERATOR QuickSet uses serial protocols to read settings from SEL devices.

Tools > Convert

Use the **Convert** menu item to convert from one settings version to another. Typically, this utility is used to upgrade an existing settings file to a newer version because devices are using a newer version number. ACSELERATOR QuickSet provides a **Convert Settings** report that shows missed, changed, and invalid settings created as a result of the conversion. Review this report to determine whether changes are required.

Settings Editor (Editor Mode)

Use the **Settings Editor (Editor Mode)** to enter settings. These features include the ACSELERATOR QuickSet settings driver version number (the first three digits of the Z number) in the lower left corner of the Settings Editor.

Entering Settings

NOTE: Setting changes made during the edit session are not read by the relay unless they are transferred to the relay with a Send menu item.

- Step 1. Click the + marks and the buttons in the **Settings Tree View** to expand and select the settings you want to change.
- Step 2. Use **Tab** to navigate through the settings, or click on a setting.
- Step 3. To restore the previous value for a setting, right-click the mouse over the setting and select **Previous Value**.
- Step 4. To restore the factory default setting value, right-click in the setting dialog box and select **Default Value**.

Step 5. If you enter a setting that is out of range or has an error, ACSELERATOR QuickSet shows the error at the bottom of the **Settings Editor**. Double-click the error listing to go to the setting and enter a valid input.

File > Save

Select the **Save** menu item from the **File** menu item of the **Settings Editor** once settings are entered into ACSELERATOR QuickSet. This will help ensure the settings are not lost.

File > Send

To transfer the edits made in the ACSELERATOR QuickSet edit session, you must send the settings to the relay. Select **Send** from the **File** menu. In the dialog box that opens, select the settings section you want transferred to the relay by checking the appropriate box.

Edit > Part Number

Use this menu item to change the part number if it was entered incorrectly during an earlier step.

Text Files

Select **Tools > Import** and **Tools > Export** on the ACSELERATOR QuickSet menu bar to import or export settings from or to a text file. Use this feature to create a small file that can be more easily stored or sent electronically.

Event Analysis

ACSELERATOR QuickSet has integrated analysis tools that help you retrieve information about relay operations quickly and easily. Use the event information that the SEL-701 stores to evaluate the performance of a system (select **Tools > Events > Get Event Files**). *Figure 3.8* shows composite screens for retrieving events.




Figure 3.8 Composite Screens for Retrieving Event

Event Waveforms

The relay provides two types of event data captures: event reports that uses 4 samples/cycle filtered data and 16 samples/cycle unfiltered (raw) data. See *Section 9: Event Analysis* for information on recording events. Use the **Options** function in *Figure 3.8* to select the 16 samples/cycle unfiltered (raw) data event (default is 4 samples/cycle filtered data).

View Event History

You can retrieve event files stored in the relay and transfer these files to a computer. For information on the types of event files and data capture, see *Section 9: Event Analysis*. To download event files from the device, click **Tools > Events > Get Event Files**. The **Event History** dialog box appears, as shown in *Figure 3.8*.

Get Event

Highlight the event you want to view (e.g., Event 1 in *Figure 3.8*), select the event type with the Options Event type function (4 samples or 16 samples) and click the **Get Selected Event** button. When downloading is complete, ACSELERATOR QuickSet queries whether to save the file on your computer, as shown in *Figure 3.9*.




Figure 3.9 Saving the Retrieved Event

Enter a suitable name in the **File name** text box and select the appropriate location where ACSELERATOR QuickSet should save the event record.

View Event Files

To view the saved events, you need the ACSELERATOR Analytic Assistant SEL-5601 Software package. Use the **View Event Files** function from the **Tools > Events** menu to select the event you want to view (ACSELERATOR QuickSet remembers the location where you stored the previous event record). Use **View Combined Event Files** to simultaneously view up to three separate events.

Meter and Control

Click on **Tools > Meter & Control** to bring up the screen shown in *Figure 3.10*. The HMI tree view shows all the functions available from the HMI function.

Metering Overview

The metering overview screen provides an overview of the device. It shows metering functions, front-panel LED status and input/output status. The overview hides voltage and RTD related quantities if the relay does not have these option cards installed.




Figure 3.10 Device Overview Screen

The **Instantaneous**, **Demand/Peak**, **Min/Max**, etc., screens display the corresponding values.

Help

Various forms of ACSELERATOR QuickSet help are available, as shown in *Table 3.4*. Press <F1> to open a context-sensitive help file with the appropriate topic as the default.

Table 3.4 Help

Help	Description
General ACSELERATOR QuickSet	Select Help from the main menu bar
SEL-701 Settings	Select Settings Help from the Help menu bar while the Settings Editor is open.
Database Manager	Select Help from the bottom of the Database Manager window

This page intentionally left blank

Section 4

Settings Calculations

Introduction

The SEL-701 Relay protection settings are divided into two major categories. The first category, described in this section, includes settings to configure the motor protection elements and basic functions. The second category, described in *Appendix B: SELOGIC Control Equations and Relay Logic*, includes logic settings that allow you, if you wish, to customize the relay contact input and output operation. The relay also includes settings that control the function of the serial ports and the sequential events recorder (SER) function.

NOTE: Each SEL-701 Relay is shipped with default factory settings summarized in Appendix F: SEL-701 Relay Settings Sheets Example. Calculate and enter settings for your motor to ensure that the relay provides secure, dependable protection.

This instruction manual section includes the following subsections:

Application Data. Lists information that you will need to know about the protected motor before starting to calculate the relay settings.

General Data. Lists settings that configure the relay inputs to accurately measure and interpret the ac current and optional voltage input signals.

Basic Motor Protection. Lists settings for protection elements that are included in all models of the SEL-701 Relay, including the thermal element, overcurrent elements, load-loss, and load-jam functions.

RTD-Based Protection. Lists settings associated with the optional internal RTD inputs (Relay Models 0701010X and 0701011X) or if the relay will be connected to an SEL-2600 RTD module. You can skip this subsection if your application does not include RTD measuring.

Voltage-Based Protection (Relay Models 0701001X and 0701011X). Lists settings associated with the optional ac voltage-based protection elements. You can skip this subsection if your relay is not equipped with optional voltage inputs.

Output Configuration. Lists settings for the analog output, front-panel display control, output contact fail-safe function, and additional settings controlling the tripping functions for all relay models.

Serial Port Settings. Lists settings that configure the relay front- and rear-panel serial ports.

Sequential Events Recorder (SER) Settings. Lists settings that configure the relay sequential events recorder (SER) function.

When you calculate the protection element settings to protect your motor, proceed through the subsections listed earlier. Skip the RTD- and voltage-based protection subsections if they do not apply to your specific relay model or installation. As you calculate the settings, record them using the ACSELERATOR QuickSet® SEL-5030 Software settings function. If a PC is not available, you can manually record the calculated settings on a photocopy of the Settings Sheets found in *Appendix F: SEL-701 Relay Settings Sheets*.

If you record the settings using ACSELERATOR QuickSet, you can download them directly to a relay, or save them to a file for future download. If you record the settings manually, you can enter them using the front-panel Set Relay function, or the front-panel serial port and the Access Level 2 commands listed below.

Command	Activity
SET	Enter relay settings
SET R	Enter SER function settings
SET P F	Enter settings for the front-panel serial port
SET P R	Enter settings for the rear-panel serial port

See *Section 3: PC Software* for more information on ACSELERATOR QuickSet. *Section 5: Front-Panel Operations* includes information on using the front-panel interface; *Section 6: ASCII Serial Port Operation* includes details on using the serial port **SET** command.

Application Data

It is quicker and easier for you to calculate settings for the SEL-701 Relay if you collect the following information before you begin:

- Specifications of the protected motor including:
 - Rated full load current
 - Service factor
 - Locked rotor current
 - Maximum locked rotor time with the motor at ambient and/or operating temperature
 - Maximum motor starts per hour, if known
 - Minimum time between motor starts, if known
- Additional data regarding the motor application including:
 - Minimum no load current or power, if known
 - Motor accelerating time. This is the normal time required for the motor to reach full speed.
 - Maximum time to reach motor full load. This time may be significantly longer than the motor accelerating time, particularly in pump motor applications where the motor may run at full speed for some time before the pump reaches full head and full load.
- Current transformer primary and secondary ratings and connections
- System phase rotation and nominal frequency
- Voltage transformer ratios and connections, if used
- Type and location of resistance temperature devices (RTDs), if used
- Expected fault current magnitudes for motor or cable ground and three-phase faults

General Data

Identifier Settings

All models of the SEL-701 Relay have the following identifier settings:

Table 4.1 Identifier Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Relay Identifier	20 Characters	RID = SEL-701
Terminal Identifier	20 Characters	TID = MOTOR RELAY

The SEL-701 Relay prints the Relay and Terminal Identifier strings at the top of responses to serial port commands to identify messages from individual relays. Enter up to 20 characters, include capital letters A–Z, numbers 0–9, periods (.), dashes (-), and spaces. Suggested identifiers include the location, process, circuit, size, or equipment number of the protected motor.

Current Transformer (CT) Configuration Settings

Table 4.2 CT Configuration Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Phase (IA, IB, IC) CT Ratio	1–6000 to 1	CTR = 100
Phase CT Secondary Rating	1, 5 A	ITAP = 5
Neutral (IN) CT Ratio	1–6000 to 1	CTRN = 100
Neutral CT Secondary Rating	1, 5 A	INTAP = 5

The CT ratio and secondary rating settings configure the relay to accurately scale measured values and report the primary quantities. Calculate the phase and neutral CT ratios by dividing the primary rating by the secondary rating. See *Example 4.1*.

EXAMPLE 4.1 Phase CT Ratio Setting Calculation

Consider an application where the phase CT ratios are 600:5.

Set $CTR = 600/5 = 120$.

Set ITAP = 5 A.

Typically, the phase current transformers are selected such that the primary current rating is greater than the motor full load current (e.g., 110% of FLA).

If you connect the IN current input to the secondary of a neutral or ground current transformer as shown in *Figure 2.6 on page 2.6 in Section 2: Installation*, calculate CTRN and INTAP based on the ground CT ratings similar to the phase CT calculations shown in the example above.

If you connect the IN input residually, as shown in *Figure 2.7 on page 2.6 in Section 2: Installation*, set CTRN equal to CTR and INTAP equal to ITAP.

Phase Rotation, Nominal Frequency Settings

Table 4.3 Phase Rotation, Nominal Frequency Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Phase Rotation	ABC, ACB	PHROT = ABC
Nominal Frequency	50, 60 Hz	FNOM = 60
Date Format	MDY, YMD	DATE_F = MDY
Demand Meter Time Constant	5, 10, 15, 30, 60 min	DMTC = 15

The phase rotation setting tells the relay your phase labeling standard. Set PHROT equal to ABC when B-phase current lags A-phase current by 120°. Set PHROT equal to ACB when B-phase current leads A-phase current by 120°.




Figure 4.1 Phase Rotation Settings

Set the FNOM setting equal to your system nominal frequency. The DATE_F setting allows you to change the relay date presentation format to either North American standard (Month/Day/Year) or engineering standard (Year/Month/Day). The DMTC setting defines the thermal time constant used by the relay current and power demand meter function, if voltages are included.

Voltage Transformer
(VT) Configuration
Settings (Relay
Models 0701001X
and 0701011X)

Table 4.4 VT Configuration Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Phase (VA, VB, VC) VT Ratio	1–6000 to 1	PTR = 100
Phase VT Connection	D, Y	DELTA_Y = Y
Single Voltage Input	Y, N	SINGLELEV = N

These settings configure the optional relay voltage inputs to correctly measure and scale the voltage signals. Set the Phase VT Ratio (PTR) setting equal to the VT ratio to 1.

EXAMPLE 4.2 Phase VT Ratio Setting Calculations

Consider a 4160 V motor application where the phase-to-phase connected voltage transformer ratios are 4160:118.
Set PTR = 4160/118 = 35.25 = 35

When phase-to-phase potentials are connected to the relay, set DELTA_Y equal to D. When phase-to-neutral potentials are connected to the relay, set DELTA_Y equal to Y.

In applications where only a single voltage is available, set SINGLELEV equal to Y. As shown in Figure 2.7 and Figure 2.8 on page 2.7 in Section 2: Installation, the single voltage must be connected to the A-phase input, but it may be an A-N or an A-B voltage. Be sure to set DELTA_Y equal to Y for an A-N input or DELTA_Y equal to D for an A-B input voltage.

When you set SINGLEV equal to Y, the relay performance changes in the following ways:

- **Voltage Elements.** When you use one phase-to-phase voltage, the relay overvoltage and undervoltage elements use the applied phase-to-phase voltage only. When you use one phase-to-neutral voltage, the relay voltage elements use the applied phase-to-neutral voltage only.
- **Power Elements.** When you use one voltage, the relay assumes that the system voltages are balanced in both magnitude and phase angle to calculate apparent, real, and reactive power and the power factor.
- **Metering.** When you use one phase-to-phase voltage, the relay displays that magnitude and phase angle. When you use one phase-to-neutral voltage, the relay multiplies that magnitude by the square-root of three to calculate an approximate phase-to-phase voltage for display. The relay also adjusts the phase angle of the measured phase-to-neutral voltage by $\pm 30^\circ$ to represent phase-to-phase voltage. The relay displays zero for the magnitudes of the unmeasured voltages. Balanced voltages are assumed for power and power factor calculations.

Relays that are not equipped with phase voltage inputs hide these settings and disable voltage-based protection and metering functions.

Alarm Contact Setting

Table 4.5 Alarm Contact Setting

Setting Prompt	Setting Range	Setting Name = Factory Default
Standard Alarm Contact Operation	Y, N	STDALARM = Y

The ALARM relay on an SEL-701 Relay is a normally energized relay with form C contact. The diagnostic tests listed in *Table 10.2 on page 10.3 in Section 10: Maintenance and Troubleshooting* are performed continually as part of the background functions of the SEL-701 Relay. A failure of one of these tests will de-energize the ALARM relay.

In addition to diagnostic tests, the following user actions via the EIA-232 ports or front panel can operate the ALARM relay:

- Accessing Level 2 on the relay
- Three sequential failed Level 2 access attempts
- Changing settings on the relay (requires Level 2 access)
- Changing passwords on the relay (requires Level 2 access)

Setting STDALARM equal to Y will de-energize the ALARM relay for all of the above conditions; however, if STDALARM is equal to N, the ALARM relay will de-energize **only** for diagnostic test failure.

Basic Motor Protection

Thermal Model Element

The SEL-701 Relay motor thermal element provides integrated protection for all of the following motor operating conditions:

- Locked Rotor Starts
- Running Overload
- Unbalance Current/Negative-Sequence Current Heating
- Repeated or Frequent Starting

The Setting Method setting (SETMETH) selects the thermal element algorithm that will be used in the SEL-701 Relay. The Setting Method setting offers four options: Rating, Generic, User, and OFF.

Rating Setting Method. When selected, the relay configures a thermal curve based on the motor Full Load Amps, Service Factor, Locked Rotor Amps, Hot and Cold Locked Rotor Time, and Locked Rotor Trip Time Dial settings.

Generic Setting Method. When selected, the relay offers 45 standard motor thermal limit curves which you can select by curve number.

User Setting Method. When selected, the relay allows you to build a customized thermal limit curve by directly entering from 5 to 25 time-current points based on your motor's published thermal limit curve.

All three thermal element setting methods can provide outstanding motor protection. In each case the relay operates a thermal model with a trip value defined by the relay settings and a present heat estimate that varies with time and changing motor current. The relay expresses the present motor thermal estimate as a % Thermal Capacity. When the % Thermal Capacity reaches 100%, the relay trips. You can see the present % Thermal Capacity value using the relay front panel Meter Values\Thermal and RTD Data function or the serial port **METER T** command.

See *Appendix E: Motor Thermal Element* for more details on the thermal model.

If the Thermal Model is turned off (SETMETH = OFF), the thermal model is disabled, the output of the thermal model is blocked, and the relay reports the % Thermal Capacity as either 0 or 999.9% as noted in *Section 8: Metering and Monitoring*. It is recommended that you reset Load Profile, Motor Statistic, Motor Start Trend data, and Learned Motor Parameters when the Thermal Model is turned back on. See *Section 5: Front-Panel Operations* and *Section 6: ASCII Serial Port Operation* for the reset procedure.

Thermal Element RATING Setting Method

NOTE: The relay automatically raises the initial heat estimate at Starting (motor current > 2.5 per unit of FLA) to an operating level and ramps up the trip value to the starting element threshold. The ramping feature ensures that an overload condition during the start-to-run transition period of the model will result in trip time equal to or faster than hot overload trip time. You may observe a sudden rise in % Thermal Capacity value when you start the motor. This is normal operation for the SEL-701.

The SEL-701 thermal element always operates in one of two modes: **STARTING** (50S = 1) and **RUNNING** (50S = 0). In starting mode, the thermal element trips in locked rotor time at locked rotor current whether the motor is at ambient or at normal operating temperature. In running mode, the thermal element provides overload protection by limiting the motor heat energy estimate to a value represented by the overload settings.

The 50S overcurrent element uses the sum of positive- and negative-sequence magnitudes, $2.5 \cdot \text{FLA}$ as a pickup threshold, and $2.4 \cdot \text{FLA}$ as a dropout threshold.

**Table 4.6 Thermal Element Configuration Settings,
Setting Method = RATING**

Setting Prompt	Setting Range	Setting Name = Factory Default
Setting Method	Rating, Generic, User, OFF	SETMETH = RATING
Full Load Amps	1.00–8.00 A ITAP = 5 A	FLA = 5.00
	0.20–1.60 A ^a ITAP = 1 A	FLA = 1.00
Service Factor	1.01–1.50 ^b	SF = 1.15
Locked Rotor Amps	2.50–80.00 A ITAP = 5 A	LRA = 30.00
	0.50–16.00 A ^a ITAP = 1 A	LRA = 6.00
Hot Locked Rotor Time	1.0–200.0 s	LRTHOT = 2.1
Cold Locked Rotor Time	1.0–240.0 s	LRTCOLD = 2.5
Locked Rotor Trip Time Dial	0.10–1.50	TD = 1.00

^a The range of the Full Load Amps and Locked Rotor Amps settings depends on the ITAP settings as shown.

^b For IEC applications, set SF=1.05 or higher, but no higher than 1.2.

When you select the RATING thermal element setting method, the relay requests information on the protected motor capabilities. Obtain all of the requested information except the Locked Rotor Trip Time Dial from the motor specifications.

Occasionally, only one locked rotor time will be specified for a particular motor. Unless the specification states otherwise, assume the time is the cold locked rotor time. Multiply the cold locked rotor time by 0.833 to determine a hot locked rotor time that is acceptable for most motors. If only the hot locked rotor time is specified, multiply that value by 1.2 to determine a cold locked rotor time that is acceptable for most motors.

EXAMPLE 4.3 Thermal Element Rating Method Setting

A 4160 V, 600 HP motor is to be protected using the SEL-701 Relay Thermal Element Rating Method. The motor data sheet includes the following information.

Rated Horsepower (HP) = 600 HP
 Rated Voltage (V) = 4160 V
 Rated Full Load Current (A) = 76.9 A
 Rated Locked Rotor Amps (A) = 462.0 A
 Safe Stall Time at 100% Volts
 Cold = 21 seconds
 Hot = 16 seconds
 Service Factor = 1.2

Phase current transformers having 80:5 ratios are selected for the application. The SEL-701 Relay settings for the application are calculated as shown below.

Current Transformer Ratio (CTR) = $80/5 = 16$
 CT Secondary Rating (ITAP) = 5
 Full Load Amps (FLA) = $76.9/16 = 4.81$ A secondary
 Service Factory (SF) = 1.2
 Locked Rotor Amps (LRA) = $462.0/16 = 28.9$ A secondary
 Hot Locked Rotor Time (LRTHOT) = 16 seconds
 Cold Locked Rotor Time (LRTCOLD) = 21 seconds

The Locked Rotor Trip Time Dial setting reduces or extends the allowed accelerating time under locked rotor conditions. You can always safely set this value equal to 1.00. If you know that the driven load will always accelerate in less than the rated locked rotor time, you may wish to use a Locked Rotor Trip Time Dial less than 1.00 to provide a faster trip in locked rotor conditions. Do not set the Locked Rotor Trip Time Dial setting greater than 1.00, except to allow a start with a longer than normal accelerating time (e.g., high inertia motor application, emergency condition). When TD is set greater than 1.00, use the speed switch (see *Table 4.22* and *Figure B.22*) to provide locked rotor protection.

EXAMPLE 4.4 Locked Rotor Trip Time Dial Setting Calculation

In a particular application, a motor with a 10 second hot locked rotor time always starts in 5 seconds.

Setting the Locked Rotor Trip Time Dial setting equal to 0.75 causes the relay to trip in 7.5 seconds under locked rotor conditions. This setting allows ample time for the motor to start, but does not subject the motor to the full 10 seconds of locked rotor current if a locked rotor start attempt takes place.

Continue calculating the balance of thermal element settings with *Thermal Capacity Alarm Setting* on page 4.15.

Thermal Element GENERIC Setting Method

The Generic Method differs from the Rating Method in the following ways:

**Table 4.7 Thermal Element Configuration Settings,
Setting Method = GENERIC**

Setting Prompt	Setting Range	Setting Name = Example Setting
Setting Method	Rating, Generic, User, OFF	SETMETH = GENERIC
Full Load Amps	1.00–8.00 A ITAP = 5 A 0.20–1.60 A ITAP = 1 A	FLA = 5.00 FLA = 1.00
Service Factor	1.01–1.50	SF = 1.15
Curve Number	1–45	CURVE = 1

For simple, yet thorough motor protection, you may elect to use one of the 45 available standard motor overload/locked rotor curves. Set the motor rated Full Load Amps and Service Factor, then select the desired curve from *Figure 4.2*. Be sure that the standard curve you select trips in a time less than or equal to the motor rated locked rotor time at locked rotor current. Each increase in the curve number yields a 2.5-second increase in the curve thermal limit time at six times full load current. For a cold motor, the curve 10 trip time at six times full load current is 25 seconds. *Table 4.8* and *Table 4.9* show the cold motor thermal limit time versus current for several curves.




Figure 4.2 Generic Thermal Limit Curves, Cold Motor (SF=1.01)

Each increase in the curve number yields a 2.1-second increase in the hot motor thermal limit time at six times full load current.

The relay does not raise the initial heat estimate at starting (motor current > 2.5 per unit of FLA); however, the relay does ramp up the trip value to the starting element threshold. For a motor at ambient temperature, the locked rotor trip time will be 120 percent of the time for the same motor at operating temperature.

Continue calculating the balance of thermal element settings with *Thermal Capacity Alarm Setting* on page 4.15.

EXAMPLE 4.5 Thermal Element Generic Method Setting

A 4160 V, 800 HP motor is to be protected using the SEL-701 Relay Thermal Element Generic Curve Method. The motor data sheet includes the following information.

Rated Horsepower (HP) = 800 HP
 Rated Voltage (V) = 4160 V
 Rated Full Load Current (A) = 101.0 A
 Rated Locked Rotor Amps (A) = 620.4 A
 Safe Stall Time, Hot = 30 seconds
 Service Factor = 1.15

Each increase in generic curve number increases the hot motor thermal limit time by 2.1 seconds at six times full load current. Therefore, we can select the maximum curve number using the following equation.

$$\text{Curve} = \frac{\text{Safe Stall Time, Hot (seconds)}}{2.1 \text{ seconds}}$$

$$\text{Curve} = 30/2.1 = 14.3; \text{ select curve 14 or less}$$

Phase current transformers having 150:5 ratios are selected for the application. The SEL-701 Relay settings for the application are shown below.

Current Transformer Ratio (CTR) = 150/5 = 30
 CT Secondary Rating (ITAP) = 5
 Full Load Amps (FLA) = 101/30 = 3.36 A secondary
 Service Factor (SF) = 1.15
 Curve Number (CURVE) = 14

Table 4.8 Generic Thermal Limit Curve Tripping Times From Reset vs. Multiples of Full Load Amps, Curves 1-10 (Thermal Limit Times in Seconds)

Multiples of Full Load Amps	Curves									
	1	2	3	4	5	6	7	8	9	10
1.01	311.4	622.7	934.1	1245.4	1556.8	1868.1	2179.5	2490.8	2802.2	3113.6
1.10	138.9	277.7	416.6	555.4	694.3	833.1	972.0	1110.8	1249.7	1388.5
1.15	111.9	223.8	335.7	447.6	559.4	671.3	783.2	895.1	1007.0	1118.9
1.20	94.0	188.0	282.0	376.0	470.0	564.0	658.0	752.0	846.0	940.0
1.30	71.0	142.0	213.1	284.1	355.1	426.1	497.2	568.2	639.2	710.2
1.40	56.6	113.2	169.8	226.4	283.0	339.6	396.2	452.7	509.3	565.9
1.50	46.6	93.2	139.8	186.4	233.0	279.6	326.2	372.8	419.4	466.0
1.70	33.7	67.3	101.0	134.7	168.4	202.0	235.7	269.4	303.0	336.7
2.00	22.8	45.6	68.4	91.2	114.0	136.9	159.7	182.5	205.3	228.1
2.50	14.4	28.8	43.2	57.6	72.0	86.4	100.8	115.2	129.6	144.0
3.00	10.0	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0	100.0
3.50	7.3	14.7	22.0	29.4	36.7	44.1	51.4	58.8	66.1	73.5
4.00	5.6	11.2	16.9	22.5	28.1	33.7	39.4	45.0	50.6	56.2
4.50	4.4	8.9	13.3	17.8	22.2	26.7	31.1	35.6	40.0	44.4
5.00	3.6	7.2	10.8	14.4	18.0	21.6	25.2	28.8	32.4	36.0
6.00	2.5	5.0	7.5	10.0	12.5	15.0	17.5	20.0	22.5	25.0
7.00	1.8	3.7	5.5	7.4	9.2	11.0	12.9	14.7	16.5	18.4
8.00	1.4	2.8	4.2	5.6	7.0	8.4	9.8	11.3	12.7	14.1
9.00	1.1	2.2	3.3	4.4	5.5	6.6	7.7	8.8	10.0	11.1
10.00	0.9	1.8	2.7	3.6	4.5	5.4	6.3	7.2	8.1	9.0

Table 4.9 Generic Thermal Limit Curve Tripping Times From Reset vs. Multiples of Full Load Amps, Curves 15, 20, 25, 30, 35, 40, 45 (Thermal Limit Times in Seconds)

Multiples of Full Load Amps	Curves						
	15	20	25	30	35	40	45
1.01	4670.3	6227.1	7783.9	9340.7	10897.4	12454.2	14011.0
1.10	2082.8	2777.1	3471.3	4165.6	4859.9	5554.1	6248.4
1.15	1678.3	2237.8	2797.2	3356.7	3916.1	4475.6	5035.0
1.20	1410.1	1880.1	2350.1	2820.1	3290.2	3760.2	4230.2
1.30	1065.4	1420.5	1775.6	2130.7	2485.9	2841.0	3196.1
1.40	848.9	1131.9	1414.8	1697.8	1980.8	2263.7	2546.7
1.50	699.1	932.1	1165.1	1398.1	1631.2	1864.2	2097.2
1.70	505.1	673.4	841.8	1010.1	1178.5	1346.8	1515.2
2.00	342.1	456.2	570.2	684.3	798.3	912.4	1026.4
2.50	216.0	288.0	360.0	432.0	504.0	576.0	648.0
3.00	150.0	200.0	250.0	300.0	350.0	400.0	450.0
3.50	110.2	146.9	183.7	220.4	257.1	293.9	330.6
4.00	84.4	112.5	140.6	168.7	196.9	225.0	253.1
4.50	66.7	88.9	111.1	133.3	155.6	177.8	200.0
5.00	54.0	72.0	90.0	108.0	126.0	144.0	162.0
6.00	37.5	50.0	62.5	75.0	87.5	100.0	122.5
7.00	27.6	36.8	45.9	55.1	64.3	73.5	82.7
8.00	21.1	28.1	35.2	42.2	49.2	56.3	63.3
9.00	16.7	22.2	27.8	33.3	38.9	44.4	50.0
10.00	13.5	18.0	22.5	27.0	31.5	36.0	40.5

Thermal Element USER Setting Method

Table 4.10 Thermal Element Configuration Settings, Setting Method = USER (Sheet 1 of 2)

Setting Prompt	Setting Range	Setting Name = Example Setting
Setting Method	Rating, Generic, User, OFF	SETMETH = USER
Full Load Amps	1.00–8.00 A ITAP = 5 A	FLA = 3.66
	0.20–1.60 A ITAP = 1 A	FLA = 0.732
Service Factor	1.01–1.50	SF = 1.25
Time to trip at 1.05 • FLA	1.0–6000.0 s, NP	TTT105 = NP
Time to trip at 1.10 • FLA	1.0–6000.0 s, NP	TTT110 = NP
Time to trip at 1.20 • FLA	1.0–6000.0 s, NP	TTT120 = NP
Time to trip at 1.30 • FLA	1.0–6000.0 s, NP	TTT130 = NP
Time to trip at 1.40 • FLA	1.0–6000.0 s, NP	TTT140 = NP
Time to trip at 1.50 • FLA	1.0–6000.0 s, NP	TTT150 = NP
Time to trip at 1.75 • FLA	1.0–6000.0 s, NP	TTT175 = 625.0
Time to trip at 2.00 • FLA	1.0–6000.0 s	TTT200 = 400.0
Time to trip at 2.25 • FLA	1.0–6000.0 s, NP	TTT225 = NP
Time to trip at 2.50 • FLA	1.0–6000.0 s	TTT250 = 225.0
Time to trip at 2.75 • FLA	1.0–6000.0 s, NP	TTT275 = NP
Time to trip at 3.00 • FLA	1.0–6000.0 s, NP	TTT300 = NP

Table 4.10 Thermal Element Configuration Settings, Setting Method = USER (Sheet 2 of 2)

Setting Prompt	Setting Range	Setting Name = Example Setting
Time to trip at 3.50 • FLA	1.0–6000.0 s, NP	TTT350 = NP
Time to trip at 4.00 • FLA	1.0–6000.0 s, NP	TTT400 = 72.0
Time to trip at 4.50 • FLA	1.0–6000.0 s, NP	TTT450 = 58.0
Time to trip at 5.00 • FLA	1.0–600.0 s, NP	TTT500 = 30.0
Time to trip at 5.50 • FLA	1.0–600.0 s	TTT550 = 25.0
Time to trip at 6.00 • FLA	1.0–600.0 s	TTT600 = 18.1
Time to trip at 6.50 • FLA	1.0–600.0 s	TTT650 = 15.2
Time to trip at 7.00 • FLA	1.0–450.0 s, NP	TTT700 = 13.2
Time to trip at 7.50 • FLA	1.0–400.0 s, NP	TTT750 = NP
Time to trip at 8.00 • FLA	1.0–400.0 s, NP	TTT800 = NP
Time to trip at 8.50 • FLA	1.0–350.0 s, NP	TTT850 = NP
Time to trip at 9.00 • FLA	1.0–300.0 s, NP	TTT900 = NP
Time to trip at 10.00 • FLA	1.0–225.0 s, NP	TTT1000 = NP

When the thermal element setting method is set to USER, the relay allows you to construct a custom motor protection curve using as few as 5 or as many as 25 thermal limit points. The relay requires:

- The Full Load Amps and Service Factor ratings for the motor
- Time to Trip settings at 2.00 and 2.50 times Full Load Amps for overload protection
- Time to Trip settings at 5.50, 6.00, and 6.50 times Full Load Amps for locked rotor protection

If you wish to emulate a manufacturer's specified thermal limit curve, you may enter additional time points along the curve. If you do not wish to enter a time for a point, enter NP. The relay automatically creates a smooth thermal limit curve between the entered time points.

User Method Setting Rules

There are three (3) interdependency rules associated with the Time to Trip settings. The corresponding error messages are:

- User defined curve must be flat or decreasing
- Time to trip must be equal to or greater than 5% of TTTxxx
- Average of TTT550, TTT600, and TTT650 must be equal to or greater than 1% of TTTyyy

All of these error messages are in the firmware. If an interdependency rule is violated the proper error message will be displayed.

For error messages one and two, the interdependency rule is:

The user curve is constrained to be flat or decreasing and to have subsequent points no more than 95% apart (that is, if point $TTT120 = 1000$, then point TTT130 has to be $50 \leq TTT130 \leq 1000$).

For error message three, the interdependency rule is:

The user curve is additionally constrained such that the average LRTCOLD user (average of $5.5 \times \text{FLA}$, $6.0 \times \text{FLA}$, and $6.5 \times \text{FLA}$) is at least 1% of the first entered point.

For $\text{SETHMETH} = \text{USER}$, the SEL-701 firmware calculates $\text{LRTCOLD} = (\text{TTT550} + \text{TTT600} + \text{TTT650})/3$ and then sets $\text{LRTHOT} = \text{LRTCOLD}/1.2$. The “first entered point” is the first setting with a numerical value (settings with the value NP are disregarded).

If out-of-bound values are entered for TTT550, TTT600, and TTT650, the SEL-701 firmware will calculate a trip curve that does NOT pass through those entered points (settings with numerical values) from TTT275 to TTT1000 ($\text{FLA} > 2.5$).

The SEL-701 user curve method is a way of manipulating the Thermal Model to “fit” user-entered values. The user curve method does not discard the Thermal Model and simply implements an overcurrent function. Because of this fact, certain restrictions are placed on what user values are allowed.

Normally, you would use this method only if the motor thermal limit curve includes a discontinuity between the stator limit curve and the locked rotor limit curve, as shown in *Figure 4.3*.




Figure 4.3 3000 HP Example Motor Cold Thermal Limit Curve

EXAMPLE 4.6 Thermal Element User Method Setting

A 4000 V, 3000 HP motor is to be protected using the SEL-701 Relay Thermal Element User Method. The motor data sheet includes the following information:

Rated Horsepower (HP) = 3000 HP
 Rated Voltage (V) = 4000 V
 Rated Full Load Current (A) = 366 A
 Rated Locked Rotor Amps (A) = 2380 A
 Safe Stall Time at 100% Volts
 Cold = 16 seconds
 Hot = 12 seconds
 Service Factor = 1.25

The data sheet also includes the Thermal Limit Curve shown in Figure 4.3.

The discontinuities in the thermal limit curve between the Overload, Acceleration, and Locked Rotor curve sections make this motor ideal for protection using a purpose-built thermal limit curve. The User setting method provides the facility to protect this motor.

By examining the curve, we can find the thermal limit times at various multiples of Full Load Current, as listed in *Table 4.11*. These times map directly to the relay settings shown below the table.

Table 4.11 3000 HP Motor Thermal Limit Times

Multiples of Full Load Current	Thermal Limit Time (Sec.)
1.75	625
2.00	400
2.50	225
4.00	72
4.50	58
5.00	30
5.50	25
6.00	18.1
6.50	15.2
7.00	13.2

Phase current transformers having 500:5 ratios are selected for the application. The SEL-701 Relay settings for the application are calculated as shown below.

Current Transformer Ratio (CTR) = $500/5 = 100$
 CT Secondary Rating (ITAP) = 5
 Full Load Amps (FLA) = $366/100 = 3.66$ A secondary
 Service Factor (SF) = 1.25
 Time to Trip at 1.30 x FLA (TTT130) = NP
 Time to Trip at 1.40 x FLA (TTT140) = NP
 Time to Trip at 1.50 x FLA (TTT150) = NP
 Time to Trip at 1.75 x FLA (TTT175) = 625.0 seconds
 Time to Trip at 2.00 x FLA (TTT200) = 400.0 seconds
 Time to Trip at 2.25 x FLA (TTT225) = NP
 Time to Trip at 2.50 x FLA (TTT250) = 225.0 seconds
 Time to Trip at 2.75 x FLA (TTT275) = NP
 Time to Trip at 3.00 x FLA (TTT300) = NP
 Time to Trip at 3.50 x FLA (TTT350) = NP
 Time to Trip at 4.00 x FLA (TTT400) = 72.0 seconds
 Time to Trip at 4.50 x FLA (TTT450) = 58.0 seconds
 Time to Trip at 5.00 x FLA (TTT500) = 30.0 seconds

Time to Trip at 5.50 x FLA (TTT550) = 25.0 seconds
 Time to Trip at 6.00 x FLA (TTT600) = 18.1 seconds
 Time to Trip at 6.50 x FLA (TTT650) = 15.2 seconds
 Time to Trip at 7.00 x FLA (TTT700) = 13.2 seconds
 Time to Trip at 7.50 x FLA (TTT750) = NP
 Time to Trip at 8.00 x FLA (TTT800) = NP
 Time to Trip at 8.50 x FLA (TTT850) = NP
 Time to Trip at 9.00 x FLA (TTT900) = NP
 Time to Trip at 10.00 x FLA (TTT1000) = NP

The relay neither requests settings for thermal limit times less than the service factor nor does it require that all settings have a time entered. You can enter NP for some points and the relay automatically builds the thermal limit curve between the nearest two specified points. For instance, the relay thermal limit characteristic between 2.5 and 4.0 times Full Load Amps forms a continuous curve between 225 seconds and 72 seconds.

Thermal Capacity Alarm Setting

Table 4.12 Thermal Capacity Alarm Setting

Setting Prompt	Setting Range	Setting Name = Factory Default
Thermal Capacity Alarm Pickup	50%–100%	TCAPU = 90

For all thermal element settings methods, the relay provides a thermal alarm. When the motor thermal capacity used exceeds the Thermal Capacity Alarm Pickup (TCAPU), the relay issues an alarm. The early alarm may allow you to correct the load problem before a thermal trip occurs. The alarm dropout is at 90% of the setting to help avoid occasional chattering.

Thermal Capacity to Start Settings

Table 4.13 Thermal Capacity to Start Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Thermal Capacity Used to Start	20%–100%	TCSTART = 85
Use Learned Starting Thermal Capacity	Y, N	TCLRNNEN = Y

NOTE: When TCSTART is equal to or greater than 90, the available thermal capacity required to start is 99.9%.

The motor tripping and starting functions include supervision to help prevent a thermal trip on a normal start. The relay prevents motor starting until the thermal element has enough available thermal capacity to allow a motor start without tripping. The available thermal capacity required to start is $(100\% - 10\% - \text{TCSTART})$, where the Thermal Capacity Used To Start (TCSTART) setting or the relay can learn a value.

When you use the Use Learned Starting Thermal Capacity function (TCLRNNEN = Y), the relay records the thermal capacity used during the past five starts and uses it in the thermal model in place of the Thermal Capacity Used to Start setting. The relay adds 10% to the largest of the last five starting thermal capacities and requires that the motor thermal model cool enough to permit that start.

EXAMPLE 4.7 Learned Starting Thermal Capacity Calculation

Over the past five starts, a motor has used 24%, 27%, 22%, 25%, and 26% of thermal capacity. The largest thermal capacity to start is 27%. The relay requires that the present thermal capacity drop below 63% (100%-37%) before a new start is allowed.

You can view the present learned thermal capacity to start using the serial port **MOTOR** command or the front-panel Motor Statistics\Average and Peak Data Function (see *Figure 5.29 on page 5.13 in Section 5: Front-Panel Operations*).

Motor Cooling Time Settings

Use the motor manufacturer supplied cooling time or time constant when available. The following cooling time setting calculation method and learned cooling time option are suggested when manufacturer data is not available.

Table 4.14 Motor Cooling Time Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Motor Stopped Cooling Time	180–72000 s	COOLTIME = 259
Use Learned Cooling Time	Y, N	COOLEN = Y

A stopped motor may take longer to cool than a running motor due to reduced airflow or loss of forced coolant. The factory default settings assume that the motor stopped cooling time is twice the motor running cooling time. Based on the setting names, the equation is:

$$\begin{aligned}
 \text{COOLTIME} &= 2 \cdot \left[9 \cdot (\text{LRTCOLD} - \text{LRTHOT}) \cdot \left(\frac{\text{LRA}}{\text{FLA}} \right)^2 \right] \\
 &= 2 \cdot \left[9 \cdot (2.5 - 2.1) \cdot \left(\frac{30.00}{5.00} \right)^2 \right] \\
 &= 259 \text{ s}
 \end{aligned}$$

Equation 4.1

You can take similar steps to calculate the COOLTIME setting for your application. The following rules apply in calculating the COOLTIME setting for each of the setting methods.

Rating Method

LRTCOLD is constrained so that

$$1.1 \cdot \text{LRTHOT} \leq \text{LRTCOLD} \leq 1.5 \cdot \text{LRTHOT}.$$

LRA is constrained such that $2.5 \cdot \text{FLA} \leq \text{LRA} \leq 10 \cdot \text{FLA}$.

Generic Method

The minimum COOLTIME setting is constrained to be

$135 \cdot \text{Curve\#}$ seconds. For example, if Curve #4 is selected, the minimum cooltime is constrained to be 540 seconds.

User Method

LRTCOLD is defined as the average trip time for the trip time values at $5.5 \cdot \text{FLA}$, $6.0 \cdot \text{FLA}$, and $6.5 \cdot \text{FLA}$:

$$\text{LRTCOLD} = \frac{1}{3}(\text{TTT550} + \text{TTT600} + \text{TTT650})$$

$$\text{LRTHOT} = (\text{LRTCOLD}/1.2)$$

$$\text{LRA} = 6 \bullet \text{FLA}$$

The relay allows COOLTIME settings as derived above for all methods. The safety-factor of two used in the default setting can be replaced with a factor equal to or greater than one.

Motor running and stopped cooling times or time constants may be provided by the motor manufacturer. If a time constant is provided, multiply that value by three to calculate the Motor Stopped Cooling Time (COOLTIME) setting.

When the relay is monitoring one or more RTDs in the motor windings and an ambient temperature RTD, the relay can learn the stator cooling time by monitoring the winding temperature when the motor is stopped. If you set Use Learned Cooling Time equal to Y, the relay learns the cooling time over five stops and uses it in the thermal model in place of the Motor Stopped Cooling Time setting.

Overcurrent Elements

Table 4.15 Overcurrent Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Level 1 Phase O/C Pickup	OFF, 0.25–100.00 A ^a	50P1P = OFF
Level 1 Phase O/C Time Delay	0.00–400.00 s	50P1D = 0.60
Level 2 Phase O/C Pickup	OFF, 0.25–100.00 A ^a	50P2P = OFF
Level 2 Phase O/C Time Delay	0.00–400.00 s	50P2D = 0.50
Level 1 Residual O/C Pickup	OFF, 0.25–100.00 A ^a	50G1P = OFF
Level 1 Residual O/C Time Delay	0.00–400.00 s	50G1D = 0.60
Level 2 Residual O/C Pickup	OFF, 0.25–100.00 A ^a	50G2P = OFF
Level 2 Residual O/C Time Delay	0.00–400.00 s	50G2D = 0.50
Level 1 Neutral O/C Pickup	OFF, 0.025–10.000 A ^b	50N1P = 0.500
Level 1 Neutral O/C Time Delay	0.00–400.00 s	50N1D = 0.10
Level 2 Neutral O/C Pickup	OFF, 0.025–10.000 A ^b	50N2P = OFF
Level 2 Neutral O/C Time Delay	0.00–400.00 s	50N2D = 0.50
Negative-Seq. O/C Pickup	OFF, 0.25–100.00 A ^b	50QP = OFF
Negative-Seq. O/C Time Delay	0.10–400.00 s	50QD = 0.60

^a Setting range shown for ITAP = 5 A. Range is 0.05–20.00 A when ITAP = 1 A.

^b Setting range shown for INTAP = 5 A. Range is 0.005–2.000 A when INTAP = 1 A.

Two phase overcurrent elements (50P1 and 50P2) are available (see *Equation B.14 on page B.21 in Appendix B: SELLOGIC Control Equations and Relay Logic*). Their pickup settings (50P1P and 50P2P, respectively) are compared to the magnitude of the maximum phase current. The phase current is normally the output of the cosine filter, but during CT saturation the phase current is the output of a bipolar peak detector filter if the overcurrent element pickup is equal to or greater than eight times the ITAP setting and a harmonic distortion index is high.

When the harmonic distortion index exceeds the fixed threshold that indicates severe CT saturation, the phase overcurrent elements operate on the output of the peak detector filter. When the harmonic distortion index is below the fixed threshold, the phase overcurrent elements operate on the output of the cosine filter.

The cosine filter provides excellent performance in removing dc offset and harmonics. However, the bipolar peak detector filter has the best performance in situations of severe CT saturation when the cosine filter magnitude estimation is significantly degraded. Combining the two filters provides an elegant solution for ensuring dependable phase overcurrent element operation.

The relay offers two types of ground fault detecting overcurrent elements. The neutral overcurrent elements (50N1T and 50N2T) operate using current measured by the IN input. The residual overcurrent elements (50G1T and 50G2T) operate using the sum of the measured phase currents.

When a ground fault CT is connected to the relay IN input, as in *Figure 2.5 on page 2.5 in Section 2: Installation*, use the Level 1 ground overcurrent element to detect motor ground faults. Calculate the pickup setting based on the available ground fault current and the neutral CT ratio.

EXAMPLE 4.8 Ground Fault CT Application

A resistance-grounded transformer limits the current for motor or cable ground faults. The resistor is sized to limit the current to 10 A primary. The three motor leads are passed through the window of a 10:1 CT. The CT secondary is connected to the SEL-701 Relay 1 A IN current input, as shown in *Figure 4.4*. The relay IN input measures 1 A for a motor or cable ground fault. Setting the Level 1 Neutral O/C Pickup (50N1P) equal to 0.5 A with 0.10 second time delay ensures that the element will quickly detect and trip for motor ground faults, but prevent misoperation due to unequal breaker or contactor pole closing times.




Figure 4.4 Ground Fault Currents Using a Window CT

NOTE: Phase CT ratios are typically higher than ground CT ratios. For this reason, the relay sensitivity to motor ground faults is less when IN is connected residually than if IN is connected to the secondary winding of an appropriate ground CT. A separate ground fault detection method should be used if a ground CT is not available in applications where resistance grounding reduces available ground fault current.

When a ground fault CT is not available, either use the 50G residual overcurrent elements or connect the IN input residually, as in *Figure 2.6 on page 2.6 in Section 2: Installation*. Set the Level 1 O/C Pickup between one-half and one-fifth of the full load phase current and set the Level 1 Time Delay equal to 0.2 seconds. Set the Level 2 element more sensitively, but with a longer time delay. The long time delay allows the sensitive Level 2 element to ride through the false residual current that can be caused by phase CT saturation during motor starting.

The relay offers a negative-sequence overcurrent element 50Q to be used in addition to or instead of the 46 Current Unbalance Element to detect phase-to-phase faults, single phasing, and heavy motor unbalance. If 50Q is used, the following setting criteria is recommended:

$$50Q1P = 0.3 \cdot \text{FLA}$$

$$50Q1D = 0.2 \text{ seconds}$$

Jogging Block Elements

Table 4.16 Jogging Block Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Maximum Number of Starts per Hour	OFF, 1–15	MAXSTART = 3
Minimum Time Between Starts	OFF, 1–150 min	TBSDLY = 20

When the protected motor is rated for a specific maximum number of starts per hour or minimum time between starts, set the MAXSTART and TBSDLY settings accordingly. If the relay detects MAXSTART starts within 60 minutes and the motor stops or is tripped, the relay asserts the TRIP output contact to prevent an additional start until 60 minutes after the oldest start. If the motor stops or is tripped within TBSDLY minutes of the last start, the relay asserts the TRIP output contact to prevent a new start until TBSDLY minutes after the most recent start. The relay retains accurate start time data (within ± 5 seconds) through control power cycles.

The relay will maintain the trip signal until enough time passes that the motor can be safely restarted. During the lockout period, the relay will display a countdown time in minutes to the next allowed start if a start is attempted through the relay. The Emergency Restart function overrides both of these limits allowing the motor to be placed back in service in an emergency.

Load-Jam Elements

Table 4.17 Load-Jam Function Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Load Jam Trip Pickup	OFF, 0.5–6.0 pu FLA	LJTPU = 2.0
Load Jam Trip Delay	0.00–400.00 s	LJTDLY = 1.00

When the motor is running, the relay offers load-jam detection. When the motor load jams, stalling the motor, the phase current will increase to near the locked rotor value. When Load Jam Tripping is enabled, if the phase current exceeds the Load Jam Trip Pickup setting for longer than the time delay setting, the relay will trip. Set the Load Jam Trip Pickup greater than the expected normal load current but less than rated locked rotor current. This setting is entered in per unit of the Full Load Amps (FLA) setting.

Load-Loss Elements

Load-Loss Element, No Voltage Option (Relay Models 0701000X and 0701010X)

Table 4.18 Load-Loss Element Settings, No Voltage Option

Setting Prompt	Setting Range	Setting Name = Factory Default
Load Loss Alarm Threshold	OFF, 0.10–1.00 pu FLA	LLAPU = OFF
Load Loss Trip Threshold	0.10–1.00 pu FLA	LLTPU = 0.50
Load Loss Starting Time Delay	0–15000 s	LLSDLY = 0
Load Loss Alarm Time Delay	0.40–400.00 s	LLADLY = 5.00
Load Loss Trip Time Delay	0.40–400.00 s	LLTDLY = 10.00

When the relay is not equipped with optional voltage inputs, the load-loss detection function is dependent on current alone. The relay arms the load-loss detection logic a settable time after the motor starts, as defined by the Load Loss Starting Time Delay setting. Set this delay to allow pumps or compressors to reach normal load. Once armed, the function issues an alarm or trip if phase current drops below the alarm or trip threshold for the specified time delay.

Set the Load Loss Trip and Alarm thresholds greater than the expected motor no load current but less than the minimum current expected when the motor is operating normally. These settings are entered in per unit of the Full Load Amps (FLA) setting.

If you expect the motor to operate at no load normally, disable this function by setting LLAPU equal to OFF. The relay automatically hides the remaining load-loss settings.

Load-Loss Element, Voltage Option Included (Relay Models 0701001X and 0701011X)

Table 4.19 Load-Loss Element Settings, With Voltage Option

Setting Prompt	Setting Range	Setting Name = Factory Default
Load Loss Alarm Threshold	OFF, 30–2000 W ^a	LLAPU = OFF
Load Loss Trip Threshold	30–2000 W ^a	LLTPU = 100
Load Loss Starting Time Delay	0–15000 s	LLSDLY = 0
Load Loss Alarm Time Delay	0.40–400.00 s	LLADLY = 5.00
Load Loss Trip Time Delay	0.40–400.00 s	LLTDLY = 10.00

^a Setting range shown for ITAP = 5 A. Range is 6–400 W when ITAP = 1 A.

When the relay is equipped with optional voltage inputs, the load-loss detection function depends on the power used by the motor. The relay arms the load-loss detection logic a settable time after the motor starts, as defined by the Load Loss Starting Time Delay setting. Set this delay to allow pumps or compressors to reach normal load. Once armed, the function issues an alarm or trip if three-phase power drops below the alarm or trip threshold for the specified time delay. Set the Load Loss Trip and Alarm thresholds greater than the expected motor no load power but less than the minimum power expected when the motor is operating normally.

If you expect the motor to operate at no load normally, disable this function by setting LLAPU equal to OFF. The relay automatically hides the remaining load-loss settings.

Current Unbalance Elements

Table 4.20 Current Unbalance Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Current Unbalance Alarm Pickup	OFF, 2%–80%	46UBA = 15
Current Unbalance Alarm Delay	0.10–400.00 s	46UBAD = 10.00
Current Unbalance Trip Pickup	OFF, 2%–80%	46UBT = 20
Current Unbalance Trip Delay	0.10–400.00 s	46UBTD = 5.00

Unbalanced motor terminal voltages cause unbalanced stator currents to flow in the motor. The negative-sequence current component of the unbalance current causes significant rotor heating. While the SEL-701 Relay motor thermal element models the heating effect of the negative-sequence current, many users desire the additional unbalance and single-phasing protection offered by a current unbalance element.

The SEL-701 Relay calculates percent unbalance current in one of two ways depending on the magnitude of the average current. When the average current, I_{av} , is greater than the motor-rated full load current, the relay calculates percent unbalance:

$$UB\% = 100\% \cdot \frac{|(I_m - I_{av})|}{I_{av}} \quad \text{Equation 4.2}$$

When the average current is less than motor-rated full load current, the relay calculates percent unbalance:

$$UB\% = 100\% \cdot \frac{|(I_m - I_{av})|}{FLA} \quad \text{Equation 4.3}$$

where:

UB% = Current unbalance percentage

I_m = Magnitude of the phase current with the largest deviation from average

I_{av} = Magnitude of the average phase current

FLA = Motor-rated full load current

In either case, the function is disabled if the average phase current magnitude is less than 25% of the Full Load Amps setting.

A 1% voltage unbalance typically causes approximately 6% current unbalance in induction motors. If a 2% voltage unbalance can occur in your location, set the current unbalance alarm greater than 12% to prevent nuisance alarms. A 15% current unbalance alarm pickup setting corresponds to approximately 2.5% voltage unbalance and a 20% current unbalance trip setting corresponds to approximately 3.3% voltage unbalance. A 10-second alarm delay and 5-second trip delay should provide adequate performance in most applications.

Phase Reversal Tripping

NOTE: When the relay is applied with a single voltage input (SINGLEV = Y) phase reversal detection is based on phase current measurement only.

Table 4.21 Phase Reversal Tripping Setting

Setting Prompt	Setting Range	Setting Name = Factory Default
Enable Phase Reversal Tripping	Y, N	E47T = Y

The SEL-701 Relay uses phase currents or phase voltages (if available) to determine that the phase rotation of signals applied to the relay matches the phase rotation setting, PHROT. When you set E47T equal to Y, the relay trips 0.5 seconds after incorrect phase rotation signals are applied to the relay. For relays equipped with current inputs only, the trip will occur approximately 0.5 seconds after the motor start is initiated. When the relay is equipped with voltage inputs, the trip will occur approximately 0.5 seconds after ac voltages are applied to the relay.

To ensure that phase reversal protection is enabled in case PHROT is set wrong, make sure the setting E47T = Y and 47T is in the TRIP equation.

Speed Switch Tripping

NOTE: An SEL-2600 RTD module updates the state of the RTD measurements and contact input about every 0.75 seconds. To account for this update delay, you may wish to set a slightly longer Speed Switch Trip Time Delay when the speed switch contact is monitored by the external module.

Table 4.22 Speed Switch Tripping Time Delay Setting

Setting Prompt	Setting Range	Setting Name = Factory Default
Speed Switch Trip Time Delay	OFF, 0.50–400.00 s	SPDSDLY = OFF

When the motor is equipped with a speed switch, you may wish to provide additional locked rotor protection using the relay speed switch input. When the Speed Switch Trip Time Delay is set, the relay will trip if the speed switch is not closed SPDSDLY seconds after the motor start begins. If you wish to use speed switch tripping, connect the speed switch contacts to relay input IN3 or to the contact input at the SEL-2600 RTD module. The contact input on an SEL-2600 RTD module is the Relay Word bit IN7.

To disable speed switch tripping, set the Speed Switch Trip Time Delay equal to OFF.

Breaker Failure Logic

Table 4.23 Breaker Failure Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Breaker Failure Initiation	Control Equation ^a	BFI = /TRIP
52A Interlock in Breaker Failure Logic	Y, N	52ABF = N
Breaker Failure Delay	0.00–2.00 s	BFD = 0.50

^a Appendix B: SELogic Control Equations and Relay Logic

The SEL-701 Relay provides flexible breaker failure logic. In default breaker failure logic, assertion of Relay Word bit TRIP starts the BFD timer if the sum of the magnitudes of positive- and negative-sequence currents is above $0.02 \cdot ITAP$ (Relay Word bit 50CD asserts). If the current remains above the threshold for BFD delay setting, Relay Word bit BFT will assert. Use the BFT to operate an output relay to trip appropriate backup breakers.

Changing the BFI and/or 52ABF settings can modify the default breaker failure logic.

- Set BFI = /TRIP * !IN2 if input IN2 is manual trip only and breaker failure initiation is not desired when the tripping is caused by this input.
- Set 52ABF = Y if you want the breaker failure logic to detect failure of auxiliary contact 52A to open during the trip operation as defined by the BFI setting.

RTD-Based Protection

When you purchase the SEL-701 Relay with optional RTD inputs, or connect an SEL-2600 RTD module, the relay offers several protection and monitoring functions whose settings are described below.

RTD Configuration Settings

Table 4.24 RTD Configuration Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
RTD Input Option	INT ^a , EXT, NONE	RTDOPT = NONE
Temperature Preference Setting	C, F	TMPREF = F

^a INT is only available in Models 0701010X and 0701011X.

The SEL-701 can monitor temperature using RTD inputs in one of two ways:

- Optional internal RTD inputs
- An SEL-2600 RTD module

When RTDs will not be connected to the relay or to an external module, set the RTD Input Option setting equal to NONE. When RTDs will be connected to internal RTD inputs, set the RTD Input Option setting equal to INT. When monitored RTDs will be connected to the inputs of the external module, set the RTD Input Option setting equal to EXT.

The Temperature Preference Setting allows you to configure the RTD temperature trip and alarm settings and temperature reporting functions in your preferred units: degrees Celsius or degrees Fahrenheit.

The relay automatically hides the Temperature Preference setting and all other settings associated with the RTD inputs if you set RTDOPT equal to NONE.

NOTE: SEL-701 Relays equipped with internal RTD inputs may be connected to monitor the RTD inputs of an SEL-2600 RTD module. The relay will monitor only those inputs enabled by the RTD Input Option setting. It will not monitor both input sets simultaneously.

RTD Location Settings

Table 4.25 RTD Location Settings (Sheet 1 of 2)

Setting Prompt	Setting Range	Setting Name = Factory Default
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD1LOC = BRG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD2LOC = BRG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD3LOC = BRG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD4LOC = BRG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD5LOC = WDG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD6LOC = WDG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD7LOC = WDG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD8LOC = WDG

Table 4.25 RTD Location Settings (Sheet 2 of 2)

Setting Prompt	Setting Range	Setting Name = Factory Default
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD9LOC = WDG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD10LOC = BRG
RTD Location	WDG, BRG, AMB, OTH, NONE	RTD11LOC = AMB
RTD Location ^a	WDG, BRG, AMB, OTH, NONE	RTD12LOC = OTH

^a The twelfth RTD input is only available when you use an SEL-2600 RTD module.

The relay allows you to define the location of each monitored RTD independently using the RTD Location settings.

Define the RTD Location settings using the following suggestions:

- If an RTD is not connected to an input or has failed in place and will not be replaced, set RTD Location for that input equal to NONE.
- For RTDs embedded in motor stator windings, set RTD Location equal to WDG.
- For inputs connected to RTDs measuring bearing race temperature, set RTD Location equal to BRG.
- For the input connected to an RTD measuring ambient motor cooling air temperature, set RTD Location equal to AMB. Only one ambient temperature RTD is allowed.
- For inputs connected to monitor temperatures of other apparatus, set RTD Location equal to OTH.

NOTE: RTD curves in SEL products are based on the IEC/DIN 60751 standard.

RTD Type Settings

Table 4.26 RTD Type Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
RTD Type	PT100, NI100, NI120, CU10	RTD1TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD2TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD3TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD4TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD5TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD6TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD7TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD8TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD9TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD10TY = PT100
RTD Type	PT100, NI100, NI120, CU10	RTD11TY = PT100
RTD Type ^a	PT100, NI100, NI120, CU10	RTD12TY = PT100

^a The twelfth RTD input is only available when you use an SEL-2600 RTD module.

The relay allows you to define the type of each monitored RTD independently using the RTD Type settings.

If an RTD Location setting is equal to NONE, the relay does not request that an RTD Type setting be entered for that input.

The four available RTD types are:

- 100-ohm platinum (PT100)
- 100-ohm nickel (NI100)
- 120-ohm nickel (NI120)
- 10-ohm copper (CU10)

RTD Alarm and Trip Temperatures

Table 4.27 RTD Alarm and Trip Temperature Settings^a

Setting Prompt	Setting Range	Setting Name = Factory Default
RTD Trip Temperature	OFF, 32°–482°F	TRTMP1 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP1 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP2 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP2 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP3 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP3 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP4 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP4 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP5 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP5 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP6 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP6 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP7 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP7 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP8 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP8 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP9 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP9 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP10 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP10 = OFF
RTD Trip Temperature	OFF, 32°–482°F	TRTMP11 = OFF
RTD Alarm Temperature	OFF, 32°–482°F	ALTMP11 = OFF
RTD Trip Temperature ^b	OFF, 32°–482°F	TRTMP12 = OFF
RTD Alarm Temperature ^b	OFF, 32°–482°F	ALTMP12 = OFF
Enable Winding Trip Voting	Y, N	EWNDGV = N
Enable Bearing Trip Voting	Y, N	EBRNGV = N
Enable RTD Biasing	Y, N	RTDBEN = Y

^a When the TEMPREF setting equals C, the trip and alarm temperature setting ranges above are OFF, 0°–250°C.

^b The twelfth RTD input is only available when you use an SEL-2600 RTD module.

The SEL-701 Relay provides temperature alarms and trips using the RTD temperature measurements and the alarm and trip temperature settings in *Table 4.27*. The temperature setting range is dependent on the Temperature Preference setting so you can enter your alarm and trip temperatures in degrees Celsius or degrees Fahrenheit.

The relay issues a winding temperature alarm if any of the healthy winding RTDs (RTD Location setting equals WDG) indicate a temperature greater than its RTD Alarm Temperature setting. The relay issues a winding temperature trip if one or two of the healthy winding RTDs indicate a temperature greater than their RTD Trip Temperature settings. Two winding RTDs must indicate excessive temperature when the Enable Winding Trip Voting setting equals Y. Only one excessive temperature indication is required if Winding Trip Voting is not enabled. Bearing Trip Voting works similarly.

The alarm and trip temperature settings for Bearing, Ambient, and Other RTD types function similarly except that trip voting is not available for Ambient and Other RTDs.

To disable any of the temperature alarm or trip functions, set the appropriate temperature setting to OFF.

Only healthy RTDs can contribute temperatures to the alarm and trip functions. The relay includes specific logic to indicate if RTD, leads are shorted or open.

When you have connected an ambient temperature sensing RTD and set trip temperatures for one or more winding RTDs, the relay gives you the option to enable RTD thermal model biasing. When you enable RTD biasing, the relay:

- Calculates RTD % Thermal Capacity and adds the value to the Thermal Meter values.
- Automatically reduces the winding RTD trip temperatures and thermal element trip threshold if ambient temperature rises above 40°C.
- Provides an RTD Bias Alarm if the winding temperature exceeds 60°C rise over ambient and the RTD % Thermal Capacity exceeds the thermal element % Thermal Capacity by more than 10%.

The relay calculates RTD % Thermal Capacity using *Equation 4.4*:

$$\text{RTD\% Thermal Capacity} = \frac{\left(\text{Winding RTD Temperature} \right) - \left(\text{Ambient Temperature} \right)}{\left(\text{Winding RTD Trip Temperature} \right) - \left(\text{Ambient Temperature} \right)} \cdot 100\%$$

Equation 4.4

As ambient temperature rises, the motor's ability to shed heat to the surroundings is reduced and internal temperatures rise. To preserve insulation life, NEMA standards suggest a 1°C reduction in RTD trip temperature for each 1°C rise in ambient temperature over 40°C. When you enable RTD biasing, the SEL-701 Relay automatically reduces the RTD trip temperatures for all winding RTDs when ambient temperature is above 40°C. The relay reduces the trip temperatures by 1°C for each degree rise in ambient temperature over 40°C.

Finally, when you enable RTD biasing, the relay provides an RTD Bias Alarm when the RTD % Thermal Capacity exceeds the thermal element % Thermal Capacity by more than 10 percentage points while the winding temperature rise is higher than 60°C over ambient. This alarm can be a useful indicator that the motor has lost coolant flow or that the winding RTD trip temperature is conservatively low.

For all the RTD thermal capacity and bias calculations described above, the relay uses the winding RTD whose measured temperature is closest to its trip value.

Table 4.28 lists the RTD resistance versus temperature for the four supported RTD types.

Table 4.28 RTD Resistance versus Temperature

Temp (°F)	Temp (°C)	100 Platinum	120 Nickel	100 Nickel	10 Copper
-58	-50.00	80.31	86.17	74.30	7.10
-40	-40.00	84.27	92.76	79.10	7.49
-22	-30.00	88.22	99.41	84.20	7.88
-4	-20.00	92.16	106.15	89.30	8.26
14	-10.00	96.09	113.00	94.60	8.65
32	0.00	100.00	120.00	100.00	9.04
50	10.00	103.90	127.17	105.60	9.42
68	20.00	107.79	134.52	111.20	9.81
86	30.00	111.67	142.06	117.10	10.19
104	40.00	115.54	149.79	123.00	10.58
122	50.00	119.39	157.74	129.10	10.97
140	60.00	123.24	165.90	135.30	11.35
158	70.00	127.07	174.25	141.70	11.74
176	80.00	130.89	182.84	148.30	12.12
194	90.00	134.70	191.64	154.90	12.51
212	100.00	138.50	200.64	161.80	12.90
230	110.00	142.29	209.85	168.80	13.28
248	120.00	146.06	219.29	176.00	13.67
266	130.00	149.83	228.96	183.30	14.06
284	140.00	153.58	238.85	190.90	14.44
302	150.00	157.32	248.95	198.70	14.83
320	160.00	161.05	259.30	206.60	15.22
338	170.00	164.77	269.91	214.80	15.61
356	180.00	168.47	280.77	223.20	16.00
374	190.00	172.17	291.96	231.80	16.39
392	200.00	175.85	303.46	240.70	16.78
410	210.00	179.15	315.31	249.80	17.17
428	220.00	183.17	327.54	259.20	17.56
446	230.00	186.82	340.14	268.90	17.95
464	240.00	190.45	353.14	278.90	18.34
482	250.00	194.08	366.53	289.10	18.73

Voltage-Based Protection (Relay Models 0701001X and 0701011X)

When you purchase the SEL-701 Relay with optional voltage inputs, the relay enables a number of additional protection functions. The settings for these functions are described below.

Under- and Overvoltage Elements

Phase-to-Phase Under- and Overvoltage Elements

Refer to *Figure B.10* and *Figure B.16* in *Appendix B: SELOGIC Control Equations and Relay Logic* for the Undervoltage Element Logic and Overvoltage Element Logic diagrams, respectively.

Table 4.29 Under- and Overvoltage Settings, Phase-to-Phase Potentials

Setting Prompt	Setting Range	Setting Name = Factory Default
Level 1 Phase-phase U/V Pickup	OFF, 1–300 V	27P1P = 40
Level 2 Phase-phase U/V Pickup	OFF, 1–300 V	27P2P = OFF
Level 1 Phase-phase O/V Pickup	OFF, 1–300 V	59P1P = 73
Level 2 Phase-phase O/V Pickup	OFF, 1–300 V	59P2P = OFF

When you connect the SEL-701 Relay voltage inputs to phase-to-phase connected VTs, as in *Figure 2.6* or *Figure 2.7 on page 2.6 in Section 2: Installation*, the relay provides two levels of phase-to-phase overvoltage and undervoltage elements. You may use these elements for tripping, alarming, or supervision of other conditions through the relay programmable logic described in *Appendix B: SELOGIC Control Equations and Relay Logic*. To disable any of these elements, set the pickup settings equal to OFF. The default 27P1P setting provides undervoltage supervision for the underpower, reactive power, and power factor tripping elements.

Phase-to-Neutral Under- and Overvoltage Elements

Table 4.30 Under- and Overvoltage Settings, Phase-to-Neutral Potentials

Setting Prompt	Setting Range	Setting Name = Factory Default
Level 1 Phase U/V Pickup	OFF, 1–300 V	27P1P = 40
Level 2 Phase U/V Pickup	OFF, 1–300 V	27P2P = OFF
Level 1 Phase O/V Pickup	OFF, 1–300 V	59P1P = 73
Level 2 Phase O/V Pickup	OFF, 1–300 V	59P2P = OFF
Residual O/V Pickup	OFF, 1–300 V	59GP = OFF

When you connect the SEL-701 Relay voltage inputs to phase-to-neutral connected VTs, as in *Figure 2.5* or *Figure 2.8 on page 2.7 in Section 2: Installation*, the relay provides two levels of phase-to-neutral overvoltage and undervoltage elements, plus a residual overvoltage element. The residual overvoltage element operates using the phasor sum of the three phase voltages

and is hidden and disabled if only a single phase-to-neutral VT is connected to the relay. You may use these elements for tripping, alarming, or supervision of other conditions through the relay programmable logic described in *Appendix B: SELOGIC Control Equations and Relay Logic*. To disable any of these elements, set the pickup settings equal to OFF. The default 27P1P setting provides undervoltage supervision for the underpower, reactive power, and power factor tripping elements.

Loss-of-Potential (LOP) Protection

The SEL-701 sets Relay Word bit LOP (loss-of-potential) upon detecting a loss of relay ac voltage input such as that caused by blown potential fuses or by the operation of molded-case circuit breakers. Because accurate relaying potentials are required by certain protection elements (undervoltage 27 elements, for example), you can use the loss-of-potential function to supervise these protection elements.

The relay declares a loss-of-potential when there is more than a 10 percent drop in the measured positive-sequence voltage (V1) with no corresponding magnitude or angle change (above a pre-determined threshold) in positive-sequence (I1), negative-sequence (I2), or zero-sequence currents (I0). If this condition persists for 60 cycles, then the relay latches the LOP Relay Word bit at logical 1. The relay resets LOP when the positive-sequence voltage (V1) returns to a level greater than 50 V while negative-sequence voltage (V2) and zero-sequence voltage (V0) are both less than 5 V secondary.

Settings

The loss-of-potential function has no settings and is always active. You must incorporate the LOP function in a SELOGIC control equation in order to supervise relay protection elements (see *Example 4.9*).

LOP Impact on Other Protection Elements

Undervoltage and directional power elements require accurate relaying potentials for correct operation. It is critical that the relay detects a loss-of-potential condition and prevents operation of these elements. For example, when a technician drops a wrench on the phase-voltage input fuse holders, the relay LOP logic accurately determines that this loss of input voltages is a loss-of-potential condition and does not trip (if the LOP Relay Word bit supervises selected tripping elements, see *Example 4.9*). If you are using voltage-determined relay elements for tripping decisions, then blocking these elements is crucial when the voltage component is no longer valid.


EXAMPLE 4.9 Supervising Voltage-Element Tripping With Loss-of-Potential

Use the loss-of-potential function to supervise undervoltage tripping. If you use the undervoltage trip element 27P1, then change a portion of the Trip equation to the following:

$$\text{TRIP} := \dots + (!\text{LOP} * 27\text{P1}) +$$

LOP Monitoring and Alarms

You should take steps to immediately correct a loss-of-potential problem so that normal protection is rapidly re-established. Include the LOP Relay Word bit in an output contact alarm to notify operation personnel of abnormal voltage input conditions and failures that can be detrimental to the protection system performance if not quickly corrected.



Note: I_{TAP} is 1 A or 5 A depending on the relay setting.
 $V1$, $V2$, and $V0$ are the positive-, negative-, and zero-sequence components of the secondary phase voltages.
 I_1 , I_2 , and I_0 are the positive-, negative-, and zero-sequence components of the secondary phase currents.
 Δ is the change in 1 cycle.

Figure 4.5 Loss-of-Potential (LOP) Logic

Reactive Power (VAR) Elements

Table 4.31 Reactive Power Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Negative VAR Alarm Pickup	OFF, 30–2000 VAR ^a	NVARAP = OFF
Positive VAR Alarm Pickup	30–2000 VAR ^a	PVARAP = 2000
VAR Alarm Time Delay	0.04–400.00 s	VARAD = 0.00
Negative VAR Trip Pickup	OFF, 30–2000 VAR ^a	NVARTP = OFF
Positive VAR Trip Pickup	30–2000 VAR ^a	PVARTP = 2000
VAR Trip Time Delay	0.04–400.00 s	VARTD = 0.00
VAR Element Arming Delay	0–15000 s	VARDLY = 10

^a Setting range shown for ITAP = 5 A. Range is 6–400 VAR when ITAP = 1 A.

When you apply the SEL-701 Relay on a synchronous motor, the VAR Element Arming Delay disarms the reactive power elements for a settable time after the motor starts. This allows the motor to be brought to full speed and the field applied. After the VAR Element Arming Delay expires, the VAR Alarm and VAR Trip elements are enabled. If the positive or negative reactive power exceeds the appropriate threshold for longer than the time delay setting, the relay can issue an alarm or trip signal. The reactive power elements are disabled when the motor is stopped or starting. These elements can be used to detect synchronous motor out-of-step or loss-of-field conditions.

Refer to *Figure 8.1 on page 8.4 in Section 8: Metering and Monitoring* for the relay power measurement convention.

For application on an induction motor, disable the elements by setting both the Negative VAR Alarm Pickup and Negative VAR Trip Pickup settings to OFF.

Underpower Elements

Table 4.32 Underpower Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Phase Underpower Alarm Pickup	OFF, 30–2000 W ^a	37PAP = OFF
Phase Underpower Alarm Time Delay	0.40–400.00 s	37PAD = 0.00
Phase Underpower Trip Pickup	OFF, 30–2000 W ^a	37PTP = OFF
Phase Underpower Trip Time Delay	0.40–400.00 s	37PTD = 0.00
Underpower Element Arming Delay	0–15000 s	37DLY = 10

^a Setting range shown for ITAP = 5 A. Range is 6–400 VAR when ITAP = 1 A.

The SEL-701 Relay Underpower Element Arming Delay disarms the underpower elements for a settable time after the motor starts. This allows the motor to be brought to full load. After the Underpower Element Arming Delay expires, the Phase Underpower Alarm and Phase Underpower Trip elements are enabled. If the real three-phase power falls below the alarm or trip threshold for longer than the time delay setting, the relay can issue an alarm or trip signal. The underpower elements are disabled when the motor is stopped or starting. These elements operate in addition to the Load Loss function and you can use them to detect motor load loss and other underpower conditions.

Disable the elements by setting both the Phase Underpower Alarm Pickup and Phase Underpower Trip Pickup settings to OFF.

Power Factor Elements

Table 4.33 Power Factor Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Power Factor Alarm Leading Pickup	OFF, 0.05–0.99	55LDAP = OFF
Power Factor Alarm Lagging Pickup	0.05–0.99	55LGAP = 0.05
Power Factor Alarm Time Delay	0.00–400.00 s	55AD = 2.50
Power Factor Trip Leading Pickup	OFF, 0.05–0.99	55LDTP = OFF
Power Factor Trip Lagging Pickup	0.05–0.99	55LGTP = 0.05
Power Factor Trip Time Delay	0.00–400.00 s	55TD = 5.00
Power Factor Element Arming Delay	0–15000 s	55DLY = 10

When you apply the SEL-701 Relay on a synchronous motor, the Power Factor Element Arming Delay disarms the power factor elements for a settable time after the motor starts. This allows the motor to be brought to full speed and the field applied. After the Power Factor Element Arming Delay expires, the Power Factor Alarm and Power Factor Trip elements are enabled. If the measured power factor falls below the leading or lagging threshold for longer than the time delay setting, the relay can issue an alarm or trip signal. The power factor elements are disabled when the motor is stopped or starting. These elements can be used to detect synchronous motor out-of-step or loss-of-field conditions. Refer to *Figure 8.1 on page 8.4 in Section 8: Metering and Monitoring* for the relay power measurement convention.

For application on an induction motor, disable the elements by setting both the Power Factor Alarm Leading Pickup and Power Factor Trip Leading Pickup settings to OFF.

Frequency Elements

Table 4.34 Frequency Element Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Level 1 Pickup	OFF, 20.00–70.00 Hz	81D1P = 59.10
Level 1 Time Delay	0.03–400.00 s	81D1D = 0.03
Level 2 Pickup	OFF, 20.00–70.00 Hz	81D1P = OFF
Level 2 Time Delay	0.03–400.00 s	81D1D = 0.03
Level 3 Pickup	OFF, 20.00–70.00 Hz	81D3P = OFF
Level 3 Time Delay	0.03–400.00 s	81D1D = 0.03

The SEL-701 Relay provides three over- or underfrequency elements with independent pickup and time-delay settings. When an element pickup setting is less than the Nominal Frequency setting, the element operates as an underfrequency element. When the pickup setting is greater than the Nominal Frequency setting, the element operates as an overfrequency element.

The relay measures system frequency for these elements using the A-phase voltage. All three elements are disabled if the applied ac voltage magnitude drops below 20 V.

Output Configuration

Analog Output Settings

Table 4.35 Analog Output Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Analog Output Signal Type	0–1mA, 0–20mA, 4–20mA	AOSIG = 4–20mA
Analog Output Parameter	%LOAD_I—Percentage of Full Load Current %THERM— Percentage Thermal Capacity WDG_RTD—Hottest Winding RTD Temperature BRG_RTD—Hottest Bearing RTD Temperature AVG_I—Average Phase Current MAX_I—Maximum Phase Current	AOPARM = %LOAD_I
Analog Output Full Scale Current	0.5–80.0 A ITAP = 5 A 0.1–16.0 A ITAP = 1 A	AOFSC = 5.0

The SEL-701 Relay provides a dc analog current output with three signal ranges and a variety of output parameters. Set the Analog Output Signal Type to select the operating range of dc output current. Select the Analog Output Parameter from the list of available options.

When you select a percentage-type output parameter, the relay automatically scales the output to indicate full scale at 100%. If you select a hottest RTD output parameter, the relay automatically scales the output to indicate full scale at 250°C or 482°F and zero scale at 0°C or 32°F. If you select average or maximum phase current output parameters, the relay requests that you enter your preferred Analog Output Full Scale Current in secondary amps. The

range available depends on whether your nominal secondary current is 5 A or 1 A. The Analog Output Full Scale Current setting is hidden when the Analog Output Parameter is not AVG_I or MAX_I.

Front-Panel Configuration Settings

Table 4.36 Front-Panel Configuration Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Front Panel Power Display	Y, N	FP_KW = N
Front Panel RTD Display	Y, N	FP_RTD = N
Front Panel Timeout	0–30 min	FP_TO = 15
Front Panel Display Brightness	25%, 50%, 75%, 100%	FPBRITE = 50

The relay default front-panel display shows measured phase currents and, if included, phase-to-phase voltage. When the relay is equipped with voltage inputs, the Front-Panel Power Display setting gives you the option to add power quantities to the front-panel default display. When Front-Panel Power Display is equal to Y, the relay displays measured kW, horsepower, kVAR, kVA, power factor, and frequency. When the relay is equipped with internal or external RTD inputs and the Front Panel RTD Display setting equals Y, the relay displays the temperatures of the hottest winding, bearing, and other RTDs, plus the ambient temperature.

Use the Front-Panel Timeout setting as a security measure. If the front-panel interface is inactive for this length of time, the relay automatically blacks out the front-panel display. This function preserves the life of the vacuum fluorescent display. If the display is within an Access Level 2 function such as relay setting entry, the function is automatically terminated without saving changes. If you prefer to disable the front-panel timeout function during relay testing, set Front-Panel Timeout equal to 0 minutes. Do not leave the front-panel timeout setting at 0 minutes while the relay is in service.

The Front-Panel Display Brightness setting adjusts the intensity of the vacuum fluorescent display. If the display dims over a period of years or if the relay will be installed in a brightly lit location, you may wish to increase the Front-Panel Display Brightness setting.

Front-Panel Display Message Settings

Table 4.37 Display Message Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Display Messages	20 characters; enter NA to NULL	DM1_1 = SEL-701 DM1_0 = DM2_1 = MOTOR RELAY DM2_0 = DM3_1 = RTD FAILURE DM3_0 = DM4_1 = TIME BET STARTS LO DM4_0 = DM5_1 = NUM OF STARTS LO DM5_0 = DM6_1 = THERMAL LO DM6_0 =

Output Contact Fail-Safe, Trip Duration, and Starting Lockout Settings

The Display Messages function allows you to monitor a total of 6 logic conditions and display up to 12 different messages, depending on the state of the monitored conditions. When the monitored logic condition is true (logical 1), the relay displays the message entered as the DMn_1 setting in the default display rotation. When the monitored condition is false (logical 0), the relay displays the message entered as the DMn_0 setting in the display rotation.

Display messages are useful for indicating the state of relay contact inputs. Message text can include capital letters A-Z, numbers 0-9, spaces, periods (.), and dashes (-). Type 'NA' to clear a message setting. *Appendix B: SELOGIC Control Equations and Relay Logic* describes the logic used to control display messages.

Table 4.38 Output Contact Fail-Safe, Trip Duration, and Starting Lockout Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Enable TRIP Contact Failsafe	Y, N	TRFS = Y
Enable OUT1 Contact Failsafe	Y, N	OUT1FS = N
Enable OUT2 Contact Failsafe	Y, N	OUT2FS = N
Enable OUT3 Contact Failsafe	Y, N	OUT3FS = N
Minimum Trip Duration Time	0.00–400.00 s	TDURD = 0.50

The SEL-701 Relay allows you to enable fail-safe output contact operation for relay contacts on an individual basis. When contact fail-safe is enabled, the relay output contact is held in its energized position when relay control power is applied and falls to its de-energized position when control power is removed. Output contact de-energized positions are indicated on the relay chassis and in *Figure 2.11 on page 2.10 in Section 2: Installation*.

When TRIP Contact Failsafe is enabled and the TRIP output contact is appropriately connected to the motor breaker or contactor, the motor is automatically tripped when relay control power fails. This setting/connection philosophy is appropriate if the protected motor is more valuable than the process that the motor supports. In critical applications where the protected motor is not more valuable than the process, you may want the motor to run even if the relay is out of service. In this case, disable TRIP Contact Failsafe by selecting N.

The Minimum Trip Duration Time is the minimum amount of time that the relay trip signal will last in the event of a fault. Set this time at least as long as your motor breaker operate time or your motor contactor dropout time. Note that the Trip Duration Time only applies to trips caused by output logic equation **TRIP** and **STOP** commands as shown in *Figure B.7 on page B.13 in Appendix B: SELOGIC Control Equations and Relay Logic*. Include all desired protection elements in the TRIP equation to take advantage of the Trip Duration Time feature. In the event of a thermal element trip or a trip caused by the starts per hour limit or minimum time between starts function, the trip signal will remain until the motor thermal estimate has cooled or time has passed to permit another start.

Antibackspin Setting

Table 4.39 Antibackspin Setting

Setting Prompt	Setting Range	Setting Name = Factory Default
Antibackspin Starting Delay	0–60 min	ABSDLY = 0

In certain pump applications, fluid flowing backward through the pump may spin the pump motor for a short time after the motor is stopped. It is dangerous to attempt to start the motor during this time. To prevent motor starts during the backspin period, enter a time in minutes in the Antibackspin Starting Delay setting. If the relay trips or the motor is stopped, the relay will generate a trip signal and maintain it for at least this amount of time. The relay will not issue a start during the antibackspin period.

The Emergency Restart function overrides the Antibackspin function allowing the motor to be placed back in service in an emergency.

Factory Logic Settings

Table 4.40 Factory Logic Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Use Factory Logic Settings	Y, N	FACTLOG = Y

The SEL-701 Relay includes factory logic settings that generate trip and alarm outputs for the protection elements shown in *Figure 4.6* through *Figure 4.9*. The elements shown in *Figure 4.6* and *Figure 4.7* only cause a trip or alarm if you have enabled them through settings described throughout this section. If the tripping, alarm, and control input logic shown in *Figure 4.6* through *Figure 4.9* are acceptable for your application, set Use Factory Logic Settings equal to Y.

If you do not connect the 52b contact to IN1, as shown in *Figure 4.8*, you must change the factory default logic equation 52A. For example, set $52A = IN1$ if you connect the 52a contact to input IN1. Set $52A = 0$ if you do not connect the breaker auxiliary contact to the relay.

Appendix B: SELOGIC Control Equations and Relay Logic describes powerful, flexible logic that allows you to customize the tripping, input, and output contact performance. If you wish to change the performance shown in *Figure 4.6* through *Figure 4.9*, set Use Factory Logic Settings equal to N. The relay will present additional logic settings that you can modify to customize the relay performance for your application.




Figure 4.6 Factory Tripping Logic




Figure 4.7 Factory Contact Output Logic



Figure 4.8 Factory Contact Input Logic




Figure 4.9 Factory Event Triggering Logic

Serial Port Settings

The SEL-701 Relay provides settings that allow you to configure the communication parameters for the front- and rear-panel serial ports. The front-panel serial port only supports ASCII communications described in detail in *Section 6: ASCII Serial Port Operation*. The rear-panel serial port settings include the Protocol setting. When you set the rear-panel serial port Protocol setting equal to ASCII, the relay supports ASCII commands at the rear-panel EIA-232 port. When you set the rear-panel serial port Protocol setting equal to MOD, the relay supports Modbus® RTU protocol at the rear-panel EIA-485 port and disables the rear-panel EIA-232 port.

Table 4.41 SET P Serial Port Settings, Protocol = ASCII

Setting Prompt	Setting Range	Setting Name = Factory Default
Protocol (shown for rear port only)	ASCII, MOD	PROTO = ASCII
Baud Rate	300–19200	SPEED = 2400
Data Bits	7, 8	BITS = 8
Parity	O, E, N	PARITY = N
Stop Bits	1, 2	STOP = 1
Timeout	0–30 min	T_OUT = 15
Send Auto Messages to Port	Y, N	AUTO = N
Enable Hardware Handshaking	Y, N	RTSCTS = N
Fast Operate Enable	Y, N	FASTOP = N

The SEL-701 Relay front-panel serial port supports EIA-232 communication of ASCII text data and SEL Binary commands and responses. The rear panel is equipped with EIA-232 and EIA-485 serial port connectors. *Table 4.41* shows relay serial port settings for the front-panel port and the rear-panel port

when it is set to use ASCII protocol. Set the Baud Rate, Data Bits, Parity, and Stop Bits settings to match the serial port configuration of the equipment that is communicating with the serial port.

After Timeout minutes of inactivity on a serial port at Access Level 2, the port automatically returns to Access Level 1. This security feature helps prevent unauthorized access to the relay settings if the relay is accidentally left in Access Level 2. If you do not want the port to time out, set Timeout equal to 0 minutes.

If you would like the relay to automatically send text messages to devices connected to the EIA-232 serial port in response to faults and self-test warnings or failures, set Send Auto Messages to Port setting equal to Y. If the serial port will not normally be connected to any device while the relay is in service, set Send Auto Messages to Port setting equal to N.

The relay EIA-232 serial ports support software (XON/XOFF) flow control. If you wish to enable support for hardware (RTS/CTS) flow control, set the Enable Hardware Handshaking setting equal to Y.

The SEL-701 Relay can accept binary commands to operate output contacts, set and clear logic conditions, or start and stop the motor when the Fast Operate Enable setting equals Y. This is a particularly useful function when the relay is connected to an SEL Communications Processor. These binary Fast Operate commands are described in *Appendix D: SEL Communications Processors*.

Table 4.42 SET P Rear-Panel Serial Port Settings, Protocol = MOD

Setting Prompt	Setting Range	Setting Name = Factory Default
Protocol	ASCII, MOD	PROTO = MOD
Baud Rate	300–19200	SPEED = 2400
Parity	O, E, N	PARITY = N
Modbus Slave ID	1–247	SLAVEID = 1

NOTE: The SEL-701 Relay also includes Modbus user map settings that you should define, store, and upload/download using ACSELERATOR QuickSet.

The SEL-701 Relay rear-panel serial port supports Modbus RTU protocol when the Protocol setting equals MOD. Define the Baud Rate and Parity settings to match the requirements of the Modbus master connected to the relay. The Modbus Slave ID must be set with a numeric address that is different from the Slave IDs of the other devices on the Modbus network.

Sequential Events Recorder (SER) Settings

The SEL-701 Relay processes ac and dc inputs four times per power system cycle. During every processing interval, it updates the state of each protection element and logic function. The details of this activity are described in *Appendix B: SELOGIC Control Equations and Relay Logic*. The Sequential Events Recorder (SER) function operates by monitoring a user-defined subset of the protection element results, contact input states, and contact output states. When any of the monitored elements changes state, the relay adds a record to the SER memory. Each record includes the date and time of the state change, the name or alias of the monitored element, and the element's final state. The relay stores the 512 latest records sequentially in nonvolatile memory. You can view the stored information using a PC connected to the front- or rear-panel serial ports.

This instruction manual subsection outlines the SER function settings. The SER settings include settings which trigger entries into the event record and alias settings that allow you to customize the way the recorded data is displayed. *Section 9: Event Analysis* describes the format and contents of the SER reports.

SER Trigger Settings

Table 4.43 SET R SER Trigger Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
SER1	24 Relay Word bits, separated by commas. Use NA to disable setting.	SER1 = IN1, IN2, IN3, IN4, IN5, IN6, IN7
SER2	24 Relay Word bits, separated by commas. Use NA to disable setting.	SER2 = STARTING, RUNNING, STOPPED, JAMTRIP, LOSSALRM, LOSSTRIP, 46UBA, 46UBT, 49A, 49T, 47T, SPEEDSW, SPDSTR, TRIP, OUT1, OUT2, OUT3, 50G1T, 50G2T, 50N1T, 50N2T
SER3	24 Relay Word bits, separated by commas. Use NA to disable setting.	SER3 = RTDFLT, WDGALRM, WDGTRIP, BRGALRM, BRGTRIP, AMBALRM, AMBTRIP, OTHALRM, OTHTRIP, 81D1T, 81D2T, 81D3T, TRGTR, START, 50P1T, 50P2T
SER4	24 Relay Word bits, separated by commas. Use NA to disable setting.	SER4 = ABSLO, TBSLO, NOSLO, THERMLO

The SEL-701 Relay SER function provides four list settings to define the conditions that add records to the SER memory: SER1, SER2, SER3, and SER4. You can set the relay to monitor up to 96 conditions. Each list can contain up to 24 items. Each item must be the name of a Relay Word bit whose definitions are shown in *Table B.4 on page B.17 in Appendix B: SELOGIC Control Equations and Relay Logic*. The factory default SER settings are shown in *Table 4.43*.

For convenience, and because you may not need to make any changes to the factory default settings above, the definitions of the Relay Word bits used in the factory default SER settings are shown in *Table 4.44*.

Table 4.44 Default SER Trigger Setting Relay Word Bits Definitions (Sheet 1 of 2)

Relay Word Bits	Relay Word Bit Definitions
IN1, IN2, IN3, IN4, IN5, IN6, IN7	Represent the state of contact inputs IN1–IN7, respectively. Assert (Logical 1) when the input detects that the contact connected to it is closed. Contact input IN7 is located on an SEL-2600 RTD module.
STARTING, RUNNING, STOPPED JAMTRIP	Represent the states of the protected motor. Load Jam Trip. Asserts when the relay trips in response to a load jam condition, as defined by that function. This Relay Word bit is inactive if the load jam function is disabled.
LOSSALRM, LOSSTRIP	Load Loss Alarm and Load Loss Trip. Assert when the relay issues an alarm or trip in response to a load loss condition, as defined by that function. These Relay Word bits are inactive if the load loss function is disabled.
46UBA, 46UBT	Phase Current Unbalance Alarm (46UBA) and Trip (46UBT). Assert when the relay issues an alarm or trip in response to a current unbalance condition, as defined by that function. These Relay Word bits are inactive if the current unbalance function is disabled.
49A, 49T	Thermal Alarm and Trip. Assert when the relay issues a thermal element alarm or trip due to locked rotor or running overload conditions.

Table 4.44 Default SER Trigger Setting Relay Word Bits Definitions (Sheet 2 of 2)

Relay Word Bits	Relay Word Bit Definitions
47T	Phase Reversal Trip. Asserts when the relay detects a phase reversal condition if phase reversal tripping is enabled by the relay settings.
SPEEDSW, SPDSTR	Speed Switch Input and Trip. SPEEDSW asserts when the speed switch input is asserted. SPDSTR asserts when the relay does not detect a speed switch contact closure within a settable time from the beginning of a motor start if the function is enabled by the relay settings.
TRIP, OUT1, OUT2, OUT3	Represent the states of the contact outputs.
50G1T, 50G2T, 50N1T, 50N2T	Ground Fault. Assert when the relay issues a ground fault trip due to pickup and timeout of a residual (50G1T or 50G2T, sum of phase current inputs) or neutral (50N1T or 50N2T, IN current input) definite-time overcurrent element.
RTDFLT	RTD Fault. Asserts when any enabled RTD is short- or open-circuited, connected with reversed polarity, or if communication with the external RTD module is interrupted. This Relay Word bit is inactive if RTD monitoring is disabled.
WDGALRM, WDGTRIP	Winding RTD Temperature Alarm or Trip. WDGALRM asserts when any healthy motor winding RTD temperature exceeds its settable alarm threshold. WDGTRIP asserts when any one or two healthy motor winding RTD temperatures exceed their settable trip thresholds. Both Relay Word bits are inactive if RTD monitoring is disabled or if no winding RTDs are connected.
BRGALRM, BRGTRIP	Bearing RTD Temperature Alarm or Trip. BRGALRM asserts when any healthy motor bearing RTD temperature exceeds its settable alarm threshold. BRGTRIP asserts when any one or two healthy motor bearing RTD temperatures exceed their settable trip thresholds. Both Relay Word bits are inactive if RTD monitoring is disabled or if no bearing RTDs are connected.
AMBALRM, AMBTRIP	Ambient RTD Temperature Alarm or Trip. AMBALRM asserts when the healthy ambient RTD temperature exceeds its settable alarm threshold. AMBTRIP asserts when the healthy ambient RTD temperature exceeds its settable trip threshold. Both Relay Word bits are inactive if RTD monitoring is disabled or if no ambient temperature RTD is connected.
OTHALRM, OTHTRIP	Other RTD Temperature Alarm or Trip. OTHALRM asserts when any healthy “Other” RTD temperature exceeds its settable alarm threshold. OTHTRIP asserts when any one or two healthy “Other” RTD temperatures exceed their settable trip thresholds. Both Relay Word bits are inactive if RTD monitoring is disabled or if no “Other” RTDs are connected.
81D1T, 81D2T, 81D3T	Level 1, Level 2, and Level 3 Time-Delayed Over/Underfrequency. 81DnT asserts when an over- or underfrequency (depending on the pickup setting) has been detected for the duration of the time-delay setting. All three Relay Word bits are inactive if the relay is not equipped with optional voltage inputs.
START	Motor Start. Asserts when an internal relay function calls for a motor start. A motor start will only occur if a relay output contact is programmed and connected to close the contactor or motor circuit breaker.
50P1T, 50P2T	Phase Fault. Assert when the relay issues a phase fault trip due to pickup and timeout of a phase definite-time overcurrent element.

SER Alias Settings

Table 4.45 SET R SER Enable Alias Settings

Setting Prompt	Setting Range	Setting Name = Factory Default
Enable ALIAS Settings (N, 1–20)	N, 1–20	EALIAS = 20

To simplify your review of the information displayed in the SER record, the relay provides the Alias setting function. Using the Alias settings, you can change the way relay elements listed in the SER settings above are displayed in the SER report. In addition, the Alias settings allow you to change the text

displayed when a particular element is asserted and deasserted. The relay permits up to 20 unique aliases, as defined by the Enable Alias Settings (EALIAS) setting. Factory default alias settings are shown in *Table 4.45*.

Define the enabled alias settings by entering the Relay Word bit name, a space, the desired alias, a space, the text to display when the condition asserts, a space, and the text to display when the condition deasserts.

ALIAS1 = STARTING MOTOR_STARTING BEGINS ENDS

See *Relay Word Bits in Appendix B: SELOGIC Control Equations and Relay Logic* for the complete list of Relay Word bits. Use up to 15 characters to define the alias, asserted text, and deasserted text strings. You can use capital letters (A–Z), numbers (0–9), and the underscore character (_) within each string. Do not attempt to use a space within a string because the relay will interpret a space as the break between two strings. If you wish to clear a string, simply type **NA**.

Table 4.46 SET R SER Alias Settings

Setting Prompt	Relay Word Bit	Alias	Asserted Text	Deasserted Text
ALIAS1 =	STARTING	MOTOR_STARTING	BEGINS	ENDS
ALIAS2 =	RUNNING	MOTOR_RUNNING	BEGINS	ENDS
ALIAS3 =	STOPPED	MOTOR_STOPPED	BEGINS	ENDS
ALIAS4 =	JAMTRIP	LOAD_JAM_TRIP	PICKUP	DROPOUT
ALIAS5 =	LOSSTRIP	LOAD_LOSS_TRIP	PICKUP	DROPOUT
ALIAS6 =	LOSSALRM	LOAD_LOSS_ALARM	PICKUP	DROPOUT
ALIAS7 =	46UBA	UNBALNC_I_ALARM	PICKUP	DROPOUT
ALIAS8 =	46UBT	UNBALNC_I_TRIP	PICKUP	DROPOUT
ALIAS9 =	49A	THERMAL_ALARM	PICKUP	DROPOUT
ALIAS10 =	49T	THERMAL_TRIP	PICKUP	DROPOUT
ALIAS11 =	47T	PHS_REVRSL_TRIP	PICKUP	DROPOUT
ALIAS12 =	SPDSTR	SPEED_SW_TRIP	PICKUP	DROPOUT
ALIAS13 =	IN2	DIRECT_TRIP_IN	PICKUP	DROPOUT
ALIAS14 =	SPEEDSW	SPEED_SW_IN	PICKUP	DROPOUT
ALIAS15 =	IN5	EMERGNCY_RSTART	PICKUP	DROPOUT
ALIAS16 =	IN1	MOTOR_BREAKER	OPEN	CLOSED
ALIAS17 =	IN4	ACCESS2	ALLOWED	PASSWORD_ONLY
ALIAS18 =	TBSLO	TIME_BSTARTS_LO	PICKUP	DROPOUT
ALIAS19 =	NOSLO	NUM_STARTS_LO	PICKUP	DROPOUT
ALIAS20 =	THERMLO	THERMAL_LO	PICKUP	DROPOUT

Section 5

Front-Panel Operations

Front-Panel Layout

The SEL-701 Relay front-panel interface consists of LEDs, a vacuum fluorescent display, a six-button keypad, and an EIA-232 serial port connector. The front-panel layout is shown in *Figure 5.1*.





Figure 5.1 SEL-701 Relay Front Panel

Normal Front-Panel Display

In normal operation, the Relay Enabled LED should be lit. Usually, you will find the front-panel vacuum fluorescent display dark. The relay is equipped with a front-panel timeout setting (see *Front-Panel Configuration Settings in Section 4: Settings Calculations*) that extends the life of the vacuum fluorescent display and improves front-panel security. After a settable period of inactivity, usually 15 minutes, the relay automatically shuts off the display. If the front panel was in Access Level 2, it automatically returns to Access Level 1 when the display times out.

To activate the display, press the **{ESC}** pushbutton.


When the front-panel display is active, the relay can place several screens in a rotation, showing each screen for about two seconds before moving to the next. The default meter screen, shown in *Figure 5.2*, includes the phase current and maximum phase-to-phase voltage magnitudes. If the relay is equipped with optional voltage and/or RTD inputs, you can enable the relay to add real and reactive power, power factor, and frequency meter screens and/or the temperatures of the hottest RTDs to the default rotation.



IA=	10.8	IB=	10.8
IC=	10.9	V=	481V

Figure 5.2 Default Meter Display Screen

The relay automatically displays custom text messages in rotation with the meter screens. The factory default settings define three display messages. Two of these messages are always included in the default display rotation and are shown in *Figure 5.3*. The third is only shown if an RTD failure is detected.



SEL-701
MOTOR RELAY

Figure 5.3 Default Display Message Screen

Control the contents of these custom messages using the Display Message settings, described in *Front-Panel Display Message Settings in Section 4: Settings Calculations*. If you wish to change the conditions under which the relay displays a message, refer to *Appendix B: SELOGIC Control Equations and Relay Logic*.

Front-Panel Automatic Messages

The relay displays automatic messages under the conditions described in *Table 5.1*.

Table 5.1 Front-Panel Automatic Message

Condition	Front-Panel Message Shows
Motor Running Overloaded	Predicted time to thermal element trip, in seconds
Relay Trip Has Occurred	Type or cause of the trip (See <i>Section 9: Event Analysis</i> for more information.)
Relay Self-Test Failure Has Occurred	Type of failure (See <i>Section 10: Maintenance and Troubleshooting</i> for more information.)
Attempted Motor Start Was Blocked or Escape Button Was Pressed While in Lockout Condition.	Reason for the lockout and time until a start is allowed

Front-Panel Menus and Operations

Introduction

The SEL-701 Relay front panel gives you access to most of the information that the relay measures and stores. You can also use front-panel controls to start or stop the motor, pulse output contacts, and view or modify relay settings.

All of the front-panel functions are accessible using the six-button keypad and vacuum fluorescent display. Use the keypad, shown in *Figure 5.4*, to maneuver within the front-panel menu structure, described in detail throughout the remainder of this section.










Figure 5.4 Front-Panel Pushbuttons

Table 5.2 describes the function of each front-panel button.

Table 5.2 Front-Panel Pushbutton Functions

Button	Function
	Move up within a menu or data list. While editing a setting value, increases the value of the underlined digit.
	Move down within a menu or data list. While editing a setting value, decreases the value of the underlined digit.
	Move the cursor to the left. While viewing History Data, moves to data for a newer event.
	Move the cursor to the right. While viewing History Data, moves to data for an older event.
	Wake up the front-panel display. Escape from current menu or display. Accept password displayed and proceed with protected action.
	Move from default display to main menu. Select menu item at the cursor. Select displayed setting to edit setting.

Front-Panel Security

Front-Panel Access Levels

The relay front panel typically operates at Access Level 1 and allows any user to view relay measurements and settings. Some activities such as editing settings and controlling output contacts are restricted to those relay operators who know the relay Access Level 2 password or can assert the ACCESS2 input (factory programmed to input IN4). In the figures that follow, restricted activities are marked with the padlock symbol shown in *Figure 5.5*.



Figure 5.5 Access Level Security Padlock Symbol

Before you can perform a front-panel menu activity that is marked with the padlock symbol, you must enter the correct Access Level 2 password once or assert input IN4. After you have correctly entered the password, you can perform other Access Level 2 activities without reentering the password. The relay will not request the password again until after the front-panel inactivity timer expires. (See *Output Configuration in Section 4: Settings Calculations*.)

Access Level 2 Password Entry

When you try to perform an Access Level 2 activity, the relay determines whether you have entered the correct Access Level 2 password since the front-panel inactivity timer expired. If you have not, the relay displays the screen shown in *Figure 5.6* for you to enter the password.



Figure 5.6 Password Entry Screen

To Enter The Password

NOTE: Use these steps to enter the correct password, to execute an Access level 2 function, or to change the Access Level 2 password, as described in Figure 5.20 on page 5.11.

- Step 1. Press the **{Down Arrow}** pushbutton. A blinking cursor will appear in the first character position of the password and an underline will appear beneath the A character in the lower line of the display.
- Step 2. Underline the first character of the password by moving through the characters shown in *Figure 5.6*. Use the **{Left Arrow}** and **{Right Arrow}** pushbuttons to move the underline to the left and right and the **{Up Arrow}** and **{Down Arrow}** pushbuttons to move to other character rows.
- Step 3. With the correct first character underlined, press the **{ENTER}** pushbutton. The first character will appear in the upper line of the display and the blinking cursor will move one character to the right.
- Step 4. Using the arrow pushbuttons, continue to move within the character table and select each of the characters to build the Access Level 2 password.
- Step 5. With the correct Access Level 2 password spelled in the upper line of the display, press the **{ESC}** pushbutton to move the cursor from the lower line of the display. Press the **{ENTER}** pushbutton to accept the password shown in the upper line of the display. If the password is correct, the relay displays the message “Level 2 Access Granted.” Press the **{ENTER}** pushbutton to continue your task. If the password is incorrect, the relay displays the message “Invalid Password.” Press the **{ENTER}** pushbutton to return to your previous task.

NOTE: The factory default Access Level 2 password is 701.

To Correct Entry Errors

- Step 1. If the cursor in the upper line of the display is blinking, press the **{ESC}** pushbutton once.
- Step 2. Use the **{Left Arrow}** or **{Right Arrow}** pushbutton to move the underline cursor to the position of the incorrect letter.

- Step 3. With the incorrect letter underlined, press the **{Down Arrow}** pushbutton. The blinking cursor will reappear in the upper line of the display and the underline cursor will appear in the lower line.
- To substitute a new character in the location of the blinking cursor, use the arrow pushbuttons to move the underline cursor to the location of the desired character in the character table and press the **{ENTER}** pushbutton.
 - To insert a character in front of the blinking cursor, use the arrow pushbuttons to move the underline cursor to INS and press the **{ENTER}** pushbutton. Use the arrow pushbuttons to move the underline to the desired character in the character table and press the **{ENTER}** pushbutton.
 - To delete the character at the blinking cursor, use the arrow pushbuttons to move the underline cursor to DEL and press the **{ENTER}** pushbutton.
 - To clear the entire password and start over, use the arrow pushbuttons to move the underline cursor to CLR and press the **{ENTER}** pushbutton.
- Step 4. Continue making corrections until the password appears in the upper line of the display. With the correct Access Level 2 password spelled in the upper line of the display, press the **{ESC}** pushbutton to move the cursor from the lower line of the display. Press the **{ENTER}** pushbutton to accept the password shown in the upper line of the display. If the password is correct, the relay displays the message: “Level 2 Access Granted.” Press the **{ENTER}** pushbutton to continue your task. If the password was incorrect, the relay displays the message “Invalid Password.” Press the **{ENTER}** pushbutton to return to your previous task.

Front-Panel Main Menu

All access to information and relay settings through the front panel starts at the relay Main Menu. The remainder of this section describes the use of the main and lower level menus.




Figure 5.7 Activate Front-Panel Display




Figure 5.8 Front-Panel Main Menu




Figure 5.9 Main Menu: Start Motor Function




Figure 5.10 Main Menu: Emergency Restart Function




Figure 5.11 Main Menu: Stop Motor Function




Figure 5.12 Main Menu: Reset Trip and Targets Function




Figure 5.13 Main Menu: Set Relay Function




Figure 5.14 Set Relay/Relay Elements Function

NOTE: Within the list of setting categories, press the **(ENTER)** pushbutton to view or change specific settings within the category. To edit a setting, press the **(ENTER)** pushbutton while the setting is displayed. The relay requires Level 2 Access to edit settings.




Figure 5.15 Set Relay/SER Setting Categories




Figure 5.16 Set Relay/Front Serial Port Settings




Figure 5.17 Set Relay/Rear Serial Port Settings




Figure 5.18 Set Relay/Date Function




Figure 5.19 Set Relay/Time Function




Figure 5.20 Set Relay/Password Function

NOTE: Edit the Access Level 2 password using the steps described in Access Level 2 Password Entry on page 5.4 for password entry. Remember that the relay password is case sensitive. To disable Access Level 2 password protection, set Password = DISABLE.




Figure 5.21 Main Menu: Meter Values Function

The Meter Values menu includes functions to display and reset meter data. Display functions are Instantaneous Meter, Thermal and RTD Data, Demand Meter, Energy Meter, and Maximum/Minimum Meter. Reset functions are Reset Demands, Reset Demand Peaks, Reset Energy, and Reset Maximum/Minimum. When you select a display function such as Instantaneous Meter in *Figure 5.22*, the relay displays a list of meter values you can move through using the {Up Arrow} and {Down Arrow} pushbuttons. When you select a reset function such as Reset Demand Peaks in *Figure 5.23*, the relay displays a confirmation message. If you select yes, the relay resets the indicated meter values.




Figure 5.22 Meter Values Display Functions




Figure 5.23 Meter Values Reset Functions




Figure 5.24 Main Menu: History Data Function




Figure 5.25 History Data/Display History Function




Figure 5.26 History Data/Clear History Function




Figure 5.27 Main Menu: Motor Statistics Function




Figure 5.28 Motor Statistics/Motor Use Data Function




Figure 5.29 Motor Statistics/Average and Peak Data Function




Figure 5.30 Motor Statistics/Trip and Alarm Data Function




Figure 5.31 Motor Statistics/Reset Statistics Function




Figure 5.32 Main Menu: Status of Relay Function




Figure 5.33 Main Menu: View Relay Word Function




Figure 5.34 Main Menu: Pulse Out Contact Function




Figure 5.35 Pulse Output Contact Menu Function




Figure 5.36 Main Menu: Reset Thermal Model Function




Figure 5.37 Main Menu: Reset Learned Param Function




Figure 5.38 Reset Learned Param/Reset Cooling Time Function




Figure 5.39 Reset Learned Param/Reset Start Therm Cap Function

Section 6

ASCII Serial Port Operation

Introduction

You can interact with the SEL-701 Relay through the front-panel interface or the serial port interface. This section describes the connections and commands used with the serial port interface; the front-panel interface is discussed in *Section 5: Front-Panel Operations*.

The serial port interface provides an efficient way to transfer relay settings using the ACSELERATOR QuickSet® SEL-5030 Software. The serial port also provides the only way to retrieve some of the extensive data that the relay stores. Use a PC connected to the relay front-panel serial port to download the following information:

- Load Profile data
- Motor Start reports
- Motor Start Trend reports
- 15-Cycle Event Reports for fault and oscillographic analysis
- Sequential Events Recorder (SER) reports for fault analysis

The first three of these items are described in *Section 8: Metering and Monitoring*; the last two are discussed in *Section 9: Event Analysis*.

You Will Need...

To connect a PC serial port to the relay front-panel serial port and enter relay commands, you will need the following:

- Personal computer equipped with one available EIA-232 serial port
- Communication cable to connect the computer serial port to the relay serial port
- Terminal emulation software to control the computer serial port
- SEL-701 Relay

On most newer computers, the connector for the EIA-232 serial port is a 9-pin D-sub connector. You can purchase the cable to connect the computer port to the relay port from SEL (part number C234A), you can use a null-modem cable, or you can build your own cable using the pinouts shown in *Figure 6.1*.


You can use a variety of terminal emulation programs on your personal computer to communicate with the SEL-701 Relay. The ACSELERATOR QuickSet® SEL-5030 Software also includes a terminal emulation function. If you use this package, no additional software is necessary.

Connect Your PC to the Relay

Connect your PC serial port to the SEL-701 Relay serial port using a cable having the pinout shown in *Figure 6.1* or a null-modem cable. This and other cables are available from SEL. Use SEL-5801 Cable SELECTOR software to select an appropriate cable for another application. This software is available for download free from the SEL web site at www.selinc.com.

NOTE: If you use a null-modem cable connection to the relay EIA-232 serial port, be aware that the relay does not use the DTR and DSR signals. If your communication device requires these signals, please use a cable wired as shown in Figure 6.1.

For best performance, SEL Cable C234A should not be more than 50 feet (15 meters) long. For communications up to 500 meters and for electrical isolation of communications ports, use the SEL-2800 family of fiber-optic transceivers. Contact SEL for more details on these devices.



*DTE = Data Terminal Equipment (Computer, Terminal, etc.)

Figure 6.1 Cable C234A Pinout

Female Chassis Connector, as Viewed From Outside Panel




Figure 6.2 DB-9 Connector Pinout for EIA-232 Serial Ports

Table 6.1 Pin Functions and Definitions for the SEL-701 Relay EIA-232 Serial Ports

Pin	Pin Function	Definition
1, 4, 6	N/C	No Connection
2	RXD, RX	Receive Data
3	TXD, TX	Transmit Data
5, 9	GND	Ground
	SHLD	Shield Ground
7	RTS	Request to Send
8	CTS	Clear to Send

Configure Your Terminal Emulation Software

Personal computers use terminal emulation software to send and interpret received characters at the EIA-232 serial port. This software allows you to type letters and numbers to form commands at the computer keyboard, and to see the characters you type and the relay responses on the computer screen. In order for the PC to communicate correctly with the relay, you must configure the terminal emulation software connection properties to match the relay serial port configuration.

Configure your terminal emulation software to match the default settings shown in *Table 6.2*. For the best display, use VT-100 terminal emulation. If VT-100 is not available, WYSE-100 and ANSI terminal emulations also work.

Table 6.2 SEL-701 Relay Serial Communication Default Settings

Setting	Default
Baud Rate	2400
Data Bits	8
Parity	N
Stop Bits	1
Flow Control	XON/XOFF (software flow control)

To change the port settings, use the front-panel Set Relay\Front Serial Port or Rear Serial Port settings menu item.

Using Terminal Commands

When you type commands at the terminal emulation screen, you can type in either the entire command or just use the first three letters. For example, the commands **EVENT 1 <Enter>** and **EVE 1 <Enter>** both cause the relay to display the most recent full length event report. You may use upper- and lower-case characters to type in commands; however, Access Level 2 Password entry is case sensitive. *Table 6.4* lists all the user commands the relay accepts at the EIA-232 serial ports.

The relay serial ports use software flow control, meaning that character transmission is controlled by receipt of XON and XOFF characters. When the relay receives XOFF during transmission, it pauses until it receives an XON

character. If there is no message in progress when the relay receives XOFF, it blocks transmission of any message presented to its buffer. Messages will be accepted after the relay receives XON.

You can send control characters from most keyboards using the keystrokes listed in *Table 6.3*.

Table 6.3 Serial Port Control Characters

Control Characters	Key Commands	Key Command Instructions
XON	<Ctrl+Q>	Hold down the Control key and press Q.
XOFF	<Ctrl+S>	Hold down the Control key and press S.
CAN	<Ctrl+X>	Hold down the Control key and press X.

You can use the XOFF character to pause in the middle of long transmissions from the relay, such as event reports and SER reports. To resume the transmission use the XON character. To cancel a transmission in progress, use the <Ctrl+X> keystrokes.

Serial Port Access Levels

The available serial port commands are listed in *Table 6.4*. Some commands are not available at Access Level 1 for security reasons. All commands are available at Access Level 2.

Access Level 1

Access Level 1 is the lowest access level. The relay serial ports are initially in Access Level 1 when you energize the relay. If left in Access Level 2, serial ports automatically return to Access Level 1 after a settable inactivity period. When the relay is in Access Level 1, the relay sends the following prompt when you press <Enter> or after a command response is finished:

```
=>
```

The Access Level 1 commands primarily allow the user to look at information (such as settings and metering) but not to change it.

Access Level 2

The Access Level 2 commands primarily allow the user to change relay settings, reset data buffers, and control relay outputs. If left in Access Level 2, serial ports automatically return to Access Level 1 after a settable inactivity period. All Access Level 1 commands are also available in Access Level 2.

When the relay is in Access Level 2, the relay sends the following prompt when you press <Enter> or after a command response is finished:

```
=>>
```

Access Level C

The CAL access level is intended for use by the SEL factory and for use by SEL field service personnel to help diagnose troublesome installations. A list of commands available at the CAL level is available from SEL upon request. Do not enter the CAL access level except as directed by SEL.

The **CAL** command allows the relay to go to Access Level C . Enter the **CAL** command at the Access Level 2 prompt:

```
=>>CAL <Enter>
```

Command Summary

Table 6.4 lists the serial port commands associated with particular activities. All Access Level 1 commands are also available in Access Level 2. The commands are shown in upper-case letters, but can also be entered with lower-case letters. Access Level C (restricted access level) should be used under the direction of SEL only.

Table 6.4 SEL-701 Serial Port Command Summary(Sheet 1 of 2)

Access Level	Serial Port Command	Command Description	Page Number
Serial Port Access Commands			
1	HELP	Display available commands	6.7
1	2ACCESS	Go to Access Level 2	6.4
2	ACCESS	Go to Access Level 1	6.4
2	CAL	Go to Access Level CAL	6.4
2	PASSWORD	View/change password	6.14
2	QUIT	Go to Access Level 1	6.15
Relay Self-Test Status Commands			
1	STATUS	Display relay self-test status	6.18
2	STATUS R	Clear self-test status and restart relay	6.18
Relay Clock/Calendar Commands			
1	DATE	View/change date	6.8
1	TIME	View/change time	6.20
Meter Data Commands			
1	METER	Display metering data	6.10
1	METER D	Display demand and peak demand data	6.11
1	METER E	Display energy metering data	6.11
1	METER M	Display max/min metering data	6.11
1	METER T	Display thermal metering data	6.12
1	METER RD	Reset demand ammeter	6.12
1	METER RE	Reset energy metering	6.12
1	METER RM	Reset max/min metering	6.13
1	METER RP	Reset peak demand ammeter	6.13
Event Analysis Commands			
1	EVENT	View event reports	6.9
1	HISTORY	View event summaries/histories	6.9
2	HISTORY R	Reset event history data	6.9
1	SER	View sequential events recorder data	6.15
2	SER R	Reset sequential events recorder data	6.15

Table 6.4 SEL-701 Serial Port Command Summary(Sheet 2 of 2)

Access Level	Serial Port Command	Command Description	Page Number
1	TARGET	Display relay element status	6.19
1	TARGET R	Reset target LEDs	6.20
1	TRIGGER	Trigger an event report	6.20
Motor Data Commands			
1	LDP	Display load profile data	6.10
1	LDP D	Display load profile buffer size	6.10
2	LDP R	Reset load profile data	6.10
1	MOTOR	Display motor statistics	6.13
2	MOTOR R	Reset motor statistics	6.13
1	MSR	Display motor start reports	6.13
1	MSR F	Display the format of a motor start report	6.13
1	MST	Display motor start trend data	6.13
2	MST R	Reset motor start trend data	6.13
2	RLP	Reset learned motor parameters	6.15
Relay Setting Commands			
1	SHOW	Show/view relay settings	6.16
2	SET	Enter/change relay settings	6.15
Relay Output Control Commands			
2	ANALOG	Test analog output	6.8
2	CON	Control remote bit	6.8
2	PUL	Pulse output contact	6.14
2	STOP	Stop motor	6.19
2	STR	Start motor	6.19

The serial port command explanations that follow in the *Command Explanations* subsection are in alphabetical order.

Command Explanations

Each command explanation lists:

- The command
- The serial port access levels where the command is available, in parentheses
- An explanation of the command use or response

For example, you can execute the **HELP** command, below, from serial port Access Level 1 or 2.

HELP (Level 1 or 2)

Use the **HELP** command to display the available serial port commands. For more details regarding a particular command, type **HELP CMD**, where **CMD** is the name of the command you are interested in. *Figure 6.3* shows an example **HELP** command response.

```
=>HELP
Relay Serial Port Commands:
Command (Access Level) Description
HELP cmd (1 or 2) View more detailed help for the command cmd
2ACCESS (1 or 2) Change to Access Level 2
ACCESS (1 or 2) Change to Access Level 1
ANA p t (2) Output an analog value of p% for t minutes (1 - 10)
ANA R t (2) Ramp the analog output over t minutes (1 - 10)
CONTROL n (2) Set, clear, or pulse Relay Word bit RBn (1 - 4)
DATE (1 or 2) View or change the date
EVENT n (1 or 2) View full-length event report n (1 - 14)
HISTORY (1 or 2) View the event summary reports
HISTORY R (2) Reset the event buffer
LDP (1 or 2) View load profile data
LDP D (1 or 2) View load profile buffer size, days remaining
LDP R (2) Reset load profile data
METER (1 or 2) View/reset relay measured quantities
MOTOR (1 or 2) View the motor operating statistics
MOTOR R (2) Reset the motor operating statistics
MSR n (1 or 2) View motor start report n (1 - 5)
MST (1 or 2) View motor start trending data
MST R (2) Reset the motor start trend data
PASSWORD (2) View/change the relay passwords
PULSE n k (2) Pulse output contact n for k minutes (1 - 30)
QUIT (1 or 2) Change to Access Level 1
RLP (2) Reset learned motor parameters
SER (1 or 2) View sequential events records
SER R (2) Reset the sequential events buffer
SET (2) Set the relay
SHOW (1 or 2) View the relay settings
STATUS (1 or 2) View the relay self-test status
STATUS R (2) Reset relay self-test warning or failure
STOP (2) Stop the motor
STR (2) Start the motor
TARGET (1 or 2) View the status of relay elements, inputs, or outputs
TARGET R (1 or 2) Reset trip/target LEDs
TIME (1 or 2) View or change the time
TRIGGER (1 or 2) Trigger an event report
=>
```

Figure 6.3 HELP Command Response

ACC and 2AC (Go to Access Level 1 or 2)

The **ACC** and **2AC** commands provide entry to the multiple access levels. Different commands are available at the different access levels as shown in *Table 6.4*. Commands **ACC** and **2AC** are explained together because they operate similarly.

- **ACC** moves from Access Level 2 to Access Level 1
- **2AC** moves from Access Level 1 to Access Level 2

See *PASSWORD (Level 2)* on page 6.14 for more information on passwords. The factory default password for Access Level 2 is 701.

The relay closes the **ALARM** b-contact for one second after a successful Level 2 access. If you make three incorrect password guesses, access is denied and the **ALARM** contact closes for one second. *Figure 6.4* shows an example **2AC** command execution.

```
=>2AC
Password: ? 701@@@
SEL-701 Date: 08/27/1999 Time: 11:01:59.467
MOTOR RELAY

Level 2
=>>
```

Figure 6.4 2AC Command Example

ANALOG (Level 2)

Use the **ANALOG p t** command to test the relay analog current output. When you use the **ANALOG** command, the relay ends normal analog current output and sends a signal defined by the percentage value, $p = 0\% - 100\%$ for t minutes ($t = 1 - 10$ minutes). For example, when the analog output signal type is 4–20 mA, the command **ANA 75 5.5** instructs the relay to output 16 mA (75% of full scale) for 5.5 minutes or until any character or space key is pressed to end the test. *Figure 6.5* shows an example **ANA** command execution.

```
=>>ANA 75 5.5
Outputing 16.00mA to Analog Output Port for 5.5 minutes.
Press any key to end test
Analog Output Port Test Completed.
=>>
```

Figure 6.5 ANA Command Example

You can also use the **ANALOG** command to generate a current signal that increases linearly. Replace the fixed percentage value with an **R** to ramp the signal from zero to full scale over time. For example, the command **ANA R 10** instructs the relay to ramp the analog signal from zero to full scale, reaching full scale in ten minutes. As above, you can stop the test by pressing any keyboard character key or the space bar.

CONTROL (Level 2)

The **CONTROL** command is a two-step command that allows you to control Relay Word bits RB1 through RB4. At the Access Level 2 prompt, type **CON**, a space, and the number of the remote bit you wish to control (1–4). The relay repeats your command followed by a colon. At the colon, type the Control subcommand you wish to perform (see *Table 6.5*).

Table 6.5 SEL-701 Relay Control Subcommands

Subcommand	Description
SRB n	Set Remote Bit n (“ON” position)
CRB n	Clear Remote Bit n (“OFF” position)
PRB n	Pulse Remote Bit n for 1/4 cycle (“MOMENTARY” position)

The following example shows the steps necessary to pulse Remote Bit 4 (RB4):

```
=>>CON 4 <Enter>
CONTROL RB4: PRB 4 <Enter>
=>>
```

You must enter the same remote bit number in both steps in the command. If the bit numbers do not match, the relay responds “Invalid Command.” See *Remote Control Switches in Appendix B: SELOGIC Control Equations and Relay Logic* for more information.

DATE (Level 1 or 2)

DATE displays the date stored by the internal calendar/clock. If the date format setting **DATE_F** is set to MDY, the date is displayed as month/day/year. If the date format setting is set to YMD, the date is displayed as year/month/day.

To set the date, type **DATE mm/dd/yyyy <Enter>** if the Date Format setting is MDY. If the Date Format setting is set to YMD, type **DATE yyyy/mm/dd <Enter>**. You can separate the month, day, and year parameters with spaces, commas, slashes, colons, or semicolons. *Figure 6.6* shows an example **DATE** command execution, changing the date to September 1, 1999.

```
=>>DATE 09/01/99
09/01/1999
=>>
```

Figure 6.6 DATE Command Example

EVENT (Level 1 or 2)

Use the **EVENT** command to view event reports. The general command format is listed in *Table 6.6*.

Table 6.6 Event Commands

Event n R	
where:	
n	Event number (1–14). Defaults to 1 if not listed, where 1 is the most recent event.
R	Specifies the unfiltered (raw) event report. Displays 16 samples per cycle.

Table 6.7 lists example **EVE** commands. If you request an event report that does not exist, the relay responds “Invalid Event.” See *Example Event Report in Section 9: Event Analysis* for an example event report.

Table 6.7 EVE Command Examples

Serial Port Command	Description
EVE	Display the most recent event report at 1/4-cycle resolution.
EVE 2	Display the second event report at 1/4-cycle resolution.
EVE R	Display the most recent report at 1/16-cycle resolution; analog data are not digitally filtered (raw).

HISTORY (Level 1 or 2)

HISTORY n displays event summaries. If no parameters are specified with the **HISTORY** command, the relay displays up to 14 of the most recent event summaries in reverse chronological order. If *n* is a number (1–14), the relay displays the *n* most recent event summaries. The relay saves up to fourteen 15-cycle event reports. For more details on the information included in the relay event summaries, see *Section 9: Event Analysis*. *Figure 6.7* shows an example **HISTORY** command response.

```
=>HIS 1
SEL-701                               Date: 07/07/1999   Time: 15:51:24.365
MOTOR RELAY
Event: UNBALANCED CURRENT
Event #: 1
Event Date: 07/07/1999
Event Time: 14:39:47.907
Frequency (Hz):      60.00
% Thermal Capacity:  69.0
% Unbalance Current: 15.3
Currents (A):         IA      IB      IC      IN      IG      3I2
                    259.7    191.6    190.6     0.1    68.2    69.0
                    Winding  Bearing  Ambient  Other
Hottest RTD (F):     150      112      78      NA
Voltages (V):         VAB      VBC      VCA
                    458      460      457
Power:                kW      kVAR      kVA      PF
                    163.8    44.1    169.6    0.97 LAG
=>
```

Figure 6.7 HISTORY Command Example

HISTORY R (Level 2)

HISTORY R removes the event summaries and all corresponding event reports from nonvolatile memory.

LDP (Level 1 or 2)

Use the **LDP** (Load Profile) command to view information stored by the relay Load Profile function described in detail in *Section 8: Metering and Monitoring*. Each load profile entry is stored with a record number, a date, and a time. You can access load profile data by record number or by date. The most recent record is always record number 1. The various **LDP** command options are listed in *Table 6.8*.

Table 6.8 LDP Command Options

Serial Port Command	Description
LDP	Display all available load profile data.
LDP <i>n</i>	Display the <i>n</i> most recent load profile records, starting with record <i>n</i> .
LDP <i>n1 n2</i>	Display load profile records <i>n2</i> to <i>n1</i> , starting with <i>n2</i> .
LDP <i>d1</i>	Display all the load profile records made on date <i>d1</i> .
LDP <i>d1 d2</i>	Display all the load profile records made from <i>d2</i> to <i>d1</i> , inclusive, starting with <i>d2</i> .

The date entries used with the **LDP** command should match the Date Format setting. If the Date Format setting equals MDY, then the dates entered should have the format mm/dd/yyyy. If the Date Format setting equals YMD, then the dates entered should have the format yyyy/mm/dd.

If the requested load profile records do not exist, the relay responds “No Load Profile Data.” See *Load Profiling* in *Section 8: Metering and Monitoring* for an example load profile report.

LDP D (Level 1 or 2)

Use the **LDP D** command to learn how many total days of data the relay can store and how many days remain until the oldest data is lost.

LDP R (Level 2)

LDP R removes the load profile data from nonvolatile memory.

METER (Level 1 or 2)

The **METER** commands provide access to the relay metering data. To make the extensive amount of meter information manageable, the relay divides the displayed information into five groups: Instantaneous, Demand, Energy, Maximum/Minimum, and Thermal.

Instantaneous Metering: METER k

The **METER k** command displays instantaneous magnitudes (and angles if applicable) of the measured and calculated analog quantities.

The angles are referenced to the A-phase voltage if it is included and greater than 13 V secondary; otherwise, the angles are referenced to A-phase current. The angles range from –179.99 to 180.00 degrees.

To view the instantaneous meter values once, use the **METER** command. To view the **METER** values *k* times, use the **METER k** command, where *k* is a number between 1 and 32767.


```
=>METER
SEL-701                               Date: 08/01/1999   Time: 15:59:15.739
MOTOR RELAY

  A      B      C      N      G
I MAG (A, Fn)  69.74  69.85  69.61  0.00  0.33
  (A,RMS)      69.66  69.77  69.62  0.02
I ANG (DEG)    -45.08 -164.96  75.02 -156.51 -130.61
              AB      BC      CA      G
V MAG (V, Fn)      464      465      464      1
  (V,RMS)          464      464      463
V ANG (DEG)       0.00 -120.08  119.85 -5.94

              3P
kW (Fn)          54.14
kW (AVG)         54.09
HP (Fn)          72.57
kVAR             14.44
kVA              56.03
pf               0.97 LAG
Negative-Sequence Current   Negative-Sequence Voltage
              (3I2)              (3V2)
MAG           0.07              1
ANG (DEG)     53.63              147.19
FREQ (Hz)     60.00
Unbalance (%)  0.1
=>
```

Figure 6.8 METER Command Example

Demand Metering: METER D

The **METER D** command displays the demand and peak demand current values. If the relay is equipped with voltage inputs, power demand and peak power demand quantities are also included.

```
=>METER D
SEL-701                               Date: 08/01/1999   Time: 15:59:26.490
MOTOR RELAY

  IA      IB      IC      IN      IG      3I2
DEMAND    38.7    38.6    38.6    0.0    0.7    0.5
PEAK       40.5    41.3    41.8    0.1    2.4    2.1
kW3P      kVAR3P-IN  kVAR3P-OUT  kVA3P
DEMAND    667.2    179.7    0.0      692.0
PEAK      681.6    183.7    0.0      704.1
LAST DEMAND RESET 07/02/1999 11:11:18.305
LAST PEAK RESET  07/02/1999 11:11:17.120
=>
```

Figure 6.9 METER D Command Example

Energy Metering: METER E

When the relay is equipped with optional voltage inputs, the **METER E** command displays the measured megawatt hours, megavar hours, and megavolt-amp hours since the last reset.

```
=>METER E
SEL-701                               Date: 03/23/2009   Time: 07:14:36.352
MOTOR RELAY
MWhr      MVARhr-IN  MVARhr-OUT  MVAhr
30.709    10.416     7.766        46.165
LAST RESET 09/04/2008 07:30:10.653
=>
```

Figure 6.10 METER E Command Example

Maximum/Minimum Metering: METER M

The **METER M** command displays the maximum and minimum values of assorted current, voltage, power, and temperature quantities. The relay begins updating the maximum and minimum quantities 30 cycles after the motor starts. Voltage values are only updated if the phase-to-phase voltage is greater than 13 V secondary. Residual voltage, if wye-potentials are connected, is only updated if the voltage is greater than 3 V secondary.

=>METER M						
SEL-701		Date: 08/21/1999		Time: 15:59:53.365		
MOTOR RELAY						
	Max	Date	Time	Min	Date	Time
IA(A)	400.0	07/20/1999	14:00:36.676	15.6	07/02/1999	18:20:00.615
IB(A)	399.3	07/20/1999	14:00:36.726	19.6	07/02/1999	17:48:24.444
IC(A)	398.7	07/20/1999	14:00:36.676	19.1	07/02/1999	17:50:12.939
IN(A)	0.1	07/02/1999	17:53:21.805	0.1	07/02/1999	17:53:21.805
IG(A)	23.5	08/01/1999	15:44:54.574	1.5	07/02/1999	17:42:12.187
VAB(V)	470	07/02/1999	18:29:45.812	72	07/02/1999	18:28:49.100
VBC(V)	465	08/01/1999	15:33:17.710	200	07/20/1999	13:45:42.984
VCA(V)	464	07/20/1999	13:28:21.973	86	07/20/1999	13:45:43.971
VG(V)	RESET			RESET		
KW3P	159.7	07/20/1999	14:00:36.755	0.0	07/02/1999	18:26:44.964
KVAR3P	15.7	07/02/1999	18:29:34.063	-0.0	07/02/1999	18:29:48.921
KVA3P	159.6	07/20/1999	14:35:26.772	2.3	07/02/1999	18:28:48.928
1 WDG (F)	161	07/20/1999	14:32:18.416	118	07/14/1999	04:44:36.676
2 WDG (F)	158	07/20/1999	14:33:26.356	124	07/14/1999	04:36:58.786
3 WDG (F)	155	07/20/1999	14:38:14.284	116	07/14/1999	04:42:32.476
4 WDG (F)	164	07/20/1999	14:31:34.676	128	07/14/1999	04:40:14.135
5 WDG (F)	150	07/20/1999	14:40:46.763	115	07/14/1999	04:39:28.616
6 WDG (F)	158	07/20/1999	14:36:33.656	121	07/14/1999	04:39:40.526
7 BRG (F)	120	07/20/1999	14:20:36.476	74	07/14/1999	04:45:34.873
8 BRG (F)	112	07/20/1999	14:18:58.067	78	07/14/1999	04:44:56.908
9 BRG (F)	114	07/20/1999	14:35:32.985	76	07/14/1999	04:35:46.089
10 BRG (F)	109	07/20/1999	14:30:16.975	81	07/14/1999	04:36:18.542
11 AMB (F)	98	07/20/1999	14:28:38.186	62	07/14/1999	04:38:36.458
LAST RESET 07/02/1999 11:09:10.745						
=>						

Figure 6.11 METER M Command Example

Thermal and RTD
Metering: METER T

The **METER T** command displays the temperatures of any connected RTDs. This command also shows the motor current in % of Full Load Amps, the present thermal model % Thermal Capacity, and the RTD % Thermal Capacity if ambient and winding temperatures are monitored and a winding RTD trip temperature is set. If the motor is in overload, this command response shows the calculated time to a thermal trip. If the motor is not in overload, the time shown is 9999 seconds. The number of starts this hour and the minutes since the last start are also shown.

It also reports “Time to Reset” as the maximum of the THERMLO, TBSLO, NOSLO, and ABSLO lockout timers.

=>METER T		
SEL-701		
MOTOR RELAY		
Date: 09/01/1999 Time: 16:00:07.876		
1 WDG =	140 F	
2 WDG =	137 F	
3 WDG =	136 F	
4 WDG =	142 F	
5 WDG =	133 F	
6 WDG =	136 F	
7 BRG =	96 F	
8 BRG =	91 F	
9 BRG =	94 F	
10 BRG =	92 F	
11 AMB =	78 F	
Full Load Amps(%)	69.7	
% Thermal Capacity	47.1	
RTD % Thermal Capacity	43	
Calculated Time to Thermal Trip (seconds)	9999	
Minutes Since Last Start	0	
Starts This Hour	0	
Time to Reset (seconds)	12345	
=>		

Figure 6.12 METER T Command Example

METER RD (Level 1
or 2)

Reset the accumulated demand values using the **MET RD** command.

METER RE (Level 1 or 2)

Reset the measured energy values using the **MET RE** command.

METER RM (Level 1 or 2)

Reset the maximum/minimum meter values using the **MET RM** command.

METER RP (Level 1 or 2)

Reset the peak demand values using the **MET RP** command.

MOTOR (Level 1 or 2)

The **MOTOR** command displays the motor operating statistics that include the following:

- Total motor running hours, stopped hours, and percent running time
- Total megawatt hours (if optional voltages are included)
- Total number of motor starts
- Average and peak starting times, starting current magnitudes, thermal capacities, and other average and peak operating values
- Learned motor cooling time (if RTDs are included) and learned starting thermal capacity
- Trip and alarm counters, listed by type

Section 8: Metering and Monitoring includes additional details on the motor operating statistics report.

MOTOR R (Level 2)

Reset the motor operating statistics using the **MOTOR R** command. The relay resets all the data accumulators except the learned motor parameters, which you reset using the **RLP** command.

MSR (Level 1 or 2)

Use the **MSR** (Motor Start Report) command to view motor start reports. The relay records a 3600-cycle report each time the motor starts. The general command format is listed in *Table 6.9*.

Table 6.9 MSR General Command Format

MSR n	
where:	
<i>n</i>	Event number (1–5). Defaults to 1 if not listed, where 1 is the most recent event.
MSR F	Display the format of a motor start report.

See *Section 8: Metering and Monitoring* for information on the contents of motor start reports.

MST (Level 1 or 2)

Use the **MST** (Motor Start Trend) command to review the motor start trend data. The relay records the number of starts and average information for each of the past eighteen 30-day periods. See *Section 8: Metering and Monitoring* for information on the contents of the motor start trend data.

MST R (Level 2)

Use the **MST R** command to reset the data stored in the motor start trend buffers. This should only be done at initial relay installation, for motor rewinds, or after overhaul of the load equipment.

PASSWORD (Level 2)

WARNING

The device is shipped with default passwords. Default passwords should be changed to private passwords at installation. Failure to change each default password to a private password may allow unauthorized access. SEL shall not be responsible for any damage resulting from unauthorized access.

PAS allows you to inspect or change the existing password. To inspect the Access Level 2 password, type: **PAS <Enter>**. The relay will display the present password.

The factory default password is 701. To change the password for Access Level 2 to BIKE, enter: **PAS 2 BIKE <Enter>**.

After entering the new password, type **PAS <Enter>** to inspect it. Make sure it is what you intended and record it.

The password may include up to six characters. Valid characters consist of: 'A-Z', 'a-z', '0-9', '-', and '.'. Upper- and lower-case letters are treated as different characters.

Strong passwords consist of six characters, with at least one special character or digit and mixed case sensitivity, but do not form a name, date, acronym, or word. Passwords formed in this manner are less susceptible to password guessing and automated attacks. Examples of valid, distinct passwords include:

- Ot3579
- A24.68
- lh2dcs
- 4u-Iwg
- .351r.

To disable password protection for Access Level 2, set the password to DISABLE.

PASSWORD (Level C)

The factory default password to access CAL Level (Level C) from Level 2 is CLARKE. To change the password for Access Level C to MOTOR, enter **PAS C MOTOR <Enter>**. After entering the new password, type **PAS <Enter>** to inspect it. Make sure it is what you intended and record it. The CAL access level is intended for use by the SEL factory and for use by SEL field service personnel to help diagnose troublesome installations. A list of commands available at the CAL level is available from SEL upon request. Do not enter the CAL access level except as directed by SEL.

PULSE (Level 2)

The **PULSE** command allows you to pulse any of the output contacts for a specified length of time. The command format is shown in *Table 6.10*.

Table 6.10 PULSE Command Format

PUL x y	
where:	
<i>x</i>	The output name (TRIP, OUT1, OUT2, OUT3, or ALARM).
<i>y</i>	The pulse duration (1–30) in minutes. If <i>y</i> is not specified, the pulse duration defaults to 1 second.
MSR F	Display the format of a motor start report.

Use the **PULSE** command to test contact wiring during installation and maintenance testing.

```
=>>PUL TRIP 1
Are you sure (Y/N) ? Y <Enter>
=>>
```

Figure 6.13 PULSE Command Example

QUIT (Level 2)

The **QUI** command returns the relay to Access Level 1.

RLP (Level 2)

Use the **RLP** (Reset Learned Parameters) command at Access Level 2 to reset the learned motor parameters. You can reset the learned motor stopped cooling time and the learned motor starting time values individually. After a value is reset, the relay needs five motor starts or motor stops to learn the parameter. Only use this command when the relay is initially installed, after a motor rewind, or after overhaul of the load equipment.

```
=>>RLP
Reset the Learned Cooling Time (Y/N)? Y <Enter>
Learned Cooling Time Reset
Reset the Learned Starting Thermal Capacity (Y/N)? Y <Enter>
Learned Starting Thermal Capacity Reset
=>>
```

Figure 6.14 RLP Command Example

SER (Level 1 or 2)

Use the **SER** (Sequential Events Record) command to view the Sequential Events Recorder (SER) report, described in detail in *Section 9: Event Analysis*. Each event record is stored with a record number, a date, and a time. You can access SER data by record number or by date. The most recent record is always record number 1. The various **SER** command options are shown in *Table 6.11*.

Table 6.11 SER Command Options

Serial Port Command	Description
SER	Display all available SER records.
SER <i>n</i>	Display the <i>n</i> most recent SER records, starting with record <i>n</i> .
SER <i>n1 n2</i>	Display SER records <i>n2</i> to <i>n1</i> , starting with <i>n2</i> .
SER <i>d1</i>	Display all the SER records made on date <i>d1</i> .
SER <i>d1 d2</i>	Display all the SER records made from <i>d2</i> to <i>d1</i> , inclusive, starting with <i>d2</i> .

The date entries used with the **SER** command are dependent on the Date Format setting. If the Date Format setting equals MDY, then the dates entered should have the format mm/dd/yyyy. If the Date Format setting equals YMD, then the dates entered should have the format yyyy/mm/dd.

If the requested load profile records do not exist, the relay responds “No SER Data.”

SER R (Level 2)

SER R removes the SER data from nonvolatile memory.

SET (Level 2)

The **SET** command allows the user to view or change the relay settings.

Table 6.12 Serial Port SET Commands

Command	Settings Type	Description
SET	Relay	Protection elements, timers, etc.
SET R	SER	Sequential Events Recorder trigger conditions and ALIAS settings.
SET P n	Port	Serial port settings for Serial Port n ($n = F$ or R).

When you issue the **SET** command, the relay presents a list of settings one at a time. Enter a new setting or press <Enter> to accept the existing setting. Editing keystrokes are shown in *Table 6.13*.

Table 6.13 SET Command Editing Keystrokes

Press Key(s)	Results
<Enter>	Retains setting and moves to the next setting.
^ <Enter>	Returns to previous setting.
< <Enter>	Returns to previous setting category.
> <Enter>	Moves to next setting category.
END<Enter>	Exits editing session, then prompts you to save the settings.
<Ctrl+X>	Aborts editing session without saving changes.

The relay checks each entry to ensure that it is within the setting range. If it is not, an “Out of Range” message is generated, and the relay prompts you for the setting again.

When all the settings are entered, the relay displays the new settings and prompts you for approval to enable them. Answer **Y** <Enter> to enable the new settings. The relay is disabled for as long as 5 seconds while it saves the new settings. The ALARM output b-contact closes momentarily and the Relay Enabled LED extinguishes while the relay is disabled.

To change a specific setting, enter the command shown in *Table 6.14*.

Table 6.14 SET Command Format

SET n s TERSE	
where:	
n	not used to enter Relay settings R to enter SER settings P F to enter front serial port settings P R to enter rear serial port settings
s	the name of the specific setting you wish to jump to and begin setting. If s is not entered, the relay starts at the first setting.
TERSE	instructs the relay to skip the settings display after the last setting. Use this parameter to speed up the SET command. If you wish to review the settings before saving, do not use the TERSE option.

SHOW (Level 1 or 2)

Use the **SHOW** command to view relay settings, serial port settings, and SER settings. **SHOW** command options are listed in *Table 6.15*.

Table 6.15 SHOW Command Options

Command	Description
SHOW	Show relay settings.
SHO P <i>n</i>	Show serial port settings. <i>n</i> specifies the port (F or R); <i>n</i> defaults to the active port if not listed.
SHO R	Show SER settings.

You may append a setting name to each of the commands to specify the first setting to display (e.g., **SHO 50P1P** displays the relay settings starting with setting 50P1P). The default is the first setting.

The **SHOW** commands display only the enabled settings. To display all settings, including disabled/hidden settings, append an A to the **SHOW** command (e.g., **SHOW A**).

```
=>SHOW
Relay Settings:
RID      =SEL-701
TID      =MOTOR RELAY
CTR      = 20      ITAP      = 5      CTRN      = 10      INTAP      = 5
PHROT    = ABC      FNOM      = 60      DATE_F     = MDY      DMTC      = 15
PTR      = 4      DELTA_Y   = Y      SINGLEV    = N
SETMETH  = RATING   FLA       = 5.00      SF         = 1.15      LRA       = 30.00
LRTHOT   = 2.1      LRTCOLD   = 2.5      TD         = 1.00      TCAPU     = 90
TCSTART  = 85      TCLRNEN   = Y      COOLTIME   = 259      COOLEN    = Y
50P1P    = OFF      50P2P     = OFF      50G1P      = 2.50      50G1D     = 0.10
50G2P    = OFF      50N1P     = 2.500     50N1D      = 0.10      50N2P     = OFF
50QP     = OFF
MAXSTART = 3      TBSDLY    = 20
LJTPU    = 2.0      LJTDLY    = 1.00      LLAPU      = OFF
46UBA    = 10      46UBAD    = 2.50      46UBT      = 15      46UBTD    = 5.00
Press RETURN to continue
E47T     = Y
SPDSPLY  = OFF
RTDOPT   = INT      TMPREF     = F      RTD1LOC    = WDG      RTD2LOC    = WDG
RTD3LOC  = WDG      RTD4LOC    = WDG      RTD5LOC    = WDG      RTD6LOC    = WDG
RTD7LOC  = BRG      RTD8LOC    = BRG      RTD9LOC    = BRG      RTD10LOC   = BRG
RTD11LOC = AMB      RTD1TY     = PT100     RTD2TY     = PT100     RTD3TY     = PT100
RTD4TY   = PT100     RTD5TY     = PT100     RTD6TY     = PT100     RTD7TY     = NI120
RTD8TY   = NI120     RTD9TY     = NI100     RTD10TY    = NI100     RTD11TY    = PT100
TRTMP1   = 280      ALTMP1     = 250      TRTMP2     = 280      ALTMP2     = 250
TRTMP3   = 280      ALTMP3     = 250      TRTMP4     = 280      ALTMP4     = 250
TRTMP5   = 280      ALTMP5     = 250      TRTMP6     = 280      ALTMP6     = 250
TRTMP7   = OFF      ALTMP7     = 199      TRTMP8     = OFF      ALTMP8     = 199
TRTMP9   = OFF      ALTMP9     = 199      TRTMP10    = OFF      ALTMP10    = 199
TRTMP11  = OFF      ALTMP11    = OFF      EWDGV      = Y      EBRGV      = N
RTDBEN   = N
27P1P    = OFF      27P2P     = OFF
59P1P    = 73      59P2P     = OFF      59GP       = OFF
NVARAP   = OFF      NVARTP     = OFF
37PAP    = OFF      37PTP     = OFF
Press RETURN to continue
55LDAP   = OFF      55LDTP    = OFF
81D1P    = 59.10     81D1D     = 0.03      81D2P      = OFF      81D3P      = OFF
AOSIG    = 4-20MA    AOPARM     = %LOAD_I   FP_KW       = N      FP_RTD      = N
FP_TO     = 15      FPBRITE    = 50
DM1_1    =SEL-701      DM1_0      =
DM2_1    =MOTOR RELAY  DM2_0      =
DM3_1    =RTD FAILURE   DM3_0      =
DM4_1    =TIME BET STARTS LO DM4_0      =
DM5_1    =NUM OF STARTS LO DM5_0      =
DM6_1    =THERMAL LO    DM6_0      =
TRFS     = Y      OUT1FS     = N      OUT2FS     = N      OUT3FS     = N
TDURD    = 0.50      ABSPLY     = 0
FACTLOG  = Y
=>
```

Figure 6.15 SHOW Command Example

STATUS (Level 1 or 2)

The **STATUS** command displays the relay self-test information.

To view a status report, enter the command **STATUS**. To view the status report *k* times, enter the command **STATUS *k***, where *k* is a number between 1 and 32767.

STATUS Command
Row and Column
Definitions

Table 6.16 STATUS Command Options

STA Command Row	Column Definitions
FID	Firmware identifier string.
CID	Firmware checksum identifier.
Offset	Measures the dc offset voltages for the current and voltage channels.
+5V_PS	Tests the power supply voltage outputs.
-5V_PS	
+15V_PS	
+28V_PS	
TEMP	Tests the internal relay temperature.
RAM, ROM, CR_RAM (critical RAM), and EEPROM	Tests the relay memory components.
BATTERY	Tests the real time clock battery voltage.
RTC	Tests the real time clock integrated circuit.
LC_TIME	Tests the memory locations where the Motor Learned Cooling Time data is stored.
TC_START	Tests the memory locations where the Motor Learned Thermal Capacity to Start data is stored.

The relay indicates OK or FAIL for each self-test result. Refer to *Section 10: Maintenance and Troubleshooting* for self-test thresholds and corrective actions.

```

=>STATUS
SEL-701                                Date: 09/01/1999    Time: 16:01:28.364
MOTOR RELAY
FID=SEL-701-R102-V11xxx-Z000000-D19990730    CID=D5EE
SELF TESTS
      IA      IB      IC      IN
Offset: OK      OK      OK      OK
      VA      VB      VC      N
Offset: OK      OK      OK      OK
+5V_PS  -5V_PS  +15V_PS +28V_PS
OK      OK      OK      OK
TEMP    RAM     ROM     CR_RAM  EEPROM
OK      OK      OK      OK      OK
BATTERY RTC     LC_TIME TC_START
OK      OK      OK      OK
      Relay Enabled
=>

```

Figure 6.16 STATUS Command Example

STATUS R (Level 2)

To reset the self-test status and restart the relay, use the **STA R** command from Access Level 2.

The relay then restarts (just like powering down, then powering up the relay) and all diagnostics are rerun before the relay is enabled.

STOP (Level 2)

The **STOP** command causes the relay to trip, opening the motor contactor or circuit breaker and stopping the motor. The command also triggers an event report.

STR (Level 2)

The **STR** (Start) command initiates a motor start using the relay's internal logic. The factory default logic configures output contact OUT3 to close to start the motor. Refer to *Appendix B: SELOGIC Control Equations and Relay Logic* for information on how to change the factory default logic.

TARGET (Level 1 or 2)

The **TARGET** command displays the status of relay elements whether they are asserted or deasserted. The elements are represented as Relay Word bits and are listed in rows of eight, called Relay Word rows. For additional information on individual Relay Word bits, refer to *Appendix B: SELOGIC Control Equations and Relay Logic*.

A Relay Word bit is either at a logical 1 (asserted) or a logical 0 (deasserted).

```
=>TARGET 1
STARTING RUNNING STOPPED JAMTRIP LOSSALRM LOSSTRIP 46UBA 46UBT
0 1 0 0 0 0 0 0
=>
```

Figure 6.17 TARGET Command Example

The **TAR** command options are listed in *Table 6.17*.

Table 6.17 TARGET Command Options

Commands	Descriptions
TAR <i>n k</i>	Shows Relay Word row number <i>n</i> (0–11). <i>k</i> is an optional parameter to specify the number of times (1–32767) to repeat the Relay Word row display. If <i>k</i> is not specified, the Relay Word row is displayed once. See <i>Table 6.18</i> for definition of Row 0. See <i>Table 6.19</i> for a list of the Relay Word bits in each row (<i>n</i> = 1–10).
TAR <i>name k</i>	Shows Relay Word row containing Relay Word bit <i>name</i> (e.g., TAR 50PIT displays Relay Word Row 3). Valid names are shown in <i>Table 6.18</i> . Parameter <i>k</i> is an optional parameter that specifies the number of times (1–32767) the Relay Word row display repeats. If <i>k</i> is not specified, the Relay Word row is displayed once.

Table 6.18 Front-Panel LEDs and the TAR 0 Command^a

LED Name	Relay Enabled	Motor Energized	Thermal Overload	Overcurrent	Unbalance	Load Loss	Voltage	Frequency
When LED is Dark, TAR 0 Displays	ENABLE 0	MOTRUN 0	THERM_OL 0	OVERCURR 0	UNBAL 0	LOADLOSS 0	VOLTAGE 0	FREQ 0
When LED is Flashing, TAR 0 Displays	—	MOTSTART 1	THERM_AL 1	—	UNBAL_AL 1	LOSS_AL 1	VOLT_AL 1	—
When LED is On, TAR 0 Displays	ENABLE 1	MOTRUN 1	THERM_OL 1	OVERCURR 1	UNBAL 1	LOADLOSS 1	VOLTAGE 1	FREQ 1

^a See Section 9: Event Analysis for additional information on the meaning of each target LED condition.

Table 6.19 SEL-701 Relay Word and Corresponding TAR Command^a

TAR	Relay Word Bits							
1	STARTING	RUNNING	STOPPED	JAMTRIP	LOSSALRM	LOSSTRIP	46UBA	46UBT
2	49A	49T	THERMLO	NOSLO	TBSLO	ABSLO	*b	*b
3	50P1T	50P2T	50N1T	50N2T	50QT	50S	50G1T	50G2T
4	47T	TRGTR	START	52A	SPDSTR	SPEEDSW	RTDBIAS	RTDFLT
5	WDGALRM	WDGTRIP	BRGTRIP	BRGTRIP	AMBALRM	AMBTRIP	OTHALRM	OTHTRIP
6	27P1	27P2	59P1	59P2	59G	81D1T	81D25	81D35
7	37PA	37PT	55A	55T	VARA	VART	LOP	*b
8	LT1	LT2	LT3	LT4	RB1	RB2	RB3	RB4
9	SV1	SV2	SV3	SV4	SV1T	SV2T	SV3T	SV4T
10	IN1	IN2	IN3	IN4	IN5	IN6	IN7	*b
11	TRIP	OUT1	OUT2	OUT3	ALARM	50CD	BFI	BFT

^a See Section 9: Event Analysis for additional information on the meaning of each target LED condition.

^b Bit not used; reserved for future expansion.

TARGET R (Level 1 or 2)

Resets front-panel tripping targets and releases the trip signal if the fault condition has vanished and no lockout conditions are present. If the relay tripping targets do not reset when you execute the **TARGET R** command at the relay serial port or use the front-panel menu selection Reset Trip/Targets, verify that the fault condition and all lockouts have cleared.

TIME (Level 1 or 2)

TIME displays the relay clock. To set the clock, type **TIME** and the desired setting, then press <Enter>. Separate the hours, minutes, and seconds with colons, semicolons, spaces, commas, or slashes.

```
=>TIME
16:02:21
=>
```

Figure 6.18 TIME Command Example

TRIGGER (Level 1 or 2)

Use the **TRIGGER** command to generate an event report. See *Section 9: Event Analysis* for more information on event reports.

```
=>TRIGGER
Triggered
=>
```

Figure 6.19 TRIGGER Command Example

Serial Port Automatic Messages

When the serial port AUTO setting is Y, the relay sends automatic messages to indicate specific conditions. The automatic messages are described in *Table 6.20*.

Table 6.20 Serial Port Automatic Messages

Condition	Description
Power Up	The relay sends a message containing the present date and time, relay and terminal identifiers, and the Access Level 1 prompt when the relay is turned on.
Event Trigger	The relay sends an event summary each time an event report is triggered. See <i>Section 9: Event Analysis</i> .
Self-Test Warning or Failure	The relay sends a status report each time a self-test warning or failure condition is detected. See <i>STATUS Command Row and Column Definitions on page 6.18</i> .

This page intentionally left blank

Section 7

Commissioning

Introduction

This section provides guidelines for commissioning and testing the SEL-701 Relay.

SEL performs a complete functional check and calibration of each relay before it is shipped. This helps to ensure that you receive a relay that operates correctly and accurately. Commissioning tests should verify that the relay is properly connected to the power system and all auxiliary equipment. Verify control signal inputs and outputs. Use an ac connection check to verify that the relay current and voltage inputs are of the proper magnitude and phase rotation.

Brief functional tests ensure that the relay settings are correct. It is not necessary to test every relay element, timer, and function in these tests.

Relay Commissioning Procedure

Introduction

This procedure is a guideline to help you enter settings into the SEL-701 Relay and verify that it is properly connected. Modify the procedure as necessary to conform with your standard practices.

Use the commissioning procedure at initial relay installation; you should not need to repeat it unless major changes are made to the relay electrical connections.

Required Equipment

- SEL-701 Relay, installed and connected according to your protection design
- PC with serial port, terminal emulation software or ACSELERATOR QuickSet® SEL-5030 Software, and serial communication cable (for relay setting entry)
- SEL-701 Relay Settings Sheets copied from *Appendix F: SEL-701 Relay Settings Sheets* or ACSELERATOR QuickSet settings files and filled out with settings appropriate to your application and protection cabinet design
- AC and dc elementary schematics and wiring diagrams for this relay installation
- Continuity tester
- Protective relay ac test source:
 - Minimum:** Single-phase voltage plus single-phase current with ability to control phase angle between signals
 - Preferred:** Two- or three-phase voltage plus three-phase current with ability to control phase angle between signals

Commissioning Procedure

HINT: Use the **HELP** command at any Access Level to get a list of available serial port commands.

- Step 1. Ensure that control power and ac signals are removed from the SEL-701 Relay by opening the appropriate breaker(s) or removing fuses. Isolate the relay TRIP contact.
- Step 2. Verify the accuracy and correctness of the ac and dc connections by performing point-to-point continuity checks on the circuits associated with the SEL-701 Relay.
- Step 3. Apply ac or dc control power to the relay. Within a moment of energizing the relay, the green enable LED (Relay Enabled) on the front panel should illuminate, and the relay self-test ALARM b-contact (B17, B18) should open.
- Step 4. Connect the PC to the relay using the appropriate serial cable (SEL Cable C234A or a null-modem cable). Start the PC and terminal emulation software or ACSELERATOR QuickSet. Establish communication with the relay at Access Level 1. Refer to *Section 6: ASCII Serial Port Operation* for more information on serial port communications. Refer to *Section 3: PC Software* for more information on ACSELERATOR QuickSet. Enter Access Level 2 using the factory default password, 701.
- Step 5. Using the front-panel Set Relay\Date and Set Relay\Time functions or serial port **DATE** and **TIME** commands, set the correct relay clock time and, if necessary, date.
- Step 6. Using the front-panel Set Relay\Password or serial port Access Level 2 **PASSWORD** command, enter your new Access Level 2 password. Be sure to record the new password in a safe location.
- Step 7. Using ACSELERATOR QuickSet or the **SET**, **SET R**, and **SET P** commands, enter relay settings according to the Settings Sheets for your application. If you are using ACSELERATOR QuickSet, you can use it to develop, store, and transfer settings to the SEL-701 Relay. See *Section 3: PC Software* for more details on ACSELERATOR QuickSet.
- Step 8. If you are using an SEL-2600 RTD module, connect the fiber-optic cable to the module fiber-optic output. At the relay-end of the fiber, you should be able to see a red light that indicates the module is sending data. Plug the relay-end of the fiber into the relay fiber-optic receiver input.
- Step 9. Verify relay ac connections. Connect the protective relay ac test signal source to the SEL-701 Relay through the motor control center wiring. (You may connect directly to the relay; however, this does not verify the accuracy of the wiring in the motor control center.)

Apply rated ac current (1 A or 5 A) to the relay phase current inputs. If the relay is equipped with voltage inputs, apply rated voltage for your application to the relay phase voltage inputs.

- If you set the relay to accept phase-to-neutral voltages (DELTA_Y = Y), set the current and/or voltage source phase angles as shown in *Figure 7.1*.
- If you use open-delta potentials, set the test source phase angles as shown in *Figure 7.2*.

- When you set the relay to accept single-phase voltage (SINGLEV = Y), you can connect and apply V_A or V_{AB} only.
- Use the front-panel Meter Values\Instantaneous Meter function or serial port **METER** command to verify that the relay is measuring the magnitude and phase angle of both voltage and current correctly, taking into account the relay PTR and CTR settings and the fact that the quantities are displayed in primary units. This step verifies the signal polarity and per-phase ac connections to the relay.
- Apply rated ac current (1 A or 5 A) to the relay IN input if used. Use the front-panel or serial port **METER** function to verify that the relay is measuring current magnitude and phase angle correctly, taking into account the relay CTRN setting and the fact that the quantities are displayed in primary units.




Figure 7.1 Three-Phase AC Connection Test Signals




Figure 7.2 Open-Delta AC Potential Connection Test Signals

- Step 10. Verify contact input connections. Using the front-panel View Relay Word\Row 10 function, check the contact input status in the relay front-panel display. As you short-circuit each input, its label (IN1, IN2, IN3, etc.) should appear in the front-panel display.
- Step 11. Verify relay contact output electrical performance using the front-panel Pulse Out Contact\TRIP command to close the TRIP output contact. Repeat for the other output contacts. Make sure that each contact operates properly in its designated annunciation, control, or tripping circuit. See *Section 5: Front-Panel Operations* and *Section 6: ASCII Serial Port Operation* for more details regarding the **PULSE** command.
- Step 12. Perform any desired protection element tests using the individual element test procedures found in *Selected Functional Tests on page 7.5*. Only perform enough tests to prove that the relay operates as intended; exhaustive element performance characterizations are not necessary for commissioning.
- Step 13. Connect the relay for tripping duty. Verify that any settings changed during the tests performed in *Step 12* have been changed back to their correct values for this application.
- Step 14. Prepare the relay for operation by clearing the relay data buffers, using the relay commands in *Table 7.1*. This prevents data generated during installation testing from being confused with operational data collected later.

NOTE: The **MOT R**, **MST R**, and **SER R** commands should only be used at initial installation. Do not reset the motor operating statistics or SER buffer following routine maintenance unless you are very familiar with the use of the data contained in these buffers and are certain that the data is no longer needed.

Table 7.1 Serial Port Commands that Clear Relay Data Buffers

Serial Port Command	Task Performed
MET RD	Resets Demand Meter Data
MET RP	Resets Peak Demand Meter Data
MET RE	Resets Energy Meter Data
MET RM	Resets Max/Min Data
LDP R	Resets the Load Profile Data
HIS R	Resets Event Report and History Command Buffers
MOT R	Resets Motor Operating Statistic Buffers and Start Reports
MST R	Resets Motor Start Trend Data
RLP	Reset Learned Motor Parameters
SER R	Resets Sequential Events Record Buffer

- Step 15. When it is safe to do so, start the motor.
- Step 16. Verify the following ac quantities using the front-panel Meter Values\Instantaneous Meter or serial port **METER** command:
- Phase current magnitudes should be nearly equal.
 - Phase current phase angles should be balanced, should have proper phase rotation, and should have appropriate phase relationship to their phase voltages.
 - The positive-sequence current magnitude, I1, should be nearly equal to IA, IB, and IC.
 - The negative-sequence current magnitude, I2, and residual current magnitude should both be nearly zero.

NOTE: If the relay reports I1 near zero and I2 nearly equal to IA, IB, and IC, there is a phase rotation problem. Verify the relay ac current connections and the phase rotation setting, PHROT. A nonzero 3I0 meter value indicates a phase current polarity connection problem.

NOTE: If the relay reports V1 near zero and V2 nearly equal to $V_{AB}/1.74$, there is a phase rotation problem. Verify the relay ac voltage connections and the phase rotation setting, PHROT. A nonzero 3V0 meter value, if shown, typically indicates a single-phase voltage connection

- Step 17. If your relay is equipped with voltage inputs, check the following:
- Phase voltage magnitudes should be nearly equal.
 - Phase voltage phase angles should be balanced and have proper phase rotation.
 - The negative-sequence voltage magnitude, V2, and zero-sequence voltage magnitude, 3V0, if shown, should both be nearly zero.

Step 18. The SEL-701 Relay is now ready for continuous service.

Selected Functional Tests

Test Connections

Refer to *Table 7.2* to determine which test source connection diagram to use for testing in your application.

Table 7.2 Test Source Connections for Different Relay Configurations

AC Configuration	Test Source Connections
Currents Only	See <i>Figure 7.3</i> ; connect currents only
Currents plus single-phase voltage connected phase-to-phase	See <i>Figure 7.4</i> ; connect currents and A-B voltage only. Include B-N jumper connection
Currents plus single-phase voltage connected phase-to-neutral	See <i>Figure 7.3</i> ; connect currents and A-N voltage only
Currents plus three-phase voltages connected phase-to-phase	See <i>Figure 7.4</i>
Currents plus three-phase voltages connected phase-to-neutral	See <i>Figure 7.3</i>




Figure 7.3 Three Voltage Source and Three Current Source Test Connections

NOTE: Relays equipped with ac voltage inputs (Models 0701001X and 0701011X) must be properly grounded for accurate voltage measurement.




Figure 7.4 Two Voltage Source and Three Current Source Test Connections

NOTE: Relays equipped with ac voltage inputs (Models 0701001X and 0701011X) must be properly grounded for accurate voltage measurement.

Phase Current Measuring Accuracy

- Step 1. Connect the current sources to the IA, IB, and IC current inputs (5 A or 1 A, as indicated by the ITAP setting).
- Step 2. Using the front-panel Set Relay\Relay Elements\General Data functions or serial port **SHOW** command, note the CTR and PHROT settings.
- Step 3. Set the current source phase angles to apply balanced three-phase currents. Refer to *Figure 7.1* for the correct phase angles that depend on the PHROT setting.
- Step 4. Turn on the current sources and increase the current applied to the relay. Use the front-panel Meter Values\Instantaneous Meter function to view the relay phase current measurements. For the applied current values shown in *Table 7.3*, the relay should display phase current magnitudes equal to the applied current magnitude times the CTR setting.

Table 7.3 Phase Current Measuring Accuracy

 I Applied (A secondary)	Expected Reading (CTR • I A primary)	A-Phase Reading (A primary)	B-Phase Reading (A primary)	C-Phase Reading (A primary)
0.5				
1.0				
1.5				
2.0				
2.5				
5.0				

Neutral Current Measuring Accuracy

- Step 1. Connect one current source to the IN current input (5 A or 1 A, as indicated by the INTAP setting) to test neutral current measuring accuracy.
- Step 2. Using the front-panel Set Relay\Relay Elements\General Data functions or serial port **SHOW** command, note the CTRN setting.
- Step 3. Turn on the current source and increase the current applied to the relay. Use the front-panel Meter Values\Instantaneous Meter function to view the relay neutral current measurement. For the applied current values shown in *Table 7.4*, the relay should display neutral current magnitudes equal to the applied current magnitude times the CTRN setting.

Table 7.4 Neutral Current Measuring Accuracy

 I Applied (A secondary)	Expected Reading (CTR _N • I A primary)	IN Reading (A primary)
0.05 • INTAP		
0.10 • INTAP		
0.25 • INTAP		
0.50 • INTAP		
1.00 • INTAP		
2.00 • INTAP		

Current Unbalance Element Accuracy

- Step 1. Connect the current sources to the IA, IB, and IC current inputs (5 A or 1 A, as indicated by the ITAP setting).
- Step 2. Using the front-panel Set Relay\Relay Elements\General Data and Set Relay\Relay Elements\Thermal Model Elements functions or serial port **SHOW** command, note the CTR, PHROT, and FLA settings.
- Step 3. Set the current source phase angles to apply balanced three-phase currents. Refer to *Figure 7.1* for the correct angles that depend on the PHROT setting.
- Step 4. Turn on the current sources and increase the current applied to the relay. Refer to *Table 7.5* to determine the appropriate magnitude for each phase current. Use the front-panel Meter Values\Instantaneous Meter function to view the unbalance current measurement (U/B = xx%). For each applied current value shown in *Table 7.5*, the relay should display unbalance current magnitude equal to the expected reading percent shown.

Table 7.5 Current Unbalance Measuring Accuracy (Sheet 1 of 2)

 I Applied (A secondary)	Expected Reading (%)	Actual Reading (%)
IA = 0.9 • FLA IB = FLA IC = FLA	7%	
IA = 0.75 • FLA IB = FLA IC = FLA	17%	

Motor Thermal Element Accuracy

NOTE: This test outlines steps to verify performance of any of the GENERIC thermal curves. When using the RATING or USER thermal element setting methods, the steps are similar, but the expected operating times will be different, depending on the settings you use.

NOTE: This function requires that you enter the Access Level 2 password. The factory password is 701.

NOTE: Changing settings requires that you enter the Access Level 2 password. The factory password is 701.

NOTE: Reset the motor thermal model before each test run or the element will trip faster than expected.

Table 7.5 Current Unbalance Measuring Accuracy (Sheet 2 of 2)

I Applied (A secondary)	Expected Reading (%)	Actual Reading (%)
IA = FLA IB = 1.2 • FLA IC = 1.2 • FLA	12%	
IA = 0.9 • FLA IB = 1.1 • FLA IC = 1.1 • FLA	13%	

- Step 1. Connect the current sources to the IA, IB, and IC current inputs (5 A or 1 A, as indicated by the ITAP setting).
- Step 2. Using the front-panel Set Relay\Relay Elements\Thermal Model Elements function or serial port **SHOW** command, note the PHROT, FLA, and CURVE settings. Set the Service Factor setting, SF equal to 1.15.
- Step 3. Set the current source phase angles to apply balanced three-phase currents. Refer to *Figure 7.1* for the correct angles, which depend on the PHROT setting.
- Step 4. Reset the motor thermal element using the front-panel Reset Thermal Model function.

Set the current sources to apply the test current shown in *Table 7.6*, then turn on the current sources together. Refer back to *Table 7.6* to determine the expected element operating time. For instance, when the setting CURVE is equal to 4, the thermal element should trip in $4 \cdot 10 = 40$ seconds when applied three-phase current equals three times the motor full load current setting, FLA. Use the front-panel Meter Values\Thermal and RTD Data function to view the estimated Time to Thermal Trip during each test.

Table 7.6 Thermal Element Expected Trip Times

Applied Current (A secondary)	Expected Time to Trip (s)	Measured Time to Trip (s)
1.2 • FLA	CURVE • 145.7	
1.5 • FLA	CURVE • 51.5	
2.0 • FLA	CURVE • 23.3	
3.0 • FLA	CURVE • 10.0	
4.0 • FLA	CURVE • 5.63	
5.0 • FLA	CURVE • 3.60	
6.0 • FLA	CURVE • 2.50	
7.0 • FLA	CURVE • 1.84	

Analog Output Accuracy

- Step 1. Connect a dc milliammeter in series with the analog output terminals (B01, B02). Connect a PC to the relay front-panel serial port using an appropriate serial cable. Using the ACCELERATOR QuickSet terminal function or other terminal emulation software, establish communications with the relay at Access Level 2 (see *Section 6: ASCII Serial Port Operation* for more details).

- Step 2. Use the Access Level 2 **ANALOG** command to temporarily control the analog output. Refer to *Table 7.7*. Using the milliammeter reading, verify that the analog output is correct for each level.

Table 7.7 Analog Output Test

Desired % Output	ANALOG Command	Expected Meter Reading (0-1 mA Range)	Expected Meter Reading (0-20 mA Range)	Expected Meter Reading (4-20 mA Range)	Actual Meter Reading
0%	ANA 0 1	0.0 mA	0.0 mA	4.0 mA	
25%	ANA 25 1	0.25 mA	5.0 mA	8.0 mA	
50%	ANA 50 1	0.5 mA	10.0 mA	12.0 mA	
75%	ANA 75 1	0.75 mA	15.0 mA	16.0 mA	
100%	ANA 100 1	1.0 mA	20.0 mA	20.0 mA	

RTD Input Measuring Accuracy

- Step 1. Use the front-panel Set Relay\Relay Elements\RTD Configuration function or serial port **SHOW** command to view the input RTD Type setting for each RTD input. Connect a variable resistance to each RTD input in turn. The temperatures given in *Table 7.8* through *Table 7.15* are based on the RTD type and the value of the resistance. Referring to these tables, change the resistance applied to each input until the appropriate temperature is displayed.
- Step 2. Use the front-panel Meter Values\Thermal and RTD Data function or serial port **METER T** command to view the present temperature measured by the relay RTD input. The temperature displayed should be $\pm 2^{\circ}\text{C}$ or $\pm 4^{\circ}\text{F}$ from the temperature represented by the variable resistance.

Table 7.8 100-Ohm Platinum RTD Type (RTDs 1-6)

Resistance Value (ohms)	Expected Temperature Reading ($^{\circ}\text{C}$)	Expected Temperature Reading ($^{\circ}\text{F}$)	RTD Temperatures					
			7	8	9	10	11	12
80.31	-50	-58						
100.00	0	32						
119.39	50	122						
138.50	100	212						
157.32	150	302						
175.84	200	392						
190.45	240	464						

Table 7.9 100-Ohm Platinum RTD Type (RTDs 7-12)

Resistance Value (ohms)	Expected Temperature Reading (°C)	Expected Temperature Reading (°F)	RTD Temperatures					
			7	8	9	10	11	12
80.31	-50	-58						
100.00	0	32						
119.39	50	122						
138.50	100	212						
157.32	150	302						
175.84	200	392						
190.45	240	464						

Table 7.10 120-Ohm Nickel RTD Type (RTDs 1-6)

Resistance Value (ohms)	Expected Temperature Reading (°C)	Expected Temperature Reading (°F)	RTD Temperatures					
			1	2	3	4	5	6
86.17	-50	-58						
120.00	0	32						
157.74	50	122						
200.64	100	212						
248.95	150	302						
303.64	200	392						
353.14	240	464						

Table 7.11 120-Ohm Nickel RTD Type (RTDs 7-12)

Resistance Value (ohms)	Expected Temperature Reading (°C)	Expected Temperature Reading (°F)	RTD Temperatures					
			7	8	9	10	11	12
86.17	-50	-58						
120.00	0	32						
157.74	50	122						
200.64	100	212						
248.95	150	302						
303.64	200	392						
353.14	240	464						

Table 7.12 100-Ohm Nickel RTD Type (RTDs 1-6)

Resistance Value (ohms)	Expected Temperature Reading (°C)	Expected Temperature Reading (°F)	RTD Temperatures					
			1	2	3	4	5	6
71.81	-50	-58						
100.00	0	32						
131.45	50	122						
167.20	100	212						
207.45	150	302						
252.88	200	392						
294.28	240	464						

Table 7.13 100-Ohm Nickel RTD Type (RTDs 7-12)

Resistance Value (ohms)	Expected Temperature Reading (°C)	Expected Temperature Reading (°F)	RTD Temperatures					
			7	8	9	10	11	12
71.81	-50	-58						
100.00	0	32						
131.45	50	122						
167.20	100	212						
207.45	150	302						
252.88	200	392						
294.28	240	464						

Table 7.14 10-Ohm Copper RTD Type (RTDs 1-6)

Resistance Value (ohms)	Expected Temperature Reading (°C)	Expected Temperature Reading (°F)	RTD Temperatures					
			1	2	3	4	5	6
7.10	-50	-58						
9.04	0	32						
10.97	50	122						
12.90	100	212						
14.83	150	302						
16.78	200	392						
18.34	240	464						

Table 7.15 10-Ohm Copper RTD Type (RTDs 7-12)

Resistance Value (ohms)	Expected Temperature Reading (°C)	Expected Temperature Reading (°F)	RTD Temperatures					
			7	8	9	10	11	12
7.10	-50	-58						
9.04	0	32						
10.97	50	122						
12.90	100	212						
14.83	150	302						
16.78	200	392						
18.34	240	464						

Power and Power Factor Measuring Accuracy

Accuracy Test, Wye Voltages

- Step 1. Connect the current sources to the IA, IB, and IC current inputs (5 A or 1 A, as indicated by the ITAP setting). Connect the voltage sources to the VA, VB, and VC inputs in wye configuration. Refer to *Figure 7.3*.
- Step 2. Using the front-panel Set Relay\Relay Elements\General Data function or serial port **SHOW** command, note the CTR, PTR, and PHROT settings.
- Step 3. Referring to *Table 7.16*, set the current and voltage source magnitudes. The phase angles you should apply depend on the PHROT setting. Use the front-panel Meter Values\Instantaneous Meter function to verify the relay measurements.

Table 7.16 Power Measuring Accuracy Test Values, Wye Voltages

Applied Currents and Voltages	Real Power (kW)	Reactive Power (kVar)	Power Factor (pf)
PHROT = ABC Ia = 2.5 A $\angle -26^\circ$ Ib = 2.5 A $\angle -146^\circ$ Ic = 2.5 A $\angle 94^\circ$ Va = 67 V $\angle 0^\circ$ Vb = 67 V $\angle -120^\circ$ Vc = 67 V $\angle 120^\circ$	Expected: $P = 0.4523 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: $Q = 0.2211 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: pf = 0.90 lag Measured:
PHROT = ACB Ia = 2.5 A $\angle -26^\circ$ Ib = 2.5 A $\angle 94^\circ$ Ic = 2.5 A $\angle -146^\circ$ Va = 67 V $\angle 0^\circ$ Vb = 67 V $\angle 120^\circ$ Vc = 67 V $\angle -120^\circ$	Expected: $P = 0.4523 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: $Q = 0.2211 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: pf = 0.90 lag Measured:

Accuracy Test, Delta Voltages

- Step 1. Connect the current sources to the IA, IB, and IC current inputs (5 A or 1 A, as indicated by the ITAP setting). Connect the voltage sources to the voltage inputs in delta configuration. Refer to *Figure 7.4 on page 7.6*.
- Step 2. Using the front-panel Set Relay\Relay Elements\General Data function or serial port **SHOW** command, note the CTR, PTR, and PHROT settings.
- Step 3. Referring to *Figure 7.4*, set the current and voltage source magnitudes. The phase angles you should apply depend on the PHROT setting. Use the front-panel Meter Values\Instantaneous Meter function to verify the relay measurements.

Table 7.17 Power Measuring Accuracy Test Values, Delta Voltages

Applied Currents and Voltages	Real Power (kW)	Reactive Power (kVar)	Power Factor (pf)
PHROT = ABC Ia = 2.5 A $\angle -26^\circ$ Ib = 2.5 A $\angle -146^\circ$ Ic = 2.5 A $\angle 94^\circ$ Vab = 120 V $\angle 30^\circ$ Vcb = 120 V $\angle 90^\circ$	Expected: $P = 0.4677 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: $Q = 0.2286 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: pf = 0.90 lag Measured:
PHROT = ACB Ia = 2.5 A $\angle -26^\circ$ Ib = 2.5 A $\angle 94^\circ$ Ic = 2.5 A $\angle -146^\circ$ Vab = 120 V $\angle -30^\circ$ Vcb = 120 V $\angle -90^\circ$	Expected: $P = 0.4677 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: $Q = 0.2286 \cdot \text{CTR} \cdot \text{PTR}$ Measured:	Expected: pf = 0.90 lag Measured:

This page intentionally left blank

Section 8

Metering and Monitoring

Introduction

The SEL-701 Relay features metering functions to display the present values of current and (if included) voltage and RTD measurements. The relay provides several methods to read the present meter values, including:

- Rotating front-panel display
- Front-panel menu
- EIA-232 serial port (using ACSELERATOR QuickSet® SEL-5030 Software or ASCII text command)
- Rear-panel EIA-232 (using ACSELERATOR QuickSet or ASCII text command) or EIA-485 port (using Modbus® protocol)
- Analog output

Motor load monitoring and trending are possible using the Load Profile function. The relay automatically configures itself to save available meter values every 15 minutes for 34 or 48 days.

For preventive maintenance purposes, the SEL-701 Relay provides a motor operating statistics report, available using the front panel or serial port.

Also helpful in preventive maintenance tasks, the SEL-701 Relay calculates and stores motor starting information. The relay retains motor start reports for the five latest motor starts. The motor start trending function stores motor start averages for the last eighteen 30-day periods.

Metering

SEL-701 Relay meter data fall into several categories:

- Instantaneous metering
- Demand metering
- Max/Min metering
- Thermal metering
- Energy metering

Details on each of the meter data types are shown below. *Section 5: Front-Panel Operations* and *Section 6: ASCII Serial Port Operation* describe how to access the various types of meter data using the relay front panel and serial ports.

Instantaneous Metering

Table 8.1 Measured Values

Relay Option	Meter Values
All Models	Ia, Ib, Ic, In Fundamental Magnitudes and Phase Angles; RMS Values Ig Residual Current Fundamental Magnitude and Phase Angle Negative-Sequence Current (3I2) Magnitude and Phase Angle Frequency % Unbalance
With Voltage Inputs (Relay Models 0701001 and 0701011)	Vab, Vbc, Vca Fundamental Magnitudes and Phase Angles; RMS Values Vg Residual Voltage Fundamental Magnitude and Phase Angle (wye-connection only) Negative-Sequence Magnitude and Phase Angle kW Fundamental and Average Values HP, kVAR, kVA, and pf

The relay displays both the fundamental frequency component and the RMS values of several measurands. The fundamental frequency signal has a defined magnitude and phase angle with respect to the other quantities. Reported phase angle is associated with the fundamental frequency magnitude, referenced to Vab or Ia at 0 degrees. RMS quantities do not have a defined phase angle. Reactive and apparent powers (kVAR and kVA) are not defined for RMS measurement.

Demand Metering

Table 8.2 Demand Meter Values

Relay Option	Demand Meter Values
All Models	Ia, Ib, Ic, In Fundamental Demand Magnitudes Ig Residual Current Fundamental Demand Magnitude Negative-Sequence Current (3I2) Fundamental Demand Magnitude
With Voltage Inputs (Relay Models 0701001 and 0701011)	kW, kVAR, kVA Fundamental Demand Magnitudes

Using the instantaneous fundamental current and power quantities (optional), the relay calculates new demand quantities every two seconds. The relay uses a thermal demand calculation algorithm with a settable time constant. You enter the Demand Meter Time Constant as a relay setting. The demand algorithm yields an output equal to 0.9 times the input quantity Demand Meter Time Constant minutes after the signal was applied, assuming the demand was reset initially. The demand metering function also records the peak values of each demand quantity. The demand metering data collected are added to nonvolatile memory at midnight.

Max/Min Metering

Table 8.3 Max/Min Recorded Values

Relay Option	Max/Min Values
All Models	Ia, Ib, Ic, In, Ig Fundamental Magnitudes
With RTD Monitoring (Relay Models 0701010 and 0701011) or when an SEL-2600 RTD module is connected	Up to 11 or 12 RTD Input Temperatures
With Voltage Inputs (Relay Models 0701001 and 0701011)	Vab, Vbc, Vca, Vg (wye-connection only) Fundamental Magnitudes kW, kVAR, kVA Fundamental Magnitudes

The relay records maximum and minimum instantaneous quantities while the following conditions are true:

- The motor is running
- Phase currents are greater than 3% of the Phase CT Secondary Rating, ITAP setting
- Phase voltages, if included, are greater than 13 Vac

Residual voltage is recorded only if three phase-neutral voltages are connected to the relay and residual voltage is greater than 3 Vac. RTD temperatures are only recorded if optional RTDs are connected and the connected RTD has not failed open or short.

Thermal Metering

Table 8.4 Thermal Meter Values

Relay Option	Thermal Values
All Models	% Full Load Amps % Thermal Capacity Used Calculated Time to Thermal Trip Minutes Since Last Start Starts This Hour Time to Reset
With RTD Monitoring (Relay Models 0701001 and 0701011) or when an SEL-2600 RTD module RTD Module is connected	All RTD Temperatures RTD % Thermal Capacity

NOTE: If the setting SETMETH=OFF, the relay will always report % Thermal Capacity=999.9 and Calculated Time to Thermal Trip (Seconds)=9999.

The thermal metering function reports the present values of the RTD input temperatures and several quantities related to the motor thermal protection function.

The thermal meter function also reports the state of connected RTDs if any have failed. Failure messages are shown in *Table 8.5*.

Table 8.5 RTD Input Status Messages

Message	Status
Open	RTD leads open
Short	RTD leads shorted
Comm. Fail	Fiber-optic communications to an SEL-2600 RTD module have failed
Stat Fail	SEL-2600 RTD module self-test status failure

Energy Metering

Table 8.6 Energy Meter Values

Relay Option	Energy Values
Without Voltage Inputs (Relay Models 0701000 and 0701010)	None
With Voltage Inputs (Relay Models 0701001 and 0701011)	MWahr, MVARhr-in, MVARhr-out, and MVAhr Magnitudes

When voltage inputs are selected and connected, the relay records the real, reactive, and apparent energy consumed by the motor.

Power Measurement Conventions

The SEL-701 Relay uses the IEEE convention for power measurement assuming motor action. The implications of this convention are described by Figure 8.1.




Figure 8.1 Power Measurement Conventions

In the SEL-701 Relay, reported positive power and energy are always into the motor.

Load Profiling

The SEL-701 Relay includes a built-in load profiling function that does not require any configuration. The relay automatically records selected quantities into nonvolatile memory every 15 minutes, synchronized to the quarter-hour. The relay memory is sized to hold data for the past 34 days for relays equipped with voltage inputs or 48 days for relays not equipped with voltage inputs before beginning to write over the oldest data. Download the load profile data using the serial port **LDP** command described in *Section 6: ASCII Serial Port Operation*.

Load profile data retained depends on the relay options you select. *Table 8.7* lists the load profile data retained for each relay option.

Table 8.7 Load Profile Data

Relay Option	Load Profile Values
All Models	Ia, Ib, Ic, In Fundamental Magnitudes % Thermal Capacity % Unbalance Frequency
With RTD Monitoring (Relay Models 0701010 and 0701011) or when anSEL-2600 RTD module is connected	Hottest Winding RTD Temperature Hottest Bearing RTD Temperature Ambient Temperature
With Voltage Inputs (Relay Models 0701001 and 0701011)	Vab, Vbc, Vca Fundamental Magnitudes kW, kVAR, and kVA

Figure 8.2 shows an example **LDP** serial port command response.

```
=>LDP <Enter>
SEL-701                               Date: 08/26/1999   Time: 16:32:38.364
MOTOR RELAY
Record Number,Date,Time,Ia,Ib,Ic,In,% Thermal Capacity,% Current Unbalance,Frequ
ency,Winding RTD,Bearing RTD,Ambient RTD,Vab,Vbc,Vca,kW,kVAR,kVA
3,08/26/1999,16:00:00,190,192,191,0,69,0,60.0,150,112,78,458,460,457,156,44,162
2,08/26/1999,16:15:00,192,194,190,0,70,0,60.0,151,112,79,460,464,460,156,44,161
1,08/26/1999,16:30:00,190,190,192,0,69,0,60.0,150,111,78,458,462,463,156,44,162
=>
```

Figure 8.2 LDP Command Response

Motor Operating Statistics

NOTE: While the relay power is off, the elapsed timers do not advance. If relay power is off for a significant time, the elapsed calendar time will not match the elapsed time recorded by the relay.

NOTE: The relay records motor operating statistics every six hours to nonvolatile memory. If the power is removed from the relay, the relay will lose the information collected between the last save and the time of the power removal.

The SEL-701 Relay retains useful information regarding the protected motor. The serial port **MOTOR** command and front-panel Motor Statistics commands make the stored data available. The data also appear in the Modbus memory map. Items included in the report are shown below.

Times and Totals

The relay records the total time that the motor is running and stopped in days, hours, and minutes, then divides the running time by the total time to indicate a percent time running. These figures provide an indication of the amount of use that the motor is receiving. The relay also records the total megawatt-hours consumed by the motor and the total number of motor starts that have taken place.

Average and Peak Data

To help you discern operational trends early, the relay records the average and peak of a number of key measurements, listed below. Some of these measurements are dependent on the presence of optional voltage inputs and RTD inputs. The relay stores average and peak values of:

- Starting time in seconds
- Starting current
- Minimum starting voltage
- Starting % Thermal Capacity (if the setting SETMETH=OFF, the relay will always report 0.0)
- Running % Thermal Capacity (if the setting SETMETH=OFF, the relay will always report 999.9).
- RTD % Thermal Capacity
- Running current
- Running kW, kVAR, and kVA
- Hottest winding RTD temperature
- Hottest bearing RTD temperature
- Ambient RTD temperature
- Hottest other RTD temperature

Learned Parameters

The SEL-701 Relay can learn two protection parameters of the protected motor. When you connect the relay to monitor at least one motor winding RTD and the ambient temperature, the relay can learn the cooling time of the protected motor when it is stopped. The relay can also learn the thermal element thermal capacity used when the motor starts. The motor statistics report includes both of these learned parameters.

Alarm and Trip Counters

The relay records the number and type of element alarms and trips that occur for the protected motor. The reported trip counter types are listed below. If the relay does not include optional voltage or RTD inputs, the motor statistics report does not include counter types for those elements. Those items marked with an (A) also have alarm counters.

- | | |
|----------------------------------|-----------------------------|
| ➤ Thermal Element ^A | ➤ Locked Rotor ^A |
| ➤ Load Loss ^A | ➤ Load Jam |
| ➤ Unbalance Current ^A | ➤ Phase Fault |
| ➤ Ground Fault | ➤ Speed Switch |
| ➤ Undervoltage | ➤ Overvoltage |
| ➤ Underpower ^A | ➤ Power Factor ^A |
| ➤ Reactive Power ^A | ➤ Phase Reversal |
| ➤ Underfrequency | ➤ Overfrequency |
| ➤ RTD ^A | ➤ Total ^A |

```

=>MOTOR <Enter>
SEL-701                               Date: 09/01/1999   Time: 16:00:14.625
MOTOR RELAY
Operating History, elapsed time in ddd:hh:mm   Since: 07/02/1999 10:56:15
Running time: > 0:01:58
Stopped time: 54:23:47
Time running: 0.1%
Total MWhr: 0.4
Number of starts: 10

Average      Peak
Starting time: 7.6      10.0
Starting current (A): 2762.1 3014.0
Min starting voltage (V): 476 463
Starting % thermal capacity: 76.5 84.0
Running % thermal capacity: 60.5 68.8
Rtd % thermal capacity: 45.3 54.2
Running current (A): 70.1 75.0
Running kW: 54.9 58.4
Running kVARin: 15.2 15.7
Running kVARout: 0.9 1.3
Running kVA: 56.8 57.9
Hottest winding RTD temp (F): 145 164
Hottest bearing RTD temp (F): 95 120
Ambient RTD temp (F): 79 98
Hottest other RTD temp (F): NA
Learned Motor Parameters
Stopped Cooling Time: 486
Starting Thermal Capacity: 62

Alarms      Trips
Thermal: 0 2
Locked rotor: 2 2
Load loss: 0 0
Load jam: 0 3
Unbalance current: 1 1
Phase fault: 0 0
Ground fault: 0 0
Speed switch: 0 0
Undervoltage: 0 0
Overvoltage: 36 0
Underpower: 0 0
Power factor: 0 0
Reactive power: 0 0
Phase reversal: 0 0
Underfrequency: 0 0
Overfrequency: 0 0
RTD: 28 0
Total: 31 44
=>

```

Figure 8.3 MOTOR Command Example

Motor Start Report

Each time the relay detects a motor start, it stores a motor start report. The five latest motor start reports are stored in nonvolatile memory. View any of the five latest motor start reports using the serial port **MSR n** command, where $n = 1-5$. Each report consists of two parts: a summary and the start data.

Summary Data

Each motor start report contains a summary. The summary shows the following information:

- Date and time of the start
- Number of motor starts since last reset
- Motor acceleration time
- Starting % Thermal Capacity
- Maximum Starting Current
- Minimum Starting Voltage, if voltages are present

The motor acceleration time is calculated from the time the starting current is detected until the running state is declared (see *Figure B.24 on page B.26 in Appendix B: SELOGIC Control Equations and Relay Logic*). The Starting % Thermal Capacity value is the thermal element capacity used at the end of the start, expressed in percent of the trip value.

Start Data

The motor start data is taken every 5 cycles for 3600 cycles, starting 5 cycles after the starting current is detected. The relay stores the following data every 5 cycles:

- Magnitude of A-, B-, and C-phase currents
- Magnitude of neutral current, I_N
- % Thermal Capacity
- Magnitude of AB, BC, and CA phase-to-phase voltages, if included

The start data is output in a comma-delimited text format for easy integration into computer spreadsheets for motor starting analysis.

Report Format

The motor start report comma delimited format makes the data easy to use with spreadsheets or other visualization software. Use the **MSR F** serial port command to view or capture the report format. The relay responds to the **MSR F** serial port command by sending a motor start report whose data fields are filled with zeroes. Executing the **MSR F** command does not affect the statistical data stored by the relay. *Figure 8.4* shows data from an example Motor Start Report.

```
=>MSR <Enter>
SEL-701                               Date: 07/21/1999   Time: 17:13:04.295
MOTOR RELAY
FID=SEL-701-R102-V11xxx-Z000000-D19990702   CID=DE83
Date of Motor Start:                        07/20/1999
Time of Motor Start:                        13:59:28.618
Starts Since Last Reset:                    7
Acceleration Time (s):                     8.0
Starting % Thermal Capacity:               72
Maximum Starting Current (A pri):          3001
Minimum Starting Voltage (V pri):          4702
Cycle,Ia (A pri),Ib (A pri),Ic (A pri),In (A pri),Vab (V pri),Vbc (V pri),Vca (V
pri),% Thermal Capacity
5,2999,2994,2990,0,4705,4706,4705,17
10,2999,2993,2990,0,4708,4710,4707,18
15,2999,2993,2989,0,4702,4706,4704,18
20,3000,2993,2989,0,4708,4710,4707,19
.
.
.
470,2884,2882,2880,0,4720,4718,4716,71
475,2878,2880,2878,0,4719,4716,4718,71
480,1017,1008,988,0,4750,4752,4754,72
485,348,350,347,0,4780,4782,4784,72
490,348,349,347,0,4782,4782,4784,72
.
.
.
3595,347,348,347,0,4782,4784,4782,70
3600,348,348,348,0,4780,4782,4784,70
```

Figure 8.4 Motor Start Report Example

Motor Start Trending

NOTE: All the trend data collected each day are added to nonvolatile memory at midnight. If relay power is removed, the information collected between midnight and power removal is lost.

Each time the relay stores a motor start report, it adds the motor start summary data (described in *Summary Data*) to the motor start trending buffer. The motor start trending function tracks motor start summary data for the past eighteen 30-day periods. For each 30-day interval, the relay records the date the interval began, the total number of starts in the interval, and the averages of the following quantities:

- Motor Acceleration Time
- Starting % Thermal Capacity
- Maximum Starting Current
- Minimum Starting Voltage (if voltages are present)

View the motor start trending data using the serial port **MST** command. *Figure 8.5* shows data from an example Motor Start Trend Report.

```

=>MST <Enter>
SEL-701                               Date: 08/27/1999   Time: 10:35:49.755
MOTOR RELAY

```

Record Number	Began on Date	Number of Starts	Accel Time (s)	Starting % Thermal Capacity	Maximum Current (A pri)	Minimum Voltage (VL-L pri)
1	08/02/1999	25	9.8	73	3002	4706
2	---	---	---	---	---	---
3	---	---	---	---	---	---
4	---	---	---	---	---	---
5	---	---	---	---	---	---
6	---	---	---	---	---	---
7	---	---	---	---	---	---
8	---	---	---	---	---	---
9	---	---	---	---	---	---
10	---	---	---	---	---	---
11	---	---	---	---	---	---
12	---	---	---	---	---	---
13	---	---	---	---	---	---
14	---	---	---	---	---	---
15	---	---	---	---	---	---
16	---	---	---	---	---	---
17	---	---	---	---	---	---
18	---	---	---	---	---	---

```

=>

```

Figure 8.5 Motor Start Trending Report Example

Section 9

Event Analysis

Introduction

The SEL-701 Relay provides several facilities to analyze the cause of relay operations. Use these tools to help diagnose the cause of the relay operation and more quickly restore the protected motor to service. Each tool, listed below, provides increasing detail regarding the causes of a relay operation.

- Front-panel target LEDs
- Front-panel display trip messages
- Front-panel history data menu
- Serial port text and oscillographic event reports
- Serial port sequential events recorder (SER) function

Front-Panel Target LEDs

Table 9.1 SEL-701 Relay Front-Panel Target LED Definitions

LED Label	Definition
Relay Enabled	Illuminated whenever the relay is in service. If this LED is not illuminated, the relay is out of service. Verify relay control power and self-test status.
Motor Energized	This LED remains off while the motor is stopped, flashes while the motor is starting, and remains on while the motor is running.
Thermal Overload	This LED flashes when the thermal element reaches the alarm level, or if any monitored, healthy RTD exceeds its alarm temperature. This LED remains on steadily after a thermal element trip, load jam trip, speed switch trip, or RTD temperature trip.
Overcurrent	This LED remains on steadily after a trip due to a short circuit fault detected by a phase, negative-sequence, residual, or neutral overcurrent element.
Unbalance	This LED flashes when the current unbalance alarm element picks up. This LED remains on steadily after a trip while the current unbalance element is picked up or after a phase reversal trip.
Load Loss	This LED flashes when a load loss alarm occurs or if the underpower alarm element picks up. This LED remains on steadily after a load loss trip or a trip while the underpower element is picked up.
Voltage	This LED flashes when a power factor or reactive power alarm occurs. This LED remains on steadily after a power factor or reactive power trip or a trip that occurs while an undervoltage or overvoltage element is picked up.
Frequency	This LED remains on steadily after a trip that occurs while an over- or underfrequency element is picked up.

Resetting Front-Panel Targets

NOTE: If you try to reset the relay targets and one or more of the red LEDs remains lit after the target reset command, the tripping condition or a lockout condition is still present. Correct the condition that caused the relay to trip and try again.

NOTE: The factory default relay logic causes relay trip signals to remain latched after the fault is cleared until you reset the relay targets. If this performance is not acceptable for your application, refer to *Appendix B: SELogic Control Equations and Relay Logic* for instructions on changing the factory default relay logic settings.

To reset the front-panel tripping targets, select the Reset Trip/Targets function from the front-panel display main menu, or execute the serial port **TARGET R** command. When you reset the relay targets using one of these methods:

- All tripping LEDs are extinguished if the trip condition has vanished and no lockout conditions remain.
- The front-panel display trip message (described in *Front-Panel Messages on page 9.2*) is cleared.

When you reset the LEDs using the front-panel menu function, the relay illuminates all the LEDs as a lamp test before clearing the targets.

Motor Energized LED

The Motor Energized LED is dark, flashes, or remains on to indicate the stopped, starting, or running condition of the motor. The relay determines the motor condition by measuring the positive-sequence current (I_1) and comparing the magnitude of the current to several thresholds defined by the Full Load Amps (FLA) setting.

STOPPED. When the relay word bit STOPPED is asserted, the relay declares the motor stopped. The Motor Energized LED is dark.

STARTING. When the relay word bit STARTING is asserted, the relay declares the motor starting. The Motor Energized LED flashes.

RUNNING. When the relay word bit RUNNING is asserted, the relay declares the motor running. The Motor Energized LED remains on continuously.

Refer to *Figure B.24 on page B.26 in Appendix B: SELogic Control Equations and Relay Logic* for a detailed logic diagram on STOPPED/STARTING/RUNNING.

Front-Panel Messages

Each time the relay trips in response to a fault, it automatically displays a front-panel message. The message describes the type of trip that occurred. Trip messages include:

- Thermal Trip
- Locked Rotor Trip
- Load-Loss Trip
- Load-Jam Trip
- Unbalance Trip
- Phase Fault Trip
- Ground Fault Trip
- Speed Switch Trip
- Undervoltage Trip
- Overvoltage Trip
- Underpower Trip

- Power Factor Trip
- Reactive Power Trip
- Phase Reversal Trip
- Underfrequency Trip
- Overfrequency Trip
- RTD Trip

The relay clears the trip-type message when you reset the tripping target LEDs.

History Data and Event Summaries

Each time the SEL-701 Relay trips, and in response to other selected conditions, the relay captures motor current, voltage (if included), RTD (if included), protection element, contact input, and contact output information. This collection of data is called an event report and is described in detail in *Event Reports on page 9.4*.

The relay stores the 14 most recent event reports and their summaries in nonvolatile memory. These reports are numbered 1 through 14, older reports having higher numbers. When the relay stores a new report, it discards the oldest report if 14 reports are already in memory.

The relay also stores an event summary associated with each event report. Each event summary contains selected data acquired at the instant the relay tripped or at the instant the event was triggered if a trip did not occur during the event. Use the summary data to help discern the cause of relay trip operations before you review the full event report.

View the present collection of event summaries using the front-panel History Data menu selection or the serial port **HISTORY** command. Each event summary contains:

- The type of event, from the list of event type strings in *Note 4 on page C.30 in Appendix C: Modbus RTU Communications Protocol*
- The event number, date, and time
- The system frequency
- The % Thermal Capacity used
- The % Unbalance Current
- The magnitudes of the phase, neutral, residual, and negative-sequence currents
- The temperatures of the hottest winding, bearing, ambient, and other RTDs, if included
- The magnitudes of the phase-to-phase voltages, if included
- The magnitudes of the real power, reactive power, and power factor, if voltages are included

Table 9.2 provides a list of event triggering commands and their equivalent names reported in the Event/History reports. For example, if the event is stored in response to execution of the serial port **TRIGGER** command, the Event/History report will list the event type as TRIG.

Table 9.2 Event Triggers

Event Trigger	Event Type
TRIGGER Command	TRIG
PULSE Command	PULSE
RISING EDGE of ER SELOGIC control equation	ER
STOP Command	STOP Command

If the event was stored in response to a rising edge of the TRIP SELOGIC control equation, but the trip type doesn't correspond to any of the trip messages in *Front-Panel Messages on page 9.2*, TRIP will be the listed trip type.

Event Reports

The SEL-701 Relay captures and stores detailed information concerning the relay measurements, protection element status, and contact input/output status. The relay stores the 14 most recent event reports in nonvolatile memory. Each report is numbered; older reports have higher numbers. After the relay reaches the storage limit, it discards the oldest report every time it captures a new report.

If you cannot determine the root cause of a relay trip operation after using the analysis tools described earlier in this section, analyze the event report associated with the trip. Each event report contains the following information:

- Date and time of the event
- Fifteen (15) cycles of current, voltage, protection element, input, and output data
- Event summary data, described in *History Data and Event Summaries on page 9.3*
- Relay settings

The following discussion covers these areas:

- What causes the relay to save an event report?
- How do I retrieve new event data?
- What does the event data mean?

ACSELERATOR QuickSet® SEL-5030 Software supports oscillographic event retrieval and analysis. Refer to the ACSELERATOR QuickSet Help function for more details.

Event Report Triggering

The relay triggers an event report when any of the following occur:

- The relay trips.
- A user executes the serial port **TRIGGER** command or serial port or front-panel **PULSE** command or **STOP** command.

Any of the programmable event triggering conditions occur (see below).

The factory default logic settings include settings that cause the relay to trigger an event report when any of the following conditions occur:

- Thermal Element Alarm
- Load-Loss Alarm
- Current Unbalance Alarm
- Underpower Element Alarm
- Reactive Power Element Alarm
- Power Factor Element Alarm
- Dropout of any Over- or Underfrequency Element

If your application requires different performance, you can change these settings by following the steps described in *Appendix B: SELOGIC Control Equations and Relay Logic*.

Retrieving Event Reports

Use the serial port **EVENT** command to retrieve event reports. There are several options for customizing the report format. The general command format is shown in *Table 9.3*. *Table 9.4* lists example **EVE** commands.

Table 9.3 Event Commands

Event <i>n</i> R	
where:	
<i>n</i>	Event number (1–14). Defaults to 1 if not listed, where 1 is the most recent
R	Specifies the unfiltered (raw) event report. Displays 16 samples per cycle.

Table 9.4 EVE Command Options

Serial Port Command	Description
EVE	Display the most recent event report at 1/4-cycle resolution.
EVE 2	Display the second event report at 1/4-cycle resolution.
EVE R	Display most recent report at 1/16-cycle resolution; analog data are not digitally filtered (raw).

The SEL-701 Relay also provides a facility to allow you to download event report data using Modbus® protocol and the rear-panel serial port. For more information, see *Appendix C: Modbus RTU Communications Protocol*.

Compressed ASCII Event Reports and History

The SEL-701 provides Compressed ASCII event reports to facilitate event report storage and display. SEL communications processors and the ACCELERATOR® Analytic Assistant SEL-5601 Software take advantage of the Compressed ASCII format, as shown in *Table 9.5*.

Table 9.5 Compressed ASCII Event Commands

Command	Description
CHI	Displays Compressed ASCII event history information.
CEV	Displays Compressed ASCII event reports.

Use the **CEV** command to obtain event report data in a Compressed ASCII response. These data are similar to those data produced by the **EVENT** command. When using the **CEV** command to retrieve event reports, the event data is in a format suitable for use by PC software to display the event in oscillographic form. The report length is 15 cycles.

Table 9.6 CEVENT Command

Command	Description	Access Level
CEV <i>n</i>	Return the filtered ac analog data, 4 sample/cycle event report number <i>n</i> .	1
CEV <i>n</i> R	Return the raw (unfiltered) ac analog data, 16 sample/cycle raw event report number <i>n</i> . Raw reports include an extra cycle of data at the beginning of the report.	1

Parameter *n* specifies the event report number. Use the **HIS** command to determine the event report number of the event you want to display. If *n* is not specified, the device displays Event Report 1.

See the *Compressed ASCII Commands in Appendix D: SEL Communications Processors* for further information. Compressed ASCII Event Reports contain all of the Device Word bits.

Event Report Data Column Definitions

The event report data is arranged in columns and rows. Each column includes a single type of data such as A-phase current samples or the state of two output contacts. Each row displays the measurements and results of a single instant in time. Event reports you view using the **EVENT** command contain four samples per power system cycle. Raw event reports and the compressed event format that ACSELERATOR QuickSet uses to display oscillographic information include data for 16 samples per power system cycle. In event reports, time runs down the page; first occurrences are shown at the top of the page, final conditions at the bottom. Events contain 4 cycles of pretrigger data and 11 cycles of posttrigger data to show the motor and system conditions before, during, and after the fault. Definitions and descriptions of the event report data columns are shown in *Table 9.7* and *Table 9.8*.

Current and Voltage Columns

Table 9.7 summarizes the event report current and voltage columns.

Table 9.7 Event Report Current and Voltage Columns

Column Heading	Definition
IA	Current measured by channel IA (primary A)
IB	Current measured by channel IB (primary A)
IC	Current measured by channel IC (primary A)
IG	Residual current (IA + IB + IC, primary A)
IN	Current measured by channel IN (primary A)
VA or VAB	Voltage measured by channel VA or VAB (primary V)
VB or VBC	Voltage measured by channel VB or VBC (primary V)
VC or VCA	Voltage measured by channel VC or calculated from VAB and VBC (primary V)

Output, Input, and Element Columns

Table 9.8 summarizes the event report output, input, and relay element control columns. Not all relays include all the element types.

Table 9.8 Output, Input, and Element Event Report Columns (Sheet 1 of 2)

Column Heading	Symbol	Definition
All columns	•	Element/input/output not picked up or not asserted.
Motor	S	Motor starting.
	R	Motor running.
	•	Motor stopped.
Load	J	Load Jam Trip picked up.
	l	Load Loss Alarm picked up.
	L	Load Loss Trip picked up.
46	A	Current Unbalance Alarm picked up.
	T	Current Unbalance Trip picked up.
47	T	Phase Reversal Trip.
49	A	Thermal Element Alarm picked up.
	T	Thermal Element Trip picked up.
50 O/C	Q	Negative-Sequence Definite-Time Overcurrent Element picked up and time delay expired.
	1	Level 1 Phase Definite-Time Overcurrent Element picked up and time delay expired.
	2	Level 2 Phase Definite-Time Overcurrent Element picked up and time delay expired.
	b	Both Level 1 and Level 2 Phase Overcurrent Elements picked up and time delays expired.
50G O/C	1	Level 1 Residual Overcurrent Element picked up and time delay expired.
	2	Level 2 Residual Overcurrent Element picked up and time delay expired.
	b	Both Level 1 and Level 2 Residual Overcurrent Elements picked up and time delays expired.
Wdg	w	A Winding RTD has exceeded the alarm temperature.
	W	One or two Winding RTDs have exceeded the trip temperature.
Brg	b	A Bearing RTD has exceeded the alarm temperature.
	B	One or two Bearing RTDs have exceeded the trip temperature.
Oth RTD	o	An Other RTD has exceeded the alarm temperature.
	O	One or two Other RTDs have exceeded the trip temperature.
Amb RTD	a	The Ambient RTD has exceeded the alarm temperature.
	A	The Ambient RTD has exceeded the trip temperature.
Out T1	T	TRIP contact output asserted.
	1	Contact output OUT1 asserted.
	b	Both TRIP and OUT1 asserted.

Table 9.8 Output, Input, and Element Event Report Columns (Sheet 2 of 2)

Column Heading	Symbol	Definition
Out 23	2	Contact output OUT2 asserted.
	3	Contact output OUT3 asserted.
	b	Both OUT2 and OUT3 asserted.
Out A	A	Contact output ALARM asserted.
In 12	1	Contact input IN1 asserted.
	2	Contact input IN2 asserted.
	b	Both IN1 and IN2 asserted.
In 34	3	Contact input IN3 asserted.
	4	Contact input IN4 asserted.
	b	Both IN3 and IN4 asserted.
In 56	5	Contact input IN5 asserted.
	6	Contact input IN6 asserted.
	b	Both IN5 and IN6 asserted.
In 7	7	Contact input IN7 (from an SEL-2600 series RTD module) asserted.

Filtered and Unfiltered Event Reports

The SEL-701 Relay samples the basic power system measurands (ac current and ac voltage) 16 times per power system cycle. The relay filters the measurands to remove transient signals. Four times per cycle the relay operates on the filtered values and reports them in the event report.

To view the raw inputs to the relay, use the unfiltered event report retrieved using the serial port command **EVENT *n* R**. Use the unfiltered event reports to observe:

- Power system harmonics on current and voltage channels
- Decaying dc offset during fault conditions on IA, IB, or IC

Raw event reports display one extra cycle of data at the beginning of the report.

Resetting the Event Report Buffer

The **HISTORY R** command clears the event summaries and corresponding event reports from nonvolatile memory. See *Section 6: ASCII Serial Port Operation* for more information on the **HISTORY** command.

Sequential Events Recorder (SER) Report

SER Triggering

The relay stores an entry in the SER report for a change of state of any one of the elements listed in the SER trigger setting as outlined in *Section 4: Settings Calculations*.

The relay adds a message to the SER to indicate power up or settings change conditions:

Relay newly powered up or settings changed

Each entry in the SER includes SER row number, date, time, element name or defined alias, and element state.

SER Trigger Condition Aliases

You may rename any of the SER trigger conditions using the SEL-701 Relay ALIAS settings. The relay permits up to 20 aliases to be assigned to conditions that trigger SER row entries. For instance, the factory default logic settings define contact input IN5 for operation as an Emergency Restart input. Factory default alias setting 15 renames input IN5 for reporting in the SER:

```
ALIAS15 =IN5 EMERGENCY_RSTART PICKUP DROPOUT
```

When input IN5 is asserted, the SER report will show the date and time of EMERGENCY_RSTART PICKUP. When input IN5 is deasserted, the SER report will show the date and time of EMERGENCY_RSTART DROPOUT. With this and other alias assignments, the SER record is easier for the operator to review. See *Section 4: Settings Calculations* for additional details regarding the alias settings.

Retrieving SER Reports

The relay saves the latest 512 rows of the SER report in nonvolatile memory. Row 1 is the most recently triggered row and Row 512 is the oldest. Use the serial port **SER** command to view the SER report by date or SER row number as outlined in the examples shown in *Table 9.9*.

Table 9.9 Retrieving SER Reports

Example SER Serial Port Commands	Format
SER	If you enter the SER command with no numbers following it, the relay displays all available rows, up to row number 512. The rows display with the oldest row at the beginning (top) of the report and the newest row (Row 1) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.
SER 17	If you enter the SER command with a single number following it, the relay displays that number of rows, if they exist. The rows display with the oldest row at the beginning (top) of the report and the newest row (Row 1) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.
SER 10 33	If you enter the SER command with two numbers following it, the relay displays all the rows between (and including) Rows 10 and 33, if they exist. The rows display with the oldest row (Row 33) at the beginning (top) of the report and the latest row (Row 10) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.
SER 47 22	If you enter the SER command with two numbers following it, the relay displays all the rows between (and including) Rows 47 and 22, if they exist. The rows display with the row (Row 22) at the beginning (top) of the report and the oldest row (Row 47) at the end (bottom) of the report. Reverse chronological progression through the report is down the page and in ascending row number.
SER 3/30/97	If you enter the SER command with one date following it, the relay displays all the rows on that date, if they exist. The rows display with the oldest row at the beginning (top) of the report and the latest row at the end (bottom) of the report, for the given date. Chronological progression through the report is down the page and in descending row number.
SER 2/17/97 3/23/97	If you enter the SER command with two dates following it, the relay displays all the rows between (and including) dates 2/17/97 and 3/23/97, if they exist. The rows display with the oldest row (date 2/17/97) at the beginning (top) of the report and the latest row (date 3/23/97) at the end (bottom) of the report. Chronological progression through the report is down the page and in descending row number.
SER 3/16/97 1/5/97	If you enter the SER command with two dates following it, the relay displays all the rows between (and including) dates 1/5/97 and 3/16/97, if they exist. The rows display with the latest row (date 3/16/97) at the beginning (top) of the report and the oldest row (date 1/5/97) at the end (bottom) of the report. Reverse chronological progression through the report is down the page and in ascending row number.

The date entries in the previous example SER commands depend on the Date Format setting DATE_F. If setting DATE_F is equal to MDY, you should enter the dates as in the above examples (Month/Day/Year). If setting DATE_F is equal to YMD, you should enter the dates Year/Month/Day. If the requested SER event report rows do not exist, the relay responds “No SER Data.”

Resetting the SER Report Buffer

Reset the SER data with the serial port **SER R** command.

Example Event Report

The example event report in *Figure 9.1* corresponds to the example Sequential Events Recorder (SER) report in *Figure 9.1*. The boxed numbers in *Figure 9.1* match the SER row numbers in *Figure 9.2*. Row explanations follow *Figure 9.2*.

In *Figure 9.1*, the arrow (>) in the column following the IN or Vc column identifies the “trigger” row, the row that corresponds to the Date and Time values at the top of the event report.

The asterisk (*) in the column following the Vc column identifies the row where the event summary data was taken. If the “trigger” row (>) and the summary row (*) are the same, the * symbol takes precedence.

SEL-701 MOTOR RELAY		Date: 07/07/1999 Time: 14:39:47.907										Event Date & Time		
												Relay Firmware ID		
FID=SEL-701-R100-V11Xxx-Z000000-D19990707		CID=1905										Relay Firmware Checksum		
		M L		O/C RTD		Out In								
		o o		t a444 555 WBOA										
Currents (A Pri)		Voltages (V Pri)		o d679 000 drtm T2A 1357										
IA	IB	IC	IG	IN	VA	VB	VC	r	d679	GN	gghb	13	246	
[1]	45.2	-180.6	145.2	9.8	-0.0	113	-265	151 R	.A..	1..	...	11, 10, 9, 8
	256.0	-63.8	-125.4	66.8	-0.0	237	-21	-218 R	.A..	1..	...	} One cycle of data
	-45.2	180.2	-144.8	-9.8	0.1	-113	265	-151 R	.A..	1..	...	
	-256.4	63.8	125.6	-67.0	0.0	-236	21	218 R	.A..	1..	...	
[2 cycles of event data removed]														
[4]	46.4	-180.6	144.4	10.2	0.1	114	-265	150 R	.A..	1..	...	
	255.6	-63.6	-124.6	67.4	0.0	236	-20	-219 R	.A..	1..	...	
	-46.8	180.8	-144.2	-10.2	-0.1	-114	265	-150 R	.A..	1..	...	
	-255.4	63.4	124.6	-67.4	-0.1	-236	20	219*R	.T..	b..	...	7, 6
[5]	46.8	-180.8	144.0	10.0	0.1	114	-265	150 R	.T..	b..	...	
	255.8	-63.0	-124.8	68.0	0.1	236	-20	-219 R	.T..	b..	...	
	-47.0	180.6	-144.0	-10.4	-0.1	-114	265	-150 R	.T..	b..	...	
	-255.8	62.8	124.8	-68.2	0.0	-236	20	219 R	.T..	b..	...	
[5 cycles of event data removed]														
[10]	48.2	-180.8	144.0	11.4	0.0	116	-265	149 R	.T..	b..	...	
	255.4	-62.4	-125.0	68.0	0.0	236	-19	-220 R	.T..	b..	...	5, 4, 3
	-48.0	180.8	-144.0	-11.2	0.0	-116	265	-149 R	.T..	b..	...	
	-192.4	29.2	111.8	-51.4	0.0	-236	19	220 R	T..	...	
[11]	49.0	-127.4	89.6	11.2	0.0	116	-265	148 R	T..	...	
	64.8	2.0	-49.6	17.2	0.0	238	-19	-220 R	T..	...	
	-25.4	36.8	-17.4	-6.0	0.0	-117	265	-148 R	T..	...	
	0.0	0.0	0.0	0.0	0.0	-239	18	220 R	T..	...	2, 1
[12]	0.0	0.0	0.0	0.0	-0.0	118	-265	148	T..	...	
	-0.2	0.0	0.0	-0.2	0.0	239	-18	-220	T..	...	
[3.5 cycles of event data removed]														

```

Event: UNBALANCED CURRENT
Frequency (Hz):      60.00
% Thermal Capacity:  69.0
% Unbalance Current: 15.3
  IA      IB      IC      IN      IG      3I2
Currents (A): 259.7 191.6 190.6 0.1 68.2 69.0
  Windings Bearing Ambient Other
Hottest RTD(F): 150 112 78 NA

      VAB      VBC      VCA
Voltages (V): 458 460 457

      kW      kVAR      kVA      PF
Power: 163.8 44.1 169.6 0.97 LAG

Relay Settings:
RID      =SEL-701
TID      =MOTOR RELAY
CTR      = 60      ITAP      = 5      CTRN      = 60      INTAP      = 5
PHROT    = ABC      FNOM      = 60      DATE_F    = MDY      DMTC      = 15
PTR      = 4      DELTA_Y  = Y      SINGLEV   = N
SETMETH  = RATING    FLA      = 5.00    SF         = 1.15    LRA        = 30.00
LRTHOT   = 12.0      LRTCOLD  = 14.4    TD         = 1.00    TCAPU      = 90
TCSTART  = 85      TCLRNEN  = Y      COOLTIME   = 800
50P1P    = OFF      50P2P    = OFF      50G1P      = 2.50    50G1D      = 0.10
50G2P    = OFF      50N1P    = 2.500    50N1D      = 0.10    50N2P      = OFF
50QP      = OFF
MAXSTART = 3      TBSDLY   = 20
LJTUPU   = 2.0      LJTDLY   = 1.00    LLAPU      = OFF
46UBA    = 10      46UBAD   = 2.50    46UBT      = 15      46UBTD     = 5.00
E47T     = Y
SPDSPLY  = OFF
RTDOPT   = INT      TMPREF    = F      RTD1LOC    = WDG      RTD2LOC    = WDG
RTD3LOC  = WDG      RTD4LOC  = WDG      RTD5LOC    = WDG      RTD6LOC    = WDG
RTD7LOC  = BRG      RTD8LOC  = BRG      RTD9LOC    = BRG      RTD10LOC   = BRG
RTD11LOC = AMB      RTD1TY   = PT100    RTD2TY     = PT100    RTD3TY     = PT100
RTD4TY   = PT100    RTD5TY   = PT100    RTD6TY     = PT100    RTD7TY     = NI120
RTD8TY   = NI120    RTD9TY   = NI100    RTD10TY    = NI100    RTD11TY    = PT100
TRTMP1   = 280      ALTMP1   = 250      TRTMP2     = 280      ALTMP2     = 250
TRTMP3   = 280      ALTMP3   = 250      TRTMP4     = 280      ALTMP4     = 250
TRTMP5   = 280      ALTMP5   = 250      TRTMP6     = 280      ALTMP6     = 250
TRTMP7   = OFF      ALTMP7   = 199      TRTMP8     = OFF      ALTMP8     = 199
TRTMP9   = OFF      ALTMP9   = 199      TRTMP10    = OFF      ALTMP10    = 199
TRTMP11  = OFF      ALTMP11  = OFF      EWDGV      = Y      EBRGV      = N
RTDBEN   = N
27P1P    = OFF      27P2P    = OFF      59GP       = OFF
59P1P    = 73      59P2P    = OFF
NVARAP   = OFF      NVARTP    = OFF
37PAP    = OFF      37PTP     = OFF
55LDAP   = OFF      55LDTP    = OFF
81D1P    = 59.10    81D1D     = 0.03    81D2P      = OFF      81D3P      = OFF
AOSIG    = 4-20MA    AOPARM     = %LOAD_I
FP_TO     = 15      FPBRITE    = 50      FP_KW      = N      FP_RTD     = N
DM1_1    =SEL-701    DM1_0      =
DM2_1    =MOTOR RELAY DM2_0      =
DM3_1    =RTD FAILURE DM3_0      =
DM4_1    =TIME BET STARTS LO DM4_0      =
DM5_1    =NUM OF STARTS LO DM5_0      =
DM6_1    =THERMAL LO DM6_0      =
TRFS      = Y      OUT1FS     = N      OUT2FS     = N      OUT3FS     = N
TDURD     = 0.50    ABSDLY     = 0
FACTLOG   = Y

```

Event Summary data taken from
last two samples of 4th cycle

Figure 9.1 Example Event Report

Example Sequential Events Recorder (SER) Report

This example SER report (*Figure 9.2*) corresponds to the event report in *Figure 9.1*.

SEL-701 MOTOR RELAY		Date: 07/07/1999	Time: 14:50:04.744	
FID=SEL-701-R100-V11Xxx-Z000000-D199907071 CID=1905				
#	DATE	TIME	ELEMENT	STATE
13	06/07/1999	14:34:32.786	MOTOR_STOPPED	ENDS
12	06/07/1999	14:34:32.786	MOTOR_STARTING	BEGINS
11	06/07/1999	14:34:42.795	MOTOR_RUNNING	BEGINS
10	06/07/1999	14:34:42.795	MOTOR_STARTING	ENDS
9	06/07/1999	14:39:45.398	UNBALNC_I_ALARM	PICKUP
8	06/07/1999	14:39:45.398	OUT1	Asserted
7	06/07/1999	14:39:47.907	UNBALNC_I_TRIP	PICKUP
6	06/07/1999	14:39:47.907	TRIP	Asserted
5	06/07/1999	14:39:48.007	UNBALNC_I_TRIP	DROPOUT
4	06/07/1999	14:39:48.007	UNBALNC_I_ALARM	DROPOUT
3	06/07/1999	14:39:48.007	OUT1	Deasserted
2	06/07/1999	14:39:48.028	MOTOR_STOPPED	BEGINS
1	06/07/1999	14:39:48.028	MOTOR_RUNNING	ENDS

Figure 9.2 Example Sequential Events Recorder (SER) Event Report

The SER event report rows in *Figure 9.2* are explained in the *Table 9.10*, numbered in correspondence to the # column. The numbered comments in *Figure 9.1* also correspond to the # column numbers in *Figure 9.2*. The SER event report in *Figure 9.2* contains records of events that occurred before the beginning of the event report in *Figure 9.1*.

Table 9.10 Example Sequential Events Recorder (SER) Event Report Explanations

Item #	Explanation
13, 12, 11, 10, 9, 8	After a 10-second accelerating time, the motor relay indicates the motor is running (11). Later, the current unbalance alarm element (46UBA, aliased as UNBALNC_I_ALARM) times out, causing the relay to close output contact OUT1, programmed to indicate protection element alarms (9, 8).
7, 6	The current unbalance trip element (46UBT, aliased as UNBALNC_I_TRIP) times out, causing the relay to trip. Since now both output contact OUT1 and TRIP are asserted, the relay places a 'b' in the T1 output column of the event report.
5, 4, 3	Declining current due to the opening contactor allows the unbalance detecting overcurrent elements to drop out and the relay deasserts output contact OUT1.
2, 1	As the current continues to drop, the relay declares the motor stopped.

Section 10

Maintenance and Troubleshooting

Routine Maintenance Checks

WARNING

Before working on a CT circuit, first apply a short to the secondary winding of the CT.

Because the SEL-701 Relay is equipped with extensive self-tests, the most effective maintenance task is to monitor the relay ALARM contact. The ALARM output contact closes when the relay is de-energized or when relay self-tests fail. If you are monitoring the ALARM contact, you know immediately if the relay is de-energized or detects a failure. In addition, we recommend review of relay event reports following faults. This review frequently reveals problems with equipment external to the relay such as voltage transformers and control wiring.

The SEL-701 Relay does not require specific routine tests, but your operational standards may require some periodic relay verification. If you need or wish to perform periodic relay verification, we recommend the following checks.

Relay Status Verification

Use the front-panel Status of Relay or serial port **STATUS** command to verify that the relay self-tests have not detected any out-of-tolerance conditions.

Meter Verification

Verify that the relay is measuring current signals and, if included, voltage signals by comparing the relay meter reading to the reading of a separate meter connected in series (for current circuits) or parallel (for voltage circuits) with the relay input.

Contact Input Verification

With the relay and motor off-line, short-circuit the individual relay contact inputs using a wire jumper or the connected switch or contact. Using the front-panel View Relay Word/Row 10 function, check the contact input status in the relay front-panel display. As you short-circuit each input, its label (IN1, IN2, IN3, etc.) should appear in the front-panel display.

Contact Output Verification

Use the front-panel Pulse Out Contact\Trip command to close the TRIP output contact. Repeat for the other output contacts. Make sure that each contact operates properly in its designated annunciation, control, or tripping circuit. See *Section 5: Front-Panel Operations* and *Section 6: ASCII Serial Port Operation* for more details regarding the **PULSE** command.

Periodic Data Capture

We recommend that you download information from the relay using the schedule shown in *Table 10.1*.

Table 10.1 Data Capture

Information Type	Download Schedule
Event Summaries (HIS)	As needed, to analyze relay trips.
Event Reports (EVE)	As needed, to analyze relay trips.
Sequential Events Recorder (SER)	As needed, to analyze relay operation.
Load Profile (LDP)	Every 30 days, clear the buffer when you download.
Motor Statistics (MOT)	Every 3-6 months or when you perform motor maintenance.
Motor Start Reports (MSR)	Following initial motor start, following any locked rotor trip, and for motor or system analysis.
Motor Start Trending (MST)	Every 3-6 months or when you perform motor maintenance.
Max/Min Meter (MET M)	Every 3-6 months or when you perform motor maintenance.
Relay Status (STA)	When you perform motor maintenance.

Self-Testing

The relay runs a variety of self-tests. As shown below, when the relay detects certain types of self-test failures, it closes the **ALARM** output b-contact. Monitoring this contact is the single most important relay maintenance activity that you can perform.

The relay takes the following actions for out-of-tolerance conditions in *Table 10.2*.

Protection Disabled

The relay:

- Disables all protection functions and stop/start logic.
- De-energizes all output contacts.
- Extinguishes the Relay Enabled front-panel LED.

ALARM Output

The **ALARM** output contact signals an alarm condition by going to its de-energized state.

- The **ALARM** output b-contact closes for an alarm condition; the **ALARM** output a-contact opens for an alarm condition or if the relay is de-energized.
- The relay generates a **STATUS** report at the serial port for failures.
- The relay displays failure messages on the relay display.

Use the serial port **STATUS** command or front-panel Status of Relay function to view the relay self-test status.

Table 10.2 Relay Self-Tests

Self-Test	Description	Limits	On Failure		
			Protection Disabled	ALARM Output	Front-Panel Message
DC Offset	Measures the dc offset at each of the input channels.	30 mV	No	Pulsed	OFFSET WARN
+5 V PS	Measures the +5 V power supply.	+4.65 V +5.65 V	Yes	Latched	+5V FAILURE
–5 V PS	Measures the –5 V power supply.	–4.65 V –5.40 V	Yes	Latched	–5V FAILURE
+15 V PS	Measures the +15 V power supply.	+14.00 V +16.00 V	Yes	Latched	+15V FAILURE
+28 V PS	Measures the +28 V power supply.	+24.00 V	Yes	Latched	+28V FAILURE
TEMP	Measures the temperature at the A/D voltage reference.	–50°C +100°C	Yes	Latched	TEMPERATURE FAILURE
RAM	Performs a read/write test on system RAM.		Yes	Latched	RAM FAILURE
ROM	Performs a checksum test on the relay program memory.	Checksum	Yes	Latched	ROM FAILURE
CR_RAM	Performs a checksum test on the active copy of the relay settings.	Checksum	Yes	Latched	CR_RAM FAILURE
EEPROM	Performs a checksum test on the nonvolatile copy of the relay settings.	Checksum	Yes	Latched	EEPROM FAILURE
Microprocessor Crystal	Monitors the microprocessor crystal.		Yes	Latched	CLOCK STOPPED
Microprocessor	The microprocessor examines each program instruction, memory access, and interrupt.	Test fails on detection of an invalid instruction, memory access, or spurious interrupt.	Yes	Latched	VECTOR nn
Clock Battery	Measures the real-time clock battery voltage.	Battery Voltage <2.50 V	No	Pulsed	—
Real-Time Clock	Verifies the real-time clock chip communication, time-keeping, and memory functions.		No	Pulsed	—
Learned Cool Time	Verifies the relay's ability to learn the motor cooling time.	Unable to write data to target address	No	Pulsed	—
Learned Thermal Capacity to Start	Verifies the relay's ability to learn the motor thermal capacity to start.	Unable to write data to target address	No	Pulsed	—

Troubleshooting Procedure

Relay Enabled Front-Panel LED Dark

Table 10.3 Relay Enabled Front-Panel LED Dark

Possible Cause	Solution
Input power not present or fuse is blown.	Verify input power and fuse continuity.
Self-test failure.	Check to see if the ALARM b-contact is closed. Use the front-panel Status of Relay function to view self-test results.

Cannot See Characters on Relay Front-Panel Display Screen

Table 10.4 Cannot See Characters on Relay Front-Panel Display Screen

Possible Cause	Solution
Relay front-panel has timed-out.	Press the {ESC} pushbutton to activate display.
Relay is de-energized.	Verify input power and fuse continuity.

Relay Does Not Accurately Measure Voltages or Currents

Table 10.5 Relay Does Not Accurately Measure Voltages or Currents

Possible Cause	Solution
Wiring error.	Verify input wiring.
Incorrect CTR, ITAP, CTRN, INTAP, or PTR setting.	Verify signal source ratios, connections, and associated settings.
Voltage neutral terminal (D09) not properly grounded.	Verify wiring and connections.

Relay Does Not Respond to Commands From Device Connected to Serial Port

Table 10.6 Relay Does Not Respond to Commands From Device Connected to Serial Port

Possible Cause	Solution
Communications device not connected to relay.	Verify cable connections.
Relay or communications device at incorrect baud rate or other communication parameter incompatibility, including cabling error.	Verify terminal setup and cable pinout.
Relay serial port has received an XOFF, halting communications.	Type <CTRL+Q> to send relay on XON and restart communications.
Rear-panel serial port protocol set differently than expected.	If you select Modbus® protocol, the rear-panel EIA-232 serial port is disabled. Use the EIA-485 port to communicate with the relay using Modbus, or use the front-panel EIA-232 port to communicate with the relay using ASCII text. See <i>Section 4: Settings Calculations</i> for more information on serial port configuration.

Relay Does Not Respond to Faults

Table 10.7 Relay Does Not Respond to Faults

Possible Cause	Solution
Relay improperly set.	Verify relay settings.
Improper test source settings.	Verify test source settings.
CT or PT input wiring error.	Verify input wiring.
Failed relay self-test.	Use the front-panel Status of Relay function to view self-test results.

Power Supply Fuse Replacement

The relay power supply is equipped with a fuse that you can replace without disassembling the relay. The fuse holder is located on the relay rear panel, immediately above the power supply input terminals, D01–D03. Using a flat-blade screwdriver, push the fuse holder in slightly, then turn counterclockwise. After replacing the fuse, insert the fuse holder into the hole and, with a flat-blade screwdriver, turn clockwise to lock it in place.

Replacement Fuse Specifications: T 2 A 250 V, high breaking capacity. The following manufacturers' part numbers are suitable replacement fuses:

Manufacturer	P/N	Comment
Schurter, Inc.	0001.2507	Original Equipment
Wickman USA, Inc.	181.1200.0.02	
Bussman	5505 2A	
Littelfuse	215 002	

Contact SEL for replacement fuses if you have difficulty obtaining an equivalent replacement locally. Use only high breaking capacity replacement fuses.

Real-Time Clock Battery Replacement

A lithium battery powers the relay clock (date and time) if the external power source is lost or removed. The battery is a 3 V lithium coin cell, Rayovac No. BR2335 or equivalent. At room temperature (25°C), the battery will operate nominally for 10 years at rated load. When the relay is powered from an external source, the battery only experiences a low self-discharge rate. Thus, battery life can extend well beyond the nominal 10 years because the battery rarely has to discharge after the relay is installed. The battery cannot be recharged.

CAUTION

The relay contains devices sensitive to Electrostatic Discharge (ESD). When working on the relay with the front panel removed, work surfaces and personnel must be properly grounded or equipment damage may result.

WARNING

Be sure to carefully align the front panel with the relay chassis during reassembly. If the front panel is not well aligned with the chassis, you may bend connector pins, causing the relay to fail.

If the relay does not maintain the date and time after power loss, or if the relay self-tests indicate an RTC Battery Warning, replace the battery following the steps listed below.

- Step 1. De-energize the relay.
- Step 2. Remove two front-panel retaining screws with a Phillips screwdriver from the relay front panel. Carefully remove the relay front panel from the relay chassis.
- Step 3. The relay main board and display are attached to the inside of the relay front panel. The battery is located on the upper left-hand side of the relay main board. Carefully remove the battery from beneath the clip. Properly dispose of the old battery; it is not rechargeable.
- Step 4. Install the new battery with the positive (+) side of the battery facing up.
- Step 5. Carefully replace the relay front panel on the relay chassis. Install and tighten the front-panel retaining screws with a Phillips screwdriver.
- Step 6. Reenergize the relay. Set the relay date and time using the front-panel Set Relay\Date and Set Relay\Time functions.

Firmware Upgrade Installation

SEL occasionally offers firmware upgrades to improve the performance of your relay. Since the SEL-701 Relay stores firmware in flash memory, changing physical components is not necessary. Upgrade the relay firmware by downloading a file from a personal computer to the relay via the front-panel serial port as outlined in the following sections.

Required Equipment

- Personal computer
- Terminal emulation software that supports XMODEM/CRC protocol
- Serial communications cable (SEL-C234A or equivalent, or a null-modem cable)
- Disk containing firmware upgrade file

Upgrade Instructions

NOTE: Always review the latest settings in the relay, including ranges, so you can update them for the firmware upgrade. For details on firmware releases and associated settings changes, see Appendix A: Firmware and Manual Versions and the Product Revision Release Notes.

The instructions below assume you have a working knowledge of your personal computer terminal emulation software. In particular, you must be able to modify your serial communications parameters (baud rate, data bits, parity, etc.), select transfer protocol (XMODEM/CRC), and transfer files (e.g., send and receive binary files).

- Step 1. If the relay is in service, open its motor control circuits.
- Step 2. Connect the personal computer to the front-panel serial port and enter Access Level 2.
- Step 3. Save the relay settings before upgrading the firmware.
Save settings with SEL-5010 Relay Assistant Software, or SEL-5807 PC Software for SEL-701(for R112 and earlier), or ACSELERATOR® QuickSet SEL-5030 Software (for R112 and later).
- Step 4. Using the **STATUS** command at the ASCII prompt, check the firmware version.
If your SEL-701 Relay contains R105 firmware or earlier, your current relay settings will be erased during the upgrade procedure.
If the relay successfully retains the original settings after an upgrade, please review and revise the settings as required depending on settings changes in the relay firmware. The relay does not automatically flag out-of-range settings after or during an upgrade; therefore, it is critical to review the settings and new ranges.
Also, if your current firmware is R103 or earlier, please record the calibration settings by issuing the **SHO C** command at the ASCII prompt.
- Step 5. Issue the **L_D <Enter>** command to the relay (L underscore D <Enter>).
- Step 6. Type **Y <Enter>** to the `Disable relay to send or receive firmware (Y/N)?` prompt and **Y <Enter>** to the `Are you sure (Y/N)?` prompt. The relay will send the SELBOOT prompt !>.
- Step 7. Type **BAU 38400 <Enter>**. This will change the baud rate of the communications port to 38400. Change the baud rate of your PC to 38400 to match the relay.
- Step 8. Make a copy of the firmware currently in the relay. This is recommended in case the new firmware download is unsuccessful. To make a backup of the firmware, you will need approximately 2.3 MB of free disk space. The procedure takes less than 10 minutes at 38400 baud.
Issue the **SEN <Enter>** command to initiate the firmware transfer. Select the binary XMODEM transfer and filename in your communications software. Give the file a unique name to clearly identify the firmware version (e.g., 701R100.S19). After the transfer, the relay will respond “Download completed successfully!”
- Step 9. Begin the transfer of new firmware to the relay by issuing the **REC <Enter>** command to instruct the relay to receive new firmware.
- Step 10. Type **Y** to erase the existing firmware or just **<Enter>** to abort.

Step 11. The relay then prompts you to press a key and begin the transfer. Press a key (e.g., <Enter>).

Step 12. Start the file transfer by selecting the send file option in your communications software. Use the XMODEM protocol and send the file that contains the new firmware (e.g., 701R101.S19).

The file transfer takes less than 10 minutes at 38400 baud. After the transfer is complete, the relay will reboot and return to Access Level 1. The following screen capture shows the entire process. If you require additional commands during the upload/download process, type **HELP** to view the available commands.

```
=>>L_D <Enter>
Disable relay to send or receive firmware (Y/N) ? Y <Enter>
Are you sure (Y/N) ? Y <Enter>
Relay Disabled
!>BAU 38400 <Enter>
!>SEN <Enter>
Download completed successfully!
!>REC <Enter>
Caution! - This command erases the relay's firmware.
If you erase the firmware, new firmware must be loaded into the relay
before it can be put back into service.
Are you sure you wish to erase the existing firmware? (Y/N) Y <Enter>
Erasing
Erase successful
Press any key to begin transfer, then start transfer at the PC <Enter>
Upload completed successfully. Attempting a restart
```

Step 13. The relay illuminates the Relay Enabled front-panel LED if the relay settings were retained through the download. If the Relay Enabled LED is illuminated, proceed to *Step 14*. If the Relay Enabled LED is not illuminated or the front-panel display says, STATUS FAIL EEPROM FAILURE, reload the relay settings using the procedure below.

- a. Set your communications software settings to 2400 baud, 8 data bits, 1 stop bit.
- b. Enter Access Level 2 by issuing the **2AC** command.
- c. Issue the **R_S** command to restore the factory default settings in the relay. The relay will then reboot with the factory default settings.
- d. If the message, Calibration settings lost, please call the factory! appears during the restart, please contact the factory. (See *Factory Assistance on page 10.9*.)
- e. Enter Access Level 2.
- f. Issue a **STA** command and verify that relay status is OK.
- g. Set the relay clock and calendar using the **DATE** and **TIME** commands.
- h. Set the Relay, Port, and SER settings using ACSELERATOR QuickSet, SEL-5010 software, or the following commands: **SET**, **SET P F**, **SET P R**, **SET R**.
- i. Set the relay passwords via the **PAS** command.

Step 14. Set your communications software settings (baud rate, number of data bits, number of stop bits) to agree with the port settings of the SEL-701 Relay.

NOTE: To load saved settings for firmware versions prior to R112 (prior to SVN 003) into ACSELERATOR QuickSet from an old 701PC database, follow these steps.

- 1 File > Active Database** to start ACSELERATOR QuickSet. Make the old 701PC database the active database.
- 2 File > Database Manager** and choose the settings to import into the new driver. Click **Export** and save the five settings files to a user-specified location.
- 3** Open a new 701 driver by selecting the desired SVN and part number. **Tools > Import** to import the files. Accept the settings and resolve any existing errors.

- Step 15. Execute the **STATUS** command to verify all relay self-test results are okay.
- Step 16. Apply current and voltage signals to the relay. Issue the **METER** command; verify that current and voltage signals are correct. Issue the **TRIGGER** and **EVENT** commands. Verify that current and voltage signals are correct in the **EVENT** report.
- Step 17. If an SEL communications processor (SEL-2032, SEL-2030, or SEL-2020) is connected to the SEL-701 Relay, re-auto-configure the communications processor port. This step will prevent a future auto-configuration failure of the communications processor when its power is cycled and the new SEL-701 Relay firmware does not match the original configuration.

The relay is now ready for your commissioning procedure.

Factory Assistance

We appreciate your interest in SEL products and services. If you have any questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 USA
Tel: +1.509.332.1890
Fax: +1.509.332.7990
Internet: www.selinc.com
Email: info@selinc.com

This page intentionally left blank

Appendix A

Firmware and Manual Versions

Firmware

Determining the Firmware Version in Your Relay

To find the firmware revision number in your relay, view the status report using the serial port **STATUS** command or the front-panel Status of Relay function. The status report displays the FID label with the Part/Revision number in bold, for example:

FID=SEL-701-**R100-Vx1xxx-Z000000-D199907078**

Table A.1 lists the firmware versions, a description of modifications, and the instruction manual date code that corresponds to firmware versions. The most recent firmware version is listed first.

Table A.1 Firmware Revision History (Sheet 1 of 3)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
Base Version SEL-701-R116-Vx0xxx-Z004002-D20100924 Voltage Option SEL-701-R116-Vx1xxx-Z004002-D20100924	Manual update only. See <i>Table A.2</i> for a summary of manual updates.	20151002
Base Version SEL-701-R116-Vx0xxx-Z004002-D20100924 Voltage Option SEL-701-R116-Vx1xxx-Z004002-D20100924	Manual update only. See <i>Table A.2</i> for a summary of manual updates.	20110125
Base Version SEL-701-R116-Vx0xxx-Z004002-D20100924 Voltage Option SEL-701-R116-Vx1xxx-Z004002-D20100924	<ul style="list-style-type: none"> Corrected an issue where the setting FNOM = 50Hz registers a START with no current applied when the control power is turned on. 	20100924
Base Version SEL-701-R115-Vx0xxx-Z004002-D20090330 Voltage Option SEL-701-R115-Vx1xxx-Z004002-D20090330	<ul style="list-style-type: none"> Improved energy metering resolution from 100 kWh to 1 kWh. 	20090330
Base Version SEL-701-R114-Vx0xxx-Z004002-D20070420 Voltage Option SEL-701-R114-Vx1xxx-Z004002-D20070420	<ul style="list-style-type: none"> Added conformal coating option. 	20070420
Base Version SEL-701-R113-Vx0xxx-Z004002-D20061027 Voltage Option SEL-701-R113-Vx1xxx-Z004002-D20061027	<ul style="list-style-type: none"> Added ACSELERATOR QuickSet SEL-5030 Software support to SEL-701 for firmware versions R112 and greater. SEL-5807 701 PC Software will not support SEL-701 beyond firmware version R112. Added new Loss of Potential (LOP) element and Relay Word bit to supervise and restrain protection, such as 27P1 for a blown PT fuse event. Added Relay Word bit 50CD to enhance Breaker Failure logic monitoring. 	20061027

Table A.1 Firmware Revision History (Sheet 2 of 3)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
	<ul style="list-style-type: none"> ➤ Enhanced thermal element protection during phase reversal condition by adding negative sequence current magnitude to 50S element and to Motor State logic. ➤ Added hysteresis to 49A (Thermal Alarm) logic to eliminate occasional nuisance alarms due to chatter. ➤ Improved saving of motor operating statistics to non-volatile memory from twenty-four hours to every six hours. ➤ Revised DC offset self-test threshold to 30 mV and made it a WARNING instead of a FAILURE. ➤ There are no settings changes in this revision of firmware. 	20061027
Base Version SEL-701-R112-Vx0xxx-Z003002-D20050819 Voltage Option SEL-701-R112-Vx1xxx-Z003002-D20050819	<ul style="list-style-type: none"> ➤ Added thermal element trip value ramping during start to improve thermal protection. ➤ Added following default settings: <ul style="list-style-type: none"> ➢ /TRIP (Relay Word) to ER equation ➢ DM4, DM5, DM6 ➢ SER4 ➢ ALIAS 18, ALIAS 19, ALIAS 20 ➤ Revised following setting values: <ul style="list-style-type: none"> ➢ SF range ➢ 37PAD, 37PTD range ➢ LLTDLY, LLADLY range ➤ Added "Time to Reset" for Lockout timer in Modbus map and METER T report. 	20050819
Base Version SEL-701-R111-Vx0xxx-Z002001-D20040713 Voltage Option SEL-701-R111-Vx1xxx-Z002001-D20040713	<ul style="list-style-type: none"> ➤ Corrected settings file transfer. 	20040713
Base Version SEL-701-R110-Vx0xxx-Z002001-D20040610 Voltage Option SEL-701-R110-Vx1xxx-Z002001-D20040610	<ul style="list-style-type: none"> ➤ Corrected Learned Parameter for TCSTART. 	20040610
Base Version SEL-701-R109-Vx0xxx-Z002001-D20030912 Voltage Option SEL-701-R109-Vx1xxx-Z002001-D20030912	<ul style="list-style-type: none"> ➤ Improved Motor State Logic. ➤ Enhanced CT saturation protection to improve security with low-set instantaneous values. 	20030912
Base Version SEL-701-R108-Vx0xxx-Z002001-D20030728 Voltage Option SEL-701-R108-Vx1xxx-Z002001-D20030728	<ul style="list-style-type: none"> ➤ Improved Motor State Logic. 	20030728
Base Version SEL-701-R107-Vx0xxx-Z002001-D20020517 Voltage Option SEL-701-R107-Vx1xxx-Z002001-D20020517	<ul style="list-style-type: none"> ➤ Added Breaker Failure Function ➤ Added Alarm Contact Setting ➤ Added peak detector function ➤ Added ability to turn off thermal model. 	20020517
Base Version SEL-701-R106-Vx0xxx-Z001000-D20010223 Voltage Option SEL-701-R106-Vx1xxx-Z001000-D20010223	Manual update only. See <i>Table A.2</i> for a summary of manual updates.	20010719
Base Version SEL-701-R106-Vx0xxx-Z001000-D20010223 Voltage Option SEL-701-R106-Vx1xxx-Z001000-D20010223	<ul style="list-style-type: none"> ➤ Corrected the threshold calculation for the RATING method of the thermal model. 	20010223

Table A.1 Firmware Revision History (Sheet 3 of 3)

Firmware Identification (FID) Number	Summary of Revisions	Manual Date Code
Base Version SEL-701-R105-Vx0xxx-Z001000-D20001102 Voltage Option SEL-701-R105-Vx1xxx-Z001000-D20001102	<ul style="list-style-type: none"> ➤ Added TARR SELOGIC® control equation. ➤ Increased range of FLA and LRA settings. ➤ Increased number of display messages to six. Nickel 100 RTD measurement now complies with DIN 43760. ➤ Increased motor starting criterion from 3% to 10% of FLA. 	20001102
Base Version SEL-701-R104-Vx0xxx-Z000000-D19991210 Voltage Option SEL-701-R104-Vx1xxx-Z000000-D20001102	<ul style="list-style-type: none"> ➤ Improve Power Factor Accuracy ➤ Modify TRIP and 27P1P defaults to provide supervision during loss-of-field condition. 	991210
Base Version SEL-701-R103-Vx0xxx-Z000000-D19990830 Voltage Option SEL-701-R103-Vx1xxx-Z000000-D19990830	<ul style="list-style-type: none"> ➤ Corrected MST “Began on Date” function. ➤ Corrected CME M command response. ➤ Corrected CME T command response. 	990702 Errata Pages dated 990806
Base Version SEL-701-R102-Vx0xxx-Z000000-D19990730 Voltage Option SEL-701-R102-Vx1xxx-Z000000-D19990730	<ul style="list-style-type: none"> ➤ Modified front-panel password entry function. ➤ Added MSR F command support. ➤ Added “Began on Date” to MST command response. 	990702
Base Version SEL-701-R101-Vx0xxx-Z000000-D19990719 Voltage Option SEL-701-R101-Vx1xxx-Z000000-D19990719	<ul style="list-style-type: none"> ➤ Corrected internal RTD diagnostic. 	990702
Base Version SEL-701-R100-Vx0xxx-Z000000-D19990707 Voltage Option SEL-701-R100-Vx1xxx-Z000000-D19990707	<ul style="list-style-type: none"> ➤ Initial version. 	990702

Instruction Manual

The date code at the bottom of each page of this manual reflects the creation or revision date.

Each time revisions are made, both the main table of contents and the affected individual section table of contents are regenerated and the date code is changed to reflect the revision date.

Table A.2 lists the instruction manual release dates and a description of modifications. The most recent instruction manual revisions are listed at the top.

Table A.2 Instruction Manual Revision History (Sheet 1 of 5)

Revision Date	Summary of Revisions
20151002	<p>Section 1</p> <ul style="list-style-type: none"> ➤ Updated <i>SEL-701 Relay Serial Number and Compliance Labels</i>. ➤ Updated <i>Compliance in Specifications</i>. <p>Section 2</p> <ul style="list-style-type: none"> ➤ Updated the contact connections table in <i>Wire Sizes and Insulation</i>. <p>Section 3</p> <ul style="list-style-type: none"> ➤ Updated <i>Table 3.1: SEL Software Solutions</i> and <i>Table 3.2: ACSELERATOR QuickSet Software</i>. <p>Section 4</p> <ul style="list-style-type: none"> ➤ Updated <i>Current Transformer (CT) Configuration Settings</i>. ➤ Added a note on RTD curves to <i>RTD Location Settings</i>.

Table A.2 Instruction Manual Revision History (Sheet 2 of 5)

Revision Date	Summary of Revisions
	<p>Section 10</p> <ul style="list-style-type: none"> ➤ Added a note on CT circuits to <i>Routine Maintenance Checks</i>. <p>Appendix B</p> <ul style="list-style-type: none"> ➤ Updated <i>Figure B.1: Relay Processing Order</i>. ➤ Updated <i>Figure B.9: Remote Control Switches Drive Remote Bits RB1 Through RB4</i>.
20110125	<p>Section 1</p> <ul style="list-style-type: none"> ➤ Updated <i>Type Test</i> lists. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Added Access Level CAL information. <p>Command Summary</p> <ul style="list-style-type: none"> ➤ Added Access Level CAL information.
20100924	<p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R116.
20090330	<p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R115. <p>Appendix E</p> <ul style="list-style-type: none"> ➤ Updated to include motor thermal element trip-time equations.
20070420	<p>Section 1</p> <ul style="list-style-type: none"> ➤ Updated for conformal coating option. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R114.
20061027	<p>Section 2</p> <ul style="list-style-type: none"> ➤ Added wire sizes and insulation. ➤ Updated information on <i>Current Transformer Inputs</i>. <p>Section 3</p> <ul style="list-style-type: none"> ➤ Added ACSELERATOR QuickSet SEL-5030 Software information. <p>Section 4</p> <ul style="list-style-type: none"> ➤ Updated Thermal Element Rating Setting Method and Overcurrent Elements. ➤ Updated <i>Loss-of-Potential (LOP) Protection</i> section. <p>Section 8</p> <ul style="list-style-type: none"> ➤ Updated information on Motor Operating Statistics. ➤ Added Relay Word Bits, LOP and 50CD. ➤ Updated <i>Figure 8.1: Power Measurement Conventions</i>. <p>Section 9</p> <ul style="list-style-type: none"> ➤ Added information on CEV command. <p>Section 10</p> <ul style="list-style-type: none"> ➤ Updated Relay Self-Test. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R113. <p>Appendix B</p> <ul style="list-style-type: none"> ➤ Updated logic diagrams. <p>Appendix E</p> <ul style="list-style-type: none"> ➤ Clarified difference between motor states and thermal element starting and running models under Basic Thermal Element. <p>Command Summary</p> <ul style="list-style-type: none"> ➤ Added CEV command.
20050819	<p>Section 1</p> <ul style="list-style-type: none"> ➤ Updated settings range changes. <p>Section 3</p> <ul style="list-style-type: none"> ➤ Updated PC Software (SEL-5807) requirements. <p>Section 4</p> <ul style="list-style-type: none"> ➤ Updated settings range changes, default settings changes, and thermal model descriptions. <p>Section 6 and 8</p> <ul style="list-style-type: none"> ➤ Updated MET T report with “Time to Reset.” <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R112.

Table A.2 Instruction Manual Revision History (Sheet 3 of 5)

Revision Date	Summary of Revisions
	Appendix B ➤ Updated for default settings changes and minor edits. Appendix C ➤ Added “Time to Reset” to Modbus Map. Appendix E ➤ Updated with minor edits. Appendix F ➤ Updated setting sheets with settings range changes and default settings changes.
20040713	Appendix A ➤ Updated for firmware version R111.
20040610	Appendix A ➤ Updated for firmware version R110.
20030912	Section 2 ➤ Updated Current Transformer Inputs. Section 4 ➤ Updated Overcurrent Elements. Appendix A ➤ Updated for firmware version R109. Appendix B ➤ Added two timers in <i>Figure B.23: Motor State Logic</i>
20030728	Section 4 ➤ 52A SELOGIC setting guideline added. Section 5 ➤ ESC button operation in <i>Table 5.1: Front-Panel Automatic Message</i> added. Appendix A ➤ Updated for firmware version R108. Appendix B ➤ Definition of STARTING, RUNNING, and STOPPED Relay Word Bits in <i>Table B.1: SEL-701 Relay Word Bits</i> revised. ➤ 50Q Logic of overcurrent element in <i>Table B.1: SEL-701 Relay Word Bits</i> added ➤ <i>Figure B.23: Motor State Logic</i> added.
20020517	Section 1 ➤ Specifications updated; <i>Transient Overreach</i> Specification added. Section 2 ➤ Current Transformer Inputs updated. Section 4 ➤ Generic Thermal Limit Curve updated. ➤ Breaker Failure setting added. ➤ Alarm Contact setting added. ➤ Thermal Model settings updated. Section 6 ➤ SHOW command example updated. Section 7 ➤ Thermal Model setting SETMETH note added. Appendix A ➤ Updated for firmware version R107. Appendix B ➤ Breaker Failure Relay Word Bits added. ➤ Breaker Failure Logic Figure added. Appendix D ➤ Fast Meter message corrected. ➤ Breaker Failure added to DNA message. ➤ Raw option added to CEV command.

Table A.2 Instruction Manual Revision History (Sheet 4 of 5)

Revision Date	Summary of Revisions
	Appendix F <ul style="list-style-type: none"> ➤ Enable Winding and Enable Bearing Trip Voting Settings corrected. ➤ Factory Logic Settings added. ➤ Breaker Failure Setting added. ➤ Alarm Contact Setting added. ➤ Thermal Model Settings updated.
20010719	<ul style="list-style-type: none"> ➤ Replaced Standard Product Warranty page with warranty statement on cover page. Section 10 <ul style="list-style-type: none"> ➤ Updated Firmware Upgrade Instructions.
20010223	Appendix A <ul style="list-style-type: none"> ➤ Updated for firmware version R106.
20001102	Section 1 <ul style="list-style-type: none"> ➤ Functional description diagram added. ➤ Specifications updated; section name changed from <i>Detailed Specifications</i> to <i>Specifications</i>. Section 3 <ul style="list-style-type: none"> ➤ SEL-5807 Software features updated. Section 4 <ul style="list-style-type: none"> ➤ Thermal model settings updated. ➤ Load-loss settings updated. ➤ Contact input IN7 shown on SEL-2600 series RTD Module. ➤ Nickel 100 RTD resistance in <i>Table 4.26: RTD Type Settings</i> updated to DIN 43760. ➤ Display message settings five and six added. Section 9 <ul style="list-style-type: none"> ➤ Display message settings five and six added. ➤ Stopped threshold to 10% of Full Load Amps revised. ➤ List of possible trip types displayed in the history report expanded. Section 10 <ul style="list-style-type: none"> ➤ Recommended data download schedule added. Appendix A <ul style="list-style-type: none"> ➤ Updated for firmware version R105. Appendix B <ul style="list-style-type: none"> ➤ TARR SELOGIC control equation added. ➤ Display message settings five and six added. ➤ Stopped threshold to 10% of Full Load Amps revised. Appendix C <ul style="list-style-type: none"> ➤ Date/time section from Modbus® deleted. ➤ Event type strings corrected. Appendix F <ul style="list-style-type: none"> ➤ Thermal model settings updated. ➤ Load-loss settings updated. ➤ Display message settings five and six added.
991210	Section 1 <ul style="list-style-type: none"> ➤ Detailed Specifications updated. Section 2 <ul style="list-style-type: none"> ➤ <i>Table 2.1: Typical Maximum RTD Lead Lengths</i> added. Section 6 <ul style="list-style-type: none"> ➤ Screen captures added to show examples of commands. Section 8 <ul style="list-style-type: none"> ➤ Examples of Motor Start Report and Motor Start Trends Report added. ➤ Screen captures added to show examples of commands. Appendix A <ul style="list-style-type: none"> ➤ Updated for firmware version R104. Appendix C <ul style="list-style-type: none"> ➤ Modbus Event Data corrected.

Table A.2 Instruction Manual Revision History (Sheet 5 of 5)

Revision Date	Summary of Revisions
990806	<p>Section 5</p> <ul style="list-style-type: none"> ➤ Changed front-panel password entry process. <p>Section 6</p> <ul style="list-style-type: none"> ➤ Modified the MSR serial port command to accept the F argument. <p>Section 7</p> <ul style="list-style-type: none"> ➤ Modified the Motor Start Trend function to include reference dates with the data records. <p>Appendix A</p> <ul style="list-style-type: none"> ➤ Updated for firmware version R103.
990702	<ul style="list-style-type: none"> ➤ Initial version.

This page intentionally left blank

Appendix B

SELOGIC Control Equations and Relay Logic

Introduction

The SEL-701 Relay is equipped with programmable logic so you can customize various relay functions. Use the programmable logic components described in this appendix to modify the factory default logic settings discussed in *Section 4: Settings Calculations*. This appendix also describes SELOGIC® control equations and their various applications within the SEL-701 Relay. Specific topics include:

- General Operation of the Relay
- Relay Word Bits
- SELOGIC Control Equations
- Front-Panel Display Configuration Settings
- Nondedicated SELOGIC Control Equation Variables
- Latching Variables
- Stop/Trip Logic
- Breaker Auxiliary Contact Input
- Start and Emergency Restart Logic
- ACCESS2 Input Logic
- TARR Input Logic
- Speed Switch Contact Input
- Event Triggering
- Output Contact Control
- Remote Control Functions

Table B.1 and *Table B.2* summarize all the Relay Word bits. Use the Relay Word bits to create SELOGIC control equation settings. Figures in this section summarize the operation of many protection elements.

Relay Functional Overview

Understanding the relay's internal processes makes it easier to understand the relay's programmable logic capabilities. *Figure B.1* illustrates these processes.

Data Acquisition and Filtering

The SEL-701 Relay passes ac current and (if included) voltage signals through low-pass filters to remove signals above the eighth harmonic. Then the relay digitally samples the signals 16 times per power system cycle. The relay automatically tracks system frequency over the range of 20 to 70 Hz to ensure that exactly 16 samples are taken every cycle.

Four times per power system cycle, the relay processes the sampled data using a digital filter that further removes unwanted signals, leaving the desired fundamental frequency data for protection calculations. At this time, the relay also checks the contact inputs to determine if any are asserted.

Element Processing

Having acquired and filtered the ac signals, the relay performs the enabled protection algorithms to determine if protection elements are picked up or dropped out.

Relay Word

Each relay element is represented internally as a logic point, called a Relay Word bit. Each Relay Word bit exists in one of two states: true or false, picked up or dropped out. The relay uses these results to evaluate fixed logic and the programmable SELogic control equations defined in the relay settings. For further details see *Relay Word Bits* on page B.3.

SELogic Control Equations

After evaluating the fixed logic, the relay evaluates the SELogic control equations, then controls the relay output contacts. See *SELogic Control Equations* on page B.6 for a full discussion.

Background Tasks

By design, there is always processing time left after the relay controls its output contacts and before it begins digitally filtering acquired signals again. During this free time, the relay performs background tasks such as:

- Self-testing
- Monitoring RTD temperature
- Storing start report, event report, and SER records
- Responding to serial port and front-panel commands




Figure B.1 Relay Processing Order

Relay Word Bits

The protection and control element results are represented by Relay Word bits. Each Relay Word bit has a label name and can be in either of the following states:

1 (logical 1) or 0 (logical 0)

Logical 1 represents an element being picked up or otherwise asserted.

Logical 0 represents an element being dropped out or otherwise deasserted.

The Relay Word bits are collected into a table of 11 rows, each row containing 8 bits. The collection is called the Relay Word. *Table B.1* and *Table B.2* show a complete listing of Relay Word bits and their descriptions. The Relay Word bit row numbers correspond to the row numbers used in the **TAR** command (see *TARGET (Level 1 or 2) in Section 6: ASCII Serial Port Operation*).

Table B.1 SEL-701 Relay Word Bits

Row	Relay Word Bits							
1	STARTING	RUNNING	STOPPED	JAMTRIP	LOSSALRM	LOSSTRIP	46UBA	46UBT
2	49A	49T	THERMLO	NOSLO	TBSLO	ABSLO	*a	*a
3	50P1T	50P2T	50N1T	50N2T	50QT	50S	50G1T	50G2T
4	47T	TRGTR	START	52A	SPDSTR	SPEEDSW	RTDBIAS	RTDFLT
5	WDGALRM	WDGTRIP	BRGALRM	BRGTRIP	AMBALRM	AMBTRIP	OTHALRM	OTHTRIP
6	27P1	27P2	59P1	59P2	59G	81D1T	81D2T	81D3T
7	37PA	37PT	55A	55T	VARA	VART	LOP	*a
8	LT1	LT2	LT3	LT4	RB1	RB2	RB3	RB4
9	SV1	SV2	SV3	SV4	SV1T	SV2T	SV3T	SV4T
10	IN1	IN2	IN3	IN4	IN5	IN6	IN7	*a
11	TRIP	OUT1	OUT2	OUT3	ALARM	50CD	BFI	BFT

^a Reserved for future use.

Table B.2 Relay Word Bit Definitions for SEL-701 (Sheet 1 of 3)

Row	Bit	Definition
1	STARTING RUNNING STOPPED JAMTRIP LOSSALRM LOSSTRIP 46UBA 46UBT	Asserts when motor is starting (see <i>Figure B.24 on page B.26</i>). Asserts when motor is running (see <i>Figure B.24 on page B.26</i>). Asserts when motor is stopped (see <i>Figure B.24 on page B.26</i>). Load-Jam Trip. Load-Loss Alarm and Load-Loss Trip. Assert when the relay detects a load-loss as defined by that function and its settings. These Relay Word bits are inactive if the function is disabled by relay settings. Phase Current Unbalance Alarm (46UBA) and Trip (46UBT). Assert when the relay issues an alarm or trip in response to a current unbalance condition, as defined by that function and its settings.
2	49A 49T THERMLO NOSLO TBSLO ABSLO * *	Thermal Alarm (49A) and Trip (49T). Assert when the relay issues a thermal element alarm or trip due to locked rotor starting or running overload conditions. Motor Lockout Conditions. Asserted by the thermal element (THERMLO), starts per hour function (NOSLO), minimum time between starts (TBSLO), and the antibackspin timer (ABSLO). Reserved for future use.
3	50P1T 50P2T	Level 1 and Level 2 Definite-Time Phase Overcurrent Elements.

Table B.2 Relay Word Bit Definitions for SEL-701 (Sheet 2 of 3)

Row	Bit	Definition
	50N1T 50N2T	Level 1 and Level 2 Definite-Time Neutral Overcurrent Elements.
	50QT	Negative-Sequence Overcurrent Element.
	50S	Motor Starting Overcurrent Element (pickup = 2.5 • full load current).
	50G1T 50G2T	Level 1 and Level 2 Definite-Time Residual Overcurrent Elements.
4	47T	Phase Reversal Trip. Asserts when the relay detects a phase reversal condition, if phase reversal tripping is enabled by the relay settings.
	TRGTR	Target Reset. Asserts for one quarter-cycle when you execute a front-panel or serial port target reset command, or when a rising edge of the TARR SELOGIC control equation is detected.
	START	Asserts when an internal relay function calls for a motor start. A motor start only occurs if a relay output contact is programmed with this relay word bit and connected to close the motor contactor or circuit breaker.
	52A	Asserts when the SELOGIC control equation 52A result is logical 1. Use to indicate that the motor contactor or circuit breaker is closed.
	SPDSTR	Speed Switch Trip. Asserts when the relay does not detect a speed switch contact closure within a settable period from the beginning of a motor start, if the function is enabled by relay settings.
	SPEEDSW	Speed Switch Input. Asserts when the SELOGIC control equation SPEEDSW result is logical 1. Used to indicate that the motor speed switch contact is closed.
	RTDBIAS	RTD Bias Alarm. When enabled, asserts when the motor winding temperature rise is greater than 60°C over ambient and the RTD % Thermal Capacity is more than ten percentage points higher than the motor thermal element % Thermal Capacity. Typically indicates a loss of motor cooling efficiency.
	RTDFLT	Asserts when an open or short circuit condition is detected on any enabled RTD input, or communication with the external RTD module has been interrupted.
5	WDGALRM WDGTRIP	Winding Temperature Alarm and Trip. WDGALRM asserts when any healthy winding RTD temperature exceeds its alarm setpoint. WDGTRIP asserts when one or two (when EWDGV = Y) healthy winding RTD temperatures exceed their trip setpoints.
	BRGALRM BRGTRIP	Bearing Temperature Alarm and Trip. BRGALRM asserts when any healthy bearing RTD temperature exceeds its alarm setpoint. BRGTRIP asserts when one or two (when EBRGV = Y) healthy bearing RTD temperatures exceed their trip setpoints.
	AMBALRM AMBTRIP	Ambient Temperature Alarm and Trip. AMBALRM asserts if the healthy ambient RTD temperature exceeds its alarm setpoint. AMBTRIP asserts when the healthy ambient RTD temperature exceeds its trip setpoint.
	OTHALRM OTHTRIP	Other Temperature Alarm and Trip. OTHALRM asserts when any healthy other RTD temperature exceeds its alarm setpoint. OTHTRIP asserts when any healthy other RTD temperature exceeds its trip setpoint.
6	27P1 27P2	Level 1 and Level 2 Phase Undervoltage Pickup.
	59P1 59P2	Level 1 and Level 2 Phase Overvoltage Pickup.
	59G	Residual Overvoltage Element Pickup.
	81D1T 81D2T 81D3T	Level 1, Level 2, and Level 3 Definite Time Over/Underfrequency Element Trip. Assert when the frequency has been either above or below the element setpoint for a definite time.
7	37PA 37PT	Underpower Alarm (37PA) and Trip (37PT). Assert when the relay issues an underpower element alarm or trip.
	55A 55T	Power Factor Alarm (55A) and Trip (55T). Assert when the relay issues a power factor element alarm or trip.

Table B.2 Relay Word Bit Definitions for SEL-701 (Sheet 3 of 3)

Row	Bit	Definition
	VARA	Reactive Power Alarm (VARA) and Trip (VART). Assert when the relay issues a reactive power element alarm or trip.
	VART	
	LOP	Loss-of-Potential (LOP) pickup
	*	Reserved for future use.
8	LT1	SELOGIC control equation latch bit results.
	LT2	
	LT3	
	LT4	
	RB1	Remote bits 1 through 4.
	RB2	
	RB3	
	RB4	
9	SV1	SELOGIC control equation variables 1 through 4.
	SV2	
	SV3	
	SV4	
	SV1T	SELOGIC control equation variable 1 through 4 with settable pickup and dropout time delay.
	SV2T	
	SV3T	
	SV4T	
10	IN1	Contact inputs IN1 through IN6.
	IN2	
	IN3	
	IN4	
	IN5	
	IN6	
	IN7	Contact input IN7. Available only when using an SEL-2600 series RTD module.
	*	Reserved for future use.
11	TRIP	Contact outputs TRIP, OUT1, OUT2, OUT3, and ALARM.
	OUT1	
	OUT2	
	OUT3	
	ALARM	
	50CD	Sum of $ I_1 $ (positive-sequence current magnitude) and $ I_2 $ (negative-sequence current magnitude) exceeds STOP threshold current.
	BFI	Breaker Failure Initiation. Asserts when the SELOGIC control equation BFI result is a logical 1. Use to indicate that the Breaker Failure logic has started.
	BFT	Breaker Failure Trip. Asserts when the relay issues a Breaker Failure Trip.

SELogic Control Equations

SELOGIC control equations combine relay protection and control elements with logic operators to create custom protection and control schemes. This section shows how to set the protection and control elements (Relay Word bits) in the SELOGIC control equations.

SELOGIC control equations are set with combinations of Relay Word bits to accomplish such functions as:

- Tripping circuit breakers
- Assigning contact inputs to functions
- Operating contact outputs

You can use SELOGIC control equations to create traditional or advanced custom schemes.

SELogic Control Equation Operators

Build SELOGIC control equation settings using logic similar to Boolean algebra logic, by combining Relay Word bits together using one or more of the six SELOGIC control equation operators listed in *Table B.3*. These operators are processed in a SELOGIC control equation in the order shown in *Table B.3*.

Table B.3 SELogic Control Equation Operators

Operator	Logic Function
/	Rising edge detect
\	Falling edge detect
()	parentheses
!	NOT
*	AND
+	OR

SELogic Control Equation AND Operator [*]

Use the asterisk [*] symbol to denote logical AND operations. When you use the [*] between two Relay Word bits, both must pick up in order for the relay to perform the operation in question. For instance, if SV1 is the equation that controls SELOGIC control equation variable 1, you could set SV1 equal to:

SV1= 50P1T * IN4

Equation B.1

With this setting, SV1 is true, or logical 1, when both 50P1T and IN4 are true. Any number of Relay Word bits may be ANDed together within an equation, subject to the overall limitations described in *SELOGIC Control Equation Limitations on page B.8*.

SELogic Control Equation OR Operator [+]

Use the plus [+] symbol to denote logical OR operations. When you use the [+] between two Relay Word bits, either can pick up to cause the relay to perform the operation in question. For instance, if SV1 is the equation controlling SELOGIC control equation variable 1, you could set SV1 equal to:

SV1 = 50P1T + 50P2T

Equation B.2

With this setting, SV1 is true, or logical 1, when either 50P1T or 50P2T are picked up. Any number of Relay Word bits may be ORed together within an equation, subject to the overall limitations described in *SELOGIC Control Equation Limitations* on page B.8.

SELogic Control Equation Falling-Edge Operator [\]

Use the falling-edge operator [\] with individual Relay Word bits to cause a single processing-cycle assertion when the Relay Word bit changes state from logical 1 to logical 0. The falling-edge operator [\] looks for Relay Word bit deassertion (element going from logical 1 to logical 0). The falling-edge operator [\] in front of a Relay Word bit sees this logical 1 to logical 0 transition as a falling-edge and asserts to logical 1 for one processing interval. Do not apply the [\] operator to groups of elements within parentheses.

For example, suppose the SELOGIC control equation event report generation setting is set with the detection of the falling-edge of an underfrequency element:

$$ER = \dots + \backslash 81D1T \quad \text{Equation B.3}$$

When frequency goes above the corresponding pickup level 81D1P, Relay Word bit 81D1T deasserts and an event report is generated (if the relay is not already generating a report that encompasses the new transition). This allows a recovery from an underfrequency condition to be observed. *Figure B.2* demonstrates the action of the falling-edge operator [\] on the underfrequency element in setting ER.




Figure B.2 Result of Falling-Edge Operator on a Deasserting Underfrequency Element

SELogic Control Equation Rising-Edge Operator [/]

Use the rising-edge operator [/] with individual Relay Word bits to cause a single processing-cycle assertion when the Relay Word bit changes state from logical 0 to logical 1. Do not apply the [/] operator to groups of elements within parentheses.

SELogic Control Equation Parentheses Operator [()]

Use parentheses to logically combine multiple elements. More than one set of parentheses [()] can be used in a SELOGIC control equation setting. Parentheses cannot be “nested” (parentheses within parentheses) in a SELOGIC control equation setting. For example, the following SELOGIC control equation setting has two sets of parentheses:

$$SV4 = (SV4 + IN2 + TRIP) \cdot (50P1T + 50N1T) \quad \text{Equation B.4}$$

In the above example, the logic within the two sets of parentheses is processed first and then the two results are ANDed together. The example equation could be used to provide simple motor breaker failure protection.

SELogic Control Equation NOT Operator [!]

Use the NOT operator [!] to invert a single Relay Word bit and also to invert the result of multiple elements combined within parentheses.

Set SELogic Control Equations Directly to Logical 1 or Logical 0

To define a condition always picked up or always dropped out, you can set SELOGIC control equations directly to:

1 (logical 1) or 0 (logical 0)

If you set a SELOGIC control equation setting directly to 1, it is always asserted/on/enabled. If you set a SELOGIC control equation setting equal to 0, it is always deasserted/off/disabled.

All SELogic Control Equations Must Be Set

If you use SELOGIC control equations, every one needs to be set by making it equal to one of the following:

- A single Relay Word bit
- A logical combination of Relay Word bits
- Directly to logical 1
- Directly to logical 0

If you are satisfied with the factory default logic setting, you may leave the SELOGIC control equation setting unedited.

SELogic Control Equation Limitations

Each single SELOGIC control equation setting is limited to 25 Relay Word bits that you can combine together with the SELOGIC control equation operators listed in *Table B.3*. If you need to exceed this limit, use a nondedicated SELOGIC control equation variable (SELOGIC control equation settings SV1 through SV4) to combine terms and shorten the final equation.

The sum of SELOGIC control equation settings is limited to approximately 80 Relay Word bits that can be combined together using the operators listed in *Table B.3*. SELOGIC control equation settings that are set directly to 1 (logical 1) or 0 (logical 0) must be included in this sum of 80 Relay Word bits with each such setting counted as one Relay Word bit.

As the relay saves its settings, it calculates the percentage of SELOGIC control equation capability used. The relay reports this percentage as LEUSE = xx.x when the settings are saved and when you execute the **SHOW** command. The LEUSE value provides a measure of the relay SELOGIC control equation capability. The remainder (100% – LEUSE) is available for future expansion.

Factory Default Logic Settings

When you use the factory default logic by setting FACTLOG equal to Y, the relay hides the logic settings and default settings shown in *Figure B.3*. Operation of these default settings is described in *Section 4: Settings Calculations*.

If you set FACTLOG equal to N, the relay displays each of the settings in the screen capture below. You can modify one or more of these settings to customize the relay function. Descriptions of the functions controlled by the default settings are included in the remainder of this appendix.

NOTE: If you change the SELogic control equation settings, then return the FACTLOG setting to Y, the relay will clear your changes and resume using the factory settings shown below.

```

DISPLAY MESSAGE VARIABLES
DM1  =1
DM2  =1
DM3  =RTDFLT
DM4  =TBSLO*STOPPED
DM5  =NOSLO*STOPPED
DM6  =THERMLO
LOGIC VARIABLES
Logic Variable 1
SV1  =0
SV1 Pickup Time (0.00 – 3000.00 s)      SV1PU=0.00
SV1 Dropout Time (0.00 – 3000.00 s)     SV1DO=0.00
Logic Variable 2
SV2  =0
SV2 Pickup Time (0.00 – 3000.00 s)      SV2PU=0.00
SV2 Dropout Time (0.00 – 3000.00 s)     SV2DO=0.00
Logic Variable 3
SV3  =0
SV3 Pickup Time (0.00 – 3000.00 s)      SV3PU=0.00
SV3 Dropout Time (0.00 – 3000.00 s)     SV3DO=0.00
Logic Variable 4
SV4  =0
SV4 Pickup Time (0.00 – 3000.00 s)      SV4PU=0.00
SV4 Dropout Time (0.00 – 3000.00 s)     SV4DO=0.00
SET/RESET LATCH VARIABLES
Latch Variable 1
SET1  =0
RST1  =1
Latch Variable 2
SET2  =0
RST2  =1
Latch Variable 3
SET3  =0
RST3  =1
Latch Variable 4
SET4  =0
RST4  =1
OUTPUT LOGIC
TRIP  =JAMTRIP + 46UBT + 49T + 50P1T + 50P2T + 50N1T
      + 50N2T + 50G1T + 50G2T + 50QT + 47T + SPDSTR + WDGTRIP
      + BRGTRIP + AMBTRIP + OTHTRIP + 81D1T + 81D2T + 81D3T
      + !27P1 * (LOSSTRIP + 37PT + 55T + VART) + IN2
ULTRIP =0
52A   =!IN1
STR   =0
EMRSTR =IN5 * STOPPED
SPEEDSW =IN3 + IN7
ACCESS2 =IN4
TARR  =0
ER    =/LOSSALRM + /46UBA + /49A + \81D1T + \81D2T + \81D3T + /37PA
      + /55A + /VARA + /TRIP
OUT1  =LOSSALRM + 46UBA + 49A + 37PA + 55A + VARA
OUT2  =RTDBIAS + WDGALRM + BRGALRM + AMBALRM + OTHALRM + RTDFLT
OUT3  =START
BFI   =/TRIP

```

Figure B.3 Factory Default Logic Settings

Front-Panel Display Message Configuration

There are six text display messages available in the SEL-701 Relay. Each text display has two complementary screens.

SELogic control equation display message setting DM_n (n = 1–6) controls the display of corresponding, complementary text settings. For example,

Message DM2_1 is displayed when the SELogic control equation DM2 = logical 1

Message DM2_0 is displayed when the SELogic control equation DM2 = logical 0

Make each text setting through the front panel or serial port using the **SET** command. View text settings using the serial port command **SHOW**. These text settings are displayed on the relay front-panel display on a two-second rotation.

The factory default settings display two relay-identifying messages continuously and a warning message in the event of an RTD failure. If there is a relay lockout condition, the lockout type is also displayed.

Nondedicated SELogic Control Equation Variable Settings

The SEL-701 Relay is equipped with four nondedicated SELOGIC control equation variables. Each variable has a defining SELOGIC control equation, a time-delay pickup timer, and a time-delay dropout timer.

The SV1 SELOGIC control equation is the logical definition of the SV1 Relay Word bit. Make the SELOGIC control equation setting by combining Relay Word bits and logical operators.

The SV1PU setting defines the SV1T Relay Word bit time-delay pickup time. SV1T asserts SV1PU seconds after the SV1 SELOGIC control equation result becomes a logical 1. The SV1DO setting defines the SV1T Relay Word bit time-delay dropout time. Once SV1T is asserted, it remains asserted for SV1DO seconds after the SV1 SELOGIC control equation result becomes a logical 0. *Figure B.4* illustrates the SELOGIC control equation variable timer logic. For an example control equation see *Equation B.4* on page B.7.

Settings SV2 through SV4 operate similarly.




Figure B.4 SELogic Control Equation Variable Timer Logic

Latch Control Switch Settings

The latch control switch feature of the SEL-701 Relay replaces latching relays. The state of a traditional latching relay output contact is changed by pulsing the latching relay inputs. (See *Figure B.5*). Pulse the set input to close (set) the latching relay output contact. Pulse the reset input to open (reset) the latching relay output contact.




Figure B.5 Traditional Latching Relay

Four latch control switches in the SEL-701 Relay provide latching relay type functions.




Figure B.6 Latch Control Switches Drive Latch Bits LT1 through LT4

The output of the latch control switch in *Figure B.6* is a Relay Word bit LT_n ($n = 1-4$), called a latch bit. The latch control switch logic in *Figure B.6* repeats for each latch bit LT1 through LT4. Use these latch bits in SELOGIC control equations.

These latch control switches each have the following SELOGIC control equation settings:

- SET_n sets latch bit LT_n to logical 1 when SET_n SELOGIC control equation result is logical 1.
- RST_n reset latch bit LT_n to logical 0 when RST_n SELOGIC control equation result is logical 1.

If both SET_n and RST_n assert to logical 1, RST_n has priority and latch bit LT_n deasserts to logical 0.

Latch Control Switch States Are Retained During Power Loss

The states of the latch bits are retained if power to the relay is lost and then restored. This capability makes the latch bit feature behave the same as traditional latching relays.

Make Latch Control Switch Settings With Care

The latch bit states are stored in nonvolatile memory so they can be retained during power loss. The nonvolatile memory is rated for a finite number of writes for all cumulative latch bit state changes. Exceeding the limit can result in an EEPROM self-test failure. An average of 150 cumulative latch bit state changes per day can be made for a 25-year relay service life.

The SELOGIC control equation settings SET_n and RST_n for any given latch bit LT_n ($n = 1-4$; see *Figure B.6*) must be set with care. Settings SET_n and RST_n must not result in continuous cyclical operation of latch bit LT_n . Use timers to qualify conditions set in settings SET_n and RST_n .

Stop/Trip Logic

The SEL-701 Relay tripping logic is designed to trip or stop motors energized through circuit breakers or contactors. The relay logic lets you define the conditions that cause a trip, the conditions that unlatch the trip, and the performance of the relay output contact motor contactor or breaker. *Figure B.7* illustrates the tripping logic.

Initiate Trip

The SEL-701 Relay Trip Logic offers three ways to stop the protected motor:

- TRIP SELOGIC control equation
- Front panel, Modbus®, or serial port **STOP** command
- Trips generated by the remote bit function

Any of the three of these conditions will trigger an event report. The relay controls the TRIP output contacts depending on the Enable Trip Contact Fail-Safe setting. Refer to *Figure B.7*.

Set the TRIP SELOGIC control equation to include an OR-combination of all the enabled protection element Relay Word bits that you want to cause the relay to trip. Use the factory default setting as a guideline.

Unlatch Trip

Following a fault, the trip signal is maintained until all of the following conditions are true:

- Minimum Trip Duration Time (TDURD) passes.
- The TRIP SELOGIC control equation result deasserts to logical 0.
- All the motor lockout functions, described below, deassert to logical 0.
- One of the following occurs:
 - Unlatch Trip SELOGIC control equation setting ULTRIP asserts to logical 1.
 - A rising edge of the TARR SELOGIC control equation is detected.
 - The front-panel Trip/Target Reset menu item is selected.
 - The serial port **TARGET R** (Target Reset) command is executed.
 - The Modbus Reset control command is executed.
 - An Emergency Restart command is executed or the EMRSTR SELOGIC control equation setting asserts to logical 1.

The relay automatically locks out the motor by asserting the trip signal under any of the following conditions:


- **Antibackspin Lockout (ABSLO).** The antibackspin timer has not expired since the motor trip occurred. The trip signal is maintained until the antibackspin timer expires.
- **Minimum Time Between Starts Lockout (TBSLO).** A new start is not permitted until after the minimum time between starts has passed. The trip signal is maintained until a start is permitted.

- **Starts-Per-Hour Limit Lockout (NOSLO).** If the starts-per-hour limit has been met, a new start is not permitted until 60 minutes after the oldest start. The trip signal is maintained until a start is permitted.
- **Thermal Element Lockout (THERMLO).** The motor thermal element % Thermal Capacity value is too high to permit a normal motor start without tripping. The trip signal is maintained until the % Thermal Capacity decreases to a level where a start can safely take place.

If any of the above protection functions is not enabled by the relay settings, that function does not affect trip unlatch.

Also note that the relay automatically asserts the trip signal if the motor stops and a lockout condition is true. The trip signal is maintained until all the enabled motor lockout conditions are satisfied.

Trips initiated by the **STOP** command, the front-panel Stop Motor function, or by Modbus operation are maintained for at least the duration of the Minimum Trip Duration Time (TDURD) setting.



TRFS = Enable TRIP Contact Fail-Safe Setting
 TRIP = TRIP SELOGIC Control Equation
 STOP Command = Serial Port STOP Command
 STOPPED = Motor Stopped Relay Word Bit
 ULTRIP = Unlatch TRIP SELOGIC Control Equation
 TRIP/TARGET RC = TRIP/TARGET Reset Command
 Modbus RC = Modbus Reset Command
 TARR = Target Reset SELOGIC Control Equation
 EMRSTR = Emergency Restart Control Equation
 or Command
 ABSLO = Antibackspin Lockout
 TBSLO = Minimum Time Between Starts Lockout
 NOSLO = Starts-Per-Hour Limit Lockout

Figure B.7 Stop/Trip Logic

Breaker Auxiliary Contact SELogic Control Equation Setting

NOTE: When the 52A is used with an appropriate control input, it enhances the motor state logic (see Figure B.23). This is particularly important if the motor has low operational idling current (less than 10 percent FLA).

The breaker auxiliary contact SELOGIC control equation setting, 52A =, defines the relay input contact that is connected to a breaker auxiliary contact. The factory default setting, 52A = !IN1, allows you to connect a breaker 52B contact to input IN1. If you wish to connect a breaker 52A contact to the input, set 52A = IN1. The equation result is the 52A Relay Word bit. You can use the result to create custom control functions such as breaker failure logic, if necessary, for your application.

If no breaker information is available, set 52A = 0 in the SELOGIC control equation.

Start and Emergency Restart Logic

Figure B.8 shows the logic the relay uses to initiate motor starts.




Figure B.8 Start Logic

If the Trip output contact is not asserted, the relay asserts the START Relay Word bit in response to any of these conditions:

- The Motor Start SELOGIC control equation (STR) result is true (logical 1).
- The Emergency Restart Relay Word bit asserts.
- You execute the STR serial port command or a Modbus Start control command.

The START Relay Word bit remains asserted for 0.5 seconds, unless the relay trips. If the relay trips before the 0.5 second timer expires, the relay resets the timer, clearing the START Relay Word bit.

The Motor Start SELOGIC control equation allows you to define a logical condition that initiates a motor start.

EXAMPLE B.1 Initiating a Motor Start Using a Relay Contact Input

You can use a relay contact input such as IN6 to initiate motor starting. Set the SELOGIC control equation STR = IN6. Connect the normally open pushbutton contact to relay terminals C08 and C09 (IN6). Program an output contact to close when the START Relay Word bit asserts, as shown in Program an Output Contact for Motor

Starting on page B.15. When you push the button, IN6 is asserted, asserting the START bit, closing the output contact, and initiating the start.

In an emergency, it may be necessary to quickly start the motor even though a protection lockout condition exists and is holding the TRIP output contact asserted. The lockout might be a result of the thermal element or another protection function (see *Stop/Trip Logic on page B.12*). You can override all the lockout conditions using the Emergency Restart function.

The relay asserts the Emergency Restart Relay Word bit (EMRSTR) in response to any of these conditions:

- The EMRSTR Control Equation result is true (logical 1).
- You execute the front-panel menu Emergency Restart command.
- The relay receives a Modbus Emergency Restart control command.

When the Emergency Restart Relay Word bit asserts, the relay:

- Resets the motor thermal element capacity used to 0%.
- Deasserts the ABSLO element if it is asserted. (When a STOPPED element is asserted, the ABSLO (antibackspin lockout) element is asserted until the antibackspin timer has expired. When the emergency restart command (EMRSTR) is issued, the antibackspin timer is set to zero and the ABSLO element is deasserted.)
- Deasserts the TBSLO element (minimum time between starts lockout) if it is asserted at the time of the emergency restart.
- Deasserts the NOSLO element (number of starts per hour limit lockout) if it is asserted at the time of the emergency restart. (The relay reduces the number of starts in the last hour by one to permit the start and clears the smallest value timer. Each start activates a 60-minute timer.)
- Deasserts the TRIP output contact if no fault detecting element is picked up.
- Initiates a motor start through the logic shown in *Figure B.8*.

NOTE: For the EMRSTR SELogic control equation performance to match the performance of the front-panel and Modbus Emergency Restart functions, you should include * STOPPED in the SELogic control equation, as shown in Factory Default Logic Settings on page B.8. Do not set EMRSTR =1.

Program an Output Contact for Motor Starting

In the factory settings, the result of the start logic in *Figure B.8* is routed to output contact OUT3 with the following SELOGIC control equation:

$$\text{OUT3} = \text{START} \quad \text{Equation B.5}$$

ACCESS2 SELogic Control Equation Setting

The ACCESS2 SELOGIC control equation settings define conditions when Level 2 command access is permitted without Level 2 password entry. The factory default setting allows Access Level 2 serial port and front-panel command execution when input IN4 is asserted. You may want to connect a keyswitch contact to the input so relay settings can be modified by persons having the correct key.

TARR SELogic Control Equation Setting

The TARR SELOGIC control equation setting defines conditions for the reset of front-panel targets. The factory default setting is disabled. You should assign a contact input to allow remote target reset.

Speed Switch SELogic Control Equation Setting

The speed switch SELOGIC control equation, SPEEDSW, defines the relay input contact that is connected to the motor speed switch. The factory default setting allows you to connect the speed switch contact to input IN3 at the relay or input IN7 at the SEL-2600 series RTD module, if installed. The Speed Switch Trip logic, described in *Section 4: Settings Calculations*, uses the result of the SPEEDSW SELOGIC control equation.

Event Triggering SELogic Control Equation


The event report trigger SELogic control equation, ER, triggers standard event reports for conditions other than trip conditions. When setting ER sees a logical 0 to logical 1 transition, it generates an event report (if the relay is not already generating a report that encompasses the new transition). The factory setting shown in *Table B.3 on page B.6* includes a rising-edge operator [/] in front of each of the alarm elements. This is used to trigger an event report at alarm inception. Falling-edge operators are used to generate an event report at frequency element dropout, when the system frequency has stabilized at or near the nominal frequency.

Contact Output Control

SELOGIC control equation settings and their respective fail-safe settings directly control the contact outputs OUT1, OUT2, and OUT3. The SELOGIC control equation settings let you program individual contact outputs using single Relay Word bits for element testing purposes or to create more complex functions by combining Relay Word bits and SELOGIC control equation operators.

Remote Control Switches

Remote control switches do not have settings; they are operated via the serial communications port only (see *CONTROL (Level 2) in Section 6: ASCII Serial Port Operation*).



The switch representation in this figure is derived from the standard: Graphics Symbols for Electrical and Electronics Diagrams IEEE Std 315-1975, ANSI Y32.2-1975, 4.11 Combination Locking and Nonlocking Switch, Item 4.11.1

Figure B.9 Remote Control Switches Drive Remote Bits RB1 through RB4

The outputs of the remote control switches in *Figure B.9* are Relay Word bits RB_n ($n = 1-4$), called remote bits. Use these remote bits in SELOGIC control equations.

Any given remote control switch can be put in one of three positions shown in *Table B.4*.

Table B.4 Remote Control Switch

Control Switch Position	Description
ON	logical 1
OFF	logical 0
MOMENTARY	logical 1 for one processing interval

Remote Bit Application Ideas

With SELOGIC control equations, you can use the remote bits to trip or start the motor or to open, close, or pulse relay output contacts for other purposes.

Also, you can use remote bits like a contact input in operating latch control switches. Pulse (momentarily operate) the remote bits for this application.

Remote Bit States Are Not Retained When Power Is Lost

The states of the remote bits (Relay Word bits RB_1 – RB_4) are not retained if power to the relay is lost and then restored. The remote control switches always come back in the OFF position (corresponding remote bit is deasserted to logical 0) when power is restored to the relay.

Selected Relay Logic Diagrams




Figure B.10 Undervoltage Element Logic




Figure B.11 Underpower Element Logic




Figure B.12 Current Unbalance Element Logic




Figure B.13 Phase Reversal Element Logic




Figure B.14 Overcurrent Element Logic






Figure B.15 Power Factor Elements Logic




*When DELTA_Y = D, VG is not calculated and phase-to-phase measurements are used.

When DELTA_Y = Y:



When DELTA_Y = Y, SINGLEV=N:



When DELTA_Y = D:




Figure B.16 Overvoltage Element Logic




Figure B.17 Over/Underfrequency Element Logic




Figure B.18 Load-Jam Elements Logic




Figure B.19 Load-Loss Logic; No Voltage Option




Figure B.20 Load-Loss Logic; Voltage Option Included




Figure B.21 Reactive Power Elements Logic




Figure B.22 Speed Switch Tripping Logic




Figure B.23 Breaker Failure Logic




Figure B.24 Motor State Logic

Appendix C

Modbus RTU Communications Protocol

Introduction

This appendix describes Modbus® RTU communications features supported by the SEL-701 Relay at the rear-panel EIA-485 port. Complete specifications for the Modbus protocol are available from Modicon on their web site: www.modicon.com.

The SEL-701 Relay supports Modbus RTU protocol when you enable Modbus protocol using the rear-panel serial port settings. When Modbus protocol is enabled, the relay activates the rear-panel EIA-485 serial port and deactivates the EIA-232 serial port.

Modbus RTU is a binary protocol that permits communication between a single master device and multiple slave devices. The communication is half-duplex: only one device transmits at a time. The master transmits a binary command that includes the address of the desired slave device. All of the slave devices receive the message, but only the slave device having the matching address responds.

The SEL-701 Relay Modbus communication allows a Modbus master device to:

- Acquire metering, monitoring, and event data from the relay
- Control SEL-701 Relay output contacts and selected internal logic variables
- Read the SEL-701 Relay self-test status and learn the present condition of all the relay protection elements

Modbus RTU Communications Protocol

Modbus Queries

Modbus RTU master devices initiate all exchanges by sending a query. The query consists of the fields shown in *Table C.1*.

Table C.1 Modbus Query Fields

Field	Number of Bytes
Slave Device Address	1 byte
Function Code	1 byte
Data Region	0–251 bytes
Cyclical Redundancy Check	2 bytes

The SEL-701 Relay SLAVEID setting defines the device address when the relay rear-panel port is set for Modbus communication. Set this value to a unique number for each device on the Modbus network. For Modbus communication to operate properly, no two slave devices may have the same address.

Function codes supported by the SEL-701 Relay are described in *Table C.2*. The cyclical redundancy check is an error detection method that validates the data received by the slave device and helps ensure that the packet received is identical to the packet sent by the master device. The CRC-16 Cyclical Redundancy Check algorithm is used.

Modbus Responses

The slave device sends a response message after it performs the action requested in the query. If the slave cannot execute the command for any reason, it sends an error response. Otherwise, the slave device response is formatted similarly to the query including the slave address, function code, data if applicable, and a cyclical redundancy check value.

Supported Modbus Function Codes

The SEL-701 Relay supports the Modbus function codes shown in *Table C.2*.

Table C.2 SEL-701 Relay Modbus Function Codes

Code	Description
01	Read Coil Status
02	Read Input Status
03	Read Holding Registers
04	Read Input Registers
05 ^a	Force Single Coil
06 ^a	Preset Single Register
07	Read Exception Status
08	Loopback Diagnostic Command
10h ^a	Preset Multiple Registers

^a The SEL-701 Relay supports broadcast operation for these function codes. Broadcast function codes use slave device address 00h. Slave devices do not send a response to broadcast functions.

Modbus Exception Responses

The SEL-701 Relay sends an exception code under the conditions described in *Table C.3*.

Table C.3 SEL-701 Relay Modbus Exception Codes

Exception Code	Error Type	Description
1	Illegal Function Code	The received function code is either undefined or unsupported.
2	Illegal Data Address	The received command contains an unsupported address in the data field.
3	Illegal Data Value	The received command contains a value that is out of range.
4	Device Error	The SEL-701 Relay is in the wrong state for the requested function.
6	Busy	The SEL-701 Relay is unable to process the command at this time due to a busy resource.
8	Memory Error	There is a checksum error on the stored data.

In the event that any of the errors listed in *Table C.3* occur, the relay assembles a response message that includes the Exception Code in the Data field. The relay sets the Most Significant Bit in the Function Code field to indicate to the master that the data field contains an error code rather than the requested data.

Cyclical Redundancy Check

The SEL-701 Relay calculates a 2-byte CRC value using the device address, function code, and data fields. It appends this value to the end of every Modbus response sent. When the master device receives the response, it uses the received data to recalculate the CRC value using the same CRC-16 algorithm. If the calculated CRC value matches the CRC value sent by the SEL-701 Relay, the master device uses the data received. If there is not a match, the check fails and the message is ignored. The devices use a similar process when the master sends queries.

01h Read Coil Status Command

Use function code 01h to read the On/Off status of selected bits (coils). You may read the status of up to 2000 bits per query. Note that the relay addresses inputs from 0. The relay returns 8 bits per byte, most significant bit first, with zeroes padded into incomplete bytes.

Table C.4 01h Read Coil Status Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (01h)
2 bytes	Address of the first bit
2 bytes	Number bits to read
2 bytes	CRC-16 for message
A Successful SEL-701 Relay Response Will Have the Following Format	
1 byte	Slave address
1 byte	Function code (01h)
1 byte	Byte count
n bytes	Byte count bytes of data
2 bytes	CRC-16 for message

To build the response, the relay calculates the number of bytes required to contain the number of bits requested. If the number of bits requested is not evenly divisible by 8, the relay adds one more byte to contain the balance of bits, padded by zeroes to make an even byte.

02h Read Input Status Command

Use function code 02h to read the On/Off status of selected bits. You may read the status of up to 2000 bits per query. Note that the relay addresses inputs from 0. The relay returns 8 bits per byte, most significant bit first, with zeroes padded into incomplete bytes.

Table C.5 02h Read Input Status Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (02h)
2 bytes	Address of the first bit
2 bytes	Number bits to read
2 bytes	CRC-16 for message
A Successful SEL-701 Relay Response Will Have the Following Format	
1 byte	Slave address
1 byte	Function code (02h)
1 byte	Byte count
n bytes	Byte count bytes of data
2 bytes	CRC-16 for message

To build the response, the relay calculates the number of bytes required to contain the number of bits requested. If the number of bits requested is not evenly divisible by 8, the relay adds one more byte to contain the balance of bits, padded by zeroes to make an even byte.

03h Read Holding Registers Command

Use function code 03h to read directly from the Modbus Register map shown in *Table C.18 on page C.11*. You may read a maximum of 125 registers at once with this function code. Most masters use 4X references with this function code. If you are accustomed to 4X references with this function code, for 5-digit addressing, add 40001 to the standard database address.

Table C.6 03h Read Holding Registers Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (03h)
2 bytes	Starting register address
2 bytes	Number of registers to read
2 bytes	CRC-16 for message
A Successful SEL-701 Relay Response Will Have the Following Format	
1 byte	Slave address
1 byte	Function code (03h)
1 byte	Byte count (should be twice number of registers read)
n bytes	Byte count bytes of data
2 bytes	CRC-16 for message

04h Read Input Registers Command

Use function code 04h to read from the Modbus map shown in *Table C.18 on page C.11*. You may read a maximum of 125 registers at once with this function code.

Table C.7 04h Read Input Registers Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (04h)
2 bytes	Starting register address
2 bytes	Number of registers to read
2 bytes	CRC-16 for message
A Successful SEL-701 Relay Response Will Have the Following Format	
1 byte	Slave address
1 byte	Function code (04h)
1 byte	Byte count (should be twice number of registers read)
n bytes	Byte count bytes of data
2 bytes	CRC-16 for message

05h Force Single Coil Command

The SEL-701 Relay uses this function code for a variety of data control purposes. Specifically, you can use it to clear archive records, operate output contacts, and operate breaker and remote bit elements.

Table C.8 05h Force Single Coil Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (05h)
2 bytes	Coil reference
1 byte	Operation code (FF for bit set, 00 for bit clear)
1 byte	Placeholder (00)
2 bytes	CRC-16 for message

The command response is identical to the command request.

The SEL-701 Relay offers the commands listed in *Table C.9* that you can execute using function code 05h. The command coils are self-resetting.

Table C.9 SEL-701 Relay Command Coils

Coil	Field
1	Start
2	Stop
3	Emergency Restart
4	Reset Trip, Targets

06h Preset Single Register Command

The SEL-701 Relay uses this function to allow a Modbus master to write directly to a database register. If you are accustomed to 4X references with this function code, for 6-digit addressing, add 400001 to the standard database addresses. The command response is identical to the command request.

Table C.10 06h Preset Single Register Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (06h)
2 bytes	Register address
2 bytes	Data
2 bytes	CRC-16 for message

07h Read Exception Status Command

The SEL-701 Relay uses this function to allow a Modbus master to read the present status of the relay and protected motor.

Table C.11 07h Read Exception Status Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (07h)
0 bytes	No data fields are sent
2 bytes	CRC-16 for message
A Successful SEL-701 Relay Response Will Have the Following Format	
1 byte	Slave address
1 byte	Function code (07h)
1 byte	Status byte
2 bytes	CRC-16 for message
The Status Byte is Sent LSB-First, and Consists of the Following Bits	
Bit 0	Trip Output Status
Bit 1	OUT1 Output Status
Bit 2	OUT2 Output Status
Bit 3	OUT3 Output Status
Bit 4	ALARM Output Status
Bit 5	0
Bit 6	Motor Stopped
Bit 7	Motor Running

If the bit is set (1), the output contact is asserted or the motor is in the indicated condition. If the bit is cleared (0), the output contact is deasserted or the motor is not in the indicated condition. In the event that both Bits 6 and 7 are cleared, the motor is starting.

08h Loopback Diagnostic Command

The SEL-701 Relay uses this function to allow a Modbus master to perform a diagnostic test on the Modbus communications channel and relay. When the subfunction field is 0000h, the relay returns a replica of the received message.

Table C.12 08h Loopback Diagnostic Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (08h)
2 bytes	Subfunction (0000h)
2 bytes	Data field
2 bytes	CRC-16 for message
A Successful SEL-701 Relay Response Will Have the Following Format	
1 byte	Slave address
1 byte	Function code (08h)
2 bytes	Subfunction (0000h)
2 bytes	Data field
2 bytes	CRC-16 for message

10h Preset Multiple Registers Command

This function code works much like code 06h, except that it allows you to write multiple registers at once, up to 100 per operation. Normally, this function code will only be used to write source addresses in the User map region. If you are accustomed to 4X references with the function code, for 6-digit addressing, simply add 400001 to the standard database addresses.

Table C.13 10h Preset Multiple Registers Command

Bytes	Field
The Master Request Must Have the Following Format	
1 byte	Slave address
1 byte	Function code (10h)
2 bytes	Starting address
2 bytes	Number of registers to write
1 byte	Byte count (should be twice number of registers)
n bytes	Byte count bytes of data
2 bytes	CRC-16 for message
A Successful SEL-701 Relay Response Will Have the Following Format	
1 byte	Slave address
1 byte	Function code (10h)
2 bytes	Starting address
2 bytes	Number of registers
2 bytes	CRC-16 for message

Controlling Output Contacts and Remote Bits Using Modbus

The SEL-701 Relay Modbus Register Map (*Table C.18 on page C.11*) includes three fields that allow a Modbus Master to control relay output contacts and Relay Word Remote Bits (see *Appendix B: SELOGIC Control Equations and Relay Logic*). Use Modbus function codes 06h or 10h to write the appropriate command codes and parameters into the registers shown in *Table C.14*.

Table C.14 SEL-701 Relay Modbus Command Region

Address	Field
0030h	Command Code
0031h	Parameter 1
0032h	Parameter 2

Table C.15 defines the command codes, their function and associated parameters, and the function code used to initiate the code.

Table C.15 Modbus Command Codes (Sheet 1 of 2)

Command Code	Function	Parameter Definition	Modbus Function Code
01 ^a	Start	No Parameters	06h, 10h
02 ^a	Stop	No Parameters	06h, 10h
03 ^a	Emergency Restart	No Parameters	06h, 10h
04 ^a	Reset Trip, Targets	No Parameters	06h, 10h
05	Pulse Output Contacts	Parameter 1: 1TRIP 2OUT1 3OUT2 4OUT3 5ALARM Parameter 2: 1–15; Pulse duration in minutes Default to 1 second if not supplied	10h
06	Control Remote Bits	Parameter 1: 1Set Remote Bit 2Clear Remote Bit 3Pulse Remote Bit Parameter 2: 0000000000000001 RB1 0000000000000010 RB2 0000000000000100 RB3 0000000000001000 RB4	10h

Table C.15 Modbus Command Codes (Sheet 2 of 2)

Command Code	Function	Parameter Definition	Modbus Function Code
07	Reset Data Regions	Parameter 1: 0000000000000001 Demand 0000000000000010 Peak Demand 0000000000000100 Max/Min Meter 0000000000001000 Energy Meter 0000000000010000 Motor Statistics 0000000000100000 Event Data 0000000001000000 Thermal Meter	10h

^a Command Codes 01–04 are also coil numbers which can be set or cleared using Function Code 05. Clearing these coils using Function Code 05 is allowed for compatibility, but has no effect as the relay immediately acts on and clears set coils.

Parameter 1 of Command Code 7 is bit-masked to allow you to manipulate several Data Regions simultaneously.

Reading the Relay Status Using Modbus

The SEL-701 Relay Modbus Register Map provides fields that allow you to read the present relay self-test results. Read the two registers starting with Modbus Map address 160h. *Table C.16* shows how to interpret the results.

Table C.16 Relay Self-Test Result in Bit Definition

Bits (s)	Definition	
	Register 1	Register 2
0	IA Offset	Temperature
1	IB Offset	RAM
2	IC Offset	ROM
3	IN Offset	CR_RAM
4	VA Offset	EEPROM
5	VB Offset	Battery
6	VC Offset	RTC
7	N Offset	Learned Cool Time
8	5 V PS	Thermal Capacity
9	–5 V PS	Enabled/Disabled
10	15 V PS	Not Used
11	28 V PS	Not Used
12–15	Not Used	Not Used

All bits, except Enabled/Disabled are defined: 0 = Okay; 1 = Failure. The Enabled/Disabled bit is defined: 0 = Enabled; 1 = Disabled.

User-Defined Modbus Data Region

The SEL-701 Relay Modbus Register Map defines an area of 125 contiguous addresses whose contents are defined by 125 user settable addresses. This feature allows you to take 125 discrete values from anywhere in the Modbus Register Map and place them in contiguous registers that you can then read in a single command. The ACSELERATOR QuickSet® SEL-5030 Software provides a convenient method to define the User Map Addresses, download the configuration to a particular relay, and store the configuration for use with other relays.

To apply the user-defined data region, follow the steps listed below:

- Step 1. Define the list of desired quantities (up to 125). Arrange the quantities in any order that is convenient for you to use.
- Step 2. Refer to *Table C.18*, and list the address of each quantity.
- Step 3. Set the SEL-701 Relay User Map Addresses equal to the addresses of the desired quantities using ACSELERATOR QuickSet and a PC connected to the front-panel serial port.
- Step 4. Use Modbus Function Code 03h or 04h to read the desired quantities from addresses 0050h through 00CCh (User Map Values) at the rear-panel EIA-485 port.

Reading Event Data Using Modbus

The Modbus Register Map provides a feature that allows you to download complete event data via Modbus. The SEL-701 Relay stores the latest 14 full-length event reports in nonvolatile memory. *Section 9: Event Analysis* contains a complete description of the event data. Download event summary data by writing an event number to 0371h, then reading the desired data from addresses 0372h through 0395h.

To download analog event data using Modbus, you need to select both the event number (write to 03A1h) and the analog channel number (write to 03A2h), then read the 4-sample per cycle event data from addresses 03A3h through 03DEh. *Table C.17* shows the channel assignments.

Table C.17 Assign Event Report Channel Using Address 03A2h (Sheet 1 of 2)

Set 03A2h Equal To	To Read Data From Channel
1	IA
2	IB
3	IC
4	IG
5	IN
6	VA
7	VB
8	VC
9	Relay Word Rows 1 and 2
10	Relay Word Rows 3 and 4
11	Relay Word Rows 5 and 6

Table C.17 Assign Event Report Channel Using Address 03A2h (Sheet 2 of 2)

Set 03A2h Equal To	To Read Data From Channel
12	Relay Word Rows 7 and 8
13	Relay Word Rows 9 and 10
14	Relay Word Row 11 and reserved

Modbus Register Map

Table C.18 Modbus Register Map (Sheet 1 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
PRODUCT ID						
0000	FID	FID string				
0001						
0002						
0003						
0004						
0005						
0006						
0007						
0008						
0009						
000A						
000B						
000C						
000D						
000E						
000F						
0010	Reserved					
0011						
0012						
0013						
0014						
0015						
0016						
0017						
0018						
0019						
001A	Relay ID	SEL-701				
001B						
001C						
001D						

Table C.18 Modbus Register Map (Sheet 2 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
001E	Reserved Terminal ID <					

Table C.18 Modbus Register Map (Sheet 3 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
USER MAP ADDRESSES						
00D0	User Map Address # 1					
00D1	User Map Address # 2					
00D2	User Map Address # 3					
014A	User Map Address # 123					
014B	User Map Address # 124					
014C	User Map Address # 125					
014D	Reserved					
014E	Reserved					
014F	Reserved					
RELAY ELEMENTS						
0150	Latched LED Targets, Row 1					
0151	Rows 2, 3					
0152	Rows 4, 5					
0153	Rows 6, 7					
0154	Rows 8, 9					
0155	Rows 10, 11					
0156–015F	Reserved					
RELAY STATUS						
0160	Status Register 1		0	2047		
0161	Status Register 2		0	511		
0162–016F	Reserved					
INSTANTANEOUS METERING						
0170	Ia Current		0	65535	1	
0171	Ib Current		0	65535	1	
0172	Ic Current		0	65535	1	
0173	Average Current		0	65535	1	
0174	In Current		0	65535	1	
0175	Vab Voltage	0 if no voltage option	0	65535	1	
0176	Vbc Voltage	0 if no voltage option	0	65535	1	
0177	Vca Voltage	0 if no voltage option	0	65535	1	
0178	Average Voltage	0 if no voltage option	0	65535	1	
0179	Ia Rms Current		0	65535	1	
017A	Ib Rms Current		0	65535	1	
017B	Ic Rms Current		0	65535	1	
017C	Average Rms Current		0	65535	1	
017D	In Rms Current		0	65535	1	
017E	Vab Rms Voltage	0 if no voltage option	0	65535	1	
017F	Vbc Rms Voltage	0 if no voltage option	0	65535	1	
0180	Vca Rms Voltage	0 if no voltage option	0	65535	1	

Table C.18 Modbus Register Map (Sheet 4 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
0181	Average Rms Voltage	0 if no voltage option	0	65535	1	• 0.01
0182	kW3P Power	0 if no voltage option	–32768	32767	1	
0183	kW3P Avg Power	0 if no voltage or single volt	–32768	32767	1	
0184	HP	0 if no voltage option	–32768	32767	1	
0185	kVAR3P Power	0 if no voltage option	–32768	32767	1	
0186	kVA3P Power	0 if no voltage option	–32768	32767	1	
0187	Power Factor	0 if no voltage option	–100	100	1	
0188	Ig Current		0	65535	1	
0189	3I2 Current		0	65535	1	• 0.01
018A	Vg Voltage	0 if no voltage opt or delta	0	65535	1	
018B	3V2 Voltage	0 if no voltage option	0	65535	1	
018C	System Frequency		2000	7000	1	
018D	% Unbalance		0	1000	1	
018E	Reserved					
018F	Reserved					
THERMAL METERING						
0190	Temperature Preference	67 = C; 70 = F	67	70		
0191	Hottest Winding RTD	See Note 1	See Note 3	See Note 3	1	
0192	Hottest Bearing RTD	See Note 1	See Note 3	See Note 3	1	
0193	Ambient RTD	See Note 1	See Note 3	See Note 3	1	
0194	Hottest Other RTD	See Note 1	See Note 3	See Note 3	1	
0195	RTD #1 Temperature	See Note 2	See Note 3	See Note 3	1	
0196	RTD #2 Temperature	See Note 2	See Note 3	See Note 3	1	
0197	RTD #3 Temperature	See Note 2	See Note 3	See Note 3	1	
0198	RTD #4 Temperature	See Note 2	See Note 3	See Note 3	1	
0199	RTD #5 Temperature	See Note 2	See Note 3	See Note 3	1	
019A	RTD #6 Temperature	See Note 2	See Note 3	See Note 3	1	
019B	RTD #7 Temperature	See Note 2	See Note 3	See Note 3	1	
019C	RTD #8 Temperature	See Note 2	See Note 3	See Note 3	1	
019D	RTD #9 Temperature	See Note 2	See Note 3	See Note 3	1	
019E	RTD #10 Temperature	See Note 2	See Note 3	See Note 3	1	
019F	RTD #11 Temperature	See Note 2	See Note 3	See Note 3	1	
01A0	RTD #12 Temperature	See Note 2	See Note 3	See Note 3	1	
01A1	% of FLA		0	65535	1	• 0.1
01A2	% Thermal Capacity		0	65535	1	• 0.1
01A3	RTD % Thermal Capacity	0 if no RTDs available	0	65535	1	
01A4	Time to Trip	ss	0	9999	1, 1	
01A5	Minutes Since Last Start		0	65535	1	
01A6	Starts This Hour	0	99	1		
01A7	Time to Reset	sssss	0	65535	1	

Table C.18 Modbus Register Map (Sheet 5 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
01A8	Reserved					
01A9	Reserved					
01AA	Reserved					
01AB	Reserved					
01AC	Reserved					
01AD	Reserved					
01AE	Reserved					
01AF	Reserved					
ENERGY METERING						
01B0	MWhr	0 if no voltage option	0	65535	1	
01B1	MVARhr In	0 if no voltage option	0	65535	1	
01B2	MVARhr Out	0 if no voltage option	0	65535	1	
01B3	MVAhr	0 if no voltage option	0	65535	1	
01B4	Last Reset Date	mm, dd	1, 1	12, 31	1, 1	
01B5		yyyy	0	65535	1	
01B6	Last Reset Time	hh, mm	0, 0	23, 59	1, 1	
01B7		ssss	0	5999	1	• 0.01
01B8	Reserved					
01B9	Reserved					
01BA	Reserved					
01BB	Reserved					
01BC	Reserved					
01BD	Reserved					
01BE	Reserved					
01BF	Reserved					
DEMAND METERING						
01C0	Ia Demand		0	65535	1	
01C1	Ib Demand		0	65535	1	
01C2	Ic Demand		0	65535	1	
01C3	In Demand		0	65535	1	
01C4	Ig Demand		0	65535	1	
01C5	3I2 Demand		0	65535	1	
01C6	kW3P Demand	0 if no voltage option	0	65535	1	
01C7	kVAR3P Demand In	0 if no voltage option	0	65535	1	
01C8	kVAR3P Demand Out	0 if no voltage option	0	65535	1	
01C9	kVA3P Demand	0 if no voltage option	0	65535	1	
01CA	Last Reset Date	mm, dd	1, 1	12, 31	1, 1	
01CB		yyyy	0	65535	1	

Table C.18 Modbus Register Map (Sheet 6 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
01CC	Last Reset Time	hh, mm	0, 0	23, 59	1, 1	• 0.01
01CD		ssss	0	5999	1	
01CE	Reserved					
01CF	Reserved					
PEAK DEMAND METERING						
01D0	Ia Peak Demand		0	65535	1	• 0.01
01D1	Ib Peak Demand		0	65535	1	
01D2	Ic Peak Demand		0	65535	1	
01D3	In Peak Demand		0	65535	1	
01D4	Ig Peak Demand		0	65535	1	
01D5	3I2 Peak Demand		0	65535	1	
01D6	kW3P Peak Demand	0 if no voltage option	0	65535	1	
01D7	kVAR3P Peak Demand In	0 if no voltage option	0	65535	1	
01D8	kVAR3P Peak Demand Out	0 if no voltage option	0	65535	1	
01D9	kVA3P Peak Demand	0 if no voltage option	0	65535	1	
01DA	Last Reset Date	mm, dd	1, 1	12, 31	1, 1	
01DB		yyyy	0	65535	1	
01DC	Last Reset Time	hh, mm	0, 0	23, 59	1, 1	
01DD		ssss	0	5999	1	
01DE	Reserved					
01DF	Reserved					
CURRENT MAX/MIN METERING						
01E0	Ia Max Current	(FFFFh if reset)	0	65535	1	• 0.01
01E1	Ia Max Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
01E2		yyyy (FFFFh if reset)	0	65535	1	
01E3	Ia Max Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
01E4		ssss (FFFFh if reset)	0	5999	1	• 0.01
01E5	Ia Min Current	(FFFFh if reset)	0	65535	1	
01E6	Ia Min Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
01E7		yyyy (FFFFh if reset)	0	65535	1	
01E8	Ia Min Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
01E9		ssss (FFFFh if reset)	0	5999	1	
01EA	Ib Max Current	(FFFFh if reset)	0	65535	1	
01EB	Ib Max Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
01EC		yyyy (FFFFh if reset)	0	65535	1	• 0.01
01ED	Ib Max Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
01EE		ssss (FFFFh if reset)	0	5999	1	
01EF	Ib Min Current	(FFFFh if reset)	0	65535	1	
01F0	Ib Min Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
01F1		yyyy (FFFFh if reset)	0	65535	1	

Table C.18 Modbus Register Map (Sheet 7 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
01F2	Ib Min Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
01F3		ssss (FFFFh if reset)	0	5999	1	
01F4	Ic Max Current	(FFFFh if reset)	0	65535	1	
01F5	Ic Max Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
01F6		yyyy (FFFFh if reset)	0	65535	1	
01F7	Ic Max Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
01F8		ssss (FFFFh if reset)	0	5999	1	
01F9	Ic Min Current	(FFFFh if reset)	0	65535	1	
01FA	Ic Min Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
01FB		yyyy (FFFFh if reset)	0	65535	1	
01FC	Ic Min Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
01FD		ssss (FFFFh if reset)	0	5999	1	
01FE	In Max Current	(FFFFh if reset)	0	65535	1	
01FF	In Max Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0200		yyyy (FFFFh if reset)	0	65535	1	
0201	In Max Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
0202		ssss (FFFFh if reset)	0	5999	1	
0203	In Min Current	(FFFFh if reset)	0	65535	1	
0204	In Min Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0205		yyyy (FFFFh if reset)	0	65535	1	
0206	In Min Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
0207		ssss (FFFFh if reset)	0	5999	1	
0208	Ig Max Current	(FFFFh if reset)	0	65535	1	
0209	Ig Max Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
020A		yyyy (FFFFh if reset)	0	65535	1	
020B	Ig Max Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
020C		ssss (FFFFh if reset)	0	5999	1	
020D	Ig Min Current	(FFFFh if reset)	0	65535	1	
020E	Ig Min Current Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
020F		yyyy (FFFFh if reset)	0	65535	1	
0210	Ig Min Current Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
0211		ssss (FFFFh if reset)	0	5999	1	
0212	Last Reset Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0213		yyyy (FFFFh if reset)	0	65535	1	
0214	Last Reset Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
0215		ssss (FFFFh if reset)	0	5999	1	
0216–021F	Reserved					

Table C.18 Modbus Register Map (Sheet 8 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
RTD MAX/MIN METERING						
0220	RTD # 1 Max Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0221	RTD # 1 Max Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0222		yyyy (FFFFh if reset)	0	65535	1	
0223	RTD # 1 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0224		ssss (FFFFh if reset)	0	5999	1	• 0.01
0225	RTD # 1 Min Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0226	RTD # 1 Min Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0227		yyyy (FFFFh if reset)	0	65535	1	
0228	RTD # 1 Min Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0229		ssss (FFFFh if reset)	0	5999	1	• 0.01
022A	RTD # 2 Max Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
022B	RTD # 2 Max Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
022C		yyyy (FFFFh if reset)	0	65535	1	
022D	RTD # 2 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
022E		ssss (FFFFh if reset)	0	5999	1	• 0.01
022F	RTD # 2 Min Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0230	RTD # 2 Min Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0231		yyyy (FFFFh if reset)	0	65535	1	
0232	RTD # 2 Min Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0233		ssss (FFFFh if reset)	0	5999	1	• 0.01
0234	RTD # 3 Max Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0235	RTD # 3 Max Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0236		yyyy (FFFFh if reset)	0	65535	1	
0237	RTD # 3 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0238		ssss (FFFFh if reset)	0	5999	1	• 0.01
0239	RTD # 3 Min Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
023A	RTD # 3 Min Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
023B		yyyy (FFFFh if reset)	00	65535	1	
023C	RTD # 3 Min Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
023D		ssss (FFFFh if reset)	0	5999	1	• 0.01
023E	RTD # 4 Max Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	

Table C.18 Modbus Register Map (Sheet 9 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
023F	RTD # 4 Max Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
0240		yyyy (FFFFh if reset)	0	65535	1	
0241	RTD # 4 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0242		ssss (FFFFh if reset)	0	5999	1	
0243	RTD # 4 Min Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	• 0.01
0244	RTD # 4 Min Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0245		yyyy (FFFFh if reset)	0	65535	1	
0246		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0247	RTD # 4 Min Temperature Time	ssss (FFFFh if reset)	0	5999	1	• 0.01
0248		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0249	RTD # 5 Max Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
024A		yyyy (FFFFh if reset)	0	65535	1	
024B	RTD # 5 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
024C		ssss (FFFFh if reset)	0	5999	1	
024D	RTD # 5 Min Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
024E	RTD # 5 Min Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
024F		yyyy (FFFFh if reset)	0	65535	1	• 0.01
0250	RTD # 5 Min Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0251		ssss (FFFFh if reset)	0	5999	1	
0252	RTD # 6 Max Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0253	RTD # 6 Max Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
0254		yyyy (FFFFh if reset)	0	65535	1	
0255	RTD # 6 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0256		ssss (FFFFh if reset)	0	5999	1	
0257	RTD # 6 Min Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	• 0.01
0258	RTD # 6 Min Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0259		yyyy (FFFFh if reset)	0	65535	1	
025A		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
025B	RTD # 6 Min Temperature Time	ssss (FFFFh if reset)	0	5999	1	• 0.01
025C		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
025D	RTD # 7 Max Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
025E		yyyy (FFFFh if reset)	0	65535	1	

Table C.18 Modbus Register Map (Sheet 10 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
025F	RTD # 7 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
0260		ssss (FFFFh if reset)	0	5999	1	
0261		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0262	RTD # 7 Min Temperature Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
0263		yyyy (FFFFh if reset)	0	65535	1	
0264		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0265	RTD # 7 Min Temperature Time	ssss (FFFFh if reset)	0	5999	1	• 0.01
0266		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0267		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0268	RTD # 8 Max Temperature Date	yyyy (FFFFh if reset)	0	65535	1	• 0.01
0269		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
026A		ssss (FFFFh if reset)	0	5999	1	
026B	RTD # 8 Min Temperature Time	FFFFh if reset or no RTD	See Note 3	See Note 3	1	• 0.01
026C		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
026D		yyyy (FFFFh if reset)	0	65535	1	
026E	RTD # 8 Min Temperature Date	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
026F		ssss (FFFFh if reset)	0	5999	1	
0270		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0271	RTD # 9 Max Temperature Time	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
0272		yyyy (FFFFh if reset)	0	65535	1	
0273		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0274	RTD # 9 Min Temperature Date	ssss (FFFFh if reset)	0	5999	1	• 0.01
0275		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0276		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0277	RTD # 9 Min Temperature Time	yyyy (FFFFh if reset)	0	65535	1	• 0.01
0278		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0279		ssss (FFFFh if reset)	0	5999	1	
027A	RTD # 10 Max Temperature Date	FFFFh if reset or no RTD	See Note 3	See Note 3	1	• 0.01
027B		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
027C		yyyy (FFFFh if reset)	0	65535	1	
027D	RTD # 10 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	

Table C.18 Modbus Register Map (Sheet 11 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
027E	RTD # 10 Min Temperature	ssss (FFFFh if reset)	0	5999	1	• 0.01
027F		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
0280		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0281	RTD # 10 Min Temperature Time	yyyy (FFFFh if reset)	0	65535	1	• 0.01
0282		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0283		ssss (FFFFh if reset)	0	5999	1	
0284	RTD # 11 Max Temperature	FFFFh if reset or no RTD	See Note 3	See Note 3	1	• 0.01
0285		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0286		yyyy (FFFFh if reset)	0	65535	1	
0287	RTD # 11 Max Temperature Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
0288		ssss (FFFFh if reset)	0	5999	1	
0289		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
028A	RTD # 11 Min Temperature	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
028B		yyyy (FFFFh if reset)	0	65535	1	
028C		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
028D	RTD # 11 Min Temperature Date	ssss (FFFFh if reset)	0	5999	1	• 0.01
028E		FFFFh if reset or no RTD	See Note 3	See Note 3	1	
028F		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0290	RTD # 12 Max Temperature	yyyy (FFFFh if reset)	0	65535	1	• 0.01
0291		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
0292		ssss (FFFFh if reset)	0	5999	1	
0293	RTD # 12 Max Temperature Time	FFFFh if reset or no RTD	See Note 3	See Note 3	1	• 0.01
0294		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0295		yyyy (FFFFh if reset)	0	65535	1	
0296	RTD # 12 Min Temperature	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
0297		ssss (FFFFh if reset)	0	5999	1	
0298		mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
0299	Last Reset Date	yyyy (FFFFh if reset)	0	65535	1	• 0.01
029A		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
029B		ssss (FFFFh if reset)	0	5999	1	
029C	Reserved					

Table C.18 Modbus Register Map (Sheet 12 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
029D	Reserved					
029E	Reserved					
029F	Reserved					
VOLTAGE/POWER MAX/MIN METERING						
02A0	Vab Max Voltage	(FFFFh if reset or no voltage option)	0	65535	1	
02A1	Vab Max Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02A2		yyyy (FFFFh if reset)	0	65535	1	
02A3	Vab Max Voltage Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02A4		ssss (FFFFh if reset)	0	5999	1	• 0.01
02A5	Vab Min Voltage	(FFFFh if reset or no voltage option)	0	65535	1	
02A6	Vab Min Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02A7		yyyy (FFFFh if reset)	0	65535	1	
02A8	Vab Min Voltage Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02A9		ssss (FFFFh if reset)	0	5999	1	• 0.01
02AA	Vbc Max Voltage	(FFFFh if reset or no voltage option)	0	65535	1	
02AB	Vbc Max Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02AC		yyyy (FFFFh if reset)	0	65535	1	
02AD	Vbc Max Voltage Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02AE		ssss (FFFFh if reset)	0	5999	1	• 0.01
02AF	Vbc Min Voltage	(FFFFh if reset or no voltage option)	0	65535	1	
02B0	Vbc Min Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02B1		yyyy (FFFFh if reset)	0	65535	1	
02B2	Vbc Min Voltage Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02B3		ssss (FFFFh if reset)	0	5999	1	• 0.01
02B4	Vca Max Voltage	(FFFFh if reset or no voltage option)	0	65535	1	
02B5	Vca Max Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02B6		yyyy (FFFFh if reset)	0	65535	1	
02B7	Vca Max Voltage Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02B8		ssss (FFFFh if reset)	0	5999	1	• 0.01
02B9	Vca Min Voltage	(FFFFh if reset or no voltage option)	0	65535	1	
02BA	Vca Min Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02BB		yyyy (FFFFh if reset)	0	65535	1	
02BC	Vca Min Voltage Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02BD		ssss (FFFFh if reset)	0	5999	1	• 0.01
02BE	Vg Max Voltage	(FFFFh if reset or no voltage option)	0	65535	1	
02BF	Vg Max Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	

Table C.18 Modbus Register Map (Sheet 13 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
02C0	Vg Max Voltage Time	yyyy (FFFFh if reset)	0	65535	1	• 0.01
02C1		hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02C2		ssss (FFFFh if reset)	0	5999	1	
02C3	Vg Min Voltage	(FFFFh if reset or no voltage option)	0	65535	1	• 0.01
02C4	Vg Min Voltage Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02C5		yyyy (FFFFh if reset)	0	65535	1	
02C6	Vg Min Voltage Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
02C7		ssss (FFFFh if reset)	0	5999	1	
02C8	Max kW3P Power	(FFFFh if reset or no voltage option)	–32768	32767	1	
02C9	Max kW3P Power Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
02CA		yyyy (FFFFh if reset)	0	65535	1	
02CB	Max kW3P Power Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02CC		ssss (FFFFh if reset)	0	5999	1	• 0.01
02CD	Min kW3P Power	(FFFFh if reset or no voltage option)	–32768	32767	1	
02CE	Min kW3P Power Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02CF		yyyy (FFFFh if reset)	0	65535	1	• 0.01
02D0	Min kW3P Power Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02D1		ssss (FFFFh if reset)	0	5999	1	
02D2	Max kVAR3P Power	(FFFFh if reset or no voltage option)	–32768	32767	1	• 0.01
02D3	Max kVAR3P Power Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02D4		yyyy (FFFFh if reset)	0	65535	1	
02D5	Max kVAR3P Power Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
02D6		ssss (FFFFh if reset)	0	5999	1	
02D7	Min kVAR3P Power	(FFFFh if reset or no voltage option)	–32768	32767	1	
02D8	Min kVAR3P Power Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
02D9		yyyy (FFFFh if reset)	0	65535	1	
02DA	Min kVAR3P Power Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02DB		ssss (FFFFh if reset)	0	5999	1	• 0.01
02DC	Max kVA3P Power	(FFFFh if reset or no voltage option)	0	65535	1	
02DD	Max kVA3P Power Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02DE		yyyy (FFFFh if reset)	0	65535	1	• 0.01
02DF	Max kVA3P Power Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	
02E0		ssss (FFFFh if reset)	0	5999	1	
02E1	Min kVA3P Power	(FFFFh if reset or no voltage option)	0	65535	1	• 0.01
02E2	Min kVA3P Power Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	
02E3		yyyy (FFFFh if reset)	0	65535	1	

Table C.18 Modbus Register Map (Sheet 14 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
02E4	Min kVA3P Power Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
02E5		ssss (FFFFh if reset)	0	5999	1	
02E6	Last Reset Date	mm, dd (FFFFh if reset)	1, 1	12, 31	1, 1	• 0.01
02E7		yyyy (FFFFh if reset)	0	65535	1	
02E8	Last Reset Time	hh, mm (FFFFh if reset)	0, 0	23, 59	1, 1	• 0.01
02E9		ssss (FFFFh if reset)	0	5999	1	
02EA	Reserved					
02EB	Reserved					
02EC	Reserved					
02ED	Reserved					
02EE	Reserved					
02EF	Reserved					
MOTOR STATISTICS						
02F0	Elapsed Time	ddd	0	65535	1	
02F1		hh, mm	0, 0	23, 59	1, 1	
02F2	Running Time	ddd	0	65535	1	
02F3		hh, mm	0, 0	23, 59	1, 1	
02F4	Stopped Time	ddd	0	65535	1	
02F5		hh, mm	0, 1	23, 60	1, 2	
02F6	% Time Running		0	1000	1	• 0.1
02F7	MegaWhr		0	65535	1	
02F8	# of Starts		0	65535	1	
02F9	Avg Starting Time	seconds	0	65535	1	• 0.01
02FA	Avg Starting Current		0	65535	1	
02FB	Avg Minimum Starting Voltage	0 if no voltage option	0	65535	1	
02FC	Avg Starting % Therm Cap		0	65535	1	• 0.1
02FD	Avg Running % Therm Cap		0	65535	1	• 0.1
02FE	Avg RTD % Therm Cap		0	65535	1	
02FF	Avg Running Current		0	65535	1	
0300	Avg Running kW	0 if no voltage option	0	65535	1	
0301	Avg Running kVAR In	0 if no voltage option	0	65535	1	
0302	Avg Running kVAR Out	0 if no voltage option	0	65535	1	
0303	Avg Running kVA	0 if no voltage option	0	65535	1	
0304	Avg Hottest Winding RTD Temp	See Note 1	See Note 3	See Note 3	1	
0305	Avg Hottest Bearing RTD Temp	See Note 1	See Note 3	See Note 3	1	
0306	Avg Ambient RTD Temp	See Note 1	See Note 3	See Note 3	1	
0307	Avg Hottest Other RTD Temp	See Note 1	See Note 3	See Note 3	1	

Table C.18 Modbus Register Map (Sheet 15 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
0308	Peak Starting Time	seconds	0	65535	1	• 0.01
0309	Peak Starting Current		0	65535	1	
030A	Peak Minimum Starting Voltage	0 if no voltage option	0	65535	1	
030B	Peak Starting % Therm Cap		0	65535	1	• 0.1
030C	Peak Running % Therm Cap		0	65535	1	• 0.1
030D	Peak RTD % Therm Cap		0	65535	1	
030E	Peak Running Current		0	65535	1	
030F	Peak Running kW	0 if no voltage option	0	65535	1	
0310	Peak Running kVAR In	0 if no voltage option	0	65535	1	
0311	Peak Running kVAR Out	0 if no voltage option	0	65535	1	
0312	Peak Running kVA	0 if no voltage option	0	65535	1	
0313	Peak Hottest Winding RTD Temp	See Note 1	See Note 3	See Note 3	1	
0314	Peak Hottest Bearing RTD Temp	See Note 1	See Note 3	See Note 3	1	
0315	Peak Ambient RTD Temp	See Note 1	See Note 3	See Note 3	1	
0316	Peak Hottest Other RTD Temp	See Note 1	See Note 3	See Note 3	1	
0317	Stopped Cooling Time	Minutes	0	65535	1	• 0.1
0318	Starting Thermal Capacity		0	65535	1	• 0.1
0319	Thermal Alarm Count		0	65535	1	
031A	Locked Rotor Alarm Count		0	65535	1	
031B	Load Loss Alarm Count		0	65535	1	
031C	Unbalance Current Alarm Count		0	65535	1	
031D	Under Power Alarm Count		0	65535	1	
031E	Power Factor Alarm Count		0	65535	1	
031F	Reactive Power Alarm Count		0	65535	1	
0320	RTD Alarm Count		0	65535	1	
0321	Total Alarm Count		0	65535	1	
0322	Thermal Trip Count		0	65535	1	
0323	Locked Rotor Trip Count		0	65535	1	
0324	Load Loss Trip Count		0	65535	1	
0325	Load Jam Trip Count		0	65535	1	
0326	Unbalance Current Trip Count		0	65535	1	
0327	Phase Fault Trip Count		0	65535	1	
0328	Ground Fault Trip Count		0	65535	1	
0329	Speed Switch Trip Count		0	65535	1	

Table C.18 Modbus Register Map (Sheet 16 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
032A	Undervoltage Trip Count		0	65535	1	• 0.01
032B	Overvoltage Trip Count		0	65535	1	
032C	Under Power Trip Count		0	65535	1	
032D	Power Factor Trip Count		0	65535	1	
032E	Reactive Power Trip Count		0	65535	1	
032F	Phase Reversal Trip Count		0	65535	1	
0330	Under-frequency Trip Count		0	65535	1	
0331	Over-frequency Trip Count		0	65535	1	
0332	RTD Trip		0	65535	1	
0333	Total Trip		0	65535	1	
0334	Reset Date	mm, dd	1, 1	12, 31	1, 1	
0335		yyyy	0	65535	1	
0336	Reset Time	hh, mm	0, 0	23, 59	1, 1	
0337		ssss	0	5999	1	
0338	Reserved					
0339	Reserved					
033A	Reserved					
033B	Reserved					
033C	Reserved					
033D	Reserved					
033E	Reserved					
033F	Reserved					
START REPORT SUMMARIES						
0340	Latest Accel Time	seconds	0	65535	1	• 0.01
0341	Latest Starting % Therm Cap		0	65535	1	• 0.1
0342	Latest Max Start Current		0	65535	1	
0343	Latest Min Start Voltage	0 if no voltage option	0	65535	1	
0344	Latest Start Date	mm, dd	1, 1	12, 31	1, 1	
0345		yyyy	0	65535	1	
0346	Latest Start Time	hh, mm	0, 0	23, 59	1, 1	
0347		ssss	0	5999	1	• 0.01
0348	2nd Latest Accel Time	seconds	0	65535	1	• 0.01
0349	2nd Latest Starting % Therm Cap		0	65535	1	• 0.1
034A	2nd Latest Max Start Current		0	65535	1	
034B	2nd Latest Min Start Voltage	0 if no voltage option	0	65535	1	
034C	2nd Latest Start Date	mm, dd	1, 1	12, 31	1, 1	
034D		yyyy	0	65535	1	

Table C.18 Modbus Register Map (Sheet 17 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
034E	2nd Latest Start Time	hh, mm	0, 0	23, 59	1, 1	• 0.01
034F		ssss	0	5999	1	
0350	3rd Latest Accel Time	seconds	0	65535	1	• 0.01
0351			0	65535	1	
0352	3rd Latest Starting % Therm Cap		0	65535	1	• 0.1
0353			0	65535	1	
0354	3rd Latest Max Start Current		0	65535	1	
0355			0	65535	1	
0356	3rd Latest Min Start Voltage	0 if no voltage option	0	65535	1	
0357			0	65535	1	
0358	3rd Latest Start Date	mm, dd	1, 1	12, 31	1, 1	
0359		yyyy	0	65535	1	
035A	3rd Latest Start Time	hh, mm	0, 0	23, 59	1, 1	• 0.01
035B		ssss	0	5999	1	
035C	4th Latest Accel Time	seconds	0	65535	1	• 0.01
035D			0	65535	1	
035E	4th Latest Starting % Therm Cap		0	65535	1	• 0.1
035F			0	65535	1	
0360	4th Latest Max Start Current		0	65535	1	
0361			0	65535	1	
0362	4th Latest Min Start Voltage	0 if no voltage option	0	65535	1	
0363			0	65535	1	
0364	4th Latest Start Date	mm, dd	1, 1	12, 31	1, 1	
0365		yyyy	0	65535	1	
0366	4th Latest Start Time	hh, mm	0, 0	23, 59	1, 1	• 0.01
0367		ssss	0	5999	1	
0368–036F	Reserved					
HISTORY RECORDS						
0370	Number of Event Records		0	14	1	
0371	Event Selection		1	14	1	
0372	Event Date	mm, dd	1, 1	12, 31	1, 1	
0373		yyyy	0	65535	1	
0374	Event Time	hh, mm	0, 0	23, 59	1, 1	• 0.01
0375		ssss	0	5999	1	
0376	Event Type	See Note 4				

Table C.18 Modbus Register Map (Sheet 18 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
0377–0381	Reserved					
0382	Ia		0	65535	1	
0383	Ib		0	65535	1	
0384	Ic		0	65535	1	
0385	In		0	65535	1	
0386	Ig		0	65535	1	
0387	3I2		0	65535	1	
0388	Hottest Winding RTD	See Note 1	See Note 3	See Note 3	1	
0389	Hottest Bearing RTD	See Note 1	See Note 3	See Note 3	1	
038A	Ambient RTD	See Note 1	See Note 3	See Note 3	1	
038B	Hottest Other RTD	See Note 1	See Note 3	See Note 3	1	
038C	Vab	0 if no voltage option	0	65535	1	
038D	Vbc	0 if no voltage option	0	65535	1	
038E	Vca	0 if no voltage option	0	65535	1	
038F	kW	0 if no voltage option	–32768	32767	1	
0390	kVAR	0 if no voltage option	–32768	32767	1	
0391	kVA	0 if no voltage option	–32768	32767	1	
0392	Power Factor	0 if no voltage option	–100	100	1	• 0.01
0393	Frequency		2000	7000	1	• 0.01
0394	% Thermal Cap		0	65535	1	• 0.1
0395	% Unbalance Current		0	1000	1	• 0.1
0396–039F	Reserved					
EVENT RECORDS						
03A0	Number of Event Records		0	14	1	
03A1	Event Selection		1	14	1	
03A2	Channel Selection		1	14	1	
03A3	1/4 Cycle		–32768	32767	1	
03A4	2/4 Cycle		–32768	32767	1	
03A5	3/4 Cycle		–32768	32767	1	
03A6	1 Cycle		–32768	32767	1	
03A7	1 1/4 Cycle		–32768	32767	1	
03A8	1 2/4 Cycle		–32768	32767	1	
03A9	1 3/4 Cycle		–32768	32767	1	
03AA	2 Cycle		–32768	32767	1	
03AB	2 1/4 Cycle		–32768	32767	1	
03AC	2 2/4 Cycle		–32768	32767	1	
03AD	2 3/4 Cycle		–32768	32767	1	
03AE	3 Cycle		–32768	32767	1	
03AF	3 1/4 Cycle		–32768	32767	1	
03B0	3 2/4 Cycle		–32768	32767	1	

Table C.18 Modbus Register Map (Sheet 19 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
03B1	3 3/4 Cycle		-32768	32767	1	
03B2	4 Cycle		-32768	32767	1	
03B3	4 1/4 Cycle		-32768	32767	1	
03B4	4 2/4 Cycle		-32768	32767	1	
03B5	4 3/4 Cycle		-32768	32767	1	
03B6	5 Cycle		-32768	32767	1	
03B7	5 1/4 Cycle		-32768	32767	1	
03B8	5 2/4 Cycle		-32768	32767	1	
03B9	5 3/4 Cycle		-32768	32767	1	
03BA	6 Cycle		-32768	32767	1	
03BB	6 1/4 Cycle		-32768	32767	1	
03BC	6 2/4 Cycle		-32768	32767	1	
03BD	6 3/4 Cycle		-32768	32767	1	
03BE	7 Cycle		-32768	32767	1	
03BF	7 1/4 Cycle		-32768	32767	1	
03C0	7 2/4 Cycle		-32768	32767	1	
03C1	7 3/4 Cycle		-32768	32767	1	
03C2	8 Cycle		-32768	32767	1	
03C3	8 1/4 Cycle		-32768	32767	1	
03C4	8 2/4 Cycle		-32768	32767	1	
03C5	8 3/4 Cycle		-32768	32767	1	
03C6	9 Cycle		-32768	32767	1	
03C7	9 1/4 Cycle		-32768	32767	1	
03C8	9 2/4 Cycle		-32768	32767	1	
03C9	9 3/4 Cycle		-32768	32767	1	
03CA	10 Cycle		-32768	32767	1	
03CB	10 1/4 Cycle		-32768	32767	1	
03CC	10 2/4 Cycle		-32768	32767	1	
03CD	10 3/4 Cycle		-32768	32767	1	
03CE	11 Cycle		-32768	32767	1	
03CF	11 1/4 Cycle		-32768	32767	1	
03D0	11 2/4 Cycle		-32768	32767	1	
03D1	11 3/4 Cycle		-32768	32767	1	
03D2	12 Cycle		-32768	32767	1	
03D3	12 1/4 Cycle		-32768	32767	1	
03D4	12 2/4 Cycle		-32768	32767	1	
03D5	12 3/4 Cycle		-32768	32767	1	
03D6	13 Cycle		-32768	32767	1	
03D7	13 1/4 Cycle		-32768	32767	1	
03D8	13 2/4 Cycle		-32768	32767	1	
03D9	13 3/4 Cycle		-32768	32767	1	
03DA	14 Cycle		-32768	32767	1	

Table C.18 Modbus Register Map (Sheet 20 of 20)

Address (hex)	Field	Sample	Low	High	Step	Scale Factor
03DB	14 1/4 Cycle		–32768	32767	1	
03DC	14 2/4 Cycle		–32768	32767	1	
03DD	14 3/4 Cycle		–32768	32767	1	
03DE	15 Cycle		–32768	32767	1	
03DF	Reserved					

NOTE 1: Summary RTD Temperature Addresses can contain the following diagnostic codes:

7ffeh = Fail

7ff0h = Not Attached or Not Available

NOTE 2: Individual RTD Temperature Addresses can contain the following diagnostic codes:

8000h = RTD shorted

7fffh = RTD open

7ffch = SEL-2600 series RTD module Communication Failure

7ff8h = SEL-2600 series RTD module Self-Test Status Failure

7ff0h = RTD Not Attached or Not Available

NOTE 3: RTD Temperature Range Depends on the relay temperature preference setting.

Temperature Preference	Low	High
°C	–50	250
°F	–58	482

NOTE 4: The event type is reported as a character string as shown in the table below:

Event Type Strings	
THERMAL	POWER FACTOR
LOCKED ROTOR	REACTIVE POWER
LOAD LOSS	PHASE REVERSAL
LOAD JAM	UNDERFREQUENCY
UNBALANCED CURRENT	OVERFREQUENCY
PHASE FAULT	RTD
GROUND FAULT	STOP COMMAND
SPEED SWITCH	TRIP
UNDERVOLTAGE	ER
OVERVOLTAGE	PULSE
UNDERPOWER	TRIG

Appendix D

SEL Communications Processors

Introduction

This appendix describes communication features that the SEL-701 Relay serial ports support when they are configured for ASCII communications. These functions are not provided on the relay EIA-485 port when it is configured for Modbus® protocol support.

SEL relays have two separate data streams that share the same EIA-232 serial port. The relay supports communication with people using ASCII character commands and formatted responses that are intelligible using a terminal or terminal emulation package. In addition, the relay includes a class of compressed-ASCII commands intended for use by the ACSELERATOR QuickSet® SEL-5030 Software. These command responses include ASCII characters but are formatted in a way that makes them more compact. They are typically better suited to software analysis than analysis using a terminal emulation package.

Interleaved with the ASCII data stream, the relay can receive and respond to a set of binary commands. This mechanism allows a single communications channel to be used for ASCII communications (e.g., transmission of a long event report) interleaved with short bursts of binary data to support fast acquisition of metering data. The requesting device must be equipped to execute the binary commands, then separate and interpret the binary response. The binary commands and ASCII commands can also be accessed by a device that does not interleave the data streams.

SEL *Application Guide AG95-10, Configuration and Fast Meter Messages*, is a comprehensive description of the SEL binary messages.

Fast Binary Message Lists

Binary Message List

Table D.1 Binary Message List

Request to Relay	Response From Relay
Hex	
A5C0	Relay Definition Block
A5C1	Fast Meter Configuration Block
A5D1	Fast Meter Data Block
A5C2	Demand Fast Meter Configuration Block
A5D2	Demand Fast Meter Data Message
A5C3	Peak Demand Fast Meter Configuration Block
A5D3	Peak Demand Fast Meter Data Message
A5B9	Fast Meter Status Acknowledge
A5CE	Fast Operate Configuration Block
A5E0	Fast Operate Remote Bit Control
A5E3	Fast Operate Breaker/Contactor Control

ASCII Configuration Message List

Table D.2 ASCII Configuration Message List

Request to Relay	Response From Relay
ASCII	
ID	ASCII Relay Identification and Configuration Strings
DNA	ASCII Names of Relay Word Bits
BNA	ASCII Names of Bits in the A5B9 Status Byte

Fast Binary Message Definitions

A5C0 Relay Definition Block

In response to the A5C0 request, the relay sends the block shown in *Table D.3*.

Table D.3 A5C0 Relay Definition Block

Data	Description
A5C0	Command
48	Length
02	Support two protocols
03	Support three Fast Meter messages
06	Support three status flag commands
A5C1	Fast Meter configuration command
A5D1	Fast Meter command
A5C2	Demand Fast Meter configuration command
A5D2	Demand Fast Meter command
A5C3	Peak Demand Fast Meter configuration command
A5D3	Peak Demand Fast Meter command
0004	Settings change bit
A5C100000000	Fast Meter configuration message
0004	Settings change bit
A5C200000000	Demand Fast Meter configuration message
0004	Settings change bit
A5C300000000	Peak Demand Fast Meter configuration message
0004	Settings change bit
444E410D0000	DNA Command
0004	Settings change bit
49440D000000	ID Command
0004	Settings change bit
4341530D0000	CAS Command
0100	SEL protocol, Fast Operate
0002	Modbus protocol
00	Reserved
checksum	1-byte checksum of preceding bytes

A5C1 Fast Meter Configuration Block

In response to the A5C1 request, the SEL-701 Relay sends the block shown in *Table D.4*.

Table D.4 A5C1 Fast Meter Configuration Block (Sheet 1 of 3)

Data	Description
A5C1	Fast Meter command
xx	Response Length in Bytes (specific value of xx based on relay model, as shown below)
	0x6C Base Relay
	0x94 Relay with RTDs
	0xD0 Relay with voltages
	0xF8 Relay with RTDs, voltages
01	One status flag byte
00	Scale factors in Fast Meter message
00	No scale factors
xx	# of analog input channels (specific value of xx based on relay model, as shown below)
	09 Base Relay
	0D Relay with RTDs
	13 Relay with voltages
	17 Relay with RTDs, voltages
01	# of samples per channel
0D	# of digital banks
00	# of calculation blocks
0004	Analog channel offset
xxxx	Time stamp offset (specific value of xxxx based on relay model, as shown below)
	0028 Base Relay
	0030 Relay with RTDs
	0050 Relay with voltages
	0058 Relay with RTDs, voltages
xxxx	Digital offset (specific value of xxxx based on relay model, as shown below)
	0030 Base Relay
	0038 Relay with RTDs
	0058 Relay with voltages
	0060 Relay with RTDs, voltages
494100000000	Analog channel name (IA)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494200000000	Analog channel name (IB)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494300000000	Analog channel name (IC)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494E00000000	Analog channel name (IN)

Table D.4 A5C1 Fast Meter Configuration Block (Sheet 2 of 3)

Data	Description
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
334932000000	Analog channel name (3I2)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
25556E62616C	Analog channel name (%Unbal)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
465245510000	Analog channel name (Freq)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
25544845524D	Analog channel name (%Therm)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
25464C410000	Analog channel name (%FLA)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
If the Relay Is Equipped With Voltage Inputs	
564142000000	Analog channel name (VAB)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
564243000000	Analog channel name (VBC)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
564341000000	Analog channel name (VCA)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
564700000000	Analog channel name (VG)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
335632000000	Analog channel name (3V2)

Table D.4 A5C1 Fast Meter Configuration Block (Sheet 3 of 3)

Data	Description
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
6B5700000000	Analog channel name (kW)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
485000000000	Analog channel name (HP)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
6B5641520000	Analog channel name (kVAR)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
6B5641000000	Analog channel name (kVA)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
706600000000	Analog channel name (pf)
01	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
If the Relay Is Equipped With Internal or External RTD Inputs	
574447000000	Analog channel name (WDG) [Hottest Winding RTD Temp.]
00	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
425247000000	Analog channel name (BRG) [Hottest Bearing RTD Temp.]
00	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
414D42000000	Analog channel name (AMB) [Ambient RTD Temp.]
00	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
4F5448000000	Analog channel name (OTH) [Hottest Other RTD Temp.]
00	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
All Versions	
00	Reserved
checksum	1-byte checksum of all preceding bytes

A5D1 Fast Meter Data Block

In response to the A5D1 request, the SEL-701 Relay sends the block shown in *Table D.5*.

Table D.5 A5D1 Fast Meter Data Block

Data	Description
A5D1	Command
xx	Length (specific value of xx based on relay model, as shown below) 63 bytes Base Relay 71 bytes Relay with RTDs 103 bytes Relay with voltages 111 bytes Relay with RTDs, voltages
1-byte	1 Status Byte
##-bytes	Magnitudes in 4-byte IEEE floating point numbers (specific value of ## based on relay model, as shown below) 36 bytes Base Relay 76 bytes Relay with voltages
##-bytes	Magnitudes in 2-byte integer (specific value f ## based on relay model, as shown below) 8 bytes Relay with RTDs
8-bytes	Time stamp
13-bytes	13 Digital banks: 11 Relay Word rows, plus 2 rows for targets
1-byte	Reserved
checksum	1-byte checksum of all preceding bytes

A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages

In response to the A5C2 or A5C3 request, the SEL-701 Relay sends the block shown in *Table D.6*.

Table D.6 A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages (Sheet 1 of 3)

Data	Description
A5C2 or A5C3 Command; Demand (A5C2) or Peak Demand (A5C3)	
xx	Length in bytes (specific value of xx based on relay model, as shown below) 78 bytes Base Relay 118 bytes Relay with voltages
01	# of status flag bytes
00	Scale factors in meter message
00	# of scale factors
xx	# of analog input channels (specific value of xx based on relay model, as shown below) 6 Base Relay 10 Relay with voltages
01	# of samples per channel
00	# of digital banks

Table D.6 A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages (Sheet 2 of 3)

Data	Description
00	# of calculation blocks
0004	Analog channel offset
xxxx	Time stamp offset (specific value of xxxx based on relay model, as shown below)
0034	Base Relay
0054	Relay with voltages
FFFF	Digital offset
494100000000	Analog channel name (IA)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494200000000	Analog channel name (IB)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494300000000	Analog channel name (IC)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494E00000000	Analog channel name (IN)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
494700000000	Analog channel name (IG)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
334932000000	Analog channel name (3I2)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
When Voltage Inputs Are Included	
50332B000000	Analog channel name (P3+)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
51332B000000	Analog channel name (Q3+)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
533300000000	Analog channel name (S3)

Table D.6 A5C2/A5C3 Demand/Peak Demand Fast Meter Configuration Messages (Sheet 3 of 3)

Data	Description
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
51332D000000	Analog channel name (Q3-)
02	Analog channel type
FF	Scale factor type
0000	Scale factor offset in Fast Meter message
All Versions	
00	Reserved
checksum	1-byte checksum of preceding bytes

A5D2/A5D3 Demand/Peak Demand Fast Meter Message

In response to the A5D2 or A5D3 request, the SEL-701 Relay sends the block shown in *Table D.7*.

Table D.7 A5D2/A5D3 Demand/Peak Demand Fast Meter Message

Data	Description
A5D2 or A5D3 Command	
xx	Length (specific value of xx based on relay model, as shown below)
	62 bytes Base Relay
	94 bytes Relay with voltages
1-byte	1 Status Byte
xx-bytes	Demand/Peak demand quantities in 8-byte IEEE Floating Point numbers (specific value of xx based on relay model, as shown below)
	48 bytes Base Relay
	80 bytes Relay with voltages
8-bytes	Time stamp
1-byte	Reserved
1-byte	1-byte checksum of all preceding bytes

A5B9 Fast Meter Status Acknowledge Message

In response to the A5B9 request, the SEL-701 Relay clears the Fast Meter (message A5D1) Status Byte. The SEL-701 Relay Status Byte contains one active bit, STSET (bit 4). The bit is set on power up and on settings changes. If the STSET bit is set, the external device should request the A5C1, A5C2, and A5C3 messages. The external device can then determine if the scale factors or line configuration parameters have been modified.

A5CE Fast Operate Configuration Block

In response to the A5CE request, the relay sends the block shown in *Table D.8*.

Table D.8 A5CE Fast Operate Configuration Block

Data	Description
A5CE	Command
18	Length
01	Support 1 circuit breaker or contactor
0004	Support 4 remote bit set/clear commands
0100	Allow remote bit pulse commands
31	Operate code, open breaker/contactator (STOP)
11	Operate code, close breaker/contactator (STR)
00	Operate code, clear remote bit RB1
20	Operate code, set remote bit RB1
40	Operate code, pulse remote bit RB1
01	Operate code, clear remote bit RB2
21	Operate code, set remote bit RB2
41	Operate code, pulse remote bit RB2
02	Operate code, clear remote bit RB3
22	Operate code, set remote bit RB3
42	Operate code, pulse remote bit RB3
03	Operate code, clear remote bit RB4
23	Operate code, set remote bit RB4
43	Operate code, pulse remote bit RB4
00	Reserved
checksum	1-byte checksum of all preceding bytes

The SEL-701 Relay performs the specified remote bit operation if the following conditions are true:

- The Operate code is valid.
- The Operate validation = $4 \cdot \text{Operate code} + 1$.
- The message checksum is valid.
- The FASTOP port setting is set to Y.
- The relay is enabled.

Remote bit set and clear operations are latched by the relay. Remote bit pulse operations assert the remote bit for one processing interval (1/4 cycle).

It is common practice to route remote bits to output contacts to provide remote control of the relay outputs. If you wish to pulse an output contact closed for a specific duration, SEL recommends using the remote bit pulse command and SELOGIC® control equations to provide secure and accurate contact control. The remote device sends the remote bit pulse command; the relay controls the timing of the output contact assertion. You can use any remote bit and any SELOGIC control equation timer to control any of the output contacts.

A5E0 Fast Operate Remote Bit Control

Send the **A5E0** command to operate Remote Bits RB1–RB4. The **A5E0** command should contain the items listed in *Table D.9*.

Table D.9 A5E0 Command

Data	Description
A5E0	Command
06	Message length in bytes
1-byte	Operate Code
	00 Clear RB1
	01 Clear RB2
	02 Clear RB3
	03 Clear RB4
	20 Set RB1
	21 Set RB2
	22 Set RB3
	23 Set RB4
	40 Pulse RB1
	41 Pulse RB2
	42 Pulse RB3
	43 Pulse RB4
1-byte	Command validation (4 • Operate Code) + 1
1-byte	1-byte checksum of all preceding bytes

A5E3 Fast Operate Breaker/Contactor Control

Send the **A5E3** command to stop or start the protected motor. Motor starting is only effective if a relay output contact is properly connected to close the motor contactor or breaker.

The **A5E3** command should contain the items listed in *Table D.10*.

Table D.10 A5E3 Command

Data	Description
A5E3	Command
06	Message length in bytes
1-byte	Operate Code
	31 Stop Motor
	11 Start Motor
1-byte	Command validation (4 • Operate Code) + 1
1-byte	1-byte checksum of all preceding bytes

ID Message

In response to the **ID** command, the SEL-701 Relay sends the firmware ID, boot code ID, relay RID setting, the Modbus device code, part number, and configuration as described below.

```
<STX>"FID STRING ENCLOSED IN QUOTES", "yyyy"<CR>
"BOOT CODE ID STRING ENCLOSED IN QUOTES", "yyyy"<CR>
"RID SETTING ENCLOSED IN QUOTES", "yyyy"<CR>
"DEVICE CODE ENCLOSED IN QUOTES", "yyyy"<CR>
"RELAY PART NUMBER ENCLOSED IN QUOTES", "yyyy"<CR>
"RELAY CONFIGURATION NUMBER ENCLOSED IN QUOTES", "yyyy"<CR>
<ETX>
```

where:

- <STX> is the STX character (02).
- <ETX> is the ETX character (03).
- “yyyy” is the 4-byte ASCII hex representation of the checksum for each line.

The ID message is available from Access Level 1 and higher.

DNA Message

In response to the Access Level 1 **DNA** command, the relay sends names of the Relay Word bits transmitted in the A5D1 message. The first name is associated with the MSB and the last name with the LSB. The SEL-701 Relay DNA message is:

```
<STX>
"STARTING", "RUNNING", "STOPPED", "JAMTRIP", "LOSSALRM", "LOSSTRIP", "46UBA", "46UBT",
"13C7"
"49A", "49T", "THERMLO", "NOSLO", "TBSLO", "ABSLO", "*", "*", "0BDE"
"50P1T", "50P2T", "50N1T", "50N2T", "50QT", "50S", "50G1T", "50G2T", "0C8B"
"47T", "TRGTR", "START", "52A", "SPDSTR", "SPEEDSW", "RTDBIAS", "RTDFLT", "0FDC"
"WDGALRM", "WDGTRIP", "BRGALRM", "BRGTRIP", "AMBALRM", "AMBTrip", "OTHALRM", "OTHTRIP",
"141C"
"27P1", "27P2", "59P1", "59P2", "59G", "81D1T", "81D2T", "81D3T", "0B82"
"37PA", "37PT", "55A", "55T", "VARA", "VART", "LOP", "*", "09AD"
"LT1", "LT2", "LT3", "LT4", "RB1", "RB2", "RB3", "RB4", "09E4"
"SV1", "SV2", "SV3", "SV4", "SV1T", "SV2T", "SV3T", "SV4T", "0BAC"
"IN1", "IN2", "IN3", "IN4", "IN5", "IN6", "IN7", "*", "0937"
"TRIP", "OUT1", "OUT2", "OUT3", "ALARM", "50CD", "BFI", "BFT", "0B81"
"*, "MOTSTART", "THERM_AL", "*", "UNBAL_AL", "LOSS_AL", "VOLT_AL", "*", "0FA4"
"ENABLE", "MOTRUN", "THERM_OL", "OVERCURR", "UNBAL", "LOADLOSS", "VOLTAGE", "FREQ", "1311"
<ETX>
```

where:

- <STX> is the STX character (02).
- <ETX> is the ETX character (03).
- the last field in each line is the 4-byte ASCII hex representation of the checksum for the line.
- “*” indicates an unused bit location.

BNA Message

In response to the **BNA** command, the relay sends names of the bits transmitted in the Status Byte in the A5D1 message. The first name is the MSB and the last name is the LSB. The BNA message is:

```
<STX> "*", "*", "*", "STSET", "*", "*", "*", "yyyy"
<ETX>
```

where:

- “yyyy” is the 4-byte ASCII representation of the checksum.
- “*” indicates an unused bit location.

The **BNA** command is available from Access Level 1 and higher.

Compressed ASCII Commands

The SEL-701 Relay provides compressed ASCII versions of some of the relay ASCII commands. The compressed ASCII commands allow an external device, such as ACSELERATOR QuickSet, to obtain data from the relay in a format that directly imports into spreadsheet or database programs and can be validated with a checksum.

The SEL-701 Relay provides the compressed ASCII commands shown in *Table D.11*.

Table D.11 Compressed ASCII Commands

Command	Description
CAS	Configuration message
CSTATUS	Status message
CHISTORY	History message
CEVENT	Event message
CME E	Energy meter values
CME T	Thermal meter values
CME M	Max/Min meter values

CAS Command General Format

The compressed ASCII configuration message provides data for an external computer to extract data from other compressed ASCII commands. To obtain the configuration message for the compressed ASCII commands available in an SEL relay, type:

CAS <CR>

The SEL-701 Relay sends:

```
<STX>"CAS",n,"yyy"<CR>
"COMMAND 1",L1,"yyy"<CR>
"#H","xxxx","xxxx",.....,"xxxx","yyy"<CR>
"#D","ddd","ddd","ddd","ddd",.....,"ddd","yyy"<CR>
"COMMAND 2",L1,"yyy"<CR>
"#H","ddd","ddd",.....,"ddd","yyy"<CR>
"#D","ddd","ddd","ddd","ddd",.....,"ddd","yyy"<CR>
.
.
.
"COMMAND n",L1,"yyy"<CR>
"#H","xxxx","xxxx",.....,"xxxx","yyy"<CR>
"#D","ddd","ddd","ddd","ddd",.....,"ddd","yyy"<CR>
<ETX>
```

where:

- “n” is the number of compressed ASCII command descriptions to follow.
- “COMMAND” is the ASCII name for the compressed ASCII command as sent by the requesting device. The naming convention for the compressed ASCII commands is a ‘C’ preceding the typical command. For example, **CSTATUS** (abbreviated to **CST**) is the compressed **STATUS** command.
- “L1” is the minimum access level at which the command is available.
- “#H” identifies a header line to precede one or more data lines; “#” is the number of subsequent ASCII names. For example, “21H” identifies a header line with 21 ASCII labels.

- “xxxxx” is an ASCII name for corresponding data on following data lines. Maximum ASCII name width is 10 characters.
- “#D” identifies a data format line; “#” is the maximum number of subsequent data lines.
- “ddd” identifies a format field containing one of the following type designators:
- “I” Integer data
- “F” Floating point data
- “mS” String of maximum m characters (e.g., 10S for a 10 character string)
- “yyyy” is the 4-byte hex ASCII representation of the checksum

A compressed ASCII command may require multiple header and data configuration lines.

If a compressed ASCII request is made for data that are not available (e.g., the history buffer is empty or invalid event request), the relay responds with the following message:

```
<STX>"No Data Available","0668"<CR>
<ETX>
```

SEL-701 Relay Command Response Contents

Display the SEL-701 Relay compressed ASCII configuration message by typing:

CAS <CR>

The relay replaces the items in *italics* with the actual relay data.

The SEL-701 Relay sends:

```
<STX>
"CAS",6,"yyyy"<CR>
"CST",1,"yyyy"<CR>
"1H","FID","yyyy"<CR>
"1D","45S","yyyy"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"<CR>
"1D","I","I","I","I","I","I","I","yyyy"<CR>
"22H","IA","IB","IC","IN","VA","VB","VC","N","+5V_PS","-
5V_PS","+15V_PS","+28V_PS","TEMP","RAM","ROM","CR_RAM","EEPROM","BATTERY","RTC"
,"LC_TIME","TC_START","RELAY"yyyy"<CR>
"1D","12S","12S","12S","12S","12S","12S","12S","12S","12S","12S","12S",
"12S","12S","12S","12S","12S","12S","12S","12S","12S","12S","12S",
"CHI",1,"yyyy"<CR>
"1H","FID","yyyy"<CR>
"1D","45S","yyyy"<CR> where n is defined below
"30H","REC_NUM","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","TYPE","FREQ","THM
CAP(%)" ,"UB_CURR(%)" ,"IA","IB","IC","IN","IG","3I2","WDG(C)" ,"BRG(C)" ,"AMB(C)" ,
"OTH(C)" ,"VAB","VBC","VCA","kW","kVAR","kVA","PF","LD/LG","yyyy"<CR>
"14D","I","I","I","I","I","I","I","I","25S","F","F","F","F","F","F","F","F",
"10S","10S","10S","10S","F","F","F","F","F","F","F","F","5S","yyyy"<CR>
"CEV",1,"yyyy"<CR>
"1H","FID","yyyy"<CR>
"1D","45S","yyyy"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"<CR>
"1D","I","I","I","I","I","I","I","I","yyyy"<CR>
"25H","FREQ","SAM/CYC_A","SAM/
CYC_D","NUM_OF_CYC","TYPE","IA","IB","IC","IN","IG","3I2","UB_CURR(%)" ,
"THM_CAP(%)" ,"VAB","VBC","VCA","kW","kVAR","kVA","PF","LEAD/
LAG","WINDING(C)" ,"BEARING(C)" ,"AMBIENT(C)" ,"OTHER(C)" ,"yyyy"<CR>
"1D","F","I","I","I","I","25S","F","F","F","F","F","F","F","F","F","F",
"F","5S","10S","10S","10S","10S","10S","yyyy"<CR>
"10H","IA","IB","IC","IG","IN","VAB","VBC","VCA","TRIG" ,"Names of elements in the
Relay Word separated by spaces","yyyy"<CR>
"60D","F","F","F","F","F","F","F","F","F","F","F","2S","24S","yyyy"<CR>
```

```
"CME E",1,"yyyy"<CR>
"1H","FID","yyyy"<CR>
"1D","45S","yyyy"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"<CR>
"1D","I","I","I","I","I","I","I","yyyy"<CR>
"4H","MWhr","MVARhr-IN","MVARhr-OUT","MVAhr","yyyy"<CR>
"1D","F","F","F","F","yyyy"<CR>
"1H","LAST RESET","yyyy"<CR>
"1D","23S","yyyy"<CR>
"CME M",1,"yyyy"<CR>
"1H","FID","yyyy"<CR>
"1D","45S","yyyy"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"<CR>
"1D","I","I","I","I","I","I","I","yyyy"<CR>
"7H","CHANNEL","MAX","DATE","TIME","MIN","DATE","TIME","yyyy"<CR>
"24D","12S","10S","10S","12S","10S","10S","12S","yyyy"<CR>
"1H","LAST RESET","yyyy"<CR>
"1D","23S","yyyy"<CR>
"CME T",1,"yyyy"<CR>
"1H","FID","yyyy"<CR>
"1D","45S","yyyy"<CR>
"7H","MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"<CR>
"1D","I","I","I","I","I","I","I","yyyy"<CR>
"18H","1 BRG (C)","2 BRG (C)","3 BRG (C)","4 BRG (C)","5 BRG (C)","6 BRG (C)",
"7 WDG (C)","8 WDG (C)","9 WDG (C)","10 WDG (C)","11 AMB (C)","12 OTH
(C)","FLA(%)" ,"THM CAP(%)" ,"RTD TC(%)" ,"CALC TIME","MINUTES","STARTS","yyyy"<CR>
"1D","10S","10S","10S","10S","10S","10S","10S","10S","10S","10S","10S","10S","F",
"F","F","I","I","I","I","yyyy"<CR>
<ETX>
```

See the *DNA Message on page D.11* for definition of the “**Names of elements in the Relay Word separated by spaces**” field.

In all instances, if the relay does not support voltage measurement, the voltage and power labels are replaced with “*”. The CME E report is not included if voltage inputs are not supported.

If the relay is not equipped with internal or external RTD inputs, the RTD labels are replaced with “*”. If the relay is equipped with RTD inputs, the RTD locations (BRG, WDG, etc.) are setting dependent. If Fahrenheit is the designated temperature scale, the temperature designator (C) is replaced with (F).

where:

- “THM CAP(%)” is the thermal model thermal capacity used in percent.
- “RTD TC(%)” is the RTD estimated thermal capacity used in percent.
- “CALC TIME” is the calculated time to thermal trip in seconds.
- “MINUTES” is the number of minutes since the last motor start.
- “STARTS” is the number of motor starts in the past hour.

CSTATUS Command

Display status data in compressed ASCII format by typing:

CST <CR>

The relay replaces the items in *italics* with the actual relay data.

The SEL-701 Relay sends:

```

<STX>"FID", "yyyy"<CR>
"Relay FID string", "yyyy"<CR>
"MONTH", "DAY", "YEAR", "HOUR", "MIN", "SEC", "MSEC", "yyyy"<CR>
xxxx, xxxx, xxxx, xxxx, xxxx, xxxx, xxxx, "yyyy"<CR>
"IA", "IB", "IC", "IN", "VA", "VB", "VC", "N", "+5V_PS", "-
5V_PS", "+15V_PS", "+28V_PS", "TEMP", "RAM", "ROM", "CR_RAM", "EEPROM", "BATTERY", "RTC"
, "LC_TIME", "TC_START", "RELAY", "yyyy"<CR>
"xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx",
"xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx",
"xxxx", "xxxx", "xxxx", "xxxx", "zzzz", "yyyy"<CR>
<ETX>

```

where:

- “xxxx” are the data values corresponding to the first line labels.
- “zzzz” is a message saying whether the relay is “ENABLED” or “DISABLED.”
- “yyyy” is the 4-byte hex ASCII representation of the checksum.

In relays where voltages are not supported, “VA”, “VB”, “VC”, and “N” are reported as “*”.

CHISTORY Command

Display history data in compressed ASCII format by typing:

CHI <CR>

The relay replaces the items in *italics* with the actual relay data.

The SEL-701 Relay sends:

```

<STX>"FID", "yyyy"<CR>
"Relay FID string", "yyyy"<CR>
"REC_NUM", "MONTH", "DAY", "YEAR", "HOUR", "MIN", "SEC", "MSEC", "TYPE", "FREQ", "THM
CAP(%)", "UB_CURR(%)", "IA", "IB", "IC", "IN", "IG", "3I2", "WDG (C)", "BRG (C)", "AMB
(C)", "OTH (C)", "VAB", "VBC", "VCA", "kW", "kVAR", "kVA", "PF", "LD/LG", "yyyy"<CR>
xxxx, xxxx, xxxx, xxxx, xxxx, xxxx, xxxx, "xxxx", "xxxx", "xxxx, xxxx, xxxx, xxxx,
xxxx,
xxxx, xxxx, "xxxx", "xxxx", "xxxx", "xxxx", "xxxx, xxxx, xxxx, xxxx, xxxx, xxxx, "xxxx"
,
"yyyy"<CR>
<ETX>

```

(the second line is then repeated for each record)

where:

- “xxxx” are the data values corresponding to the first line labels.
- “yyyy” is the 4-byte hex ASCII representation of the checksum.
- “THM CAP(%)” is the thermal model thermal capacity used in percent.

If the history buffer is empty, the relay responds:

```
<STX>"No Data Available","0668"<CR>
<ETX>
```

If the relay does not support voltage measurement, the voltage and power labels are replaced with “*”.

If the relay is not equipped with internal or external RTD inputs, the RTD labels are replaced with: “*”. If Fahrenheit is the designated temperature scale, the temperature designator (C) is replaced with (F).

CEVENT Command

Display event report in compressed ASCII format by sending:

CEV n r

where:

- n event number (1–n), defaults to 1.
- optional, when r is selected, analog data will not be digitally filtered (raw).

The relay responds to the **CEV** command with the **nth** event report as shown below. The relay replaces the items in *italics* with the actual relay data.

“The SEL-701 Relay sends:

```
<STX>"FID","yyyy"<CR>
"Relay FID string","yyyy"<CR>
"MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"<CR>
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,"yyyy"<CR>
"FREQ","SAM/CYC_A","SAM/
CYC_D","NUM_OF_CYC","TYPE","IA","IB","IC","IN","IG","3I2","UB_CURR(%)",
"THM_CAP(%)","VAB","VBC","VCA","KW","KVAR","KVA","PF","LEAD/LAG","WINDING
(C)","BEARING (C)","AMBIENT (C)","OTHER (C)","yyyy"<CR>
xxxx,xxxx,xxxx,xxxx,"xxxx",xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,
xxxx,xxxx,xxxx,xxxx,"xxxx","xxxx","xxxx","xxxx","yyyy"<CR>
"IA","IB","IC","IG","IN","VAB","VBC","VCA","TRIG","Names of elements in the Relay
Word separated by spaces","yyyy"<CR>
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,z,"HEX-ASCII Relay Word","yyyy"<CR>
"SETTINGS","yyyy"<CR>
"Relay settings as displayed with the showset command (surrounded by
quotes)","yyyy"<CR>
<ETX>
```

where:

- “xxxx” are the data values corresponding to the line labels.
- “yyyy” is the 4-byte hex ASCII representation of the checksum.
- “FREQ” is the power system frequency at the trigger instant.
- “SAM/CYC_A” is the number of analog data samples per cycle (4 or 16).
- “SAM/CYC_D” is the number of digital data samples per cycle (4 or 16).
- “NUM_OF_CYC” is the number of cycles of data in the event report.
- “TYPE” is the event type.
- “TRIG” refers to the trigger record.
- “IA”, “IB”, “IC”, “IN”, “IG”, “3I2” are the summary currents.

- “VAB”, “VBC”, and “VCA” are replaced by “VA”, “VB”, and “VC” in the event body when phase-neutral potentials are applied. They are replaced by “*” when voltages are not included.
- “TRIG” refers to the trigger record.
- “z” is “>” for the trigger row, “*” for the fault current row and empty for all others. If the trigger row and fault current row are the same, both characters are included (e.g., “>”).
- **“HEX-ASCII Relay Word”** is the hex ASCII format of the Relay Word. The first element in the Relay Word is the most significant bit in the first character.

If the specified event does not exist, the relay responds:

```
<STX>"No Data Available","0668"<CR>
<ETX>
```

See the *DNA Message on page D.11* for definition of the **“Names of elements in the Relay Word separated by spaces”** field.

A typical *HEX-ASCII Relay Word* is shown below:

```
"2000001000000000000080","0CA0"
```

Each byte in the *HEX-ASCII Relay Word* reflects the status of 8 Relay Word bits. The order of the labels in the *“Names of elements in the relay word separated by spaces”* field matches the order of the *HEX-ASCII Relay Word*. In the example above, the first two bytes in the *HEX-ASCII Relay Word* are “20”. In binary, this evaluates to 00100000. Mapping the labels to the bits yields:

Labels	STARTING	RUNNING	STOPPED	JAMTRIP	LOSSALRM	LOSSTRIP	46VBA	46BVT
Bits	0	0	1	0	0	0	0	0

In this example, the STOPPED Relay Word bit is asserted (logical 1); all others are deasserted (logical 0).

CME E Command

Display energy meter data in compressed ASCII format by typing:

CME E <CR>

The relay replaces items in *italics* with the actual relay data.

The SEL-701 Relay sends:

```
<STX>"FID","yyyy"<CR>
"Relay FID string","yyyy"<CR>
"MONTH","DAY","YEAR","HOUR","MIN","SEC","MSEC","yyyy"<CR>
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,"yyyy"<CR>
"MWhr","MVARhr-IN","MVARhr-OUT","MVAhr","yyyy"<CR>
xxxx,xxxx,xxxx,xxxx,"yyyy"<CR>
"LAST RESET","yyyy"<CR>
"xxxx","yyyy"<CR>
<ETX>
```

If the voltage option is not supported, the relay responds:

```
<STX>"No Data Available","0668"<CR>
<ETX>
```

CME M Command

Display Max/Min meter data in compressed ASCII format by typing:

CME M <CR>

The relay replaces the items in *italics* with the actual relay data.

The SEL-701 Relay sends:

```
<STX>"FID", "yyyy"<CR>
"Relay FID string", "yyyy"<CR>
"MONTH", "DAY", "YEAR", "HOUR", "MIN", "SEC", "MSEC", "yyyy"<CR>
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx, "yyyy"<CR>
"CHANNEL", "MAX", "DATE", "TIME", "MIN", "DATE", "TIME", "yyyy"<CR>
"IA(A)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"IB(A)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"IC(A)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"IN(A)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"IG(A)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"VAB(V)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"VBC(V)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"VCA(V)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"VG(V)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"kW3P", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"kVAR3P", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"kVA3P", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 1 BRG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 2 BRG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 3 BRG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 4 BRG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 5 BRG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 6 BRG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 7 WDG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 8 WDG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
" 9 WDG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"10 WDG (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"11 AMB (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"12 OTH (C)", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "yyyy"<CR>
"LAST RESET", "yyyy"<CR>
"xxxx", "yyyy"<CR>
<ETX>
```

Voltage and power labels are replaced with “*” if the optional voltage inputs are not included. RTD labels are replaced with “*” if RTDs are not supported or enabled. RTD locations and temperature designators are setting dependent.

CME T Command

Display thermal meter data in compressed ASCII format by typing:

CME T <CR>

The relay replaces the items in *italics* with the actual relay data.

The SEL-701 Relay sends:

```
<STX>"FID", "yyyy"<CR>
"Relay FID string", "yyyy"<CR>
"MONTH", "DAY", "YEAR", "HOUR", "MIN", "SEC", "MSEC", "yyyy"<CR>
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx,xxxx, "yyyy"<CR>
"1 BRG (C)", "2 BRG (C)", "3 BRG (C)", "4 BRG (C)", "5 BRG (C)", "6 BRG (C)",
"7 WDG (C)", "8 WDG (C)", "9 WDG (C)", "10 WDG (C)", "11 AMB (C)",
"12 OTH (C)", "FLA(%)", "THM CAP(%)", "RTD TC(%)",
"CALC TIME", "MINUTES", "STARTS", "yyyy"<CR>
"xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx", "xxxx",
xxxx,xxxx,xxxx,xxxx,xxxx,xxxx, "yyyy"<CR>
<ETX>
```

where:

- “THM CAP(%)” is the thermal model thermal capacity used in percent.
- “RTD TC(%)” is the RTD estimated thermal capacity used in percent.
- “CALC TIME” is the calculated time to thermal trip in seconds.
- “MINUTES” is the number of minutes since the last motor start.
- “STARTS” is the number of motor starts in the past hour.

RTD labels are replaced with “*” if RTDs are not supported or enabled. RTD locations and temperature designators are setting dependent. RTD thermal capacity is reported as 0 if RTDs are not supported or enabled.

This page intentionally left blank

Appendix E

Motor Thermal Element

Introduction

The SEL-701 Relay provides effective motor thermal protection using a patented protection algorithm. The relay offers three convenient methods to set the thermal element. They are:

- Motor ratings method
- Generic thermal limit curve method
- User thermal limit curve method

These setting methods are described in detail in *Section 4: Settings Calculations*. The three methods accommodate differences in protected motors and in the amount and type of motor information available. They also offer the majority of relay users at least one familiar setting method.

While the implementation details of each setting method vary, the fundamental thermal element is the same for all three, so this generalized discussion applies to all three methods equally. Regardless of the setting method used, the thermal element provides motor protection for the following potentially damaging conditions:

- Locked Rotor Starts
- Running Overload
- Operation Under Unbalanced Currents
- Too Frequent or Prolonged Starting

In order to provide integrated protection for all these conditions, the thermal element:

- Continuously maintains a numeric estimate analogous to the heat energy in the motor
- Adjusts the heat estimate based on the measured positive-sequence and negative-sequence current flowing in the motor
- Weights the heating effect of negative-sequence current as five times the heating effect of positive-sequence current when the motor is running
- Weights the heating effects of positive- and negative-sequence current equally when the motor is starting
- Models the heat lost to the surroundings when the motor is running
- Compares the present heat estimate to an adaptive starting trip threshold or a running trip threshold, depending on the state of the motor

- Provides a trip output if the present heat estimate exceeds the present trip threshold
- Provides an alarm output if the present heat estimate exceeds the present alarm threshold (user settable as a percentage of the trip threshold)
- Adjusts the present trip threshold based on RTD ambient temperature measurement when enabled

Purpose of Motor Thermal Protection

A typical induction motor draws six times its rated full load current when starting. This high stator current induces a comparably high current in the rotor. The rotor resistance at zero speed typically is three times the rotor resistance when the motor is at rated speed. Thus, the I^2R heating in the rotor is approximately $6^2 \cdot 3$ or 108 times the I^2R heating when the motor is running normally. Consequently, the motor must tolerate an extreme temperature for a limited time in order to start. Manufacturers communicate the motor tolerance through the maximum locked rotor time and locked rotor amps specifications for each motor. In a similar manner, the motor manufacturer communicates the motor's ability to operate under continuous heavy load through the service factor specification.

The purpose of motor thermal protection is to allow the motor to start and run within the manufacturer's published guidelines, but trip if the motor heat energy exceeds those ratings due to overloads, negative-sequence current, or locked rotor starting.

Figure E.1 shows a typical motor thermal limit characteristic plotted with the motor starting current. Some motor protection applications use an inverse-time phase overcurrent element to provide locked rotor and overload protection along with a separate negative-sequence overcurrent relay to prevent overheating due to current unbalance. Unfortunately, neither of these elements accounts for the motor thermal history or track temperature excursions. The SEL-701 Relay thermal element, with its integrated design, offers distinct advantages over the use of discrete elements.

The SEL-701 Relay thermal element always operates in one of two modes: starting or running. In starting mode, the thermal element provides locked rotor protection, allowing the motor to absorb the high energy of the I^2t threshold represented by the rated locked rotor current and time. In running mode, the thermal element provides overload and unbalance protection by limiting the motor heat energy estimate to a value represented by the service factor and two other motor parameters.




Figure E.1 Motor Thermal Limit Characteristic Plotted With Motor Starting Current

The Basic Thermal Element

NOTE: The Thermal Element description in this appendix is intended to give a simplified overview to the reader.

Figure E.2 shows a simple electrical analog for a thermal system. The thermal element includes:

- A heat source, modeled as a current source
- A thermal capacitance, modeled as a capacitor
- A thermal impedance to ambient, modeled as a resistor
- A comparator, to compare the present heat estimate, U , to the Thermal Trip Value




Figure E.2 Electrical Analog of a Thermal System

In order to define a thermal element for an induction motor, the characteristics of each component in *Figure E.2* must be defined, starting with the heat source. In an induction motor, heat principally is caused by I^2r losses. To consider the effects of negative-sequence current on the motor, it is called out separately in *Equation E.1*.

$$\text{Heat Source} = I_1^2 \cdot K_1 + I_2^2 \cdot K_2 \quad \text{Equation E.1}$$

Heating factors K_1 and K_2 are defined by the positive-sequence rotor resistance and negative-sequence rotor resistance, respectively.

Figure E.3 shows a plot of a typical induction motor current, torque, and rotor resistance versus slip. When motor slip is 1 per unit, rotor speed is zero. As the motor approaches rated speed, slip decreases to near zero.




Figure E.3 Typical Induction Motor Current, Torque, and Rotor Resistance versus Slip

Calculate the positive-sequence rotor resistance plotted in *Figure E.3* using *Equation E.2*.

$$R_r = \left(\frac{Q_M}{I^2} \right) \cdot S \quad \text{Equation E.2}$$

where:

- S = Motor slip
- Q_m = Motor torque at slip S
- I = Motor positive-sequence current at slip S

The positive-sequence rotor resistance is represented as a linear function of slip S by *Equation E.3*.

$$R_{r+} = (R_1 - R_0) \cdot S + R_0 \quad \text{Equation E.3}$$

where:

- R_1 = Positive-sequence rotor resistance at slip (S = 1)
- R_0 = Positive-sequence rotor resistance at full load slip (S ≈ 0)

To properly account for the heating effects of the negative-sequence current, calculate the negative-sequence rotor resistance. The rotor has slip with respect to the stator negative-sequence current. To determine the value of the negative-sequence slip as a function of positive-sequence slip, S, observe that negative-sequence stator currents cause counter-rotating magnetic poles on the

inside face of the stator. When rotor speed is zero, the counter-rotating poles induce fundamental frequency currents in the rotor: negative-sequence slip equals positive-sequence slip, S . When the rotor is spinning at near synchronous speed, the counter-rotating magnetic poles induce approximately double-frequency currents in the rotor: negative-sequence slip equals twice the fundamental frequency.

Based on these observations, negative-sequence slip equals $(2-S)$. Substituting this value for S in *Equation E.3*, calculate negative-sequence rotor resistance, R_{r-} .

$$R_{r-} = (R_1 - R_0) \bullet (2 - S) + R_0 \quad \text{Equation E.4}$$

To obtain factors expressing the relative heating effect of positive- and negative-sequence current, divide *Equation E.3* and *Equation E.4* by R_0 . For the locked rotor case (slip, $S = 1$).

$$\left. \frac{R_{r+}}{R_0} \right|_{S=1} = \left. \frac{R_{r-}}{R_0} \right|_{S=1} = \frac{R_1}{R_0} = 3 \quad \text{Equation E.5}$$

When the motor is running ($S \approx 0$), the positive-sequence heating factor, K_1 , is found.

$$\left. \frac{R_{r+}}{R_0} \right|_{S \approx 0} = \frac{R_0}{R_0} = 1 \quad \text{Equation E.6}$$

The negative-sequence heating factor, K_2 , at $S \approx 0$ is found.

$$\left. \frac{R_{r-}}{R_0} \right|_{S \approx 0} = 2 \bullet \left(\frac{R_1}{R_0} \right) - 1 = 5 \quad \text{Equation E.7}$$

To summarize, based on the assumption that the locked-rotor rotor resistance is three times the running rotor resistance:

- The heating factor of positive-sequence current, K_1 , when the motor is running is 1 per unit
- The heating factor of negative-sequence current, K_2 , when the motor is running is 5 per unit
- Both K_1 and K_2 are 3 per unit when the rotor is locked

The differences in the positive- and negative-sequence heating factors immediately suggest that the thermal element should have two models representing motor starting and running. The SEL-701 Relay thermal element automatically selects the appropriate model based on the measured sum of the positive-sequence current and the negative-sequence current. When the current is greater than 2.5 times the motor rated full load current setting, the relay uses the starting model. When the current drops below 2.4 times the rated full load current, the relay uses the running model.

Motor Starting Protection

Figure E.4 shows the thermal element used when the motor is starting. Locked rotor heating occurs over just a few seconds, so the model assumes that no heat is lost to the surroundings and the resistor is removed from the thermal circuit. The thermal trip value is defined by the motor rated locked rotor current, I_L , squared, times the rated hot motor locked rotor time, T_o . The thermal capacitance is selected to match the heat source heating factor, 3. By setting the capacitance equal to 3, when the motor positive-sequence current, I_1 , equals locked rotor current, I_L , the heat estimate, U , reaches the trip value in exactly locked rotor time, T_o .

This is true for the motor initially at or below the normal operating temperature and the rating method is used. If a less conservative curve method is used, the locked rotor trip time will adapt to the actual initial temperature (heat estimate at the beginning of the motor start). For example, the locked rotor trip time will be 120 percent or T_o for the motor at an ambient temperature.

NOTE: The trip value shown in Figure E.4 is the limiting value. Actually, the trip value ramps up during the starting mode and will not reach the limit for a successful motor start.




Figure E.4 Motor Starting Thermal Element

When a successful motor start occurs and positive-sequence current drops below 2.4 times full load current, the relay switches from the starting thermal element to the running thermal element. The present heat estimate, U , is transferred directly to the running element, representing the heat build-up that occurred during motor starting.

Motor Running Protection

When the motor is running, it returns heat energy to its surroundings through radiation, conduction, convection, and, in some cases, using forced cooling. The motor running thermal element provides a path for that energy return through the resistor, R, in *Figure E.5*.




Figure E.5 Motor Running Thermal Element With Resistance and Trip Level Undefined

To determine the value of that resistor, recall that the motor will reach an energy level representing its rated operating temperature when 1 per unit of positive sequence current flows in the motor for a long time. Since the positive-sequence heat factor, K_1 , is 1 in the running model, and 1 per unit of I_1 squared equals 1, the value of resistor R equals the energy level representing the motor rated operating temperature.

To determine the normal operating energy, recall that many motor datasheets publish two locked rotor trip times: one longer time when the motor is started from ambient temperature (referred to as T_a) and one shorter time when the motor is started from operating temperature (T_o).

Figure E.6 shows a graphical representation of the problem and its solution.




Figure E.6 Calculating the Normal Operating Energy Using Locked Rotor Trip Times

The motor normal operating energy is the difference between the ambient and operating temperature locked rotor times, multiplied by locked rotor current squared. For those motors that do not publish separate locked rotor times, assume that the locked rotor trip energy is approximately six times the operating energy in the relation.

$$\frac{I_L^2 \cdot T_a}{I_L^2 \cdot (T_a - T_o)} = 6 \text{ which reduces to}$$

$$T_a = 1.2 \cdot T_o$$

Equation E.8

The motor ratings allow the motor to be run continuously at the motor service factor, thus the service factor, SF, is accounted for in the running thermal element trip threshold. *Figure E.7* shows the final running thermal element.




Figure E.7 Motor Running Thermal Element

Example E.1 illustrates the difference between the trip thresholds of the starting and running thermal elements. When the relay switches from the starting to the running thermal element, it maintains the present heat estimate, U, which begins to decrease due to the drop in current-squared and due to the insertion of the resistor into the model. The decay of U is exponential due to the interaction between the model thermal capacitance and resistance. Rather than instantly switch from the high starting trip threshold to the low running trip threshold, the relay allows the trip threshold to decay exponentially using the same time-constant as the thermal element RC circuit from the initial starting value to the final running value.

NOTE: The Motor Starting Trip Threshold calculated in Example E.1 is the limiting value. The actual threshold ramps up during the starting mode and will not reach the limit for a successful motor start.

EXAMPLE E.1 Starting and Running Trip Level Calculations

Given a motor with the following characteristics, calculate the starting and running thermal model trip thresholds.

Service Factor, SF	= 1.15
Locked Rotor Current, I_L	= 6 per unit of full load amps
Locked Rotor Time From Operating Temperature, T_o	= 12 seconds
Locked Rotor Time From Ambient Temperature, T_a	= 14.4 seconds
Motor Starting Trip Threshold	$= I_L^2 \cdot T_o$
	$= 36 \cdot 12$
	$= 432$
Motor Running Trip Threshold	$= I_L^2 \cdot (T_a - T_o) \cdot SF^2$
	$= 36 \cdot 2.4 \cdot 1.323$
	$= 114.3$

Percent Thermal Element Capacity Values

Several of the SEL-701 Relay reporting functions include a % Thermal Capacity value. At all times, the relay calculates the percent thermal capacity using *Equation E.9*.

$$\% \text{ Thermal Capacity} = \frac{\left(\begin{array}{c} \text{Present Heat} \\ \text{Estimate, U} \end{array} \right)}{\left(\begin{array}{c} \text{Present Thermal} \\ \text{Trip Value} \end{array} \right)} \bullet 100\% \quad \text{Equation E.9}$$

By this definition, when the % Thermal Capacity reaches 100%, the heat estimate equals the trip value and the thermal element trips.

As *Example E.1* shows, the thermal trip values for the running and starting elements are very different. For this reason, it is not generally meaningful to compare the % Thermal Capacity during a start to the % Thermal Capacity during running conditions. However, it is quite useful to compare the % Thermal Capacities of several starts using the relay Motor Start Reports and Motor Start Trend data. Using this data, you may notice an increasing trend in the Starting % Thermal Capacity, the final % Thermal Capacity value when the thermal model switches from starting to running. This could indicate gradually increasing load torque which could eventually result in an unwanted locked rotor trip and subsequent down-time.

The average and peak running % Thermal Capacity values reported in the motor operating statistics report also offer a useful basis of comparison, allowing you to compare the present % Thermal Capacity to normal values.

Motor Starting Thermal Capacity

NOTE: For the EMRSTR SELOGIC control equation performance to match the performance of the front-panel and Modbus Emergency Restart functions, you should include * STOPPED in the SELOGIC control equation, as shown in Factory Default Logic Settings on page B.8. Do not set EMRSTR =1.

NOTE: Since the Thermal Capacity Used to Start percentage is based on the starting thermal element trip threshold, the relay automatically switches to that threshold for % Thermal Capacity calculation as soon as the motor stops. You may observe this as a large drop in the % Thermal Capacity value when you stop the motor. This is normal operation for the SEL-701 Relay.

A normal motor start is expected to use a significant percentage of the available starting thermal capacity. After a motor start, it is generally necessary for the motor to cool for a time before another start is permitted. The cooling can usually take place while the motor is stopped or running.

If a motor usually requires 70% of the available thermal capacity to start and if a start is attempted while the present % Thermal Capacity exceeds 30%, a locked rotor trip is likely because the motor is still too hot.

The SEL-701 Relay provides two facilities to help ensure that a motor start is not attempted while the motor is still too hot to be started safely. The Thermal Capacity Used to Start (TCSTART) setting allows you to define a fixed value of thermal capacity that you expect the motor to use on a start. The relay adds a 10% safety margin to this setting, thus if you set Thermal Capacity Used to Start equal to 65%, the relay requires the % Thermal Capacity to fall below 25% ($100\% - 65\% - 10\% = 25\%$) when the motor is stopped before another start is permitted. The relay asserts the Thermal Lockout until the motor is cool.

In addition, the relay learns a thermal capacity used to start by recording the thermal capacity used during each of the past five successful motor starts. This learned parameter is reported in the motor operating statistics report. When

you set Use Learned Starting Thermal Capacity (TCLRNEN) equal to Y, the relay uses the largest of the last five starting percentages in place of the TCSTART value to determine when to release the thermal lockout.

Thermal Element Trip-Time Equations

Figure 4.2 in Section 4: Settings Calculations shows trip time curves for selected settings of the thermal element. Following are equations for calculating the trip times or curves for any settings.

As stated earlier, the motor model consists of distinct starting and running thermal elements (see Figure E.4 and Figure E.7). Equations for each element appear in the following text. For simplicity, all motor currents are assumed to be balanced three phase and in per unit of full load current (e.g., motor current I = motor current/full load current).

Definitions

- I = Motor current in per unit of full load current
- I_0 = Preload motor current in per unit of full load current
= $0.9 \bullet SF$ for stator initially at normal operating temperature (hot stator)
- T_p = Thermal element trip time in seconds
- SETMETH = Thermal element method setting
- SF = Service factor setting
- RTC = Run state time constant (in seconds)
- T_o = Locked rotor time hot (setting LRTHOT in seconds)
- T_a = Locked rotor time cold (setting LRTCOLD in seconds)
- I_L = Locked rotor current in per unit of full load current (setting LRA/setting FLA)
- R = Thermal resistance = $I_L^2 \bullet (T_a - T_o)$
- U_0 = Initial energy in per unit of R
- TD = Acceleration factor setting
- CURVE = Curve number setting (when SETMETH = Generic)

General Equations

Equation E.10 applies to the starting element when $10 \geq I \geq 2.5$.

$$T_p = \frac{[(TD + (T_a/T_o) - 1) \bullet T_o \bullet I_L^2] - U_0}{I^2} \quad \text{Equation E.10}$$

Equation E.11 applies to the running element when $2.5 > I > SF$.

$$T_p = RTC \bullet \ln \left[\frac{I^2 - I_0^2}{I^2 - SF^2} \right] \quad \text{Equation E.11}$$

Rating Method Equations

Equation E.12 applies to the starting element when $10 \geq I \geq 2.5$ and SETMETH = Rating. To obtain the trip time (hot or cold rotor), substitute $U_0 = R$ in *Equation E.10*.

$$T_p = \frac{TD \cdot T_o \cdot I_L^2}{I^2} \quad \text{Equation E.12}$$

Equation E.13 and *Equation E.14* apply to the running element when $2.5 > I > SF$ and SETMETH = Rating. To obtain the trip time (cold stator), substitute $I_0 = 0$ and RTC in *Equation E.11*.

$$RTC = 3 \cdot I_L^2 \cdot (T_a - T_o) \text{ seconds}$$

$$T_p = 3 \cdot I_L^2 \cdot (T_a - T_o) \cdot \ln \left[\frac{I^2}{I^2 - SF^2} \right] \quad \text{Equation E.13}$$

Generic Method Equations

Equation E.14 and *Equation E.15* apply to the starting element when $10 \geq I \geq 2.5$ and SETMETH = Generic. To obtain the trip time (cold rotor), substitute $U_0 = 0$, $TD = 1.0$, $T_o = (2.1 \cdot \text{CURVE})$, $T_a = (2.5 \cdot \text{CURVE})$, and $I_L = 6.0$ in *Equation E.10*.

$$T_p = \frac{90 \cdot \text{CURVE}}{I^2} \quad \text{Equation E.14}$$

To obtain the trip time (hot rotor), substitute $U_0 = R$, $TD = 1.0$, $T_o = (2.1 \cdot \text{CURVE})$, $T_a = (2.5 \cdot \text{CURVE})$, and $I_L = 6.0$ in *Equation E.10*.

$$T_p = \frac{75.6 \cdot \text{CURVE}}{I^2} \quad \text{Equation E.15}$$

Equation E.16 applies to the running element when $2.5 > I > SF$ and SETMETH = Curve. To obtain the trip time (cold stator), substitute $I_0 = 0$ and RTC in *Equation E.11*.

$$T_p = \frac{13.824 \cdot \text{CURVE}}{\ln \left[\frac{6.25}{6.25 - SF^2} \right]} \cdot \ln \left[\frac{I^2}{(I^2 - SF^2)} \right] \quad \text{Equation E.16}$$

This page intentionally left blank

Appendix F

SEL-701 Relay Settings Sheets Example

Relay Settings

(Factory Defaults, Model **0701011X2X**)

General Data

Relay Identifier

Range: 20 Characters

RID = SEL-701 _____

Terminal Identifier

Range: 20 Characters

TID = MOTOR RELAY _____

Phase (IA, IB, IC) CT Ratio

Range: 1–6000 to 1

CTR = 100 _____

Phase CT Secondary Rating

Range: 1 A, 5 A

ITAP = 5 _____

Neutral (IN) CT Ratio

Range: 1–6000 to 1

CTRN = 100 _____

Neutral CT Secondary Rating

Range: 1 A, 5 A

INTAP = 5 _____

Phase Rotation

Range: ABC, ACB

PHROT = ABC _____

Nominal Frequency

Range: 50, 60 Hz

FNOM = 60 _____

Date Format

Range: MDY, YMD

DATE_F = MDY _____

Demand Meter Time Constant

Range: 5, 10, 15, 30, 60 min

DMTC = 15 _____

Phase (VA, VB, VC) VT Ratio (Hidden if
voltages not included)

Range: 1–6000 to 1

PTR = 100 _____

Phase VT Connection (Hidden if voltages not
included)

Range: D, Y

DELTA_Y = Y _____

Single Voltage Input (Hidden if voltages not
included)

Range: Y, N

SINGLELEV = N _____

Standard Alarm Contact Operation

Range: Y, N

STDALARM = Y _____

Thermal Model Elements

Setting Method

Range: OFF, Rating, Generic, User

SETMETH = RATING _____

Full Load Amps

Range: 1.00–8.00 A; ITAP = 5 A

0.20–1.60 A; ITAP = 1 A

FLA = 5.00 _____

Thermal Element Settings When Setting Method = RATING

(Hidden When SETMETH = GENERIC, USER, or OFF)

Service Factor

Range: 1.01–1.50

SF = 1.15 _____

Locked Rotor Amps

Range: 2.50–80.00 A; ITAP = 5 A

0.50–16.00 A; ITAP = 1 A

LRA = 30.00 _____

Hot Locked Rotor Time

Range: 1.0–200.0 s

LRTHOT = 2.1 _____

Cold Locked Rotor Time

Range: 1.0–240.0 s

LRTCOLD = 2.5 _____

Locked Rotor Trip Time Dial

Range: 0.10–1.50

TD = 1.00 _____

Thermal Element Settings When Setting Method = GENERIC

(Hidden When SETMETH = RATING, USER, or OFF)

Service Factor

Range: 1.01–1.50

SF = 1.15 _____

Curve Number

Range: 1–45

CURVE = _____

Thermal Element Settings When Setting Method = USER

(Hidden When SETMETH = RATING, GENERIC, or OFF)

Service Factor

Range: 1.01–1.50

SF = 1.15 _____

Time to Trip at 1.05 x FLA

Range: 1.0–6000.0 s, NP

TTT105 = _____

Time to Trip at 1.10 x FLA

Range: 1.0–6000.0 s, NP

TTT110 = _____

Time to Trip at 1.20 x FLA

Range: 1.0–6000.0 s, NP

TTT120 = _____

Time to Trip at 1.30 x FLA

Range: 1.0–6000.0 s, NP

TTT130 = _____

Time to Trip at 1.40 x FLA

Range: 1.0–6000.0 s, NP

TTT140 = _____

Time to Trip at 1.50 x FLA

Range: 1.0–6000.0 s, NP

TTT150 = _____

Time to Trip at 1.75 x FLA

Range: 1.0–6000.0 s, NP

TTT175 = _____

Time to Trip at 2.00 x FLA

Range: 1.0–6000.0 s

TTT200 = _____

Time to Trip at 2.25 x FLA

Range: 1.0–6000.0 s, NP

TTT225 = _____

Time to Trip at 2.50 x FLA

Range: 1.0–6000.0 s

TTT250 = _____

Time to Trip at 2.75 x FLA

Range: 1.0–6000.0 s, NP

TTT275 = _____

Time to Trip at 3.00 x FLA

Range: 1.0–6000.0 s, NP

TTT300 = _____

Time to Trip at 3.50 x FLA

Range: 1.0–6000.0 s, NP

TTT350 = _____

Time to Trip at 4.00 x FLA

Range: 1.0–6000.0 s, NP

TTT400 = _____

Time to Trip at 4.50 x FLA

Range: 1.0–6000.0 s, NP

TTT450 = _____

Time to Trip at 5.00 x FLA

Range: 1.0–600.0 s, NP

TTT500 = _____

Time to Trip at 5.50 x FLA

Range: 1.0–600.0 s

TTT550 = _____

Time to Trip at 6.00 x FLA

Range: 1.0–600.0 s

TTT600 = _____

Time to Trip at 6.50 x FLA

Range: 1.0–600.0 s

TTT650 = _____

Time to Trip at 7.00 x FLA

Range: 1.0–400.0 s

TTT700 = _____

Time to Trip at 7.50 x FLA

Range: 1.0–450.0 s, NP

TTT750 = _____

Time to Trip at 8.00 x FLA

Range: 1.0–400.0 s, NP

TTT800 = _____

Time to Trip at 8.50 x FLA

Range: 1.0–350.0 s, NP

TTT850 = _____

Time to Trip at 9.00 x FLA

Range: 1.0–300.0 s, NP

TTT900 = _____

Time to Trip at 10.00 x FLA

Range: 1.0–225.0 s, NP

TTT1000 = _____

(The balance of Thermal Element Settings are hidden when SETMETH=OFF.)

Thermal Capacity Alarm Pickup

Range: 50%–100%

TCAPU = 90 _____

Thermal Capacity Used to Start

Range: 20%–100%

TCSTART = 85 _____

Use Learned Starting Thermal Capacity

Range: Y, N

TCLRNE = Y _____

Motor Stopped Cooling Time

Range: 180–72000 s

COOLTIME = 259 _____

Use Learned Cooling Time (*Hidden when
RTDOPT = NONE*)
Range: Y, N

COOLEN = Y _____

Overcurrent (O/C) Elements

(Time-delay settings are hidden when their associated pickup settings = OFF)

Level 1 Phase O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50P1P = OFF _____

Level 1 Phase O/C Time Delay

Range: 0.00–400.00 s

50P1D = _____

Level 2 Phase O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50P2P = OFF _____

Level 2 Phase O/C Time Delay

Range: 0.00–400.00 s

50P2D = _____

Level 1 Residual O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50G1P = 2.50 _____

Level 1 Residual O/C Time Delay

Range: 0.00–400.00 s

50G1D = 0.10 _____

Level 2 Residual O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50G2P = OFF _____

Level 2 Residual O/C Time Delay

Range: 0.00–400.00 s

50G2D = _____

Level 1 Neutral O/C Pickup

Range: OFF, 0.025–10.000 A; INTAP = 5 A
OFF, 0.005–2.000 A; INTAP = 1 A

50N1P = 2.500 _____

Level 1 Neutral O/C Time Delay

Range: 0.00–400.00 s

50N1D = 0.10 _____

Level 2 Neutral O/C Pickup

Range: OFF, 0.025–10.000 A; INTAP = 5 A
OFF, 0.005–2.000 A; INTAP = 1 A

50N2P = OFF _____

Level 2 Neutral O/C Time Delay

Range: 0.00–400.00 s

50N2D = _____

Negative-Sequence O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50QP = OFF _____

Negative-Sequence O/C Time Delay

Range: 0.10–400.00 s

50QD = _____

Jogging Block Element Settings

Maximum Number of Starts per Hour

Range: OFF, 1–15

MAXSTART = 3 _____

Minimum Time Between Starts

Range: OFF, 1–150 min

TBSDLY = 20 _____

Load-Jam Function Settings

Load-Jam Trip Pickup

Range: OFF, 0.5–6.0 pu FLA

LJTPU = 2.0

Load-Jam Trip Delay

Range: 0.00–400.00 s

LJTDLY = 1.00

Load-Loss Element Settings

(Hidden when voltage option unavailable)

Load-Loss Alarm Threshold

Range: OFF, 30–2000 W; ITAP = 5 A

OFF, 6–400 W; ITAP = 1 A

LLAPU = OFF

(Hidden when LLAPU = OFF)

Load-Loss Trip Threshold

Range: 30–2000 W; ITAP = 5 A

6–400 W; ITAP = 1 A

LLTPU = 100

Load-Loss Starting Time Delay

Range: 0–15000 s

LLSDLY = 0

Load-Loss Alarm Time Delay

Range: 0.40–400.00 s

LLADLY = 5.00

Load-Loss Trip Time Delay

Range: 0.40–400.00 s

LLTDLY = 10.00

(Hidden when voltage option available)

Load-Loss Alarm Threshold

Range: OFF, 0.10–1.00 pu FLA

LLAPU = OFF

Load-Loss Trip Threshold

Range: 0.10–1.00 pu FLA

LLTPU = 0.5

Load-Loss Starting Time Delay

Range: 0–15000 s

LLSDLY = 0

Load-Loss Alarm Time Delay

Range: 0.40–400.00 s

LLADLY = 5.00

Load-Loss Trip Time Delay

Range: 0.40–400.00 s

LLTDLY = 10.00

Current Unbalance Elements Settings

Current Unbalance Alarm Pickup

Range: OFF, 2%–80%

46UBA = 10

Current Unbalance Alarm Delay

Range: 0.10–400.00 s

46UBAD = 10.00

Current Unbalance Trip Pickup

Range: OFF, 2%–80%

46UBT = 15

Current Unbalance Trip Delay

Range: 0.10–400.00 s

46UBTD = 5.00

Phase Reversal Tripping Setting

Enable Phase Reversal Tripping

Range: Y, N

E47T = Y _____

Speed Switch Tripping Time Delay Setting

Speed Switch Trip Time Delay

Range: OFF, 0.50–400.00 s

SPDSPLY = OFF _____

Breaker Failure Settings

52A Interlock in BF Logic

Range: Y, N

52ABF = N _____

Breaker Failure Delay

Range: 0.00–2.00 s

BFD = 0.50 _____

RTD Configuration Settings

RTD Input Option (*INT is not available if no RTD option*)

Range: INT, EXT, NONE

RTDOPT = None _____

Temperature Preference Setting (*Hidden when RTDOPT = NONE*)

Range: C, F

TMPREF = _____

RTD Location Settings

(Hidden when RTDOPT = NONE)

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD1LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD2LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD3LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD4LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD5LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD6LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD7LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD8LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD9LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD10LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD11LOC = _____

RTD Location (*Hidden when RTDOPT = INT*)
Range: WDG, BRG, AMB, OTH, NONE

RTD12LOC = _____

RTD Type Settings

(Hidden when RTDOPT = NONE)

RTD Type
Range: PT100, NI100, NI120, CU10

RTD1TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD2TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD3TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD4TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD5TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD6TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD7TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD8TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD9TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD10TY = _____

RTD Type
Range: PT100, NI100, NI120, CU10

RTD11TY = _____

RTD Type (*Hidden when RTDOPT = INT*)
Range: PT100, NI100, NI120, CU10

RTD12TY = _____

RTD Temperature Settings

(Hidden when RTDOPT = NONE)

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP1 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP1 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP2 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP2 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP3 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP3 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP4 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP4 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP5 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP5 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP6 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP6 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP7 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP7 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP8 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP8 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP9 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP9 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP10 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP10 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP11 = _____

RTD Alarm Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP11 = _____

RTD Trip Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP12 = _____

RTD Alarm Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP12 = _____

Enable Winding Trip Voting

(Hidden if <2 RTD Winding trip temperatures are
NOT OFF.)

Range: Y, N

EWDGV = _____

Enable Bearing Trip Voting

(Hidden if <2 RTD Bearing trip temperatures are
NOT OFF.)

Range: Y, N

EBRGV = _____

Enable RTD Biasing

(Hidden if no RTDnLOC = AMB, or if all winding
RTD trip
temperatures are OFF.)

Range: Y, N

RTDBEN = _____

Voltage-Based Protection

Undervoltage (U/V) Elements

(Hidden if no voltage option or if DELTA_Y = Y)

Level 1 Phase-Phase U/V Pickup

Range: OFF, 1–300 V

27P1P = _____

Level 2 Phase-Phase U/V Pickup

Range: OFF, 1–300 V

27P2P = _____

Overvoltage (O/V) Elements

(Hidden if no voltage option or if DELTA_Y = Y)

Level 1 Phase-Phase O/V Pickup

Range: OFF, 1–300 V

59P1P = _____

Level 2 Phase-Phase O/V Pickup

Range: OFF, 1–300 V

59P2P = _____

Undervoltage (U/V) Elements

(Hidden if no voltage option or if DELTA_Y = D)

Level 1 Phase U/V Pickup

Range: OFF, 1–300 V

27P1P = 40 _____

Level 2 Phase U/V Pickup

Range: OFF, 1–300 V

27P2P = OFF _____

Overvoltage (O/V) Elements

(Hidden if no voltage option or if DELTA_Y = D)

Level 1 Phase O/V Pickup

Range: OFF, 1–300 V

59P1P = 73 _____

Level 2 Phase O/V Pickup

Range: OFF, 1–300 V

59P2P = OFF _____

Residual O/V Pickup (Hidden if SINGLEV = Y)

Range: OFF, 1–300 V

59GP = OFF _____

Reactive Power (VAR) Element Settings

(Hidden if no voltage option)

Negative VAR Alarm Pickup

Range: OFF, 30–2000 VAR; ITAP = 5 A

OFF, 6–400 VAR; ITAP = 1 A

NVARAP = OFF _____

Positive VAR Alarm Pickup (Hidden if

NVARAP = OFF)

Range: 30–2000 VAR; ITAP = 5 A

6–400 VAR; ITAP = 1 A

PVARAP = _____

VAR Alarm Time Delay (Hidden if

NVARAP = OFF)

Range: 0.00–400.00 s

VARAD = _____

Negative VAR Trip Pickup

Range: OFF, 30–2000 VAR; ITAP = 5 A
OFF, 6–400 VAR; ITAP = 1 A

NVARTP = OFF _____

Positive VAR Trip Pickup (Hidden if

NVARTP = OFF)

Range: 30–2000 VAR; ITAP = 5 A
6–400 VAR; ITAP = 1 A

PVARTP = _____

VAR Trip Time Delay (Hidden if

NVARTP = OFF)

Range: 0.00–400.00 s

VARTD = _____

VAR Element Arming Delay (Hidden if both

NVARAP and NVARTP = OFF)

Range: 0.00–15000 s

VARDLY = _____

Underpower Element Settings

(Hidden if no voltage option)

Phase Underpower Alarm Pickup

Range: OFF, 30–2000 W; ITAP = 5 A
OFF, 6–400 W; ITAP = 1 A

37PAP = OFF _____

Phase Underpower Alarm Time Delay (Hidden

if 37PAP = OFF)

Range: 0.40–400.00 s

37PAD = _____

Phase Underpower Trip Pickup

Range: OFF, 30–2000 W; ITAP = 5 A
OFF, 6–400 W; ITAP = 1 A

37PTP = OFF _____

Phase Underpower Trip Time Delay (Hidden if

37PTP = OFF)

Range: 0.40–400.00 s

37PTD = _____

Underpower Element Arming Delay (Hidden if

both 37PAP and 37PTP = OFF)

Range: 0–15000 s

37DLY = _____

Power Factor Element Settings

(Hidden if no voltage option)

Power Factor Alarm Leading Pickup

Range: OFF, 0.05–0.99

55LDAP = OFF _____

Power Factor Alarm Lagging Pickup (Hidden if

55LDAP = OFF)

Range: 0.05–0.99

55LGAP = _____

Power Factor Alarm Time Delay (Hidden if

55LDAP = OFF)

Range: 0.00–400.00 s

55AD = _____

Power Factor Trip Leading Pickup

Range: OFF, 0.05–0.99

55LDTP = OFF _____

Power Factor Trip Lagging Pickup (Hidden if

55LDTP = OFF)

Range: 0.05–0.99

55LGTP = _____

Power Factor Trip Time Delay *(Hidden if 55LDTP = OFF)*
Range: 0.00–400.00 s

55TD = _____

Power Factor Element Arming Delay *(Hidden if both 55LDAP and 55LDTP = OFF)*
Range: 0–15000 s

55DLY = _____

Frequency Elements Settings
(Hidden if no voltage option)

Level 1 Pickup
Range: OFF, 20.00–70.00 Hz

81D1P = 59.10 _____

Level 1 Time Delay *(Hidden if 81D1P = OFF)*
Range: 0.03–400.00 s

81D1D = 0.03 _____

Level 2 Pickup
Range: OFF, 20.00–70.00 Hz

81D2P = OFF _____

Level 2 Time Delay *(Hidden if 81D2P = OFF)*
Range: 0.03–400.00 s

81D2D = _____

Level 3 Pickup
Range: OFF, 20.00–70.00 Hz

81D3P = OFF _____

Level 3 Time Delay *(Hidden if 81D3P = OFF)*
Range: 0.03–400.00 s

81D3D = _____

Output Configuration

Analog Output Settings

Analog Output Signal Type

Range: 0–1 mA, 0–20 mA, 4–20 mA

AOSIG = 4-20 mA _____

Analog Output Parameter

Range: %Load_I Percentage of Full Load

AOPARM = %LOAD_I _____

Current

%THERM Percentage Thermal Capacity

WDG_RTD Hottest Winding RTD

Temperature

BRG_RTD Hottest Bearing RTD

Temperature

AVG_I Average Phase Current

MAX_I Maximum Phase Current

Analog Output Full Scale Current (*Only shown*

if AOPARM = AVG_I or MAX_I)

Range: 0.5–80.0 A; ITAP = 5 A

0.1–16.0 A; ITAP = 1 A

AOFSC = _____

Front-Panel Display Settings

Front-Panel Timeout

Range: 0–30 min

FP_TO = 15 _____

Front-Panel Display Brightness

Range: 25%, 50%, 75%, 100%

FPBRITE = 50 _____

Front-Panel Power Display (*Hidden if no voltage option*)

Range: Y, N

FP_KW = N _____

Front-Panel RTD Display (*Hidden if*

RTDOPT = NONE)

Range: Y, N

FP_RTD = _____

Front-Panel Display Message Settings

Display Messages

Range: 20 Characters; enter NA to null

DM1_1 = SEL-701 _____

DM1_0 = _____

DM2_1 = MOTOR RELAY _____

DM2_0 = _____

DM3_1 = RTD FAILURE _____

DM3_0 = _____

DM4_1 = TIME BET STARTS LO _____

DM4_0 = _____

DM5_1 = NUM OF STARTS LO _____

DM5_0 = _____

DM6_1 = THERMAL LO _____

DM6_0 = _____

Output Contact Settings

Enable TRIP Contact Fail-Safe

Range: Y, N

TRFS = Y _____

Enable OUT1 Contact Fail-Safe

Range: Y, N

OUT1FS = N _____

Enable OUT2 Contact Fail-Safe

Range: Y, N

OUT2FS = N _____

Enable OUT3 Contact Fail-Safe

Range: Y, N

OUT3FS = N _____

Minimum Trip Duration Time

Range: 0.00–400.00 s

TDURD = 0.5 _____

Antibackspin Setting

Antibackspin Starting Delay

Range: 0–60 min

ABSDLY = 0 _____

Factory Logic Settings

Use Factory Logic Settings

Range: Y, N

FACTLOG = Y _____

Front-Panel Display Message Variables (Hidden if FACTLOG = Y)

Display Message Variables

Range: SELOGIC Control Equation

DM1 = 1 _____

DM2 = 1 _____

DM3 = RTDFLT _____

DM4 = TBSLO * STOPPED _____

DM5 = NOSLO * STOPPED _____

DM6 = THERMLO _____

Logic Variables (Hidden if FACTLOG = Y)

Logic Variable 1

Range: SELOGIC Control Equation

SV1 Pickup Time (0.00–3000.00 s)

SV1 Dropout Time (0.00–3000.00 s)

SV1 = 0 _____

SV1PU = 0.00 _____

SV1DO = 0.00 _____

Logic Variable 2

Range: SELOGIC Control Equation

SV2 Pickup Time (0.00–3000.00 s)

SV2 Dropout Time (0.00–3000.00 s)

SV2 = 0 _____

SV2PU = 0.00 _____

SV2DO = 0.00 _____

Logic Variable 3

Range: SELOGIC Control Equation

SV3 Pickup Time (0.00–3000.00 s)

SV3 Dropout Time (0.00–3000.00 s)

SV3 = 0 _____

SV3PU = 0.00 _____

SV3DO = 0.00 _____

Logic Variable 4

Range: SELOGIC Control Equation

SV4 Pickup Time (0.00–3000.00 s)

SV4 Dropout Time (0.00–3000.00 s)

SV4 = 0 _____

SV4PU = 0.00 _____

SV4DO = 0.00 _____

Set/Reset Latch Variables (Hidden if FACTLOG = Y)

Latch Variable (1–4)

Range: SELOGIC Control Equation

SET1 = 0

RST1 = 1

SET2 = 0

RST2 = 1

SET3 = 0

RST3 = 1

SET4 = 0

RST4 = 1

Output Variables (Hidden if FACTLOG = Y)

Trip Variable

Range: SELOGIC Control Equation

TRIP = JAMTRIP + 46UBT + 49T + 50P1T + 50P2T + 50N1T + 50N2T + 50G1T + 50G2T + 50QT + 47T + SPDSTR + WDGTRIP + BRGTRIP + AMBTRIP + 0THTRIP + 81D1T + 81D2T + 81D3T + !27P1 * (LOSSTRIP + 37PT + 55T + VART) + IN2

Unlatch Trip Variable

Range: SELOGIC Control Equation

ULTRIP = 0

52A Variable

Range: SELOGIC Control Equation

52A = !IN1

Motor Start Variable

Range: SELOGIC Control Equation

STR = 0

Emergency Restart Variable

Range: SELOGIC Control Equation

EMRSTR = IN5 * STOPPED

Password Access2 Variable

Range: SELOGIC Control Equation

ACCESS2 = IN4

Target Reset Variable

Range: SELOGIC Control Equation

TARR = 0

Event Report Trigger Variable

Range: SELOGIC Control Equation

ER = /LOSSALRM + /46UBA + /49A + \81D1T + \81D2T + \81D3T + /37PA + /55A + /VARA + /TRIP

Output Variables 1–3

Range: SELOGIC Control Equation

OUT1 = LOSSALRM + 46UBA + 49A + 37PA + 55A + VARA

OUT2 = RTDBIAS + WDGALRM + BRGALRM + AMBALRM + OTHALRM + RTDFLT

OUT3 = START

Breaker Failure Initiate

Range: SELOGIC Control Equation

BFI = /TRIP

Serial Port Settings

(Serial Port Command SET P F or SET P R)

SET P Serial Port Settings

Protocol (*Hidden, Equal ASCII for Front Port*)

Range: ASCII, MOD

PROTO = ASCII

Protocol = ASCII (Hidden when Protocol = MOD)

Baud Rate

Range: 300–19200

SPEED = 2400

Data Bits

Range: 7, 8

BITS = 8

Parity

Range: O, E, N

PARITY = N

Stop Bits

Range: 1, 2

STOP = 1

Timeout

Range: 0–30 min

T_OUT = 15

Send Auto Messages to Port

Range: Y, N

AUTO = N

Enable Hardware Handshaking

Range: Y, N

RTSCTS = N

Fast Operate Enable

Range: Y, N

FASTOP = N

Protocol = MOD (Hidden when Protocol = ASCII)

Baud Rate

Range: 300–19200

SPEED = 2400

Parity

Range: O, E, N

PARITY = N

Modbus® Slave ID

Range: 1–247

SLAVEID = 1

Sequential Events Recorder Settings (SET R)

SER Trigger Settings

SER1

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER1 = IN1, IN2, IN3, IN4, IN5, IN6, IN7 _____

SER2

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER2 = STARTING, RUNNING, STOPPED, JAMTRIP,
LOSSALRM, LOSSTRIP, 46UBA, 46UBT, 49A, 49T, 47T,
SPEEDSW, SPEEDSTR, TRIP, OUT1, OUT2, OUT3, 50G1T,
50G2T, 50N1T, 50N2T _____

SER3

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER3 = RTDFT, WDGALRM, WDGTRIP, BRGALRM,
BRGTRIP, AMBALRM, AMBTRIP, OTHALRM, OTHTRIP,
81D1T, 81D2T, 81D3T, TRGTR, START, 50P1T, 50P2T

SER4

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER4 = ABSLO, TBSLO, NOSLO, THERMLO

SER Alias Settings

Enable ALIAS Settings

Range: N, 1–20

EALIAS = 20 _____

Alias Settings (Hidden when EALIAS = N, ALIAS# > EALIAS setting are hidden.)

NOTE: Relay Word bit (space) Alias (space) Asserted text (space) Alias and text strings can each be up to 15 text characters. Asserted and deasserted text strings are not required. Use NA to disable setting.

ALIAS1 = STARTING MOTOR STARTING BEGINS ENDS

ALIAS2 = RUNNING MOTOR RUNNING BEGINS ENDS

ALIAS3 = STOPPED MOTOR STOPPED BEGINS ENDS

ALIAS4 = JAMTRIP LOAD JAM TRIP PICKUP DROPOUT

ALIAS5 = LOSSTRIP LOAD LOSS TRIP PICKUP DROPOUT

ALIAS6 = LOSSALRM LOAD LOSS ALARM PICKUP DROPOUT

ALIAS7 = 46UBA UNBALNC I ALARM PICKUP DROPOUT

ALIAS8 = 46UBT UNBALNC I TRIP PICKUP DROPOUT

ALIAS9 = 49A THERMAL ALARM PICKUP DROPOUT

ALIAS10 = 49T THERMAL TRIP PICKUP DROPOUT

ALIAS11 = 47T PHS REVRSL TRIP PICKUP DROPOUT

ALIAS12 = SPDSTR SPEED SW TRIP PICKUP DROPOUT

ALIAS13 = IN2 DIRECT TRIP IN PICKUP DROPOUT

ALIAS14 = SPEEDSW SPEED SW IN PICKUP DROPOUT

ALIAS15 = IN5 EMERGNCY RSTART PICKUP DROPOUT

ALIAS16 = IN1 MOTOR BREAKER OPEN CLOSED

ALIAS17 = IN4 ACCESS2 ALLOWED PASSWORD ONLY

ALIAS18 = TBSLO TIME BSTARTS LO PICKUP DROPUT

ALIAS19 = NOSLO NUM STARTS LO PICKUP DROPUT

ALIAS20 = THERMLO THERMAL LO PICKUP DROPOUT

Appendix F

SEL-701 Relay Settings Sheets

Relay Settings

(Blank Sheets)

General Data

Relay Identifier

Range: 20 Characters

RID = _____

Terminal Identifier

Range: 20 Characters

TID = _____

Phase (IA, IB, IC) CT Ratio

Range: 1–6000 to 1

CTR = _____

Phase CT Secondary Rating

Range: 1 A, 5 A

ITAP = _____

Neutral (IN) CT Ratio

Range: 1–6000 to 1

CTRN = _____

Neutral CT Secondary Rating

Range: 1 A, 5 A

INTAP = _____

Phase Rotation

Range: ABC, ACB

PHROT = _____

Nominal Frequency

Range: 50, 60 Hz

FNOM = _____

Date Format

Range: MDY, YMD

DATE_F = _____

Demand Meter Time Constant

Range: 5, 10, 15, 30, 60 min

DMTC = _____

Phase (VA, VB, VC) VT Ratio *(Hidden if voltages not included)*

Range: 1–6000 to 1

PTR = _____

Phase VT Connection *(Hidden if voltages not included)*

Range: D, Y

DELTA_Y = _____

Single Voltage Input *(Hidden if voltages not included)*

Range: Y, N

SINGLELEV = _____

Standard Alarm Contact Operation

Range: Y, N

STDALARM = _____

Thermal Model Elements

Setting Method

Range: OFF, Rating, Generic, User

SETMETH = _____

Full Load Amps

Range: 1.00–8.00 A; ITAP = 5 A

0.20–1.60 A; ITAP = 1 A

FLA = _____

Thermal Element Settings When Setting Method = RATING

(Hidden When SETMETH = GENERIC, USER, or OFF)

Service Factor

Range: 1.01–1.50

SF = _____

Locked Rotor Amps

Range: 2.50–80.00 A; ITAP = 5 A

0.50–16.00 A; ITAP = 1 A

LRA = _____

Hot Locked Rotor Time

Range: 1.0–200.0 s

LRTHOT = _____

Cold Locked Rotor Time

Range: 1.0–240.0 s

LRTCOLD = _____

Locked Rotor Trip Time Dial

Range: 0.10–1.50

TD = _____

Thermal Element Settings When Setting Method = GENERIC

(Hidden When SETMETH = RATING, USER, or OFF)

Service Factor

Range: 1.01–1.50

SF = _____

Curve Number

Range: 1–45

CURVE = _____

Thermal Element Settings When Setting Method = USER

(Hidden When SETMETH = RATING, GENERIC, or OFF)

Service Factor

Range: 1.01–1.50

SF = _____

Time to Trip at 1.05 x FLA

Range: 1.0–6000.0 s, NP

TTT105 = _____

Time to Trip at 1.10 x FLA

Range: 1.0–6000.0 s, NP

TTT110 = _____

Time to Trip at 1.20 x FLA

Range: 1.0–6000.0 s, NP

TTT120 = _____

Time to Trip at 1.30 x FLA

Range: 1.0–6000.0 s, NP

TTT130 = _____

Time to Trip at 1.40 x FLA

Range: 1.0–6000.0 s, NP

TTT140 = _____

Time to Trip at 1.50 x FLA

Range: 1.0–6000.0 s, NP

TTT150 = _____

Time to Trip at 1.75 x FLA

Range: 1.0–6000.0 s, NP

TTT175 = _____

Time to Trip at 2.00 x FLA

Range: 1.0–6000.0 s

TTT200 = _____

Time to Trip at 2.25 x FLA

Range: 1.0–6000.0 s, NP

TTT225 = _____

Time to Trip at 2.50 x FLA

Range: 1.0–6000.0 s

TTT250 = _____

Time to Trip at 2.75 x FLA

Range: 1.0–6000.0 s, NP

TTT275 = _____

Time to Trip at 3.00 x FLA

Range: 1.0–6000.0 s, NP

TTT300 = _____

Time to Trip at 3.50 x FLA

Range: 1.0–6000.0 s, NP

TTT350 = _____

Time to Trip at 4.00 x FLA

Range: 1.0–6000.0 s, NP

TTT400 = _____

Time to Trip at 4.50 x FLA

Range: 1.0–6000.0 s, NP

TTT450 = _____

Time to Trip at 5.00 x FLA

Range: 1.0–600.0 s, NP

TTT500 = _____

Time to Trip at 5.50 x FLA

Range: 1.0–600.0 s

TTT550 = _____

Time to Trip at 6.00 x FLA

Range: 1.0–600.0 s

TTT600 = _____

Time to Trip at 6.50 x FLA

Range: 1.0–600.0 s

TTT650 = _____

Time to Trip at 7.00 x FLA

Range: 1.0–400.0 s

TTT700 = _____

Time to Trip at 7.50 x FLA

Range: 1.0–450.0 s, NP

TTT750 = _____

Time to Trip at 8.00 x FLA

Range: 1.0–400.0 s, NP

TTT800 = _____

Time to Trip at 8.50 x FLA

Range: 1.0–350.0 s, NP

TTT850 = _____

Time to Trip at 9.00 x FLA

Range: 1.0–300.0 s, NP

TTT900 = _____

Time to Trip at 10.00 x FLA

Range: 1.0–225.0 s, NP

TTT1000 = _____

(The balance of Thermal Element Settings are hidden when SETMETH=OFF)

Thermal Capacity Alarm Pickup

Range: 50%–100%

TCAPU = _____

Thermal Capacity Used to Start

Range: 20%–100%

TCSTART = _____

Use Learned Starting Thermal Capacity

Range: Y, N

TCLRNE = _____

Motor Stopped Cooling Time

Range: 180–72000 s

COOLTIME = _____

Use Learned Cooling Time (*Hidden when
RTDOPT = NONE*)
Range: Y, N

COOLEN = _____

Overcurrent (O/C) Elements

(Time-delay settings are hidden when their associated pickup settings = OFF)

Level 1 Phase O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50P1P = _____

Level 1 Phase O/C Time Delay

Range: 0.00–400.00 s

50P1D = _____

Level 2 Phase O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50P2P = _____

Level 2 Phase O/C Time Delay

Range: 0.00–400.00 s

50P2D = _____

Level 1 Residual O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50G1P = _____

Level 1 Residual O/C Time Delay

Range: 0.00–400.00 s

50G1D = _____

Level 2 Residual O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50G2P = _____

Level 2 Residual O/C Time Delay

Range: 0.00–400.00 s

50G2D = _____

Level 1 Neutral O/C Pickup

Range: OFF, 0.025–10.000 A; INTAP = 5 A
OFF, 0.005–2.000 A; INTAP = 1 A

50N1P = _____

Level 1 Neutral O/C Time Delay

Range: 0.00–400.00 s

50N1D = _____

Level 2 Neutral O/C Pickup

Range: OFF, 0.025–10.000 A; INTAP = 5 A
OFF, 0.005–2.000 A; INTAP = 1 A

50N2P = _____

Level 2 Neutral O/C Time Delay

Range: 0.00–400.00 s

50N2D = _____

Negative-Sequence O/C Pickup

Range: OFF, 0.25–100.00 A; ITAP = 5 A
OFF, 0.05–20.00 A; ITAP = 1 A

50QP = _____

Negative-Sequence O/C Time Delay

Range: 0.10–400.00 s

50QD = _____

Jogging Block Element Settings

Maximum Number of Starts per Hour

Range: OFF, 1–15

MAXSTART = _____

Minimum Time Between Starts

Range: OFF, 1–150 min

TBSDLY = _____

Load-Jam Function Settings

Load-Jam Trip Pickup

Range: OFF, 0.5–6.0 pu FLA

LJTPU = _____

Load-Jam Trip Delay

Range: 0.00–400.00 s

LJTDLY = _____

Load-Loss Element Settings (Hidden when voltage option unavailable)

Load-Loss Alarm Threshold

Range: OFF, 30–2000 W; ITAP = 5 A

OFF, 6–400 W; ITAP = 1 A

LLAPU = _____

(Hidden when LLAPU = OFF)

Load-Loss Trip Threshold

Range: 30–2000 W; ITAP = 5 A

6–400 W; ITAP = 1 A

LLTPU = _____

Load-Loss Starting Time Delay

Range: 0–15000 s

LLSDLY = _____

Load-Loss Alarm Time Delay

Range: 0.40–400.00 s

LLADLY = _____

Load-Loss Trip Time Delay

Range: 0.40–400.00 s

LLTDLY = _____

(Hidden when voltage option available)

Load-Loss Alarm Threshold

Range: OFF, 0.10–1.00 pu FLA

LLAPU = _____

Load-Loss Trip Threshold

Range: 0.10–1.00 pu FLA

LLTPU = _____

Load-Loss Starting Time Delay

Range: 0–15000 s

LLSDLY = _____

Load-Loss Alarm Time Delay

Range: 0.40–400.00 s

LLADLY = _____

Load-Loss Trip Time Delay

Range: 0.40–400.00 s

LLTDLY = _____

Current Unbalance Elements Settings

Current Unbalance Alarm Pickup

Range: OFF, 2%–80%

46UBA = _____

Current Unbalance Alarm Delay

Range: 0.10–400.00 s

46UBAD = _____

Current Unbalance Trip Pickup

Range: OFF, 2%–80%

46UBT = _____

Current Unbalance Trip Delay

Range: 0.10–400.00 s

46UBTD = _____

Phase Reversal Tripping Setting

Enable Phase Reversal Tripping

Range: Y, N

E47T = _____

Speed Switch Tripping Time Delay Setting

Speed Switch Trip Time Delay

Range: OFF, 0.50–400.00 s

SPDSDLY = _____

Breaker Failure Settings

52A Interlock in BF Logic

Range: Y, N

52ABF = _____

Breaker Failure Delay

Range: 0.00–2.00 s

BFD = _____

RTD Configuration Settings

RTD Input Option (*INT is not available if no RTD option*)

Range: INT, EXT, NONE

RTDOPT = _____

Temperature Preference Setting (*Hidden when RTDOPT = NONE*)

Range: C, F

TMPREF = _____

RTD Location Settings (Hidden when RTDOPT = NONE)

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD1LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD2LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD3LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD4LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD5LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD6LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD7LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD8LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD9LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD10LOC = _____

RTD Location

Range: WDG, BRG, AMB, OTH, NONE

RTD11LOC = _____

RTD Location (Hidden when RTDOPT = INT)

Range: WDG, BRG, AMB, OTH, NONE

RTD12LOC = _____

RTD Type Settings (Hidden when RTDOPT = NONE)

RTD Type

Range: PT100, NI100, NI120, CU10

RTD1TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD2TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD3TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD4TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD5TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD6TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD7TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD8TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD9TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD10TY = _____

RTD Type

Range: PT100, NI100, NI120, CU10

RTD11TY = _____

RTD Type (Hidden when RTDOPT = INT)

Range: PT100, NI100, NI120, CU10

RTD12TY = _____

RTD Temperature Settings (Hidden when RTDOPT = NONE)

RTD Trip Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP1 = _____

RTD Alarm Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP1 = _____

RTD Trip Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP2 = _____

RTD Alarm Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP2 = _____

RTD Trip Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP3 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP3 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP4 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP4 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP5 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP5 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP6 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP6 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP7 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP7 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP8 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP8 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP9 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP9 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP10 = _____

RTD Alarm Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP10 = _____

RTD Trip Temperature
Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP11 = _____

RTD Alarm Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP11 = _____

RTD Trip Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

TRTMP12 = _____

RTD Alarm Temperature

Range: OFF, 0°–250°C
OFF, 32°–482°F

ALTMP12 = _____

Enable Winding Trip Voting

(Hidden if <2 RTD Winding trip temperatures are
NOT OFF.)

Range: Y, N

EWDGV = _____

Enable Bearing Trip Voting

(Hidden if <2 RTD Bearing trip temperatures are
NOT OFF.)

Range: Y, N

EBRGV = _____

Enable RTD Biasing

(Hidden if no RTDnLOC = AMB, or if all winding
RTD trip
temperatures are OFF.)

Range: Y, N

RTDBEN = _____

Voltage-Based Protection

Undervoltage (U/V) Elements (Hidden if no voltage option or if DELTA_Y = Y)

Level 1 Phase-Phase U/V Pickup

Range: OFF, 1–300 V

27P1P = _____

Level 2 Phase-Phase U/V Pickup

Range: OFF, 1–300 V

27P2P = _____

Overvoltage (O/V) Elements (Hidden if no voltage option or if DELTA_Y = Y)

Level 1 Phase-Phase O/V Pickup

Range: OFF, 1–300 V

59P1P = _____

Level 2 Phase-Phase O/V Pickup

Range: OFF, 1–300 V

59P2P = _____

Undervoltage (U/V) Elements (Hidden if no voltage option or if DELTA_Y = D)

Level 1 Phase U/V Pickup

Range: OFF, 1–300 V

27P1P = _____

Level 2 Phase U/V Pickup

Range: OFF, 1–300 V

27P2P = _____

Overvoltage (O/V) Elements (Hidden if no voltage option or if DELTA_Y = D)

Level 1 Phase O/V Pickup

Range: OFF, 1–300 V

59P1P = _____

Level 2 Phase O/V Pickup

Range: OFF, 1–300 V

59P2P = _____

Residual O/V Pickup (Hidden if SINGLEV = Y)

Range: OFF, 1–300 V

59GP = _____

Reactive Power (VAR) Element Settings (Hidden if no voltage option)

Negative VAR Alarm Pickup

Range: OFF, 30–2000 VAR; ITAP = 5 A

OFF, 6–400 VAR; ITAP = 1 A

NVARAP = _____

Positive VAR Alarm Pickup (Hidden if

NVARAP = OFF)

Range: 30–2000 VAR; ITAP = 5 A

6–400 VAR; ITAP = 1 A

PVARAP = _____

VAR Alarm Time Delay (Hidden if

NVARAP = OFF)

Range: 0.00–400.00 s

VARAD = _____

Negative VAR Trip Pickup

Range: OFF, 30–2000 VAR; ITAP = 5 A

OFF, 6–400 VAR; ITAP = 1 A

NVARTP = _____

Positive VAR Trip Pickup (Hidden if

NVARTP = OFF)

Range: 30–2000 VAR; ITAP = 5 A

6–400 VAR; ITAP = 1 A

PVARTP = _____

VAR Trip Time Delay (*Hidden if*

NVARTP = OFF)

Range: 0.00–400.00 s

VARTD = _____

VAR Element Arming Delay (*Hidden if both*

NVARAP and NVARTP = OFF)

Range: 0.00–15000 s

VARDLY = _____

Underpower Element Settings (*Hidden if no voltage option*)

Phase Underpower Alarm Pickup

Range: OFF, 30–2000 W; ITAP = 5 A

OFF, 6–400 W; ITAP = 1 A

37PAP = _____

Phase Underpower Alarm Time Delay (*Hidden*

if 37PAP = OFF)

Range: 0.40–400.00 s

37PAD = _____

Phase Underpower Trip Pickup

Range: OFF, 30–2000 W; ITAP = 5 A

OFF, 6–400 W; ITAP = 1 A

37PTP = _____

Phase Underpower Trip Time Delay (*Hidden if*

37PTP = OFF)

Range: 0.40–400.00 s

37PTD = _____

Underpower Element Arming Delay (*Hidden if*

both 37PAP and 37PTP = OFF)

Range: 0–15000 s

37DLY = _____

Power Factor Element Settings (*Hidden if no voltage option*)

Power Factor Alarm Leading Pickup

Range: OFF, 0.05–0.99

55LDAP = _____

Power Factor Alarm Lagging Pickup (*Hidden if*

55LDAP = OFF)

Range: 0.05–0.99

55LGAP = _____

Power Factor Alarm Time Delay (*Hidden if*

55LDAP = OFF)

Range: 0.00–400.00 s

55AD = _____

Power Factor Trip Leading Pickup

Range: OFF, 0.05–0.99

55LDTP = _____

Power Factor Trip Lagging Pickup (*Hidden if*

55LDTP = OFF)

Range: 0.05–0.99

55LGTP = _____

Power Factor Trip Time Delay (*Hidden if*

55LDTP = OFF)

Range: 0.00–400.00 s

55TD = _____

Power Factor Element Arming Delay (*Hidden*

if both 55LDAP and 55LDTP = OFF)

Range: 0–15000 s

55DLY = _____

Frequency Elements Settings (Hidden if no voltage option)

Level 1 Pickup	
Range: OFF, 20.00–70.00 Hz	81D1P = _____
Level 1 Time Delay (Hidden if 81D1P = OFF)	
Range: 0.03–400.00 s	81D1D = _____
Level 2 Pickup	
Range: OFF, 20.00–70.00 Hz	81D2P = _____
Level 2 Time Delay (Hidden if 81D2P = OFF)	
Range: 0.03–400.00 s	81D2D = _____
Level 3 Pickup	
Range: OFF, 20.00–70.00 Hz	81D3P = _____
Level 3 Time Delay (Hidden if 81D3P = OFF)	
Range: 0.03–400.00 s	81D3D = _____

Output Configuration

Analog Output Settings

Analog Output Signal Type

Range: 0–1 mA, 0–20 mA, 4–20 mA

AOSIG = _____

Analog Output Parameter

Range: %Load_I Percentage of Full Load

AOPARM = _____

Current

%THERM Percentage Thermal Capacity

WDG_RTD Hottest Winding RTD

Temperature

BRG_RTD Hottest Bearing RTD

Temperature

AVG_I Average Phase Current

MAX_I Maximum Phase Current

Analog Output Full Scale Current (*Only shown*

if AOPARM = AVG_I or MAX_I)

Range: 0.5–80.0 A; ITAP = 5 A

0.1–16.0 A; ITAP = 1 A

AOFSC = _____

Front-Panel Display Settings

Front-Panel Timeout

Range: 0–30 min

FP_TO = _____

Front-Panel Display Brightness

Range: 25%, 50%, 75%, 100%

FPBRITE = _____

Front-Panel Power Display (*Hidden if no voltage option*)

Range: Y, N

FP_KW = _____

Front-Panel RTD Display (*Hidden if*

RTDOPT = NONE)

Range: Y, N

FP_RTD = _____

Front-Panel Display Message Settings

Display Messages

Range: 20 Characters; enter NA to null

DM1_1 = _____

DM1_0 = _____

DM2_1 = _____

DM2_0 = _____

DM3_1 = _____

DM3_0 = _____

DM4_1 = _____

DM4_0 = _____

DM5_1 = _____

DM5_0 = _____

DM6_1 = _____

DM6_0 = _____

Output Contact Settings

Enable TRIP Contact Fail-Safe

Range: Y, N

TRFS = _____

Enable OUT1 Contact Fail-Safe

Range: Y, N

OUT1FS = _____

Enable OUT2 Contact Fail-Safe

Range: Y, N

OUT2FS = _____

Enable OUT3 Contact Fail-Safe

Range: Y, N

OUT3FS = _____

Minimum Trip Duration Time

Range: 0.00–400.00 s

TDURD = _____

Antibackspin Setting

Antibackspin Starting Delay

Range: 0–60 min

ABSDLY = _____

Factory Logic Settings

Use Factory Logic Settings

Range: Y, N

FACTLOG = _____

Front-Panel Display Message Variables (Hidden if FACTLOG = Y)

Display Message Variables

Range: SELOGIC Control Equation

DM1 = _____

DM2 = _____

DM3 = _____

DM4 = _____

DM5 = _____

DM6 = _____

Logic Variables (Hidden if FACTLOG = Y)

Logic Variable 1

Range: SELOGIC Control Equation

SV1 Pickup Time (0.00–3000.00 s)

SV1 Dropout Time (0.00–3000.00 s)

SV1 = _____

SV1PU = _____

SV1DO = _____

Logic Variable 2

Range: SELOGIC Control Equation

SV2 Pickup Time (0.00–3000.00 s)

SV2 Dropout Time (0.00–3000.00 s)

SV2 = _____

SV2PU = _____

SV2DO = _____

Logic Variable 3

Range: SELOGIC Control Equation

SV3 Pickup Time (0.00–3000.00 s)

SV3 Dropout Time (0.00–3000.00 s)

SV3 = _____

SV3PU = _____

SV3DO = _____

Logic Variable 4

Range: SELOGIC Control Equation

SV4 Pickup Time (0.00–3000.00 s)

SV4 Dropout Time (0.00–3000.00 s)

SV4 = _____

SV4PU = _____

SV4DO = _____

Set/Reset Latch Variables (Hidden if FACTLOG = Y)

Latch Variable (1–4)

Range: SELOGIC Control Equation

SET1 = _____

RST1 = _____

SET2 = _____

RST2 = _____

SET3 = _____

RST3 = _____

SET4 = _____

RST4 = _____

Output Variables (Hidden if FACTLOG = Y)

Trip Variable

Range: SELOGIC Control Equation

TRIP = _____

Unlatch Trip Variable

Range: SELOGIC Control Equation

ULTRIP = _____

52A Variable

Range: SELOGIC Control Equation

52A = _____

Motor Start Variable

Range: SELOGIC Control Equation

STR = _____

Emergency Restart Variable

Range: SELOGIC Control Equation

EMRSTR = _____

Password Access2 Variable

Range: SELOGIC Control Equation

ACCESS2 = _____

Target Reset Variable

Range: SELOGIC Control Equation

TARR = _____

Event Report Trigger Variable

Range: SELOGIC Control Equation

ER = _____

Output Variables 1–3

Range: SELOGIC Control Equation

OUT1 = _____

OUT2 = _____

OUT3 = _____

Breaker Failure Initiate

Range: SELOGIC Control Equation

BFI = _____

Serial Port Settings

(Serial Port Command SET P F or SET P R)

SET P Serial Port Settings

Protocol *(Hidden, Equal ASCII for Front Port)*
Range: ASCII, MOD

PROTO = _____

Protocol = ASCII *(Hidden when Protocol = MOD)*

Baud Rate
Range: 300–19200

SPEED = _____

Data Bits
Range: 7, 8

BITS = _____

Parity
Range: O, E, N

PARITY = _____

Stop Bits
Range: 1, 2

STOP = _____

Timeout
Range: 0–30 min

T_OUT = _____

Send Auto Messages to Port
Range: Y, N

AUTO = _____

Enable Hardware Handshaking
Range: Y, N

RTSCTS = _____

Fast Operate Enable
Range: Y, N

FASTOP = _____

Protocol = MOD *(Hidden when Protocol = ASCII)*

Baud Rate
Range: 300–19200

SPEED = _____

Parity
Range: O, E, N

PARITY = _____

Modbus® Slave ID
Range: 1–247

SLAVEID = _____

Sequential Events Recorder Settings (SET R)

SER Trigger Settings

SER1

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER1 = _____

SER2

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER2 = _____

SER3

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER3 = _____

SER4

Range: 24 Relay Word bits, separated by commas.
Use NA to disable setting.

SER4 = _____

SER Alias Settings

Enable ALIAS Settings

Range: N, 1–20

EALIAS = _____

Alias Settings (Hidden when EALIAS = N, ALIAS# > EALIAS setting are hidden.)

NOTE: Relay Word bit (space) Alias (space) Asserted text (space) Alias and text strings can each be up to 15 text characters. Asserted and deasserted text strings are not required. Use NA to disable setting.

ALIAS1 = _____**ALIAS2** = _____**ALIAS3** = _____**ALIAS4** = _____**ALIAS5** = _____**ALIAS6** = _____**ALIAS7** = _____**ALIAS8** = _____**ALIAS9** = _____**ALIAS10** = _____**ALIAS11** = _____**ALIAS12** = _____**ALIAS13** = _____**ALIAS14** = _____**ALIAS15** = _____**ALIAS16** = _____**ALIAS17** = _____**ALIAS18** = _____**ALIAS19** = _____**ALIAS20** = _____

Glossary

A	Abbreviation for amps or amperes; units of electrical current magnitude.
Alias	User assigned name of a Relay Word bit used in the SEL-701 Relay Sequential Events Recorder (SER) function. The assigned alias appears in the SER report in place of the Relay Word bit, making the SER report easier to review.
Ambient Temperature	Temperature of the motor cooling air at the cooling air inlet. Measured by an RTD whose location setting is AMB.
ANSI Standard Device Numbers	<p>A list of standard numbers used to represent electrical protection and control relays. The standard device numbers used in this instruction manual include:</p> <ul style="list-style-type: none">27 Undervoltage Element37 Underpower Element46 Phase Balance or Current Unbalance Element47 Phase Sequence Element49 Thermal Element50 Overcurrent Element52 AC Circuit Breaker55 Power Factor Element59 Overvoltage Element66 Jogging Device (limits number of operations within a given time of each other)81 Frequency Element <p>These numbers are frequently used within a suffix letter to further designate their application. The suffix letters used in this instruction manual include:</p> <ul style="list-style-type: none">P Phase ElementG Residual/Ground ElementN Neutral/Ground ElementQ Negative-Sequence (3I2) Element
Antibackspin Protection	Relay function that prevents the motor from being started for a short time after it is stopped. Used on pump motors to prevent a start attempt while fluid is running backward through the pump.
Antijogging Protection	Relay functions that prevent the motor from being started too many times within an hour (also referred to as Starts Per Hour protection) or too soon following the last start (also referred to as Minimum Time Between Starts protection).
Apparent Power, S	Complex power expressed in units of volt-amps (VA), kilovolt-amps (kVA), or megavolt-amps (MVA). Accounts for both real (P) and reactive (Q) power dissipated in a circuit: $S = P + jQ$.

ASCII	Abbreviation for American Standard Code for Information Interchange. Defines a standard way to communicate text characters between two electronic devices. The SEL-701 Relay uses ASCII text characters to communicate using its front- and rear-panel EIA-232 serial ports.
Assert	To activate; to fulfill the logic or electrical requirements needed to operate a device. To apply a short-circuit or closed contact to an SEL-701 Relay input. To set a logic condition to its true state (logical 1). To close a normally-open output contact. To open a normally-closed output contact.
Breaker Auxiliary Contact	A spare electrical contact associated with a circuit breaker that opens or closes to indicate the breaker position. A form-a breaker auxiliary contact (ANSI Standard Device Number 52A) closes when the breaker is closed, opens when the breaker is open. A form-b breaker auxiliary contact (ANSI Standard Device Number 52B) opens when the breaker is closed and closes when the breaker is open.
Checksum	A numeric identifier of the firmware in the relay. Calculated by the result of a mathematical sum of the relay code.
CID	Abbreviation for Checksum Identifier. The checksum of the specific firmware installed in the relay.
Contiguous	Items in sequence; the second immediately following the first.
CR_RAM	Abbreviation for Critical RAM. Refers to the area of relay Random Access Memory (RAM) where the relay stores mission critical data.
CRC-16	Abbreviation for Cyclical Redundancy Check-16. A mathematical algorithm applied to a block of digital information to produce a unique, identifying number. Used to ensure that the information was received without data corruption.
CT	Abbreviation for current transformer.
Current Unbalance Element	Protection element that calculates the magnitudes of the measured phase currents, calculates the average of those magnitudes, determines the magnitude with the largest deviation from average. It then calculates the difference between the magnitude average and magnitude of the phase with the largest deviation from the average. Finally, the relay calculates the percent unbalance current by dividing the difference value by the motor rated full load amps or by the average magnitude, whichever is larger. Unbalance current causes heating in the rotor of the protected motor. The unbalance element can trip the motor in the presence of heavy unbalance to prevent rotor damage due to overheating. In the SEL-701 Relay, this element works together with the motor thermal element which also provides unbalance current protection.
Deassert	To deactivate; to remove the logic or electrical requirements needed to operate a device. To remove a short-circuit or closed contact from an SEL-701 Relay input. To clear a logic condition to its false state (logical 0). To open a normally-open output contact. To close a normally-closed output contact.

Delta	As used in this instruction manual, a phase-to-phase connection of voltage transformers for electrical measuring purposes. Typically, two voltage transformers are used with one primary lead of the first transformer connected to A-phase and the other lead connected to B-phase. The second voltage transformer is connected to measure the voltage from B-phase to C-phase. When two transformers are used, this connection is frequently called “Open-Delta.”
Demand Meter	A measuring function that calculates a rolling average or thermal average of instantaneous measurements over time.
Dropout Time	The time measured from the removal of an input signal until the output signal deasserts. The time can be user settable, as in the case of a logic variable timer, or can be a result of the characteristics of an element algorithm, as in the case of an overcurrent element dropout time.
EEPROM	Abbreviation for Electrically Erasable Programmable Read-Only Memory. Nonvolatile memory where relay settings, event reports, SER records, and other nonvolatile data are stored.
Event Report	A text-based collection of data stored by the relay in response to a triggering condition, such as a fault or user command. The data shows relay measurements before and after the trigger, in addition to the states of protection elements, relay inputs, and relay outputs each processing interval. After an electrical system fault, use event reports to analyze relay and system performance.
Fail-Safe	Refers to an output contact that is energized during normal relay operation and de-energized when relay power is removed or if the relay fails.
Fast Meter, Fast Operate	Binary serial port commands that the relay recognizes at its front-and rear-panel EIA-232 serial ports. These commands and the relay’s responses make relay data collection by a communications processor faster and more efficient than transfer of the same data using formatted ASCII text commands and responses.
FID	Relay firmware identification string. Lists the relay model, firmware version and datecode, and other information that uniquely identifies the firmware installed in a particular relay.
Firmware	The nonvolatile program stored in the relay that defines relay operation.
Flash	A type of nonvolatile relay memory used for storing large blocks of nonvolatile data, such as load profile records.
Fundamental Frequency	The component of the measured electrical signal whose frequency is equal to the normal electrical system frequency, usually 50 or 60 Hz. Generally used to differentiate between the normal system frequency and any harmonic frequencies present.
hp	Abbreviation for horsepower. 1 hp = 745.7 W.
IA, IB, IC	Measured A-, B-, and C-phase currents.
IG	Residual current, calculated from the sum of the phase currents. In normal, balanced operation, this current is very small or zero. When a motor ground fault occurs, this current can be large.

IN	Neutral current measured by the relay IN input. The IN input is typically connected to the secondary winding of a window-CT for motor ground fault detection on resistance-grounded systems.
Instantaneous Meter	Type of meter data presented by the SEL-701 Relay that includes the present values measured at the relay ac inputs. The word “Instantaneous” is used to differentiate these values from the measurements presented by the demand, thermal, energy, and other meter types.
Key Switch Contact	A type of electrical contact that can only be moved from the open to closed position or back when you insert the appropriate key and rotate the cylinder.
Learned Motor Cooling Time	A motor parameter that the SEL-701 Relay can calculate using data collected over time. In order to calculate Learned Motor Cooling Time, the relay must be connected to measure the temperature of an ambient temperature RTD and at least one RTD embedded in the motor windings. The relay collects cooling time data for five consecutive motor stops and, if enabled by your settings, uses that cooling time in the thermal model.
Learned Starting Thermal Capacity	A motor parameter that the SEL-701 Relay can calculate using data collected over time. In order to calculate Learned Starting Thermal Capacity, the relay records the percent of thermal model capacity used during each of the last five motor starts.
LED	Abbreviation for Light-Emitting Diode. Used as indicator lamps on the relay front panel.
Load Jam Element	A motor protection element that, when enabled, can trip the protected motor if the rotor stops turning due to a sudden increase in load torque or decrease in bus voltage. When the rotor stops, the motor phase current increases. The relay detects the stopped rotor using a settable overcurrent element and trips after a settable time-delay.
Load Loss Element	A motor protection element that, when enabled, can trip the protected motor if the motor shaft is suddenly decoupled from the mechanical load. The relay detects the sudden decrease in mechanical load using an undercurrent or underpower element.
Load Profile	A function that stores selected relay measurements in nonvolatile memory every 15 minutes. The relay has enough memory to store at least 30 days of data before it replaces the oldest record with the newest one.
LOP	Loss of potential (loss of relay ac voltage input).
Max/Min Meter	Type of meter data presented by the SEL-701 Relay that includes a record of the maximum and minimum of each value, along with the date and time that each maximum and minimum occurred.
Motor Thermal Element	A motor protection element that measures motor current, calculates a representation of the energy dissipated in the motor, and compares the present energy estimate to trip thresholds defined by the relay settings. The output of the motor thermal element is represented as a % Thermal Capacity. When the % Thermal Capacity reaches 100, the relay trips to protect the motor. The Motor Thermal Element provides motor protection for the following conditions that cause motor overheating: locked rotor, overload operation, and current unbalance.
NEMA	Abbreviation for National Electrical Manufacturers Association.

Neutral Overcurrent Element	A protection element that causes the relay to trip when the neutral current magnitude (measured by the IN input) exceeds a user settable value. Used to detect and trip in response to motor or cable ground faults.
Nominal Frequency	Normal electrical system frequency, usually 50 or 60 Hz.
Nonfail-Safe	Refers to an output contact that is not energized during normal relay operation. When referred to a trip or stop output contact, the protected motor remains in operation unprotected when relay power is removed or if the relay fails.
Nonvolatile Memory	Relay memory that is able to correctly maintain its data even when the relay is de-energized.
Overfrequency Element	A protection element that causes the relay to trip when the measured electrical system frequency exceeds a user settable frequency.
Phase Reversal Element	A protection element that detects the phase rotation of the voltage or current signals applied to the protected motor, and trips if that phase rotation is the opposite of the desired phase rotation.
Phase Rotation	The sequence of voltage or current phasors in a multi-phase electrical system. In an ABC phase rotation system, the B-phase voltage lags the A-phase voltage by 120°, and the C-phase voltage lags B-phase voltage by 120°. In an ACB phase rotation system, the C-phase voltage lags the A-phase voltage by 120°, and the B-phase voltage lags the C-phase voltage by 120°.
Pickup Time	The time measured from the application of an input signal until the output signal asserts. The time can be user settable, as in the case of a logic variable timer, or can be a result of the characteristics of an element algorithm, as in the case of an overcurrent element pickup time.
Pinout	The definition or assignment of each electrical connection at an interface. Typically refers to a cable, connector, or jumper.
Power Factor	The cosine of the angle by which phase current lags phase voltage in an ac electrical circuit. Power factor equals 1.0 for power flowing to a resistive load.
PT	Abbreviation for potential transformer. Also referred to as a voltage transformer or VT.
RAM	Abbreviation for Random Access Memory. Volatile memory where the relay stores intermediate calculation results, Relay Word bits, and other data that is updated every processing interval.
Reactive Power Element	A motor protection element that can trip the protected motor if the measured reactive power exceeds a user settable threshold.
Relay Word	The collection of relay element and logic results. Each element or result is represented by a unique identifier, known as a Relay Word bit.

Relay Word Bit	A single relay element or logic result that the relay updates once each processing interval. A Relay Word bit can be equal to either logical 1 or logical 0. Logical 1 represents a true logic condition, picked up element, or asserted contact input or contact output. Logical 0 represents a false logic condition, dropped out element, or deasserted contact input or contact output. You can use Relay Word bits in SELOGIC control equations to control relay tripping, event triggering, and output contacts, as well as other functions.
Remote Bit	A Relay Word bit whose state is controlled by serial port commands, including the CONTROL command, binary Fast Operate command, or Modbus [®] command.
Residual Current	The sum of the measured phase currents. In normal, balanced operation, this current is very small or zero. When a motor ground fault occurs, this current can be large.
RMS	Abbreviation for Root-Mean-Squared. Refers to the effective value of the sinusoidal current and voltage measured by the relay, accounting for the fundamental frequency and higher order harmonics in the signal.
ROM	Abbreviation for Read-Only Memory. Nonvolatile memory where the relay firmware is stored.
RTD	Abbreviation for Resistance Temperature Device. An RTD is made of a metal having a precisely known resistance and temperature coefficient of resistance. The SEL-701 Relay and the SEL-2600 series RTD Module can measure the resistance of the RTD, and thus, determine the temperature at the RTD location. Typically embedded in the motor windings or attached to the races of bearings.
Self-Test	A function that verifies the correct operation of a critical device subsystem and indicates if an out-of-tolerance condition is detected. The SEL-701 Relay is equipped with self-tests that validate the relay power supply, microprocessor, memory, and other critical systems.
SELOGIC[®] Control Equation	A relay setting that allows you to control a relay function (such as an output contact) using a logical combination of relay element outputs and fixed logic outputs. Logical AND, OR, INVERT, Rising Edge [/], and Falling Edge [\] operators, plus a single level of parentheses are available to use in each control equation setting.
Sequential Events Recorder	A relay function that stores a record of the date and time of each assertion and deassertion of every Relay Word bit in a user settable list. Provides a useful way to determine the order and timing of events following a relay operation.
SER	Abbreviation for Sequential Events Recorder or the relay serial port command to request a report of the latest 512 sequential events.
Speed Switch	An electrical contact that closes to indicate that a motor speed exceeds a certain value.
Terminal Emulation Software	Personal computer (PC) software that can be used to send and receive ASCII text messages via the PC serial port.
Underfrequency Element	A protection element that causes the relay to trip when the measured electrical system frequency is less than a user settable frequency.

Underpower Element	A protection element that causes the relay to trip when the measured electrical power consumed by a motor is less than a user settable value.
VA, VB, VC	Measured A-, B-, and C-phase-to-neutral voltages.
VAB, VBC, VCA	Measured or calculated phase-to-phase voltages.
VFD	Abbreviation for Vacuum Fluorescent Display. Used as the relay front-panel alphanumeric display.
VG	Residual voltage calculated from the sum of the three phase-to-neutral voltages, if connected.
VT	Abbreviation for voltage transformer. Also referred to as a potential transformer or PT.
Wye	As used in this instruction manual, a phase-to-neutral connection of voltage transformers for electrical measuring purposes. Three voltage transformers are used with one primary lead of the first transformer connected to A-phase and the other lead connected to ground. The second and third voltage transformers are connected to measure the voltage from B-phase and C-phase-to-ground, respectively. This connection is frequently called 'four-wire wye,' alluding to the three phase leads plus the neutral lead.

This page intentionally left blank

Index

Page numbers appearing in bold mark the location of the topic's primary discussion.

Numerics

2ACCESS Command **6.7**

A

ACSELERATOR® QuickSet™ SEL-5030 Software **3.1**

ACCESS

commands

ACCESS **6.7**

ACCESS2 **2.12, B.15**

Level 1 **6.4**

Level 2 **6.4**

contact input **2.12**

control equation **B.15**

front-panel password entry **5.4**

password loss **2.12**

Alarm

ALARM output contact **10.2**

wiring diagram 2.9

counters **8.7**

See also Motor Statistics

protection alarms **4.37**

ANALOG Command **6.8**

Analog Output **2.12**

functional test **7.8**

maximum load **2.12**

settings **4.32**

wiring diagram **2.12**

AND [*] Operator **B.6**

ANSI Standard Device **GL.1**

Antibackspin Protection **4.35**

lockout **B.12**

Antijogging Protection **4.19, GL.1**

Apparent Power

See also Meter

average running **8.6**

demand **8.2**

glossary entry GL.1

meter **8.2**

ASCII Protocol

EIA-232 port 2.14

Average Data

See Motor Statistics

B

Battery

See Clock Battery

Breaker Auxiliary Contact

contact input 2.11, **2.11**

control equation **B.14**

Breaker Failure Logic 4.22, B.26

C

Chassis Ground

chassis connection **2.7**

figure of **2.4**

Clock Battery

life **10.6**

replacement **10.6**

specification **10.6**

Commands

summary of **6.5**

2ACCESS **6.7**

ACCESS **6.7**

ANALOG **6.8**

CONTROL **6.8**

DATE **6.8**

EVENT **6.9**

HELP **6.7**

HISTORY **6.9, 9.3**

LDP **6.10**

METER **6.10**

MOTOR **6.13, 8.6**

MSR **6.13, 8.8**

MST **6.13, 8.9**

PASSWORD **6.14**

PULSE **6.14**

QUIT **6.15**

reset data buffers **7.4**

RLP **6.15**

SER **6.15**

SET 4.2, **6.15**

SHOW **6.16**

STATUS **6.18**

STOP **6.19**

STR **6.19**

TARGET **6.19**

TIME **6.20**

TRIGGER **6.20, 9.4**

Commissioning Procedure **7.2–7.5**

clear data buffers **7.4**

connection check **7.2**

required equipment **7.1**

Communication Cables

EIA-232 2.14, **6.2**

EIA-485 **2.14**

null-modem **6.2**

PC-to-relay cable pinout **6.2**

Compressed ASCII Commands **D.12**

CASCI **D.13**

CEVENT **D.16**

CHISTORY **D.15**

CME E **D.17**

CME M **D.18**

CME T **D.19**

CSTATUS **D.15**

Configuration

part number **3.6**

Contact Inputs **2.11**

factory configuration 2.11–2.12

factory logic diagram **4.37**

wetting voltage **2.11**

wiring diagram **2.11**

Contact Outputs **2.9–2.11**

control equations **B.16**

deenergized position 2.9

factory configuration 2.10

factory logic diagram **4.37**

fail-safe operation **2.9, 2.10**

fail-safe settings **4.34**

Modbus control **C.8**

nonfail-safe operation **2.9, 2.10**

wiring diagrams **2.9, 2.10, 2.11**

CONTROL Command **6.8**

CT Ratio

setting **4.1**

setting example **4.3**

Current Unbalance

See also Meter

elements **4.21**

logic diagram **B.19**

percent unbalance equations **4.21**

functional test **7.7**

meter **8.2**

protection

using % unbalance element **4.21**

using overcurrent element **4.19**

using thermal element **4.6**

Current Unbalance Element

glossary entry **GL.2**

Currents

See also Ground CT; Meter

average running **8.6**

connections

ground/neutral 2.8

phase 2.7

demand **8.2**

starting **8.8, 8.9**

wiring diagrams

phase 2.5, 2.6

residual IN 2.6

Cut & Drill Dimensions

See Dimensions, cut & drill

D

DATE command **6.8**

Demand Meter **8.2**

See also Meter, demand

front-panel function **5.11**

glossary entry **GL.3**

serial port command **6.11**

time constant setting, DMTC **4.3**

Diagrams

- front panel **5.1**, **5.3**
- installation/mechanical
 - cut & drill dimensions **2.1**
 - ground CT placement **2.8**
 - mechanical dimensions **2.1**
 - mounting **2.2**
 - rear panel **2.3**
 - side panel **2.4**
- logic
 - current unbalance elements **B.19**
 - factory contact inputs **4.37**
 - factory contact outputs **4.37**
 - factory event triggering **4.38**
 - factory tripping **4.36**
 - frequency elements **B.23**
 - load jam elements **B.23**
 - load loss **B.24**
 - Loss-of-Potential (LOP) **4.30**
 - overcurrent elements **B.21**
 - overvoltage elements **B.22**
 - phase reversal **B.20**
 - power factor elements **B.22**
 - reactive power elements **B.25**
 - speed switch **B.25**
 - start logic **B.14**
 - stop/trip logic **B.13**
 - underpower elements **B.18**
 - undervoltage elements **B.18**
- phase rotation **4.4**
- wiring
 - analog output **2.12**
 - delta voltages **2.6**
 - EIA-485 serial port **2.15**
 - factory default
 - contact input **2.11**
 - contact output **2.9**
 - four-wire wye voltages **2.5**
 - ground CT **2.5**
 - motor starting **2.11**
 - residual IN connection **2.6**
 - RTD inputs **2.13**
 - single phase-to-neutral
 - voltage **2.7**
 - single phase-to-phase voltage **2.6**
 - test connections **7.5**, **7.6**
 - trip contact failsafe **2.10**

Dimensions

- cut & drill **2.1**
- mechanical **2.1**

Direct Trip

- contact input **2.11**

Display

- HMI (SEL-5030) **3.10**

Display Message

- control equations **B.9**
- default display **5.2**
- settings **4.33**

E

- EIA-232 Port
 - See Serial Port, EIA-232
- EIA-485 Port
 - See Serial Port, EIA-485
- Emergency Restart
 - contact input **2.12**
 - front-panel function **5.7**
 - impact on antibackspin **4.35**
 - impact on antijogging **4.19**
 - logic **B.15**
- Energy Meter **8.4**
 - front-panel function **5.11**
 - serial port command **6.11**
- EVENT Command **6.9**
- Event History
 - See History
- Event Report **9.4**
 - clearing the buffer **9.8**
 - column definitions **9.6**
 - example **9.10**
 - factory tripping logic **4.38**
 - retrieval **9.5**
 - TRIGGER command **6.20**
 - trigger control equation **B.16**
 - triggering conditions **9.4**
 - unfiltered **9.8**
- Event Summary **9.3**

F

- Factory Assistance **10.9**
- Factory Default
 - contact input
 - configuration **2.11–2.12**
 - logic diagram **4.37**
 - wiring diagram **2.11**
 - contact output
 - logic diagram **4.37**
 - wiring diagram **2.9**, **2.11**
 - event triggering **4.38**
 - settings **4.1**, **F.1**
 - logic settings **B.8**
 - password **5.5**
 - tripping logic **4.36**
- Fail-Safe
 - See Contact Outputs
- Failure Messages **10.2**
- Falling-Edge [\] Operator **B.7**
- Fast Binary Messages **D.1**
 - See also Fast Operate, Fast Meter
 - message definitions **D.2**
- Fast Meter
 - A5B9 **D.8**
 - A5C1 **D.3**
 - A5C2 **D.6**
 - A5C3 **D.6**
 - A5D1 **D.6**
 - A5D2 **D.8**
 - A5D3 **D.8**
 - binary commands **D.1**

Fast Operate

- A5CE **D.9**
- A5E0 **D.10**
- A5E3 **D.10**
- binary commands **D.1**
- enable setting **4.39**
- Firmware Upgrade **10.6**
 - instructions **10.7**
- Firmware Versions **A.1**
- Frequency
 - measurement **2.14**
 - meter **8.1**
 - tracking **2.14**
- Frequency Elements **4.32**
 - logic diagram **B.23**
 - overfrequency
 - glossary entry **GL.5**
 - underfrequency
 - glossary entry **GL.6**
- Front Panel
 - See also Pushbuttons
 - access levels **5.4**
 - automatic messages **5.3**, **9.2**
 - configuration settings **4.33**
 - diagram **5.1**, **5.3**
 - display brightness **4.33**
 - display message settings **4.33**
 - failure messages **10.2**
 - function **5.13**
 - menus **5.3**
 - emergency restart **5.7**
 - front-panel function **5.11**
 - history data **5.12**, **9.3**
 - main menu **5.7**
 - meter values **5.11**
 - motor statistics **5.13**
 - pulse output contact **5.15**
 - reset learned parameters **5.15**
 - reset thermal model **5.15**
 - reset trip/targets **5.8**
 - set relay **5.8**
 - front serial port **5.10**
 - rear serial port **5.10**
 - relay date **5.10**
 - relay elements **5.9**
 - relay password **5.11**
 - relay time **5.11**
 - SER function **5.9**
 - start motor **5.7**
 - status of relay **5.14**
 - stop motor **5.8**
 - view relay word **5.14**
 - See also TARGET Command
- password entry **5.4**
- pushbuttons **5.1**, **5.4**
- removal **10.6**
- rotating message display **5.2**
- rotating meter display **5.2**
- target LEDs **9.1**

timeout **4.33**
trip messages **9.2**
Functional Overview **B.2**
Functional Tests **7.5**
analog output **7.8**
current
neutral **7.7**
phase **7.6**
unbalance **7.7**
power & power factor **7.12**
RTD accuracy **7.9**
test connections **7.5**
thermal element **7.8**
Fuse
ratings **2.7**
replacement **10.5**

G

Ground CT
application example **4.18**
placement **2.8**
wiring diagram **2.5**

H

HELP Command **6.7**
History
command **6.9**
front-panel function **5.12**
history data **9.3**
serial port command **6.9**

I

Installation **2.1–2.15**
See also Commissioning Procedure
diagram **2.2**
Instantaneous Meter **8.2**
front-panel function **5.11**
serial port command **6.10**

J

Jogging Block Elements **4.19**

L

LDP (Load Profile) Command **6.10**
Learned Parameters
cooling time **4.17**
reset using front panel **5.15**
starting thermal capacity **4.16**
view using
front panel **6.13**, **8.6**
MOTOR command **6.13**, **8.6**
LEUSE **B.8**
Load Jam Element **4.19**
glossary entry **GL.4**
logic diagram **B.23**
Load Loss Element **4.20**
glossary entry **GL.4**
logic diagrams **B.24**
voltage option
with **4.20**
without **4.20**

Load Profile **8.5**
LDP command **6.10**, **8.5**
Lockout Conditions **B.12**
Logic Diagrams
See Diagrams, logic
Loss-of-Potential (LOP) **4.31**

M

Maintenance
routine checks **10.1**
self-testing **10.2**
Max/Min Meter **8.3**
front-panel function **5.11**
serial port command **6.11**
Menus
See Front Panel, menus
Meter
apparent power **5.11**, **6.10**, **6.11**, **8.2**, **8.2**, **8.3**
command **6.10**
current **5.11**, **6.11**, **8.2**, **8.3**
unbalance **5.11**, **6.10**, **8.2**
demand **5.11**, **6.11**, **8.2**
energy **5.11**, **6.11**, **8.4**
frequency **5.11**, **6.10**, **8.2**
front-panel menu **5.11**
instantaneous **5.11**, **6.10**, **8.2**
max/min **5.11**, **6.11**, **8.3**
power **5.11**, **6.10**, **6.11**, **8.2**, **8.2**, **8.3**
power factor **5.11**, **6.10**, **8.2**
reactive power **5.11**, **6.10**, **6.11**, **8.2**, **8.2**, **8.3**
resetting quantities **5.11**, **6.12–6.13**
RTD **5.11**, **6.12**, **8.3**
serial port command **6.10**
starts this hour **5.11**, **6.12**
temperature **5.11**, **6.11**, **6.12**, **8.3**, **8.3**
thermal **5.11**, **6.12**, **8.3**
thermal capacity **5.11**, **6.12**, **8.3**
time since last start **5.11**, **6.12**, **8.3**
time to thermal trip **5.11**, **6.12**, **8.3**
voltage **5.11**, **6.10**, **6.11**, **8.2**, **8.3**

Modbus

01h read coil status **C.3**
02h read input status **C.3**
03h read holding registers **C.4**
04h read input registers **C.5**
05h force single coil **C.5**
06h preset single register **C.6**
07h read exception status **C.6**
08h loopback diagnostic **C.7**
10h preset multiple registers **C.7**
controlling
contact outputs **C.8**
remote bits **C.8**
cyclical redundancy check **C.3**
EIA-485 port **2.14**
event data **C.10**
exception responses **C.2**
function codes **C.2**

protocol description **C.1**
protocol setting **4.38**
register map **C.11**
self-test status **C.9**
settings **4.39**
user map **4.39**
user region **C.10**

MOTOR Command 6.13

Motor Example

3000 HP **4.7**
600 HP **4.7**
800 HP **4.7**

Motor Ratings

cooling time **4.16**
nameplate **4.2**

Motor Start Report 3.10, 8.8

MSR command 6.13

start

count **8.8**
data **8.8**
summary data **8.8**

Motor Start Trend 8.9

MST command 6.13

Motor Starts Count

motor start report **8.8**
motor start trend **8.9**
motor statistics **6.13**, **8.6**

Motor Statistics 5.13, 8.6

alarm & trip counters **8.7**
average & peak data **8.6**
front-panel function **8.6**
learned parameters **8.6**

MOTOR serial port command **6.13**, **8.6**

operating times **8.6**

Motor Thermal Element

See also Thermal Element
glossary entry **GL.4**

Mounting 2.2

torque spec **2.2**

MSR Command 6.13

MST Command 6.13

N

NOT [!] Operator **B.8**

O

Operating Times

See Motor Statistics

OR [+] Operator B.6

Overcurrent Elements 4.17

logic diagram **B.21**
negative-sequence **4.19**
neutral **4.18**
application example **4.18**
glossary entry **GL.5**
phase **4.17**
residual **4.18**, **4.18**

P

- Parentheses [()] Operator **B.7**
- Part Number **1.5**
 - creation **1.6**
 - table 1.3, **1.6**
- Password
 - command **6.14**
 - factory default **5.5**
 - front panel
 - change **5.4, 5.11**
 - entry **5.4, 5.11**
 - serial port command **6.14**
- Peak Data
 - See Motor Statistics
- Phase Reversal Tripping **4.22**
 - glossary entry **GL.5**
 - logic diagram **B.20**
- Phase Rotation
 - phasor diagram **4.4**
 - setting, PHROT **4.4**
- Power
 - See also Meter
 - average running **8.6**
 - demand **8.2**
 - front-panel display **4.33**
 - functional test **7.12**
 - meter **8.2**
 - underpower element
 - glossary entry **GL.7**
- Power Factor
 - See also Meter
 - elements **4.31**
 - logic diagram **B.22**
 - functional test **7.12**
 - meter **8.2**
- Power Factor Measurement
 - Convention **8.4**
- Power Measurement Convention **8.4**
- Power Supply
 - fuse ratings 2.7
 - operating range 2.7
- Processing Order **B.2**
- PULSE Command **6.14**
- Pulse Output Contact **5.15**
 - See also PULSE Command
- Pushbuttons
 - activate display **5.2, 5.6**
 - diagram **5.3**
 - functions **5.4**

Q

- QUIT Command **6.15**

R

- Reactive Power
 - average running **8.6**
 - demand **8.2**
 - elements **4.30**
 - element logic diagram **B.25**
 - glossary entry **GL.5**
 - meter **8.2**

- Reactive Power Measurement
 - Convention **8.4**
- Real Power
 - See Power
- Rear Panel
 - diagram **2.3**
- Relay Enabled LED
 - normal operation 5.2
- Relay Models **1.3**
 - See also Part Number
- Relay Word **B.3**
 - bit definitions **B.3**
 - table **B.3**
- Relay Word Bits
 - See also Relay Word
 - definitions **B.3**
- Remote Bits **B.17**
 - CONTROL command **6.8**
 - Modbus control **C.8**
- Reset Learned Parameters **5.15**
 - RLP command **6.15**
- Reset Meter Values
 - reset targets **9.2**
 - serial port commands 6.12–6.13
 - using front panel 5.11
- Reset Targets **9.2**
- Resistance Temperature Device (RTD)
 - See also Meter
 - alarm temperatures 4.25
 - biasing 4.25, **4.26**
 - connections **2.12**
 - failure messages **8.3**
 - functional test **7.9**
 - location settings **4.23**
 - ambient **4.24**
 - bearing **4.24**
 - other **4.24**
 - winding **4.24**
 - temperature
 - analog output 4.32
 - average **8.6**
 - display **4.33**
 - temperature vs. resistance table **4.27**
 - thermal meter 5.11
 - trip temperatures **4.25**
 - trip voting 4.25, **4.26**
 - tripping logic **4.36**
 - type settings **4.24**
 - available types **4.25**
 - wiring diagram, relay 2.13
- Retrieve
 - event **3.8**
- Rising-Edge [/] Operator **B.7**
- RLP Command **6.15**
- Routine Maintenance
 - See Maintenance
- Running
 - LED indication **9.2**

S

- Safety Ground
 - See Chassis Ground
- SEL-2600 Series RTD Module **2.15**
 - contact input 4.22
 - failure messages **8.3**
 - fiber-optic connections 2.15
 - RTD connections 2.15
 - RTD-based protection **4.23**
 - update rate 4.22
- Self-Testing **10.2**
 - See also STATUS Command; Status of Relay
 - self-test table **10.2**
- SELOGIC Control Equations **B.6**
 - ACCESS2 logic **B.15**
 - AND [*] operator **B.6**
 - breaker auxiliary **B.14**
 - contact output contact **B.16**
 - display message equations **B.9**
 - event trigger **B.16**
 - factory default settings **B.8**
 - falling-edge [/] operator **B.7**
 - latch variables **B.10**
 - LEUSE **B.8**
 - limitations **B.8**
 - nondedicated variables **B.10**
 - NOT [!] operator **B.8**
 - operators **B.6**
 - OR [+] operator **B.6**
 - parentheses [()] operator **B.7**
 - remote bits **B.17**
 - rising-edge [/] operator **B.7**
 - speed switch logic **B.16**
 - start and emergency restart
 - logic **B.14**
 - Stop/Trip logic **B.12**
- Sequential Events Recorder **4.39, 9.8**
 - alias settings **4.41, 9.9**
 - clearing the buffer **9.10**
 - example report **9.12**
 - front-panel setting entry **5.9**
 - retrieving reports **9.9**
 - SER Command **6.15**
 - SER Report **9.10**
 - trigger settings **4.40, 9.8**
- SER Command **6.15**
- Serial Number Label **1.7**
- Serial Ports
 - EIA-232
 - access levels **6.4**
 - automatic messages **6.21**
 - command summary **6.5**
 - communication cable **6.2**
 - connector pinout **6.2**
 - control characters **6.4**
 - factory default settings **6.3**
 - front panel 5.1
 - settings **4.38**

- EIA-485 **2.14**
 - Modbus protocol **C.1**
 - wiring diagram **2.15**
- SET Command **6.15**
- Set Relay
 - editing keystrokes **6.16**
 - SET Command **6.15**
 - using
 - front panel **5.8**
- Help
 - ACSELERATOR QuickSet SEL-5030 Software 3.11
- Settings
 - See also
 - SELOGIC Control Equations;
 - ACSELERATOR QuickSet
 - SEL-5030 Software
 - application data **4.2**
 - calculation 4.1
 - locked rotor amps **4.6**
 - setting names
 - 27PIP **4.28**
 - 27P2P **4.28**
 - 37DLY **4.31**
 - 37PAD **4.31**
 - 37PAP **4.31**
 - 37PTD **4.31**
 - 37PTP **4.31**
 - 46UBA **4.21**
 - 46UBAD **4.21**
 - 46UBT **4.21**
 - 46UBTD **4.21**
 - 50G1D **4.17**
 - 50G1P **4.17**
 - 50G2D **4.17**
 - 50G2P **4.17**
 - 50N1D **4.17**
 - 50N1P **4.17**
 - 50N2D **4.17**
 - 50N2P **4.17**
 - 50P1D **4.17**
 - 50P1P **4.17**
 - 50P2D **4.17**
 - 50P2P **4.17**
 - 50QD **4.17**
 - 50QP **4.17**
 - 55AD **4.31**
 - 55DLY **4.31**
 - 55LDAP **4.31**
 - 55LDTP **4.31**
 - 55LGAP **4.31**
 - 55LGTP **4.31**
 - 55TD **4.31**
 - 59GP **4.28**
 - 59PIP **4.28**
 - 59P2P **4.28**
 - 81D1D **4.32**
 - 81D1P **4.32**
 - 81D2D **4.32**
 - 81D2P **4.32**
 - 81D3D **4.32**
 - 81D3P **4.32**
 - ABSDLY **4.35**
 - ALIAS1-ALIAS20 **4.42**
 - ALTMP1-ALTMP12 **4.25**
 - AOFSC **4.32**
 - AOPARM **4.32**
 - AOSIG **4.32**
 - AUTO **4.38**
 - BITS **4.38**
 - COOLEN **4.16**
 - COOLTIME **4.16**
 - CTR **4.3**
 - CTRN **4.3**
 - CURVE **4.8**
 - DATE_F 6.15, 9.9
 - DELTA_Y **4.4**
 - DMI_1-DM6_0 **4.33**
 - DMTC 8.2
 - E47T **4.22**
 - EALIAS **4.41**
 - EBRNGV **4.25**
 - EWNDGV **4.25**
 - FACTLOG **4.35**
 - FASTOP **4.38**
 - FLA 4.7, 4.8, 4.11, 4.20, 9.2
 - FP_KW **4.33**
 - FP_RTD **4.33**
 - FP_TO **4.33**
 - FPBRITE **4.33**
 - INTAP **4.3**
 - ITAP **4.3**
 - LLADLY 4.20
 - LLAPU 4.20
 - LLSDLY 4.20
 - LLTDLY 4.20
 - LLTPU 4.20
 - LRTCOLD **4.7**
 - LRTHOT **4.7**
 - MAXSTART **4.19**
 - NVARAP **4.30**
 - NVARTP **4.30**
 - OUT1FS **4.34**
 - OUT2FS **4.34**
 - OUT3FS **4.34**
 - PARITY 4.38, 4.39
 - PHROT **4.3**, 4.4
 - PROTO 4.38, 4.39
 - PTR **4.4**
 - PVARAP **4.30**
 - PVARTP **4.30**
 - RID **4.3**
 - RTD1LOC-RTD12LOC **4.23**, **4.24**
 - RTDBEN **4.25**
 - RTDOPT **4.23**
 - RTSCTS **4.38**
 - SER1-SER4 **4.40**
 - SETMETH 4.7, 4.8, 4.11
 - SF 4.7, 4.8, 4.11
 - SINGLE_V **4.4**
 - SLAVEID **4.39**
 - SPDSPLY **4.22**
 - SPEED 4.38, 4.39
 - STOP **4.38**
 - T_OUT **4.38**
 - TBSDLY **4.19**
 - TCAPU **4.15**
 - TCLRNEN **4.15**
 - TCSTART **4.15**
 - TD **4.7**
 - TDURD **4.34**, B.12
 - TID **4.3**
 - TMPREF **4.23**
 - TRFS **4.34**
 - TRTMP1-TRTMP12 **4.25**
 - TTT105-TTT1000 **4.11**
 - VARAD **4.30**
 - VARDLY **4.30**
 - VARTD **4.30**
 - setting prompts
 - analog output full scale
 - current **4.32**
 - analog output parameter **4.32**
 - analog output signal type **4.32**
 - antibackspin starting delay **4.35**
 - baud rate 4.38, 4.39
 - cold locked rotor time **4.7**
 - current unbalance alarm
 - delay **4.21**
 - current unbalance alarm pickup **4.21**
 - current unbalance trip
 - pickup **4.21**
 - curve number **4.8**
 - data bits **4.38**
 - date format 6.15, 9.9
 - demand meter time constant 8.2
 - display messages **4.33**
 - enable ALIAS settings **4.41**
 - enable bearing trip voting **4.25**
 - enable hardware
 - handshaking **4.38**
 - enable OUT1 contact fail-safe **4.34**
 - enable OUT2 contact fail-safe **4.34**
 - enable OUT3 contact fail-safe **4.34**
 - enable phase reversal
 - tripping **4.22**
 - enable RTD biasing **4.25**
 - enable trip contact fail-safe **4.34**
 - enable winding trip voting **4.25**
 - fast operate enable **4.38**
 - front-panel display
 - brightness **4.33**
 - front-panel power display **4.33**
 - front-panel RTD display **4.33**
 - front-panel timeout **4.33**
 - full load amps 4.7, 4.8, 4.11, 4.20, 9.2

- hot locked rotor time **4.7**
- level 1 neutral O/C pickup **4.17**
- level 1 neutral O/C time
 - delay **4.17**
- level 1 overvoltage pickup **4.28**
- level 1 phase O/C pickup **4.17**
- level 1 phase O/C time
 - delay **4.17**
- level 1 pickup **4.32**
- level 1 residual O/C pickup **4.17**
- level 1 residual O/C time
 - delay **4.17**
- level 1 time delay **4.32**
- level 1 undervoltage pickup **4.28**
- level 2 neutral O/C pickup **4.17**
- level 2 neutral O/C time
 - delay **4.17**
- level 2 overvoltage pickup **4.28**
- level 2 phase O/C pickup **4.17**
- level 2 phase O/C time
 - delay **4.17**
- level 2 pickup **4.32**
- level 2 residual O/C pickup **4.17**
- level 2 residual O/C time
 - delay **4.17**
- level 2 time delay **4.32**
- level 2 undervoltage pickup **4.28**
- level 3 pickup **4.32**
- level 3 time delay **4.32**
- load loss alarm threshold **4.20**
- load loss alarm time delay **4.20**
- load loss starting delay **4.20**
- load loss starting time delay **4.20**
- load loss trip threshold **4.20**
- load loss trip time delay **4.20**
- locked rotor trip time dial **4.7**
- maximum number of starts per
 - hour **4.19**
- minimum time between
 - starts **4.19**
- minimum trip duration
 - time **4.34**, **B.12**
- Modbus slave ID **4.39**
- motor stopped cooling time **4.16**
- negative VAR alarm pickup **4.30**
- negative VAR trip pickup **4.30**
- negative-sequence O/C
 - pickup **4.17**
- negative-sequence O/C time
 - delay **4.17**
- neutral (IN) CT ratio **4.3**
- neutral CT secondary rating **4.3**
- parity **4.38**, **4.39**
- phase (IA, IB, IC) CT ratio **4.3**
- phase (VA, VB, VC) VT
 - ratio **4.4**
- phase CT secondary rating **4.3**
- phase rotation **4.3**, **4.4**
- phase underpower alarm
 - pickup **4.31**

- phase underpower alarm time
 - delay **4.31**
- phase underpower trip
 - pickup **4.31**
- phase underpower trip time
 - delay **4.31**
- phase VT connection **4.4**
- positive VAR alarm pickup **4.30**
- positive VAR trip pickup **4.30**
- power factor alarm lagging
 - pickup **4.31**
- power factor alarm leading
 - pickup **4.31**
- power factor alarm time
 - delay **4.31**
- power factor element arming
 - delay **4.31**
- power factor trip lagging
 - pickup **4.31**
- power factor trip leading
 - pickup **4.31**
- power factor trip time delay **4.31**
- protocol **4.38**, **4.39**
- relay identifier **4.3**
- residual overvoltage pickup **4.28**
- RTD alarm temperature **4.25**
- RTD input option **4.23**
- RTD location **4.23**, **4.24**
- RTD trip temperature **4.25**
- send auto messages to port **4.38**
- SER alias settings **4.42**
- SER trigger settings **4.40**
- service factor **4.7**, **4.8**, **4.11**
- setting method **4.7**, **4.8**, **4.11**
- single voltage input **4.4**
- speed switch trip time delay **4.22**
- stop bits **4.38**
- temperature preference
 - setting **4.23**
- terminal identifier **4.3**
- thermal capacity alarm
 - pickup **4.15**
- thermal capacity used to
 - start **4.15**
- time to trip **4.11**
- timeout **4.38**
- underpower element arming
 - delay **4.31**
- use factory logic settings **4.35**
- use learned cooling time **4.16**
- use learned starting thermal
 - capacity **4.15**
- VAR alarm time delay **4.30**
- VAR element arming delay **4.30**
- VAR trip time delay **4.30**

Short Circuit

- See Overcurrent Elements

SHOW Command **6.16**

Side Panel

- diagrams **2.4**

Software (ACSELERATOR QUICKSET) **3.1**

- databases **3.4**
- device editor **3.7**
- Human Machine Interface (HMI) **3.10**
- settings editor **3.5**

Speed Switch

- contact input **2.11**, **2.11**
- control equation **B.16**
- logic diagram **B.25**
- tripping function **4.22**

Start Motor

- front-panel function **5.7**
- logic **B.14**
- STR command **6.19**

Starting

- See also Motor Start Report; Motor Start Trend
- current **8.8**
 - average **8.6**
- LED indication **9.2**
- minimum voltage **8.8**
 - average **8.6**
- start report **3.10**
- thermal capacity **8.8**
- time **8.8**
 - average **8.6**

Starts Per Hour **4.19**

- lockout **B.13**
- meter **5.11**, **6.12**, **8.3**
- protection **4.19**

STATUS Command **6.18**

Status of Relay

- See also STATUS Command
- front-panel function **5.14**

STOP Command **6.19**

Stop Motor

- front-panel function **5.8**
- STOP command **6.19**

Stopped

- LED indication **9.2**

STR Command **6.19**

T

TARGET Command **6.19**

Target LEDs

- definitions **9.1**
- diagram **5.1**
- reset
 - See Target Reset
- viewed using TARGET command **6.19**

Target Reset

- front-panel function **5.8**
- reset targets **9.2**

Temperature

- See also Resistance Temperature Device (RTD)
- self-test **4.39**

Terminal Emulation

- default configuration **6.3**

- Test Signals
 - connection check **7.3**
 - Thermal & RTD Meter **8.3**
 - front-panel function **5.11**
 - serial port command **6.12**
 - % Thermal Capacity
 - analog output **4.32**
 - interpreting values **E.9**
 - RTD **4.26**
 - thermal element **4.6**
 - Thermal Capacity
 - See also % Thermal Capacity
 - alarm setting **4.15**
 - average & peak values **8.6**
 - learned starting **4.16**
 - meter **5.11**, **6.12**, **8.3**
 - required to start **4.15**, **E.9**
 - RTD % thermal capacity **4.26**
 - starting **8.8**, **8.9**
 - Thermal Element **4.6–4.17**
 - alarm **4.15**
 - front-panel reset **5.15**
 - functional test **7.8**
 - generic curves, figure **4.9**
 - generic curves, table **4.10**
 - generic method **4.6**, **4.8**
 - lockout **B.13**
 - motor cooling time **4.16**
 - rating method **4.6**, **4.6**
 - example **4.7**
 - RTD biasing **4.26**
 - setting examples
 - locked rotor trip time dial **4.8**
 - rating method **4.7**
 - user method **4.14**
 - setting methods **4.6**
 - starting protection **E.6**, **E.7**
 - theoretical description **E.1**
 - user method **4.6**, **4.11**
 - example **4.14**
 - Thermal Element Biasing **4.26**
 - Thermal Limit
 - generic curves, figure **4.9**
 - time per curve **4.8**
 - Thermal Model
 - See Thermal Element
 - Thermistors **2.12**
 - Thermocouples **2.12**
 - Time Between Starts
 - lockout **B.12**
 - meter **5.11**, **6.12**, **8.3**
 - protection **4.19**
 - TIME Command **6.20**
 - Time to Thermal Trip
 - meter **5.11**, **6.12**, **8.3**
 - Torque
 - mounting nut spec **2.2**
 - TRIGGER Command **6.20**
 - Trip Contact
 - fail-safe operation **4.34**
 - minimum duration timer **4.34**
 - wiring diagrams **2.10**
 - Trip Counters **8.7**
 - Trip Logic
 - factory default **4.36**
 - Trip Reset
 - front-panel function **5.8**
 - Trip Voting **4.26**
 - Troubleshooting Procedure **10.4**
 - Typographic Conventions **1.2**
- U**
- Unbalance Current
 - See Current, unbalance
 - Underpower Element **4.31**
 - logic diagram **B.18**
 - Upgrade
 - See Firmware Upgrade
- V**
- View Relay Word
 - See TARGET Command
 - Voltage-Based Protection **4.28**
 - frequency elements **4.32**
 - overvoltage elements **4.28**
 - logic diagram **B.22**
 - power factor elements **4.31**
 - reactive power (VAR) elements **4.30**
 - relay models **4.28**
 - tripping logic **4.36**
 - underpower elements **4.31**
 - undervoltage elements **4.28**
 - logic diagram **B.18**
 - Voltages
 - See also Metering
 - configuration settings **4.4**
 - connections **2.14**
 - delta
 - wiring diagram **2.6**
 - four-wire wye
 - wiring diagram **2.5**
 - phase-to-neutral voltage
 - elements **4.28**
 - phase-to-phase voltage
 - elements **4.28**
 - protection elements **4.28**
 - single phase-to-neutral
 - wiring diagram **2.7**
 - single phase-to-phase
 - wiring diagram **2.6**
 - starting **8.8**, **8.9**
- W**
- Wiring Diagrams
 - 4-wire wye voltages **2.5**
 - contact inputs **2.11**
 - contact output **2.9**
 - delta voltages **2.6**
 - EIA-485 port **2.15**
 - ground CT **2.5**
 - motor starting **2.11**
 - residual IN connection **2.6**
 - RTD connections, relay **2.13**
 - side panel **2.4**
- single phase-to-neutral voltage **2.7**
 - single phase-to-phase voltage **2.6**
 - trip contact **2.10**

ZZ number **3.7**

This page intentionally left blank

SEL-701 Relay Command Summary

The table below lists the serial port commands associated with particular activities. All Access Level 1 commands are also available in Access Level 2. The commands are shown in uppercase letters, but can also be entered with lowercase letters.

Serial Port Command	Command Description
Access Level 1 Commands	
2ACCESS	Go to Access Level 2
CEV <i>n</i>	Display compressed event report, 15 cycles (<i>n</i> is the event report)
CEV <i>n</i> R	Display compressed event report with raw (unfiltered) data, 16 cycles
DATE	View/change date
EVENT	View event reports
HELP	Display available commands
HISTORY	View event summaries/histories
LDP	Display load profile data
LDP D	Display load profile buffer size
METER	Display metering data
METER D	Display demand and peak demand data
METER E	Display energy metering data
METER M	Display max/min metering data
METER T	Display thermal metering data
METER RD	Reset demand ammeter
METER RE	Reset energy metering
METER RM	Reset max/min metering
METER RP	Reset peak demand ammeter
MOTOR	Display motor statistics
MSR	Display motor start reports
MSR F	Display the format of a motor start report
MST	Display motor start trend data
SER	View sequential events recorder data
SHOW	Show/view relay settings
STATUS	Display relay self-test status
TARGET	Display relay element status
TARGET R	Reset target LEDs
TIME	View/change time
TRIGGER	Trigger an event report

Serial Port Command	Command Description
Access Level 2 Commands	
ACCESS	Go to Access Level 1
ANALOG	Test analog output
CAL	Enter Access Level C. If the mainboard Access jumper is not in place, the relay prompts for the entry of the Access Level C password. Access Level C is reserved for SEL use only.
CON	Control remote bit
HISTORY R	Reset event history data
LDP R	Reset load profile data
MOTOR R	Reset motor statistics
MST R	Reset motor start trend data
PASSWORD	View/change password
PUL	Pulse output contact
QUIT	Go to Access Level 1
RLP	Reset learned motor parameters
SER R	Reset sequential events recorder data
SET	Enter/change relay settings
STATUS R	Clear self-test status and restart relay
STOP	Stop motor
STR	Start motor
Access Level C Commands	
PAS C	Change Access Level C password

SEL-701 Relay Command Summary

The table below lists the serial port commands associated with particular activities. All Access Level 1 commands are also available in Access Level 2. The commands are shown in uppercase letters, but can also be entered with lowercase letters.

Serial Port Command	Command Description
Access Level 1 Commands	
2ACCESS	Go to Access Level 2
CEV <i>n</i>	Display compressed event report, 15 cycles (<i>n</i> is the event report)
CEV <i>n</i> R	Display compressed event report with raw (unfiltered) data, 16 cycles
DATE	View/change date
EVENT	View event reports
HELP	Display available commands
HISTORY	View event summaries/histories
LDP	Display load profile data
LDP D	Display load profile buffer size
METER	Display metering data
METER D	Display demand and peak demand data
METER E	Display energy metering data
METER M	Display max/min metering data
METER T	Display thermal metering data
METER RD	Reset demand ammeter
METER RE	Reset energy metering
METER RM	Reset max/min metering
METER RP	Reset peak demand ammeter
MOTOR	Display motor statistics
MSR	Display motor start reports
MSR F	Display the format of a motor start report
MST	Display motor start trend data
SER	View sequential events recorder data
SHOW	Show/view relay settings
STATUS	Display relay self-test status
TARGET	Display relay element status
TARGET R	Reset target LEDs
TIME	View/change time
TRIGGER	Trigger an event report

Serial Port Command	Command Description
Access Level 2 Commands	
ACCESS	Go to Access Level 1
ANALOG	Test analog output
CAL	Enter Access Level C. If the mainboard Access jumper is not in place, the relay prompts for the entry of the Access Level C password. Access Level C is reserved for SEL use only.
CON	Control remote bit
HISTORY R	Reset event history data
LDP R	Reset load profile data
MOTOR R	Reset motor statistics
MST R	Reset motor start trend data
PASSWORD	View/change password
PUL	Pulse output contact
QUIT	Go to Access Level 1
RLP	Reset learned motor parameters
SER R	Reset sequential events recorder data
SET	Enter/change relay settings
STATUS R	Clear self-test status and restart relay
STOP	Stop motor
STR	Start motor
Access Level C Commands	
PAS C	Change Access Level C password