



Transforms the C64 JoyKEY into a gamepad for the Nintendo Entertainment System.
SELECT is placed on the third fire button, START placed on adapter itself or recent JoyKEY.

Sheet: /
File: NES.sch

Title: NES Adapter (C64 JoyKEY)

Size: A4
KiCad E.D.A. kicad (5.1.8)-1

Date:
Rev: A
Id: 1/1