




Periodic cleaning and inspection should be standard procedure.
This should be done after EVERY use.

1

Pull piston complete with collar out of barrel. Remove any dirt, sand or water.




2

Inspect for any signs of damage.
Be sure to check the following:




Nipple and Air Ports in barrel.
Make sure there is no debris blocking any air holes.



Make sure threads on collar and T-handles are free of dirt and debris.

3

Check the rubber cup attached to the bottom of the piston. It should be secure and round. Every 2-3 months "flare" out the rubber cup by hand.
This will help the cup retain its shape.
Periodically spray the cup with a non-petroleum based silicon.



- 4 Clean strut by wiping, washing or steam cleaning. DO NOT immerse piston cup rubber cup in solvents or petroleum based products.
- 5 Assemble piston and barrel.
- 6 Pull piston up and down to assure free, smooth movement.
- 7 Clean and inspect all accessories and base. Ensure all adjusting screws, bolts, pins and connectors are in place and in good working order.



Hurst Jaws of Life®
Hale Products, Inc.
A Unit of IDEX Corporation
711 North Post Road
Shelby, NC 28150
Tel: 704-687-5961
Fax: 704-687-7271
Internet: www.hurstjaws.com