



Português

01F14	Fusível de ignição	H17
01K01	Relé de descarga do terminal 15	K8
01K05	Chave geral da bateria	K5
01K09	Relé de descarga do terminal 15	K10
03K02	Relé do interruptor principal do sistema de emergência	K3
01S04	Chave de ignição	B10
10S01	Interruptor de bloqueio da partida na tampa traseira	k13
X2811	Conexão para encarroçador	k15
A	Válido para sistema de emergência	E3
B	Válido para relé eletromagnético sem sistema de emergência	E5

Español

01F14	Fusible de ignición	H17
01K01	Relé de descarga del terminal 15	K8
01K05	Llave general de la batería	K5
01K09	Relé de descarga del terminal 15	K10
03K02	Relé del interruptor principal del sistema de emergencia	K3
01S04	Llave de ignición	B10
10S01	Interruptor de bloqueo del arranque en la tapa trasera	k13
X2811	Conexión para montaje de carrocería	k15
A	Válido para sistema de emergencia	E3
B	Válido para relé electromagnético sin sistema de emergencia	E5

English

01F14	Ignition fuse	H17
01K01	Terminal 15 relief relay	K8
01K05	Battery main switch	K5
01K09	Terminal 15 relief relay	K10
03K02	Main isolate switch relay emergency system	K3
01S04	Ignition switch	B10
10S01	Engine compartment interlock switch	k13
X2811	Spare connector for body builder	k15
A	Valid for emergency system	E3
B	Valid for electromagnetic relay without emergency system	E5

Interruptor de ignição
Interruptor de ignición
Ignition switch

PE15.30-B-2025BB