

DS2003 High-Speed A/D Board

# RTI Reference

Release 2021-A – May 2021

## How to Contact dSPACE

Mail:	dSPACE GmbH Rathenaustraße 26 33102 Paderborn Germany
Tel.:	+49 5251 1638-0
Fax:	+49 5251 16198-0
E-mail:	<a href="mailto:info@dspace.de">info@dspace.de</a>
Web:	<a href="http://www.dspace.com">http://www.dspace.com</a>

## How to Contact dSPACE Support

If you encounter a problem when using dSPACE products, contact your local dSPACE representative:

- Local dSPACE companies and distributors: <http://www.dspace.com/go/locations>
- For countries not listed, contact dSPACE GmbH in Paderborn, Germany.  
Tel.: +49 5251 1638-941 or e-mail: [support@dspace.de](mailto:support@dspace.de)

You can also use the support request form: <http://www.dspace.com/go/supportrequest>. If you are logged on to mydSPACE, you are automatically identified and do not need to add your contact details manually.

If possible, always provide the relevant dSPACE License ID or the serial number of the CmContainer in your support request.

## Software Updates and Patches

dSPACE strongly recommends that you download and install the most recent patches for your current dSPACE installation. Visit <http://www.dspace.com/go/patches> for software updates and patches.

## Important Notice

This publication contains proprietary information that is protected by copyright. All rights are reserved. The publication may be printed for personal or internal use provided all the proprietary markings are retained on all printed copies. In all other cases, the publication must not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of dSPACE GmbH.

© 1999 - 2021 by:  
dSPACE GmbH  
Rathenaustraße 26  
33102 Paderborn  
Germany

This publication and the contents hereof are subject to change without notice.

AUTERA, ConfigurationDesk, ControlDesk, MicroAutoBox, MicroLabBox, SCALEXIO, SIMPHERA, SYNECT, SystemDesk, TargetLink and VEOS are registered trademarks of dSPACE GmbH in the United States or other countries, or both. Other brand names or product names are trademarks or registered trademarks of their respective companies or organizations.

# Contents

About This Reference	5
General Information on the DS2003 Blockset	9
Overview of the DS2003 Blockset.....	9
ADC Unit	11
DS2003_Bx.....	12
Block Description (DS2003_Bx).....	12
Unit Page (DS2003_Bx).....	13
Range Page (DS2003_Bx).....	14
Resolution Page (DS2003_Bx).....	14
Interrupts	17
DS2003_HWINT_Bx_Iy.....	18
Block Description (DS2003_HWINT_Bx_Iy).....	18
Unit Page (DS2003_HWINT_Bx_Iy).....	18
Index	21



# About This Reference

## Content

This RTI Reference provides a full description of the Real-Time Interface (RTI) software support for the DS2003 High-Speed A/D Board, which can be controlled by the DS1006 Processor Board and the DS1007 PPC Processor Board.

## Symbols

dSPACE user documentation uses the following symbols:

Symbol	Description
 <b>DANGER</b>	Indicates a hazardous situation that, if not avoided, will result in death or serious injury.
 <b>WARNING</b>	Indicates a hazardous situation that, if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.
 <b>NOTICE</b>	Indicates a hazard that, if not avoided, could result in property damage.
 <b>Note</b>	Indicates important information that you should take into account to avoid malfunctions.
 <b>Tip</b>	Indicates tips that can make your work easier.
	Indicates a link that refers to a definition in the glossary, which you can find at the end of the document unless stated otherwise.
	Precedes the document title in a link that refers to another document.

## Naming conventions

dSPACE user documentation uses the following naming conventions:

**%name%** Names enclosed in percent signs refer to environment variables for file and path names.

< > Angle brackets contain wildcard characters or placeholders for variable file and path names, etc.

Examples:

- Where you find terms such as `rti<XXXX>` replace them by the RTI platform support you are using, for example, `rti1007`.
- Where you find terms such as `<model>` or `<submodel>` in this document, replace them by the actual name of your model or submodel. For example, if the name of your Simulink model is `smd_1007_s1.slx` and you are asked to edit the `<model>_usr.c` file, you actually have to edit the `smd_1007_s1_usr.c` file.

**RTI block name conventions** All I/O blocks have default names based on dSPACE's board naming conventions:

- Most RTI block names start with the board name.
- A short description of functionality is added.
- Most RTI block names also have a suffix.

Suffix	Meaning
B	Board number (for PHS-bus-based systems)
M	Module number (for MicroAutoBox II)
C	Channel number
G	Group number
CON	Converter number
BL	Block number
P	Port number
I	Interrupt number

A suffix is followed by the appropriate number. For example, `DS2201IN_B2_C14` represents a digital input block located on a DS2201 board. The suffix indicates board number 2 and channel number 14 of the block. For more general block naming, the numbers are replaced by variables (for example, `DS2201IN_Bx_Cy`).

## Special folders

Some software products use the following special folders:

**Common Program Data folder** A standard folder for application-specific configuration data that is used by all users.

`%PROGRAMDATA%\dSPACE\<InstallationGUID>\<ProductName>`

or

%PROGRAMDATA%\dSPACE\<ProductName>\<VersionNumber>

**Documents folder** A standard folder for user-specific documents.

%USERPROFILE%\Documents\dSPACE\<ProductName>\<VersionNumber>

**Local Program Data folder** A standard folder for application-specific configuration data that is used by the current, non-roaming user.

%USERPROFILE%\AppData\Local\dSPACE\<InstallationGUID>\<ProductName>

---

## Accessing dSPACE Help and PDF Files


After you install and decrypt dSPACE software, the documentation for the installed products is available in dSPACE Help and as PDF files.

**dSPACE Help (local)** You can open your local installation of dSPACE Help:

- On its home page via Windows Start Menu
- On specific content using context-sensitive help via **F1**

**dSPACE Help (Web)** You can access the Web version of dSPACE Help at [www.dspace.com](http://www.dspace.com).

To access the Web version, you must have a *mydSPACE* account.

**PDF files** You can access PDF files via the  icon in dSPACE Help. The PDF opens on the first page.





# General Information on the DS2003 Blockset

## Overview of the DS2003 Blockset

### About this board


The DS2003 High-Speed A/D Board provides 32 A/D channels of 2 independent A/D converters. You can choose between various channel numbers, resolutions and speeds.

### RTI blockset

The Real-Time Interface (RTI) board library for the DS2003 Multi-Channel A/D Converter Board provides the RTI blocks that implement the functionality and I/O capabilities of the DS2003 board in Simulink models.

DS2003

After you double-click the corresponding board library icon in the library `rtlibm` the Library: `rtlibm/DS2003` opens:



The following I/O units can be accessed by the RTI blockset for the DS2003:

- [ADC Unit](#) on page 11
- [Interrupts](#) on page 17

### Demo model

For Simulink models, that shows how to use the RTI blocks of the DS2003 board, refer to the RTI demo library of your processor board. You can find the model files also at `<RCP_HIL_InstallationPath>\Demos\<ProcessorBoard>\RTI`.

Related topics

References

ADC Unit.....	11
Interrupts.....	17

# ADC Unit

---

<b>Objective</b>	The Library: rtilibm/DS2003 provides access to the ADC unit of the DS2003.
<b>Demo model</b>	For a demo model using the ADC unit, refer to <code>&lt;RCP_HIL_InstallationPath&gt;\Demos\&lt;ProcessorBoard&gt;\RTI\demom_ds2003_1.slx</code> . This is the DS2003, DS2102 model, which you can find in the processor board's RTI demo library.

---

## DS2003\_Bx


### Where to go from here

### Information in this section

Block Description (DS2003_Bx).....	12
Unit Page (DS2003_Bx).....	13
Range Page (DS2003_Bx).....	14
Resolution Page (DS2003_Bx).....	14

## Block Description (DS2003\_Bx)

### Block



### Purpose

To get access to up to 32 multiplexed channels of an A/D converter.

#### Note

Because the A/D conversion works in polling mode, do not specify an interrupt using the HWINT block. Otherwise the processor will be blocked. For further information, refer to [Limitations \(DS2003 Features !\[\]\(758ebdf4629c903da74c2e079717ae32\_img.jpg\)](#)).

### I/O mapping

For details on the I/O mapping, refer to [ADC Unit \(DS2003 Features !\[\]\(626ce8ac21792b9405bfddfea8e0c96a\_img.jpg\)](#)).

### I/O characteristics

- The scaling between the analog input voltage and the output of the block is:

Input Voltage Range	Simulink Output
$\pm 5$ V DC	$\pm 1.0$
$\pm 10$ V DC	$\pm 1.0$

- The width of the block output vector matches the number of selected channels.
- The DS2003 board uses two parallel A/D converters. The channels used are distributed automatically to the 2 converters in a way that achieves maximum performance with respect to the overall conversion time.

**Note**








When started, data conversion takes place for all selected channels. A second conversion must not be started until the first one has finished completely and all sampled data is read out. For this reason all channels must be sampled in a single task, and thus only one DS2003 block should be used in a Simulink model.

**Dialog pages**

The dialog settings can be specified on the following pages:

- [Unit Page \(DS2003\\_Bx\)](#) on page 13
- [Range Page \(DS2003\\_Bx\)](#) on page 14
- [Resolution Page \(DS2003\\_Bx\)](#) on page 14

**Related RTLib functions**

[ds2003\\_board\\_init](#) (DS2003 RTLib Reference ) , [ds2003\\_init\\_scantbl](#) (DS2003 RTLib Reference ) , [ds2003\\_set\\_range](#) (DS2003 RTLib Reference ) , [ds2003\\_set\\_trigger](#) (DS2003 RTLib Reference ) , [ds2003\\_set\\_wordlen](#) (DS2003 RTLib Reference ) , [ds2003\\_start](#) (DS2003 RTLib Reference ) , [ds2003\\_in](#) (DS2003 RTLib Reference )

## Unit Page (DS2003\_Bx)

**Purpose**

To specify the board number, and to select a set of channels.

**Dialog settings**

**Board number** Lets you select the board number in the range 1 ... 16. If your system contains several boards of the same type, RTI uses the board number to distinguish between them.

**Channel selection** Lets you select a set of up to 32 channels. To select all or none of the 32 channels, push the All or the None button, respectively.

**Related topics****References**

<a href="#">Block Description (DS2003_Bx)</a> .....	12
<a href="#">Range Page (DS2003_Bx)</a> .....	14
<a href="#">Resolution Page (DS2003_Bx)</a> .....	14

## Range Page (DS2003\_Bx)

---

**Purpose** To specify the input voltage range.

---

**Dialog settings**

**Configure channels** Lets you switch between channel sets (1 ... 8, 9 ... 16, ... ), for which you want to specify the input voltage range.

**Range** Lets you select the input voltage ranges of  $\pm 5$  V or  $\pm 10$  V for each channel of the specified channel set. To assign one input voltage range to all of the channels displayed, specify the desired value before pushing the Set all button.

**Note**

The range setting is only possible for the channels, that were specified on the Unit page.

---

**Related topics**

**References**

<a href="#">Block Description (DS2003_Bx)</a> .....	12
<a href="#">Resolution Page (DS2003_Bx)</a> .....	14
<a href="#">Unit Page (DS2003_Bx)</a> .....	13

## Resolution Page (DS2003\_Bx)

---

**Purpose** To specify the bit resolution.

---

**Dialog settings**

**Configure channels** Lets you switch between channel sets (1 ... 8, 9 ... 16, ... ), for which you want to specify the bit resolution.

**Resolution** Lets you select the bit resolution of 4, 8, 10, 12, 13, 14, 15 or 16 bits for each channel of the specified channel set. To assign one bit resolution to all of the channels displayed, specify the desired value before pushing the Set all button.

Tip

You can achieve faster conversion times if you lower the resolution of the converters. For detailed information, refer to [Faster A/D Conversion via Short-Cycling \(DS2003 Features !\[\]\(d84e7ea36f695d92cb39ec32c307ac93\_img.jpg\)](#)).

Related topics

References

<a href="#">Block Description (DS2003_Bx)</a>	12
<a href="#">Range Page (DS2003_Bx)</a>	14
<a href="#">Unit Page (DS2003_Bx)</a>	13





# Interrupts

---

**Objective**

The Library: rtilibm/DS2003 provides access to the hardware interrupts of the DS2003.

## DS2003\_HWINT\_Bx\_Iy


### Where to go from here

### Information in this section

Block Description (DS2003_HWINT_Bx_Iy).....	18
Unit Page (DS2003_HWINT_Bx_Iy).....	18

## Block Description (DS2003\_HWINT\_Bx\_Iy)

### Block



### Purpose

To make the hardware interrupts of the DS2003 board available as trigger sources in a block diagram.

#### Note

Because the A/D conversion works in polling mode, do not specify an interrupt using the HWINT block. Otherwise the processor will be blocked. For further information, refer to [Limitations \(DS2003 Features\)](#).

### Dialog pages

The dialog settings can be specified on the Unit Page (refer to [Unit Page \(DS2003\\_HWINT\\_Bx\\_Iy\)](#) on page 18).

## Unit Page (DS2003\_HWINT\_Bx\_Iy)

### Purpose

To specify the board number and the interrupt source.

### Dialog settings

**Board number** Lets you select the board number in the range 1 ... 16. If your system contains several boards of the same type, RTI uses the board number to distinguish between them.

**Interrupt** Lets you specify the type of the interrupt source.

Four interrupts of the DS2003 board provide access to the state of the conversion process:

Interrupt No.	Interrupt Type
1	Conversion process complete
2	ADC data buffer not empty
3	ADC data buffer half full
4	ADC data buffer full

- The ADC data buffer is used to obtain the results of a conversion process. The buffer consists of 512 x 32 bits first-in-first-out (FIFO) memory. It can be read randomly even while a conversion process is in progress. The 32-bit word of the buffer is shared by the 2 converters.

Data Buffer Event	State	Function
Buffer not empty	true	At least one data pair is available.
	false	The data buffer is empty. Reading it results in erroneous data.
Buffer half full	true	At least 256 data pairs available.
	false	255 or fewer ADC data pairs available.
Buffer full	true	512 ADC data pairs available. Further data values will be lost.
	false	Less than 512 data pairs available.

- The events *ADC data buffer half full* and *ADC data buffer full* will never occur with code generated from the DS2003 block.

#### Tip

For detailed information on the conversion process and the ADC buffer, refer to [ADC Unit \(DS2003 Features\)](#).

## Related topics

## References

<a href="#">Block Description (DS2003_HWINT_Bx_Iy)</a> .....	18
--	----



## C

Common Program Data folder 6

## D

Documents folder 7

DS2003\_Bx 12

    block description 12

    Range page 14

    Resolution page 14

    Unit page 13

DS2003\_HWINT\_Bx\_ly 18

    block description 18

    Unit page 18

## L

Local Program Data folder 7

