



Powering off and powering on a data center

ONTAP MetroCluster

netapp-ivanad, ntap-bmegan
April 21, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/maintain/task_power_on_and_power_off_a_data_center.html on April 28, 2021. Always check docs.netapp.com for the latest.

Table of Contents

- Powering off and powering on a data center 1
 - Powering off a MetroCluster site 1
 - Relocating the powered-off site of the MetroCluster 7
 - Powering on the MetroCluster configuration and returning to normal operation 14

Powering off and powering on a data center

You must know how to power off and power on a data center for the purpose of site maintenance or to relocate a site to another location.

If a site needs to be relocated and reconfigured (if you need to expand from a four-node to an eight-node cluster, for example), these tasks cannot be completed at the same time. This procedure only covers the steps that are required to perform site maintenance or to relocate a site without changing its configuration.



This procedure is for use in both MetroCluster IP and FC configurations.

Powering off a MetroCluster site

You must power off a site and all of the equipment before site maintenance or relocation can begin.

Steps

1. Before you begin, check that any non-mirrored aggregates at the site are offline.
2. Verify the operation of the MetroCluster configuration in ONTAP:
 - a. Check whether the system is multipathed:
`node run -node node-name sysconfig -a`
 - b. Check for any health alerts on both clusters:
`system health alert show`
 - c. Confirm the MetroCluster configuration and that the operational mode is normal:
`metrocluster show`
 - d. Perform a MetroCluster check:
`metrocluster check run`
 - e. Display the results of the MetroCluster check:
`metrocluster check show`
 - f. Check for any health alerts on the switches (if present):
`storage switch show`
 - g. Run Config Advisor.

[NetApp Downloads: Config Advisor](#)
 - h. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.
3. Enter the following command to implement the switchover:

```
metrocluster switchover
```

The operation can take several minutes to complete.

In MetroCluster FC configurations, the unmirrored aggregates will only be online after a switchover if the remote disks in the aggregate are accessible. If the ISLs fail, the local node may be unable to access the data in the unmirrored remote disks. The failure of an aggregate can lead to a reboot of the local node.

4. Monitor and verify the completion of the switchover:

metrocluster operation show

```
cluster_A::*> metrocluster operation show
  Operation: Switchover
  Start time: 10/4/2012 19:04:13
  State: in-progress
  End time: -
  Errors:

cluster_A::*> metrocluster operation show
  Operation: Switchover
  Start time: 10/4/2012 19:04:13
  State: successful
  End time: 10/4/2012 19:04:22
  Errors: -
```

5. If you are in a MetroCluster IP configuration running ONTAP 9.6 or later, wait for the disaster site plexes to come online and the healing operations to automatically complete.

In MetroCluster IP configurations running earlier versions of ONTAP, the disaster site nodes do not automatically boot to ONTAP and the plexes remain offline.

6. Depending on your configuration and ONTAP version, identify and move offline affected plexes that are located at the disaster site.



This step is required in the following configurations:

- All MetroCluster FC configurations.
- MetroCluster IP configurations running ONTAP version 9.6 or later.

You should move the following plexes offline:

- Non-mirrored plexes residing on disks located at the disaster site.

If you do not move the non-mirrored plexes at the disaster site offline, an outage might result when the disaster site is later powered off.

- Mirrored plexes residing on disks located at the disaster site for aggregate mirroring. Once they are moved offline, the plexes are inaccessible.
 - a. Identify the affected plexes.

Plexes that are owned by nodes at the surviving site consist of Pool1 disks. Plexes that are owned by nodes at the disaster site consist of Pool0 disks.



“Home” refers to the “home” owner, not the “current” owner.

```
Cluster_A::> storage aggregate plex show -fields
aggregate,status,is-online,Plex,pool
aggregate      plex  status      is-online pool
-----
Node_B_1_aggr0 plex0 normal,active true      0
Node_B_1_aggr0 plex1 normal,active true      1

Node_B_2_aggr0 plex0 normal,active true      0
Node_B_2_aggr0 plex5 normal,active true      1

Node_B_1_aggr1 plex0 normal,active true      0
Node_B_1_aggr1 plex3 normal,active true      1

Node_B_2_aggr1 plex0 normal,active true      0
Node_B_2_aggr1 plex1 normal,active true      1

Node_A_1_aggr0 plex0 normal,active true      0
Node_A_1_aggr0 plex4 normal,active true      1

Node_A_1_aggr1 plex0 normal,active true      0
Node_A_1_aggr1 plex1 normal,active true      1

Node_A_2_aggr0 plex0 normal,active true      0
Node_A_2_aggr0 plex4 normal,active true      1

Node_A_2_aggr1 plex0 normal,active true      0
Node_A_2_aggr1 plex1 normal,active true      1
14 entries were displayed.

Cluster_A::>
```

The affected plexes are those that are remote to cluster A. The following table shows whether the disks are local or remote relative to cluster A:

Node	Disks in pool	Should the disks be set offline?	Example of plexes to be moved offline
Node _A_1 and Node _A_2	Disks in pool 0	No. Disks are local to cluster A.	-
	Disks in pool 1	Yes. Disks are remote to cluster A.	Node_A_1_aggr0/plex 4 Node_A_1_aggr1/plex 1 Node_A_2_aggr0/plex 4 Node_A_2_aggr1/plex 1
Node _B_1 and Node _B_2	Disks in pool 0	Yes. Disks are remote to cluster A.	Node_B_1_aggr1/plex 0 Node_B_1_aggr0/plex 0 Node_B_2_aggr0/plex 0 Node_B_2_aggr1/plex 0
	Disks in pool 1	No. Disks are local to cluster A.	-

b. Move the affected plexes offline:

storage aggregate plex offline

```
storage aggregate plex offline -aggregate Node_B_1_aggr0 -plex
plex0
```



Perform this for all plexes that have disks that are remote to Cluster_A.

7. Persistently offline the switchports according to the switch type.



This step is only required for MetroCluster FC configurations. Skip this step if your configuration is a MetroCluster IP configuration or a stretched MetroCluster configuration with FC backend switches.

Switch type	Action
If the FC switches are Brocade switches...	<p>a. Use the portcfgpersistentdisable port command to persistently disable the ports as shown in the following example. This must be done on both switches at the surviving site.</p> <pre> Switch_A_1:admin> portcfgpersistentdisable 14 Switch_A_1:admin> portcfgpersistentdisable 15 Switch_A_1:admin> </pre> <p>b. Verify that the ports are disabled using the switchshow command shown in the following example:</p> <pre> Switch_A_1:admin> switchshow switchName: Switch_A_1 switchType: 109.1 switchState: Online switchMode: Native switchRole: Principal switchDomain: 2 switchId: fffc02 switchWwn: 10:00:00:05:33:88:9c:68 zoning: ON (T5_T6) switchBeacon: OFF FC Router: OFF FC Router BB Fabric ID: 128 Address Mode: 0 Index Port Address Media Speed State Proto ===== ===== ... 14 14 020e00 id 16G No_Light FC Disabled (Persistent) 15 15 020f00 id 16G No_Light FC Disabled (Persistent) ... Switch_A_1:admin> </pre>

Switch type	Action
If the FC switches are Cisco switches...	<p>a. Use the interface command to persistently disable the ports. The following example shows ports 14 and 15 being disabled:</p> <pre>Switch_A_1# conf t Switch_A_1(config)# interface fc1/14-15 Switch_A_1(config)# shut Switch_A_1(config-if)# end Switch_A_1# copy running- config startup-config</pre> <p>b. Verify that the switch port is disabled using the show interface brief command as shown in the following example:</p> <pre>Switch_A_1# show interface brief Switch_A_1</pre>

8. Power off the site.

The following equipment needs to be turned off in no specific order:

Configuration type	Equipment to be powered off
In a MetroCluster IP configuration, power off...	<ul style="list-style-type: none"> • MetroCluster IP switches • Storage controllers • Storage shelves
In a MetroCluster FC configuration, power off...	<ul style="list-style-type: none"> • MetroCluster FC switches • Storage controllers • Storage shelves • Atto FibreBridges (if present)

Relocating the powered-off site of the MetroCluster

Once the site is powered off, you can begin maintenance work. The procedure is the same whether the MetroCluster components are relocated within the same data center or

relocated to a different data center.

- The hardware should be cabled in the same way as the previous site.
- If the Inter-Switch Link (ISL) speed, length, or number has changed, they all need to be reconfigured.

Steps

1. Make sure that the cabling for all components is carefully recorded so that it can be correctly reconnected at the new location.
2. Physically relocate all the hardware, storage controllers, FC and IP switches, FibreBridges, and storage shelves.
3. Configure the ISL ports and verify the intersite connectivity.
 - a. Power on the FC and IP switches.



Do **not** power up any other equipment.

4. Enable the ports.



This step is only required in MetroCluster FC configurations. You can skip this step if your configuration is a MetroCluster IP configuration.

Enable the ports according to the correct switch types in the following table:

Switch type	Command
If the FC Switches are Brocade switches...	<p>a. Use the portcfgpersistentenable <i>port number</i> command to persistently enable the port. This must be done on both switches at the surviving site.</p> <p>The following example shows ports 14 and 15 being enabled on Switch_A_1.</p> <pre>switch_A_1:admin> portcfgpersistentenable 14 switch_A_1:admin> portcfgpersistentenable 15 switch_A_1:admin></pre> <p>b. Verify that the switch port is enabled: switchshow</p> <p>The following example shows that ports 14 and 15 are enabled:</p>

Switch type	Command
If the FC Switches are Cisco switches...	<p>a. Enter the interface command to enable the port.</p> <p>The following example shows ports 14 and 15 being enabled on Switch_A_1.</p> <pre>switch_A_1# conf t switch_A_1(config)# interface fc1/14-15 switch_A_1(config)# no shut switch_A_1(config-if)# end switch_A_1# copy running- config startup-config</pre> <p>b. Verify that the switch port is enabled: show interface brief</p> <pre>switch_A_1# show interface brief switch_A_1#</pre>

5. Use tools on the switches (as they are available) to verify the intersite connectivity.



You should only proceed if the links are properly configured and stable.

6. Disable the links again if they are found to be stable.

Disable the ports based on whether you are using Brocade or Cisco switches as shown in the following table:

```
14 14 020e00 id 16G
Online FC E-Port
10:00:00:05:33:86:89:cb
Switch_A_1
15 15 020f00 id 16G
Online FC E-Port
10:00:00:05:33:86:89:cb
"Switch_A_1" (downstream)
...
switch_A_1:admin>
```


Switch type	Command
If the FC Switches are Brocade switches...	<p>a. Enter the portcfgpersistentdisable <i>port number</i> command to persistently disable the port.</p> <p>This must be done on both switches at the surviving site. The following example shows ports 14 and 15 being disabled on Switch_A_1:</p> <pre>switch_A_1:admin> portpersistentdisable 14 switch_A_1:admin> portpersistentdisable 15 switch_A_1:admin></pre> <p>b. Verify that the switch port is disabled: switchshow</p> <p>The following example shows that ports 14 and 15 are disabled:</p>

Switch type	Command
If the FC Switches are Cisco switches...	<p>a. Disable the port using the interface command.</p> <p>The following example shows ports fc1/14 and fc1/15 being disabled on Switch A_1:</p> <pre>switch_A_1# conf t switch_A_1(config)# interface fc1/14-15 switch_A_1(config)# shut switch_A_1(config-if)# end switch_A_1# copy running- config startup-config</pre> <p>b. Verify that the switch port is disabled using the show interface brief command.</p> <pre>switch_A_1# show interface brief switch_A_1#</pre>

Powering on the MetroCluster configuration and returning to normal operation

After maintenance has been completed or the site has been moved, you must power on the site and reestablish the MetroCluster configuration.

Steps

1. Power on the switches.

Switches should be powered on first. They might have been powered on during the previous step if the site was relocated.

- a. Reconfigure the Inter-Switch Link (ISL) if required or if this was not completed as part of the relocation.
- b. Enable the ISL if fencing was completed.
- c. Verify the ISL.

2. Power on the shelves and allow enough time for them to power on completely.
3. Power on the FibreBridge bridges.



You can skip this step if your configuration is a MetroCluster IP configuration.

- a. On the FC switches, verify that the ports connecting the bridges are coming online.

You can use a command such as **switchshow** for Brocade switches, and **show interface brief** for Cisco switches.

- b. Verify that the shelves and disks on the bridges are clearly visible.

You can use a command such as **sastargets** on the ATTO command-line interface (CLI).

4. Enable the ISLs on the FC switches.



Skip this step if your configuration is a MetroCluster IP configuration.

Enable the ports based on whether you are using Brocade or Cisco switches as shown in the following table:

Switch type	Command
<p>If the FC Switches are Brocade switches...</p>	<p>a. Enter the portcfgpersistentenable port command to persistently enable the ports. This must be done on both switches at the surviving site.</p> <p>The following example shows ports 14 and 15 being enabled on Switch_A_1:</p> <div data-bbox="889 428 1487 688" style="border: 1px solid #ccc; padding: 10px; margin: 10px 0;"> <pre>Switch_A_1:admin> portcfgpersistentenable 14 Switch_A_1:admin> portcfgpersistentenable 15 Switch_A_1:admin></pre> </div> <p>b. Verify that the switch port is enabled using the switchshow command:</p>

Switch type	Command
If the FC Switches are Cisco switches...	<p>a. Use the interface command to enable the ports.</p> <p>The following example shows port fc1/14 and fc1/15 being enabled on Switch A_1:</p> <pre>switch_A_1# conf t switch_A_1(config)# interface fc1/14-15 switch_A_1(config)# no shut switch_A_1(config-if)# end switch_A_1# copy running- config startup-config</pre> <p>b. Verify that the switch port is disabled:</p> <pre>switch_A_1# show interface brief switch_A_1#</pre>

5. Verify that the storage is now visible.

Select the appropriate method of determining whether the storage is visible based on whether you have a MetroCluster IP or FC configuration:

```
=====
...
14 14 020e00 id 16G
Online FC E-Port
10:00:00:05:33:86:89:cb
```

Configuration	Step
If your configuration is a MetroCluster IP...	Verify that the local storage is visible from the node Maintenance mode.
If your configuration is a MetroCluster FC...	Verify that the storage is visible from the surviving site. Put the offline plexes back online. This restarts the resync operations and reestablishes the SyncMirror.

6. Reestablish the MetroCluster configuration.

Follow the instructions in the *MetroCluster Disaster and Recovery Guide* to perform healing and switchback operations according to your MetroCluster configuration.

[MetroCluster management and disaster recovery](#)

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.