

## Commands for ROV thruster test software

**Command Format:** [Command] [SPACE] [Para 1] [SPACE] [Para 2] [SPACE] [Para 3]

[Command] Two alphabetical characters

[SPACE] Single space

[Para 1/2/3] Parameters of the command. Number of required parameters varies.

Some parameters (shown in [...]) are optional.

Command	Description	Parameter 1	Parameter 2	Parameter 3
<b>LF 0 100 5000</b>	Linear Forward Linearly speeds up thruster in forward direction in given time span	Initial Throttle	Final Throttle	Time span in milliseconds
<b>LR 0 100 5000</b>	Linear Reverse Linearly speeds up thruster in reverse direction in given time span	Initial Throttle	Final Throttle	Time span in milliseconds
<b>FW 100 [5000]</b>	Forward Drives thruster forward in constant speed	Throttle (0-100)	[Optional] Time span in milliseconds	-
<b>RV 100 [5000]</b>	Reverse Drives thruster reverse in constant speed	Throttle (0-100)	[Optional] Time span in milliseconds	-
<b>ST [5000]</b>	Stop Stops the thruster	[Optional] Time span in milliseconds	-	-
<b>WT 1000</b>	Wait Waits for specified interval before processing next command	Interval in milliseconds	-	-
<b>TR</b>	Tare Tare (set zero) the load cell reading	-	-	-

\*For **FW**, **RV** and **ST** commands, next command will be executed immediately if time span is not specified.