

z/OS
2.5

*MVS Programming: Authorized
Assembler Services Reference, Volume 4
(SET-WTO)*



Note

Before using this information and the product it supports, read the information in [“Notices” on page 417.](#)

This edition applies to Version 2 Release 5 of z/OS® (5650-ZOS) and to all subsequent releases and modifications until otherwise indicated in new editions.

Last updated: 2022-10-24

© **Copyright International Business Machines Corporation 1988, 2022.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Figures.....	xix
Tables.....	xxi
About this information.....	xxv
Who should use this information.....	xxv
How to use this information.....	xxv
z/OS information.....	xxv
How to send your comments to IBM.....	xxvii
If you have a technical problem.....	xxvii
Summary of changes.....	xxix
Summary of changes for z/OS MVS Programming: Authorized Assembler Services Reference SET- WTO for Version 2 Release 5 (V2R5).....	xxix
Summary of changes for z/OS Version 2 Release 4.....	xxix
Summary of changes for z/OS Version 2 Release 3.....	xxx
Chapter 1. Using the services.....	1
Compatibility of MVS macros.....	1
Addressing mode (AMODE).....	2
Address space control (ASC) mode.....	3
ALET qualification.....	3
User parameters.....	4
Telling the system about the execution environment	5
Specifying a macro version number.....	6
How to request a macro version using PLISTVER.....	6
Register use.....	7
Handling return codes and reason codes.....	8
Handling program errors.....	8
Handling environmental and system errors.....	9
Using X-macros.....	9
Macro forms.....	10
Conventional list form macros.....	10
Alternative list form macros.....	11
Coding the macros.....	11
Continuation lines.....	13
Coding the callable services.....	14
Including equate (EQU) statements.....	14
Link-editing linkage-assist routines.....	15
Service summary.....	15
Chapter 2. SETFRR – Set up functional recovery routines.....	27
Description.....	27
Environment.....	27
Programming requirements.....	27
Restrictions.....	28
Input register information.....	28
Output register information.....	28

Performance implications.....	28
Syntax.....	28
Parameters.....	29
ABEND codes.....	31
Return and reason codes.....	31
Example 1.....	31
Example 2.....	31
Chapter 3. SETLOCK — Control access to serially reusable resources.....	33
Description.....	33
Environment.....	33
Programming requirements.....	33
Restrictions.....	33
Input register information.....	34
Output register information.....	34
Performance implications.....	35
SETLOCK OBTAIN.....	35
Syntax.....	35
Parameters.....	35
ABEND codes.....	37
Return and reason codes.....	37
Example 1.....	38
Example 2.....	38
Example 3.....	38
SETLOCK RELEASE.....	38
Syntax.....	38
Parameters.....	39
Return and reason codes.....	41
Example 1.....	41
Example 2.....	41
SETLOCK TEST.....	42
Syntax.....	42
Parameters.....	42
Return and reason codes.....	44
Example 1.....	44
Example 2.....	44
Example 3.....	44
Chapter 4. SETRP — Set return parameters.....	45
Description.....	45
Environment.....	45
Programming requirements.....	45
Restrictions.....	45
Input register information.....	46
Output register information.....	46
Performance implications.....	47
Syntax.....	47
Parameters.....	49
ABEND codes.....	54
Return and reason codes.....	54
Example 1.....	54
Example 2.....	54
Chapter 5. SJFREQ — Call scheduler JCL facility services.....	55
Description.....	55
Environment.....	55
Programming requirements.....	56

Restrictions.....	56
Input register information.....	56
Output register information.....	56
Performance implications.....	57
Syntax.....	57
Parameters.....	57
Example.....	58
SJFREQ RETRIEVE service.....	60
Programming requirements.....	61
SJFREQ RETRIEVE keyword list.....	61
SJFREQ RETRIEVE input parameters.....	61
SJFREQ RETRIEVE output parameters.....	62
ABEND codes.....	62
SJFREQ RETRIEVE return and reason codes.....	63
SJFREQ SWBTU_MERGE service.....	64
Programming requirements.....	64
SJFREQ SWBTU_MERGE input parameters.....	64
SJFREQ SWBTU_MERGE output parameters.....	65
SJFREQ SWBTU_MERGE ABEND codes.....	66
SJFREQ SWBTU_MERGE Return and reason codes.....	66
SJFREQ VERIFY service.....	71
SJFREQ VERIFY input parameters.....	71
SJFREQ VERIFY output parameters.....	74
Operand descriptions.....	76
ABEND codes.....	77
Return and reason codes with related message text.....	77
SJFREQ TERMINATE service.....	82
SJFREQ TERMINATE input parameters.....	82
Return and reason codes.....	83

Chapter 6. SMFEWTM – Write an SMF record..... 85

Chapter 7. SMFWTM – Write an SMF record..... 89

Chapter 8. SPIE – Specify program interruption exit.....93

Description.....	93
Environment.....	93
Programming requirements.....	94
Restrictions.....	94
Input register information.....	94
Output register information.....	94
Performance implications.....	94
Syntax.....	95
Parameters.....	95
ABEND codes.....	96
Return and reason codes.....	96
Example.....	96
SPIE - List form.....	97
Syntax.....	97
Parameters.....	97
SPIE - Execute form.....	97
Syntax.....	98
Parameters.....	98

Chapter 9. SPOST – Synchronize POST.....99

Description.....	99
Environment.....	99

Programming requirements.....	99
Restrictions.....	99
Input register information.....	99
Output register information.....	99
Performance implications.....	100
Syntax.....	100
ABEND codes.....	100
Return and reason codes.....	100
Example.....	100
Chapter 10. SRBSTAT – Save, restore, or modify SRB status.....	101
Description.....	101
Environment.....	101
Programming requirements.....	101
Restrictions.....	101
Input register information.....	101
Output register information.....	101
Performance implications.....	102
Syntax.....	102
Parameters.....	103
ABEND codes.....	104
Return and reason codes.....	104
Chapter 11. SRBTIMER – Establish time limit for system service.....	105
Description.....	105
Environment.....	105
Programming requirements.....	105
Restrictions.....	105
Input register information.....	105
Output register information.....	105
Performance implications.....	106
Syntax.....	106
Parameters.....	106
ABEND codes.....	107
Return codes.....	107
Chapter 12. STATUS – Control dispatchability or process-must-complete state... 	109
Description.....	109
Environment.....	109
Programming requirements.....	110
Restrictions.....	110
Register information.....	110
Performance implications.....	111
START/STOP options.....	111
Syntax.....	111
Parameters.....	112
Return codes.....	112
SET/RESET option.....	113
Syntax.....	113
Parameters.....	113
Return codes.....	113
Example.....	114
Chapter 13. STORAGE – Obtain and release storage.....	115
Description.....	115
Environment.....	115
Programming requirements.....	116

Restrictions.....	116
Register information.....	117
Performance implications.....	117
STORAGE OBTAIN.....	117
Input register information for LINKAGE=SYSTEM.....	117
Output register information for LINKAGE=SYSTEM.....	117
Input register information for LINKAGE=SVC.....	118
Output register information for LINKAGE=SVC.....	118
Input register information for LINKAGE=BRANCH.....	119
Output register information for LINKAGE=BRANCH.....	119
Input register information for LINKAGE=GLOBALBRANCH.....	120
Output register information for LINKAGE=GLOBALBRANCH.....	120
Syntax.....	121
Parameters.....	124
ABEND codes.....	130
Return and reason codes.....	131
Examples.....	132
STORAGE RELEASE.....	132
Input register information for LINKAGE=SYSTEM.....	132
Output register information for LINKAGE=SYSTEM.....	132
Input register information for LINKAGE=SVC.....	133
Output register information for LINKAGE=SVC.....	133
Input register information for LINKAGE=BRANCH.....	133
Output register information for LINKAGE=BRANCH.....	134
Input register information for LINKAGE=GLOBALBRANCH.....	134
Output register information for LINKAGE=GLOBALBRANCH.....	135
Syntax.....	135
Parameters.....	136
ABEND codes.....	138
Return and reason codes.....	139
Examples of the OBTAIN and RELEASE options.....	139
Chapter 14. SUSPEND – Suspend execution of an RB.....	141
Description.....	141
Environment.....	141
Programming requirements.....	141
Restrictions.....	141
Input register information.....	141
Output register information.....	141
Performance implications.....	142
Syntax.....	142
Parameters.....	142
ABEND codes.....	142
Return and reason codes.....	142
Example.....	142
Chapter 15. SUSPEND – Suspend execution of an SRB.....	145
Description.....	145
Environment.....	145
Programming requirements.....	145
Restrictions.....	145
Input register information.....	146
Output register information.....	146
Performance implications.....	146
Syntax.....	146
Parameters.....	147
ABEND codes.....	147

Return codes.....	147
Example.....	148
SUSPEND (SRB) - List form.....	148
Syntax.....	148
Parameters.....	149
SUSPEND (SRB) - Execute form.....	149
Syntax.....	149
Parameters.....	150
Chapter 16. SVCUPDTE – SVC update.....	151
Description.....	151
Environment.....	151
Programming requirements.....	151
Restrictions.....	151
Input register information.....	151
Output register information.....	151
Performance implications.....	152
Syntax.....	152
Parameters.....	153
ABEND codes.....	155
Return codes.....	155
Example 1.....	156
Example 2.....	157
Example 3.....	157
Example 4.....	157
Example 5.....	157
Example 6.....	157
SVCUPDTE - List form.....	157
Syntax.....	157
Parameters.....	159
Example 1.....	159
Example 2.....	159
SVCUPDTE - Execute form.....	159
Syntax.....	159
Parameters.....	160
Example.....	160
Chapter 17. SWAREQ – Invoke SWA manager in locate mode.....	161
Description.....	161
Environment.....	161
Programming requirements.....	162
Restrictions.....	162
Input register information.....	162
Output register information.....	162
Performance implications.....	162
ABEND codes.....	162
Return and reason codes.....	163
SWAREQ - List form.....	163
Syntax.....	163
Parameters.....	164
SWAREQ - Execute form.....	164
Syntax.....	164
Parameters.....	165
SWAREQ - Modify form.....	165
Syntax.....	165
Parameters.....	166

Chapter 18. SWBTUREQ – Call SJF SWBTU processing services.....	167
Description.....	167
Environment.....	167
Programming requirements.....	167
Restrictions.....	168
Input register information.....	168
Output register information.....	168
Performance implications.....	168
Syntax.....	168
Parameters.....	169
SWBTUREQ RETRIEVE service.....	169
SWBTUREQ RETRIEVE input parameters.....	169
SWBTUREQ RETRIEVE output.....	170
ABEND codes.....	171
Return and reason codes.....	171
Example.....	173
Chapter 19. SYNCH and SYNCHX – Take a synchronous exit to a processing program.....	177
Description.....	177
Environment.....	177
Programming requirements.....	178
Restrictions.....	178
Register information.....	178
Syntax.....	178
Parameters.....	179
Example 1.....	181
Example 2.....	181
Example 3.....	181
Example 4.....	181
SYNCHX - Take a synchronous exit to a processing program.....	181
Syntax.....	182
Parameters.....	183
SYNCH and SYNCHX - List form.....	183
Syntax.....	183
Parameters.....	183
Example.....	184
SYNCH and SYNCHX - Execute form.....	184
Syntax.....	184
Parameters.....	185
Example.....	185
Chapter 20. SYSEVENT – System event.....	187
Description.....	187
Environment.....	187
Programming requirements.....	188
Restrictions and limitations.....	188
Input register information.....	188
Output register information.....	188
Syntax.....	189
Parameters.....	190
SYSEVENT mnemonics.....	192
Notify SRM of transaction completion (TRAXRPT, TRAXFRPT, TRAXERPT).....	192
Return and reason codes.....	193
Example 1.....	194
Example 2.....	194

Example 3.....	195
Control swapping (DONTSWAP, OKSWAP, TRANSWAP).....	195
Example 1.....	196
Example 2.....	196
Obtain system measurement information (STGTEST).....	196
Example.....	197
Obtain address space classification information (REQASCL).....	197
Input register information.....	198
Return and reason codes.....	198
Obtain address space related information (REQASD and REQFASD).....	198
Input register information.....	198
Return and reason codes.....	199
Example 1.....	199
Example 2.....	199
Obtain workload management mode status information (REQSRMST).....	200
Input register information.....	200
Return and reason codes.....	200
Obtain data for defined capacity (REQLPDAT).....	200
Input register information.....	201
Return and reason codes.....	201
Identify holder of a resource (ENQHOLD).....	201
Input register information.....	202
Return and reason codes.....	202
Identify that a holder has released resource (ENQRLSE).....	203
Input register information.....	203
Return and reason codes.....	203
Associate an enclave with an address space (ENCASSOC).....	203
Input register information.....	204
Return and reason codes.....	204
Set the state for an enclave (ENCSTATE).....	204
Input register information.....	204
Query amount of free AUX storage (FREEAUX).....	205
Output register information.....	205
Return resource contention information (QRYCONT).....	205
Input register information.....	205
Return codes.....	205
Query a virtual server (QVS).....	205
Return and reason codes.....	207

Chapter 21. TCBTOKEN – Request or translate the TTOKEN..... 209

Description.....	209
Environment.....	209
Programming requirements.....	210
Restrictions.....	210
Register information.....	210
Performance implications.....	210
Syntax.....	210
Parameters.....	211
Abend codes.....	213
Return codes.....	213
Example 1.....	214
Example 2.....	214
Example 3.....	214
TCBTOKEN - List form.....	214
Syntax.....	214
Parameters.....	215
TCBTOKEN - Execute form.....	215

Syntax.....	215
Parameters.....	216
Chapter 22. TCTL — Transfer control from an SRB routine.....	217
Description.....	217
Environment.....	217
Programming requirements.....	217
Restrictions.....	217
Input register information.....	217
Output register information.....	217
Performance implications.....	217
Syntax.....	217
Parameters.....	218
ABEND codes.....	218
Return and reason codes.....	218
Example.....	218
Chapter 23. TESTAUTH — Test authorization of caller.....	219
Description.....	219
Environment.....	219
Programming requirements.....	219
Restrictions.....	219
Input register information.....	220
Output register information.....	220
Performance implications.....	220
Syntax.....	220
Parameters.....	221
ABEND codes.....	222
Return codes.....	222
Example 1.....	222
Example 2.....	222
Chapter 24. TIMEUSED — Obtain accumulated CPU or vector time.....	223
Description.....	223
Environment.....	223
Programming requirements.....	223
Restrictions.....	224
Input register information.....	224
Output register information.....	224
Performance implications.....	225
Syntax.....	225
Parameters.....	226
Return codes.....	228
Example 1.....	228
Example 2.....	228
Example 3.....	228
Chapter 25. T6EXIT — Type 6 exit.....	229
Description.....	229
Environment.....	229
Programming requirements.....	229
Restrictions.....	229
Input register information.....	229
Output register information.....	229
Performance implications.....	229
Syntax.....	229
Parameter.....	230

ABEND codes.....	230
Return and reason codes.....	230
Example.....	230

Chapter 26. UCBINFO – Return information from a UCB.....231

Description.....	231
Environment.....	231
Programming requirements.....	232
Restrictions.....	233
Input register information.....	233
Output register information.....	233
Performance implications.....	233
UCBINFO DEVCOUNT.....	233
Syntax.....	233
Parameters.....	235
Return and reason codes.....	237
Example.....	237
UCBINFO DEVCOUNT–List form.....	238
Parameters.....	238
UCBINFO DEVCOUNT–Execute form.....	239
Parameters.....	240
UCBINFO DEVINFO.....	240
Syntax.....	240
Parameters.....	242
Return and reason codes.....	243
Example.....	244
UCBINFO DEVINFO - List form.....	244
Parameters.....	245
UCBINFO DEVINFO - Execute form.....	245
Parameters.....	246
UCBINFO GETCDR.....	246
Syntax.....	247
Parameters.....	248
Return and reason codes.....	249
Example.....	250
UCBINFO GETCDR - List form.....	250
Parameters.....	251
UCBINFO GETCDR - Execute form.....	251
Parameters.....	253
UCBINFO HYPERPAVALIASES.....	253
Syntax.....	253
Parameters.....	254
Return and reason codes.....	256
Example.....	257
UCBINFO HYPERPAVALIASES - List form.....	257
Parameters.....	258
UCBINFO HYPERPAVALIASES - Execute form.....	258
Parameters.....	260
UCBINFO PATHINFO.....	260
Syntax.....	260
Parameters.....	261
Return and reason codes.....	262
Example.....	264
UCBINFO PATHINFO - List form.....	264
Parameters.....	264
UCBINFO PATHINFO - Execute form.....	265
Parameters.....	266

UCBINFO PATHMAP.....	266
Syntax.....	266
Parameters.....	267
Return and reason codes.....	269
Example.....	270
UCBINFO PATHMAP - List form.....	270
Parameters.....	271
UCBINFO PATHMAP - Execute form.....	271
Parameters.....	272
UCBINFO PAVINFO.....	272
Syntax.....	272
Parameters.....	274
Return and reason codes.....	276
Example.....	278
UCBINFO PAVINFO - List form.....	278
Parameters.....	279
UCBINFO PAVINFO - Execute form.....	279
Parameters.....	281
UCBINFO PRFXDATA.....	281
Syntax.....	281
Parameters.....	282
Return and reason codes.....	283
Example.....	284
UCBINFO PRFXDATA - List form.....	284
Parameters.....	285
UCBINFO PRFXDATA - Execute form.....	285
Parameters.....	287
Chapter 27. UCBLOOK – Obtain addresses of UCB segments.....	289
Description.....	289
Environment.....	289
Programming requirements.....	290
Restrictions.....	290
Input register information.....	290
Output register information.....	290
Performance implications.....	290
Syntax.....	290
Parameters.....	292
ABEND codes.....	295
Return and reason codes.....	295
UCBLOOK - List form.....	296
Syntax.....	296
Parameters.....	297
UCBLOOK - Execute form.....	297
Syntax.....	297
Parameters.....	299
Chapter 28. UCBPIN – Pinning or unpinning a UCB.....	301
Description.....	301
Environment.....	301
Programming requirements.....	301
Restrictions.....	301
Register information.....	302
Performance implications.....	302
Syntax.....	302
Parameters.....	304
Return and reason codes.....	305

UCBPIN - List form.....	306
Syntax.....	306
Parameters.....	306
UCBPIN - Execute form.....	307
Syntax.....	307
Parameters.....	308
Chapter 29. UCBSCAN – Scan UCBs.....	311
Description.....	311
Environment.....	311
Programming requirements.....	312
Restrictions.....	312
Input register information.....	312
Output register information.....	312
Performance implications.....	313
Parameters.....	313
Return and reason codes.....	316
UCBSCAN COPY.....	318
Syntax.....	318
UCBSCAN COPY - List form.....	320
Syntax.....	320
Parameters.....	321
UCBSCAN COPY - Execute form.....	321
Syntax.....	321
Parameters.....	323
UCBSCAN ADDRESS.....	324
Syntax.....	324
Parameters.....	326
Return and reason codes.....	329
UCBSCAN ADDRESS - List form.....	330
Syntax.....	331
Parameters.....	331
UCBSCAN ADDRESS - Execute form.....	331
Syntax.....	332
Parameters.....	334
Chapter 30. VSMLIST – List virtual storage map.....	335
Description.....	335
Environment.....	335
Programming requirements.....	335
Restrictions.....	336
Input register information.....	336
Output register information.....	336
Performance implications.....	336
Syntax.....	336
Parameters.....	338
ABEND codes.....	341
Return and reason codes.....	341
Example 1.....	341
Example 2.....	342
Example 3.....	342
Example 4.....	342
Chapter 31. VSMLOC – Verify virtual storage allocation.....	343
Description.....	343
Environment.....	343
Programming requirements.....	343

Restrictions.....	343
Input register information for LINKAGE=SYSTEM.....	343
Output register information for LINKAGE=SYSTEM.....	344
Input register information for LINKAGE=BRANCH.....	344
Output register information for LINKAGE=BRANCH.....	344
Performance implications.....	345
Syntax.....	345
Parameters.....	346
ABEND codes.....	348
Return and reason codes.....	348
Example 1.....	349
Example 2.....	349
Example 3.....	349
Example 4.....	349
Example 5.....	349
Chapter 32. VSMREGN – Obtain private area region size.....	351
Description.....	351
Environment.....	351
Programming requirements.....	351
Restrictions.....	351
Input register information.....	351
Output register information.....	352
Performance implications.....	352
Syntax.....	352
Parameters.....	353
ABEND codes.....	353
Return and reason codes.....	353
Example 1.....	353
Example 2.....	353
Example 3.....	353
Example 4.....	354
Chapter 33. WAIT – Wait for one or more events.....	355
Description.....	355
Environment.....	355
Programming requirements.....	355
Restrictions.....	355
Input register information.....	356
Output register information.....	356
Performance implications.....	356
Syntax.....	356
Parameters.....	357
Example.....	358
ABEND codes.....	358
Return and reason codes.....	358
Example 1.....	358
Example 2.....	359
Example 3.....	359
Chapter 34. WTL – Write to log.....	361
Description.....	361
Environment.....	361
Programming requirements.....	361
Restrictions.....	361
Input register information.....	361
Output register information.....	362

Performance implications.....	362
Syntax.....	362
Parameters.....	363
ABEND codes.....	363
Return and reason codes.....	363
Example 1.....	365
Example 2.....	365
Example 3.....	365
Example 4.....	365
WTL - List form.....	366
Syntax.....	366
Parameters.....	366
WTL - Execute form.....	366
Syntax.....	366
Parameters.....	367
Chapter 35. WTO – Write to operator.....	369
Description.....	369
Environment.....	369
Programming requirements.....	370
Restrictions.....	371
Input register information.....	372
Output register information.....	372
Performance implications.....	372
Syntax.....	372
Parameters.....	375
ABEND codes.....	383
Return and reason codes.....	384
Example 1.....	385
Example 2.....	385
Example 3.....	386
WTO - List form.....	386
Syntax.....	386
Parameters.....	389
WTO - Execute form.....	389
Syntax.....	389
Parameters.....	391
Example.....	391
Chapter 36. WTOR – Write to operator with reply.....	393
Description.....	393
Environment.....	393
Programming requirements.....	394
Restrictions.....	394
Input register information.....	395
Output register information.....	395
Performance implications.....	395
Syntax.....	396
Parameters.....	398
ABEND codes.....	404
Return and reason codes.....	404
Example 1.....	405
Example 2.....	406
Example 3.....	406
Example 4.....	406
WTOR - List form.....	407
Syntax.....	407

Parameters.....	410
WTOR - Execute form.....	410
Syntax.....	410
Parameters.....	413
Example.....	413
Appendix A. Accessibility.....	415
Notices.....	417
Terms and conditions for product documentation.....	418
IBM Online Privacy Statement.....	419
Policy for unsupported hardware.....	419
Minimum supported hardware.....	419
Programming interface information.....	420
Trademarks.....	420
Index.....	421

Figures

1. Sample User Parameter List for Callers in AR Mode..... 5

2. Sample tabular syntax diagram for the TEST macro..... 12

3. Continuation Coding..... 14

4. Relationship of Data and Work Areas Referenced in IEFSJTRP..... 171

Tables

1. Passing User Parameters in AR Mode.....	4
2. Execution environment characteristics and corresponding SYSSTATE parameters and global symbols.....	5
3. Service Summary.....	16
4. Return Codes for the SETLOCK Macro.....	38
5. Return Codes for SETLOCK RELEASE.....	41
6. Return Codes for SETLOCK TEST.....	44
7. Return and Reason Codes for the SJFREQ RETRIEVE Service.....	63
8. Return and Reason Codes for the SJSMREAS Macro.....	66
9. Return and Reason Codes for the SJFREQ Macro SWBTU_MERGE Service.....	71
10. Required Fields for SJFREQ VERIFY Functions.....	73
11. SJFREQ VERIFY Output Fields.....	75
12. SJF Operand and Keyword Operand Descriptions.....	76
13. Return and Reason Codes for the SJFREQ Macro VERIFY Service.....	78
14. Return Codes from the SJFREQ TERMINATE Service.....	83
15. Return codes for the SMFEWTM macro.....	87
16. Return codes for the SMFWTM macro.....	90
17. Return Codes for the SRBTIMER Macro.....	107
18. Return Codes for the STATUS Macro.....	112
19. Return Codes for the SET/RESET Option.....	113
20. Return Codes for STORAGE OBTAIN.....	131
21. Return Codes for STORAGE RELEASE.....	139
22. Return Codes for the SUSPEND Macro.....	147

23. Return Codes for the SVCUPDTE Macro.....	155
24. Return codes for the SWAREQ macro with UNAUTH=YES.....	163
25. Return codes for the SWAREQ macro.....	163
26. Parameter Combinations for SWBTUREQ RETRIEVE Functions.....	169
27. Return and Reason Codes for SWBTUREQ RETRIEVE.....	171
28. Return Codes for the SYSEVENT Macro.....	193
29. Fields and constants.....	198
30. Return Codes for REQASCL.....	198
31. Return Codes for REQASD and REQFASD.....	199
32. Return Codes for REQSRMST.....	200
33. Return Codes for REQLPDAT.....	201
34. Return Codes for ENQHOLD.....	202
35. Return Codes for ENQRLSE.....	203
36. Return Codes for ENCASSOC.....	204
37. Return Codes for REQLPDAT.....	205
38. Return Codes for QVS.....	207
39. Usage of TCBTOKEN parameters with the TYPE parameter.....	211
40. Return codes for the TCBTOKEN macro.....	213
41. Return Codes for the SAMPLE Macro.....	222
42. Return Codes for the TIMEUSED Macro.....	228
43. Return Codes for the UCBPIN Macro.....	305
44. Return Codes for the VSMLIST Macro.....	341
45. Return Codes for the VSMLOC Macro.....	348
46. Return and Reason Codes for the WTL Macro.....	363
47. MCSFLAG Flag Names.....	381

48. Return codes for the WTO macro.....	384
49. MCSFLAG Flag Names.....	402
50. Return Codes for the WTOR Macro.....	404

About this information

This information describes the authorized services that the MVS™ operating system provides; that is, services available only to authorized programs. An authorized program must meet one or more of the following requirements:

- Running in supervisor state
- Running under PSW key 0-7
- Running with APF-authorization.

Some of the services included in this information are not authorized, but are included because they are of greater interest to the system programmer than to the general applications programmer. The functions of these services are of such a nature that their use should be limited to programmers who write authorized programs. Services are also included if they have one or more authorized parameters — parameters available only to authorized programs.

Programmers using assembler language can use the macros described in this information to invoke the system services that they need. This document includes the detailed information — such as the function, syntax, and parameters — needed to code the macros.

This document is divided into four volumes. Volumes 1 through 4 present the macro descriptions in alphabetical order.

Who should use this information

This information is for the programmer who is using assembler language to code a system program. A system program is usually one that runs in supervisor state or runs with PSW key 0-7 or runs with APF authorization.

The information assumes that the reader understands system concepts and writes programs in assembler language.

System macros require High Level Assembler. For more information about assembler language programming, see *High Level Assembler and Toolkit Feature in IBM Documentation* (www.ibm.com/docs/en/hla-and-tf/1.6).

Using this information also requires you to be familiar with the operating system and the services that programs running under it can invoke.

How to use this information

This information is one of the set of programming documents for MVS. This set describes how to write programs in assembler language or high-level languages, such as C, FORTRAN, and COBOL. For more information about the content of this set of documents, see *z/OS Information Roadmap*.

z/OS information

This information explains how z/OS references information in other documents and on the web.

When possible, this information uses cross document links that go directly to the topic in reference using shortened versions of the document title. For complete titles and order numbers of the documents for all products that are part of z/OS, see *z/OS Information Roadmap*.

To find the complete z/OS library, go to *IBM Documentation* (www.ibm.com/docs/en/zos).

How to send your comments to IBM

We invite you to submit comments about the z/OS product documentation. Your valuable feedback helps to ensure accurate and high-quality information.

Important: If your comment regards a technical question or problem, see instead [“If you have a technical problem”](#) on page xxvii.

Submit your feedback by using the appropriate method for your type of comment or question:

Feedback on z/OS function

If your comment or question is about z/OS itself, submit a request through the [IBM RFE Community](#) (www.ibm.com/developerworks/rfe/).

Feedback on IBM® Documentation function

If your comment or question is about the IBM Documentation functionality, for example search capabilities or how to arrange the browser view, send a detailed email to IBM Documentation Support at ibmdocs@us.ibm.com.

Feedback on the z/OS product documentation and content

If your comment is about the information that is provided in the z/OS product documentation library, send a detailed email to mhvrcfs@us.ibm.com. We welcome any feedback that you have, including comments on the clarity, accuracy, or completeness of the information.

To help us better process your submission, include the following information:

- Your name, company/university/institution name, and email address
- The following deliverable title and order number: z/OS MVS Authorized Assembler Services Reference SET-WTO, SA23-1375-50
- The section title of the specific information to which your comment relates
- The text of your comment.

When you send comments to IBM, you grant IBM a nonexclusive authority to use or distribute the comments in any way appropriate without incurring any obligation to you.

IBM or any other organizations use the personal information that you supply to contact you only about the issues that you submit.

If you have a technical problem

If you have a technical problem or question, do not use the feedback methods that are provided for sending documentation comments. Instead, take one or more of the following actions:

- Go to the [IBM Support Portal](#) (support.ibm.com).
- Contact your IBM service representative.
- Call IBM technical support.

Summary of changes

This information includes terminology, maintenance, and editorial changes. Technical changes or additions to the text and illustrations for the current edition are indicated by a vertical line to the left of the change.

Note: IBM z/OS policy for the integration of service information into the z/OS product documentation library is documented on the z/OS Internet Library under [IBM z/OS Product Documentation Update Policy \(www-01.ibm.com/servers/resourceLink/svc00100.nsf/pages/ibm-zos-doc-update-policy?OpenDocument\)](http://www-01.ibm.com/servers/resourceLink/svc00100.nsf/pages/ibm-zos-doc-update-policy?OpenDocument).

Summary of changes for z/OS MVS Programming: Authorized Assembler Services Reference SET-WTO for Version 2 Release 5 (V2R5)

The following content is new, changed, or no longer included in V2R5.

New

The following content is new.

- The SMFEWTM macro is added in [Chapter 6, “SMFEWTM — Write an SMF record,” on page 85](#).
- The SMFWTM macro is added in [Chapter 7, “SMFWTM — Write an SMF record,” on page 89](#).

Changed

The following content is changed.

- The ADDR parameter description for the STORAGE OBTAIN macro is updated in [“STORAGE OBTAIN” on page 117](#).
- The SWAREQ macro return codes are updated. See [“Return and reason codes” on page 163](#) for more information.
- The SETRP macro is updated to mention the modify form of SNAP(X) as needed. See [Chapter 4, “SETRP — Set return parameters,” on page 45](#) for more information.
- Added clarification to EXECUTABLE=YES or NO on the STORAGE macro. See [“STORAGE OBTAIN” on page 117](#) and [“STORAGE RELEASE” on page 132](#).

Deleted

The following content was deleted.

- None

Summary of changes for z/OS Version 2 Release 4

The following content is new, changed, or no longer included in V2R4.

New

The following information is new in this publication:

- **June 2020 refresh**

- Added clarification to REQUEST=VERIFY of SJFREQ macro about specifying SJxxNOCU and ensuring that TERMINATE is done at the same linkage stack level. For more information, see [“Parameters” on page 57](#).

Changed

The following information is changed in this publication:

- **June 2021 refresh**
 - Added clarification to EXECUTABLE=YES or NO on the STORAGE macro. See [“STORAGE OBTAIN” on page 117](#) and [“STORAGE RELEASE” on page 132](#).
- **Prior to June 2021 refresh**
 - The WTO macro is updated to clarify parameter ,DESC=(descriptor code). See [“Description” on page 369](#) for more information.
 - The WTO and WTOR macros are updated to replace the value RX with RS on the CONSNAME, KEY, JOBID, JOBNAME, and SYSNAME parameters. See [“WTO - Execute form” on page 389](#) and [“WTOR - Execute form” on page 410](#) for more information.
 - The SWAREQ macro description is updated. See [Chapter 17, “SWAREQ — Invoke SWA manager in locate mode,” on page 161](#) for more information.
- **Prior to June 2020 refresh**
 - An additional action was added to return code 4 for the STORAGE RELEASE macro. See [“Return and reason codes” on page 139](#).
 - Added information clarifying the results from a STORAGE OBTAIN macro when a system fails to obtain the requested storage. See [“Return and reason codes” on page 131](#), for additional information.

Summary of changes for z/OS Version 2 Release 3

The following information has been added, changed, or deleted in z/OS Version 2 Release 3 (V2R3). The most recent updates are listed at the top of each section.

New

- Added register content section and programming requirements for access registers in [Chapter 24, “TIMEUSED — Obtain accumulated CPU or vector time,” on page 223](#).
- Added a sentence for SAVE and RESTORE under notes in [Chapter 10, “SRBSTAT — Save, restore, or modify SRB status,” on page 101](#).
- Added new EXECUTABLE parameter for API STORAGE to [“STORAGE OBTAIN” on page 117](#).
- Added new UCBINFO GETCDR and HYPERPAVALIASES macros for [Chapter 26, “UCBINFO — Return information from a UCB,” on page 231](#).

Changed

- Several changes were made to [Chapter 20, “SYSEVENT — System event,” on page 187](#).

Deleted

- APAR OA53248 - Return code 1C has been removed from [“STORAGE OBTAIN” on page 117](#).
- Information about interruption type 17 has been removed from [Chapter 8, “SPIE — Specify program interruption exit,” on page 93](#).

Chapter 1. Using the services

Macros and callable services are programming interfaces that application programs can use to access MVS system services. This chapter provides general information and guidelines about how to use the macros and callable services accurately and efficiently. For more specific and detailed information about coding a particular macro or callable service, see the individual service description in this information.

Some of the topics covered in this chapter apply only to macros, some apply only to callable services, and some apply to both. This chapter uses the word "services" when referring to information that applies to both service types. When information applies only to one type or the other, the particular service type is specified.

Note: z/OS macros do not code to restrictions that are imposed by the COMPAT(CASE) HLASM option or its abbreviation CPAT(CASE). Therefore, you cannot rely on using COMPAT(CASE) if you use z/OS macros.

The following table lists the topics covered in this chapter and whether the topic applies to macros, callable services, or both:

Topic	Service Type
"Compatibility of MVS macros" on page 1	Macros
"Addressing mode (AMODE)" on page 2	Both
"Address space control (ASC) mode" on page 3	Both
"ALET qualification" on page 3	Both
"User parameters" on page 4	Macros
"Telling the system about the execution environment " on page 5	Macros
"Specifying a macro version number" on page 6	Macros
"Register use" on page 7	Both
"Handling return codes and reason codes" on page 8	Both
"Handling program errors" on page 8	Both
"Handling environmental and system errors" on page 9	Both
"Using X-macros" on page 9	Macros
"Macro forms" on page 10	Macros
"Coding the macros" on page 11	Macros
"Coding the callable services" on page 14	Callable Services
"Including equate (EQU) statements" on page 14	Callable Services
"Link-editing linkage-assist routines" on page 15	Callable Services
"Service summary" on page 15	Both

Compatibility of MVS macros

When IBM introduces a new version or a new release of an existing version, the new version or release supports all MVS macros from previous versions and releases. Programs assembled on an earlier level of MVS that issue macros will run on later levels of MVS.

In most cases, the reverse is also true. When you assemble programs that issue macros on a particular version and release of MVS, those programs can run on earlier versions and releases of MVS, provided you request only those functions that are supported by the earlier version and release. This is useful for

installations that write applications that might be assembled on one level of MVS, but run on a different level.

As MVS supports new architectures, addressability changes. To take best advantage of the new architectures, some macros have more than one possible expansion. You are required to have the macro expand according to the environment in which the program runs. This topic is described in this introductory information.

The problem of compatibility is not the same as selecting a macro version through the PLISTVER parameter to ensure the correct parameter list size for a macro. For selecting a parameter list version number, see [“Specifying a macro version number”](#) on page 6.

Addressing mode (AMODE)

A program can run in addressing mode (AMODE) 24, 31, or 64. A program that executes in AMODE 24 or 31 can invoke most of the services described in this information. A program that executes in AMODE 64 has a smaller group of services that it can invoke.

In general:

- A program running in AMODE 24 cannot pass parameters or parameter addresses that are higher than 16 megabytes. However, there are exceptions. For example, a program running in AMODE 24 can:
 - Free storage above 16 megabytes using the FREEMAIN macro
 - Allocate storage above 16 megabytes using the GETMAIN macro
 - Use cell pool services for cell pools located in storage above 16 megabytes using the CPOOL macro
 - Use page services for storage locations above 16 megabytes using the PGSER macro
- A program is allowed to call a service from AMODE 64 only if the documentation for the service indicates that it supports AMODE 64.
- A program is allowed to call a service from RMODE 64 only if the documentation for the service indicates that it supports RMODE 64.
- A program running in AMODE 64 should not call a service with data, parameters, or parameter addresses that are higher than 2 gigabytes, unless the individual service description indicates that it is allowed.
- If a program running in AMODE 31 or 64 issues a service, parameters and parameter addresses can be above or below 16 megabytes, unless otherwise stated in the individual service description.

Some macros can generate code that is appropriate for programs in either AMODE 64 or 24 or 31. These macros check a global symbol set by the SYSSTATE macro. See [“Telling the system about the execution environment”](#) on page 5 for more information.

When you call a callable service in AMODE 24 or 31, you must pass 31-bit addresses to the system service regardless of what addressing mode your program is running in. If your program is running in AMODE 24 and you use a callable service, you must set the high-order byte of parameter addresses to zeros.

You can invoke the following services in 64-bit addressing mode, subject to the “SVC or PC” restrictions mentioned later in this topic, but you cannot pass parameters and parameter addresses above 2 gigabytes: ABEND, ATTACHX, CALLDISP, CHAP, CSVQUERY, DELETE, DEQ, DETACH, DOM, DSPSERV, DYNALLOC, ENQ, ESPIE, ESTAEX, EXCP, FREEMAIN, GETMAIN, GTRACE, IARVserv, IDENTIFY, IEAARR, LINKX, LOAD, MODESET, PGSER, POST, RESERVE, SDUMPX, SETRP, STAX, STIMER, STIMERm, STORAGE, SYNCHX, TIME, TIMEUSED, TTIMER, VRADATA, WAIT, WTO, WTOR, and XCTL.

There are many services that support AMODE 64 and parameter addresses above 2 gigabytes. Examples are IRAV64, IARST64, and ISGENQ. For details on the supported addressing mode and parameter address ranges for any specific service, see the following books:

- [z/OS MVS Programming: Assembler Services Reference ABE-HSP](#)
- [z/OS MVS Programming: Assembler Services Reference IAR-XCT](#)

- [z/OS MVS Programming: Authorized Assembler Services Reference ALE-DYN](#)
- [z/OS MVS Programming: Authorized Assembler Services Reference EDT-IXG](#)
- [z/OS MVS Programming: Authorized Assembler Services Reference LLA-SDU](#)
- [z/OS MVS Programming: Authorized Assembler Services Reference SET-WTO](#)
- [z/OS MVS Programming: Sysplex Services Reference](#)

Before invoking a service in AMODE 64, you must inform system macros, by specifying SYSSTATE AMODE64=YES. You can invoke only those options that result in calling the system by an SVC or PC in AMODE 64. You cannot invoke any option that results in calling the system by a branch-entry in AMODE 64.

Unless explicitly stated otherwise, assume that a given service cannot be invoked in AMODE 64 and cannot accept data, parameters, or parameter addresses above 2 gigabytes. Such an explicit statement would include a specific reference to AMODE 64 in a macro's environment section and additional information would mention that data, parameters, and parameter addresses could be above 2 gigabytes. By contrast, an AMODE specification of "Any" means that the macro can be invoked in either AMODE 24 or 31; it does not mean that the macro can be invoked in AMODE 64.

For information about AMODE 64 and the 64-bit GPR, see [z/OS MVS Programming: Extended Addressability Guide](#).

Address space control (ASC) mode

A program can run in either primary ASC mode or access register (AR) ASC mode. In primary mode, the processor uses the contents of general purpose registers (GPRs) to resolve an address to a specific location. In AR mode, the processor uses the contents of ARs as well as the contents of GPRs to resolve an address to a specific location. See [z/OS MVS Programming: Assembler Services Guide](#) for more detailed information about AR mode.

Some macros can generate code that is appropriate for programs in either primary mode or AR mode. These macros check a global symbol set by the SYSSTATE macro. See [“Telling the system about the execution environment” on page 5](#) for more information. [Table 3 on page 16](#) lists the macros that check the global symbol.

Some services can generate code that is appropriate for programs in primary mode only. If you write a program in AR mode that invokes one or more services, check the description in this information for each service your program issues. Unless the description indicates that a service supports callers in AR mode, the service *does not* support callers in AR mode. In this case, use the SAC instruction to change the ASC mode of your program and issue the service in primary mode.

Whether the caller is in primary or AR ASC mode, the system uses ARs 0-1 and 14-15 as work registers across any service call.

ALET qualification

The address space where you can place parameters varies with the individual service:

- You can place parameters in the primary address space in all service.
- You must place parameters in the primary address space in some services.
- You can place parameters in any address space in some services.

To identify where you can locate parameters in a service, read the individual service description.

Programs in AR mode that pass parameters must use an access register and the corresponding general purpose register together (for example, access register 1 and general purpose register 1) to identify where the parameters are located. The access register must contain an access list entry token (ALET) that identifies the address space where the parameters reside. The general purpose register must identify the location of the parameters within the address space.

The only ALETs that MVS services typically accept are:

- Zero (0), which specifies that the parameters are in the caller's primary address space
- An ALET for a public entry on the caller's dispatchable unit access list (DU-AL)
- An ALET for a common area data space (CADS)

MVS services do not accept the following ALETs, and you cannot attempt to pass them to a service:

- One (1), which signifies that the parameters are in the caller's secondary address space
- An ALET that is on the caller's primary address space access list (PASN-AL) that does not represent a CADS
- An ALET for a private entry on the PASN-AL or the DU-AL

Throughout, this information uses the term **AR/GPR *n*** to mean an access register and its corresponding general purpose register. For example, to identify access register 1 and general purpose register 1, this information uses **AR/GPR 1**.

User parameters

Some macros that you can issue in AR mode include control parameters, user parameters, or both. Control parameters refer to the macro parameter list, and the parameters whose addresses are in the parameter list. Control parameters control the operation of the macro itself. User parameters are parameters that a user provides to be passed through to a user routine. For example, the PARAM parameter on the ATTACHX macro defines user parameters. The ATTACHX macro passes these parameters to the routine that it attaches. All other parameters on the ATTACHX macro are control parameters that control the operation of the ATTACHX macro.

Note:

1. User parameters are sometimes referred to as problem program parameters.
2. Control parameters are sometimes referred to as system parameters or control program parameters.

The macros shown in Table 1 on page 4 allow a caller in AR mode to pass information in the form of a parameter list (or parameter lists) to another routine. This table identifies the parameter that receives the ALET-qualified address of the parameter list and tells you where the target routine finds the ALET-qualified address.


Table 1. Passing User Parameters in AR Mode		
Macro	Parameter	Location of User Parameter List Address
ATTACH/ATTACHX	PARAM,VL=1	AR/GPR 1 contains the address of a list of addresses. When either <ul style="list-style-type: none"> • a 4-bytes-per-entry parameter list or • an 8-bytes-per-entry parameter list with PLIST8ARALETs=YES is being used, this list also contains the ALETs associated with those addresses. (See Figure 1 on page 5 for the format of the 4-bytes-per-entry parameter list when it contains ALETs.)
ESTAEX	PARAM	SDWAPARM contains the address of an 8-byte area, which contains the address and ALET of the parameter list.

When an AR mode caller who is using a 4-bytes-per-entry parameter list passes ALET-qualified addresses to the called program through PARAM,VL=1 on the ATTACH/ATTACHX macro, the system builds a list formatted as shown in Figure 1 on page 5. The addresses passed to the called program are at the beginning of the list, and their associated ALETs follow the addresses. The last address in the list has the high-order bit on to indicate the end of the list. For example, Figure 1 on page 5 shows the format of a

list where an AR mode issuer of ATTACHX who is using a 4-bytes-per-entry parameter list has coded the PARAM parameter as follows:

```
PARAM=(A,B,C),VL=1
```

When an AR mode caller who is using an 8-bytes-per-entry parameter list specifies PLIST8ARALETs=YES, the system builds a parameter list with the 8-byte addresses at the beginning of the list and their associated 4-byte ALETs following the addresses.



For information about linkage conventions, see the chapter in *z/OS MVS Programming: Assembler Services Guide*.

Telling the system about the execution environment

To generate code that is correct for the environment in which the program runs, some macros need to know one or more of the following characteristics about that environment:

- The addressing mode (AMODE) at the time the macro is issued
- The ASC mode of the program at the time the macro is issued
- The architectural level in which the program runs

For macros that are sensitive to their environment, use the SYSSTATE macro to define the environment. During the assembly stage, SYSSTATE sets one or more global symbols. Later, in your source code, the macro checks the global symbols and generates the correct code, which might mean avoiding using a z/Architecture® instruction or an access register. Table 3 on page 16 lists MVS macros and identifies macros that need to know the environmental characteristics.

IBM recommends you issue the SYSSTATE macro before you issue other macros. Once a program has issued SYSSTATE, there is no need to reissue it, unless the program switches from one AMODE to another or one ASC mode to another or has code paths that are isolated according to architecture level or operating system release. If you switch AMODE or ASC mode to a different architecture code path, issue SYSSTATE immediately after the switch to indicate the new state. In general, specify SYSSTATE ARCHLVL=2, and switch to SYSSTATE ARCHLVL=3 before issuing macros in sections of code that only run when z/OS 2.1 capabilities are available. If you do not issue the SYSSTATE macro, the system assumes the macro is issued as follows:

- In AMODE other than 64-bit
- In primary ASC mode
- Usually, in ESA/390 architectural level (but may assume z/Architecture level since all supported z/OS releases require z/Architecture level)

Table 2 on page 5 describes the relevant characteristics, the corresponding parameters on the SYSSTATE macro, and the global symbols the macro checks.

Table 2. Execution environment characteristics and corresponding SYSSTATE parameters and global symbols		
Characteristic	Parameter on SYSSTATE	Global symbol
AMODE of 64-bit, or either 24-bit or 31-bit	AMODE64=YES or NO	&SYSAM64

Table 2. Execution environment characteristics and corresponding SYSSTATE parameters and global symbols (continued)		
Characteristic	Parameter on SYSSTATE	Global symbol
Primary or AR ASC mode	ASCENV=P or AR	&SYSASCE
Architectural level of z/Architecture	ARCHLVL=0, 1, 2, 3 or OSREL	&SYSALVL
Operating system release	ZOSVvRr	&SYSOSREL

You can issue the SYSSTATE macro with the TEST parameter in your own user-written macro to allow your macros to generate code appropriate for their execution environment.

Callable services do not check the global symbols described in this topic. To determine whether a callable service is sensitive to the AMODE, ASC mode, or the Architecture level, see the description of the individual callable service.

In early releases of MVS, the SPLEVEL macro performs a function similar to SYSSTATE. The SPLEVEL macro identifies the level of the operating system, so that you can tune a macro expansion based on that level. You can use this where macro expansions change incompatibly. Because SPLEVEL applies to levels that the system no longer supports, it is not described in this topic.

Specifying a macro version number

Often there is more than one version of a macro, differentiated by additional parameters or new or expanded function. For example, version 1 of the IXGCONN macro provides a connection to a log stream, while version 2 adds new parameters in support of resource manager programs. This is different than using the SPLEVEL macro to select a macro version level to solve problems of downward compatibility.

You can request a specific version of a macro based on the parameters you need to use in your application, but you should also be attuned to the storage constraints of the program. The version of a macro might affect the length of the parameter list generated when the macro is assembled, because when you add new parameters to a macro, the parameter list must be large enough to fit them. The size of the parameter list might grow from release to release of z/OS, perhaps affecting the amount of storage your program needs.

How to request a macro version using PLISTVER

Many macros that have one or more versions supply the PLISTVER parameter. For those that do, use the PLISTVER parameter to request a version of the macro. PLISTVER is the only parameter allowed on the list form of a macro (MF), and it determines which parameter list the system generates. PLISTVER is optional. If you omit it, the system generates a parameter list for the lowest version that will accommodate the parameters specified. This is the IMPLIED_VERSION default. Note that on the list form, the default will cause the smallest parameter list to be created.

You can also code a specific version number using *plistver*, or specify MAX:

- You can use ***plistver*** to code a decimal value corresponding to the version of the macro you require. The decimal value you provide determines the amount of storage allotted for the parameter list.
- You can use **MAX** to request that the system generate a parameter list for the highest version number currently available. The amount of storage allotted for the parameter list will depend on the level of the system on which the macro is assembled.

IBM recommends, if your program can tolerate additional growth, that you always specify PLISTVER=MAX on the list form of the macro. MAX ensures that the list form parameter list is always long enough to hold whatever parameters might be specified on the execute form when both forms are assembled using the save level of the system.

Hints for using PLISTVER

There are some general considerations that you should keep in mind when specifying the version of a macro with PLISTVER:

- If PLISTVER is omitted, the macro generates a parameter list of the lowest version that allows all the parameters specified to be processed.
- If you code PLISTVER=*n* and then specify any version '*n*+1' parameter, the macro will not assemble.
- If you code PLISTVER=*n* and do not specify any version '*n*' parameter, the macro will generate a version '*n*' parameter list.
- If you are using the standard form of the macro (MF=S), there is no reason you need to code the PLISTVER parameter.
- Not all macros have the same version numbers. The version numbers need not be contiguous.

The PLISTVER parameter appears in the syntax diagram and in the parameter descriptions. Within each macro description, the PLISTVER parameter description specifies the range of values and lists the parameters applicable for each version of the macro.

Register use

Some services require that the caller place information in specific general purpose registers (GPRs) or access registers (ARs) prior to issuing the service. If a service has such a requirement, the "Input Register Information" topic for the service provides that information. The topic lists only those registers that have a requirement. If a register is not specified as having a requirement, then the caller does not have to place any information in that register unless using it in register notation for a particular parameter, or using it as a base register.

Once the caller issues the service, the system can change the contents of one or more registers, and leave the contents of other registers unchanged. When control returns to the caller, each register contains one of the following values or has the following status:

- The register content is preserved and is the same as it was before the service was issued.
- The register contains a value placed there by the system for the caller's use. Examples of such values are return codes and tokens.
- The system used the register as a work register. Do not assume that the register content is the same as it was before the service was issued.

Unless otherwise defined by the individual interface, the calling program expects upon return:

- The low halves (Bits 32-63) of GPRs 0, 1, 14, 15 are not preserved; the low halves of GPRs 2-13 are preserved.
- The high halves (Bits 0-31) of GPRs 0, 1, and 15 are not preserved; the high halves of GPRs 2-14 are preserved.
- When GPR 0, 1, 14, and/or 15 is defined as unchanged, unless otherwise stated by the individual interface, that definition applies only to the low halves of those registers.
- ARs 0,1, 14, 15 are not preserved; ARs 2-13 are preserved.

For more information about linkage conventions for a calling program's registers, see the "Saving the calling program's registers" topic in the "Linkage conventions" chapter in *z/OS MVS Programming: Assembler Services Guide*.

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Many macros require that the caller have a program base register and assembler USING instruction in effect when issuing the macro; that is, the caller must have *program addressability*. AR mode programs also require that the AR associated with the caller's base GPR be set to zero. **IBM recommends** the following:

- When issuing a macro, the caller should always have program addressability in effect.
- When establishing addressability, the caller should use only registers 2 through 12.

Many macros can take advantage of relative branching when they are used with the IEABRC macro or with SYSSTATE ARCHLVL=1 or SYSSTATE ARCHLVL=2, if they are running on z/OS. If relative branching is used, the caller might then need addressability only to the static data portion of the program, and not to the executable code.

Handling return codes and reason codes

Most of the services described in this information provide return codes and reason codes. Return and reason codes indicate the outcome of the service in one of the following ways:

- Successful completion: you do not need to take any action.
- Successful or partially successful completion, with additional information supplied: you should evaluate the additional information in light of your particular program and determine if you need to take any action.
- Unsuccessful completion: some type of error has occurred, and you must take some action to correct the error.

The errors that cause unsuccessful completion fall into three broad categories:

Program errors

Errors that your program causes: you can correct these.

Environmental errors

Errors not caused directly by your program; rather, your program's request caused a limit to be exceeded, such as a storage limit, or the limit on the size of a particular data set. You might or might not be able to correct these.

System errors

Errors caused by the system: your program did nothing to cause the error, and you probably cannot correct these.

In some cases, a return or reason code can result from some combination of these errors.

The return and reason code descriptions for the services in this information indicate whether the error is a program error, an environmental error, a system error, or some combination. Whenever possible, the return and reason code descriptions give you a specific action that you can take to fix the error.

IBM recommends that you read all the return and reason codes for each service that your program issues. You can then design your program to handle as many errors as possible. When designing your program, you should allow for the possibility that future releases of MVS might add new return and reason codes to a service that your program issues.

Handling program errors

The actions to take in the case of program errors are usually straightforward. Typical examples of program errors are:

1. Breaking one of the rules of the service. For example:
 - Passing parameters that are either in the wrong format or not valid
 - Violating one of the environment requirements (addressing mode, locking requirements, dispatchable unit mode, and so on)
 - Providing insufficient storage for information to be returned by the system.
2. Causing errors related to the parameter list. For example:
 - Coding an incorrect combination of parameters
 - Coding one or more parameters on the service incorrectly
 - Inadvertently overlaying an area of the parameter list storage
 - Inadvertently destroying the pointer to the parameter list.

3. Requesting a service or function for which the calling program is not authorized, or which is not available on the system on which the program is running.

In each of the first two cases, you can correct your program. For completeness, the return and reason code descriptions give you specific actions to perform, even when it might seem obvious what the action should be.

In the third case, you might have to contact your system administrator or system programmer to obtain the necessary authorization, or to request that the service or function be made available on your system, and the return or reason code description asks you to take that step.

Note: Generally, the system does not take dumps for errors that your program causes when issuing a system service. If you require such a dump, then it is your responsibility to request one in your recovery routine. See the topic on providing recovery in *z/OS MVS Programming: Authorized Assembler Services Guide* for information about writing recovery routines.

Handling environmental and system errors

With environmental errors, often your first action should be to rerun your program or retry the request one or more times. The following are examples of environmental errors where rerunning your program or retrying the request is appropriate:

- The request being made through the service exceeds some internal system limit. Sometimes, rerunning your program or retrying the request results in successful completion. If the problem persists, it might be an indication of a larger problem requiring you to consult your system programmer, or possibly IBM support personnel. Your system programmer might be able to tune the system or cancel users so that the limit is no longer exceeded.
- The request exceeds an installation-defined limit. If the problem persists, the action might be to contact your system programmer and request that a specification in an installation exit or parmlib member be modified.
- The system cannot obtain storage, or some other resource, for your request. If the problem persists, the action might be to check with the operator to see if another user in the installation is causing the problem, or to see if the entire installation is experiencing storage constraint problems.

You might be able to design your program to anticipate certain environmental errors and handle them dynamically.

With system errors, as with environmental errors, often your first action should be to rerun your program or retry the request one or more times. If the problem persists, you might have to contact IBM support personnel.

Whenever possible for environmental and system errors, the return or reason code description gives you either a specific action you can take, or a list of recommended actions you can try.

For some errors, providing a specific action is not possible, because the action you should take depends on your particular application, and on what is happening in your installation. In those cases, the return or reason code description gives you one or more possible causes of the error to help you to determine what action to take.

Some system errors result in return and reason codes that are provided for IBM diagnostic purposes only. In these cases, the return or reason code description asks you to record the information and provide it to the appropriate IBM support personnel.

Using X-macros

Some MVS services support callers in both primary and AR ASC mode. When the caller is in AR mode, macros must generate larger parameter lists; the increased size of the list reflects the addition of ALETs to qualify addresses, as described under [“ALET qualification” on page 3](#). For some MVS macros, two versions of a particular macro are available: one for callers in primary mode and one for callers in AR mode. The name of the macro for the AR mode caller is the same as the name of the macro for primary mode callers, except the AR mode macro name ends with an “X”. This information refers to these macros as **X-macros**.

The authorized X-macros are:

- ATTACHX
- ESTAEX
- SDUMPX
- SYNCHX

The only way these macros know that a caller is in AR mode is by checking the global symbol that the SYSSTATE macro sets. Each of these macros (and corresponding non-X-macro) checks the symbol. If SYSSTATE ASCENV=AR has been issued, the macro issues code that is valid for callers in AR mode. If it has not been issued, the macro generates code that is not valid for callers in AR mode. When your program returns to primary mode, use the SYSSTATE ASCENV=P macro to reset the global symbol.

IBM recommends that you use the X-macro regardless of whether your program is running in primary or AR mode. However, you should consider the following before deciding which macro to use:

The rules for using all X-macros, except ESTAEX, are:

- Callers in primary mode can invoke either macro.

Some parameters on the X-macros, however, are not valid for callers in primary mode. Some parameters on the non-X-macros are not valid for callers in AR mode. Check the macro descriptions for these exceptions.

- Callers in AR mode should issue the X-macros.

If a caller in AR mode issues the non-X-macro, the system substitutes the X-macro and sends a message describing the substitution.

IBM recommends you always use ESTAEX unless your program and your recovery routine are in 24-bit addressing mode, or your program requires a branch entry. In these cases, you should use ESTAE.

Macro forms

You can code most macros in three forms: standard, list, and execute. Some macros also have a modify form. When you code a macro, you use the MF parameter to select one of the forms. The list, execute and modify forms are for reenterable programs that need to change values in the parameter list of the macro. The standard form is for programs that are not reenterable, or for programs that do not change values in the parameter list.

When a program wants to change values in the parameter list of a macro, it can make the change dynamically.

However, using the standard form and changing the parameter list dynamically might cause errors. For example, after storing a new value into the inline, standard form of the parameter list, a reenterable program operating under a given task might be interrupted by the system before the program can invoke the macro. In a multiprogramming environment, another task can use the same reenterable program, and that task might change the inline parameter list again before the first task regains control. When the first task regains control, it invokes the macro. However, the inline parameter list now has the wrong values.

Through the use of the different macro forms, a program that runs in a multiprogramming environment can avoid errors related to reenterable programs. The techniques required for using the macro forms, however, are different for some macros, called alternative list form macros, than for most other macros. For the alternative list form macros, the list form description notes that different techniques are required and refers you to the information under [“Alternative list form macros” on page 11](#).

Conventional list form macros

With conventional list form macros, you can use the macro forms as follows:

1. Use the list form of the macro, which expands to the parameter list. Place the list form in the section of your program where you keep non-executable data, such as program constants. Do not code it in the instruction stream of your program.

2. In the instruction stream, code a GETMAIN or a STORAGE macro to obtain some virtual storage.
3. Code a move character instruction that moves the parameter list from its non-executable position in your program into the virtual storage area that you obtained.
4. For macros that have a modify form, you can code the modify form of the macro to change the parameter list. Use the address parameter of the modify form to reference the parameter list in the virtual storage area that you obtained. Thus, the parameter list that you change is the one in the virtual storage area obtained by the GETMAIN or STORAGE macro.
5. Invoke the macro by issuing the execute form of the macro. Use the address parameter of the execute form to reference the parameter list in the virtual storage area that you obtained.

With this technique, the parameter list is safe even if the first task is interrupted and a second task intervenes. When the program runs under the second task, it cannot access the parameter list in the virtual storage of the first task.

Alternative list form macros

Certain macros, called alternative list form macros, require a somewhat different technique for using the list form. With these macros, you do not move the area defined by the list form into virtual storage that you have obtained; instead, you place the area defined by the list form into a DSECT. Also, it is the list form, not the execute form, that you use to specify the address parameter that identifies the address of the storage for the parameter list. Note that no modify form is available for these macros.

You can use the macro forms for the alternative list form macros as follows:

1. Use the list form of the macro to define an area of storage that the execute form can use to store the parameters. As with other macros, do not code the list form in the instruction stream of your program.
2. In the instruction stream, code a GETMAIN or a STORAGE macro to obtain virtual storage for the list form expansion.
3. Place the area defined by the list form into a DSECT that maps a portion of the virtual storage you obtained.
4. Invoke the macro by issuing the execute form of the macro. The address parameter specified on the list form references the parameter list in the virtual storage area that you obtained.

Coding the macros

In this information, each macro description includes a syntax diagram near the beginning of the macro description. The diagram shows how to code the macro. The syntax diagram does not explain the meanings of the parameters; the meanings are explained in the parameter descriptions that follow the syntax diagram. For most macros, the syntax diagrams are in a tabular format; however, some newer macros might have syntax diagrams in the railroad track format.

The syntax tables assume that the standard begin, end, and continue columns are used. Thus, column 1 is assumed as the begin column. To change the begin, end, and continue columns, use the ICTL instruction to establish the coding format you want to use. If you do not use ICTL, the assembler recognizes the standard columns. For more information about coding the ICTL instruction, see [High Level Assembler and Toolkit Feature in IBM Documentation \(www.ibm.com/docs/en/hla-and-tf/1.6\)](http://www.ibm.com/docs/en/hla-and-tf/1.6).

Figure 2 on page 12 shows a sample macro called TEST and summarizes all the coding information that is available for it. The table is divided into three zones, A, B, and C.




Figure 2. Sample tabular syntax diagram for the TEST macro

- Column one of the table contains zones A and B. Zone A begins at the left margin; zone B is indented from the left margin by one or more blank spaces. Column two of the table contains zone C.
- Zone A and zone B contain those parameters that are allowed for the macro. Zone A contains those parameters that are required; zone B contains those parameters that are optional.
- If a parameter appears on a single line in the diagram (that is, a line whose preceding line and following line are both blank), as shown in A1 and B1, then that is the only available choice for the particular parameter.
- If two or more parameters appear on adjacent lines (that is, with no intervening blank lines), as shown in A2 and B2, the parameters on those lines are mutually exclusive, that is, you can code any one of those parameters.
- A further distinction is made between mandatory and optional parameters. The parameter descriptions that follow the syntax table clearly identify those parameters which are optional.
- Zone C (which is the second column in the syntax table), provides additional information about coding the macro.

When substitution of a variable is indicated in zone C, the following classifications are used:

Variable

Classification

symbol

Any symbol valid in the assembler language. The symbol can be as long as the supported maximum length of a name entry in the assembler you are using.

Decimal digit

Any decimal digit up to and including the value indicated in the parameter description. If both symbol and decimal digit are indicated, an absolute expression is also allowed.

Register (2) - (12)

One of general purpose registers 2 through 12, specified within parentheses, previously loaded with the right-adjusted value or address indicated in the parameter description. You must set the unused high-order bits to zero. You can designate the register symbolically or with an absolute expression.

Register (0)

General purpose register 0, previously loaded with the right-adjusted value or address indicated in the parameter description. You must set the unused high-order bits to zero. Designate the register as (0) only.

Register (1)

General purpose register 1, previously loaded with the right-adjusted value or address indicated in the parameter description. You must set the unused high-order bits to zero. Designate the register as (1) only.

Register (15)

General purpose register 15, previously loaded with the right-adjusted value or address indicated in the parameter description. You must set the unused high-order bits to zero. Designate the register as (15) only.

RX-type address

Any address that is valid in an RX-type instruction (for example, LA).

RS-type address

Any address that is valid in an RS-type instruction (for example, STM).

RS-type name

Any name that is valid in an RS-type instruction (for example, STM).

A-type address

Any address that can be written in an A-type address constant.

Default

A value that is used in default of a specified value; that is, the value the system assumes if the parameter is not coded.

Rules for parameters: Use the parameters to specify the services and options to be performed, and write them according to the following rules:

- If the selected parameter is written in all capital letters (for example, MATH, HIST, or FMT=HEX), code the parameter exactly as shown.
- If the selected parameter is written in italics (for example, *grade*), substitute the indicated value, address, or name.
- If the selected parameter is a combination of capital letters and italics separated by an equal sign (for example, DATA=*data addr*), code the capital letters and equal sign as shown, and then make the indicated substitution for the italicized portion.
- Read the table from top to bottom.
- Code commas and parentheses exactly as shown.
- Positional parameters (parameters without equal signs) appear first; you must code them in the order shown. You may code keyword parameters (parameters with equal signs) in any order.
- If you select a parameter, read the second column (zone C) before proceeding to the next parameter. The second column often contains coding restrictions for the parameter.

Continuation lines

You can continue the parameter field of a macro on one or more additional lines according to the following rules:

- Enter a continuation character (not blank, and not part of the parameter coding) in column 72 of the line.
- Continue the parameter field on the next line, starting in column 16. All columns to the left of column 16 must be blank.

You can code the parameter field being continued in one of two ways. Code the parameter field through column 71, with no blanks, and continue in column 16 of the next line; or truncate the parameter field by a comma, where a comma normally falls, with at least one blank before column 71, and then continue in column 16 of the next line. Figure 3 on page 14 shows an example of each method.




Figure 3. Continuation Coding

Coding the callable services

A callable service is a programming interface that uses the CALL macro to access system services. To code a callable service, code the CALL macro followed by the name of the callable service, and a parameter list; for example:

```
CALL service,(parameter list)
```

The syntax diagram for the sample callable service SCORE:

Syntax	Description
CALL SCORE	,(test_type ,level ,data ,format_option ,return_code)

Considerations for coding callable services are:

- You must code all the parameters in the parameter list because parameters are positional in a callable service interface. That is, the function of each parameter is determined by its position with respect to the other parameters in the list. Omitting a parameter, therefore, assigns the omitted parameter's function to the next parameter in the list.
- You must place values explicitly into all input parameters, because callable services do not set default values.
- You can use the list and execute forms of the CALL macro to preserve your program's reentrancy.

Including equate (EQU) statements

IBM supplies sets of equate (EQU) statements for use with some callable services. These statements, which you may optionally include in your source code, provide constants for use in your program. IBM provides the statements as a programming convenience to save you the trouble of coding the definitions yourself.

Note: Check the “Programming Requirements” section of the individual service description to determine if the equate statements are available for the callable service you are using. If the equate statements are

available, that section will also provide a list of the statements that are provided, along with a description of how to include them in your program.

Link-editing linkage-assist routines

Linkage-assist routines provide the connection between your program and the system services that your program requests. When using callable services, link-edit the appropriate linkage-assist routines into your program module so that, during execution, the linkage-assist routines can resolve the address of, and pass control to, the requested system services. You can also dynamically link to linkage-assist routines as an alternative to link-editing. For example, issue the LOAD macro for the linkage-assist routine, then issue a CALL to the loaded addresses.

To invoke the linkage-editor or binder, code JCL as in the following example:

```
//userid JOB 'accounting-info','name',CLASS=x,
// MSGCLASS=x,NOTIFY=userid,MSGLEVEL=(1,1),REGION=4096K
//LINKSTEP EXEC PGM=HEWL,
// PARM='LIST,LET,XREF,REFR,RENT'
//SYSPRINT DD SYSOUT=x
//SYSLMOD DD DSN=userid.LOADLIB,DISP=OLD
//SYSLIB DD DSN=SYS1.CSSLIB,DISP=SHR
//OBJLIB DD DSN=userid.OBJLIB,DISP=SHR
//SYSUT1 DD UNIT=SYSDA,SPACE=(TRK,(5,2))
//SYSLIN DD *
INCLUDE OBJLIB(userpgm)
ENTRY userpgm
NAME userpgm(R)
/*
```

Note: Omitting NCAL from the linkedit parameters (as the example shows) and specifying SYS1.CSSLIB in the //SYSLIB statement, as shown, causes the addresses of all required linkage-assist routines to be automatically resolved. This statement saves you the trouble of having to specify individual linkage-assist routines in INCLUDE statements.

Service summary

Table 3 on page 16 lists services described in the following:

- [*z/OS MVS Programming: Authorized Assembler Services Reference ALE-DYN*](#)
- [*z/OS MVS Programming: Authorized Assembler Services Reference EDT-IXG*](#)
- [*z/OS MVS Programming: Authorized Assembler Services Reference LLA-SDU*](#)
- [*z/OS MVS Programming: Authorized Assembler Services Reference SET-WTO*](#).

For each service, the table indicates:

- Whether a program in AR ASC mode can issue the service
- Whether a program in cross memory mode can issue the service
- Whether the macro checks the SYSSTATE global macro variables
- Whether the macro can be issued in 64-bit addressing mode

Note:

1. A program running in primary ASC mode when PASN=HASN=SASN can issue any of the services listed in the table.
2. Cross memory mode means that at least one of the following conditions is true:

PASN≠SASN

The primary address space (PASN) and the secondary address space (SASN) are different.

PASN≠HASN

The primary address space (PASN) and the home address space (HASN) are different.

SASN≠HASN

The secondary address space (SASN) and the home address space (HASN) are different.

For more information about functions that are available to programs in cross memory mode, see [z/OS MVS Programming: Extended Addressability Guide](#).

3. Callable services do not check the SYSSTATE or SPLEVEL global variables.

Table 3. Service Summary				
Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
ALESERV	Yes	Yes	No	No
ASCRE	Yes	Yes	Yes	No
ASDES	Yes	Yes	Yes	No
ASEXT	Yes	Yes	No	No
ATSET	No	Yes	Yes	No
ATTACH	Yes (See note “1” on page 24)	No	Yes	No
ATTACHX	Yes	No	Yes	Yes
AXEXT	No	Yes	Yes	No
AXFRE	No	Yes	Yes	No
AXRES	No	Yes	Yes	No
AXREXX	No	Yes	Yes	Yes
AXSET	No	Yes	Yes	No
BPXEKDA	Yes	No	Yes	No
BPXESMF	Yes	No	Yes	No
CALLDISP	No	Yes	No	Yes
CALLRTM	No	Yes (See note “2” on page 24)	No	No
CHANGKEY	No	Yes	No	No
CIRB	No	No	No	No
CMDAUTH	No	No	No	No
CNZMXURF	No	Yes	No	No
CNZTRKR	No	Yes	No	No
COFCREAT	Yes	Yes	Yes	No
COFDEFIN	Yes	Yes	Yes	No
COFIDENT	Yes	Yes	Yes	No
COFNOTIF	Yes	Yes	Yes	No
COFPURGE	Yes	Yes	Yes	No
COFREMOV	Yes	Yes	Yes	No
COFRETRI	Yes	Yes	Yes	No
COFSDONO	No	No	Yes	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
CONFCHG	No	No	Yes	No
CPF	No	No	No	No
CPOOL	No	Yes	Yes	No
CPUTIMER	No	Yes	Yes	No
CSRSI	No	Yes	No	No
CSRUNIC	Yes	Yes	No	No
CSVAPF	Yes (See note “11” on page 25)	Yes (See note “12” on page 25)	Yes	No
CSVDYNEX	Yes (See note “13” on page 25)	Yes (See note “14” on page 25)	Yes	No
CTRACE	No	No	Yes	No
CTRACECS	Yes	No	Yes	No
CTRACEWR	Yes	Yes	Yes	No
DATOFF	Yes	No	No	No
DEQ	No	Yes	Yes	Yes
DIV	Yes	No	Yes	No
DOM	No	No	No	Yes
DSPSERV	Yes	Yes	Yes	Yes
DYNALLOC	No	No	No	Yes
EDTINFO	No	Yes	Yes	Yes
ENFREQ	No	No	No	No
ENQ	No	Yes	Yes	Yes
ESPIE	No	No	No	Yes
ESTAE (See note “3” on page 24)	No	No	Yes	No
ESTAEX	Yes	Yes	Yes	Yes
ETCON	No	Yes	Yes	No
ETCRE	No	Yes	Yes	No
ETDEF	Yes	Yes	No	No
ETDES	No	Yes	Yes	No
ETDIS	No	Yes	Yes	No
EVENTS	No	No	No	No
EXTRACT	No	No	No	No
FESTAE	No	No	No	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
FREEMAIN	Yes (See note “4” on page 25)	Yes	Yes	Yes
GETDSAB	No	No	Yes	No
GETMAIN	Yes (See note “4” on page 25)	Yes	Yes	Yes
GQSCAN	No	Yes	No	No
GTRACE	No	Yes	No	Yes
HSPSERV	Yes	Yes (See note “5” on page 25)	(See note “6” on page 25)	No
IARCP64	Yes	Yes	Yes	Yes
IARR2V	Yes	Yes	No	No
IARSUBSP	Yes	Yes	Yes	No
IARST64	Yes	Yes	Yes	Yes
IARVserv	Yes	Yes	Yes	No
IARV64	Yes	Yes	Yes	Yes
IAZXCTKN	Yes	Yes	Yes	No
IAZXJSAB	Yes	Yes (See note “15” on page 25)	Yes	No
IEAARR	Yes	Yes	Yes	Yes
IEAFP	Yes	Yes	Yes	No
IEALSQRY	Yes	Yes	Yes	No
IEAMETR	Yes	Yes	Yes	No
IEAMRMF3	No	Yes	No	No
IEAMSCHD	Yes	Yes	Yes	No
IEANTCR	Yes	Yes	N/A	No
IEANTDL	Yes	Yes	N/A	No
IEANTRT	Yes	Yes	N/A	No
IEARBUP	Yes	Yes	Yes	No
IEATDUMP	Yes	No	Yes	No
IEATEDS	Yes	Yes	Yes	No
IEATXDC	Yes	Yes	Yes	Yes
IEAVAPE	No	Yes	No	No
IEAVAPE2	No	Yes	No	No
IEAVDPE	No	Yes	No	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
IEAVDPE2	No	Yes	No	No
IEAVPSE	No	Yes	No	No
IEAVPSE2	No	Yes	No	No
IEAVRLS	No	Yes	No	No
IEAVRLS2	No	Yes	No	No
IEAVRPI	No	Yes	No	No
IEAVRPI2	No	Yes	No	No
IEAVTPE	No	Yes	No	No
IEAVXFR	No	Yes	No	No
IEAVXFR2	No	Yes	No	No
IEA4APE	No	Yes	No	Yes
IEA4APE2	No	Yes	No	Yes
IEA4DPE	No	Yes	No	Yes
IEA4DPE2	No	Yes	No	Yes
IEA4PSE	No	Yes	No	Yes
IEA4PSE2	No	Yes	No	Yes
IEA4RLS	No	Yes	No	Yes
IEA4RLS2	No	Yes	No	Yes
IEA4RPI	No	Yes	No	Yes
IEA4RPI2	No	Yes	No	Yes
IEA4TPE	No	Yes	No	Yes
IEA4XFR	No	Yes	No	Yes
IEA4XFR2	No	Yes	No	Yes
IEECMDS	Yes	Yes	Yes	No
IEEQEMCS	Yes	Yes	Yes	No
IEEVARYD	No	No	Yes	No
IEFPPSCN	No	No	Yes	No
IEFQMREQ	No	No	No	No
IEFSSI	Yes	No	No	No
IEFSSVT	Yes	No	No	No
IEFSSVTI	Yes	Yes	No	No
IFAQUERY	Yes	Yes	No	No
IOCINFO	Yes	Yes	No	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
IOSADMF	No	No	Yes	No
IOSCAPF	No	Yes (See note “7” on page 25)	Yes	No
IOSCAPU	Yes	Yes (See note “7” on page 25)	Yes	No
IOSCDR	No	No	Yes	No
IOSCHPD	Yes	Yes	Yes	No
IOSCMXA	No	Yes (See note “7” on page 25)	Yes	No
IOSCMXR	No	Yes (See note “7” on page 25)	Yes	No
IOSDCXR	No	Yes (See note “7” on page 25)	Yes	No
IOSENQ	Yes	Yes	Yes	No
IOSINFO	No	No	No	No
IOSLOOK	No	No	No	No
IOSPTHV	No	No	Yes	No
IOSSPOF	No	Yes	Yes	Yes
IOSUPFA	No	Yes	Yes	No
IOSUPFR	No	Yes	Yes	No
IOSVRYSW	Yes	Yes	Yes	No
IOSWITCH	Yes	Yes	Yes	No
IOSZHPF	Yes	Yes	Yes	No
IRDFSD	Yes	Yes	Yes	No
IRDFSDU	Yes	Yes	Yes	No
ISGADMIN	Yes	Yes	Yes	Yes
ISGECA	Yes	Yes	Yes	Yes
ISGENQ	Yes	Yes	Yes	Yes
ISGLCRT (See note “16” on page 25)	No	Yes	N/A	No
ISGLID (See note “16” on page 25)	No	Yes	N/A	Yes
ISGLOBT	No	Yes	N/A	No
ISGLREL	No	Yes	N/A	No
ISGLPRG	No	Yes	N/A	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
ISGQUERY	Yes	Yes	Yes	Yes
ITTFMTB	No	No	No	No
ITZXFLT	No	Yes	Yes	No
IWMCLSFY	No	Yes	Yes	No
IWMCONN	No	Yes	Yes	No
IWMDISC	No	Yes	Yes	No
IWMECQRY	No	Yes	Yes	No
IWMECREA	No	Yes	Yes	No
IWMEDELE	No	Yes	Yes	No
IWMMABNL	No	Yes	No	No
IWMMCHST	No	Yes	No	No
IWMMCREA	No	Yes	Yes	No
IWMMDELE	No	Yes	Yes	No
IWMMEXTR	No	Yes	Yes	No
IWMMINIT	No	Yes	No	No
IWMMNTFY	No	Yes	Yes	No
IWMMRELA	No	Yes	Yes	No
IWMMSWCH	No	Yes	Yes	No
IWMMXFER	No	Yes	No	No
IWMPQRY	Yes	Yes	Yes	No
IWMRCOLL	Yes	Yes	Yes	No
IWMRPT	No	Yes	Yes	No
IWMRQRY	Yes	Yes	Yes	No
IWMSRDRS	No	Yes	Yes	No
IWMSRSRG	No	Yes	Yes	No
IWMSRSRS	No	Yes	Yes	No
IWMWMCON	No	Yes	Yes	No
IWMWQRY	Yes	Yes	Yes	No
IWMWQWRK	No	Yes	Yes	No
IXCCREAT	Yes	Yes	Yes	No
IXCDELET	Yes	Yes	Yes	No
IXCJOIN	Yes	No	Yes	No
IXCLEAVE	Yes	No	Yes	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
IXCMG	Yes	Yes	Yes	No
IXCMOD	Yes	Yes	Yes	No
IXCMSGI	Yes	No	Yes	No
IXCMSGO	Yes	Yes	Yes	No
IXCQUERY	Yes	Yes	Yes	No
IXCQUIES	Yes	No	Yes	No
IXCSETUS	Yes	Yes	Yes	No
IXCTERM	Yes	Yes	Yes	No
IXGBRWSE	Yes	Yes	Yes	Yes
IXGCONN	Yes	Yes	Yes	Yes
IXGDELET	Yes	Yes	Yes	Yes
IXGWRITE	Yes	Yes	Yes	Yes
LLACOPY	No	No	Yes	No
LOAD	Yes	No	No	Yes
LOADWAIT	No	Yes	Yes	No
LOCASCB	Yes	Yes	Yes	No
LXFRE	No	Yes	Yes	No
LXRES	No	Yes	Yes	No
MCSOPER	Yes	No	Yes	No
MCSOPMSG	Yes	No	Yes	No
MGCR	No	No	No	No
MGCRE	No	No	No	No
MIHQUERY	Yes	No	Yes	No
MODESET	No	Yes	No	Yes
NIL	Yes	Yes	Yes	No
NMLDEF	No	No	No	No
NUCLKUP	No	No	No	No
OIL	Yes	Yes	Yes	No
OUTADD	No	No	No	No
OUTDEL	No	No	No	No
PCLINK	No	Yes	No	No
PGANY	No	No	No	No
PGFIX	No	Yes	No	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
PGFIXA	No	No	No	No
PGFREE	No	Yes	No	No
PGFREEA	No	No	No	No
PGSER	Yes (See note “8” on page 25)	Yes (See note “8” on page 25)	No	Yes
POST	No	Yes	No	Yes
PTRACE	No	Yes	No	No
PURGEDQ	No	No	No	No
QEDIT	No	No	No	No
RESERVE	No	No	No	Yes
RESMGR	Yes	Yes	No	No
RESUME	No	Yes	No	No
RISGNL	No	Yes	No	No
SCHEDIRB	Yes	No	Yes	No
SCHEDULE	Yes	Yes	Yes	No
SCHEDXIT	No	Yes	No	No
SDUMP	Yes (See note “1” on page 24)	Yes (See note “9” on page 25)	Yes	No
SDUMPX	Yes	Yes (See note “9” on page 25)	Yes	Yes
SETFRR	Yes	Yes	Yes	No
SETLOCK	Yes	Yes	Yes	No
SETRP	Yes	Yes	Yes	Yes
SJFREQ	No	Yes	No	No
SPIE	No	No	No	No
SPOST	No	No	No	No
SRBSTAT	No	Yes	No	No
SRBTIMER	No	No	No	No
STATUS	Yes	Yes	No	No
STORAGE	Yes	Yes	No	Yes
SUSPEND	No	Yes	No	No
SVCUPDTE	No	No	No	No
SWAREQ	No	No	No	No
SWBTUREQ	No	No	No	No

Table 3. Service Summary (continued)

Service	Can be issued in AR ASC mode	Can be issued in cross memory mode	Checks SYSSTATE	Can be issued in 64-bit AMODE
SYMREC	No	Yes	Yes	No
SYNCH	Yes (See note “1” on page 24)	No	Yes	No
SYNCHX	Yes	No	Yes	Yes
SYSEVENT	No	No	No	No
TCBTOKEN	Yes	Yes	No	No
TCTL	No	No	No	No
TESTAUTH	No	No	No	No
TIMEUSED	Yes (See note “10” on page 25)	Yes	No	Yes
T6EXIT	No	No	No	No
UCBINFO	Yes	Yes	Yes	No
UCBLOOK	Yes	Yes	Yes	No
UCBPIN	Yes	Yes	Yes	No
UCBSCAN	Yes	Yes	Yes	No
VSMLIST	No	Yes	Yes	No
VSMLOC	No	Yes	Yes	No
VSMREGN	No	Yes	No	No
WAIT	No	Yes	No	Yes
WTL	No	No	No	No
WTO	No	No	No	Yes
WTOR	No	No	No	Yes

Notes:

1. Primary mode callers can use either macro in the following macro pairs:

- ATTACH or ATTACHX
- SDUMP or SDUMPX
- SYNCH or SYNCHX

IBM recommends that programs in AR ASC mode use the X-macros (ATTACHX, SDUMPX, and SYNCHX). If, however, a program in AR mode issues ATTACH, SDUMP, or SYNCH after issuing SYSSTATE ASCENV=AR, the system substitutes the corresponding X-macro and issues a message telling you that it made the substitution.

2. CALLRTM TYPE=MEMTERM can be issued in cross memory mode. For CALLRTM TYPE=ABTERM, see the CALLRTM macro description.
3. The only programs that can use ESTAE are programs that are in primary mode with (PASN=HASN=SASN).

IBM recommends you always use ESTAEX unless your program and your recovery routine are in 24-bit addressing mode, or your program requires a branch entry. In these cases, you should use ESTAE.

4. IBM recommends that AR mode callers use the STORAGE macro instead of using GETMAIN or FREEMAIN.
5. For HSPSERV SREAD and HSPSERV SWRITE, PASN=HASN=SASN for a non-shared standard hiperspace for which an ALET is not used (that is, the HSPALET parameter is omitted).
6. If you use the HSPALET parameter, the HSPSERV macro checks SYSSTATE.
7. If the input UCB is captured, the IOSCAPF, IOSCMXA, IOSCMXR, and IOSDCXR macros can be issued in cross memory mode only if the UCB is captured in the primary address space. IOSCAPU CAPTOACT without the ASID parameter also can be issued in cross memory mode if the UCB was captured in the primary address space. IOSCAPU CAPTUCB and IOSCAPU UCAPTUCB cannot be issued in cross memory mode.
8. PGSER can be issued in AR ASC mode only if you specify BRANCH=Y. PGSER can be issued in cross memory mode only if you specify BRANCH=Y or BRANCH=SPECIAL.
9. Both SDUMP and SDUMPX can be issued in cross memory mode only if you specify BRANCH=YES.
10. Only TIMEUSED LINKAGE=SYSTEM can be issued in AR ASC mode. TIMEUSED LINKAGE=BRANCH cannot be issued in AR ASC mode.
11. For a QUERY request, CSVAPF can be issued only in primary mode. For all other requests, CSVAPF can be issued in primary or AR mode.
12. For CSVAPF with the ADD, DELETE, and DYNFORMAT requests, PASN = HASN = SASN. For CSVAPF with the QUERY, QUERYFORMAT, and LIST requests, any PASN, any HASN, any SASN.
13. For a QUERY or a CALL request with FASTPATH=YES, CSVDYNEX can be issued only in primary mode. For all other requests, CSVDYNEX can be issued in primary or AR mode.
14. For CSVDYNEX CALL, RECOVER, and QUERY requests, any PASN, any HASN, any SASN. For all other requests, PASN=HASN=SASN.
15. When the caller of the IAZXJSAB macro specifies the ASCB parameter, any PASN, any HASN, any SASN; otherwise, PASN=HASN is required.
16. The 64 bit entry names are as follows:
 - ISGLCR64
 - ISGLID64
 - ISGLOB64
 - ISGLRE64
 - ISGLPB64
 - ISGLPR64

Chapter 2. SETFRR — Set up functional recovery routines

Description

The SETFRR macro gives authorized programs the ability to define their recovery in the FRR (functional recovery routine) LIFO stack, which is used during processing of the system recovery manager. Any program function can use SETFRR to define its own unique recovery environment.

The SETFRR macro can be used to add, delete, or replace FRRs in the LIFO stack, or to purge all FRRs in the stack. The macro also optionally returns to the user the address of a parameter area that is eventually passed to the FRR when an error occurs. The parameter area can be used to keep information that might be useful to the FRR. The recovery and retry routines execute in the same addressing mode as the issuer of the macro.

z/OS MVS Programming: Authorized Assembler Services Guide describes the interface to an FRR and contains guidelines for writing an FRR.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state and PSW key 0
Dispatchable unit mode:	Task or SRB (see note below)
Cross memory mode:	Any PASN, any HASN, any SASN
AMODE:	24-bit, 31-bit, or 64-bit
ASC mode:	Primary, in any AMODE Secondary, in any AMODE Access register (AR), in AMODE 24 or AMODE 31 only
Interrupt status:	Enabled or disabled for I/O and external interrupts (see note below)
Locks:	The caller may hold locks, but is not required to hold any. (See note below.)
Control parameters:	None.

Note: If the caller does not specify the EUT=YES parameter, the caller must be one of the following:

- Holding a lock
- Disabled for I/O and external interrupts
- In SRB mode.

Programming requirements

If your program is in AR mode, issue the SYSSTATE ASCENV=AR macro before issuing SETFRR. SYSSTATE ASCENV=AR tells the system to generate code appropriate for AR mode.

The caller must include the following mapping macros:

- IHAFFRS
- IHAPSA

Restrictions

None.

Input register information

Before issuing the SETFRR macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the contents of the general purpose registers (GPRs) and access registers (ARs) are unchanged, with the exception of the GPRs you specify on the WRKREGS parameter, which are used by the system.

Performance implications

None.

Syntax

The SETFRR macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SETFRR.
SETFRR	
␣	One or more blanks must follow SETFRR.
A,FRRAD= <i>FRR addr</i>	<i>FRR addr</i> : A-type address, or register (2) - (12).
R,FRRAD= <i>FRR addr</i>	
D	
P	
,WRKREGS=(<i>reg1,reg2</i>)	<i>reg1</i> : Decimal digits 1-15.
	<i>reg2</i> : Decimal digits 1-15.
,PARMAD= <i>parm area addr</i>	<i>parm area addr</i> : A-type address, or register (2) - (12).
	Note: This parameter may only be specified with A or R above.
,CANCEL=YES	Default: CANCEL=YES

Syntax	Description
,CANCEL=NO	
,EUT=YES	
,MODE=	Default: MODE=HOME
(
FULLXM	
PRIMARY	
HOME	
,	
LOCAL	
)	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.
,SDWALOC31=NO	Default: SDWALOC31=NO
,SDWALOC31=YES	

Parameters

The parameters are explained as follows:

A,FRRAD=FRRAD *addr*

R,FRRAD=FRRAD *addr*

D

P

Specifies the operation to be performed on the FRR LIFO stack:

A

An FRR address is to be added to the stack.

R

The FRR address last added to the stack is to be replaced by another FRR address.

D

The FRR address last added to the stack is to be deleted.

P

All entries in the stack are to be purged.

FRRAD specifies the address of a fullword containing the FRR address that is to be added or replaced. The parameter specifies the FRR address in a register or specifies the address of a storage location containing the FRR address.

Note: When an FRR wants to deactivate itself, **IBM recommends** that the FRR issue SETRP with REMREC=YES rather than issuing SETFRR D. See the chapter on providing recovery in [z/OS MVS Programming: Authorized Assembler Services Guide](#) for an explanation.

,WRKREGS=(reg1,reg2)

Specifies two unique general purpose registers to be used as work registers by the system.

,PARMAD=parm area addr

Specifies the address of a fullword to receive the address of the 24-byte parameter area initialized to zeros and provided by the system to the issuer of SETFRR. This 24-byte parameter area is in key 0 storage. If a register is specified, the address of the 24-byte parameter area is placed in the register. This parameter area is associated with the FRR address that has either been added to or has replaced an FRR address on the stack. This parameter area is passed to the FRR when an error occurs.

,CANCEL=YES**,CANCEL=NO**

Specifies whether you want to allow the recovery routine to be interrupted by cancel or detach processing.

To allow a recovery routine to be interrupted, specify CANCEL=YES.

To prevent a recovery routine from being interrupted, specify CANCEL=NO. If a cancel or detach is attempted against a recovery routine for which you have specified CANCEL=NO, MVS defers cancel and detach processing until the recovery routine returns control to the system.

Note:

1. If a recovery routine that runs under the CANCEL=NO option can be called by an unauthorized program running under the same task, IBM recommends that you specify ASYNCH=NO for each ESTAE(X) macro that the recovery routine issues. This also includes any ESTAE(X) macros issued by programs that the recovery routine calls.
2. If a recovery routine running under the CANCEL=NO option calls an unauthorized program, cancel and detach processing is also deferred for the called program.

,EUT=YES

Used only with A and R, specifies that the new FRR can be used in any environment. EUT=YES is used by routines that are not certain of their environment; for example, a routine that can be called by an SRB or by a task that is executing enabled and might not hold any locks. While the FRR remains in effect, no SVCs can be issued, no new asynchronous exits are dispatched, and no vector instructions can be executed.

,MODE=options

Specifies the environment in which the FRR is to get control and also, optionally, identifies the FRRs that free critical resources. The normal or expected addressing environment is identified by FULLXM, PRIMARY, or HOME. Specify LOCAL to enable the FRR to be entered in a restricted addressing environment for freeing critical resources. Parentheses are not needed if only one option is chosen.

FULLXM

Specifies that the FRR must be entered in the same cross memory environment that existed when the SETFRR was issued.

PRIMARY

Specifies that the FRR must be entered in primary addressing mode with both the PASID and SASID the same as the PASID that existed when the SETFRR was issued, the home address space must be unchanged, and the PSW key mask must be the same as when the SETFRR was issued.

HOME

Specifies that the FRR must be entered in primary addressing mode with PASID=SASID=HASID, and the PSW key mask either the same as that at the time of the error for SRB mode, or the task storage protect key for TCB mode.

If neither FULLXM, PRIMARY, nor HOME is coded, HOME is the default.

LOCAL

Specifies that the FRR frees a critical local resource. If the FRR cannot be entered in its normal addressing environment then it must be entered in LOCAL restricted addressing environment to free resources.

For the FRR to be entered in LOCAL restricted addressing environment, a local lock must be held.

If it cannot be entered either as an FRR or as a resource manager, the FRR is skipped.

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user, and may be any valid coding values.

,SDWALOC31=NO

,SDWALOC31=YES

Used only with A and R, SDWALOC31=YES specifies that an AMODE 31 FRR can tolerate an SDWA in 31-bit storage. The default of SDWALOC31=NO specifies that an AMODE 31 FRR is not known to be able to tolerate an SDWA in 31-bit storage and an SDWA in 24-bit storage will be provided. Because 31-bit storage is generally less likely to be constrained than 24-bit storage and RTM skips FRRs for which it can not obtain an SDWA, SDWALOC31=YES should be used whenever possible for AMODE 31 FRRs.

This parameter is ignored for FRRs established in AMODE 64 because they are assumed to be able to tolerate an SDWA in 31-bit storage. It is also ignored for FRRs established in AMODE 24.

Note: Programs generated with this parameter can be used on systems before HBB7770, where the parameter will be ignored.

ABEND codes

SETFRR might abnormally end with abend code X'07D'. See [z/OS MVS System Codes](#) for an explanation and programmer response for this code.

Return and reason codes

None.

Example 1

Add an FRR to the FRR stack and return the address of the parameter list to the issuer of the SETFRR. The FRR address contained in register (R5) is placed on the FRR stack in the next available FRR entry. On return, register (R2) contains the address of the parameter list associated with this FRR entry. Registers R3 and R4 are work registers used by the system.

```
SETFRR A,FRRAD=(R5),PARMAD=(R2),WRKREGS=(R3,R4)
```

Example 2

Delete the last FRR added to the FRR stack. Registers 1 and 6 are work registers used by the system.

```
SETFRR D,WRKREGS=(1,6)
```


Chapter 3. SETLOCK — Control access to serially reusable resources

Description

Use the SETLOCK macro to control access to serially reusable resources. Each kind of serially reusable resource is assigned a separate lock.

SETLOCK can do the following:

- Obtain a specified lock
- Release a specified lock
- Test a specified lock or determine if the lock is held on the caller's processor.

Locks are discussed in the “Serialization” chapter in [z/OS MVS Programming: Authorized Assembler Services Guide](#).

Note: The OBTAIN, RELEASE, and TEST options of the SETLOCK macro have the same environmental specifications, programming requirements, restrictions, register information, and performance implications described below, except where noted in the explanations of each option.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state, PSW key 0
Dispatchable unit mode:	Task or SRB
Cross memory mode:	Any
AMODE:	24- or 31-bit
ASC mode:	Primary or access register (AR)
Interrupt status:	Enabled or disabled for I/O and external interrupts. The caller cannot be disabled when unconditionally requesting a suspend lock.
Locks:	LOCAL or CML lock must be held to obtain the CMS lock; otherwise, the caller may hold locks, but is not required to hold any. Only locks lower in the hierarchy than the lock currently being requested may be held at the time of invocation.
Control parameters:	None.

Programming requirements

- Before you invoke the SETLOCK macro in access register mode, issue SYSSTATE ASCENV=AR.
- The caller must include the IHAPSA mapping macro.
- Before issuing an OBTAIN request for a CML lock, establish the target ASCB as either the primary or secondary address space.

Restrictions

None.

Input register information

Before issuing the SETLOCK macro, the caller must ensure that the following general purpose register (GPR) contains the specified information:

Register	Contents
-----------------	-----------------

13

A 5-word save area if REGS=SAVE is specified, or an 18-word save area if REGS=STDSAVE is specified.

Output register information

For an OBTAIN or RELEASE request, when the REGS parameter is not specified, the contents of the general purpose registers (GPRs) after control returns to the caller are as follows:

Register	Contents
-----------------	-----------------

0-10

Unchanged

11-12

Used as work registers by the system

13

Return code

14

Used as a work register by the system

15

Unchanged

For an OBTAIN or RELEASE request when the REGS parameter is specified, see the description of the REGS parameter for information on GPR usage.

For a TEST request, the contents of the GPRs after control returns to the caller are as follows:

Register	Contents
-----------------	-----------------

0-1

Unchanged.

2-12

If one of these registers is specified on the LOCKHLD parameter, that register is used as a work register by the system; otherwise, registers 2-12 are unchanged.

13-14

Unchanged.

When control returns to the caller, the access registers (ARs) contain:

Register	Contents
-----------------	-----------------

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

SETLOCK OBTAIN

Syntax

The OBTAIN option of SETLOCK macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SETLOCK.
SETLOCK	
␣	One or more blanks must follow SETLOCK.
OBTAIN	
,TYPE=CPU	
,TYPE=CMS	
,TYPE=LOCAL	
,TYPE=CML,ASCB=(11)	
,TYPE=CML,ASCB= <i>addr</i>	<i>addr</i> : A-type address
,MODE=COND	Note: MODE cannot be specified with TYPE=CPU.
,MODE=UNCOND	
,REGS=SAVE	
,REGS=USE	
,REGS=STDSAVE	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.

Parameters

The parameters are explained as follows:

OBTAIN

Specifies that the lock designated by the TYPE parameter is to be obtained on the caller's behalf.

,TYPE=CPU

,TYPE=CMS

,TYPE=LOCAL

,TYPE=CML,ASCB=(11)

,TYPE=CML,ASCB=addr

Specifies the type of lock. The types available are:

CPU

The processor lock. It is a pseudo spin lock providing MVS-recognized disablement. There is one CPU lock per processor and no processor can request another processor's lock. The lock is always available. Users can obtain the CPU lock to become disabled for I/O and external interrupts.

CMS

The cross memory services lock. It is a global suspend lock used to serialize functions between address spaces.

LOCAL

The lock that serializes resources in the home address space pointed to by PSAAOLD. It is a local level suspend lock.

CML

The cross memory local lock. It is a local level suspend type lock used to serialize resources in an address space other than the home address space.

The requestor of a CML lock must have authority to access the specified address space before requesting the lock. To establish authority, the requestor sets the primary or secondary address space to the one specified by the ASCB=(11) or ASCB=addr parameter. Register 11 or addr must contain the address of the ASCB whose local lock is requested. This address space must be nonswappable before the SETLOCK request.

Note: If the requestor specifies OBTAIN,TYPE=CML and the ASCB parameter points to the home address space, the request is treated as though the LOCAL lock were being obtained.

,MODE=COND

,MODE=UNCOND

Specifies whether the lock is to be conditionally or unconditionally obtained.

COND

Specifies that the lock is to be conditionally obtained. That is, if the lock is not owned on another processor, it is acquired on the caller's behalf. If the lock is already held, control is returned indicating that the caller holds the lock or that another unit of work on another processor owns the lock.

UNCOND

Specifies that the lock is to be unconditionally obtained. That is, if the lock is not owned on another processor, it is acquired on the caller's behalf. If the lock is already held by the caller, control is returned to the calling program indicating that it already owns the lock. If the lock is held on another processor, the system suspends the SETLOCK caller until the lock is available.

The system does not permit an unconditional OBTAIN request for a CML lock if the lock is held by a unit of work that is set nondispatchable.

,REGS=SAVE

,REGS=USE

,REGS=STDSAVE

Specifies the use of general purpose registers by the SETLOCK macro.

SAVE

Specifies that the contents of registers 11 through 14 are saved in the area pointed to by register 13 and are restored upon completion of the SETLOCK request. This save area must be at least 20 bytes, and must not be the same area as the standard linkage save area used by the program.

Upon completion of the SETLOCK macro with REGS=SAVE, the register contents are as follows:

Register Contents

0-14

Unchanged

15

Return code

USE

Specifies that the contents of registers 11 through 13 are saved in work registers 0, 1, and 15.

Upon completion of the SETLOCK macro with REGS=USE, the register contents are as follows:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

STDSAVE

Specifies that the contents of registers 2 through 12 are saved in a standard 72-byte save area pointed to by register 13.

Upon completion of the SETLOCK macro with REGS=STDSAVE, the register contents are as follows:

Register Contents

0-1

Unchanged

2-13

Unchanged

14

Used as a work register by the system

15

Return code

Note: See [“Output register information” on page 34](#) for information on register usage when the REGS parameter is not specified.

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user, and may be any valid coding values.

ABEND codes

SETLOCK might abnormally terminate with abend code X'073'. See [z/OS MVS System Codes](#) for an explanation and programmer response for this code.

Return and reason codes

When control returns to the caller, register 15 (or register 13, if the REGS parameter is not specified) contains one of the following hexadecimal return codes:

Table 4. Return Codes for the SETLOCK Macro

Return Code	Meaning and Action
00	Meaning: The lock was successfully obtained. Action: None.
04	Meaning: The lock was already held by the caller. Action: None.
08	Meaning: The conditional obtain process was unsuccessful. The lock is owned by another processor. Action: None required. However, you might try to take some action based upon your application.

When the SETLOCK OBTAIN request is for the CPU lock, the system returns only return code 0. You do not need to check the return code because once control is returned to you after the SETLOCK OBTAIN,TYPE=CPU request, you will have the CPU lock.

Example 1

Obtain the CPU lock, saving registers 2 through 12 in the standard save area whose address is in register 13.

```
SETLOCK OBTAIN,TYPE=CPU,REGS=STDSAVE
```

Example 2

Obtain the CMS lock. Because the caller must hold the LOCAL or CML lock to obtain the CMS lock, the caller must first obtain the LOCAL lock unconditionally, saving registers 2 through 12 in the save area pointed to by register 13. The caller then issues the request to obtain the CMS lock.

```
SETLOCK OBTAIN,TYPE=LOCAL,MODE=UNCOND,REGS=STDSAVE
SETLOCK OBTAIN,TYPE=CMS,MODE=UNCOND,REGS=STDSAVE
```

Example 3

Obtain the LOCAL lock unconditionally, saving registers 11 through 14 in the save area pointed to by register 13. The save area pointed to by register 13 is not the same area as the standard linkage save area.

```
LR      5,13      SAVE STANDARD SAVE AREA POINTER
LA      13,SETLOCK_SAVEAREA
SETLOCK OBTAIN,TYPE=LOCAL,MODE=UNCOND,REGS=SAVE
LR      13,5      RESTORE STANDARD SAVE AREA POINTER
.
.
.
SETLOCK_SAVEAREA DS 5F          SAVE AREA FOR SETLOCK REQUESTS
```

SETLOCK RELEASE

Syntax

The RELEASE option of the SETLOCK macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.

Syntax	Description
␣	One or more blanks must precede SETLOCK.
SETLOCK	
␣	One or more blanks must follow SETLOCK.
RELEASE	
,TYPE=CPU	
,TYPE=CMS	
,TYPE=LOCAL	
,TYPE=CML,ASCB=(11)	
,TYPE=CML,ASCB= <i>addr</i>	<i>addr</i> : A-type address
,REGS=SAVE	
,REGS=USE	
,REGS=STDSAVE	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.

Parameters

The parameters are explained as follows:

RELEASE

Specifies that the lock designated by the TYPE parameter is to be released.

Note: If you specify RELEASE,TYPE=CML,ASCB=(11) or ASCB=*addr*, the ASCB parameter specifies the home address space, and the lock that the caller holds is home's local lock, then SETLOCK processing treats the CML release request as a RELEASE, TYPE=LOCAL.

,TYPE=CPU

,TYPE=CMS

,TYPE=LOCAL

,TYPE=CML,ASCB=(11)

,TYPE=CML,ASCB=*addr*

Specifies the type of lock. The types available are:

CPU

The processor lock. It is a pseudo spin lock providing MVS-recognized disablement. There is one CPU lock per processor and no processor can request another processor's lock. The lock is always available. Users can obtain the CPU lock to become disabled for I/O and external interrupts.

CMS

The cross memory services lock. It is a global suspend lock used to serialize functions between address spaces.

LOCAL

The lock that serializes resources in the home address space pointed to by PSAAOLD. It is a local level suspend lock.

CML

The cross memory local lock. It is a local level suspend type lock used to serialize resources in an address space other than the home address space.

The requestor of a CML lock must have authority to access the specified address space before requesting the lock. To establish authority, the requestor sets the primary or secondary address space to the one specified by the ASCB=(11) or ASCB=*addr* parameter. Register 11 or *addr* must contain the address of the ASCB whose local lock is requested. This address space must be nonswappable before the SETLOCK request.

Note: If the requestor specifies OBTAIN,TYPE=CML and the ASCB parameter points to the home address space, the request is treated as though the LOCAL lock were being obtained.

,REGS=SAVE**,REGS=USE****,REGS=STDSAVE**

Specifies the use of general purpose registers by the SETLOCK macro.

SAVE

Specifies that the contents of registers 11 through 14 are saved in the area pointed to by register 13 and are restored upon completion of the SETLOCK request. This save area must be at least 20 bytes, and must not be the same area as the standard linkage save area used by the program.

Upon completion of the SETLOCK macro with REGS=SAVE, the register contents are as follows:

Register**Contents****0-14**

Unchanged

15

Return code

USE

Specifies that the contents of registers 11 through 13 are saved in work registers 0, 1, and 15.

Upon completion of the SETLOCK macro with REGS=USE, the register contents are as follows:

Register**Contents****0-1**

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

STDSAVE

Specifies that the contents of registers 2 through 12 are saved in a standard 72-byte save area pointed to by register 13.

Upon completion of the SETLOCK macro with REGS=STDSAVE, the register contents are as follows:

Register**Contents**

0-1

Unchanged

2-13

Unchanged

14

Used as a work register by the system

15

Return code

Note: See “Output register information” on page 34 for information on register usage when the REGS parameter is not specified.

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user, and may be any valid coding values.

Return and reason codes

When control is returned, register 15 (or register 13, if the REGS parameter is not specified) contains one of the following hexadecimal return codes:

Table 5. Return Codes for SETLOCK RELEASE	
Return Code	Meaning and Action
00	Meaning: The lock was successfully released. Action: None.
04	Meaning: The lock was not owned. The lock was free when the release request was issued. Action: None.
08	Meaning: The release process was unsuccessful. The lock was owned by a different processor. Action: None required. However, you might try to take some action based upon your application.
0C	Meaning: The release process was unsuccessful. The caller does not own the specified local or CML lock. This return code applies to LOCAL or CML release only. Action: None required. However, you might try to take some action based upon your application.

Example 1

Release the local lock and check the return code from the SETLOCK request. If the release was unsuccessful, branch to the code at the RLSEFAIL label.

```
SETLOCK  RELEASE,TYPE=LOCAL
LTR      13,13
BNZ      RLSEFAIL
```

Example 2

Release the CML lock, saving the contents of registers 2 through 12 in a standard save area. Check the return code from the SETLOCK request, and branch to the code at the RLSEFAIL label if the release was unsuccessful.

```
SETLOCK  RELEASE,TYPE=CML,REGS=STDSAVE
LTR      15,15
BNZ      RLSEFAIL
```

SETLOCK TEST

Syntax

The TEST option of the SETLOCK macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede SETLOCK.
SETLOCK	
b	One or more blanks must follow SETLOCK.
TEST	
,TYPE=CPU	
,TYPE=CMS	
,TYPE=LOCAL	
,TYPE=ALOCAL	
,TYPE=CML	Note: LOCKHLD or ASCB must be specified with TYPE=CML.
,LOCKHLD=(<i>reg</i>)	<i>reg</i> : Register (2) - (12)
	Note: LOCKHLD is valid only with TYPE=CML, TYPE=ALOCAL, and TYPE=CPU
,ASCB=(<i>reg</i>)	<i>reg</i> : Register (2) - (12)
	Note: ASCB is valid only with TYPE=CML.
,BRANCH=(HELD, <i>addr</i>)	<i>addr</i> : RX-type address.
,BRANCH=(NOTHELD, <i>addr</i>)	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.

Parameters

The parameters are explained as follows:

TEST

Specifies that the lock designated by the TYPE parameter is to be checked to determine if it is currently held on the requesting processor.

,TYPE=CPU

,TYPE=CMS

,TYPE=LOCAL

,TYPE=ALOCAL

,TYPE=CML

Specifies the type of lock. The types available are:

CPU

The processor lock. It is a pseudo spin lock providing MVS-recognized disablement. There is one CPU lock per processor, and no processor can request another processor's lock. The lock is always available. Users can obtain the CPU lock to become disabled for I/O and external interrupts.

CMS

The cross memory services lock. It is a global suspend lock used to serialize functions between address spaces.

LOCAL

The lock that serializes resources in the home address space pointed to by PSAAOLD. It is a local level suspend lock.

ALOCAL

Determines whether a local lock is held, either home's LOCAL lock or a CML lock. The LOCKHELD=(*reg*) parameter can be specified with TYPE=ALOCAL.

CML

The cross memory local lock. It is a local level suspend type lock used to serialize resources in an address space other than the home address space. TYPE=CML specifies that the caller wishes to determine whether a CML lock is held. Either the ASCB=(*reg*) or the LOCKHLD=(*reg*) parameter can be specified with TYPE=CML, but not both.

,LOCKHLD=(*reg*)

Specifies that the designated register is to be used as a return register by the macro. This parameter is valid only for TYPE=CML, TYPE=CPU, and TYPE=ALOCAL.

If TYPE=CML is specified and a CML lock is held, the system returns the ASCB address of the CML-locked address space in the specified register.

If TYPE=CPU is specified, the system returns the current CPU lock use count for this processor in the specified register.

If TYPE=ALOCAL is specified and the LOCAL lock is held, the system returns a zero in the specified register.

If TYPE=ALOCAL is specified and a CML lock is held, the system returns the ASCB address of the CML-locked address space in the specified register.

,ASCB=(*reg*)

Specifies a register that contains the ASCB address. The system checks the ASCB to determine whether the requestor's local lock is a CML lock. This parameter is valid only with TYPE=CML.

Note: Unlike the OBTAIN and RELEASE options of the SETLOCK macro, ASCB=*addr* is not valid.

,BRANCH=(HELD,*addr*)

,BRANCH=(NOTHELD,*addr*)

If (HELD,*addr*) is specified, the specified address is branched to if the specified lock is held on the requesting processor.

If (NOTHELD,*addr*) is specified, the specified address is branched to if the specified lock is not currently held on the requesting processor.

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user, and may be any valid coding values.

Return and reason codes

When control is returned, register 15 contains one of the following hexadecimal return codes (if the BRANCH= parameter was omitted):

Table 6. Return Codes for SETLOCK TEST	
Return Code	Meaning and Action
00	Meaning: The lock was held by the requestor, or (if TYPE=CMS was specified) at least one lock was held. Action: None.
04	Meaning: The lock was available, or (if TYPE=CMS was specified) no lock was held. Action: None.

Note: TYPE=CMS is used to determine if at least one cross memory services lock is held, but cannot be used to determine which one, or to determine if all are held.

Example 1

If a local lock is not held, branch to DSRLINT; otherwise, execute the next sequential instruction.

```
SETLOCK TEST,TYPE=LOCAL,BRANCH=(NOTHELD,DSRLINT)
```

Example 2

Put the current CPU lock use count for this processor into register 3.

```
SETLOCK TEST,TYPE=CPU,LOCKHLD=(3)
```

Example 3

Determine whether the local lock of the address space specified in register 11 is held as a CML lock.

```
SETLOCK TEST,TYPE=CML,ASCB=(11)
```

Chapter 4. SETRP — Set return parameters

Description

Use the SETRP macro within a recovery routine to indicate the various requests that the recovery routine can make. SETRP is valid for functional recovery routines (FRRs) and ESTAE-type recovery routines. For more information about recovery routines, see the information on providing recovery in *z/OS MVS Programming: Authorized Assembler Services Guide*.

The SETRP macro is also described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP* with the exception of the RECORD, FRELOCK, SERIAL, RETRY, RETRY15, FRLKRTY, and SSRESET parameters.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Problem state and any PSW key. For the FRELOCK, SERIAL, RETRY, RETRY15, and FRLKRTY parameters, supervisor state or PSW key 0-7.
Dispatchable unit mode:	Task or SRB
Cross memory mode:	Any PASN, any HASN, any SASN
AMODE:	24- or 31- or 64-bit Note: For the DUMPOPX parameter, AMODE=64 is not allowed.
ASC mode:	Primary, secondary, or access register (AR) Note: Callers in secondary ASC mode cannot specify the DUMPOPX keyword.
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	The caller may hold locks, but is not required to hold any.
Control parameters:	None.

Programming requirements

- If the program is in AR mode, issue the SYSSTATE ASCENV=AR macro before SETRP. SYSSTATE ASCENV=AR tells the system to generate code appropriate for AR mode.
- Include the IHASDWA mapping macro to map the system diagnostic work area (SDWA). The SDWA is addressable when the recovery routine is entered; when the SETRP macro is issued, the same address space must be addressable. (See SDWA in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary) for the mapping provided by IHASDWA.)
- If you plan to specify RETREGS=YES,RUB=*reg info addr*, you must obtain storage for and initialize the register update block (RUB). See the RETREGS parameter description for more information about this area.

Restrictions

- You can use SETRP only if the system provided an SDWA.

- Recovery routines established through the STAE macro, or the STAI parameter on the ATTACH or ATTACHX macro, cannot update registers on retry, so the RETREGS parameter does not apply.
- For FRRs, RETREGS=YES (or RETREGS=NO) has no effect. For FRRs, the system always restores GPRs 0-14 from the SDWASRSV field, and ARs 0-14 from the SDWAARSV field. If you specify RETRY15=YES, the system also restores GPR 15 and AR 15 from the SDWASRSV and SDWAARSV fields, respectively.

Input register information

Before issuing the SETRP macro, the caller must ensure that the following general purpose registers (GPRs) contain the specified information:

Register Contents

1

If you do not specify the WKAREA parameter, address of the SDWA; otherwise, the caller does not have to place any information into this register.

13

If you specify the REGS parameter, address of a standard 72-byte save area containing the registers to be restored; otherwise, the caller does not have to place any information into this register.

Before issuing the SETRP macro, the caller must ensure that the following access registers (ARs) contain the specified information:

Register Contents

1

If you do not specify the WKAREA parameter, ALET of the SDWA whose address is in GPR 1; otherwise, the caller does not have to place any information into this register.

13

If you specify the REGS parameter, ALET of the standard 72-byte save area whose address is in GPR 13; otherwise, the caller does not have to place any information into this register.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

When control returns to the caller, the access registers (ARs) contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Note: Control does not return to the caller if the caller specifies the REGS parameter.

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

Syntax

The SETRP macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SETRP.
SETRP	
␣	One or more blanks must follow SETRP.
WKAREA=(<i>reg</i>)	<i>reg</i> : Decimal digits 1-12.
	Default: WKAREA=(1)
,REGS=(<i>reg1</i>)	<i>reg1</i> : Decimal digits 0-12, 14, 15.
,REGS=(<i>reg1,reg2</i>)	<i>reg2</i> : Decimal digits 0-12, 14, 15.
	Note: If you specify (<i>reg1,reg2</i>), specify the registers in the same order as in an STM instruction; for example, to restore all registers except register 13, specify REGS=(14,12).
,DUMP=IGNORE	Default: DUMP=IGNORE
,DUMP=YES	
,DUMP=NO	
,DUMPOPT= <i>parm list addr</i>	<i>parm list addr</i> : RX-type address, or register (2) - (12).
,DUMPOPX= <i>parm list addr</i>	Note: Specify these parameters only if you specify DUMP=YES.
,RC=0	Default: RC=0
,RC=4	
,RC=16	

Syntax	Description
,RETADDR= <i>retry addr</i>	<i>retry addr</i> : RX-type address, or register (2) - (12).
	Note: This parameter may be specified only if RC=4 is specified above.
,RETREGS=NO	<i>info addr</i> : RX-type address, or register (2) - (12).
,RETREGS=YES	Default: RETREGS=NO
,RETREGS=YES,RUB= <i>info addr</i>	Note: This parameter may be specified only if RC=4 is specified above.
,RETREGS=64	
,FRESDDWA=NO	Default: FRESDDWA=NO
,FRESDDWA=YES	Note: This parameter may be specified only if RC=4 is specified above.
,COMPCOD= <i>code1</i>	<i>code1</i> : Symbol or decimal number.
,COMPCOD=(<i>code</i>)	<i>code</i> : Symbol, decimal number, or register (2) - (12).
,COMPCOD=(<i>code</i> , USER)	Default: COMPCOD=(<i>code</i> ,USER)
,COMPCOD=(<i>code</i> ,SYSTEM)	
,FRELOCK=(<i>locks</i>)	<i>locks</i> : Any combination of the following, separated by commas: CPU CMS LOCAL CML(<i>cmlascb</i>)
	<i>cmlascb</i> : RX-type address or register (2) - (12).
,REASON= <i>code</i>	<i>code</i> : Symbol, decimal or hexadecimal number, or register (2) - (12).
,RECORD=IGNORE	Default: RECORD=IGNORE
,RECORD=YES	
,RECORD=NO	
,RECPARM= <i>record list addr</i>	<i>record list addr</i> : RX-type address, or register (2) - (12).
	Note: This parameter may be specified only if RECORD=IGNORE or RECORD=YES is specified above.
,SERIAL=YES	
,SERIAL=NO	

Syntax	Description
,RETRY=FRR	Default: RETRY=FRR
,RETRY=ERROR	
,RETRY15=NO	Default: RETRY15=NO
,RETRY15=YES	
,REMREC=NO	Default: REMREC=NO
,REMREC=YES	
,FRLKRTY=NO	Default: FRLKRTY=NO
,FRLKRTY=YES	
,SSRESET=YES	
,SSRESET=NO	
,RETRYAMODE= <i>amode</i>	<i>amode</i> : decimal 24, 31, or 64. Only honored for ARR, ESTAE, ESTAI, ESTAEX, FESTAE, FRR and IEAARR recovery routines.

Parameters

The parameters are explained below:

WKAREA=(*reg*)

Specifies the address of the SDWA passed to the recovery routine. If this parameter is omitted, the address of the SDWA must be in register 1.

,REGS=(*reg 1*)

,REGS=(*reg 2*)

Specifies the register or range of registers to be restored from the 72-byte standard save area pointed to by the address in register 13. If you specify REGS, a branch on register 14 instruction will also be generated to return control to the system. If you do not specify REGS, you must code your own branch on whichever register contains the return address.

Note: If you specify *reg1,reg2*, specify the registers in the same order as in an STM instruction; for example, to restore all registers except register 13, specify REGS=(14,12).

,DUMP=IGNORE

,DUMP=YES

,DUMP=NO

Specifies that the dump option fields will not be changed (IGNORE), will be zeroed (NO), or will be merged with dump options specified in previous dump requests, if any (YES). If IGNORE is specified, a previous recovery routine had requested a dump or a dump had been requested through the ABEND macro, and the previous request will remain intact. If NO is specified, no dump will be taken.

DUMP=YES does not guarantee that a SYSABEND/SYSUDUMP will be taken. You may specify this request in an FRR for an SRB but you will get an abdump only if the SRB abend successfully percolates

to a task *and* none of the FRRs for that task choose to retry *and* the final value of the DUMP= remains the same after every recovery routine has received control.

,DUMPOPT=parm list addr

,DUMPOPX=parm list addr

Specifies the address of a parameter list of dump options. To create the parameter list, use the list form of either the SNAP or SNAPX macro along with the modify form of SNAP(X) as needed, or build the parameter list by coding your own data constants. DUMPOPT specifies the address of a parameter list that the SNAP macro creates. DUMPOPX specifies the address of a parameter list that the SNAPX macro creates. A program in secondary mode cannot use the DUMPOPX parameter.

If the specified dump options include subpools for storage areas to be dumped, up to seven subpools can be dumped. Subpool areas are accumulated and wrapped, so that the eighth subpool area specified replaces the first.

If the dump options specified include ranges of storage areas to be dumped, only the storage areas in the first thirty ranges will be dumped.

The TCB, DCB, ID, and STRHDR options available on SNAP or SNAPX are ignored if they appear in the parameter list. The TCB used will be the one for the task that encountered the error. The DCB used will be one created by the system, and either SYSABEND, SYSMDUMP, or SYSUDUMP will be used as a DDNAME.

,REASON=code

Specifies the reason code that the user wishes to pass to subsequent recovery routines. The value range for *code* is any 32-bit hexadecimal number or 31-bit decimal number. See [z/OS MVS Programming: Assembler Services Reference ABE-HSP](#) for information about how a user can change this code.

,RC=0

,RC=4

,RC=16

Specifies the return code the recovery routine sends to the system to indicate what further action is required:

Decimal Code

Meaning

0

Continue with error processing; causes entry into previously-specified recovery routine, if any.

4

Retry using the retry address specified.

16

Valid only for an ESTAI/STAI recovery routine. The system should not give control to any further ESTAI/STAI routines, and should abnormally end the task.

,RETADDR=retry addr

Specifies the address of the retry routine to which control is to be given.

,RETREGS=NO

,RETREGS=YES

,RETREGS=YES ,RUB=reg info addr

,RETREGS=64

Specifies the contents of the registers to be restored on entry to the retry routine. RETREGS=NO indicates that you do not want the system to restore any register contents from the SDWA.

If you specify RETREGS=YES, in a recovery routine defined through the ESTAE, ESTAEX, or FESTAE macro, the ESTAI parameter on the ATTACH or ATTACHX macro, or an associated recovery routine (ARR), the system does the following:

- Initializes GPRs 0-15 from the SDWASRSV field of the SDWA
- Initializes ARs 0-15 from the SDWAARSV field of the SDWA.

Specifying RETREGS=64 is the same as specifying RETREGS=YES, except the registers for retry are the 64-bit general purpose registers in field SDWAG64.

RUB (register update block) specifies the address of an area that contains register update information for the GPRs. The data you specify in this area will be moved into the SDWASRSV field of the SDWA and will be loaded into the GPRs on entry to the retry routine. You cannot use the RUB to specify data to be moved into the SDWAARSV field for loading the ARs. You can use the RUB for both ESTAE-type recovery routines and FRRs. The maximum length of the RUB is 66 bytes. You must acquire storage for and initialize this area as follows:

- The first two bytes represent the registers to be updated, register 0 corresponding to bit 0, register 1 corresponding to bit 1, and so on. The user indicates which of the registers are to be stored in the SDWA by setting the corresponding bits in these two bytes.
- The remaining 64 bytes contain the update information for the registers, in the order 0-15. If all 16 registers are being updated, this field consists of 64 bytes. If only one register is being updated, this field consists of only 4 bytes for that one register.

For example, if only registers 4, 6, and 9 are being updated:

- Bits 4, 6, and 9 of the first two bytes are set.
- The remaining field consists of 12 bytes for registers 4, 6, and 9; the first 4 bytes are for register 4, followed by 4 bytes for register 6, and 4 final bytes for register 9.

,FRESDDWA=NO

,FRESDDWA=YES

Specifies that the entire SDWA be freed (YES) or not be freed (NO) before entry into the retry routine.

,COMPCOD=code1

,COMPCOD=(code)

,COMPCOD=(code,USER)

,COMPCOD=(code,SYSTEM)

Specifies the user or system completion code that the user wants to pass to subsequent recovery routines.

,FRELOCK=(locks)

Specifies the locks to be freed and the corresponding lockwords that are placed in the SDWA:

CPU

Processor lock

CMS

Cross memory services lock

LOCAL

Storage lock of the storage the caller is executing in

CML(cmlascb)

Cross memory local lock, where *cmlascb* indicates the ASCB address of the address space for which the local lock is to be freed

Note: If FRLKRTY=NO is specified or taken as a default, the specified locks are freed only on percolation, not on retry. Specifying FRLKRTY=YES allows the locks listed in FRELOCK to be freed on retry.

,RECORD=IGNORE

,RECORD=YES

,RECORD=NO

Specifies whether the SDWA is to be recorded in SYS1.LOGREC (RECORD=YES/NO), or whether the system should honor previous instructions about recording the SDWA in SYS1.LOGREC (RECORD=IGNORE).

If you specify RECORD=YES, the system records the entire SDWA (including the fixed length base, the variable length recording area, and the recordable extensions) in SYS1.LOGREC when the ESTAE recovery routine returns control, even if the mainline program issued the ESTAE or ESTAEX macro with RECORD=NO.

If you specify RECORD=NO, the system does not record the SDWA in SYS1.LOGREC, even if the mainline program issued ESTAE or ESTAEX with RECORD=YES.

If you specify RECORD=IGNORE, the system honors the request as specified by the RECORD parameter on the ESTAE or ESTAEX macro.

,RECPARM=record list addr

Specifies the address of a user-supplied record parameter list used to update the SDWA with recording information. The parameter list consists of three 8-byte fields:

- The first field contains the load module name.
- The second field contains the CSECT name (assembly module name).
- The third field contains the recovery routine name (assembly module name). If the recovery routine label is not the same as the assembly module name, the label can be used.

The three fields are left-justified, and padded with blanks.

,SERIAL=YES

,SERIAL=NO

Specifies whether the percolation from an SRB mode FRR to a related task recovery routine (ESTAE or FRR) is to be serialized (YES) or not serialized (NO) with respect to unlocked task recovery. See 'SRB to Task Percolation' in [z/OS MVS Programming: Authorized Assembler Services Guide](#).

If the task is already in recovery for another error when SERIAL=YES is specified, the percolation request is deferred pending a requested task retry from any recovery routine covering mainline code. If such a retry is not requested, the task is terminated and all deferred percolations are purged. Only the last FRR to receive control when an error occurs can specify SERIAL=YES.

,RETRY=FRR

,RETRY=ERROR

Specifies the cross memory environment in which the retry routine gets control.

RETRY=FRR, the default, specifies that the retry routine gets control in the cross memory environment that exists at the time of entry to the FRR.

RETRY=ERROR specifies that the retry routine gets control in the cross memory environment that existed at the time of the error. Do not specify RETRY=ERROR if the cross memory status at the time of the error is not available, that is, if SDWARPV is set to one. (Be careful not to create a loop by retrying to an erroneous cross memory state with RETRY=ERROR.)

,RETRY15=YES

,RETRY15=NO

In an FRR environment only, specifies that GPR 15 is restored from SDWASRSV and AR 15 is restored from SDWAARSV if RETRY15=YES. Otherwise, it contains the entry point address of the retry routine.

This parameter may be specified only when RC=4 is specified. If RETRY15=YES is not coded on any SETRP invocation prior to returning to the system, the effect is that of specifying RETRY15=NO.

,REMREC=YES

,REMREC=NO

In an FRR or ESTAE environment, specifies that the FRR/ESTAE entry for the currently running FRR/ESTAE routine be removed (REMREC=YES) or not removed (REMREC=NO). This parameter may be specified only when RC=4 is specified, indicating a retry request.

The entry is removed before control returns to the retry point. If REMREC=YES is not coded on any SETRP invocation before the system receives control, the effect is that of specifying REMREC=NO. The REMREC parameter may be used to remove a recovery routine that has been defined with a token, although the token cannot be specified when you code the SETRP macro.

,FRLKRTY=YES

,FRLKRTY=NO

In an FRR environment only, specifies that the locks specified on FRELOCK be freed (FRLKRTY=YES) or not be freed (FRLKRTY=NO) on retry.

This parameter may be specified only when RC=4 is specified. If FRLKRTY=YES is not coded on any SETRP invocation prior to returning to the system, the effect is that of specifying FRLKRTY=NO.

SSRESET=YES

SSRESET=NO

SSRESET=YES specifies that, if the current recovery routine abnormally ends, the next recovery routine is to get control in the subspace environment that existed when the current recovery routine was entered. Specify SSRESET=YES when the current recovery routine has temporarily modified the subspace environment, and when it is appropriate for the next recovery routine to receive control in the subspace environment in which the current recovery routine received control.

SSRESET=NO negates an earlier specification of SSRESET=YES. Specify SSRESET=NO when SSRESET=YES protection is no longer needed. If the current recovery routine abnormally ends after specifying SSRESET=NO, the next recovery routine will get control in the subspace in which the current routine was running when the error occurred.

If you do not specify SSRESET and the current recovery routine abnormally ends, the next recovery routine will get control in the subspace in which the current recovery routine was running when the error occurred.

See the chapter on subspaces in *z/OS MVS Programming: Extended Addressability Guide* for more information about subspaces and recovery.

,RETRYAMODE=amode

Specifies an explicit AMODE in which a retry routine receives control. This parameter is only honored for ARR, ESTAE, ESTAI, ESTAEX, FESTAEX, FRR and IEAARR recovery routines. If you do not specify this parameter, RTM selects an AMODE described in "providing recovery" in *z/OS MVS Programming: Authorized Assembler Services Guide*.

Note:

1. The FRESDDWA parameter cannot be specified or defaulted for a functional recovery routine (FRR). The SDWA is always released before an FRR's retry routine gets control.
2. The SERIAL parameter is relevant only for FRRs defined for SRBs that have a related task.
3. The SERIAL and RETRY parameters are mutually exclusive.

The following table indicates which parameters are available to functional recovery routines (FRRs) and which parameters are available to ESTAE-type recovery routines.

Parameter	FRR	ESTAE-type recovery routines
WKAREA	x	x
REGS	x	x
DUMP	x	x
REASON	x	x
RC=0	x	x
RC=4	x	x
RC=16		x
RETADDR	x	x
RETREGS	x	except for STAE and STAI
RUB	x	x
FRESDDWA		x
COMPCOD	x	x
FRELOCK	x	
RECORD	x	x

SETRP macro

Parameter	FRR	ESTAE-type recovery routines
RECPARM	X	X
SERIAL	X	
RETRY	X	
RETRY15	X	
REMREC	X	X
FRLKRTY	X	
DUMPOPT	X	X
DUMPOPX	X	X
SSRESET		X
RETRYAMODE	X	except for STAE and STAI

ABEND codes

None.

Return and reason codes

None.

Example 1

The first FRR established for an SRB routine requests percolation, freeing of the CML lock (the ASCB address is in register 2), and serialization of percolation to the related task.

```
SETRP  RC=0,FRELOCK=(CML(2)),SERIAL=YES
```

Example 2

An FRR requests retry with the retry routine getting control in the same cross memory mode as the time of FRR entry. The retry address is in register 3.

```
SETRP  RC=4,RETADDR=(3),RETRY=FRR
```

Chapter 5. SJFREQ — Call scheduler JCL facility services

Description

The SJFREQ macro services can be used to manipulate text unit data that represents processing options for system output (sysout) data sets. The SJFREQ services described in this information include the following:

- The SJFREQ RETRIEVE service retrieves keyword subparameter information in text unit format from output descriptors. These output descriptors can be specified either on an OUTPUT JCL statement or through dynamic output.
- The SJFREQ SWBTU_MERGE service merges lists of scheduler work block text units (SWBTUs) and allows applications to indicate keys to be removed from a list of SWBTUs.
- The SJFREQ VERIFY service verifies OUTDES statements, operands, and subparameters and builds text units to represent them. Your application can use these text units to dynamically define processing options for a sysout data set.
- The SJFREQ TERMINATE service cleans up SJF's working storage environment.

z/OS MVS Programming: Authorized Assembler Services Guide describes the OUTDES statement and its operands, as well as the individual SJF services.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	<p>The requirements vary, depending on the service.</p> <ul style="list-style-type: none"> • SJFREQ RETRIEVE and SJFREQ SWBTU_MERGE: Supervisor state, with a PSW key that matches the key of the caller's storage. • SJFREQ VERIFY: Problem state or supervisor state. For supervisor state, the caller must run in PSW key 1 and the caller's storage must be in PSW key 1. For problem state, the caller must have a PSW key that matches the key of the caller's storage. • SJFREQ TERMINATE: Problem state or supervisor state, with a PSW key that matches the key of the caller's storage.
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	Must be in the primary address space

Programming requirements

The application must include the CVT and IEFJESCT mapping macros. If the application codes the PARM parameter on the SJFREQ macro, the caller must also declare a 4-byte pointer, SJFPTR.

For each SJFREQ invocation, the application must initialize certain fields in an input parameter list. Fields are discussed within each service description. The following lists the parameter list name for each service.

Service	Parameter List Name
RETRIEVE	IEFSJREP
SWBTU_MERGE	IEFSJSMP
VERIFY	IEFSJVEP
TERMINATE	Any of the three parameter list names above.

Restrictions

None.

Input register information

Before issuing the SJFREQ macro, the caller must ensure that the following general purpose registers (GPRs) contain the specified information:

Register Contents

1

If PARM is not specified, the address of a word that contains the address of the input parameter list

13

The address of an 18-word save area

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the ARs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

Syntax

The standard form of the SJFREQ macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SJFREQ
SJFREQ	
␣	One or more blanks must follow SJFREQ
REQUEST=RETRIEVE	
REQUEST=SWBTU_MERGE	
REQUEST=VERIFY	
REQUEST=TERMINATE	
,PARM= <i>addr</i>	<i>addr</i> : RX-type address, or registers (1) - (12).

Parameters

The parameters are explained as follows:

REQUEST=RETRIEVE
REQUEST=SWBTU_MERGE
REQUEST=VERIFY
REQUEST=TERMINATE

Specifies the SJF service to be called. SJF services that you can request through the SJFREQ macro are:

RETRIEVE

The SJFREQ RETRIEVE service retrieves keyword subparameter information in text unit format from output descriptors. These output descriptors can be specified either on an OUTPUT JCL statement or through dynamic output. See [“SJFREQ RETRIEVE service” on page 60](#) for more detailed information on using this service.

SWBTU_MERGE

Use SJFREQ SWBTU_MERGE to create a single list of SWBTUs from a base SWBTU list and a merge SWBTU list. The resulting list of SWBTUs contains all the text units in the base and merge

lists. If duplicate text units exist, only one appears in the final SWBTU list. The SWBTU_MERGE service also allows an application to indicate keys to be removed from a list of SWBTUs. See [“SJFREQ SWBTU_MERGE service” on page 64](#) for more detailed information on using this service.

VERIFY

Use SJFREQ VERIFY to validate OUTDES statements and build text units to be used as input to dynamic output. See [“SJFREQ VERIFY service” on page 71](#) for more detailed information on using this service.

TERMINATE

Use SJFREQ TERMINATE after previously issuing a RETRIEVE, SWBTU_MERGE, or VERIFY request that specified the *no cleanup* option (SJxxNOCU). TERMINATE cleans up SJF's recovery and working storage environment. See [“SJFREQ TERMINATE service” on page 82](#) for more detailed information on using this service.

Note: When the no cleanup option (SJxxNOCU) is specified, you must ensure that the linkage stack level, at that time, persists until the TERMINATE is done. The TERMINATE must be done at the same linkage stack level.

,PARM=addr

Specifies the address of the parameter list for the service requested. You must initialize certain parameter list fields for each service. The following list indicates where the parameter lists are described.

- [“SJFREQ RETRIEVE input parameters” on page 61](#) describes the RETRIEVE parameter list.
- [“SJFREQ SWBTU_MERGE input parameters” on page 64](#) describes the SWBTU_MERGE parameter list.
- [“SJFREQ VERIFY input parameters” on page 71](#) describes the VERIFY parameter list.
- You may only use IEFSJREP, IEFSJSMP, or IEFSJVEP (use the same one you used on a prior request) for the TERMINATE service.

If you omit **PARM**, register 1 must contain the address of a word that contains the address of the input parameter list.

Example

Invoke the VERIFY service to:

- Validate the syntax of the statement OUTDES, the keyword operand CHARS, and the subparameter (GT10)
- Build text units for the valid keyword operand and subparameter.

```
OUTDES out1 CHARS(GT10)
```

Use the label out1 for the OUTDES statement in this example. The statement is to be converted into text units and used as input to OUTADD, the dynamic output macro.

```
*****
*   This program segment has attributes that allow the defined          *
*   storage to be altered.                                             *
*****
*
*       Set up SJVEP, VERIFY parameter list area.                      *
*
*****
*
*       XC   SJVEP(SJVELGTH),SJVEP   Clear the parameter list
*       MVC   SJVEID,=A(SJVEPEYE)   Parameter list ID
*       MVI   SJVEVERS,SJVECVER     Parameter list version
*       OI    SJVEFLAG,SJVENOCU     Indicate no cleanup to SJF on this
*                                   call, another call to SJF is
*                                   expected.
*
*       LA    R4,SJVELGTH           Get parameter list length
*       STH   R4,SJVELEN           Set parameter list length
*
```



```

*                               SJVESTOR and SJVEJDVT are properly
*                               set at zero from XC instruction.
*
*****
*                               Set up statement and operand information.
*
*****
*
*       MVC   SJVECMND,STATMNT   Set statement name field to OUTDES
*       ST     R2,SJVEOPEP       Set the operand pointer
*       LR     R15,R3            Get pointer to last operand
*                               character
*       SR     R15,R2            Get difference from first operand
*                               character
*       LA     R15,1(R15)        Add 1 to get proper operand length
*       STH    R15,SJVEOPEL      Set operand length
*
*****
*                               Set up subparameter information.
*
*****
*
*       LA     R15,1            Set up for first subparameter
*       STC    R15,SJVEPARAM    Set subparameter number to 1
*       ST     R4,SJVEPRMP      Set the subparameter pointer
*       LR     R15,R5            Get pointer to last subparameter
*                               character
*       SR     R15,R4            Get difference from first
*                               subparameter character
*       LA     R15,1(R15)        Add 1 to get proper subparameter
*                               length
*       STH    R15,SJVEPRML      Set the subparameter pointer
*
*****
*                               Set up output area information.
*
*****
*
*       LA     R15,AREASIZE      Get output work area length
*       STH    R15,SJVEUTUBL     Set text unit output area length
*       LA     R15,OUTAREA       Get address of output work area
*       ST     R15,SJVEUTBP      Set text unit output area size
*
*****
*                               Set up Register 1 to point to a word of storage that
*                               contains the address of SJVEP.
*
*****
*
*       LA     R4,SJVEP          Address of
*       ST     R4,SJVEPPTR       the SJFREQ VERIFY
*       LA     R1,SJVEPPTR       parameter list
*
*****
*                               Invoke SJFREQ VERIFY service.
*
*****
*       SJFREQ REQUEST=VERIFY    Issue the SJF macro.
*
*****
*       Check for a zero return code.
*
*****
*
*       LTR    R15,R15           Check service return code
*       BNZ    SJFERR            Go to nonzero return processing
*
*****
*
*       In this portion of the example, a zero return and reason
*       code are received. The output fields from the service
*       contain the following information:
*
*****

```

```

*      Register 15 - contains zero.
*
*      SJVEREAS - contains zero.
*
*      SJVEOPD - this field contains the operand description
*                for CHARS:
*                "CHARACTER ARRANGEMENT TABLE"
*
*      SJVEOPDL - this field contains the operand description
*                length - decimal 27.
*
*      SJVETUPL - this field contains an address into OUTAREA
*                that is the start of the text unit pointer
*                list.
*
*      OUTAREA - this area contains the text unit pointer
*                and the text unit that were built by VERIFY
*                for the CHARS(GT10) specification.
*****
*
*      SJFERR DS    0H                Label used for branch when SJFREQ
*                                     VERIFY returns with a nonzero
*                                     return code.
*
*      Code to handle SJFREQ errors
*
*****
*      Storage definitions
*
*****
*      IEFSJVEP DSECT=NO              SJFREQ VERIFY parameter list area
*
*      SJVEPPTR DS    A                Field used to contain SJVEP address
*
*      OUTAREA DS    XL1024            Area used by SJFREQ VERIFY to build
*                                     text units for valid operands and
*                                     subparameters.
*
*      AREASIZE EQU    *-OUTAREA       Size of AREA
*
*****
*      Equates and Constants
*
*****
*
R0      EQU    0                      Register 0
R1      EQU    1                      Register 1
R2      EQU    2                      Register 2
R3      EQU    3                      Register 3
R4      EQU    4                      Register 4
R5      EQU    5                      Register 5
R6      EQU    6                      Register 6
R7      EQU    7                      Register 7
R8      EQU    8                      Register 8
R9      EQU    9                      Register 9
R15     EQU    15                     Register 15
*
SJVEPEYE EQU    C'SJVE'              VERIFY parameter list identifier
STATMNT DC    CL8'OUTDES '          Statement name
*
*****

```

SJFREQ RETRIEVE service

The SJFREQ RETRIEVE service retrieves keyword subparameter information in text unit format from output descriptors. These output descriptors can be specified either on an OUTPUT JCL statement or through dynamic output. Your application can invoke this service to retrieve output descriptor information in a functional subsystem environment.

Programming requirements

An application must complete the following steps to issue a RETRIEVE request:

1. Obtain storage for the RETRIEVE parameter list (IEFSJREP) and initialize the fields. Place the address of IEFSJREP in the PARM parameter.
2. Provide a keyword list (SJRELIST). The keyword list contains the keywords for which the application wants information retrieved. [“SJFREQ RETRIEVE keyword list” on page 61](#) describes the list.
3. Issue SJFREQ RETRIEVE.

SJFREQ RETRIEVE keyword list

The keyword list contains paired fields; each pair consists of a keyword field and a pointer field. In the list, the application specifies the JCL keywords for which information is to be retrieved. For each keyword specified, the RETRIEVE service returns in SJRETPAD a pointer to the text unit pointer list associated with the keyword.

The following table shows the SJRELIST paired fields and their offsets and lengths. The fields that the application initializes are indicated.

Field Name	Offset (bytes)	Value Length (bytes)	Value to be assigned
SJRELIST			
SJREKEYW	0 (X'0')	8	keyword 1 (initialized by application)
SJRETPAD	8 (X'8')	4	pointer (returned by the system)
SJREKEYW	12 (X'C')	8	keyword 2 (initialized by application)
SJRETPAD	20 (X'14')	4	pointer (returned by the system)
.	.	.	.
.	.	.	.

In addition to JCL keywords, SJFREQ can also return a text unit for the keyword providing special TCP/IP support. This text unit has the following characteristics in the Output Descriptor.

Characteristic:

Keyword Parameter: IPADDR

Key in Hex: 8005

Maximum number of Value

Fields: 1

Length of Value Field: 0 - 124

Value Field: EBCDIC text '40'X - 'FE'X

Function: IP address extracted from the DEST='IP:ip-address' format of the DEST=keyword

SJFREQ RETRIEVE input parameters

In addition to providing a keyword list, for each SJFREQ invocation, you need to initialize certain fields of parameter list IEFSJREP. The list of parameters and descriptions of their values are below.

SJREID

The identifier 'SJRE' of the RETRIEVE parameter list. Assign the symbolic equate SJRECID to this field.

SJREVERS

The current version number of the RETRIEVE parameter list. Assign the symbolic equate SJRECVVER to this field.

SJREFLAG

The environment control flag.

SJRENOCU

Indicates whether the SJF environment is preserved from call to call or obtained for each call. Set to one to preserve the environment from call to call. Set to zero to obtain a new environment for a call.

SJRELEN

The length of the RETRIEVE parameter list (IEFSJREP). Assign the symbolic equate SJRELGTH to this field.

SJRESTOR

The local working storage pointer or zero. This field must contain zero on the first RETRIEVE call. On subsequent calls, the field contains the value returned from the most recent RETRIEVE call. Use the returned value for subsequent calls.

SJREJDVT

Enter zero for this field on input. This field must contain zero on the first RETRIEVE call. On subsequent calls, the field contains the value returned from the most recent RETRIEVE call. Use the returned value for subsequent calls.

SJRETOKN

Enter the output descriptor token in this field. If you are coding a Print Service Facility (PSF) exit, refer to *PSF/MVS System Programming Guide* for information on obtaining the output descriptor token. The token can be obtained from the GDSOUTK field in data area IAZFSIP.

SJREAREA

The address of the storage area in which RETRIEVE is to return the keyword subparameter information in text unit format from output descriptors.

SJRESIZE

The amount of the storage allocated for the output descriptor information.

SJRENKWD

The number of keywords passed in the keyword list (SJRELIST).

SJREKWDL

The address of the keyword list (SJRELIST).

SJFREQ RETRIEVE output parameters

In addition to the output provided in the keyword list, the RETRIEVE service returns data in several fields of the IEFSJREP parameter list. The list of output parameters and their descriptions are below.

SJREREAS

Contains a reason code returned from the RETRIEVE service. This field contains a value when register 15 contains a return code other than zero.

SJREKERR

Contains the address of the first keyword in the keyword list that caused the error.

SJRETPAD

Contains the address of the list of text unit pointers. Each text unit pointer points to a returned text unit. The last text unit has the high-order bit set to one.

ABEND codes

None.

SJFREQ RETRIEVE return and reason codes

SJFREQ RETRIEVE return codes appear in register 15. When SJFREQ returns control to your program, SJREREAS contains a reason code when register 15 contains a nonzero value. Return and reason codes are defined in macro IEFSJRC. The following table identifies the hexadecimal return and reason code combinations, tells what each means, and recommends an action you should take.

Table 7. Return and Reason Codes for the SJFREQ RETRIEVE Service		
Return Code	Reason Code	Meaning and Action
0	000	Meaning: RETRIEVE processing completed successfully. Action: None.
4	002	Meaning: Program error. The token specified in SJRETOKN is not valid. Action: Specify a valid token in SJRETOKN.
4	004	Meaning: Program error. The RETRIEVE request was not processed. The value specified in SJREJDVT is not valid. Action: Set SJREJDVT to hexadecimal zeros or to the value returned on the previous call.
4	005	Meaning: System error. The information referenced by parameter field SJREJDVT does not exist. Action: SJF did not initialize properly. Contact the appropriate IBM support personnel.
4	0C8	Meaning: Program error. SJRETOKN refers to a JCL statement that is not valid. Action: Supply a value in SJRETOKN that refers to a valid JCL statement.
4	0C9	Meaning: Program error. A keyword in the keyword list is not defined to the JCL statement referred to by SJRETOKN. Action: SJREKERR contains the address of the keyword in error. Correct or delete the keyword in error.
4	258	Meaning: Program error. The area specified by SJRESIZE is less than the minimum allowed. Action: Define SJRESIZE to a size that can contain at least one text unit.
4	25B	Meaning: Program error. No storage area address was specified. Action: Specify a storage area address in SJREAREA.
4	25C	Meaning: Program error. The value in SJRENKWD indicates that no keywords were specified. Action: Specify a value of one or greater for SJRENKWD.
4	25D	Meaning: Program error. No keyword list address was specified. Action: Specify a keyword list address in SJREKWDL.
4	25F	Meaning: Program error. Zero is given as the value for a keyword in the keyword list. Action: SJREKERR contains the address of the keyword. Change the zero to a valid value.
0C	000	Meaning: System error. The system could not obtain storage for this request. Action: Inform your system programmer of this problem.
10	000	Meaning: System error. The ESTAE-type recovery routine failed. Action: Inform your system programmer of this problem.

Table 7. Return and Reason Codes for the SJFREQ RETRIEVE Service (continued)		
Return Code	Reason Code	Meaning and Action
14	000	<p>Meaning: System error. SJF encountered a condition that caused an abnormal termination.</p> <p>Action: Check the input parameters, particularly any pointer fields, to determine if the input values are correct.</p>
18	000	<p>Meaning: System error. The service routines for SJFREQ are not available.</p> <p>Action: SJF did not initialize properly. Contact the appropriate IBM support personnel.</p>

SJFREQ SWBTU_MERGE service

Use the SWBTU_MERGE service to merge a list of base SWBTUs with a list of merge SWBTUs that contain modifications. An application can also use the SWBTU_MERGE service to indicate keys to be removed from a list of SWBTUs.

Programming requirements

You must provide input information in the SWBTU_MERGE parameter list (IEFSJSMP).

In addition to the IEFSJSMP parameter list, you can provide an erase list. An erase list is a contiguous set of text units that you request to be erased from a base SWBTU. An erase list is required when you set SJSMETUP and SJSMETUS. If only a merge SWBTU and erase list are provided on input, SWBTU_MERGE validates the erase list, but does not apply it to the resulting SWBTU.

SJFREQ SWBTU_MERGE input parameters

For each SJFREQ invocation, you need to initialize certain fields of parameter list IEFSJSMP. The list of parameters and descriptions of their values are below.

SJSMID

The identifier 'SJSM' of the SWBTU_MERGE parameter list. Assign the symbolic equate SJSMCID to this field.

SJSMVERS

The current version number of the SWBTU_MERGE parameter list. Assign the symbolic equate SJSMCVER to this field.

SJSMFLAG

The environment control flag.

SJSMNOCU

Indicates whether the SJF environment is preserved from call to call or obtained for each call. Set to one to preserve the environment from call to call. Set to zero to obtain a new environment for a call.

SJSMLLEN

The length of the SWBTU_MERGE parameter list (IEFSJSMP). Assign the symbolic equate SJSMLGTH to this field.

SJSMSTOR

The local working storage pointer or zero. This field must contain zero on the first SWBTU_MERGE call. On subsequent calls, the field contains the value returned from the most recent SWBTU_MERGE call. Use the value returned for subsequent calls.

SJSMAREA

The address of the area to which a single SWBTU is returned after SWBTU_MERGE processing. SJSMSIZE contains the size of this area.

SJSM SIZE

The length of the area to which a single SWBTU is returned after SWBTU_MERGE processing. Specify the size of SJSMAREA in this field.

SJSM SWBN

The number of SWBTU pointers in the base SWBTU pointer list. This field can be zero if the address of the base SWBTU pointer list (SJSM SWBA) is also zero and you specify a merge SWBTU pointer list.

SJSM SWBA

The address of the base SWBTU pointer list. You can specify zero for this value if the number of SWBTU pointers in the base SWBTU pointer list (SJSM SWBN) is zero and you specify a merge SWBTU pointer list.

SJSM MTUP

The address of the merge SWBTU pointer list. You can specify zero for this value if the number of SWBTU pointers in the merge SWBTU pointer list (SJSM MTUN) is zero and you specify a base SWBTU pointer list.

SJSM MTUN

The number of SWBTU pointers in the merge SWBTU pointer list. You can specify zero for this value if the address of the merge SWBTU pointer list (SJSM MTUP) is zero and you specify a base SWBTU pointer list.

SJSM ETUS

The number of elements contained on input in the erase text unit list area. You can specify zero for this value if the address of the erase text unit list area (SJSM ETUP) is zero.

SJSM ETUP

The address of the erase text unit list area. You can specify zero for this value if the address of the erase text unit list area (SJSM ETUS) is zero.

SJSM JDVT

Enter zero for this field on input. This field must contain zero on the first SWBTU_MERGE call. On subsequent calls, the field contains the value returned from the most recent SWBTU_MERGE call. Use the value returned for subsequent calls.

SJSM WARN

Set on to indicate that processing should continue after allowable errors. Clear this field so that processing does not continue after allowable errors. Allowable errors are described “Merging SWBTUs” in [z/OS MVS Programming: Authorized Assembler Services Guide](#).

SJSM BYMV

Set on to indicate whether the merge SWBTU text units should be validated.

SJSM BYEV

Set on to indicate whether the erase text units' keys should be validated.

SJSM SBTL

When SJSM SWBA and SJSM SWBN contain values, this field must contain the mapping of the base SWBTU pointer list. When SJSM MTUP and SJSM MTUN contain values, this field must contain the mapping of the merge SWBTU pointer list.

SJFREQ SWBTU_MERGE output parameters

Data for an SJFREQ SWBTU_MERGE function is returned in several fields of the IEFSJSMP parameter list. The list of output parameters and their descriptions are below.

SJSM REAS

Contains a reason code returned from the SWBTU_MERGE service. This field contains a value when register 15 contains a return code other than zero.

SJSM AREA

Contains a pointer to the output SWBTU.

SJSM TULN

Contains the size of the output SWBTU. The size is the total size of the prefix and all the text units.

SJSMMKER

If a validation error occurred, this field contains the key from the first merge SWBTU text unit in the merge SWBTU list where SWBTU_MERGE encountered an error. Otherwise, this field contains zero.

SJSMEKER

If a validation error occurred, this field contains the key from the first erase SWBTU in the erase SWBTU list where SWBTU_MERGE encountered the error. Otherwise, this field contains zero.

SJSMJDVT

If a value is returned in this field, use the returned value in this field for subsequent uses of the service.

SJSMRETC

The return code from the service in which the error was encountered.

SJSMERRS

This field contains a value when certain errors occur. See [Table 9 on page 71](#) for descriptions of the errors.

SJSMERRP

The point in the base or merge SWBTU pointer list entry at which an error was encountered.

SJFREQ SWBTU_MERGE ABEND codes

SJFREQ SWBTU_MERGE might abnormally terminate with abend code X'054'. See [z/OS MVS System Codes](#) for an explanation and programmer response for this code.

SJFREQ SWBTU_MERGE Return and reason codes

SJFREQ SWBTU_MERGE return codes appear in register 15. When SJFREQ returns control to your program, SJSMREAS contains a reason code if register 15 contains a nonzero value. Return and reason codes are defined in macro IEFSJRC. The following table identifies the hexadecimal return and reason code combinations, tells what each means, and recommends an action you should take. [Table 9 on page 71](#) lists and describes additional reason codes that appear in output field SJSMERRS when certain errors occur.

Table 8. Return and Reason Codes for the SJSMREAS Macro		
Return Code	Reason Code	Meaning and Action
0	000	Meaning: SWBTU_MERGE processing completed successfully. Action: None.
0	0CA	Meaning: Program error. SWBTU_MERGE processing completed successfully; however, the value in SJSMMKER or SJSMEKER was ignored. SJSMMKER or SJSMEKER contains a key in error. Action: Determine if it is acceptable for the information in SJSMMKER or SJSMEKER to be ignored.
0	0CB	Meaning: Program error. SWBTU_MERGE processing completed successfully; however, the text unit count for the key that appears in SJSMMKER is not valid. All data for this text unit is ignored. Action: Determine if it is acceptable for the text unit data to be ignored.
0	1F4	Meaning: Program error. SWBTU_MERGE processing completed successfully; however, a text unit length in a length-value pair for the key that appears in SJSMMKER is not valid. All data for this text unit is ignored. Action: Check the length specified for the key that appears in SJSMMKER. Determine if it is acceptable for the text unit to be ignored.

Table 8. Return and Reason Codes for the SJSMMREAS Macro (continued)

Return Code	Reason Code	Meaning and Action
0	1F5	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, a text unit value in a length-value pair for the key that appears in SJSMMKER is not valid. All data for this text unit is ignored.</p> <p>Action: Check the value specified for the key that appears in SJSMMKER. Determine if it is acceptable for the text unit to be ignored.</p>
0	1F6	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, a numeric value of a length-value pair in a text unit exceeds the maximum allowable value. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit and determine if it is acceptable for the text unit to be ignored.</p>
0	1F7	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, a numeric value of a length-value pair in a text unit is less than the minimum allowable value. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit and determine if it is acceptable for the text unit to be ignored.</p>
0	1FE	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, a character value level length in a text unit exceeds the maximum allowed for character data. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit and determine if it is acceptable for the text unit to be ignored.</p>
0	1FF	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, the number of levels for a character value in a text unit exceeds the maximum allowed. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit and determine if it is acceptable for the text unit to be ignored.</p>
0	200	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, the first character of the level in the character value in a text unit is not valid for character data. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit and determine if it is acceptable for the text unit to be ignored.</p>
0	201	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, a character is not valid for character data. The incorrect value is not the first character of the level in the character value in a text unit. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit and determine if it is acceptable for the text unit to be ignored.</p>
0	226	<p>Meaning: Program error. SWBTU_MERGE processing completed successfully; however, a text unit contained a text character that is outside the range X'40' - X'FE'. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit and determine if it is acceptable for the text unit to be ignored.</p>

Table 8. Return and Reason Codes for the SJSMREAS Macro (continued)		
Return Code	Reason Code	Meaning and Action
0	227	<p>Meaning: SWBTU_MERGE processing completed successfully; however, the sequence of characters in a text unit is not valid. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit parameter and determine if it is acceptable for the text unit to be ignored.</p>
0	228	<p>Meaning: SWBTU_MERGE processing completed successfully; however, there are bits on in the text unit parameter that the system does not recognize. SJSMMKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the value specified in the text unit parameter and determine if it is acceptable for the text unit to be ignored.</p>
0	76C	<p>Meaning: SWBTU_MERGE processing completed successfully. The resulting SWBTU (pointed to by SJSMAREA) has a prefix and no text units.</p> <p>Action: None required. However, you might take some action based on your application.</p>
4	0C8	<p>Meaning: Program error. The specified verb is not defined to the system.</p> <p>Action: Specify a valid verb.</p>
4	0CA	<p>Meaning: Program error. The system does not recognize the text unit key. SJSMMKER or SJSMEKER contains the key from the text unit that is in error. All data for this text unit is ignored.</p> <p>Action: Check the text unit key. Correct the key and issue the SJFREQ macro again.</p>
4	0CB	<p>Meaning: Program error. The count in a text unit is not valid. SJSMMKER contains the key for the text unit that is not valid.</p> <p>Action: Check the text unit count. Correct the count and issue the SJFREQ macro again.</p>
4	1F4	<p>Meaning: Program error. A length in a length-value pair in a text unit is not valid. SJSMMKER contains the key for the text unit that is not valid.</p> <p>Action: Check the length. Correct the length and issue the SJFREQ macro again.</p>
4	1F5	<p>Meaning: Program error. A text unit value in a length-value pair is not valid. SJSMMKER contains the key for the text unit that is not valid.</p> <p>Action: Check the value. Correct the value and issue the SJFREQ macro again.</p>
4	1F6	<p>Meaning: Program error. A numeric value of a length-value pair in a text unit exceeds the maximum allowable value. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value. Correct the value and issue the SJFREQ macro again.</p>
4	1F7	<p>Meaning: Program error. A numeric value of a length-value pair in a text unit is less than the minimum allowable value. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value. Correct the value and issue the SJFREQ macro again.</p>

Table 8. Return and Reason Codes for the SJSMREAS Macro (continued)

Return Code	Reason Code	Meaning and Action
4	1FE	<p>Meaning: Program error. A character value level length in a text unit exceeds the maximum allowed for character data. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value specified in the text unit. Correct the value and issue the SJFREQ macro again.</p>
4	1FF	<p>Meaning: Program error. The number of levels for a character value in a text unit exceeds the maximum allowed. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value specified in the text unit. Correct the value and issue the SJFREQ macro again.</p>
4	200	<p>Meaning: Program error. A character in a text unit is not valid for character data. The character is the first character in the level in the text unit. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value specified in the text unit. Correct the value and issue the SJFREQ macro again.</p>
4	201	<p>Meaning: Program error. A character is not valid for character data. The character is not the first character of the level in the character value in a text unit. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value specified in the text unit. Correct the value and issue the SJFREQ macro again.</p>
4	206	<p>Meaning: A text unit key contained hex zeros.</p> <p>Action: Check the text unit key value specified in the text unit. Correct the value and issue the SJFREQ macro again.</p>
4	226	<p>Meaning: Program error. A text unit contained a text character that is outside the range X'40' - X'FE'. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value specified in the text unit. Correct the value and issue the SJFREQ macro again.</p>
4	227	<p>Meaning: The sequence of characters in a text unit is not valid. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value specified in the text unit parameter. Correct the value and issue the SJFREQ macro again.</p>
4	228	<p>Meaning: There are bits on in the parameter that the system does not recognize. SJSMMKER contains the key from the text unit that is in error.</p> <p>Action: Check the value specified in the text unit parameter. Correct the value and issue the SJFREQ macro again.</p>
4	76D	<p>Meaning: Program error. The output area (identified by SJSMAREA and SJSMSIZE) is not large enough for the resulting SWBTU.</p> <p>Action: Increase the size of the output area and issue the SJFREQ macro again.</p>
4	76E	<p>Meaning: Program error. One of the following occurred:</p> <ul style="list-style-type: none"> • The base SWBTU pointer list address (SJSMWBA) is zero and the number of SWBTU pointers (SJMSWBN) in the base pointer list is not zero • The SWBTU pointer list address is not zero and the number of SWBTU pointers in the base pointer list is zero. <p>Action: Supply the correct values for SJMSWBA and SJMSWBN and issue the SJFREQ macro again.</p>

Table 8. Return and Reason Codes for the SJSMMREAS Macro (continued)		
Return Code	Reason Code	Meaning and Action
4	76F	<p>Meaning: Program error. One of the following occurred:</p> <ul style="list-style-type: none"> The merge SWBTU pointer list address (SJSMMTUP) is zero and the number of SWBTU pointers (SJSMMTUN) in the merge pointer list is not zero The merge SWBTU pointer list address is not zero and the number of SWBTU pointers in the merge pointer list is zero. <p>Action: Supply the correct values for SJSMMTUP and SJSMMTUN and issue the SJFREQ macro again.</p>
4	770	<p>Meaning: Program error. One of the following occurred:</p> <ul style="list-style-type: none"> The erase text unit address (SJSMETUP) is zero and the size of the erase text unit list area (SJSMETUS) is not zero The erase text unit address (SJSMETUP) is not zero and the size of the erase text unit list area (SJSMETUS) is zero. <p>Action: Supply the correct values for SJSMETUP and SJSMETUS and issue the SJFREQ macro again.</p>
4	771	<p>Meaning: Program error. Either the output area address (SJSMAREA) is zero or the output area size (SJSMSIZE) is not greater than zero.</p> <p>Action: Check the values in SJSMAREA and SJSMSIZE and determine which is incorrect. Specify valid values and issue the SJFREQ macro again.</p>
4	772	<p>Meaning: Program error. One of the following happened:</p> <ul style="list-style-type: none"> Neither a base SWBTU nor a modify SWBTU were specified (SJSMSWBA and SJSMMTUP are both zero). A base SWBTU was provided, but no modify SWBTU and no erase list were provided (SJSMMTUP and SJSMETUP are zero). <p>Action: Do one of the following:</p> <ul style="list-style-type: none"> Specify a base or modify SWBTU. If a base SWBTU was provided, specify either a modify SWBTU or an erase list.
4	773	<p>Meaning: Program error. The verb name in the merge SWBTU list does not match the verb name in the base SWBTU list.</p> <p>Action: Supply input for the same verb in both the base SWBTU list and the merge SWBTU list.</p>
4	774	<p>Meaning: Program error. One of the following occurred:</p> <ul style="list-style-type: none"> The version number (SJSMVERS) supplied in the parameter list does not match the version defined in macro IEFJSJMP The length (SJSMLLEN) supplied in the parameter list does not match the actual length. <p>Action: Ensure that the constant SJSMCVER is used in field SJSMVERS of the input parameter list and that the constant SJSMLGTH is used in field SJSMLLEN of the input parameter list.</p>
4	7A1	<p>Meaning: Program error. The base SWBTU list contains an error.</p> <p>Action: Check output fields SJSMERRP and SJSMERRS. SJSMERRP contains the address of a SWBTU that is in error. SJSMERRS may contain a reason code that indicates an error in the base or merge SWBTU list. See Table 9 on page 71 for the reason code descriptions.</p>
0C	000	<p>Meaning: System error. The system could not obtain storage for this request.</p> <p>Action: Inform your system programmer of this problem.</p>

Table 8. Return and Reason Codes for the SJSMEAS Macro (continued)

Return Code	Reason Code	Meaning and Action
10	000	Meaning: System error. The ESTAE-type recovery routine failed. Action: Inform your system programmer of this problem.
14	000	Meaning: System error. SJF encountered a condition that caused an abnormal termination. Action: Check the input parameters, particularly any pointer fields, to determine if the input values are correct.
18	000	Meaning: System error. The service routines for SJFREQ are not available. Action: SJF did not initialize properly. Contact the appropriate IBM support personnel.

Output field SJSMEERRS contains a reason code when certain errors occur. Table 9 on page 71 lists the reason codes and their meanings.

Table 9. Return and Reason Codes for the SJFREQ Macro SWBTU_MERGE Service

Return Code	Reason Code	Meaning and Action
4	018	Meaning: Program error. The application did not supply either the base SWBTU list or the merge SWBTU list. Action: Determine which list is missing. Supply the missing list and issue the SJFREQ macro again.
4	019	Meaning: Program error. The prefix for either the base SWBTU list or merge SWBTU list is not valid. Action: Determine which prefix is not valid. Supply the correct prefix and issue the SJFREQ macro again.
4	028	Meaning: Program error. The verb and label values in either the base SWBTU list or the merge SWBTU list do not match. Action: Determine which pair does not match. Correct the information and issue the SJFREQ macro again.

SJFREQ VERIFY service

Use VERIFY to validate and build text units to represent an OUTDES statement, its operands, subparameters and sublist elements. The OUTDES information corresponds to SJF-defined information on the OUTPUT JCL statement. If you do not specify correctly the input subparameter data, VERIFY returns an error message.

SJFREQ VERIFY input parameters

For each SJFREQ invocation, you need to initialize certain fields of parameter list IEFSJVEP. See SJVEP in *z/OS MVS Data Areas* in the z/OS Internet library (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary) for the mapping provided by the IEFSJVEP mapping macro. The list of parameters and descriptions of their values are below, followed by Table 10 on page 73 that summarizes the required parameter fields for the three SJFREQ VERIFY functions.

VERIFY performs three functions. Use Table 10 on page 73 to determine the required parameters for the SJFREQ VERIFY function you want to request. The table gives details about the required values.

SJVEID

The identifier 'SJVE' of the VERIFY parameter list. Assign the symbolic equate SJVECID to this field.

SJVEVERS

The current version number of the SJFREQ VERIFY parameter list. Assign the symbolic equate SJVECV to this field.

SJVEFLAG

The environment control flag.

SJVENOCU

Indicates whether the SJF environment is preserved from call to call or obtained for each call. Parameter SJVESTOR references the environment. When set to 0, the environment is obtained for each call. When set to 1, the environment is preserved.

SJVEUNAU

Indicates whether the caller is unauthorized. If an application makes repetitive service calls using the same SJF environment, the authorization must be same for each call.

SJVELEN

The length of the VERIFY parameter list (IEFSJVEP). Assign the symbolic equate SJVELGTH to this field.

SJVESTOR

The local working storage pointer or zero. This field must contain zero on the first VERIFY call. On subsequent calls, the field contains the value returned from the most recent VERIFY call.

SJVEJDVT

Enter zero for this field on input. If a value is returned in the field, use the returned value for subsequent uses of the service.

SJVECMND

The name of the statement that contains the output descriptor information. Specify the statement name OUTDES in an 8-character field, left-justified, and padded with blanks.

SJVEOPEP

The pointer to the operand or keyword operand to be validated. This field should contain an address of the first byte of the operand or keyword operand. Set the length of the operand in SJVEOPEL. Zero is a valid value when specifying just the statement name as specified in SJVECMND.

SJVEOPEL

The length of the operand or keyword operand to be validated. This field should contain the actual length of the operand or keyword operand pointed to by SJVEOPEP.

SJVEPARM

The subparameter number representing the subparameter to be validated. Set this value to one whenever validating an operand. When validating a keyword operand, set this to the correct subparameter number.

SJVESUBL

The sublist element number representing the sublist element to be validated. This field should be set to zero if the subparameter is not a sublist.

SJVEPRMP

The pointer to the subparameter or sublist element to be validated. Set the length of the subparameter or sublist element in SJVEPRML.

SJVEPRML

The length of the subparameter or sublist element pointed to by SJVEPRMP. This field should contain the actual length of the subparameter or sublist element pointed to by SJVEPRMP.

SJVETUBL

The length of the text unit output area. The field should contain the length of the output area pointed to by SJVETUBP. The minimum you should specify for the output area is 256 bytes plus sufficient storage to accommodate the text units that will be built as a result of your VERIFY request. A work area of 1K is large enough for any set of text units to be built.

SJVETUBP

The pointer to the text unit output area. The output area will contain the text unit pointer list and text units upon return from the VERIFY service call. If the output area is not large enough to hold all the text units and the text unit pointer list, you can point to and use an additional output area. When using additional output areas, the original output area must be accessible to SJF; it cannot be freed or changed. Set the length of the output area in SJVETUBL.

SJVEFLG1

The VERIFY option flag.

SJVELSTC

Indicates last call for the text units being built. Set this indicator to one for the last VERIFY call. Setting this indicator on makes the text units available for use.

SJVERSBS

Indicates that the same text unit output area is to be used for multiple calls. SJVETUBS contains the returned length of the area the service used to build the text units and text unit pointer list. When this indicator is on, SJVETUBP must be the same for each VERIFY call.

SJVEQUOT

Indicates that a subparameter was specified in quotation marks. To allow quotation marks on all subparameters, the caller can set this bit to zero. Note that some subparameters do not allow quotation marks. For any value specified in quotation marks, the caller should have:

- Removed the delimiting quotation marks
- Converted two consecutive single quotation marks to one single quotation mark.

SJVEPRFX

The prefix to be concatenated to a subparameter that is a data set name. This field is not used if SJVEQUOT is on or if the subparameter is not defined as allowing unqualified data set names. If no prefix is specified, this field must be set to zero.

<i>Table 10. Required Fields for SJFREQ VERIFY Functions</i>			
IEFSJVEP parameter list field	Validate a subparameter or sublist element and build a text unit	Validate an operand or keyword operand	Validate a statement name
SJVEID	Symbolic equate SJVECID	Symbolic equate SJVECID	Symbolic equate SJVECID
SJVEVERS	Symbolic equate SJVECVVER	Symbolic equate SJVECVVER	Symbolic equate SJVECVVER
SJVENOCU	Set to indicate if the SJF environment should be reused.	Set to indicate if the SJF environment should be reused.	Set to indicate if the SJF environment should be reused.
SJVEUNAU	Set to indicate if the caller is authorized.	Set to indicate if the caller is authorized.	Set to indicate if the caller is authorized.
SJVELEN	Symbolic equate SJVELGTH	Symbolic equate SJVELGTH	Symbolic equate SJVELGTH
SJVESTOR	Local working storage pointer or zero	Local working storage pointer or zero	Local working storage pointer or zero
SJVECMND	Statement name associated with the operand for which the subparameter or sublist is to be validated.	Statement name associated with the operand to be validated.	Statement name to be validated.
SJVEOPEP	Address of the field that contains the subparameter or sublist element to be validated.	Address of the field that contains the operand or keyword operand to be validated.	zeros

<i>Table 10. Required Fields for SJFREQ VERIFY Functions (continued)</i>			
IEFSJVEP parameter list field	Validate a subparameter or sublist element and build a text unit	Validate an operand or keyword operand	Validate a statement name
SJVEOPEL	Length of the field that contains the subparameter or sublist element (SJVEOPEP).	Length of the field that contains the operand or keyword operand to be validated (SJVEOPEP).	not used
SJVEPARM	Number of the subparameter to be verified (1 for the first, 2 for the second, . . .)	zeros	zeros
SJVESUBL	If the subparameter to be verified is a sublist, specify the number of the sublist element (1 for the first, 2 for the second, . . .). If the subparameter is not a sublist, specify zero.	not used	not used
SJVEPRMP	Address of the field with the subparameter or sublist to be verified.	not used	not used
SJVEPRML	Length of the subparameter or sublist to be verified.	not used	not used
SJVETUBL	Length of the SJFREQ VERIFY workarea.	not used	not used
SJVETUBP	Pointer to the SJFREQ VERIFY workarea.	not used	not used
SJVELSTC	Last call bit	not used	not used
SJVEQUOT	Subparameters can be specified in quotation marks.	not used	not used
SJVERSBS	Text unit buffer is to be used for multiple calls.	not used	not used
SJVEPRFX	Prefix to be concatenated to a subparameter.	not used	not used

SJFREQ VERIFY output parameters

Data for an SJFREQ VERIFY function is returned in several fields of the IEFSJVEP parameter list. The list of output parameters and their descriptions are below, followed by [Table 11 on page 75](#) that summarizes the output parameters returned for each of the three SJFREQ VERIFY functions.

SJVEREAS

The reason code returned from VERIFY processing. See [“Return and reason codes with related message text” on page 77](#) for information about specific reason codes.

SJVEJDVT

If the caller specified zero on input, this field contains the default JDVT name. Otherwise, the value in this field will be the same as it was on input.

SJVETUBS

The length of the storage used in the text unit output area to build the text unit pointer list and text units. This field is filled in only when SJVERSBS is set on. The text unit output area is referenced by fields SJVETUBL and SJVETUBP.

SJVETUPL

The pointer to the beginning of the text unit pointer list in the text unit output area.

SJVEOPD

The SJF description of the operand or keyword operand that was referenced on input by the fields SJVEOPEP and SJVEOPEL. Applications can use information in this field in messages to their application users in place of the operand or keyword operand. Refer to [“Operand descriptions” on page 76](#) for the operands and their descriptions. VERIFY returns a value in this field for return code 0 and reason codes with return code 4.

SJVEOPDL

The length of the operand or keyword operand description returned in field SJVEOPD.

SJVEMSGL

The length of the message information returned in SJVEMSG.

SJVEMSG

This field contains a message that indicates the correct syntax for the subparameter or sublist element that is in error. The subparameter or sublist element is referenced by the input fields SJVEPRMP and SJVEPRML. VERIFY returns a value in this field for return code 4 with some reason codes. Refer to [“Return and reason codes with related message text” on page 77](#) for the actual message text VERIFY returns.

When an application receives a return code of 0 or 4, VERIFY returns values in the parameter list fields indicated below. The table is organized by function and return code. VERIFY does not fill in any output parameter list fields when it returns a return code 8 or above.

<i>Table 11. SJFREQ VERIFY Output Fields</i>						
IEFSJVEP parameter list field	Validate a subparameter or sublist element and build a text unit Return Code 0	Validate a subparameter or sublist element and build a text unit Return Code 4	Validate an operand or keyword operand Return Code 0	Validate an operand or keyword operand Return Code 4	Validate a statement name Return Code 0	Validate a statement name Return Code 4
SJVEREAS	Value returned	Value returned	Value returned	Value returned	Value returned	Value returned
SJVEJDVT	Value returned	Value returned	Value returned	Value returned	Value returned	Value returned
SJVETUBS	Value returned only when SJVER SBS is set to 1.	—	—	—	—	—
SJVETUPL	Value returned	Value returned for some reason codes.	—	—	—	—
SJVEOPD	Value returned	Value returned for some reason codes.	Value returned	—	—	—
SJVEOPDL	Value returned	Value returned for some reason codes.	Value returned	—	—	—

Table 11. SJFREQ VERIFY Output Fields (continued)

IEFSJVEP parameter list field	Validate a subparamete r or sublist element and build a text unit Return Code 0	Validate a subparamete r or sublist element and build a text unit Return Code 4	Validate an operand or keyword operand Return Code 0	Validate an operand or keyword operand Return Code 4	Validate a statement name Return Code 0	Validate a statement name Return Code 4
SJVEMSG	—	Value returned for some reason codes.	—	—	—	—
SJVEMSG	—	Value returned for some reason codes.	—	—	—	—

Operand descriptions

Operand descriptions appear in parameter list field SJVEOPD as indicated in [Table 11 on page 75](#). The table that follows lists the operands, keyword operands and their descriptions.

Table 12. SJF Operand and Keyword Operand Descriptions. These descriptions appear in parameter field SJVEOPD.

Operand or Keyword Operand	Description
ADDRESS	ADDRESS FOR SEPARATOR PAGE
BUILDING	BUILDING ID
BURST	BURSTER TRIMMER STACKER
NOBURST	BURSTER TRIMMER STACKER
CHARS	CHARACTER ARRANGEMENT TABLE
CKPTLINE	CHECKPOINT LINES
CKPTPAGE	CHECKPOINT PAGES
CKPTSEC	CHECKPOINT SECONDS
CLASS	OUTPUT CLASS
COMPACT	COMPACTION TABLE NAME
CONTROL	CARRIAGE CONTROL
COPIES	NUMBER OF COPIES
COPYCNT	NUMBER OF COPIES
DATAACK	DATA CHECK
DEFAULT	DEFAULT OUTPUT DESCRIPTOR
NODEFAULT	DEFAULT OUTPUT DESCRIPTOR
DEPT	DEPARTMENT ID
DEST	OUTPUT DESTINATION
DPAGELBL	DATA PAGE LABEL
NODPAGELBL	DATA PAGE LABEL
FCB	FORMS CONTROL IMAGE
FLASH	FORMS OVERLAY

Table 12. SJF Operand and Keyword Operand Descriptions. These descriptions appear in parameter field SJVEOPD. (continued)

Operand or Keyword Operand	Description
FORMDEF	FORM DEFINITION MEMBER NAME
FORMS	PRINT FORMS
GROUPID	OUTPUT GROUP IDENTIFIER
INDEX	RIGHT PRINT POSITION INDEX
LINDEX	LEFT PRINT POSITION INDEX
LINECT	LINE COUNT
MODIFY	COPY MODIFICATION MODULE
NAME	NAME OF SYSOUT OWNER
NOTIFY	DESTINATION FOR PRINT COMPLETE MESSAGES
OUTBIN	PRINTER OUTPUT BIN ID
OUTDISP	SYSOUT DISPOSITION
PAGEDEF	PAGE DEFINITION MEMBER NAME
PIMSG	PRINTER INFORMATION MESSAGES
PRMODE	PROCESS MODE
PRTY	OUTPUT PRIORITY
ROOM	ROOM IDENTIFICATION
SYSAREA	SYSTEM PRINTABLE AREA
NOSYSAREA	SYSTEM PRINTABLE AREA
THRESHLD	MAXIMUM LINES OF OUTPUT
TITLE	NAME FOR SEPARATOR PAGE
TRC	TABLE REFERENCE CHARACTER
NOTRC	TABLE REFERENCE CHARACTER
UCS	UNIVERSAL CHARACTER SET
USERLIB	USER SPECIFIED AFP RESOURCE LIBRARIES
WRITER	EXTERNAL WRITER NAME

ABEND codes

SJFREQ VERIFY might abnormally terminate with abend code X'054'. See [z/OS MVS System Codes](#) for an explanation and programmer response.

Return and reason codes with related message text

SJFREQ VERIFY return codes appear in register 15. When SJFREQ returns control to your program, SJVEREAS contains a reason code. Return and reason codes are defined in macro IEFSJRC. The following table identifies the hexadecimal return and reason code combinations, tells what each means, and recommends an action you should take. Message text returned in field SJVEMSG appears with the meanings and actions for the related reason codes. *Italics indicates variable parts of the message.* Words in bold print indicate that VERIFY selects among those choices before returning the message.

For return code 4, reason codes 1F4 - 204, 226, and 4B3, the subparameter or sublist element referenced in SJVEPRMP and SJVEPRML is not correct. For each of these conditions, a description of the correct specification of the field is returned in SJVEMSG. The related message text appears with the appropriate reason codes that follow. SJVEOPD contains a description of the operand or keyword operand. [Table 12 on page 76](#) lists the operands and keyword operands and their descriptions.

Table 13. Return and Reason Codes for the SJFREQ Macro VERIFY Service

Return Code	Reason Code	Meaning and Action
0	000	Meaning: VERIFY processing completed successfully. Action: None.
04	004	Meaning: Program error. The VERIFY request was not processed. The value specified in SJVEJDVT is not valid. Action: Set SJVEJDVT to hexadecimal zeros or to the value returned on the previous call.
04	005	Meaning: System error. The information referenced by parameter field SJVEJDVT does not exist. Action: SJF did not initialize properly. Contact the appropriate IBM support personnel.
04	0CB	Meaning: Program error. SJF does not recognize the subparameter specified in SJVEPARM. Action: Check the number of subparameters allowed and the value specified in SJVEPARM.
04	0CF	Meaning: Program error. The command specified in SJVECMND is not recognized by SJF. Action: Check the spelling and specification (left-justified, padded with blanks) of the value specified in SJVECMND.
04	0D0	Meaning: Program error. The operand or keyword operand indicated by fields SJVEOPEP and SJVEOPEL is not recognized by SJF. Action: Check the specified length and the spelling of the operand or keyword operand. Make sure SJVEOPEP is a pointer value.
04	1F4	Meaning: Program error. The length of a specified subparameter or sublist element as specified in SJVEPRML is not valid. Action: Check the subparameter or sublist element length specified in SJVEPRML and the allowable subparameter or sublist element length. Message text: VALUE MUST BE 1 CHARACTER VALUE MUST BE <i>n</i> CHARACTERS VALUE MUST BE <i>minimum length</i> TO <i>maximum length</i> CHARACTERS If an error occurs involving a subparameter that is a data set name and the application specified a prefix, and SJVEQUOT is off (0), the following message might be added to the above message text. VALUE NOT ENCLOSED IN QUOTES IS CONCATENATED TO PREFIX <i>value in SJVEPRFX</i> .
04	1F5	Meaning: Program error. A subparameter that was specified is not a valid choice. Action: Specify one of the allowable subparameters for the keyword operand. Message text: VALUE MUST BE <i>choice1</i> . . .OR <i>choice n</i>

Table 13. Return and Reason Codes for the SJFREQ Macro VERIFY Service (continued)

Return Code	Reason Code	Meaning and Action
04	1F6	<p>Meaning: Program error. A numeric subparameter or sublist element exceeds the maximum allowable value.</p> <p>Action: Check the values specified in SJVEPRMP and SJVEPRML and the allowable value for this subparameter or sublist element.</p> <p>Message text: VALUE MUST BE IN THE RANGE OF <i>minimum value</i> TO <i>maximum value</i></p>
04	1F7	<p>Meaning: Program error. A numeric subparameter or sublist element is less than the minimum allowable value.</p> <p>Action: Check the values specified in SJVEPRMP and SJVEPRML and the allowable value for this subparameter or sublist element.</p> <p>Message text: VALUE MUST BE IN THE RANGE OF <i>minimum value</i> TO <i>maximum value</i></p>
04	1FA	<p>Meaning: Program error. No subparameter or sublist element was specified for the keyword operand.</p> <p>Action: Specify a value in SJVEPRML.</p> <p>Message text: VALUE MUST BE 1 LEVEL VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS WITH 1 TO <i>maximum level length</i> CHARACTERS IN EACH LEVEL VALUE MUST BE 1 CHARACTER VALUE MUST BE <i>n</i> CHARACTERS VALUE MUST BE <i>minimum length</i> TO <i>maximum length</i> CHARACTERS If an error occurs involving a subparameter that is a data set name and the application specified a prefix, and SJVEQUOT is off (0), the following message might be added to the above message text. VALUE NOT ENCLOSED IN QUOTES IS CONCATENATED TO PREFIX <i>value in SJVEPRFX</i>. VALUE MUST BE <i>choice1</i>. .OR <i>choice n</i> VALUE MUST BE HEXADECIMAL CHARACTER, CHARACTERS VALUE MUST BE NUMERIC CHARACTER VALUE MUST BE NUMERIC CHARACTERS PRINTABLE CHARACTER, CHARACTERS VALUE MUST BE SPECIFIED WITH THE <i>keyword</i> KEYWORD</p>

Table 13. Return and Reason Codes for the SJFREQ Macro VERIFY Service (continued)

Return Code	Reason Code	Meaning and Action
04	1FE	<p>Meaning: Program error. The subparameter or sublist element level length exceeds the maximum allowed for character data.</p> <p>Action: Check the value in SJVEPRML.</p> <p>Message text:</p> <p>VALUE MUST BE 1 LEVEL</p> <p>VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS</p> <p>VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS WITH 1 TO <i>maximum level length</i> CHARACTERS IN EACH LEVEL</p> <p>If an error occurs involving a subparameter that is a data set name and the application specified a prefix, and SJVEQUOT is off (0), the following message might be added to the above message text.</p> <p>VALUE NOT ENCLOSED IN QUOTES IS CONCATENATED TO PREFIX <i>value in SJVEPRFX</i>.</p>
04	1FF	<p>Meaning: Program error. The number of levels for a subparameter or sublist element exceeds the maximum allowed.</p> <p>Action: Check the value pointed to by SJVEPRMP.</p> <p>Message text:</p> <p>VALUE MUST BE 1 LEVEL</p> <p>VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS</p> <p>VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS WITH 1 TO <i>maximum level length</i> CHARACTERS IN EACH LEVEL</p> <p>If an error occurs involving a subparameter that is a data set name and the application specified a prefix, and SJVEQUOT is off (0), the following message might be added to the above message text.</p> <p>VALUE NOT ENCLOSED IN QUOTES IS CONCATENATED TO PREFIX <i>value in SJVEPRFX</i>.</p>
04	200	<p>Meaning: Program error. The first character of the level in the subparameter or sublist element is not valid for character data.</p> <p>Action: Check the value pointed to by SJVEPRMP.</p> <p>Message text:</p> <p>VALUE MUST BE ALPHABETIC, NUMERIC, NATIONAL, OR <i>list of special characters</i> FIRST CHARACTER</p> <p>VALUE MUST BE ALPHABETIC, NUMERIC, NATIONAL, OR <i>list of special characters</i> CHARACTER</p> <p>VALUE MUST BE ALPHABETIC, NUMERIC, NATIONAL, OR <i>list of special characters</i> CHARACTERS</p> <p>VALUE CONTAINS INVALID FIRST CHARACTER</p> <p>If an error occurs involving a subparameter that is a data set name and the application specified a prefix, and SJVEQUOT is off (0), the following message might be added to the above message text.</p> <p>VALUE NOT ENCLOSED IN QUOTES IS CONCATENATED TO PREFIX <i>value in SJVEPRFX</i>.</p>

Table 13. Return and Reason Codes for the SJFREQ Macro VERIFY Service (continued)

Return Code	Reason Code	Meaning and Action
04	201	<p>Meaning: Program error. A character other than the first character of the level in the subparameter or sublist element is not valid for character data.</p> <p>Action: Check the value pointed to by SJVEPRMP.</p> <p>Message text:</p> <p>VALUE MUST BE ALPHABETIC, NUMERIC, NATIONAL OR, <i>list of special characters</i> CHARACTERS OTHER THAN THE FIRST</p> <p>VALUE MUST BE ALPHABETIC, NUMERIC, NATIONAL, OR <i>list of special characters</i> CHARACTER</p> <p>VALUE MUST BE ALPHABETIC, NUMERIC, NATIONAL, OR <i>list of special characters</i> CHARACTERS</p> <p>If an error occurs involving a subparameter that is a data set name and the application specified a prefix, and SJVEQUOT is off (0), the following message might be added to the above message text.</p> <p>VALUE NOT ENCLOSED IN QUOTES IS CONCATENATED TO PREFIX <i>value in SJVEPRFX</i>.</p>
04	202	<p>Meaning: Program error. The level specification is not valid.</p> <p>Action: Check the value pointed to by SJVEPRMP.</p> <p>Message text:</p> <p>VALUE MUST BE 1 LEVEL</p> <p>VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS</p> <p>VALUE MUST BE 1 TO <i>maximum number of levels</i> LEVELS WITH 1 TO <i>maximum level length</i> CHARACTERS IN EACH LEVEL</p> <p>If an error occurs involving a subparameter that is a data set name and the application specified a prefix, and SJVEQUOT is off (0), the following message might be added to the above message text.</p> <p>VALUE NOT ENCLOSED IN QUOTES IS CONCATENATED TO PREFIX <i>value in SJVEPRFX</i>.</p>
04	203	<p>Meaning: Program error. Nonhexadecimal characters were specified for a subparameter or sublist element.</p> <p>Action: Check the value pointed to by SJVEPRMP.</p>
04	204	<p>Meaning: Program error. Nonnumeric characters were specified for a subparameter or sublist element.</p> <p>Action: Check the value pointed to by SJVEPRMP.</p> <p>Message text:</p> <p>VALUE MUST BE NUMERIC CHARACTER, CHARACTERS</p>
04	226	<p>Meaning: Program error. A text character that was specified for a subparameter or sublist element is not valid.</p> <p>Action: Check the value pointed to by SJVEPRMP.</p> <p>Message text:</p> <p>VALUE MUST BE PRINTABLE CHARACTER, CHARACTERS</p>
04	229	<p>Meaning: A keyword operand specified was not a valid choice.</p> <p>Action: Specify one of the allowable keyword operands.</p> <p>Message text:</p> <p>VALUE IS NOT AN ALLOWABLE KEYWORD OPERAND</p>
04	4B0	<p>Meaning: Program error. No statement was specified. The value specified for SJVECMND is zero.</p> <p>Action: Specify a statement in SJVECMND.</p>

Table 13. Return and Reason Codes for the SJFREQ Macro VERIFY Service (continued)

Return Code	Reason Code	Meaning and Action
04	4B1	Meaning: Program error. No address was specified in SJVETUBP for the text unit output area. Action: Specify a value in SJVETUBP.
04	4B2	Meaning: Program error. There is not enough storage in the text unit output area to construct the text unit for the current value. Action: Increase the size of the output area, adjust SJVETUBP and SJVETUBL, and call VERIFY again with the same input.
04	4B3	Meaning: Program error. A subparameter or sublist element cannot be specified in quotation marks. SJVEQUOT is set on, but quotation marks are not allowed for the specified subparameter or sublist element. Action: Either set SJVEQUOT off or specify a value for which quotation marks are allowed. Message text: VALUE CANNOT BE SPECIFIED IN QUOTES
04	4B4	Meaning: Program error. The text unit output area is different than the text unit output area passed on the first call. SJVETUBP has a different value than on the first call, and SJVERSBS is set on. SJF cannot obtain the amount of contiguous storage necessary for the text unit pointer list and text units when more than one buffer is provided. Action: Check the value in SJVETUBP.
08	000	Meaning: Program error. The input parameter list, IEFSJVEP, is not valid. Action: Check to see if SJVEID, SJVEVERS, or SJVELEN is incorrect and not recognized by SJF.
0C	000	Meaning: System error. The system could not obtain storage for this request. Action: Inform your system programmer of this problem.
10	000	Meaning: System error. The ESTAE-type recovery routine failed. Action: Inform your system programmer of this problem.
14	000	Meaning: System error. SJF encountered a condition that caused an abnormal termination. Action: Check the input parameters, particularly any pointer fields, to determine if the input values are correct.
18	000	Meaning: System error. The service routines for SJFREQ are not available. Action: SJF did not initialize properly. Contact the appropriate IBM support personnel.

SJFREQ TERMINATE service

TERMINATE frees the environment established by an SJF service. TERMINATE performs no other function.

SJFREQ TERMINATE input parameters

IEFSJREP, IEFSJSMP, or IEFSJVEP. The field SJVESTOR must contain a pointer to the SJF environment to be freed.

Return and reason codes

Return codes appear in register 15. The hexadecimal return codes from the SJFREQ TERMINATE service are as follows.

Table 14. Return Codes from the SJFREQ TERMINATE Service	
Return Code	Meaning and Action
00	Meaning: TERMINATE processing completed successfully. Action: None
08	Meaning: Program error. The parameter list is not valid. Action: Check to see if SJVEID, SJVEVERS, or SJVELEN is incorrect and not recognized by SJF.
14	Meaning: Program or system error. An abnormal termination occurred. Action: Check the input parameters, particularly any pointer fields, to determine if the input values are correct.
18	Meaning: System error. The service routines for SJFREQ are not available. Action: SJF did not initialize properly. Contact the appropriate IBM support personnel.

Chapter 6. SMFEWTM — Write an SMF record

Description

You can use the SMFEWTM macro to write records to the SMF data set. This macro can be issued in any application program that is APF-authorized or in any exit routine that runs in supervisor state except for IEFU83, IEFU84, IEFU85, IEFU86, IEFU29, and IEFU29L.

For more information about using the SMFEWTM macro, see [SMFEWTM - Writing SMF records in z/OS MVS System Management Facilities \(SMF\)](#).

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	For BRANCH=YES, supervisor state, key 0; otherwise, supervisor state, APF-authorized, or system key.
Dispatchable unit mode:	Task or SRB. SRB callers require BRANCH=YES.
Cross-memory mode:	For MODE=XMEM, PASN \neq HASN \neq SASN; otherwise, PASN = HASN = SASN.
AMODE:	24- or 31-bit.
ASC mode:	Primary.
Interrupt status:	Enabled for I/O and external interrupts.
Locks:	For BRANCH=NO, no locks may be held. For BRANCH=YES, the local lock may be held but is not required.
Control parameters:	Must be in the primary address space.

Programming requirements

When you invoke the SMFEWTM macro, you must include the IEESMCA mapping macro, which maps the SMF control table (SMCA).

Restrictions

None.

Input register information

Before issuing the SMFEWTM macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter.

Output register information

When control returns to the caller, the contents of the general purpose registers (GPRs) are as follows:

Register Contents

0 - 1

Used as work registers by the system.

2 - 13

Unchanged.

14

Used as a work register by the system.

15


Return code.

Performance implications

None.

Syntax

The SMFEWTM macro is written as follows:

**Parameters**

The SMFEWTM parameters are as follows:

record-address

The symbolic address of the record to be written.

(r)

A register number (2 - 12) that contains the address of the record to be written.

BRANCH=NO**BRANCH=YES**

Specifies a branch entry (YES) or an SVC entry (NO) to the requested SMF writer routine. The default is BRANCH=NO.

For either BRANCH=YES or BRANCH=NO, before SMF writes the record to the SMF data set, the SMF record is given to installation exit IEFU86.

If you specify BRANCH=NO, before SMF writes the record to the SMF data set, the SMF record is given to installation exit IEFU83.

If you specify BRANCH=YES, before SMF writes the record to the SMF data set, the SMF record is given to installation exit IEFU84, or IEFU85 if MODE=XMEM. To use BRANCH=YES, the caller must be in supervisor state, have a protection key of zero, and set register 13 to point to a standard 72-byte save area.

Note: If you change from using the SMFWTM macro to write SMF records to using the SMFEWTM macro with BRANCH=YES, the SMF records are given to installation exit IEFU84 (instead of IEFU83), or IEFU85 if MODE=XMEM.

SUBSYS=name**SUBSYS=(reg)**

Specifies the name (or address in register 2 - 12) of the 4-byte field that contains the subsystem name. The macro looks for the subsystem name in SMFPRMxx and uses the options for that subsystem to determine whether to write the record. The subsystem name must be left-justified and padded with blanks. If you specify a register, it must be enclosed in parentheses. If the subsystem

name is not found, the macro uses the options specified for the entire system on the SYS option in SMFPRMxx to determine whether to write the record.

If you do not specify SUBSYS, the macro uses the subsystem name for the current address space (for instance, TSO for TSO/E users, STC for started tasks, ASCH for APPC/MVS transactions programs), or the name of the job entry subsystem (JES2 or JES3) for batch jobs. If the defaulted subsystem name is not found, the macro uses the options specified for the entire system on the SYS option in SMFPRMxx to determine whether to write the record.

WRKAREA=addr

WRKAREA=(reg)

Specifies the *address* or *register* (2 - 12) that contains the address of a 5-word work area that you must supply for use by SMF. If you specify a register, it must be enclosed in parentheses. You must specify WRKAREA when you specify MODE=XMEM.

MODE=XMEM

Specifies that the caller is entered in cross-memory mode (the primary address space is not the home address space). The caller must be in primary ASC mode. If you specify MODE=XMEM, you must specify BRANCH=YES and WRKAREA.

ABEND codes

The SMFEWTM macro can issue the following ABEND codes. For detailed information, see [System completion codes in z/OS MVS System Codes](#).

253
653

Return codes

When the SMFEWTM macro returns control to the caller, register 15 contains one of the following return codes.

Table 15. Return codes for the SMFEWTM macro	
Return code	Meaning
0 (X'00')	The record was written successfully.
8 (X'08')	The record was not written because the length specified in the RDW was less than 18 bytes, or an SMF record exit changed the length in the RDW to be less than 18 bytes.
16 (X'10')	The record was not written because SMF is not active or has ended abnormally.
20 (X'14')	The record was not written because the installation-written IEFU83, IEFU84, IEFU85, or IEFU86 exit routine suppressed the record.
24 (X'18')	The record was not written because the data was lost.
36 (X'24')	The record was not written because the specified record type is not currently being recorded.
40 (X'28')	The record was not written because a buffer shortage caused the data to be lost.
44 (X'2C')	The record was not written because SMF could not establish recovery.
48 (X'30')	The caller was not in primary ASC mode, or an incorrect ASID was encountered.
52 (X'34')	SMF cannot write the record because of an SMF record flooding filter.

Table 15. Return codes for the SMFEWTM macro (continued)

Return code	Meaning
56 (X'38')	The record was not written because it contains a malformed record header for an extended record type. See Generating records with extended headers in <i>z/OS MVS System Management Facilities (SMF)</i> for the rules for generating a record with an extended header.
60 (X'3C')	The record was not written because it was modified by an installation exit (IEFU83, IEFU84, IEFU85, or IEFU86) to contain a malformed record header for an extended record type. See Generating records with extended headers in <i>z/OS MVS System Management Facilities (SMF)</i> for the rules for generating a record with an extended header.

Chapter 7. SMFWTM — Write an SMF record

Description

You can use the SMFWTM macro to write records to the SMF data set or log stream. This macro can be used in any application program that is APF-authorized or in any exit routine that runs in supervisor state except for IEFU83, IEFU84, IEFU85, IEFU86, IEFU29, and IEFU29L. All SMF records are given to installation exits before they are written to the SMF data set or log stream. If you use SMFWTM, installation exits IEFU86 and IEFU83 are invoked.

For more information about using the SMFWTM macro, see [SMFWTM — Writing SMF records](#) in *z/OS MVS System Management Facilities (SMF)*.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state, APF-authorized, or system key.
Dispatchable unit mode:	Task.
Cross-memory mode:	PASN = HASN = SASN.
AMODE:	24- or 31-bit.
ASC mode:	Primary.
Interrupt status:	Enabled for I/O and external interrupts.
Locks:	Local lock may be held but is not required.
Control parameters:	Must be in the primary address space.

Programming requirements

None.

Restrictions

None.

Input register information

Before issuing the SMFWTM macro, the caller does not have to place any information into any register except for the register specified in the parameter list that contains the address of the SMF record to be written.

Output register information

When control returns to the caller, the contents of the general purpose registers (GPRs) are as follows:

Register Contents

0 - 1

Used as work registers by the system.

2 - 13

Unchanged.


- 14 Used as a work register by the system.
- 15 Return code.

Performance implications

None.

Syntax

The SMFWTM macro is written as follows:



Parameters

The SMFWTM parameters are as follows:

record-address
The symbolic address of the record to be written.

(r)
A register containing the address of the record to be written. The value for *r* can be either the absolute register number or a symbol for the register. In either case, you must code the parentheses, such as (2) or (REG2).

ABEND codes

The SMFWTM macro can issue the following ABEND codes. For detailed information, see [System completion codes](#) in *z/OS MVS System Codes*.

253
653

Return codes

When the SMFWTM macro returns control to the caller, register 15 contains one of the following return codes.

Table 16. Return codes for the SMFWTM macro	
Return code	Meaning
0 (X'00')	The record was written successfully.
8 (X'08')	The record was not written because the length specified in the RDW was less than 18 bytes, or an SMF record exit changed the length in the RDW to be less than 18 bytes.
16 (X'10')	The record was not written because SMF is not active or has ended abnormally.
20 (X'14')	The record was not written because the installation-written IEFU83 or IEFU86 exit routine suppressed the record.
24 (X'18')	The record was not written because the data was lost.
36 (X'24')	The record was not written because the specified record type is not currently being recorded.

Table 16. Return codes for the SMFWTM macro (continued)

Return code	Meaning
40 (X'28')	The record was not written because a buffer shortage caused the data to be lost.
44 (X'2C')	The record was not written because SMF could not establish recovery.
52 (X'34')	SMF cannot write the record because of an SMF record flooding filter.
56 (X'38')	The record was not written because it contains a malformed record header for an extended record type. See Generating records with extended headers in z/OS MVS System Management Facilities (SMF) for the rules for generating a record with an extended header.
60 (X'3C')	The record was not written because it was modified by an installation exit (IEFU83, IEFU84, IEFU85, or IEFU86) to contain a malformed record header for an extended record type. See Generating records with extended headers in z/OS MVS System Management Facilities (SMF) for the rules for generating a record with an extended header.

Chapter 8. SPIE — Specify program interruption exit

Description

Note: IBM recommends that you use the ESPIE macro rather than SPIE. Callers in 31-bit addressing mode must use the ESPIE macro, which performs the same function as the SPIE macro for callers in both 24-bit and 31-bit addressing mode.

The SPIE macro specifies the address of an interruption exit routine and the program interruption types that are to cause the exit routine to get control.

Each succeeding SPIE macro invocation completely overrides any previous SPIE macro specifications for the task. The specified exit routine is given control in the key of the TCB when one of the specified program interruptions occurs in any problem program of the task. When a SPIE exit routine issues the SPIE macro, the system resets (zeros) the program interruption element (PIE). Thus, a SPIE exit routine should save any required PIE data before issuing a SPIE. If a caller issues an ESPIE macro from within a SPIE exit routine, it has no effect on the contents of the PIE. However, if an ESPIE macro deletes the last SPIE/ESPIE environment, the PIE is freed and the SPIE exit cannot retry.

If the current SPIE environment is canceled during SPIE exit routine processing, the control program will not return to the interrupted program when the SPIE program terminates. Therefore, if the SPIE exit routine wishes to retry within the interrupted program, a SPIE cancel should not be issued within the SPIE exit routine.

The SPIE macro can be issued by any problem program being executed in the performance of the task. The control program automatically deletes the SPIE exit routine when the request block (RB) that issued the SPIE macro terminates.

A PICA (program interruption control area) is created as part of the expansion of SPIE. The PICA contains the exit routine's address and a code indicating the interruption types specified in SPIE.

For more information on the SPIE macro, see the information on program interruption services in *z/OS MVS Programming: Assembler Services Guide* and *z/OS MVS Programming: Authorized Assembler Services Guide*.

The following description of the SPIE macro also appears in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	To issue SPIE without encountering an abnormal end, callers must be in problem state, with a PSW key value that is equal to the TCB assigned key.
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	Must be in the primary address space

Programming requirements

The caller must include the following mapping macros:

- IHAPIE
- IHAPICA

Restrictions

None.

Input register information

Before issuing the SPIE macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain the following information:

Register

Contents

0

Used as a work register by the system.

1

If a SPIE environment is already active when you issue the SPIE macro, the SPIE service routine returns the address of the previous PICA in register 1. You can use this PICA to restore the previously active SPIE environment. However, if an ESPIE environment is active when you issue the SPIE macro, the SPIE service returns the address, in register 1, of a PICA in which the first word contains binary zeros. You cannot modify the contents of this PICA, and it contains no useful information except to restore the previous SPIE or ESPIE environment. If no previous SPIE/ESPIE environment is active, the service routine returns a zero in register 1.

2-13

Unchanged.

14-15

Used as a work register by the system.

When control returns to the caller, the access registers (ARs) contain:

Register

Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

Syntax

The standard form of the SPIE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SPIE.
SPIE	
␣	One or more blanks must follow SPIE.
<i>exit addr</i>	<i>exit addr</i> : A-type address, or register (2) - (12).
<i>,(interrupts)</i>	<i>interrupts</i> : Decimal numbers 1 - 15, expressed as <ul style="list-style-type: none"> • single values: (2,3,4,7,8,9,10) • ranges of values: ((2,4),(7,10)) • combinations: (2,3,4,(7,10))

Parameters

The parameters are explained as follows:

exit addr

Specifies the address of the exit routine to be given control when a specific program interruption occurs. The exit routine receives control in 24-bit addressing mode.

,(interrupts)

Indicates the type of interruption for which the exit routine is to be given control. The interruption types are as follows:

Number

Interruption Type

- | | |
|----------|----------------------|
| 1 | Operation |
| 2 | Privileged operation |
| 3 | Execute |
| 4 | Protection |
| 5 | Addressing |
| 6 | Specification |

SPIE macro

7	Data
8	Fixed-point overflow (maskable)
9	Fixed-point divide
10	Decimal overflow (maskable)
11	Decimal divide
12	Exponent overflow
13	Exponent underflow (maskable)
14	Significance (maskable)
15	Floating-point divide

Note:

1. If an exit address is zero or no parameters are specified, the current SPIE and any previously active ESPIE environments are canceled.
2. If a program interruption type is maskable, the corresponding program mask bit in the PSW (program status word) is set to 1 when specified and to 0 when not specified. Interruption types that are not maskable and not specified above are handled by the system, which forces an abend with the program check as the completion code. If an ESTAE-type recovery routine is also active, the SDWA indicates a system-forced abnormal termination. The registers at the time of the error are those of the system.
3. If you are using vector instructions and an interruption of 8, 12, 13, 14, or 15 occurs, your recovery routine can check the exception extension code (the first byte of the two-byte interruption code in the EPIE or PIE) to determine whether the exception was a vector or scalar type of exception.

ABEND codes

The SPIE macro might return the following abend codes:

- X'10E'
- X'30E'
- X'46D'

See [z/OS MVS System Codes](#) for explanations and programmer responses.

Return and reason codes

None.

Example

Give control to an exit routine for interruption 4. DOITSPIE is the address of the SPIE exit routine.

```
SPIE DOITSPIE, (4)
```

SPIE - List form

Use the list form of the SPIE macro to construct a control program parameter list in the form of a program interruption control area.

Syntax

The list form of the SPIE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SPIE.
SPIE	
␣	One or more blanks must follow SPIE.
<i>exit addr</i>	<i>exit addr</i> : A-type address.
<i>, (interrupts)</i>	<i>interrupts</i> : Decimal numbers 1 - 15, expressed as: <ul style="list-style-type: none"> • single values: (2,3,4,7,8,9,10) • ranges of values: ((2,4),(7,10)) • combinations: (2,3,4,(7,10))
<i>,MF=L</i>	

Parameters

The parameters are explained under the standard form of the SPIE macro, with the following exception:

,MF=L

Specifies the list form of the SPIE macro.

SPIE - Execute form

A remote control program parameter list is used in, and can be modified by, the execute form of the SPIE macro. The PICA (program interruptions control area) can be generated by the list form of SPIE, or you can use the address of the PICA returned in register 1 following a previous SPIE macro. If this macro is being issued to reestablish a previous SPIE environment, code only the MF parameter.

The address of the remote control program parameter list associated with any previous SPIE environment is returned by the SPIE macro.

Syntax

The execute form of the SPIE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SPIE.
SPIE	
␣	One or more blanks must follow SPIE.
<i>exit addr</i>	<i>exit addr</i> : RX-type address, or register (2) - (12).
<i>, (interrupts)</i>	<i>interrupts</i> : Decimal numbers 1 - 15, expressed as: <ul style="list-style-type: none"> • single values: (2,3,4,7,8,9,10) • ranges of values: ((2,4),(7,10)) • combinations: (2,3,4,(7,10))
<i>,MF=(E,ctrl addr)</i>	<i>ctrl addr</i> : RX-type address, or register (1) or (2) - (12).

Parameters

The parameters are explained under the standard form of the SPIE macro, with the following exception:

,MF=(E,ctrl,addr)

Specifies the execute form of the SPIE macro using a remote control program parameter list.

Note: If SPIE is coded with a zero as the control address, the SPIE environment is canceled.

Chapter 9. SPOST — Synchronize POST

Description

The SPOST macro is used in a cross memory post environment to ensure that all outstanding cross memory post requests to the current address space have completed. SPOST resolves a synchronization problem that arises when it becomes necessary to free an ECB that is a potential target for a cross memory post request. Before issuing SPOST, you must stop any new posts from being initiated.

For explanation of the parameters in a cross memory post request, see the POST macro.

Environment

These are the requirements for the caller:

Environmental factor	Requirement
Minimum authorization:	Supervisor state or PSW key 0-7 or APF authorized
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	None

Programming requirements

The caller must include the CVT mapping macro.

Restrictions

None.

Input register information

Before issuing the SPOST macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter or using it as a base register.

Output register information

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

SPOST macro

When control returns to the caller, the ARs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The SPOST macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SPOST.
SPOST	
␣	One or more blanks must follow SPOST.

Note: SPOST contains no optional or required parameters.

ABEND codes

- 17B
- 27B
- 47B

See [z/OS MVS System Codes](#) for an explanation and programmer responses for this code.

Return and reason codes

None.

Example

Execute the SPOST macro with a comment.

```
SPOST          ,ISSUE SPOST
```

Chapter 10. SRBSTAT — Save, restore, or modify SRB status

Description

Note: IBM recommends that you use the following macros rather than SRBSTAT:

- SUSPEND - Suspend Execution of an SRB
- RESUME - Resume or Purge a Suspended SRB

The SRBSTAT macro allows the caller to save, restore, and modify the status of an SRB in a caller-supplied save area. Control returns from the SRBSTAT macro in primary ASC mode.

Environment

These are the requirements for the caller:

Environmental factor	Requirement
Minimum authorization:	Supervisor state, key 0
Dispatchable unit mode:	SRB for SAVE or RESTORE options. SRB or TASK for MODIFY option.
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	Must be in primary address space

Programming requirements

None.

Restrictions

The caller of SRBSTAT RESTORE must not change PASID before the request; the RESTORE will restore the PASID saved by the earlier SAVE request.

Input register information

Before issuing the SRBSTAT macro, the caller must ensure that general purpose register 13 points to a standard 72-byte save area addressable in primary mode.

Output register information

When control returns to the caller, the GPRs contain the following.

When SAVE is specified:

Register
Contents

SRBSTAT macro

0

Unchanged

1

Used as a work register by the system

2-14

Unchanged

15

Return code

When RESTORE is specified:

Register

Contents

0-13

Restored

14

Unchanged

15

Return code

When MODIFY is specified:

Register

Contents

0-14

Unchanged

15

Return code

When control returns to the caller, the ARs contain:

Register

Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The SRBSTAT macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SRBSTAT.

Syntax	Description
SRBSTAT	
b	One or more blanks must follow SRBSTAT.
SAVE	
RESTORE	
MODIFY	
,STSV= <i>stsv addr</i>	<i>stsv addr</i> : RX-type address or register (1) - (12), register (1) preferred.
,STSV=0	
,NEWFRR= <i>addr</i>	<i>addr</i> : RX-type address or register (0) or (2) - (12), register (0) preferred.
,PRGAT= <i>pat addr</i>	<i>pat addr</i> : RX-type address or register (2) - (12), register (2) preferred.

Parameters

The parameters are explained as follows:

SAVE

RESTORE

MODIFY

Specifies whether a save, restore, or modify operation is requested. For SAVE or RESTORE, status that is saved or restored includes:

- General, floating point, and vector registers
- Control registers 3 and 4
- CPU affinity mask
- Related ASID/TCB
- Timing information
- FRR stack
- PCLINK stack header

If SAVE is specified, only caller's registers 1 and 15 are destroyed. Register 1 is used to hold an FRR parameter area address if NEWFRR is also specified and register 15 is used for a return code. The PCLINK stack header is saved and zeroed.

If RESTORE is specified, registers 0-13 are restored. The contents of register 14 are the same as when RESTORE was entered. The current PCLINK stack header must be zero; the saved one is restored.

If MODIFY is specified, registers 0-14 are unchanged and register 15 contains a return code.

Note:

1. On entry to RESTORE, the PCLINK stack header must be zero.
2. RESTORE cannot be used in an FRR.

3. RESTORE returns to its caller and not to the caller of SAVE.
4. SRBSTAT does not save and restore access registers, extended authorization index (EAX) value, and linkage stack and access list status.
5. If vector status is saved, it can be restored only to an SRB that has previously issued IEAFP START.

,STSV=stsv addr

Specifies the address of the save area to be used for the SAVE, RESTORE, or MODIFY operation. The size of this save area is contained in field SVTSSTSV of the SVT control block. The savearea can be in private pageable storage, but it must be addressable from the home address space and it must begin on a doubleword boundary. For RESTORE or MODIFY, the savearea must contain valid status.

,STSV=0

Specifies that the current status is to be modified. This parameter is valid only with MODIFY.

For MODIFY, an existing SRB status savearea or the current status is modified. Only the purge ASID/TCB information can be modified. All registers are saved and restored except register 15, which contains a return code.

Hexadecimal Code	Meaning
00	The modify function was successfully completed.

,NEWFRR=addr

Specifies the address of an FRR established with MODE=FULLXM. For SAVE, the address of the FRR parameter area is returned to the caller in register 1. The first word of the parameter area contains the address of the SRB status savearea being used.

For RESTORE, the FRR address is used only if the saved status cannot be reinstated on the current processor. An SRB with the FRR option is scheduled specifying this FRR.

For MODIFY, this parameter is invalid.

,PRGAT=pat addr

Specifies the address of a 6-byte area of storage, currently addressable in the primary address space, that contains the new purge ASID/TCB. Bytes 1 and 2 contain the ASID; bytes 3-6 contain the TCB address. This parameter is required with MODIFY but is invalid with SAVE or RESTORE.

ABEND codes

- 05E

See [z/OS MVS System Codes](#) for an explanation and programmer responses for this code.

Return and reason codes

None.

Chapter 11. SRBTIMER — Establish time limit for system service

Description

The SRBTIMER macro is used to establish a time limit for a system service running in SRB mode. Time accumulates while the service is running; when the time limit expires, the service abends with a system completion code of X'05B'. The service can retry following the 05B ABEND.

The caller can cancel an established time limit by reissuing the macro and specifying a time limit of zero. The caller can also override the established time limit with a subsequent SRBTIMER macro.

Environment

These are the requirements for the caller:

Environmental factor	Requirement
Minimum authorization:	Supervisor state and key 0
Dispatchable unit mode:	SRB
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No requirement
Control parameters:	Must be in primary address space

Programming requirements

None.

Restrictions

None.

Input register information

Before issuing the SRBTIMER macro, the caller must ensure that general purpose register 13 points to a standard 72-byte save area addressable in primary mode.

Output register information

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the ARs contain:

Register**Contents****0-1**

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The SRBTIMER macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede SRBTIMER.
SRBTIMER	
b	One or more blanks must follow SRBTIMER.
LIMIT= <i>stor addr</i>	<i>stor addr</i> : RX-type address or register (0) or (2) - (12).
,ERRET= <i>err rtn addr</i>	<i>err rtn addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

LIMIT=*stor addr*

Specifies the virtual storage address of a doubleword field on a doubleword boundary that contains the time limit. The time limit is in the form of a signed 64-bit binary number and must be positive in order for time to elapse. A negative number causes immediate expiration of the time limit. Bit 51 of the binary number is approximately equivalent to one microsecond. If you specify a value greater than 208 days, the control program changes the value to 208 days. The resolution of the timer is model dependent. See *Principles of Operation* for details concerning the timer facility.

,ERRET=err rtn addr

Specifies the address of the routine to be given control when the SRBTIMER function encounters damaged clocks.

ABEND codes

None.

Return codes

When SRBTIMER macro returns control to your program, GPR 15 contains a hexadecimal return code.

Table 17. Return Codes for the SRBTIMER Macro	
Return Code	Meaning and Action
00	Meaning: The time limit was successfully established. Action: None.
10	Meaning: The issuer is not in SRB mode. No timing is performed. Action: Ensure that the requesting program is running in SRB mode, or use STIMER or STIMERM instead.

Chapter 12. STATUS – Control dispatchability or process-must-complete state

Description

The STATUS macro with the START or STOP option starts or stops a unit or units of work. The STATUS macro with the SET or RESET option places a program in process-must-complete mode or ends process-must-complete mode. Process-must-complete mode postpones delays from the following:

- Asynchronous exits
- Asynchronous abends (CALLRTM TYPE=ABTERM for tasks or CALLRTM TYPE=SRBTERM for preemptable SRBs)
- Status stops (by issuing the STATUS macro with the STOP option)
- Timer exits
- Dumping
- Swapping
- Attention exits

Process-must-complete mode prevents a CANCEL command from stopping a program already running but it does not postpone external interrupts or interrupts from I/O.

The description of the STATUS macro has two parts: the START/STOP option and the SET/RESET option. *z/OS MVS Programming: Assembler Services Reference IAR-XCT* describes the STATUS macro START and STOP options with the exception of the SRB and ASID parameters. These parameters, which are available only to supervisor state and key 0 callers, allow the caller to manipulate the dispatchability status or SRBs.

See *z/OS MVS Programming: Authorized Assembler Services Guide* for more information on how to use the STATUS macro SET and RESET options and *z/OS MVS Programming: Assembler Services Guide* for more information on how to use the STATUS macro START and STOP options.

Environment

The requirements for the caller issuing STATUS with the START or STOP parameters are:

Environmental factor	Requirement
Minimum authorization:	Problem state or supervisor state, with any PSW key. For SRB and ASID parameters, supervisor state and PSW key 0.
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN or PASN¬=HASN¬=SASN
AMODE:	31-bit
ASC mode:	Primary or access register (AR)
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	No requirements

The requirements for the caller issuing STATUS with the SET or RESET parameters are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state, with PSW key 0.
Dispatchable unit mode:	Task or preemptable SRB.
Cross memory mode:	PASN=HASN=SASN or PASN¬=HASN¬=SASN
AMODE:	31-bit
ASC mode:	<ul style="list-style-type: none"> • For task mode: Primary or access register (AR). • For SRB mode: Primary.
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	No locks required. The Local, CMS, and/or CPU locks may be held.
Control parameters:	No requirements

Programming requirements

None.

Restrictions

Except for the TCB, all input parameters to this macro can reside in storage above 16 megabytes.

While in process-must-complete mode, a task must not:

- Issue STATUS STOP,SRB or STATUS START,SRB
- Request the LOCAL lock unconditionally
- Issue an SVC or invoke services that issue SVCs
- Issue the WAIT macro or invoke services that issue WAITs

While in process-must-complete mode, a preemptable SRB must not:

- Request the LOCAL lock unconditionally
- Pause
- Suspend

These restrictions also apply to any routine invoked by a program in process-must-complete mode.

Process-must-complete mode is not preserved across a retry from an ESTAE-type routine. However, it is preserved across a retry from an FRR, unless the FRR is an EUT FRR and the environment at the time of the abend was Enabled, Unlocked, and in Task mode.

For the START or STOP parameters, the caller cannot have an EUT FRR established.

Register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the access registers (ARs) contain:

Register**Contents****0-1**

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

Using STATUS will degrade performance of the calling program's address space while STATUS runs.

Remaining in process-must-complete mode for an extended period of time will degrade the performance of other programs waiting to use global resources that the program in this mode holds.

START/STOP options

Syntax

The START/STOP options of the STATUS macro are written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede STATUS.
STATUS	
b	One or more blanks must follow STATUS.
START	
STOP	
,TCB= <i>tcb addr</i>	<i>tcb addr</i> : RX-type address or address in register (2) - (12), or 0.
,SRB	<i>ASID addr</i> : RX-type address or address in register (2) - (12).
,SRB, ASID= <i>ASID addr</i>	Note: ASID may only be specified with START.

Syntax	Description
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.

Parameters

The parameters are described as follows:

START STOP

Specifies that the task identified in the TCB parameter is to be stopped (STOP) or started (START). If you omit the TCB parameter, all subtasks of the originating task are stopped or started.

Note: The STOP parameter does not ensure that the subtask is stopped when control returns to the issuer. A subtask can have a “stop deferred” condition that would cause that particular subtask to remain dispatchable until stops are no longer deferred. In an MP environment, it would be possible to have a task issue the STATUS macro with the STOP parameter and resume processing while the subtask (for which the STOP was issued) is redispached to another processor.

,TCB=*tcb addr*

,SRB

,SRB,ASID=*ASID addr*

Specifies the status of the stop/start function:

TCB

Specifies the address of a fullword on a fullword boundary containing the address of the TCB that is to have its START/STOP count adjusted.

Note: The TCB resides in storage below 16 megabytes.

SRB

Specifies that the STOP and START functions affect the dispatchability of system-level SRBs; all tasks in the address space except the caller's are also set or reset nondispatchable. For START, the *ASID addr* specifies the address of a halfword containing the address space identifier. If ASID is not specified, the action is taken against the caller's address space.

,RELATED=*value*

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user and may be any valid coding values.

Return codes

When control returns to the caller, register 15 contains one of the following hexadecimal return codes:

Table 18. Return Codes for the STATUS Macro	
Return Code	Meaning and Action
00	Meaning: Processing completed successfully. Action: None required.
04	Meaning: Program error. START/STOP request failed. The task you specified is not a subtask of the calling program's task. Action: Ensure that the task you specify on the TCB parameter is a subtask of the calling program.

SET/RESET option

Syntax

The SET/RESET option of the STATUS macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede STATUS.
STATUS	
␣	One or more blanks must follow STATUS.
SET,MC,PROCESS	
RESET,MC,PROCESS	

Parameters

The parameters are explained as follows:

SET,MC,PROCESS

RESET,MC,PROCESS

SET,MC,PROCESS places the program that invokes the macro in process-must-complete mode.

RESET,MC,PROCESS ends process-must-complete mode.

Return codes

When control returns to the caller, register 15 contains one of the following hexadecimal return codes:

Table 19. Return Codes for the SET/RESET Option	
Return Code	Meaning and Action
00	Meaning: Processing completed successfully. Action: None required.
04	Meaning: Program error. You issued STATUS SET,MC,PROCESS but it had already been issued. Action: Do not issue STATUS SET,MC,PROCESS again until you have issued STATUS RESET,MC,PROCESS.
08	Meaning: Program error. You issued STATUS RESET,MC,PROCESS but had never issued STATUS SET,MC,PROCESS. Action: Issue STATUS SET,MC,PROCESS before issuing STATUS RESET,MC,PROCESS.
0C	Meaning: Program error. You issued STATUS SET,MC,PROCESS while running under a non-preemptable SRB. Action: Avoid issuing STATUS SET,MC,PROCESS from a non-preemptable SRB.

Table 19. Return Codes for the SET/RESET Option (continued)

Return Code	Meaning and Action
10	<p>Meaning: Program error. You issued STATUS RESET,MC,PROCESS while running under a non-preemptable SRB.</p> <p>Action: Avoid issuing STATUS SET,MC,PROCESS from a non-preemptable SRB.</p>

Example

Cause a program process to enter, then end, process-must-complete mode.

```

* Chaining for a nonreenterable program, but note that STATUS SET,MC,
* PROCESS and STATUS RESET,MC,PROCESS do not require that a savearea
* be provided.

SETPMC   CSECT
SETPMC   AMODE 31
SETPMC   RMODE ANY
        STM    14,12,12(13)    SAVE REGISTERS
        LR     12,15           GET ENTRY POINT ADDRESS
        USING  SETPMC,12       ESTABLISH ADDRESSABILITY
        ST     13,SAVEAREA+4   SAVE REGISTER 13
        LR     2,13           GET CALLER SAVEAREA ADDRESS
        LA     13,SAVEAREA     SET UP OUR SAVEAREA ADDRESS
        ST     13,8(2)        SAVE SAVEAREA ADDRESS IN CALLER
                                SAVEAREA
        MODESET MODE=SUP,KEY=ZERO GET INTO SUPERVISOR STATE, KEY 0
        STATUS SET,MC,PROCESS  SET PMC MODE
        LTR    15,15          CHECK RETURN CODE
        BNZ    BADSET         NOT SUCCESSFUL, GO HANDLE...

*
* Perform processing that requires process-must-complete mode...
* Note: This processing must not request the local lock and
* must not issue any SVCs or issue a WAIT.
*
*
RESET    STATUS RESET,MC,PROCESS  RESET PMC MODE
        LTR     15,15           PMC MODE HAD ALREADY BEEN RESET,
                                ALREADY OUT OF PMC MODE
        BNZ     BADRESET        NOT SUCCESSFUL, GO HANDLE...

*
EXIT     DS      0H
        MODESET MODE=PROB,KEY=NZERO GET OUT OF SUPERVISOR STATE, KEY 0
        L       13,4(13)       RESTORE REGISTER 13
        L       14,12(13)     RESTORE REGISTER 14
        LM      0,12,20(13)    RESTORE REGISTERS 0 THRU 12
        SLR     15,15         SET RETURN CODE 0 IN REGISTER 15
        BR      14           RETURN TO THE CALLER
BADSET   DS      0H
*
* Perform appropriate processing for nonzero return code from
* STATUS SET,MC,PROCESS.
*
        B       EXIT
BADRESET DS      0H
*
* Perform appropriate processing for nonzero return code from
* STATUS RESET,MC,PROCESS.
*
        B       EXIT
SAVEAREA DC      18F'0'        18-WORD SAVEAREA
        END    SETPMC

```


Chapter 13. STORAGE — Obtain and release storage

Description

The STORAGE macro requests that the system obtain or release an area of virtual storage in the primary address space (by default), or in the address space defined through the ALET parameter. The two functions of the macro are:

- STORAGE OBTAIN, which requests an area of virtual storage.
- STORAGE RELEASE, which releases an area of virtual storage.

The STORAGE macro is also described in *z/OS MVS Programming: Assembler Services Reference IAR-XCT*, with the exception of the ALET, TCBADDR, and OWNER parameters.

If you use STORAGE OBTAIN to request real storage backing above 2 gigabytes, but your system does not support 64-bit storage, your request will be treated as a request for backing above 16 megabytes, even on earlier releases of z/OS that do not support backing above 2 gigabytes. However, boundary requirements indicated by the CONTBDY and STARTBDY parameters will be ignored by earlier releases of z/OS.

Environment

The requirements for the caller are:

Environmental factor

Requirement

Minimum authorization:

For subpools 0-127: problem state and PSW key 8-15.

For subpools 131 and 132, one or more of the following:

- Supervisor state
- PSW key 0-7
- PSW key mask (PKM) that allows the calling program to switch its PSW key to match the key of the storage to be obtained or released.
- APF-authorization.

For the ALET parameter and the TCBADDR parameter, either of the following:

- Supervisor state
- PSW key 0-7

For LINKAGE=SYSTEM or LINKAGE=SVC: for all other subpools, one or more of the following:

- Supervisor state
- PSW key 0-7
- APF-authorization.

For LINKAGE=BRANCH or LINKAGE=GLOBALBRANCH: Supervisor state and PSW key 0.

To issue a subpool release for subpool 0: PSW key 0.

Dispatchable unit mode:

For LINKAGE=SVC: Task

For LINKAGE=SYSTEM, LINKAGE=BRANCH, or LINKAGE=GLOBALBRANCH: Task or SRB

Environmental factor**Requirement****Cross memory mode:**

For LINKAGE=SVC: PASN=HASN=SASN

For LINKAGE=SYSTEM, LINKAGE=BRANCH, or
LINKAGE=GLOBALBRANCH: Any PASN, any HASN, any SASN

AMODE:

For LINKAGE=SYSTEM or LINKAGE=SVC: 24- or 31- or 64-bit

For LINKAGE=BRANCH or LINKAGE=GLOBALBRANCH: 24- or 31-bit.

If in AMODE 64, code SYSSTATE AMODE64=YES before invoking this macro.

RMODE:

For LINKAGE=SVC and LINKAGE=SYSTEM, includes 64-bit

ASC mode:

For LINKAGE=SYSTEM, LINKAGE=BRANCH, or
LINKAGE=GLOBALBRANCH: Primary or access register (AR).

For LINKAGE=SVC: Primary

If in AR mode, code SYSSTATE ASCENV=AR before invoking this macro.

Interrupt status:

For LINKAGE=SYSTEM: Enabled for I/O and external interrupts if obtaining or releasing private storage. Enabled or disabled for I/O and external interrupts if obtaining or releasing common storage.

For LINKAGE=SVC or LINKAGE=BRANCH: Enabled for I/O and external interrupts.

For LINKAGE=GLOBALBRANCH: Disabled for I/O and external interrupts.

Locks:

- For LINKAGE=SYSTEM:
 - No requirement.
 - You may hold the local lock for the target address space.
 - If you hold the local lock, you may also hold the CMS lock.
 - You may hold the CPU lock when obtaining or releasing common storage.
- For LINKAGE=SVC: No locks may be held.
- For LINKAGE=BRANCH: Your program must hold the local lock for the currently addressable address space. When running in cross-memory mode, this is the CML lock for that address space. The currently addressable address space must be the address space from which the storage is to be obtained.
- For LINKAGE=GLOBALBRANCH: Your program must be in an MVS-recognized state of disablement, which can be attained by obtaining the CPU lock.

Control parameters:

No requirement.

Programming requirements

None.

Restrictions

None.

Register information

Register usage varies depending on the type of STORAGE request. For specific information, see the descriptions of STORAGE OBTAIN and STORAGE RELEASE.

Performance implications

None.

STORAGE OBTAIN

The STORAGE macro with the OBTAIN parameter requests that the system allocate an area of virtual storage to the specified task. The length you specify must not exceed the length available. The length available depends on how much storage has already been allocated and, for subpools 0 - 127, 129-132, 240, and 250-252, the region size. For some subpools, the system releases the storage when the owning task terminates. For other subpools, you must issue STORAGE RELEASE or FREEMAIN to release them. Before obtaining storage, be sure to read “Selecting the Right Subpool for Your Virtual Storage Request” in *z/OS MVS Programming: Authorized Assembler Services Guide*.

Note:

1. When you obtain storage, the system clears the requested storage to zeros if you obtain either:
 - 8192 bytes or more from a pageable, private storage subpool and PAGEFRAMESIZE1M is not specified on the LOC keyword.
 - 4096 bytes or more from a pageable, private storage subpool, with BNDRY=PAGE or STARTBDY=12 specified and PAGEFRAMESIZE1M is not specified on the LOC keyword.

In all other cases, you must not assume that the storage is cleared to zeros.

The caller can specify CHECKZERO=YES to detect these and other cases where the system clears the requested storage to zeros.

2. Do not allocate key 8 or key 9 storage in the common area because it can be read or written by any program in any address space.

Input register information for LINKAGE=SYSTEM

Before issuing the STORAGE macro with the OBTAIN parameter, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information for LINKAGE=SYSTEM

When control returns to the caller, the GPRs contain:

Register Contents

0

For a successful request in which maximum and minimum lengths were specified, contains the length of the storage obtained. Otherwise, used as a work register by the system.

1

The address of the allocated storage when STORAGE OBTAIN is successful; otherwise, used as a work register by the system.

Note: A successful STORAGE OBTAIN will return a 64-bit pointer to the obtained area (bits 0-32 will be zero).

2-13

Unchanged.

STORAGE macro

14

Used as a work register by the system.

15

Contains the return code.

When control returns to the caller, the access registers (ARs) contain:

Register

Contents

0

Used as a work register by the system.

1

The ALET value if you specified the ALET parameter and the STORAGE OBTAIN is successful.

0 if you did not specify the ALET parameter and the STORAGE OBTAIN is successful.

Otherwise, used as a work register by the system.

2-13

Unchanged.

14-15

Used as work registers by the system.

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the service returns control.

Input register information for LINKAGE=SVC

Before issuing the STORAGE macro with LINKAGE=SVC, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information for LINKAGE=SVC

When control returns to the caller the GPRs contain:

Register

Contents

0

For a successful request, contains the length of the storage obtained. Otherwise, used as a work register by the system.

1

The address of the allocated storage when STORAGE is successful; otherwise, used as a work register by the system.

Note: A successful STORAGE OBTAIN will return a 64-bit pointer to the obtained area (bits 0-32 will be zero).

2-13

Unchanged.

14

Used as a work register by the system.

15

Contains the return code.

When control returns to the caller, the access registers (ARs) contain:

Register

Contents

0-1

Used as work registers by the system.

2-13

Unchanged.

14-15

Used as work registers by the system.

Input register information for LINKAGE=BRANCH

Before issuing the STORAGE macro with LINKAGE=BRANCH, the caller must ensure that the following GPRs contain the specified information:

Register

Contents

4

The address of the input TCB, if you are obtaining private storage.

If your program is not running in cross-memory mode, setting GPR 4 to 0 identifies the input TCB as the TCB of the current task.

If your program is running in cross-memory mode, set GPR 4 to 0 or the address of a TCB in the currently addressable address space.

Setting the GPR 4 to 0 identifies the input TCB as the TCB that owns the cross-memory resources for the currently addressable address space (task whose TCB address is in ASCBXTCB).

For an explanation of the term **input TCB**, and to determine system-assigned defaults for private storage ownership, see the information about selecting the right subpool for virtual storage requests in [*z/OS MVS Programming: Authorized Assembler Services Guide*](#).

7

The address of the ASCB for the currently addressable address space.

Output register information for LINKAGE=BRANCH

When control returns to the caller, the GPRs contain:

Register

Contents

0

For a successful request, contains the length of the storage obtained. Otherwise, used as a work register by the system. Storage obtained.

1

The address of the allocated storage when STORAGE is successful; otherwise, used as a work register by the system.

Note: A successful STORAGE OBTAIN will return a 64-bit pointer to the obtained area (bits 0-32 will be zero).

2

Unchanged.

3

Used as a work register by the system.

4-13

Unchanged.

14

Used as a work register by the system.

15

Contains the return code.

STORAGE macro

When control returns to the caller, the ARs contain:

Register	Contents
----------	----------

0-1	Used as work registers by the system.
------------	---------------------------------------

2-13	Unchanged.
-------------	------------

14-15	Used as work registers by the system.
--------------	---------------------------------------

Input register information for LINKAGE=GLOBALBRANCH

Before issuing the STORAGE macro with LINKAGE=GLOBALBRANCH, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information for LINKAGE=GLOBALBRANCH

When control returns to the caller, the GPRs contain:

Register	Contents
----------	----------

0	For a successful request, contains the length of the storage obtained. Otherwise, used as a work register by the system.
----------	--

1	The address of the allocated storage when STORAGE is successful; otherwise, used as a work register by the system.
----------	--

Note: A successful STORAGE OBTAIN will return a 64-bit pointer to the obtained area (bits 0-32 will be zero).

2	Unchanged.
----------	------------

3-4	Used as work registers by the system.
------------	---------------------------------------

5-13	Unchanged.
-------------	------------

14	Used as a work register by the system.
-----------	--

15	Contains the return code.
-----------	---------------------------

When control returns to the caller, the ARs contain:

Register	Contents
----------	----------

0-1	Used as work registers by the system.
------------	---------------------------------------

2-13	Unchanged.
-------------	------------

14-15	Used as work registers by the system.
--------------	---------------------------------------

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the service returns control.

Syntax

The OBTAIN option of the STORAGE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede STORAGE.
STORAGE	
␣	One or more blanks must follow STORAGE.
OBTAIN	
,LENGTH= <i>length value</i>	<i>length value</i> : Symbol, decimal number, or register (0), (2)-(12).
,LENGTH=(<i>max length</i> , <i>min length</i>)	<i>max length</i> : Symbol, decimal number, or register (0), (2) - (12).
	<i>min length</i> : Symbol, decimal number, or register (1) - (12).
,ADDR= <i>stor addr</i>	<i>stor addr</i> : RX-type address or register (1) - (12).
	Default: ADDR=(1).
,INADDR= <i>stor addr</i>	<i>stor addr</i> : RX-type address or register (1) - (12).
	Note: This parameter can only be specified with LOC=EXPLICIT.
,SP= <i>subpool number</i>	<i>subpool number</i> : Symbol, decimal number, or register (2)-(12), (15).
	Default: SP=0.
,ALET= <i>alet-value</i>	<i>alet-value</i> : Decimal number, RX-type address, or access register(1)-(12)
	Default: ALET=0.

Syntax	Description
,BNDRY=DBLWD	Default: BNDRY=DBLWD
,BNDRY=PAGE	
,CONTBDY= <i>containing_bdy</i>	<i>containing_bdy</i> : Decimal number 3-31 or register (2) - (12).
,STARTBDY= <i>starting_bdy</i>	<i>starting_bdy</i> : Decimal number 3-31 or register (2) - (12).
,KEY= <i>key number</i>	<i>key number</i> : Decimal number 0-15 or register (2) - (12).
	Note 1: KEY is valid only when SP is specified.
	Note 2: You cannot specify both KEY and CALLRKY=YES.
,CALLRKY=NO	Default: CALLRKY=NO
,CALLRKY=YES	Note: You cannot specify both CALLRKY=YES and KEY.
,LOC=24	
,LOC=(24,31)	
,LOC=(24,64)	
,LOC=31	
,LOC=(31,31)	
,LOC=(31,64)	
,LOC=(31,PAGEFRAMESIZE1MB)	
,LOC=RES	Default: LOC=RES
,LOC=(RES,31)	
,LOC=(RES,64)	
,LOC=EXPLICIT	Note: You must specify the INADDR parameter with EXPLICIT.
,LOC=(EXPLICIT,24)	EXPLICIT.
,LOC=(EXPLICIT,31)	
,LOC=(EXPLICIT,64)	
,LOC=(EXPLICIT,PAGEFRAMESIZE1MB)	
,LINKAGE=SYSTEM	Default: LINKAGE=SYSTEM
,LINKAGE=SVC	
,LINKAGE=BRANCH	
,LINKAGE=GLOBALBRANCH	

Syntax	Description
,OWNER=HOME	Default: OWNER=HOME
,OWNER=PRIMARY	
,OWNER=SECONDARY	
,OWNER=SYSTEM	
,OWNERASID= <i>decimal number</i>	
,OWNERASID= <i>register(2)-(12)</i>	
,OWNERASID= <i>RS-type address</i>	
,CAUB=CURRENT	Default: CAUB=CURRENT
,CAUB=ADDRSPACE	
,RTCD= <i>rtcd addr</i>	<i>rtcd addr</i> : RX-type address or register (2) - (12) or (15).
	Default: RTCD=(15).
,COND=YES	Default: COND=NO
,COND=NO	
,CHECKZERO=YES	Default: CHECKZERO=NO
,CHECKZERO=NO	
,BACK=BYSPT	Default: BACK=BYSPT
,BACK=NONE	
,BACK=ALL	
,FIX=NONE	Default: FIX=NONE
,FIX=SHORT	
,FIX=LONG	
,TCBADDR= <i>tcbaddress</i>	<i>tcbaddress</i> : RS-type address or register (2) - (12).
	Default: See “Selecting the Right Subpool for Your Virtual Storage Request” in <i>z/OS MVS Programming: Authorized Assembler Services Guide</i> for the possible default values.

Syntax	Description
,EXECUTABLE=YES	Default: EXECUTABLE=YES
,EXECUTABLE=NO	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro parameter specification.

Parameters

The parameters are explained as follows:

OBTAIN

Requests that the system obtain virtual storage.

,LENGTH=*length value*

,LENGTH=(*max length,min length*)

Specifies the amount of storage the system is to obtain. *length value* specifies the length, in bytes, of the requested virtual storage. *max length* and *min length* specify the maximum and minimum amounts of storage. These numbers should be a multiple of 8; if they are not, the system uses the next higher multiple of 8.

,ADDR=*stor addr*

Specifies the location where the system is to return the address of the storage it allocates. When COND=YES and the request was not successful, the returned address is set to 7FFFF000.

,INADDR=*stor addr*

Specifies the desired virtual address for the storage to be obtained. When you specify INADDR, you must specify EXPLICIT on the LOC parameter.

Note:

1. The address specified on INADDR must be on a doubleword boundary.
2. Make sure that the virtual storage address specified on INADDR and the central storage backing specified on the LOC=EXPLICIT parameter are a valid combination. For example, if the address specified on INADDR is for storage above 16 megabytes, specify LOC=EXPLICIT or LOC=(EXPLICIT,ANY). Valid combinations include:
 - virtual above, central any
 - virtual any, central any
 - virtual below, central below
 - virtual below, central any

,SP=*subpool number*

Specifies the subpool number for the storage. (See [z/OS MVS Programming: Authorized Assembler Services Guide](#) for a list of valid subpools.) If you specify a register, the subpool number must be in bits 56-63 of the register, with bits 0-23 set to zero. If you omit this parameter, the system uses the default, which is subpool 0.

Note:

1. Callers executing in supervisor state and key 0, who specify subpool 0, will obtain storage from subpool 252. Therefore, when requesting a dump of this storage through the SDUMP or SDUMPX macro, they must specify subpool 252 rather than zero.
2. Storage requested from subpools 240 and 250 are translated to subpool 0 requests.

,ALET=*alet-value*

Specifies the ALET of the target address space — the address space in which the storage is to be obtained. The ALET must be on the caller's primary address space access list (PASN-AL) or dispatchable unit access list (DU-AL) and, if the ALET identifies a private entry, the caller must be

authorized to the target address space through the extended authorization index (EAX). For more information, see *z/OS MVS Programming: Extended Addressability Guide*. If you omit this parameter, the system assumes the target address space is in the primary address space.

The ALET parameter is valid only with LINKAGE=SYSTEM.

,BNDRY=DBLWD

,BNDRY=PAGE

Specifies that alignment on a doubleword boundary (DBLWD) or alignment with the start of a virtual page on a 4K boundary (PAGE) is required for the start of a requested area.

If the request specifies one of the LSQA or SQA subpools, the system ignores the BNDRY=PAGE keyword. Requests for storage from these subpools are then fulfilled from a single page, unless the request is greater than a page. See *z/OS MVS Programming: Authorized Assembler Services Guide* for a list of the LSQA and SQA subpools.

The default is BNDRY=DBLWD.

,CONTBDY=containing_bdy

Specifies the boundary the obtained storage must be contained within. Specify a power of 2 that represents the containing boundary. Supported values are 3-31. For example, CONTBDY=10 means the containing boundary is 2^{10} , or 1024 bytes. The containing boundary must be at least as large as the maximum requested boundary. The obtained storage will not cross an address that is a multiple of the requested boundary.

If a register is specified, the value must be in bits 24-31 of the register. Do not specify CONTBDY on a variable-length request.

CONTBDY is not valid with LOC=EXPLICIT or BNDRY=PAGE.

CONTBDY applies to all subpools.

If you omit this parameter, there is no containing boundary.

,STARTBDY=starting_bdy

Specifies the boundary the obtained storage must start on. Specify a power of 2 that represents the start boundary. Supported values are 3 - 31. For example, STARTBDY=10 means the start boundary is 2^{10} , or 1024 bytes. The obtained storage will begin on an address that is a multiple of the requested boundary.

If a register is specified, the value must be in bits 24-31 of the register. Do not specify STARTBDY on a variable-length request.

STARTBDY is not valid with LOC=EXPLICIT or BNDRY=PAGE.

STARTBDY applies to all subpools.

If you omit this parameter, the start boundary is 8 bytes (equivalent to specifying STARTBDY=3).

,KEY=key-number

Indicates the storage key of the storage to be obtained. The valid storage keys are 0 - 15. If you pass the storage key in a register, it must be in bits 56-59 in that register. KEY is valid only when SP is specified, and applies only to subpools 129 - 132, 227 - 231, 241, and 249. The system ignores the KEY parameter if KEY is used for any other subpools.

For LINKAGE=SVC, KEY is honored only for subpools 129 - 132.

For detailed information about how the system determines which storage key to assign to your storage request, see "Selecting the Right Subpool for Your Virtual Storage Request" in the *z/OS MVS Programming: Authorized Assembler Services Guide*.

,CALLRKY=NO

,CALLRKY=YES

Specifies how the system assigns the key for the storage to be obtained:

CALLRKY=NO

The system assigns the value according to the specified subpool:

- For subpools 129-132, 227-231, 241, and 249, the system assigns the value specified on the KEY parameter (or zero, if the KEY parameter is omitted) as the storage key
- For all other subpools, the system ignores the CALLRKY parameter.

CALLRKY=YES

The system assigns the caller's current PSW key as the storage key. When you specify CALLRKY=YES, do not also specify KEY. Specify CALLRKY only when obtaining storage from subpools 129-132, 227-231, 241, and 249. For all other subpools, the system ignores the CALLRKY parameter.

The default is CALLRKY=NO. For detailed information about how the system determines what storage key to assign to your storage request, see “Selecting the Right Subpool for Your Virtual Storage Request” in the *z/OS MVS Programming: Authorized Assembler Services Guide*.

,LOC=24
,LOC=(24,31)
,LOC=(24,64)
,LOC=31
,LOC=(31,31)
,LOC=(31,64)
,LOC=(31,PAGEFRAMESIZE1MB)
,LOC=RES
,LOC=(RES,31)
,LOC=(RES,64)
,LOC=EXPLICIT
,LOC=(EXPLICIT,24)
,LOC=(EXPLICIT,31)
,LOC=(EXPLICIT,64)
,LOC=(EXPLICIT,PAGEFRAMESIZE1MB)

Specifies the location of virtual storage and central (also called real) storage. This is especially helpful for callers with 24-bit dependencies. When LOC is specified, central storage is allocated anywhere until the storage is fixed (for example, using the PGSER macro). You can specify the location of central storage (after the storage is fixed) and virtual storage (whether or not the storage is fixed) using the following LOC parameter values:

LOC=24 indicates that central and virtual storage are to be located below 16 megabytes. LOC=24 must not be used to allocate disabled reference (DREF) storage.

Note: Specifying LOC=BELOW is the same as specifying LOC=24. LOC=BELOW is still supported, but IBM recommends using LOC=24 instead.

LOC=(24,31) indicates that virtual storage is to be located below 16 megabytes and central storage can be located anywhere below 2 gigabytes.

Note: Specifying LOC=(BELOW,ANY) is the same as specifying LOC=(24,31). LOC=(BELOW,ANY) is still supported, but IBM recommends using LOC=(24,31) instead.

LOC=(24,64) indicates that virtual storage is to be located below 16 megabytes and central storage can be located anywhere in 64-bit storage.

LOC=31 and LOC=(31,31) indicate that virtual and central storage can be located anywhere below 2 gigabytes.

Note: Specifying LOC=ANY or LOC=(ANY,ANY) is the same as specifying LOC=31 or LOC=(31,31). LOC=ANY and LOC=(ANY,ANY) are still supported, but IBM recommends using LOC=31 or LOC=(31,31) instead.

LOC=(31,64) indicates that virtual storage is to be located below 2 gigabytes and central storage can be located anywhere in 64-bit storage.

LOC=(31,PAGEFRAMESIZE1MB) indicates that virtual storage is to be located below 2 gigabytes and central storage can be backed anywhere in 64-bit storage, preferably by 1 megabyte page frames.

When you use LOC=RES to allocate storage that can reside either above or below 16 megabytes, LOC=RES indicates that the location of virtual and central storage depends on the location of the caller. If the caller resides below 16 megabytes, virtual and central storage are to be located below 16 megabytes. If the caller resides above 16 megabytes, virtual and central storage are to be located either above or below 16 megabytes.

LOC=(RES,31) indicates that the location of virtual storage depends upon the location of the caller. If the caller resides below 16 megabytes, virtual storage is to be located below 16 megabytes; if the caller resides above 16 megabytes, virtual storage can be located anywhere below 2 gigabytes. In either case, central storage can be located anywhere below 2 gigabytes.

Note: Specifying LOC=(RES,ANY) is the same as specifying LOC=(RES,31). LOC=(RES,ANY) is still supported, but IBM recommends using LOC=(RES,31) instead.

LOC=(RES,64) indicates that the location of virtual storage depends upon the location of the caller. If the caller resides below 16 megabytes, virtual storage is to be located below 16 megabytes; if the caller resides above 16 megabytes, virtual storage can be located anywhere in 31-bit storage. In either case, central storage can be located anywhere in 64-bit storage.

Note: If your program resides below 16 megabytes but runs with 31-bit addressing mode, you can specify LOC=RES (as a default or explicitly) or LOC=(RES,31) to obtain storage from a subpool supported only above 16 megabytes. Do not specify subpools supported only above 16 megabytes on requests using LOC=RES or LOC=(RES,31) if your program resides below 16 megabytes and runs with 24-bit addressing.

LOC=EXPLICIT, LOC=(EXPLICIT,24), LOC=(EXPLICIT,31), or LOC=(EXPLICIT,64) specify that the requested virtual storage is to be located at the address specified with the INADDR parameter, which is required with EXPLICIT. EXPLICIT is valid only for subpools 0-127, 129-132, 240, 244, 250, 251, and 252. You cannot specify the BNDRY, OWNER, or LENGTH=(*max length,min length*) parameters with EXPLICIT.

Note: Specifying LOC=(EXPLICIT,BELOW) is the same as specifying LOC=(EXPLICIT,24). Specifying LOC=(EXPLICIT,ANY) is the same as specifying LOC=(EXPLICIT,31). The older specifications are still supported, but IBM recommends using the newer specifications instead.

LOC=(EXPLICIT,31) indicates that virtual storage is to be located at the address specified on the INADDR parameter, and central storage can be located anywhere below 2 gigabytes.

LOC=(EXPLICIT,24) indicates that virtual storage is to be located at the address specified on the INADDR parameter, and central storage is to be located below 16 megabytes. The virtual storage address specified on the INADDR parameter must be below 16 megabytes.

LOC=EXPLICIT and LOC=(EXPLICIT,64) indicate that virtual storage is to be located at the address specified on the INADDR parameter, and central storage can be located anywhere in 64-bit storage.

When you specify EXPLICIT on a request for storage from the same virtual page as previously requested storage, you must request it in the same key, subpool, and central storage area as on the previous storage request. For example, if you request virtual storage backed with central storage below 16 megabytes, any subsequent requests for storage from that virtual page must be specified as LOC=(EXPLICIT,24).

LOC=(EXPLICIT,PAGEFRAMESIZE1MB) locates virtual storage at the address specified on the INADDR parameter, and backs central storage anywhere in 64-bit storage, preferably by 1 megabyte page frames.

Note:

1. A caller cannot specify LOC=24 or LOC=(24,31) from subpools: 203-205, 213-215, 223-225, 247, and 248 because they are supported only above 16 MB.
2. When you specify LOC=31, the actual location of the virtual storage (that is, whether it is above or below 16 MB) depends on the subpool you specify on the SP parameter:

- Some subpools (for example, 203-204) are supported **only above** 16 MB. For these subpools, STORAGE OBTAIN locates virtual storage above 16 MB. If you specify LOC=24 for one of these subpools, the system abends your program.
 - All other subpools are supported both above and below 16 MB. For these subpools, specifying LOC=31 causes STORAGE OBTAIN to try to allocate virtual storage above 16 MB, but below 2 GB. If the attempt fails, it tries to allocate virtual storage below 16 MB. If this attempt also fails, it does not allocate any storage.
3. A caller residing below 16 MB but running in 31-bit addressing mode can specify LOC=RES (as a default or explicitly) or LOC=(RES,31) to obtain storage from a subpool supported only above 16 MB.

,OWNER=HOME**,OWNER=PRIMARY****,OWNER=SECONDARY****,OWNER=SYSTEM**

Specifies the entity to which the system will assign ownership of requested CSA, ECSA, SQA, and ESQA storage. The system uses this ownership information to track the use of CSA, ECSA, SQA and ESQA storage. This parameter can have one of the following values:

HOME

The home address space

PRIMARY

The primary address space

SECONDARY

The secondary address space

SYSTEM

The system (the storage is not associated with an address space); specify this value if you expect the requested storage to remain allocated after termination of the job that obtained the storage.

The default value is OWNER=HOME. The system ignores the OWNER keyword unless you specify a CSA, ECSA, SQA, or ESQA subpool on the SP parameter.

Storage tracking is available as of MVS/SP release 4.3. However, programs that issue the STORAGE OBTAIN macro with the OWNER parameter can run on any MVS system from MVS/SP 3.1 to the current release.

,OWNERASID=decimal number**,OWNERASID=register(2)-(12)****,OWNERASID=RS-type address**

Specifies the ASID to be used for common storage tracking. You must also specify OWNER to designate the ASID to be used on z/OS 1.8 systems or below. If the OWNERASID value is not valid, you must specify the keyword OWNER.

OWNERASID=decimal number

Specifies the decimal ASID number.

OWNERASID=register(2)-(12)

Specifies the register, (2) - (12), containing the OWNERASID.

OWNERASID=RS-type address

Specifies the RS-type address of the OWNERASID.

,CAUB=CURRENT**,CAUB=ADDRSPACE**

Specifies that common storage tracking is requested. When not running under an initiated job, there is no difference between CAUB=CURRENT and CAUB=ADDRSPACE.

CAUB=CURRENT

Use when running in a job's address space.

CAUB=ADDRSPACE

Use when running under a job in an initiator and the storage is intended to be associated with the initiator address space, not the job.

,BACK=BYSPT

,BACK=NONE

,BACK=ALL

Specifies a preference for how much storage should be backed by real storage at the time the storage is obtained.

BACK=BYSPT

Storage should be backed by pageable storage subpools.

BACK=NONE

No storage should be backed.

BACK=ALL

All storage should be backed.

,FIX=NONE

,FIX=SHORT

,FIX=LONG

Indicates to the system whether you plan to fix the storage backed by this STORAGE OBTAIN and how long you expect that it will remain fixed.

FIX=NONE

The storage will not be fixed.

FIX=SHORT

The relative real time anticipated for the storage to remain fixed is short.

FIX=LONG

The relative real time anticipated for the storage to remain fixed is long. (In general, the duration of a fix is long if it can be measured in seconds.)

,LINKAGE= SYSTEM

,LINKAGE=SVC

,LINKAGE=BRANCH

,LINKAGE=GLOBALBRANCH

Specifies the type of entry linkage to be used.

LINKAGE=SYSTEM

The STORAGE OBTAIN macro receives control through the PC entry.

LINKAGE=SVC

The STORAGE OBTAIN macro receives control through the SVC entry.

LINKAGE=BRANCH

The STORAGE OBTAIN macro receives control through branch entry. Both local (private) and global (common) storage can be allocated.

LINKAGE=GLOBALBRANCH

The STORAGE OBTAIN macro receives control through branch entry. Only global (common) storage can be allocated.

,RTCD=*rtcd addr*

Specifies the location where the system is to store the return code. The return code is also in GPR 15. This parameter is valid only if you specify COND=YES.

,COND=YES

,COND=NO

Specifies whether the request is unconditional or conditional.

COND=YES specifies that the active unit of work should not be abnormally terminated if there is insufficient contiguous virtual storage to satisfy the request, and instead should return to the caller with a non-zero return code. Use of COND=YES does not prevent all abnormal terminations. For example, if the request has incorrect or inconsistent parameters, the system abnormally terminates

the active unit of work. If you specify COND=YES, you may also specify the RTCD parameter to define the location where the system is to store the return code.

COND=NO indicates that the request is unconditional. The system abnormally terminates the active unit of work if the STORAGE OBTAIN request cannot complete successfully. This situation occurs if the parameters passed on the request are incorrect or inconsistent, if the system encounters internal errors, or if there is not enough contiguous virtual storage to satisfy the request. COND=NO is the default.

,CHECKZERO=YES

,CHECKZERO=NO

Specifies whether or not the return code for a successful completion should indicate if the system has cleared the requested storage to zeros. When CHECKZERO=NO is specified or defaulted, the return code for a successful completion is 0. When CHECKZERO=YES is specified, the return code for a successful completion is X'14' if the system has cleared the requested storage to zeros, and 0 if the system has not cleared the requested storage to zeroes.

There is no performance cost to specifying CHECKZERO=YES.

Programs that issue the STORAGE macro with the CHECKZERO parameter can run on any MVS system from MVS/SP 2.1 to the current release. On a down-level system, CHECKZERO will be ignored, and the return code for a successful completion (conditional or unconditional) will be 0.

,TCBADDR=tcbaddress

Specifies the address of a word that contains the address of the input task control block (TCB), or a register that contains the address of the input TCB. The system assumes that the input TCB resides in the address space where the storage is to be obtained.

For an explanation of the term **input TCB**, and to determine the system-assigned defaults for private storage ownership, see “Selecting the Right Subpool for Your Virtual Storage Request” in *z/OS MVS Programming: Authorized Assembler Services Guide*.

The system ignores the TCBADDR keyword if the STORAGE OBTAIN request is for a common storage subpool.

,EXECUTABLE=YES

,EXECUTABLE=NO

Specifies if code can be executed from the obtained storage on a system that has implemented instruction-execution-protection. When you release the area, you should use the same EXECUTABLE specification to avoid additional overhead. The storage will be successfully released regardless.

,EXECUTABLE=YES

This parameter indicates that code is able to be executed from the obtained storage.

,EXECUTABLE=NO

This parameter indicates that code will not be able to be executed from the obtained storage on a system that has implemented instruction-execution-protection. The specification of NO will be ignored when executed on a system that has not implemented instruction-execution-protection or is not running an appropriate level of z/OS. It is valid only when requesting storage from a private storage subpool.

,RELATED=value

Specifies information used to self-document macro by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user, and can be any valid coding values.

ABEND codes

Abend codes that STORAGE OBTAIN might issue are listed below. For detailed abend code information, see *z/OS MVS System Codes*.

- 178
- 278

- 378
- 478
- 778
- 878
- 978
- A78
- B78
- D78

Return and reason codes

When control returns from the STORAGE OBTAIN request and you specified a conditional request, GPR 15 (and *rtcd addr*, if you coded RTCD) contains one of the following hexadecimal return codes. When running in an AMODE64 environment, only the low half of GPR15 contains a return code. There is no guarantee for the contents of the high half of GPR15.

If a system fails to obtain the requested storage, an invalid storage address is returned, with the valid return and reason codes.

Table 20. Return Codes for STORAGE OBTAIN	
Return Code	Meaning and Action
0	<p>Meaning: Successful completion. CHECKZERO=YES was not specified, or the system has not cleared the requested storage to zeroes.</p> <p>Action: None.</p>
4	<p>If you did not specify EXPLICIT on the LOC parameter:</p> <ul style="list-style-type: none"> • Meaning: Environmental or system error. Virtual storage was not obtained because insufficient storage is available. • Action: If the request was for private (local) storage, consult the system programmer to see if you have exceeded an installation-determined private storage limit. <p>If the request is for common (global) storage, your system is probably experiencing a common storage shortage and your request cannot be satisfied until the shortage is corrected.</p> <p>If you specified EXPLICIT on the LOC parameter:</p> <ul style="list-style-type: none"> • Meaning: Program error. Virtual storage was not obtained because part of the requested storage area is outside the bounds of the user region. • Action: Determine why your program is mistakenly requesting storage outside the user region. If your region size is too small, consult the system programmer about increasing the region size.
8	<p>Meaning: System error. Virtual storage was not obtained because the system has insufficient central storage to back the request.</p> <p>Action: Report the problem to the system programmer so the cause of the problem can be determined and corrected.</p>
0C	<p>Meaning: System error. Virtual storage was not obtained because the system cannot page in the page table associated with the storage to be allocated.</p> <p>Action: Report the problem to the system programmer so the cause of the problem can be determined and corrected.</p>

Table 20. Return Codes for STORAGE OBTAIN (continued)

Return Code	Meaning and Action
10	<p>Meaning: Program error. Virtual storage was not obtained due to one of the reasons listed below. This return code applies only to STORAGE requests with LOC=EXPLICIT specified.</p> <ul style="list-style-type: none"> • Part of the requested area is allocated already. • Virtual storage was already allocated in the same page as this request, but one of the following characteristics of the storage was different: <ul style="list-style-type: none"> – The subpool – The key – Central storage backing <p>Action: Determine why your program is attempting to obtain allocated storage or why your program is attempting to obtain virtual storage with different attributes from the same page of storage. Correct the coding error.</p>
14	<p>Meaning: Successful completion. The system has cleared the requested storage to zeroes. This return code occurs only when CHECKZERO=YES is specified.</p> <p>Action: None.</p>
18	<p>Meaning: PAGEFRAMESIZE1MB was specified on the LOC=parameter on a STORAGE OBTAIN request for a subpool other than 0-127, 129-132, 240, 244 or 250-252.</p> <p>Action: None.</p>

Examples

For examples of how to use the STORAGE macro with the OBTAIN option, see [“Examples of the OBTAIN and RELEASE options”](#) on page 139.

STORAGE RELEASE

The STORAGE macro with the RELEASE parameter requests that the system release an area of virtual storage or an entire virtual storage subpool, previously allocated through the STORAGE or GETMAIN macro. The system abends the active task if the specified virtual storage does not start on a doubleword boundary or, for an unconditional request, if the specified area or subpool is not allocated to the current task. The current task is determined from the input task specified on the TCBADDR parameter (see [“Selecting the Right Subpool for Your Virtual Storage Request”](#) in *z/OS MVS Programming: Authorized Assembler Services Guide* for more information about the input task).

Input register information for LINKAGE=SYSTEM

Before issuing the STORAGE macro with LINKAGE=SYSTEM, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information for LINKAGE=SYSTEM

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system.

2-13

Unchanged.

14

Used as a work register by the system.

15

Return code if you specified COND=YES; otherwise, used as a work register by the system.

When control returns to the caller, the access registers (ARs) contain:

**Register
Contents**

0-1

Used as work registers by the system.

2-13

Unchanged.

14-15

Used as work registers by the system.

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the service returns control.

Input register information for LINKAGE=SVC

Before issuing the STORAGE macro with LINKAGE=SVC, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information for LINKAGE=SVC

When control returns to the caller the GPRs contain:

**Register
Contents**

0-1

Used as work registers by the system.

2-13

Unchanged.

14

Used as a work register by the system.

15

Return code if you specified COND=YES; otherwise, used as a work register by the system.

When control returns to the caller, the access registers (ARs) contain:

**Register
Contents**

0-1

Used as work registers by the system.

2-13

Unchanged.

14-15

Used as work registers by the system.

Input register information for LINKAGE=BRANCH

Before issuing the STORAGE macro with LINKAGE=BRANCH, the caller must ensure that the following GPRs contain the specified information:

**Register
Contents**

4

The address of the input TCB, if you are obtaining private storage.

If your program is not running in cross-memory mode, setting GPR 4 to 0 identifies the input TCB as the TCB of the current task.

If your program is running in cross-memory mode, set GPR 4 to 0 or the address of a TCB in the currently addressable address space.

Setting the GPR 4 to 0 identifies the input TCB as the TCB that owns the cross-memory resources for the currently addressable address space (task whose TCB address is in ASCBXTCB).

For an explanation of the term **input TCB**, and to determine system-assigned defaults for private storage ownership, see the information about selecting the right subpool for virtual storage requests in *z/OS MVS Programming: Authorized Assembler Services Guide*.

7

The address of the ASCB for the currently addressable address space.

Output register information for LINKAGE=BRANCH

When control returns to the caller, the GPRs contain:

Register

Contents

0-1

Used as work registers by the system.

2

Unchanged.

3

Used as a work register by the system.

4-13

Unchanged.

14

Used as a work register by the system.

15

Return code if you specified COND=YES; otherwise, used as a work register by the system.

When control returns to the caller, the ARs contain:

Register

Contents

0-1

Used as work registers by the system.

2-13

Unchanged.

14-15

Used as work registers by the system.

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the service returns control.

Input register information for LINKAGE=GLOBALBRANCH

Before issuing the STORAGE macro with LINKAGE=GLOBALBRANCH, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information for LINKAGE=GLOBALBRANCH

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system.

2

Unchanged.

3-4

Used as work registers by the system.

5-13

Unchanged.

14

Used as a work register by the system.

15

Return code if you specified COND=YES; otherwise, used as a work register by the system.

When control returns to the caller, the ARs contain:

Register Contents

0-1

Used as work registers by the system.

2-13

Unchanged.

14-15

Used as work registers by the system.

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the service returns control.

Syntax

The RELEASE option of the STORAGE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede STORAGE.
STORAGE	
␣	One or more blanks must follow STORAGE.
RELEASE	

Syntax	Description
,LENGTH= <i>length value</i>	<i>length value</i> : Symbol, decimal number, or register (0), (2) - (12).
,ADDR= <i>stor addr</i>	<i>stor addr</i> : RX-type address or register (1) - (12).
,SP= <i>subpool number</i>	<i>subpool number</i> : Symbol, decimal number, or register (2) - (12), (15).
	Default: SP=0.
,ALET= <i>alet-value</i>	<i>alet-value</i> : Decimal number, RX-type address, access register (1) - (12).
	Default: ALET=0.
,KEY= <i>key number</i>	<i>key number</i> : Decimal number 0-15 or register (2) - (12).
	Note: KEY is valid only when SP is specified.
,CALLRKY=NO	Default: CALLRKY=NO
,CALLRKY=YES	Note: You cannot specify both CALLRKY=YES and KEY.
,RTCD= <i>rtcd addr</i>	<i>rtcd addr</i> : RX-type address or registers (2) - (12), (15).
	Default: RTCD=(15)
,COND=YES	Default: COND=NO
,COND=NO	
,TCBADDR= <i>tcbaddress</i>	<i>tcbaddress</i> : RS-type address or register (2) - (12).
	Default: See “Selecting the Right Subpool for Your Virtual Storage Request” in <i>z/OS MVS Programming: Authorized Assembler Services Guide</i> for the possible default values.
,EXECUTABLE=YES	Default: EXECUTABLE=YES
,EXECUTABLE=NO	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro parameter specification.

Parameters

The parameters are explained as follows:

RELEASE

Requests that the system release virtual storage.

,LENGTH=*length value*

Specifies the number of bytes of storage that the system is to release. If you specify LENGTH, you must also specify ADDR. To free an entire subpool, use SP instead of LENGTH and ADDR. Do not

specify a length value of zero with an address of zero. This will cause STORAGE RELEASE to free the subpool specified with the SP parameter, or subpool 0, if the SP parameter is omitted.

,ADDR=stor addr

Specifies the address of the storage to be released. If you specify ADDR, you must also specify LENGTH. To free an entire subpool, use SP instead of LENGTH and ADDR.

,SP=subpool number

Specifies the subpool number for the storage to be released. The subpool number must be a valid subpool number between 0 and 255. If you specify the subpool in a register, the subpool number must be in bits 24-31 of the register, with bits 0-23 set to zero. If you omit this parameter, the system uses subpool 0.

A request to release all the storage in a subpool is known as a **subpool release**. To issue a subpool release, use SP to indicate the subpool and do not specify either LENGTH or ADDR. Issue subpool releases only for the following subpools: 0-127, 129-132, 203, 204, 213, 214, 223, 224, 229, 230, 233, 236, 237, 240, 249, and 250-253. If you try to issue a subpool release for any other subpool, an abend X'478' or X'40A' occurs. See the list of subpool characteristics in *z/OS MVS Programming: Authorized Assembler Services Guide* for information and requirements pertaining to specific subpools.

Note:

1. The system translates subpool 0 storage requests to subpool 252 storage requests when you are running in supervisor state and key 0. If you are not running in supervisor state and key 0, you will receive storage from subpool 0 when you request it.
2. The system translates subpool 240 and 250 storage requests to subpool 0 storage requests. Bearing this in mind, you must be careful to specify the correct subpool when obtaining and releasing storage. For instance, if you obtain subpool 0 storage while running in problem state, you will receive subpool 0 storage. If you attempt to release it after switching to supervisor state and PSW key 0, you cannot specify subpool 0 because the system will try to free subpool 252 storage. Instead, you must release the storage specifying subpools 240 or 250, which are translated by the system to subpool 0.

,ALET=alet-value

Specifies the ALET of the address space in which the storage is to be released. The ALET must be on the caller's primary address space access list (PASN-AL) or dispatchable unit access list (DU-AL) and, if the ALET identifies a private entry, the caller must be authorized to the target address space through the extended authorization index (EAX). For additional information, see *z/OS MVS Programming: Extended Addressability Guide*. If you omit this parameter, the system assumes storage is in the primary address space.

The ALET parameter is valid only with LINKAGE=SYSTEM.

,KEY=key-number

Indicates the storage key of the storage to be released. The valid storage keys are 0-15. If you pass the storage key in a register, it must be in bits 56-59 in that register. KEY is valid only with SP and applies only to subpools 129-132, 227-231, 241, and 249. The system ignores the KEY parameter if KEY is used for any other subpools. KEY allows you to release storage in the specified storage protection key. See list of subpool characteristics in *z/OS MVS Programming: Authorized Assembler Services Guide* for information on authorization requirements pertaining to specific subpools.

,CALLRKEY=NO

,CALLRKEY=YES

Specifies what key the system will use for the storage release.

CALLRKY=NO

The system assigns the value according to the specified subpool:

- For subpools 129-132, 227-231, 241, and 249, the system assigns the value specified on the KEY parameter (or zero, if the KEY parameter is omitted) as the storage key
- For all other subpools, the system ignores the CALLRKY parameter.

CALLRKY=YES

The system assigns the caller's current PSW key as the storage key. When you specify CALLRKY=YES, do not also specify KEY. Specify CALLRKY only when obtaining storage from subpools 129-132, 227-231, 241, and 249. For all other subpools, the system ignores the CALLRKY parameter.

The default is CALLRKY=NO. For detailed information about how the system determines what storage key to assign to your storage request, see “Selecting the Right Subpool for Your Virtual Storage Request” in the [z/OS MVS Programming: Authorized Assembler Services Guide](#).

,RTCD=rtcd addr

Specifies the location where the system is to store the return code. The return code is also in GPR 15. This parameter is only valid if you specify COND=YES.

,COND=YES**,COND=NO**

Specifies whether the request is unconditional or conditional.

COND=YES specifies that the task should not abend if the system cannot release the storage. However, the system cannot prevent some abends. The RTCD parameter specifies the location where the system is to store a return code. COND=NO specifies that the system abend the active task if it cannot release the storage.

COND=NO is the default.

,TCBADDR=tcbaddress

Specifies the address of a word that contains the address of the input task control block (TCB), or a register that contains the address of the input TCB.

For an explanation of the term **input TCB**, and to determine the system-assigned defaults for private storage ownership, see “Selecting the Right Subpool for Your Virtual Storage Request” in [z/OS MVS Programming: Authorized Assembler Services Guide](#).

The system ignores the TCBADDR keyword if the STORAGE RELEASE request is for a common storage subpool. If you specified TCBADDR on STORAGE OBTAIN, you should also specify TCBADDR on STORAGE RELEASE.

,EXECUTABLE=YES**,EXECUTABLE=NO**

Specifies the EXECUTABLE attribute applied when the area was obtained. If a different attribute is provided, the storage will be successfully released but there will be additional overhead.

,RELATED=value

Specifies information used to self-document macro by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user, and can be any valid coding values.

ABEND codes

Abend codes that STORAGE RELEASE might issue are listed below. For detailed abend code information, see [z/OS MVS System Codes](#).

- 178
- 278
- 378
- 478
- 778
- 878
- 978
- A78
- B78

- D78

Return and reason codes

When the STORAGE macro returns control to your program and you specified a conditional request, GPR 15 (and *rtcd addr*, if you coded RTCD) contains one of the following hexadecimal return codes:

Table 21. Return Codes for STORAGE RELEASE	
Return Code	Meaning and Action
0	Meaning: Successful completion. Action: None.
4	Meaning: Program error. Not all requested virtual storage was freed. Action: Check your program for the following kinds of errors: <ul style="list-style-type: none"> • The address of the storage area to be freed is not correct. • The subpool you have specified does not match the subpool of the storage to be freed. • The key you have specified does not match the key of the storage to be freed. • The EXECUTABLE setting does not match the executable setting of the storage to be freed. • For private storage: the owning task identified by the input TCB is not correct for the storage to be freed.
8	Meaning: Program error. No virtual storage was freed because part of the storage area to be freed is fixed. Action: Check your program for the following kinds of errors: <ul style="list-style-type: none"> • You passed an incorrect storage area address to the STORAGE macro. • You attempted to free storage that is fixed.

Examples of the OBTAIN and RELEASE options

Example 1

Code the instructions to obtain 1000 bytes of virtual storage from subpool 223. The system returns the address of the storage in register 3. If the request fails, the system abends the caller.

```
LA      2,1000
STORAGE OBTAIN,LENGTH=(2),ADDR=(3),SP=223,COND=NO,LOC=ANY
```

Release the 1000 bytes obtained above from subpool 223 and abend the caller if the request fails. Assume that the length of the storage is still in register 2 and the address of the storage is in register 3.

```
STORAGE RELEASE,LENGTH=(2),ADDR=(3),SP=223,COND=NO
.
```

Example 2

Code the instructions to obtain 4096 bytes of virtual storage from subpool 227 — above 16 megabytes, if possible. The address is returned at location STRGA. The protection key is the caller's PSW key. The system is to assign the storage to be obtained to the primary address space. The system is to store the return code at location MY_RC.

```
STORAGE OBTAIN,LENGTH=ONE_PAGE,ADDR=STRGA,SP=MY_SUBPOOL,
CALLRKY=YES,LOC=ANY,COND=YES,OWNER=PRIMARY,RTCD=MY_RC
```

To release the 4096 bytes obtained above from subpool 227, issue:

```
L      2,KEY_5
STORAGE RELEASE,LENGTH=ONE_PAGE,ADDR=STRGA,SP=MY_SUBPOOL,
KEY=(2),COND=YES,RTCD=MY_RC
.
```

```

      .
MY_RC   DS    F
STRGA   DS    F
KEY_5   DC    X'00000050'
ONE_PAGE EQU 4096
MY_SUBPOOL EQU 227

```

Note that, when the caller passes the key in a register, the key must be in bits 24-27. Note also, that KEY=KEY_5 is not valid, as KEY_5 is neither a register nor a decimal number.

Example 3

Code the instructions to obtain 4096 bytes of virtual storage from subpool 227. Indicate that, if the system cannot obtain 4096 bytes, the caller can settle for as little as 1024 bytes. The system returns the address of the storage obtained at location STRGA. The protection key is 5. The system is to store the return code at location MY_RC.

```

STORAGE  OBTAIN,LENGTH=(ONE_PAGE,ONE_K),ADDR=STRGA,                X
          SP=MY_SUBPOOL,KEY=5,LOC=ANY,COND=YES,RTCD=MY_RC
ST       0,STRG_LEN

```

Release the storage from subpool 227, obtained above. Note that you cannot specify LENGTH=STRG_LEN.

```

      .
L       2,KEY_5
L       3,STRG_LEN
STORAGE RELEASE,LENGTH=(3),ADDR=STRGA,SP=MY_SUBPOOL,                X
          KEY=(2),COND=YES,RTCD=MY_RC
      .
STRG_LEN DS    F
MY_RC    DS    F
STRGA    DS    F
KEY_5    DC    X'00000050'
ONE_K    EQU 1024
ONE_PAGE EQU 4096
MY_SUBPOOL EQU 227

```

Example 4

Code the instructions to set up an 18-word save area, such as one that a program in AR address space control (ASC) mode would obtain to call a program in primary mode. The program issuing the STORAGE macro is in 31-bit addressing mode, and the code is reentrant.

```

PGM  CSECT
PGM  AMODE 31
PGM  RMODE ANY
      BAKR 14,0          SAVE CALLER'S ARS, GPRS AND RETURN
*                               ADDRESS ON LINKAGE STACK
      SAC 512            SWITCH TO AR ASC MODE
      LAE 12,0(15,0)     SET UP PROGRAM BASE REGISTER AND AR
      USING PGM,12
      STORAGE OBTAIN,LENGTH=72 GET REENTRANT SAVEAREA
      LAE 13,0(1,0)      PUT SAVEAREA ADDRESS IN AR/GPR 13
      MVC 4(4,13),=C'F1SA' PUT ACRONYM INTO SAVEAREA TO
*                               INDICATE STATUS SAVED ON LINKAGE STACK
      .
*   BEGIN PROGRAM CODE HERE

```

To release this save area, issue the following instructions:

```

      .
LAE 1,0(0,13)          COPY SAVEAREA ADDRESS
STORAGE RELEASE,ADDR=(1),LENGTH=72 FREE SAVEAREA
      .
SLR 15,15             SET RETURN CODE OF ZERO
PR                               RETURN TO CALLER, RESTORE CALLERS STATUS

```

Chapter 14. SUSPEND — Suspend execution of an RB

Description

Note: To suspend an SRB, use the variation of the SUSPEND macro described under [Chapter 15](#), “SUSPEND — Suspend execution of an SRB,” on page 145.

To suspend execution of a request block (RB), use this variation of the SUSPEND macro. The RB remains suspended until a subsequent RESUME macro causes the RB to resume execution.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state with PSW key 0
Dispatchable unit mode:	Task
Cross memory mode:	Any
AMODE:	24- or 31-bit
ASC mode:	Primary or secondary
Interrupt status:	Can be either enabled or disabled
Locks:	Can hold the CPU or local lock
Control parameters:	Must be in the caller's primary address space

Programming requirements

The caller must include the IHAPSA mapping macro and the CVT mapping macro specifying DSECT=YES.

Restrictions

The list and execute forms of the SUSPEND macro are not valid for suspending execution of an RB.

Input register information

Before issuing the SUSPEND macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter or using it as a base register.

Output register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the general purpose registers (GPRs) contain:

Register	Contents
0	Address of the suspended TCB

SUSPEND macro for RBs

1

Address of the suspended RB

2-10

Unchanged

11-15

Used as work registers by the system

Performance implications

None.

Syntax

The SUSPEND macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SUSPEND.
SUSPEND	
␣	One or more blanks must follow SUSPEND.
RB=PREVIOUS	Default: RB=PREVIOUS
RB=CURRENT	

Parameters

The parameters are explained as follows:

RB=PREVIOUS

RB=CURRENT

Specifies which RB on the TCB to suspend. The current RB is the one that is executing; it is the first RB on the RB chain. The previous RB is the one that follows the current RB on the RB chain.

ABEND codes

070

See [z/OS MVS System Codes](#) for an explanation and programmer responses for this code.

Return and reason codes

None.

Example

Suspend the execution of the most recently chained request block of the current task.

```
SUSPEND  RB=CURRENT
```


Chapter 15. SUSPEND – Suspend execution of an SRB

Description

Note: To suspend an RB, use the variation of the SUSPEND macro described under [Chapter 14](#), “SUSPEND – Suspend execution of an RB,” on page 141.

To request suspension of a supervisor request block (SRB), use this variation of the SUSPEND macro.

When a caller issues the SUSPEND macro for an SRB, the system passes control to an exit routine identified on the SUSPEND macro and passes the suspend token to the routine. The exit routine decides whether to suspend the SRB or allow the SRB to continue execution and informs the system of its decision. If the SRB is to be suspended, the exit routine must store the suspend token so that the token can later be used to resume the SRB. The system takes the action requested by the exit routine. If the SRB is suspended, the SRB remains suspended until a subsequent RESUME macro either causes the SRB to resume execution or purges the SRB. If the exit routine allows the SRB to continue execution, control returns to the program that issued the SUSPEND macro.

Note: If the suspend completes successfully, the system will release any local lock that the caller might have held.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state or PSW key 0 - 7
Dispatchable unit mode:	SRB
Cross memory mode:	Any
AMODE:	31-bit
ASC mode:	Primary or access register (AR)
Interrupt status:	Enabled for I/O and external interrupts
Locks:	The caller may hold the local or CML lock but is not required to hold any
Control parameters:	Must be in the caller's primary address space or addressable through the caller's dispatchable unit access list (DU-AL)

Programming requirements

Programming requirements for the calling program are:

- Before issuing the SUSPEND macro, ensure that the global symbol &SYSASCE is correctly set to indicate the ASC mode of your program. To test or set this global symbol, use the SYSSTATE macro.
- Programs in AR ASC mode must ensure that parameter addresses are ALET-qualified.

Restrictions

None.

Input register information

Before issuing the SUSPEND macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter or using it as a base register.

Output register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the general purpose registers contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the access registers contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The standard form of the SUSPEND macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede SUSPEND.
SUSPEND	

Syntax	Description
<code> </code>	One or more blanks must follow SUSPEND.
<code>SPTOKEN=<i>sptoken addr</i></code>	<i>sptoken addr</i> : RX-type address.
<code>,EXIT=<i>exit addr</i></code>	<i>exit addr</i> : RX-type address or register (2) - (12).
<code>,EXITPARM=<i>exitparm addr</i></code>	<i>exitparm addr</i> : RX-type address.
<code>,RSCODE=<i>rscode addr</i></code>	<i>rscode addr</i> : RX-type address.
<code>,RELATED=<i>value</i></code>	<i>value</i> : Any valid macro parameter specification.

Parameters

The parameters are explained as follows:

SPTOKEN=*sptoken addr*

Specifies the address of an 8-byte location where the system is to place the suspend token that identifies the SRB that is to be suspended.

,EXIT=*exit addr*

The 31-bit address of the suspend exit routine. The suspend exit routine must be addressable in the caller's primary address space.

,EXITPARM=*exitparm addr*

The 31-bit address of the parameters to be passed to the suspend exit routine.

,RSCODE=*rscode addr*

Specifies the address of the fullword where the system is to place the resume code optionally returned by the suspend exit routine or by the program that issued the RESUME macro.

,RELATED=*value*

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and content of the information provided is at the discretion of the user and may be any valid coding values.

ABEND codes

017

See [z/OS MVS System Codes](#) for an explanation and programmer responses for this code.

Return codes

When the SUSPEND macro returns control to your program, GPR 15 contains a hexadecimal return code.

Table 22. Return Codes for the SUSPEND Macro	
Return Code	Meaning and Action
00	<p>Meaning: The SRB was successfully suspended and resumed. If you code the RSCODE parameter, the program that issues the RESUME macro might have stored a value into RSCODE.</p> <p>Action: None.</p>

Table 22. Return Codes for the SUSPEND Macro (continued)

Return Code	Meaning and Action
04	Meaning: The exit routine elected to allow the SRB to continue execution. If you coded the RSCODE parameter, the exit routine might have stored a value into RSCODE. Action: None.
08	Meaning: Environmental error. A program tried to issue the SUSPEND macro from an SRB after the SRB abended with code X'47B'. This SRB cannot be suspended because it is in the process of being abended. Action: None required. However, you might take some action based upon your application.
0C	Meaning: Program error. A program tried to issue the SUSPEND macro from within the suspend exit. The suspend exit tried to resuspend the SRB. Action: Change your suspend exit program so it does not issue a SUSPEND request.
20	Meaning: Program error. An error occurred in the exit routine. Action: Correct your suspend exit program to remove program errors.
24	Meaning: A system error occurred. Action: Retry the request.

Example

Suspend the execution of an SRB.

```

:
:      SUSPEND  SPTOKEN=TOKEN,EXIT=EXITRTN,RSCODE=RCODE
:
:EXITRTN  DS      0H
:
:      XR      15,15      Indicate to suspend the SRB
:      BR      14
:
:      RCODE    DS      F'0'
:      TOKEN    DS      CL8
:
:

```

SUSPEND (SRB) - List form

For programs that require reentrant code, use the list form of the SUSPEND macro together with the execute form of the macro. The list form of the macro defines an area of storage that the execute form of the macro uses to store parameter values.

Syntax

The list form of the SUSPEND macro is valid only for suspending an SRB. It is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SUSPEND.
SUSPEND	
␣	One or more blanks must follow SUSPEND.

Syntax	Description
MF=L	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro parameter specification.

Parameters

The parameters are explained under the standard form of the SUSPEND macro with the following exception:

MF=L

Requests the list form of SUSPEND.

SUSPEND (SRB) - Execute form

For programs that require reentrant code, use the execute form of the SUSPEND macro together with the list form. The execute form of the macro stores the parameters into the storage area defined by the list form.

Syntax

The execute form of the SUSPEND macro is valid only for suspending an SRB. It is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SUSPEND.
SUSPEND	
␣	One or more blanks must follow SUSPEND.
SPTOKEN= <i>sptoken addr</i>	<i>sptoken addr</i> : RX-type address.
,EXIT= <i>exit addr</i>	<i>exit addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>cntl addr</i>)	<i>cntl addr</i> : RX-type address or register (2) - (12).
,EXITPARM= <i>exitparm addr</i>	<i>exitparm addr</i> : RX-type address.
,RSCODE= <i>rscode addr</i>	<i>rscode addr</i> : RX-type address.

Syntax	Description
,RELATED= <i>value</i>	<i>value</i> : Any valid macro parameter specification.

Parameters

The parameters are explained under the standard form of the SUSPEND macro with the following exception:

,MF=(E,*cntl addr*)

Requests the execute form of SUSPEND. *cntl addr* must be the address of the parameter list provided by the list form of the macro.

Chapter 16. SVCUPDTE – SVC update

Description

Use the SVCUPDTE macro to dynamically replace or delete SVC table entries, or return the SVC number of a routine at a specified entry point. Callers who use this service are responsible for providing recovery. Improper deletion or replacement of system-provided SVC routines causes unpredictable results and might terminate the system.

Use the resource with QNAME of SYSZSVC and RNAME of TABLE, with scope of SYSTEM, asking for exclusive control as the operands of an ENQ macro to serialize the execution of programs that use the SVCUPDTE macro.

See *z/OS MVS Programming: Authorized Assembler Services Guide* for additional information about the SVCUPDTE macro.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state and PSW key 0
Dispatchable unit mode:	Task or SRB
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	None

Programming requirements

Ensure that the code for the SVC routine added to the SVC table has the correct attributes for the type of SVC specified.

The caller must include the CVT mapping macro.

Restrictions

None.

Input register information

Before issuing the SVCUPDTE macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter or using it as a base register.

Output register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on

SVCUPDTE macro

these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

On input, register 13 must contain the address of a 72-byte save area.

When control returns to the caller, the general purpose registers (GPRs) contain:

Register Contents

0

One of the following:

- If EXTRACT is specified: The SVC number
- If REPLACE or DELETE is specified: Unchanged

1-13

Unchanged

14

Used as a work register by the system

15

Return code

Performance implications

None.

Syntax

The SVCUPDTE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SVCUPDTE.
SVCUPDTE	
␣	One or more blanks must follow SVCUPDTE.
<i>num</i>	<i>num</i> : Symbol, decimal number, hexadecimal number (for example, X'02'), or register (2) - (12). Do not specify <i>num</i> with EXTRACT. Note: <i>num</i> cannot be 109, 116, 122, or 137 unless the ESR specification is also used.
,REPLACE	
,DELETE	
,EXTRACT	
,EXTRACTANY	

Syntax	Description
,TYPE=1	Note: TYPE is only valid with REPLACE.
,TYPE=2	
,TYPE=3	
,TYPE=4	
,TYPE=6	
,EP= <i>addr</i>	<i>addr</i> : A-type address, decimal number, hexadecimal number, or register (2) - (12). <i>addr</i> should be a full 31-bit value with AMODE in bit 0.
,EPNAME= <i>entry-name</i>	<i>entry-name</i> : Symbol
	Note: EP and EPNAME are not needed with the DELETE option.
,LOCKS=(<i>lname, lname,...</i>)	<i>lname</i> : CMS or LOCAL.
	Note: LOCKS is invalid with DELETE and EXTRACT, and cannot be specified with TYPE=6.
,APF=NO	Default: APF=NO
,APF=YES	Note: APF is only valid with REPLACE.
,AR=NO	Default: AR=NO
,AR=YES	Note: AR is valid only with REPLACE.
,NPRMPT=NO	Default: NPRMPT=NO
,NPRMPT=YES	Note: NPRMPT is only valid with REPLACE.
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.
,ESR= <i>esr</i>	<i>esr</i> : decimal number, or register (2) - (12).
,USEECVT=NO	Default: USEECVT=NO
,USEECVT=YES	

Parameters

The parameters are explained as follows:

num

Specifies the number of the SVC that is being inserted or deleted.

,REPLACE**,DELETE**

Specifies the function to be performed. REPLACE indicates that an SVC table entry is to be inserted in the SVC table. This could be a new SVC or a replacement for an existing SVC. DELETE indicates that the specified SVC number is to be deleted from the SVC table.

If you issue an SVC instruction with a deleted or undefined SVC number, the program abnormally ends with a system completion code of X'Fnn' (*nn* is the operand of the SVC instruction, in hexadecimal). However, if you issue an SVCUPDTE macro using the DELETE parameter and specify a previously deleted SVC number, no abnormal end results.

,EXTRACT

Indicates that the user has supplied an EP or EPNAME and wishes to have the SVC number of that routine returned in register 0. The **num** parameter is not valid with this option.

,EXTRACTANY

Indicates that the user has supplied an EP or EPNAME and wishes to have the SVC or extended SVC number of that routine returned in register 0.

For a non-extended SVC

Bit 0 of register 0 has a value of 0. Bits 24–31 contain the SVC number.

For an extended SVC

Bit 0 of register 0 has a value of 1. Bits 16–23 contain the ESR number. Bits 24–31 contain the SVC number.

The **num** parameter is not valid with this option.

,TYPE=1**,TYPE=2****,TYPE=3****,TYPE=4****,TYPE=6**

Specifies the SVC type for a REPLACE request. See the topic “Programming Conventions for SVC Routines” in *z/OS MVS Programming: Authorized Assembler Services Guide* for information concerning the characteristics and restrictions for each type of SVC.

,EP=addr

Specifies the entry point address of the SVC routine. The addressing mode of the entry point is defined by bit 0 of the entry point address of the SVC routine. If bit 0=1, the SVC routine will be entered in 31-bit addressing mode; if bit 0=0, the SVC routine will be entered in 24-bit addressing mode.

,EPNAME=entry-name

Specifies the entry name of the SVC routine. The entry name must be the load module name or alias of a module in LPA or the entry name of a module link edited into the nucleus. The AMODE of the SVC routine is determined when the SVC is link edited.

When entry-name is IGCERROR:

- When ESR=*esr* is not specified, the SVC routine results in a Fxx abend when SVC xx is issued, where xx matches num.
- When ESR=*esr* is specified, the SVC routine results in abend 16D-8 when SVC num with routing code *esr* is issued.

,LOCKS=(lname,lname,...)

Specifies the lock(s) required when the SVC routine executes. The lock(s) specified can be CMS or LOCAL. This parameter is valid only with REPLACE.

Note:

1. TYPE=1 must not specify LOCAL.
2. TYPE=6 cannot specify any locks.
3. TYPE=2, 3, or 4 must specify LOCAL if CMS is specified.

,APF=YES**,APF=NO**

Specifies whether or not the invocation of the SVC is to be restricted to authorized programs. This parameter is valid only with REPLACE.

,AR=YES**,AR=NO**

Specifies whether or not the SVC can be issued by a program in access register mode. If you specify NO, a program that issues the SVC while in access register mode abends with a completion code of X'0F8'. This parameter is valid only with REPLACE.

,NPRMPT=YES**,NPRMPT=NO**

Indicates whether or not the SVC can be preempted for I/O interruptions.

,RELATED=value

Provides information to document the macro by relating the function performed to another service or function. The format can be any valid coding value that the user chooses.

,ESR=esr

Specifies the extended SVC routing number of an extended SVC. You may supply a decimal number or a value in register (2) - (12). When you supply an explicit SVC number, the ESR parameter is only allowed with SVC numbers 109, 116, 122, and 137. When you provide the SVC number in a register, the ESR specification is ignored if the SVC number is not 109, 116, 122, or 137. This parameter is not valid with EXTRACT. When ESR is specified, the TYPE parameter is only used to validate other parameters, because each extended SVC has a predefined type that cannot be changed.

Note: When using SVC screening with the ESR parameter, the system ignores the screening information associated with the ESR number itself (for example, 109). The system only uses screening information associated with the routing code.

,USEECVT=YES**,USEECVT=NO**

You may use this optional parameter to avoid some system processing. Specifying YES allows the system to locate the SVCUPDTE service with a pointer in the ECVT instead of using the NUCLKUP service. You must be running in AMODE 31 to use this parameter. This parameter also requires the IHAECVT mapping macro.

ABEND codes

None.

Return codes

When the SVCUPDTE macro returns control to your program, GPR 15 contains a hexadecimal return code.

Table 23. Return Codes for the SVCUPDTE Macro	
Return Code	Meaning and Action
00	<p>Meaning: The macro completed successfully.</p> <p>Action: None.</p>
04	<p>Meaning: The macro was coded incorrectly. For example, the user requested REPLACE without specifying an SVC number.</p> <p>Action: Correct the error in the program that issued the macro. Verify that the execute form of the macro correctly references the list form.</p>
08	<p>Meaning: Program error. The DELETE parameter was not specified correctly.</p> <p>Action: Correct the error in the program that issued the request. Verify that the execute form of the macro correctly references the list form.</p>

Table 23. Return Codes for the SVCUPDTE Macro (continued)	
Return Code	Meaning and Action
0C	<p>Meaning: Program error. A REPLACE request contained incorrect information. For example, the user specified an SVC type that was not 1 through 6, or the specified entry point address was not on a halfword boundary.</p> <p>Action: Correct the error in the program that issued the request. Verify that the execute form of the macro correctly references the list form.</p>
10	<p>Meaning: Program error. A REPLACE request contained illogical information. For example:</p> <ul style="list-style-type: none"> • A type 6 SVC specified a lock. • Neither an entry point nor an EPNAME was provided for a REPLACE request. • Both an entry point and an EPNAME are provided. • The entry point provided is zero. • The CMS lock was requested without the LOCAL lock. <p>Action: Correct the error in the program that issued the request. Verify that the execute form of the macro correctly references the list form.</p>
14	<p>Meaning: Program error. The function specified was not REPLACE, DELETE, or EXTRACT.</p> <p>Action: Verify that the function specified is REPLACE, DELETE, or EXTRACT.</p>
18	<p>Meaning: Program error. The user has attempted to update an extended SVC router entry in the SVC table (<i>num</i> was specified as 109, 116, 122, or 137).</p> <p>Action: Correct the error in the program that issued the macro. Verify that the execute form of the macro correctly references the list form.</p>
1C	<p>Meaning: Environmental error. Unable to locate the entry point address for an EPNAME specification.</p> <p>Action: Verify that all parts of the product or application are currently installed.</p>
20	<p>Meaning: Program error. An EXTRACT request contains illogical information. For example:</p> <ul style="list-style-type: none"> • Neither an entry point address nor an EPNAME is specified. • Both an entry point address and an EPNAME are specified. • An SVC number is specified. • The entry point address specified is zero. <p>Action: Correct the error in the program that issued the macro. Verify that the execute form of the macro correctly references the list form.</p>
24	<p>Meaning: Environmental error. Unable to locate the SVC routine for the EXTRACT request.</p> <p>Action: Verify that all parts of the product or application are currently installed.</p>
28	<p>Meaning: System error. An error occurred while updating the SVC table.</p> <p>Action: Retry the request.</p>
44	<p>Meaning: Program error. A request was made to update an extended SVC, but no extended SVC routing code was provided.</p> <p>Action: When updating an extended SVC, use the ESR parameter to specify the extended SVC routing code.</p>
48	<p>Meaning: Program error. A request was made to update a non-extended SVC, but an extended SVC routing code was provided.</p> <p>Action: When updating a non-extended SVC, do not use the ESR parameter.</p>
52	<p>Meaning: Program error. A request was made to update an extended SVC, but the supplied SVC type did not match the system-defined type for that extended SVC.</p> <p>Action: When updating a non-extended SVC, use the TYPE parameter to specify the system-defined type for that particular extended SVC.</p>

Example 1

Delete SVC 200 from the SVC table.

```
SVCUPDTE 200,DELETE
```

Example 2

Insert SVC 201 in the SVC table. This is a type 2 SVC, with entry point at location SVCADDR. The SVC cannot be preempted for I/O interruptions.

```
SVCUPDTE 201,REPLACE,NPRMPT=NO,TYPE=2,EP=SVCADDR
```

Example 3

Replace SVC 202 in the SVC table. This is a type 1 SVC with entry point at the location in register 2.

```
SVCUPDTE 202,REPLACE,TYPE=1,EP=(2)
```

Example 4

Replace SVC 203 in the SVC table. SVC 203 is a type 4 SVC requiring the LOCAL lock. The routine has been loaded into LPA with the name MYSVC.

```
SVCUPDTE 203,REPLACE,TYPE=4,LOCKS=LOCAL,EPNAME=MYSVC
```

Example 5

Determine the SVC number associated with the name IGC062. The SVC number is to be returned in register 0.

```
SVCUPDTE ,EXTRACT,EPNAME=IGC062
```

Example 6

Replace SVC 202 in the SVC table. This is a type 3 SVC with entry point at explicit location X'FFEC00'. Note that this example uses a symbol as the SVC number.

```
SVCUPDTE  SVCNUM,REPLACE,TYPE=3,EP=X'FFEC00'
          .
          .
          .
SVCNUM    EQU    202
```

SVCUPDTE - List form

The list form of the SVCUPDTE macro builds a nonexecutable parameter list that can be referred to by the execute form of the SVCUPDTE macro.

Syntax

The list form of the SVCUPDTE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede SVCUPDTE.

Syntax	Description
SVCUPDTE	
<i>b</i>	One or more blanks must follow SVCUPDTE.
<i>num</i>	<i>num</i> : Symbol, decimal number, hexadecimal number (for example X'02').
	Note: This parameter must be specified on the execute and the list form of the macro. Do not specify <i>num</i> with EXTRACT.
,REPLACE	
,DELETE	
,EXTRACT	
,EXTRACTANY	
,TYPE=1	Note: TYPE is not valid with DELETE.
,TYPE=2	
,TYPE=3	
,TYPE=4	
,TYPE=6	
,EP= <i>addr</i>	<i>addr</i> : A-type address, decimal number, or hexadecimal number.
,EPNAME= <i>entry-name</i>	<i>entry-name</i> : Symbol
	Note: EP and EPNAME are not needed with the DELETE option. This parameter must be supplied on either the execute or the list form.
,LOCKS=(<i>lname, lname,...</i>)	<i>lname</i> : CMS or LOCAL.
	Note: This option is only valid with REPLACE and must not be specified with TYPE=6.
,APF=NO	Default: APF=NO
,APF=YES	Note: APF is only valid with REPLACE.
,AR=NO	Default: AR=NO
,AR=YES	Note: AR is valid only with REPLACE.
,NPRMPT=NO	Default: NPRMPT=NO

Syntax	Description
,NPRMPT=YES	Note: NPRMPT is only valid with REPLACE.
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.
,ESR= <i>esr</i>	<i>esr</i> : decimal number, or register (2) - (12).
,MF=L	

Parameters

The parameters are explained under the standard form of the SVCUPDTE macro with the following exception:

,MF=L

Specifies the list form of the SVCUPDTE macro.

Example 1

Use the list form of the macro to replace SVC 202 in the SVC table. It is a type 2 SVC with entry point at location SVCADDR. The SVC routine needs the local lock.

```
SVCUPDTE 202,REPLACE,TYPE=2,LOCKS=LOCAL,MF=L,EP=SVCADDR
```

Example 2

Use the list form of the macro to replace SVC 201 in the SVC table. The routine is a type 2 SVC.

```
SVCUPDTE 201,REPLACE,TYPE=2,MF=L
```

SVCUPDTE - Execute form

Syntax

The execute form of the SVCUPDTE macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SVCUPDTE.
SVCUPDTE	
␣	One or more blanks must follow SVCUPDTE.

Syntax	Description
<i>num</i>	<i>num</i> : Register (2) - (12).
	Note: This parameter must be supplied on either the execute or the list form of the macro with REPLACE or DELETE, and it must not be specified with EXTRACT.
,EP= <i>addr</i>	<i>addr</i> : Register (2) - (12).
	Note: This parameter must be supplied on either the execute or the list form of the macro. This parameter is not needed with the DELETE option.
,EPNAME= <i>epna</i>	<i>epna</i> : Register (2)-(12)
	Note: EP and EPNAME are not needed with the DELETE option. This parameter must be supplied on either the execute or the list form.
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.
,USEECVT=NO	Default: USEECVT=NO
,USEECVT=YES	
,MF=(E, <i>addr</i>)	<i>addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained under the standard form of the SVCUPDTE macro with the following exception:

,EPNAME=*epna*

Specifies the address, in register (2)-(12), of the entry name of the SVC routine.

,MF=(E,*addr*)

Specifies the execute form of the SVCUPDTE macro.

Example

Use the execute form of the SVCUPDTE macro to perform the function specified by the parameter list whose address is given in register 2.

```
SVCUPDTE MF=(E,(2))
```

Chapter 17. SWAREQ – Invoke SWA manager in locate mode

Description

The SWAREQ macro has no standard form. It only has a list, an execute, and a modify form. The MF parameter, which indicates the form of the macro, is required.

When you invoke this macro in execute form, it uses the two parameters, FCODE and EPA, to modify the parameter list, which is at the location you specify by the *addr* value in the MF=(E,*addr*) parameter. After ensuring the validity of the parameters, it invokes the SWA manager in locate mode. The SWA manager obtains its input from the parameter list, and performs the function associated with the specified FCODE. If you do not specify any parameters, the macro assumes the parameter list already exists, and it simply invokes the SWA manager.

The modify form of SWAREQ is functionally the same as the execute form, except that the macro only modifies the parameter list without invoking the SWA manager. The list form of SWAREQ generates the parameter list that is modified by the other two forms of the macro, and it does not invoke the SWA manager.

Environment

The requirements of callers when UNAUTH=NO (the default) is specified are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state and any PSW key.
Dispatchable unit mode:	Task.
Cross memory mode:	PASN=HASN=SASN.
AMODE:	24- or 31-bit.
ASC mode:	Primary.
Interrupt status:	Enabled for I/O and external interrupts.
Locks:	No locks may be held.
Control parameters:	Must be in the caller's primary address space.

The requirements of callers when UNAUTH=YES is specified are:

Environmental factor	Requirement
Minimum authorization:	Problem state and any PSW key.
Dispatchable unit mode:	Task or SRB. For SRB mode, see “Programming requirements” on page 162 for details.
Cross memory mode:	PASN=HASN=SASN, or for cross-memory mode, see “Programming requirements” on page 162 for details.
AMODE:	31-bit.
ASC mode:	Primary.
Interrupt status:	Enabled for I/O and external interrupts.
Locks:	The local lock or CMS lock may be held but are not required.

SWAREQ macro

Environmental factor

Requirement

Control parameters:

Must be in the caller's primary address space.

Programming requirements

The caller must include the following mapping macros:

- IEFZB505

When UNAUTH=YES is specified, invoke the IEFZB505 macro specifying LOCEPAX=YES, which generates a longer, 28-byte EPA.

- IEFJESCT
- CVT
- IEFQMIDS

When in cross-memory mode or SRB mode, you must pass the queue manager parameter area (QMPA) address to SWAREQ. In this case, obtain the QMPA address from the active JSCB for the primary address space and place this address in the EPAL that SWAREQ refers to by its input parameter. Note that when invoking SWAREQ in cross-memory mode, you may only obtain SWA information associated with the primary address space.

Restrictions

None.

Input register information

On input to the macro, register 13 must contain the address of a standard 18-word save area.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register

Contents

0-1

Used as work registers by the system.

2-12

Unchanged

13

If AMODE 31, then high bit will be cleared. If AMODE 24, then high byte will be cleared.

14

Unchanged

15

Return code

Performance implications

None.

ABEND codes

The caller of the SWAREQ macro might receive abend code X'0B0' with one of the following reason codes:

- X'04'
- X'08'

- X'0C'
- X'1C'
- X'20'
- X'24'
- X'28'
- X'34'

Register 0 will contain the address of a 16-byte area containing:

Bytes 1-4

Address of the QMPA.

Bytes 5-12

Not an intended programming interface; record this information and provide it to the appropriate IBM® support personnel.

Bytes 13-16

Address of the failing EPA.

See [z/OS MVS System Codes](#) for explanations and responses for these codes.

Return and reason codes

The hexadecimal return code is in register 15. When you specify UNAUTH=YES, the return codes have the following meanings:

Table 24. Return codes for the SWAREQ macro with UNAUTH=YES	
Return Code	Meaning
0	The SWAREQ service was successful.
8	The SVA in the SWA prefix was not valid.
24	The SVA does not correspond to any virtual address.
28	The pointer to the EPAL was not valid.

When you do not specify UNAUTH=YES, the return codes have the following meanings:

Table 25. Return codes for the SWAREQ macro	
Return Code	Meaning
0	The SWAREQ service was successful.
8	The SVA in the SWA prefix was not valid.
0C	You attempted to read a block that was not yet written.
10	The length for a SWA block was not valid.
1C	The block id was not valid.
20	The block pointer was not valid.
24	The SVA does not correspond to any virtual address.
32	The EPA provided by the caller was not built correctly.

SWAREQ - List form

Syntax

The list form of the SWAREQ macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede SWAREQ.
SWAREQ	
b	One or more blanks must follow SWAREQ.
,FCODE= <i>fnclde</i>	<i>fnclde</i> : Function code
,EPA= <i>addr</i>	<i>addr</i> : Address of the pointer to the EPA.
	In the list form, this address may only be specified symbolically.
,MF=L	

Parameters

The parameters are explained as follows:

,FCODE=*fnclde*

Specifies the function code for the locate mode request. Valid codes are:

RL

Read/Locate

WL

Write/Locate

For more information about the meaning of each code, see [z/OS MVS Programming: Authorized Assembler Services Guide](#).

,EPA=*addr*

Specifies the address of the pointer to the extended parameter area (EPA). Do not specify the EPA itself on the EPA parameter.

,MF=L

Specifies the list form of the SWAREQ macro.

SWAREQ - Execute form

Syntax

The execute form of the SWAREQ macro is written as follows:

Syntax	Description

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SWAREQ.
SWAREQ	
␣	One or more blanks must follow SWAREQ.
,FCODE= <i>fncde</i>	<i>fncde</i> : Function code
,EPA= <i>addr</i>	<i>addr</i> : External parameter area pointer address.
	It may be specified symbolically, as a register enclosed in parentheses, or as a symbol equated to a register enclosed in parentheses.
,UNAUTH=YES	Default: UNAUTH=NO.
,UNAUTH=NO	
,MF=(E, <i>addr</i>)	<i>addr</i> : RX-type address or register (1) - (12).

Parameters

The parameters are explained under the list form of the SWAREQ macro, with the following exceptions:

,UNAUTH=YES

,UNAUTH=NO

UNAUTH=YES specifies that the system is to invoke the unauthorized form of the SWA manager. The unauthorized form of the SWA manager provides the output of the RL function of the authorized SWA manager. If you also specify the FCODE parameter, the SWAREQ macro checks the syntax of the FCODE parameter but does not use the function code.

,MF=(E,*addr*)

E specifies the execute form of the SWAREQ macro, and **addr** specifies the address of the parameter list.

SWAREQ - Modify form

Syntax

The modify form of the SWAREQ macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.

Syntax	Description
b	One or more blanks must precede SWAREQ.
SWAREQ	
b	One or more blanks must follow SWAREQ.
,FCODE= <i>fncte</i>	<i>fncte</i> : Function code
,EPA= <i>addr</i>	<i>addr</i> : External parameter area pointer address.
	It may be specified symbolically, as a register enclosed in parentheses, or as a symbol equated to a register enclosed in parentheses.
,MF=(M, <i>addr</i>)	<i>addr</i> : RX-type address or register (1) - (12).

Parameters

The parameters are explained under the list form of the SWAREQ macro, with the following exceptions:

,MF=(M,*addr*)

M specifies the modify form of the SWAREQ macro, and *addr* specifies the address of the parameter list.

Chapter 18. SWBTUREQ — Call SJF SWBTU processing services

Description

SWBTUREQ requests services for processing scheduler work block text units (SWBTUs). The RETRIEVE service can be requested on the SWBTUREQ macro. RETRIEVE obtains text unit information from SWBTUs for a specified set of keys and places the information in the output area defined by the caller.

An SWBTU is made up of JCL statement or dynamically created JCL information in contiguous text unit format. More than one SWBTU may be used to represent a single JCL statement.

Examples of the use of SWBTUREQ RETRIEVE are the JES sysout separator page installation exits. See the HASX01B member of SYS1.SHASSAMP for a sample exit.

For the RETRIEVE service, there are three calls that you can make:

- A call to determine the local working storage size needed for the service
- A call to determine the output area size needed to accommodate all the matched text units
- A call to obtain the text units that match the requested keys.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Problem state, and any PSW key. For SWBTUREQ RETRIEVE, the caller must have a PSW key that matches the key of the caller's storage.
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	Must be in the primary address space

Programming requirements

The caller must set up recovery for SWBTUREQ RETRIEVE. The caller must include the CVT and IEFJESCT mapping macros. IEFJSJTRP maps the storage for the required RETRIEVE service parameter list. [“SWBTUREQ RETRIEVE input parameters” on page 169](#) describes the parameter list's input fields. [“SWBTUREQ RETRIEVE output” on page 170](#) describes the fields that contain output on return from the SWBTUREQ RETRIEVE service.

The caller is responsible for supplying all storage for SWBTUREQ RETRIEVE processing. You can use SWBTUREQ RETRIEVE with different combinations of parameters to determine the local working storage size needed, and to determine and obtain the output area size needed for a particular request. A third combination of parameters allows you to invoke SWBTUREQ RETRIEVE to obtain text unit information. [Table 26 on page 169](#) lists the required combination of parameters to use based on the type of service call you are making.

Restrictions

None.

Input register information

On input to the SWBTUREQ macro, the caller must insure that general purpose register (GPR) 13 points to a standard, 72-byte save area.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register

Contents

0

If GPR 15 contains a zero, GPR 0 is used as a work register by the system. If GPR 15 contains return code 12, GPR 0 contains a reason code; otherwise, GPR 0 contains zero.

1

Used as a work register by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

Performance implications

None.

Syntax

The standard form of the SWBTUREQ macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
<code>_</code>	One or more blanks must precede SWBTUREQ
SWBTUREQ	
<code>_</code>	One or more blanks must follow SWBTUREQ
REQUEST= <i>service</i>	<i>service</i> : Service name
,PARM= <i>addr</i>	<i>addr</i> : RX-type address, or registers (2) - (12). Register 1 is the default.

Parameters

The parameters are explained as follows:

REQUEST=service

Specifies the SJF SWBTU service to be called. RETRIEVE is the valid service name.

,PARM=addr

Specifies the address of the parameter list for the service requested. The parameter list for the RETRIEVE service is IEFSJTRP. “SWBTUREQ RETRIEVE input parameters” on page 169 lists the parameter fields you must initialize.

SWBTUREQ RETRIEVE service

Use RETRIEVE to obtain text unit information for a specified set of JCL or output descriptor keys. The retrieved information is placed in a caller-defined output area.

Table 26. Parameter Combinations for SWBTUREQ RETRIEVE Functions	
Function	Required Parameters
Obtain local working storage size	SJTRID, SJTRVERS, SJTRLEN, SJTRSTOR, SJTRSTSZ, SJTRAREA, and SJTRSIZE. SJTRSTOR, SJTRSTSZ, SJTRAREA, and SJTRSIZE should be zero on this invocation.
Obtain output area size	SJTRID, SJTRVERS, SJTRLEN, SJTRSTOR, SJTRSTSZ, SJTRSWBN, SJTRSWBA, SJTRKIDN, SJTRKIDL. Fill in SJTRSTOR and SJTRSTSZ with the values returned when you invoked the macro to determine the local working storage size. SJTRAREA and SJTRSIZE should be zero on this invocation.
Retrieve requested keys	SJTRID, SJTRVERS, SJTRLEN, SJTRSTOR, SJTRSTSZ, SJTRSWBN, SJTRSWBA, SJTRKIDN, SJTRKIDL. Fill in SJTRSTOR, SJTRSTSZ, SJTRAREA, and SJTRSIZE with the values returned when you invoked the macro to determine the local working storage size and the output buffer size.

SWBTUREQ RETRIEVE input parameters

For each SWBTUREQ invocation, you need to initialize certain fields of parameter list IEFSJTRP. Figure 4 on page 171 illustrates some of the parameter fields and their relationships to other fields. The list below describes the valid value assignments for all input parameters in IEFSJTRP.

SJTRID

The identifier ‘SJTR’ of the SWBTUREQ RETRIEVE parameter list. Assign the symbolic equate SJTRCID to this field.

SJTRVERS

The current version number of the SWBTUREQ RETRIEVE service. Assign the symbolic equate SJTRCVER to this field.

SJTRLEN

The length of the SWBTUREQ RETRIEVE parameter list (IEFSJTRP). Assign the symbolic equate SJTRLGTH to this field.

SJTRSTOR

The local working storage pointer or zero.

SJTRSTSZ

The size of the local working storage area required by the service.

SJTRSWBN

The number of SWBTUs in the SWBTU address list table. The table is mapped by SJTRSBTL.

SJTRSWBA

The address of the SWBTU address list table from which text units are retrieved. The address list is mapped by SJTRSBTL.

SJTRAREA

The address of the text unit output area.

SJTRSIZE

The size of the text unit output area.

SJTRKIDN

The number of entries in the key list. The key list is mapped by SJTRKEYL.

SJTRKIDL

The address of the list of keys that are to be retrieved. The key list is mapped by SJTRKEYL.

SJTRSBTL

SWBTU address list from which text units are returned. The list contains one entry per SWBTU.

Parameter SJTRSWBN specifies the number of entries in the list; SJTRSWBA specifies the address of the list. More than one SWBTU may be used to represent a single JCL statement.

SJTRSTUP

An SWBTU address entry.

SJTRKEYL

The requested list of keys to be retrieved. Parameter SJTRKIDN specifies the number of entries in the list; SJTRKIDL specifies the address of this list.

SJTRKYID

The key to be used for the retrieve. If you are using the RETRIEVE service to obtain information about output descriptors, the key values for the attributes are defined in mapping macro IEFDOKEY. See *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary) for the mapping provided by IEFDOKEY. *z/OS MVS Programming: Authorized Assembler Services Guide* lists the dynamic output keys and their JCL equivalents.

SWBTUREQ RETRIEVE output

These parameters are returned with values on completion of RETRIEVE service processing.

SJTRREAS

The reason code returned. The reason codes are defined in [“Return and reason codes” on page 171](#).

SJTRWKSZ

The local working storage size required by the SWBTUREQ service.

SJTRTULN

The size of the area needed to contain all matched requested text units.

SJTRERRP

This field contains a zero unless a parameter list error (key list or SWBTU address entry error) occurs. In the case of a key list error (return code 8 with a reason code of 65), the address of the key list entry in error appears in the field. In the case of a SWBTU address entry error (return code 8 with a reason code of 19 or 28), the address of the SWBTU address entry in error appears in the field.

SJTRAREA

The address of the text unit output area. The text unit output area contains the matched text unit strings organized by key in the order they were requested. Matched text unit strings are contiguous in the text unit output area. For the mapping of each text unit see the IEFDOTUM mapping macro in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

SJTRKEYL

The requested key list. Parameter SJTRKIDN specifies the number of entries in the list; SJTRKIDL specifies the address of this list.

SJTRTPAD

The address of a text unit for this key in the output area. Values are returned in this field only if the key and text unit match. If the address is not found, this field is zero.




Figure 4. Relationship of Data and Work Areas Referenced in IEFSJTRP

ABEND codes

None.

Return and reason codes

Return codes appear in register 15. If you receive return code 12, the reason code appears in register 0. If you receive return codes 0, 4, or 8, the reason code appears in output field SJTRREAS. Return and reason codes are defined in macro IEFSJTRC. The hexadecimal return and reason codes from the SWBTUREQ RETRIEVE service are as follows:

Table 27. Return and Reason Codes for SWBTUREQ RETRIEVE		
Return Code	Reason Code	Meaning and Action
00	None	Meaning: RETRIEVE processing completed successfully. At least one text unit and key match was found. For any unmatched text units, the corresponding SJTRTPAD values are zero. Action: None.
04	None	Meaning: Either the caller did not provide enough storage for the service or none of the requested items was found. This is the expected return code if you issue the RETRIEVE request to obtain the working storage size or output area size.

Table 27. Return and Reason Codes for SWBTUREQ RETRIEVE (continued)

Return Code	Reason Code	Meaning and Action
	004	<p>Meaning: RETRIEVE requires more local working storage. The size of the local working storage, as specified in input parameter SJTRSTSZ, is not large enough for the service. The amount of local working storage needed appears in output parameter SJTRWKSZ.</p> <p>Action: Repeat the request and supply the amount of storage returned in SJTRWKSZ in SJTRSTSZ.</p>
	008	<p>Meaning: RETRIEVE requires more text unit output area storage. The size needed for the output storage area appears in output parameter SJTRTULN.</p> <p>Action: Repeat the request and supply the amount of storage returned in SJTRTULN in SJTRAREA.</p>
	064	<p>Meaning: Successful completion. None of the keys in the input key list were found in the SWBTUs. All corresponding SJTRTPAD values are zero. There are no returned text units in the output area.</p> <p>Action: None required.</p>
08	None	Meaning: The parameter list is not valid.
	015	Meaning: The parameter length specified in SJTRLEN is not valid for the specified version.
	016	Meaning: The version number specified is not correct for this service.
	018	<p>Meaning: The caller must provide at least one SWBTU. Input parameter SJTRSWBN must be greater than zero, and SJTRSWBA must reference the SWBTU address list.</p> <p>Action: Set SJTRSWBN to a value greater than zero; set SJTRSWBA to the address of the SWBTU address list.</p>
	019	<p>Meaning: The specified SWBTU is not valid. Either one of the entries is zero, or the SWBTU address entry is not valid. Output parameter SJTRERRP contains the address of the SWBTU address entry.</p> <p>Action: Specify a valid SWBTU referenced by the SWBTU address is in SJTRERRP.</p>
	01A	<p>Meaning: Program error. The text length shown in the DOCNTLEN field in the IEFDOTUM mapping macro is not valid. SWBTUREQ RETRIEVE processing stops. One possible cause of the problem is a storage overlay.</p> <p>Action: If your program has overlaid storage, correct the error and rerun the program. Otherwise, contact the appropriate IBM support personnel.</p>
	028	<p>Meaning: Either all of the verbs for the SWBTUs or all of the labels for the SWBTUs do not match. Output parameter SJTRERRP contains the address of the SWBTU address entry where the inconsistency was found.</p> <p>Action: Correct the SWBTU in the SWBTU address table entry whose address is in SJTRERRP.</p>
	029	<p>Meaning: The output area size, defined by the combination of the input parameters SJTRAREA and SJTRSIZE, is not valid. One of the parameters is zero and the other is not zero.</p> <p>Action: Set SJTRAREA and SJTRSIZE to values greater than 0. (See “SWBTUREQ RETRIEVE input parameters” on page 169.)</p>

Table 27. Return and Reason Codes for SWBTUREQ RETRIEVE (continued)

Return Code	Reason Code	Meaning and Action
	065	Meaning: The key entry is not valid. Input parameter SJTRKYID is zero. Output parameter SJTRERRP contains the address of the error key entry, SJTRKYID. Action: Correct the key in error (the key pointed to by SJTRKYID).
	066	Meaning: At least one key must be requested. Input parameter SJTRKIDN must be greater than zero and SJTRKIDL must reference the key entry list. Action: Set SJTRKIDN and SJTRKIDL to values greater than zero. (See input parameter description.)
0C	None	Meaning: A severe parameter list error occurred. The reason code appears in register 0.
	014	Meaning: An incorrect parameter ID was specified. SJTRID is not 'SJTR'. Action: See “SWBTUREQ RETRIEVE input parameters” on page 169 for SJTRID.
	015	Meaning: An incorrect parameter length was specified. SJTRLEN is not at least as large as the common parameter list size, 36 bytes. Action: See “SWBTUREQ RETRIEVE input parameters” on page 169 for SJTRLEN.
	016	Meaning: The version number is not correct. SJTRVERS is less than one. Action: See “SWBTUREQ RETRIEVE input parameters” on page 169 for SJTRVERS.
	017	Meaning: The service specified by SWBTUREQ REQUEST=service, is not known. Action: Specify a valid request for 'service'.
14	None	Meaning: SJF encountered a condition that would have caused an abend. If processing had continued, an abend would have occurred.
18	None	Meaning: The service routines for SWBTUREQ are not available.

Example

Invoke the SWBTUREQ RETRIEVE service to obtain text unit information for three output descriptor attributes (title, name, and room). Represent the output descriptor with SWBTU1 and SWBTU2. Use register 6 to contain the address of SWBTU1, and register 7 to contain the address of SWBTU2. Use AREA to define the text unit output area. Define the service's local working storage in LCLSTOR. Establish an ESTAE for a recovery environment.

On return, register 15 contains return code 0, register 0 contains reason code 0, and SJTRREAS contains reason code 0. The output areas from the service contain the following information:

- SJTRAREA contains two contiguous text units that were in the SWBTUs and were requested in the key list.
- SJTRWKSZ contains the size of local working storage required for the SWBTUREQ RETRIEVE service.
- SJTRTULN contains the size of the area used to return the two matched text units.
- SJTRKEYL contains unchanged SJTRKYIDs.
 - SJTRTPAD contains the pointers for the matched text units and zero for unmatched text units. For this example, SJTRTPAD's first entry points to the first text unit returned in the text unit output area. The

second entry contains zero, and the third entry points to the second text unit returned in the text unit output area.

```

*****
*
*      Fill in 3 requested keys in the key list, SJTRKEYL.
*
*****
*
*      XC      KEYLIST,KEYLIST      Initialize KEYLIST area
*      LA      R2,KEYLIST           Point to start of key list
*      USING   SJTRKEYL,R2         Establish addressability
*
*      MVC     SJTRKYID+0*SJTRKLEN,=Y(DOTITLE)  Title Key
*      MVC     SJTRKYID+1*SJTRKLEN,=Y(DONAME)   Name Key
*      MVC     SJTRKYID+2*SJTRKLEN,=Y(DOROOM)   Room Key
*
*****
*
*      Fill in 2 SWBTU pointers in SWBTU address list, SJTRSBTL.
*
*****
*
*      XC      SWBTULST,SWBTULST    Initialize SWBTU pointer list area
*
*      LA      R3,SWBTULST          Point to start of SWBTU pointer list
*      USING   SJTRSBTL,R3         Establish addressability
*
*      ST      R6,SJTRSTUP          Set address of first SWBTU in 1st
*                                  entry of SWBTU address list
*      LA      R3,SJTRSLen(,R3)     Point to second entry in SWBTU
*      ST      R7,SJTRSTUP          Set address of second SWBTU in 2nd
*                                  entry of SWBTU address list
*
*****
*
*      Fill in the SWBTUREQ RETRIEVE parameter list, IEFSJTRP.
*
*****
*
*      XC      SJTRP(SJTRLGTH),SJTRP  Clear the parameter list
*      MVC     SJTRID,=A(SJTRCID)    Parameter list ID
*      MVI     SJTRVERS,SJTRCVER     Parameter list version
*      LA      R4,SJTRLGTH           Get parameter list length
*      STH     R4,SJTRLEN            Set parameter list length
*
*      LA      R4,LCLSTOR            Get local working storage address
*      ST      R4,SJTRSTOR           Set local working storage address
*      LA      R4,STORLGTH           Get local working storage size
*      STH     R4,SJTRSTSZ           Set local working storage size
*
*      LA      R4,AREA               Get text unit output area address
*      ST      R4,SJTRAREA           Set text unit output area address
*      LA      R4,AREALGTH           Get text unit output area size
*      STH     R4,SJTRSIZE           Set text unit output area size
*
*      ST      R2,SJTRKIDL           Set key list address
*      LA      R4,KEYNUM             Get number of requested keys
*      STH     R4,SJTRKIDN           Set number of request keys
*
*      LA      R3,SWBTULST          Point to start of SWBTU pointer list
*      ST      R3,SJTRSWBA           Set address of SWBTU address list
*      LA      R4,SWBTUNUM           Get number of SWBTUs
*      STH     R4,SJTRSWBN           Set number of SWBTUs
*
*****
*
*      Set up Register 1 to point to a word of storage that
*      contains the address of the parameter list, IEFSJTRP.
*
*****
*
*      LA      R4,SJTRP              Address of
*      ST      R4,SJTRPPTR           the SWBTUREQ RETRIEVE
*      LA      R1,SJTRPPTR           parameter list
*
*****
*
*      Invoke the SWBTUREQ macro to retrieve the matched text units
*      for items in the requested key list.
*

```

```

*
*****
*
    SWBTUREQ REQUEST=RETRIEVE    Issue the SJF macro
*
*****
*
    Check for a zero return code.
*
*****
*
    LTR    R15,R15          Check service return code
    BNZ    NODATA          Go to nonzero return processing
*
    Code to process zero return code from SWBTUREQ ...
*
    .
*
    .
*
NODATA    DS      0H          Label used for branch when SWBTUREQ
*                               service returns with a nonzero
*                               return code.
*
    Code to process nonzero return code from SWBTUREQ...
*
    .
*
    .
*
*****
*
    Storage definitions
*
*****
*
    IEF SJTRP DSECT=N0          SWBTUREQ Retrieve parameter list
*
    SJTRP PTR DS      A          Field used to contain SJTRP address
*
    KEYLIST DS      CL24          Area mapped by SJTRKEYL:
*                               enough storage for 3 entries
*
    SWBTULST DS      CL16          Area mapped by SJTRSBTL:
*                               enough storage for 2 entries
*
    AREA      DS      CL600        Area used by SWBTUREQ service to move
*                               matched text units for output.
*                               600 bytes is large enough and was
*                               chosen at random.
    AREALGTH EQU    *-AREA        Size of AREA
*
    LCLSTOR DS      CL1000        Area used by SWBTUREQ service as
*                               local working storage.
    STORLGTH EQU    *-LCLSTOR     Size of LCLSTOR
*
*****
*
    Equates and Constants
*
*****
*
    R0      EQU    0          Register 0
    R1      EQU    1          Register 1
    R2      EQU    2          Register 2
    R3      EQU    3          Register 3
    R4      EQU    4          Register 4
    R15     EQU    15         Register 15
*
    SWBTUNUM EQU    2          Indicates number of SWBTUs
    KEYNUM   EQU    3          Indicates number of requested keys
*
    IEFDOKEY          Dynamic Output keys
    CVT   DSECT=YES   CVT mapping macro
    IEFJESCT          IEFJESCT mapping macro

```


Chapter 19. SYNCH and SYNCHX – Take a synchronous exit to a processing program

Description

The SYNCH macro takes a synchronous exit to a processing program. After the processing program has been executed, the program that issued the SYNCH macro regains control. The SYNCH macro is also described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP* with the exception of the KEYADDR, STATE, KEYMASK, and XMENV parameters. These parameters are restricted to programs in supervisor state, key 0-7, or APF-authorized.

The SYNCH macro is intended for use by primary mode programs only. If your program runs in access register (AR) mode, use SYNCHX, which provides the same function as SYNCH. Descriptions of SYNCH and SYNCHX are:

- The standard form of the SYNCH macro, which includes general information about the SYNCH and SYNCHX macros and some specific information about the SYNCH macro. The syntax of the SYNCH macro is presented, and all SYNCH parameters are explained.
- The standard form of the SYNCHX macro, which presents information specific to the SYNCHX macro and callers in AR mode.
- The list form of the SYNCH and SYNCHX macros.
- The execute form of the SYNCH and SYNCHX macros.

If the caller is in AR mode, the system passes the following values, unchanged, to the processing program:

- ARs 0-13
- Bits 16 and 17 of the current PSW indicating the ASC mode (primary or AR mode, where primary=secondary=home)
- Extended authorization index (EAX)

Parameters for SYNCH and SYNCHX must be in the caller's primary address space. Callers in AR mode must initialize AR 1 to zero before issuing SYNCHX.

Note: The SYNCH and SYNCHX macros have the same environment specifications, register information, programming requirements, restrictions and limitations, performance implications, and return and reason codes described below, except where noted in the explanation for SYNCHX.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Problem state and any PSW key.
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit for SYNCH; 24- or 31- or 64-bit for SYNCHX.
ASC mode:	Primary
Interrupt Status:	Enabled for I/O and external interrupts
Locks:	No locks held

Environmental factor**Control parameters:****Requirement**

Must be in the primary address space.

Programming requirements

None.

Restrictions

None.

Register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the GPRs contain:

Register**Contents****0-1**

Values the processing program placed there before it returned to the caller

2-13

If RESTORE=YES, unchanged

If RESTORE=NO, values the processing program placed there before it returned to the caller

14

Used as a work register by the system

15

Value the processing program placed there before it returned to the caller

Syntax

The SYNCH macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
 	One or more blanks must precede SYNCH.
SYNCH	
 	One or more blanks must follow SYNCH.
<i>entry point addr</i>	<i>entry point addr</i> : RX-type address, or register (2) - (12) or (15).

Syntax	Description
,RESTORE=NO	Default: RESTORE=NO
,RESTORE=YES	
,KEYADDR= <i>addr</i>	<i>addr</i> : RS-type address, or register (2) - (12).
,KEYADDR=NOKEYADDR	Default: KEYADDR=NOKEYADDR
	(The key in the TCB is used.)
,STATE=PROB	Default: STATE=PROB
,STATE=SUPV	
,KEYMASK= <i>addr</i>	<i>addr</i> : RX-type address, or register (0) - (12).
,XMENV= <i>addr</i>	<i>addr</i> : RX-type address or register (0) - (12).
,AMODE=24	Default: AMODE=CALLER
,AMODE=31	Note: AMODE=DEFINED can only be specified if the entry point is provided in a register.
,AMODE=DEFINED	
,AMODE=CALLER	
,RMODE64=NO	Default: RMODE64=NO
,RMODE64=YES	Note: RMODE64=YES can be specified only with SYNCHX.

Parameters

The parameters are explained as follows:

entry point addr

Specifies the address of the entry point of the processing program to receive control.

,RESTORE=NO

,RESTORE=YES

Specifies whether registers 2-13 are to be restored when control is returned to the issuer of SYNCH.

,KEYADDR=*addr*

,KEYADDR=NOKEYADDR

addr specifies the address of a one-byte area that contains the key in which the exit is to receive control. The key must be in bits 0-3; bits 4-7 must be zero. If KEYADDR=*addr* is not specified, the key in the TCB is used as the default.

,STATE=PROB

,STATE=SUPV

Specifies the state in which the requested program receives control. PROB specifies problem state and SUPV specifies supervisor state.

,KEYMASK=addr

Specifies the address of a halfword, which along with the protect key of the currently active TCB, will be an operand in an OR instruction. The results of that instruction produce the PKM of the routine to which your program will take a synchronous exit.

If you specify KEYMASK, do not specify XMENV.

,XMENV=addr

Specifies the address of a parameter list that the caller passes to the SYNCH macro service. The parameter list contains values that set up a cross memory environment for the new PRB. The parameter list consists of either a 10-byte or 20-byte list of values that determine some of the characteristics the PRB will have when it receives control. The parameter list must reside in the primary address space and the AR that qualifies the address must be set to zero. The format of the parameter list is indicated by the length field in the first two bytes.

- If the length field in the first two bytes indicates a 10 (X'0A') byte parameter list, the format is as follows (mapped by DSECT XMENV in data area CSVXMENV):

Bytes	Content of field
0-1	The value X'0A'
2-3	PKM value, which along with the protect key of the currently active TCB, will be an operand in an OR instruction. The results of that instruction produce the PKM of the routine to which the synchronous is to be taken.
4-5	SASN - defining the secondary address space for the exit routine
6-7	Extended authorization index (EAX) for the exit routine
8-9	PASN - defining the primary address space for the exit routine

- If the length field in the first two bytes indicates a 20 (X'14') byte parameter list, the format is as follows (mapped by DSECT XMENV1 in data area CSVXMENV):

Bytes	Content of field
0-1	The value X'14'
2-3	PKM value, which along with the protect key of the currently active TCB, will be an operand in an OR instruction. The results of that instruction produce the PKM of the routine to which the synchronous is to be taken.
4-5	SASN - defining the secondary address space for the exit routine
6-7	Extended authorization index (EAX) for the exit routine
8-9	PASN - defining the primary address space for the exit routine
10-11	Reserved for IBM use
12-15	The primary ASTE instance number
16-19	The secondary ASTE instance number

If you specify XMENV, do not specify KEYMASK.

,AMODE=24**,AMODE=31****,AMODE=DEFINED****,AMODE=CALLER**

Specifies the addressing mode in which the requested program is to receive control.

If AMODE=24 is specified, the requested program will receive control in 24-bit addressing mode.

If AMODE=31 is specified, the requested program will receive control in 31-bit addressing mode.

If AMODE=DEFINED is specified, the user must provide the entry point using a register, not an RX-type address. The requested program will receive control in the addressing mode indicated by the high-order bit of the entry point address. If the bit is off, the requested program will receive control in 24-bit addressing mode; if the bit is set, the requested program will receive control in 31-bit addressing mode.

If AMODE=CALLER is specified, the requested program will receive control in the addressing mode of the caller.

,RMODE64=NO

,RMODE64=YES

Specifies whether the residency mode in which the requested program is to receive control is RMODE 64 or not.

When RMODE64=YES, the entry point address in a register is treated as an 8-byte address. An entry point address that is not in a register is treated as 8-bytes.

Example 1

Take a synchronous exit to a processing program whose entry point address is specified in register 8.

```
SYNCH (8)
```

Example 2

Take a synchronous exit to a processing program labeled SUBRTN and restore registers 2-13 when control is returned.

```
SYNCH SUBRTN,RESTORE=YES
```

Example 3

Take a synchronous exit to a processing program whose entry point address is specified in register 5, modify the program's protect key by the KEYADDR and KEYMASK values, and restore registers 2-13 when control returns.

```
SYNCH (5),RESTORE=YES,KEYADDR=KEYBYTE,KEYMASK=MSKADDR
.
.
KEYBYTE DC X'80'
MSKADDR DC X'0080'
```

Example 4

Take a synchronous exit to the program located at the address given in register 8 and restore registers 2-13 when control returns. Indicate that this program is to execute in 24-bit addressing mode.

```
SYNCH (8),RESTORE=YES,AMODE=24
```

SYNCHX - Take a synchronous exit to a processing program

The SYNCHX macro allows a program running in primary or AR mode to take a synchronous exit to a processing program. This macro is the same as the SYNCH macro, except that, for callers in AR mode, it generates code and addresses that are appropriate in AR mode. All parameters on the SYNCH macro are valid for the SYNCHX macro.

You can issue the SYNCHX macro in 64-bit addressing mode. However, AMODE=DEFINED can only be used to SYNCHX to amode 24 or amode 31 programs.

Before you issue the SYNCHX macro, issue the SYSSTATE ASCENV=AR macro to tell the SYNCHX macro to generate code appropriate for AR mode.

Syntax

The SYNCHX macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede SYNCHX.
SYNCHX	
␣	One or more blanks must follow SYNCHX.
<i>entry point addr</i>	<i>entry point addr</i> : RX-type address, or register (2) - (12) or (15).
,RESTORE=NO	Default: RESTORE=NO
,RESTORE=YES	
,KEYADDR= <i>addr</i>	<i>addr</i> : RX-type address, or register (2) - (12).
,KEYADDR=NOKEYADDR	Default: KEYADDR=NOKEYADDR (The key in the TCB is used.)
,STATE=PROB	Default: STATE=PROB
,STATE=SUPV	
,KEYMASK= <i>addr</i>	<i>addr</i> : RX-type address, or register (0) - (12).
,XMENV= <i>addr</i>	addr : RX-type address or register (0) - (12).
,AMODE=24	Default: AMODE=CALLER
,AMODE=31	
,AMODE=64	
,AMODE=DEFINED	Note: AMODE=DEFINED can only be specified if the entry point is provided in a register. AMODE=DEFINED can only be used to SYNCHX to amode 24 and amode 31 programs.
,AMODE=CALLER	

Parameters

The parameters are described under the syntax of the standard form of the SYNCH macro. If AMODE=64 is specified, the requested program will receive control in 64-bit addressing mode.

SYNCH and SYNCHX - List form

The list form of the SYNCH or SYNCHX macro is used to construct a control program parameter list.

Syntax

The list form of the SYNCH or SYNCHX macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede SYNCH or SYNCHX.
SYNCH or SYNCHX	
b	One or more blanks must follow SYNCH or SYNCHX.
,RESTORE=NO	Default: RESTORE=NO
,RESTORE=YES	
,STATE=PROB	Default: STATE=PROB
,STATE=SUPV	
,KEYMASK= <i>addr</i>	<i>addr</i> : A-type address.
,XMENV= <i>addr</i>	<i>addr</i> : RX-type address or register (0) - (12).
,AMODE=24	Default: AMODE=CALLER
,AMODE=31	
,AMODE=DEFINED	
,AMODE=CALLER	
,MF=L	

Parameters

The parameters are explained under the standard form of the SYNCH macro with the following exception:

,MF=L

Specifies the list form of the SYNCH macros.

Example

Use the list form of the SYNCH macro to specify that registers 2-13 are to be restored when control returns from executing the SYNCH macro and that the addressing mode of the program is to be defined by the high-order bit of the entry point address. Assume that the execute form of the macro specifies the program address.

```
SYNCH ,RESTORE=YES,AMODE=DEFINED,MF=L
```

SYNCH and SYNCHX - Execute form

The execute form of the SYNCH or SYNCHX macro uses a remote program parameter list that can be generated by the list form of SYNCH or SYNCHX.

Syntax

The execute form of the macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede SYNCH or SYNCHX.
SYNCH	
b	One or more blanks must follow SYNCH or SYNCHX.
<i>entry point addr</i>	<i>entry point addr</i> : RX-type address, or register (2) - (12) or (15).
,RESTORE=NO	
,RESTORE=YES	
,KEYADDR= <i>addr</i>	<i>addr</i> : RX-type address, or register (2) - (12).
,KEYADDR=NOKEYADDR	
,STATE=PROB	
,STATE=SUPV	
,KEYMASK= <i>addr</i>	<i>addr</i> : RX-type address, or register (0) - (12).
,XMENV= <i>addr</i>	<i>addr</i> : RX-type address or register (0) - (12).

Syntax	Description
,AMODE=24	Note: AMODE=DEFINED can only be specified if the entry point is provided in a register.
,AMODE=31	
,AMODE=DEFINED	
,AMODE=CALLER	
,MF=(E,ctrl addr)	ctrl addr: RX-type address or register (1), (2) - (12).

Parameters

The parameters are explained under the standard form of the SYNCH macro with the following exceptions:

,KEYADDR=NOKEYADDR

Indicates that the default(the key in the TCB) should be used instead of the key in the parameter list defined by a list form of the macro.

,MF=(E,ctrl addr)

Specifies the execute form of the SYNCH macro using a list generated by the list form of SYNCH.

Example

Use the execute form of the SYNCH macro to take a synchronous exit to the program located at the address given in register 8 and restore registers 2-13 when control returns. Indicate that the program is to receive control in the same addressing mode as the caller and that the parameter list is located at SYNCHL2.

```
SYNCH (8),RESTORE=YES,AMODE=CALLER,MF=(E,SYNCHL2)
```


Chapter 20. SYSEVENT – System event

Description

The SYSEVENT macro provides the interface to the system resource manager (SRM). Using SYSEVENT mnemonics, you can:

- Notify SRM of an event
- Ask SRM to perform a specific function

Environment

The requirements for the ENTRY=BRANCH caller are:

Environmental factor	Requirement
Authorization:	Supervisor state and PSW key 0 - 7
Dispatchable unit mode:	Task or SRB.
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	Callers that specify ENTRY=BRANCH must hold the LOCAL lock for TRAXRPT, TRAXFRPT and TRAXERPT. There are no locking requirements for the other SYSEVENTs.

The requirements for the ENTRY=SVC caller are:

Environmental factor	Requirement
Authorization:	APF authorized
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locking requirements

The requirements for the ENTRY=UNAUTHPC caller are:

Environmental factor	Requirement
Authorization:	Problem state and PSW key 8 - 15
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	31- or 64-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts

Environmental factor	Requirement
Locks:	No locks held

The following SYSEVENTs are unauthorized:

- FREEAUX
- QRYCONT only with ENTRY=UNAUTHPC
- QVS
- REQFASD
- REQLPDAT only with ENTRY=UNAUTHPC
- STGTEST only with ENTRY=SVC.

The requirements are:

Environmental factor	Requirement
Authorization:	Problem state or key 8-15

All other requirements are as noted above for ENTRY=BRANCH, ENTRY=SVC, and ENTRY=UNAUTHPC.

Programming requirements

When you specify ENTRY=BRANCH, include the CVT mapping macro as a DSECT in the calling program. If a specific SYSEVENT requires a parameter list in addition to the information specified on the macro invocation, load register 1 with the address of that parameter list before issuing the macro.

Restrictions and limitations

Parameter lists that are accessed by authorized SYSEVENTs have the following requirements:

- The parameter list must be non-pageable and addressable using the caller's primary address space.
- The parameter list must be in 31-bit addressable storage (below the bar).

For additional restrictions on the use of each SYSEVENT, including input and output requirements, refer to the descriptions of the parameters.

Input register information

When you specify ENTRY=BRANCH, register 13 must contain the address of a 72-byte save area on input. For specific input register requirements, see the description of the specific SYSEVENT.

Output register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the general purpose registers (GPRs) contain:

Register Contents

0

Used as a work register by the system

1

One of the following:

- Status code (for DONTSWAP, OKSWAP, and TRANSWAP SYSEVENTs)

- Unchanged for all other SYSEVENTs

2-13

Unchanged

14

Used as a work register by the system

15

One of the following:

- Used as a work register by the system (for DONTSWAP, OKSWAP, and TRANSWAP SYSEVENTs)
- Return code for all other SYSEVENTs

Syntax

The SYSEVENT macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
<code>_</code>	One or more blanks must precede SYSEVENT.
SYSEVENT	
<code>_</code>	One or more blanks must follow SYSEVENT.
<i>sysevent mnemonic</i>	<i>sysevent mnemonic</i> : symbol.
	Note: See the description of the parameters for the valid options.

Syntax	Description
,ENTRY=SVC ,ENTRY=BRANCH ,ENTRY=UNAUTHPC	Defaults: DONTSWAP SVC (BRANCH possible) ENCASSOC BRANCH ENCSTATE BRANCH ENQHOLD SVC (BRANCH possible) ENQRLSE SVC (BRANCH possible) FREEAUX BRANCH (unauthorized BRANCH) OKSWAP SVC (BRANCH possible) QRYCONT SVC (BRANCH and UNAUTHPC possible) QVS BRANCH (unauthorized BRANCH) REQASCL SVC (BRANCH possible) REQASD SVC (BRANCH possible) REQFASD BRANCH (unauthorized BRANCH) REQLPDAT SVC (BRANCH and UNAUTHPC possible) REQSRMST SVC (BRANCH possible) STGTEST SVC (BRANCH possible) TRANSWAP SVC (BRANCH possible) TRAXERPT BRANCH (unauthorized BRANCH) TRAXFRPT BRANCH (unauthorized BRANCH) TRAXRPT BRANCH (unauthorized BRANCH)
,TYPE= <i>type value</i>	Note: <ol style="list-style-type: none"> The ENCASSOC, ENQHOLD, ENQRLSE, and REQFASD SYSEVENTs support the TYPE parameter. For valid <i>type values</i> refer to the descriptions of the specific SYSEVENT: <ul style="list-style-type: none"> For ENCASSOC, see “Associate an enclave with an address space (ENCASSOC)” on page 203. For ENQHOLD, see “Identify holder of a resource (ENQHOLD)” on page 201. For ENQRLSE, see “Identify that a holder has released resource (ENQRLSE)” on page 203. For REQFASD, see “Obtain address space related information (REQASD and REQFASD)” on page 198.
,ASID= <i>asid</i>	Address space ID
,ASIDL= <i>asidl</i>	

Parameters

The parameters are explained as follows:

sysevent mnemonic

Identifies the SYSEVENT being requested. The valid options are:

- DONTSWAP,
- ENCASSOC
- ENCSTATE

- ENQHOLD
- ENQRLSE
- FREEAUX
- OKSWAP
- QRYCONT
- QVS
- REQASCL
- REQASD
- REQFASD
- REQLPDAT
- REQSRMST
- STGTEST
- TRAXERPT
- TRAXFRPT
- TRAXRPT
- TRANSWAP

See [“SYSEVENT mnemonics”](#) on page 192 for a description of these options.

,ENTRY=SVC

,ENTRY=BRANCH

,ENTRY=UNAUTHPC

Specifies the instruction used to pass control to SRM.

Only users who do not hold a lock can specify ENTRY=SVC.

Branch entry is required when the caller holds a lock. It is also the only supported entry for ENCASSOC, ENCSTATE, FREEAUX, QVS, REQFASD, TRAXERPT, TRAXFRPT, and TRAXRPT.

Use the UNAUTHPC entry to call SYSEVENTs from an unauthorized environment or to pass a parameter list located above the bar. If your application is performance critical or issues the SYSEVENT many times a second, use ENTRY=SVC or ENTRY=BRANCH.

,TYPE=type value

Note:

1. The ENCASSOC, ENQHOLD, ENQRLSE, and REQFASD SYSEVENTs support the TYPE parameter.
2. For valid *type values* refer to the descriptions of the specific SYSEVENT:
 - For ENCASSOC, see [“Associate an enclave with an address space \(ENCASSOC\)”](#) on page 203.
 - For ENQHOLD, see [“Identify holder of a resource \(ENQHOLD\)”](#) on page 201.
 - For ENQRLSE, see [“Identify that a holder has released resource \(ENQRLSE\)”](#) on page 203.
 - For REQFASD, see [“Obtain address space related information \(REQASD and REQFASD\)”](#) on page 198.

,ASID=register

,ASIDL=asid

Specifies the address space identifier in ASIDL=*asid*, or the register containing the address space identifier in ASID=*register*. Either ASIDL or ASID is required for REQASD and REQFASD.

When a program issues a SYSEVENT with an ASID parameter of another address space, an ABEND 15F-30 might occur. To minimize the possibility of an ABEND 15F-30, check for a valid OUCB pointer (ASCBUCB > 0) of the address space prior to the SYSEVENT invocation.

SYSEVENT mnemonics

The following sections describe all SYSEVENT mnemonics that are supported. The mnemonics are grouped according to the function that they perform.

Notify SRM of transaction completion (TRAXRPT, TRAXFRPT, TRAXERPT)

The SYSEVENTs TRAXRPT, TRAXFRPT, and TRAXERPT notify SRM that a subsystem transaction has completed and provide the transaction's starting time or elapsed time and, optionally, its resource utilization. This performance data can be reported using the resource management facility (RMF).

You should use the workload management services to notify SRM of transaction start and completion times, as well as notifying SRM of transaction delays encountered. For more information, see [z/OS MVS Programming: Workload Management Services](#).

In addition to the general requirements for SYSEVENTs, TRAXRPT, TRAXFRPT, and TRAXERPT require the user to:

- Provide a parameter list
- If the issuing program is disabled, ensure that the parameter list and save area are fixed
- Provide error recovery

The mnemonics are explained as follows:

TRAXRPT

Notifies SRM that a transaction has completed and provides its start time. Register 1 must point to a serialized parameter list with the following format:

Offset in Hex	Length	Field Description
00	8	Transaction start time in store clock instruction (STCK) format
08	8	Subsystem name
10	8	Transaction name or blanks
18	8	User identification (USERID) or blanks
20	8	Transaction class or blanks

The names must be in EBCDIC format, left-justified, and padded with blanks. Note that the subsystem name is restricted to four characters in length even though the parameter list provides an eight-character field. Use the first four characters of the field for the subsystem name.

TRAXFRPT

Notifies SRM that a transaction has completed and provides the elapsed time. Because the issuer calculates the elapsed time before issuing the macro, this path is shorter than the path for TRAXRPT. Register 1 must point to a serialized parameter list with the following format:

Offset in Hex	Length	Field Description
00	4	Transaction elapsed time (1.024 milliseconds units)
04	4	Zero
08	8	Subsystem name
10	8	Transaction name or blanks
18	8	User identification (USERID) or blanks

Offset in Hex	Length	Field Description
20	8	Transaction class or blanks

Note: To map the parameter list, use the IHATRBPL mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

The names must be in EBCDIC format, left-justified, and padded with blanks. Note that the subsystem name is restricted to four characters in length.

TRAXERPT

Notifies SRM that a transaction has completed, provides its start time, and includes resource utilization data for determining service consumption. Register 1 must point to a serialized parameter list in the following format:

Offset in Hex	Length	Field Description
00	8	Transaction start time in STCK format
08	8	Subsystem name
10	8	Transaction name or blanks
18	8	User identification (USERID) or blanks
20	8	Transaction class or blanks
28	8	Task (TCB) time in STCK format or zeros
30	8	SRB time in STCK format or zeros
38	8	Main storage occupancy in page seconds (pages times msec, where msec is task (TCB) time in 1.024 millisecond units)
40	4	Logical I/O count or zeros
44	1	X'00' if the previous field contains the logical I/O count, X'80' if the previous field contains the device connect time interval (DCTI)
45	3	Reserved must be zero

Note: To map the parameter list, use the IHATREPL mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

The names must be in EBCDIC format, left-justified, and padded with blanks. Note that the subsystem name is restricted to four characters in length.

Return and reason codes

When processing is completed for TRAXRPT, TRAXFRPT, and TRAXERPT SYSEVENTs, the subsystem regains control at the instruction following the SYSEVENT macro. The last byte of register 15 contains one of the following hexadecimal return codes:

Table 28. Return Codes for the SYSEVENT Macro	
Return Code	Meaning
00	Data for the transaction has been reported successfully to the SRM.
08	Processing could not be completed at this time. No queue elements are available for recording the data. No data is reported to the SRM, but an immediate reissue could be successful.

Table 28. Return Codes for the SYSEVENT Macro (continued)

Return Code	Meaning
0C	Reporting is temporarily suspended for one of the following reasons: <ul style="list-style-type: none"> RMF workload activity reporting is not active. The TOD clock is stopped. No data is reported, but a later reissue could be successful.
10	Reporting is inoperative. The TOD clock is in error or the reporting interface is not installed. No data is reported.

Example 1

Use the SYSEVENT TRAXRPT to report transaction data providing transaction identifiers and the transaction start time. In the following example, TRAXDESC is the name of a storage area that is initialized with the subsystem name, transaction name, user ID and class information needed to pass to SRM:

```

      .
      .
      .
Transaction begins      Initialize transaction identifiers
      (TRAXDESC)
      STCK INITTIME      Save start time
      .
Process transaction
Transaction completes
      LA R13,SVAREA      Provide 72-byte save area
      LA R1,PARMS         Point to parameter area
      MVC 0(8,R1),INITTIME Move in start time
      MVC 8(32,R1),TRAXDESC Get subsystem name, transaction
                           name, user ID, and class
      SYSEVENT TRAXRPT
      .
      .
      INITTIME DS D
      PARMS    DS 5D
      SVAREA   DS 18F
      TRAXDESC DS CL40

```

Example 2

Use the SYSEVENT TRAXERPT to report transaction data, providing transaction identifiers, start time and resource utilization data. In the following example, TRAXDESC is the name of a storage area that is initialized with the subsystem name, transaction name, user ID and class information needed to pass to SRM:

```

      .
      .
      .
Transaction begins      Initialize transaction identifiers
      (TRAXDESC)
      STCK INITTIME      Save start time
      .
Process transaction      Accumulate resource utilization data
      (TRAXDESC)
      .
Transaction completes
      LA R13,SVAREA      Provide 72-byte save area
      LA R1,PARMS         Point to parameter area
      MVC 0(8,R1),INITTIME Move in start time
      MVC 8(64,R1),TRAXDESC Get subsystem name, transaction
                           name, user ID, class, and
                           resource utilization data
      SYSEVENT TRAXERPT
      .
      .
      .
      INITTIME DS D
      PARMS    DS 9D
      SVAREA   DS 18F
      TRAXDESC DS CL72

```


Example 3

Use the SYSEVENT TRAXFRPT to report transaction data, providing transaction identifiers and calculating the elapsed time. In the following example, TRAXDESC is the name of a storage area that is initialized with the subsystem name, transaction name, user ID and class information needed to pass to SRM:

```

.
.
Transaction begins      Initialize transaction identifiers (TRAXDESC)
.
.
Process transaction     Calculate elapsed time (TOTLTIME)
.
Transaction completes   Calculate elapsed time (TOTLTIME)
LA  R13,SVAREA          Provide 72-byte save area
LA  R1,PARMS            Point to parameter area
MVC 0(4,R1),TOTLTIME     Move in elapsed time
XC  4(4,R1),4(R1)        Clear reserved field
MVC 8(32,R1),TRAXDESC    Get subsystem name, transaction name,
                        user ID, and class
SYSEVENT TRAXFRPT
.
.
.
TOTLTIME DS F
PARMS     DS 5D
SVAREA    DS 18F
TRAXDESC  DS CL40

```

Control swapping (DONTSWAP, OKSWAP, TRANSWAP)

The SYSEVENTs DONTSWAP, OKSWAP, and TRANSWAP control swapping. The choice of mnemonic depends on the period of time for which the address space is to be non-swappable.

For a short period of time (less than one minute), use DONTSWAP to make it non-swappable and OKSWAP to make it swappable.

For an extended period of time (more than one minute), use TRANSWAP to make the address space non-swappable and OKSWAP to make it swappable.

Note: If you specify an ASID with DONTSWAP, OKSWAP, or TRANSWAP, that ASID must specify the home address space. This means, you can only control swapping in the address space in which the SYSEVENT is issued. If you specify another address space the request cannot be carried out.

The mnemonics are explained as follows:

DONTSWAP

Notifies SRM that the address space from which this SYSEVENT is issued cannot be swapped out until the system receives a matching OKSWAP for each DONTSWAP issued or until the jobstep ends.

No input parameters are required. One of the following codes will be returned in register 1, byte 3:

Hexadecimal Code	Meaning
00	The request was honored.
04	The request was not honored because it was not for the current address space.
08	The request was not honored because the issuer was not authorized or the outstanding count of DONTSWAP requests had reached its maximum.

OKSWAP

Notifies SRM that the address space from which the SYSEVENT was issued can be considered for swapping.

No input parameters are required. One of the following codes will be returned in register 1, byte 3:

Hexadecimal Code	Meaning
00	The request was honored.

Hexadecimal Code	Meaning
04	The request was not honored because it was not for the current address space.
08	The request was not honored because the issuer was not authorized.

TRANSWAP

Forces a swap out. After the subsequent swap-in, frames are allocated from preferred storage and the address space is non-swappable. TRANSWAP prevents programs from allocating frames in reconfigurable storage. If the program issuing SYSEVENT depends on the transition to complete, you should ensure that register 1 contains the address of an ECB. SYSEVENT will then post this ECB when it swaps out the address space. If no dependency exists, set register 1 to 0 (zero).

One of the following codes will be returned in register 1, byte 3:

Hexadecimal Code	Meaning
00	The request was honored. If an ECB was specified, your program should issue a WAIT macro specifying the same ECB.
04	The transition was previously done or the address space is permanently non-swappable. If an ECB was specified it will not be posted.

If an ECB was specified, the following POST codes may occur in the last three bytes of the ECB:

Hexadecimal Code	Meaning
000000	The transition is complete.
000004	The address space became non-swappable before it could be swapped out.

Example 1

To make the current address space non-swappable for a time period of less than one minute, specify the following:

```
SYSEVENT DONTSWAP
      .
      .
      .
SYSEVENT OKSWAP
```

Example 2

To make the current address space non-swappable for an indefinite period of time, specify the following:

```
SYSEVENT TRANSWAP
ST      1, RETCODE
CLI     TSWP_RC, 0
BNE     FAILED
WTO     'TSWP SUCCESSFUL'
      .
      .
      .
B       DONE
FAILED EQU *
WTO     'TSWP UNSUCCESSFUL (BAD RC)'
DONE    EQU *
      .
      .
      .
RETCODE DS 0F
DS      CL3
TSWP_RC DS FL1
```

Obtain system measurement information (STGTEST)

The STGTEST SYSEVENT provides information about the current physical use of resources. This is not an indication of how much virtual storage your installation allows you to obtain. For more information on obtaining virtual storage for hiperspaces or data spaces, see DSPSERV.

The user must supply the address of a storage area large enough to store the requested data.

STGTEST

Returns information about the amount of storage available in the system. The purpose of SYSEVENT STGTEST is to help an application decide whether to use an additional virtual storage area, such as a hiperspace.

When you use this information, be aware of the dynamic nature of storage.

The output of the SYSEVENT STGTEST only reflects the current state of storage and does not reserve this storage for the caller, or guarantee that it is available for use.

Note: When the address space which issues the SYSEVENT STGTEST is associated with a memory pool, the values in the output area reflect the current state of the memory pool and not the state of the system storage. Refer to *z/OS MVS Initialization and Tuning Guide* for more information on managing WLM resource groups and memory pools.

Register 1 must contain the address of a three-word output area where SRM is to return the information. After SRM returns, each word contains a storage amount that represents a specific number of frames. Before you choose a number to use as the basis for decision, be aware of how your decision affects the performance of the system. The meaning of the returned values is:

- Use of the first number affects system performance little, if at all.
- Use of the second number might affect system performance to some degree.
- Use of the third number might substantially affect system performance.

If you base decisions on the value in the second or third word, SRM can take processor storage away from other programs and replace it with auxiliary storage.

Note: Currently, the value returned in the third word is always the same as the value returned in the second word.

Note: Address spaces, which are members of a WLM resource group and has a memory limit are subject to various memory pool thresholds and the associated system actions. These address spaces are independent of the values returned by STGTEST. Refer to *z/OS MVS Initialization and Tuning Guide* for more information on managing WLM resource groups and memory pools.

Example

An application needs a standard hiperspace. Before it makes the request, the application uses SYSEVENT STGTEST to find out how much storage is available. The values that SRM returns determine how large a hiperspace the application creates.

To obtain a report on the storage available in the system, specify the following:

```
LA 1,ESPARM
SYSEVENT STGTEST
.
ESPARM DS 3F
```

The application bases its decision on the numbers in the first and second words of the output area.

Obtain address space classification information (REQASCL)

The REQASCL SYSEVENT provides information about an address space's classification information. You must specify the address space id (ASID) with either the ASID=*register* or the ASIDL=*asid* parameter.

The user must supply the address of a storage area large enough to hold the requested data.

REQASCL

Returns classification information about an address space.

The name is in EBCDIC format, left-justified, and padded with blanks.

Input register information

Register 1 must point to a parameter list, as mapped by the IRARASC macro. The parameter list for REQASCL must be non-pageable and addressable via the caller's primary address space. To map the parameter list for REQASCL, use the IRARASC mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary). The caller must set the RASC_ACRO, RASC_VERSION, and RASC_LENGTH fields. The IRARASC macro defines constants for this purpose. The following table lists the constants which contain the correct values for each field:

Table 29. Fields and constants	
Field	Constant
RASC_ACRO	RASC_ID_CONSTANT
RASC_VERSION	RASC_CURRENTVERSION
RASC_LENGTH	RASC_CURRENTVERSION_LEN

Return and reason codes

When processing is complete for the REQASCL, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 30. Return Codes for REQASCL	
Return Code	Meaning
00	Successful completion.
04	Classification information returned may not reflect how the address space is being managed.
08	Input parameter list is not properly initialized (eyecatcher, version or size specified is too small).
12	Classification information is not available.

Obtain address space related information (REQASD and REQFASD)

The SYSEVENTs REQASD and REQFASD provide information about an address space's workload activity. You must specify the address space id (ASID) with either the ASID=*register* or the ASIDL=*asid* parameter.

Both return the same kind of information. REQFASD is quicker; it does not serialize data collection, and does not provide recovery of its own. The user must provide the recovery for REQFASD.

The user must supply the address of a storage area large enough to hold the requested data.

REQASD

Returns workload activity information about an address space.

REQFASD

Returns the same information as REQASD, but is a fast path SYSEVENT, with no recovery of its own.

TYPE=SIZECHECK

Required parameter which activates work area size checking and should always be specified.

Input register information

REQASD

For REQASD, register 1 must point to a parameter list. The parameter list must be non-pageable and addressable via the caller's primary address space. To map the parameter list, use the IRARASD mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

The RASDLEN field must be filled in with the length of the RASD parameter list area that is to be used by the SYSEVENT. The constant RASDSIZE can be used to fill in the RASDLEN field.

REQFASD

For REQFASD, register 1 must point to a parameter list. The parameter list must be addressable via the caller's primary address space. To map the parameter list, use the IRARASD mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourceLink/svc00100.nsf/pages/zosInternetLibrary).

The RASDLEN field must be filled in with the length of the RASD parameter list area that is to be used by the SYSEVENT. The constant RASDSIZE can be used to fill in the RASDLEN field.

SYSEVENT REQFASD requires a workarea for the processing. The size of the workarea can be found in the constant RQFASDWA, which is defined in the IRARASD mapping. Additionally, it is necessary to fill the RASDWALEN with the provided workarea length. Prior to executing REQFASD, register 13 must point to a workarea. The workarea must be addressable via the caller's primary address space.

Return and reason codes

When processing is complete for the REQASD and REQFASD SYSEVENTS, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 31. Return Codes for REQASD and REQFASD	
Return Code	Meaning
00	Successful completion.
04	Processing could not be completed at this time. A mode switch or policy activation is in progress. A later reissue could be successful.
08	The parameter list is too small.
12	The ASID is not valid.
16	Work area is too small (only issued by REQFASD).

Example 1

Use the SYSEVENT REQASD to extract address space information:

```

LA      R1,Parmlist          Load parameter list address
USING   RASD,R1              Map parameter list with RASD
MVC     RASDACRO,=C'RASD'    Set eyecatcher

MVC     RASDLEN,=AL2(L'Parmlist) Set parameter list length
SYSEVENT REQASD,TYPE=SIZECHECK,ENTRY=BRANCH,ASID=(0)

...
Parmlist DS    CL(RASDSIZE)
```

Example 2

Use the SYSEVENT REQFASD to extract address space information:

```

LA      R1,Parmlist          Load parameter list address
USING   RASD,R1              Map parameter list with RASD
MVC     RASDACRO,=C'RASD'    Set eyecatcher

MVC     RASDLEN,=AL2(L'Parmlist) Set parameter list length
MVC     RASDWALEN,=AL2(L'Workarea) and Workarea length in RASD
LR      R2,R13               Save R13 prior Sysevent invocation
LA      R13,Workarea         Address the workarea with R13
SYSEVENT REQFASD,TYPE=SIZECHECK,ENTRY=BRANCH,ASID=(0)
LR      R13,R2               Restore R13
...
Parmlist DS    CL(RASDSIZE)
Workarea DS    CL(RQFASDWA)
```

Obtain workload management mode status information (REQSRMST)

The REQSRMST SYSEVENT allows to obtain information about the state of workload management. It returns a parameter list that includes, for example:

- Active service policy information
- When and where the policy was activated
- Active service definition information
- When and where the service definition was installed

Note: The SRMSTCAP flag is provided to prospective callers of the REQLPDAT SYSEVENT, to test if that SYSEVENT is available on the system. On systems prior to z/OS V1R3, callers should first invoke the REQSRMST SYSEVENT and check the SRMSTCAP flag before invoking the REQLPDAT SYSEVENT. See [“Obtain data for defined capacity \(REQLPDAT\)”](#) on page 200 for more information.

Input register information

Register 1 must point to a parameter list. The parameter list must be non-pageable and addressable via the caller's primary address space. To map the parameter list, use the IRASRMST mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary). The SRMSTLEN field must be filled in with the length of this parameter list. The constant SRMSTSIZ can be used to set this length.

Return and reason codes

When processing is complete for the REQSRMST SYSEVENT, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 32. Return Codes for REQSRMST	
Return Code	Meaning
00	Successful completion.
08	The parameter list is too small.

Obtain data for defined capacity (REQLPDAT)

The REQLPDAT SYSEVENT allows to obtain performance data related to a defined capacity. For example, defined capacity and group capping can be used with Sub-Capacity pricing models.

This performance data is used on monitoring products such as RMF to better analyze the following:

- The average CPU consumption of the partition
- The frequency of WLM capping the partition to enforce the defined capacity
- The average weight of the partition

Note:

1. The parameter area for REQLPDAT is mapped by macro IRALPDAT.

The only input to REQLPDAT is field LPDATLEN in the parameter area. You must set LPDATLEN to the length of the provided parameter area before invoking the REQLPDAT SYSEVENT. Take one of the following actions:

- Set LPDATLEN to 0
- Set LPDATLEN using equate LPDATPARMLENGTH and provide a parameter area that is at least LPDATPARMLENGTH bytes

- Obtain a sufficiently large parameter area of more than LPDATPARMLENGTH bytes and set LPDATLEN accordingly
2. The parameter area contains variable data and the parameter area length can change at any time, not just with a new release of z/OS. Therefore, you must check the return code from REQLPDAT. If the input LPDATLEN value is smaller than the needed size of the parameter area, the SYSEVENT returns with return code 04. In this case, the system sets the LPDATLEN field to the actual needed length of the parameter area. You must call REQLPDAT again with a parameter area that is at least LPDATLEN bytes long. Make sure that the LPDATLEN field indicates the length of the provided area.
 3. An unauthorized caller can call the REQLPDAT SYSEVENT with the ENTRY=UNAUTHPC option.

Input register information

Register 1 must point to a parameter list. For ENTRY=BRANCH and ENTRY=SVC the parameter list must be non-pageable. It must be addressable by the caller's primary address space. To map the parameter list, use the IRALPDAT mapping macro described in *z/OS MVS Data Areas* in the [z/OS Internet library](http://www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary) (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

Return and reason codes

When processing is complete for the REQLPDAT SYSEVENT, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 33. Return Codes for REQLPDAT	
Return Code	Meaning
00	Successful completion.
04	The parameter list is too small.

Identify holder of a resource (ENQHOLD)

Use the ENQHOLD SYSEVENT to identify a holder of a resource causing contention. SRM may boost the service to the resource holder to help resolve the contention more quickly. A holder can be either an address space or an enclave. You must specify the address space or enclave in the parameter list pointed to by register 1. Use the IRAEVPL mapping macro described in *z/OS MVS Data Areas* in the [z/OS Internet library](http://www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary) (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary). Specify either the ASID or STOKEN value for the address space or the enclave token for the enclave. The enclave token must have been obtained from the IWMECREA macro or IWMESQRY macro.

Specify parameter TYPE=3 for SYSEVENT ENQHOLD and ENQRLSE to pass the following data to SRM:

Subsystem information

Specify subsystem information that will be kept by SRM for RAS purposes and is formatted in IPCS.

Enqueue promotion function request

Choose either the standard enqueue management promotion, or the short time/high frequency enqueue promotion:

1. Standard enqueue promotion:

Use the SYSEVENT ENQHOLD to signal a resource contention to SRM and use the SYSEVENT ENQRLSE when the resource contention ends. This function causes SRM to boost the service to the resource holder for the number of service units defined by the ERV parameter in the IEAOPTXX member.

2. Short time/high frequency enqueue promotion:

Use the SYSEVENT ENQHOLD to signal a short time resource contention to SRM. This function causes SRM to boost the service to the holder of the resource for a small number of service units and after that, terminates this enqueue promotion process. For this reason, no SYSEVENT ENQRLSE is required nor should one be issued. No enqueue hold token is provided by SRM for this function in the parameter list.

Note: The number of service units used by SRM to boost the resource holder for a short time/high frequency enqueue promotion is a fixed value and cannot be modified. It has no relation to the ERV parameter in the IEAOPTxx member.

You can select the enqueue promotion functions with the FUNCTION parameter in the parameter list pointed to by register 1.

Enqueue hold token

Receive an output token from the ENQHOLD request and use the same token on the matching ENQRLSE request. The enqueue hold token is only valid for the standard enqueue management promotion.

When using enclaves for tasks that serialize on resources using the ENQ macro or the latch manager callable services, note that a task cannot change its transaction status. That is, it cannot join or leave an enclave, while holding a resource using ENQ or the latch manager. Otherwise, enqueue promotion processing might not work properly. The recommended sequence is:

1. Join an enclave (through IWMEJOIN, IWMSTBGN, or SYSEVENT ENCASSOC).
2. Obtain resource with ENQ or latch manager.
3. Process using serialized resource.
4. Release resource.
5. Leave an enclave (through IWMELEAV, IWMSTEND, or SYSEVENT ENCASSOC).

In addition, to ensure correct enqueue promotion processing, a task executing in an enclave should not make the following types of ENQ requests:

- Directed enqueues, that is, issuing the ENQ macro with the TCB= parameter
- Matching task enqueues, that is, issuing the ENQ macro with the MTCB or MASID parameter.

Input register information

If this SYSEVENT is invoked with the TYPE=3 keyword, then register 1 must point to a parameter list. The parameter list must be non-pageable and addressable via the caller's primary address space. To map the parameter list, use the IRAEVPL mapping macro described in *z/OS MVS Data Areas* in the [z/OS Internet library \(www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary\)](http://www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

Return and reason codes

When processing is complete for the ENQHOLD SYSEVENT, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 34. Return Codes for ENQHOLD	
Return Code (Decimal)	Meaning
00	Successful completion.
08	Invalid enclave token specified.
10	The ASID specified did not map to a valid, active address space. This may occur because the address space it represents is no longer active or was never active. Note: Only valid if parameter IraEnqHR_FLAGS_RhTerm=1 was specified in the parameter list.
12	The STOKEN specified did not map to a valid, active address space. This may occur because the address space it represents is no longer active or was never active. Note: Only valid if parameter IraEnqHR_FLAGS_RhTerm=1 was specified in the parameter list.
14	The TCB address specified did not map to a valid, active TCB. This may occur because the TCB address is no longer active or was never active.
16	Invalid combination of ASID, STOKEN, or enclave token was specified in the parameter list. Specify either ASID, or STOKEN, or enclave token.

Identify that a holder has released resource (ENQRLSE)

Use the ENQRLSE SYSEVENT to notify SRM that the holder of a resource causing contention has released the resource. The inputs must be the same as those for the ENQHOLD SYSEVENT previously issued for the holder including the specification of parameter TYPE=3. See the description of ENQHOLD for considerations related to using enclaves for tasks that serialize resources. Do not issue SYSEVENT ENQRLSE if you have selected the short time/high frequency enqueue promotion.

Input register information

If this SYSEVENT is invoked with the TYPE=3 keyword, then register 1 must point to a parameter list. The parameter list must be non-pageable and addressable via the caller's primary address space. To map the parameter list, use the IRAEVPL mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

Return and reason codes

When processing is complete for the ENQRLSE SYSEVENT, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 35. Return Codes for ENQRLSE	
Return Code	Meaning
00	Successful completion.
08	Enclave token is invalid.
10	The ASID specified did not map to a valid, active address space. This may occur because the address space it represents is no longer active or was never active. Note: Only valid if parameter IraEnqHR_FLAGS_RhTerm=1 was specified in the parameter list.
12	The STOKEN specified did not map to a valid, active address space. This may occur because the address space it represents is no longer active or was never active. Note: Only valid if parameter IraEnqHR_FLAGS_RhTerm=1 was specified in the parameter list.
16	Invalid combination of ASID, STOKEN, or enclave token was specified in the parameter list. Specify either ASID, or STOKEN, or enclave token.

Associate an enclave with an address space (ENCASSOC)

Use the ENCASSOC SYSEVENT to associate an enclave and a server address space for SRBs that were scheduled to run in this enclave. This association allows SRM to manage the server address space's storage related resources towards the enclave's performance goal.

Note:

1. It is not required to use SYSEVENT ENCASSOC when you run SRBs in enclaves. It is an improvement for storage management but it is not recommended when the address space into which the SRB is scheduled runs other significant work because the association may change the goal management for the target address space.
2. The ENCASSOC SYSEVENT is necessary only for SRBs that were scheduled to run in this enclave. A task that joins an enclave automatically associates the home address space with the enclave.

You must specify X'8000' in the ASID parameter and access registers (AR) 0 and 1 must contain the enclave token. The enclave token must have been obtained from the IWMECREA macro.

The ENCASSOC SYSEVENT supports the following functions, which have to be specified with the TYPE parameter as well as in the parameter list IRAEVPL. Valid values are '1' and '2'. Note that the value can be specified either as a decimal number or as a symbol.

TYPE=1

Allows the SRB to associate this enclave with the address space for the purpose of managing the storage related resources towards the enclave's performance goal.

TYPE=2

Allows the SRB to disassociate this enclave with the address space.

For more information about SRBs and how to use them, see [z/OS MVS Programming: Authorized Assembler Services Guide](#).

The recommended coding sequence of the ENCASSOC SYSEVENT is as follows:

1. Subsystem:

- The subsystem creates the enclave by using the IWMECREA service.
- The subsystem schedules an SRB to run in the enclave.

2. SRB:

- The SRB associates the address space with the enclave by using the ENCASSOC SYSEVENT function Associate.
- SRB process logic.
- The SRB disassociates the address space with the enclave by using the ENCASSOC SYSEVENT function Disassociate.

Input register information

Register 1 must point to a parameter list. The parameter list must be non-pageable and addressable via the caller's primary address space. To map the parameter list, use the IRAEVPL mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

Return and reason codes

When processing is complete for the ENCASSOC SYSEVENT, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 36. Return Codes for ENCASSOC	
Return Code	Meaning
00	Successful completion.
04	Invalid function code specified.
10	Invalid enclave token specified.

Set the state for an enclave (ENCSTATE)

Use the ENCSTATE SYSEVENT to set the state of an enclave to either idle or non-idle. Specify X'8000' in the ASID parameter. Access registers (AR) 0 and 1 must contain the enclave token. The enclave token must have been obtained from the IWMECREA macro. An independent enclave must not be set idle as long as there are non-idle work-dependent enclaves associated with it.

Input register information

Register 1 must point to a parameter list. The parameter list must be non-pageable and addressable via the caller's primary address space. To map the parameter list, use the IRAEVPL mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

Access register (AR) 0 and 1 must contain the enclave token whose state you are setting.

Query amount of free AUX storage (FREEAUX)

Use the FREEAUX SYSEVENT to receive the number of free AUX storage slots that can safely be used without causing an AUX shortage.

Output register information

Register 0 will contain the recommended number of free AUX storage slots.

Return resource contention information (QRYCONT)

Use SYSEVENT QRYCONT to return the resource contention information for either an address space or an enclave. You must specify the address space or enclave in the parameter list pointed to by register 1. Use the IRAEVPL mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary). Specify either the ASID or STOKEN value for the address space or the enclave token for the enclave. The enclave token must have been obtained from the IWMECREA macro or the IWMESQRY macro.

Input register information

Register 1 must point to a parameter list. The parameter list must be non-pageable for authorized SYSEVENT calls (ENTRY=SVC, ENTRY=BRANCH) and must be addressable via the caller's primary address space. To map the parameter list, use the IRAEVPL mapping macro described in *z/OS MVS Data Areas* in the *z/OS Internet library* (www.ibm.com/servers/resourcelink/svc00100.nsf/pages/zosInternetLibrary).

Return codes

When processing is complete for the SYSEVENT QRYCONT, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 37. Return Codes for REQLPDAT	
Return Code (decimal)	Meaning
00	Successful completion.
04	No contention information available.
08	Invalid enclave token specified.
10	The ASID specified did not map to a valid, active address space. This may occur because the address space it represents is no longer active or was never active.
12	The STOKEN specified did not map to a valid, active address space. This may occur because the address space it represents is no longer active or was never active.
14	Invalid combination of ASID, STOKEN, or enclave token was specified in the parameter list. Specify either ASID, STOKEN, or enclave token.
16	There is additional resource contention information available.
18	Invalid version, length, or eye catcher was specified in the parameter list.
20	Invalid request type was specified in the parameter list.

Query a virtual server (QVS)

Products can use the query virtual server (QVS) interface to obtain a virtual server's ID and capacity. A virtual server is the “logical hardware” environment in which an image runs. In the case of an image running in a logical partition, the virtual server is the logical partition. In the case of an image running as a first level VM guest, the virtual server is the first level guest. Note that the virtual server concept is not extended to second or higher level VM guests. In those cases, the virtual server is still considered to be the first level VM guest. For an image running in basic mode, the virtual server is the whole machine.

In other words, for a CPC in basic mode, the logical hardware environment equals the physical hardware environment.

Customers can define a capacity limit for each logical partition. This limit is enforced by Workload Manager based on the average CPU usage of the logical partition. Peaks of CPU usage are allowed above the limit as long as the average CPU usage stays below the limit.

This service gives software vendors or software providers the option of licensing their software to a virtual server.

One way a software product can use the virtual server ID and capacity query service is to call the service when it starts. Based on the information returned, the product can verify that it is licensed to run on the specific virtual server and that the virtual server does not have more capacity than the product is licensed for. Note that this service does *not* make any of these licensing checks — it simply returns the information to enable a software product to make the appropriate checks based on the conditions of its license.

Along with this SYSEVENT, there is also a C interface, IWMQVS (located in SYS1.CSSLIB). Both forms of this query return a QVS structure which maps the returned identification and capacity information. The assembler mapping is provided by the macro IRAQVS, and the C/C++ mapping is provided in IWMQVS.H (located in SYS1.SIEAHDR.H). Before calling this service, the caller must provide storage for the QVS structure and set the field QvsLen to the length of the structure. On return, the caller can look at fields QvsVer and QvsFlags to determine which fields have been filled in. QvsFlags contains the following flags:

QvsCecValid

The physical hardware level information is valid.

QvsImgValid

The logical partition level information is valid. This flag will be off if not running in logical partition mode.

QvsVmValid

The virtual machine information is valid. This flag will be off if not running in a virtual machine.

The physical hardware level information is provided in the following fields:

- QvsCecManufacturerName
- QvsCecPlantofManufacture
- QvsCecMachineType
- QvsCecModelId
- QvsCecSequenceCode
- QvsCecCapacity
- QvsCecCapacityStatus

The logical partition level information is provided in the following fields:

- QvsImgLogicalPartitionId
- QvsImgLogicalPartitionName
- QvsImgCapacity

The virtual machine information is provided in the following fields:

- QvsVmName
- QvsVmCapacity

QvsCecCapacity, QvsImgCapacity, and QvsVmCapacity contain the maximum service rate that theoretically could be achieved at each level. The value is in millions of service units per hour (MSU).

QvsCecCapacity is equal to the individual CPU speed multiplied by the number of online and offline physical CPUs.

QvsCecCapacityStatus indicates if the machine is running at nominal capacity or at reduced capacity.

If QvsImgValid is on, the image is in ESAME mode, and QvsVmValid is off, then QvsImgCapacity is equal to one of the following:

- The partition's defined capacity set via the Hardware Management Console, if any
- The individual CPU speed multiplied by the number of online and offline logical CPUs, if the partition is uncapped and has no defined capacity
- The capacity at the partition's weight, if the partition is capped via the Hardware Management Console.

If QvsImgValid is on, and either the image is in ESA/390 mode or QvsVmValid is on, then QvsImgCapacity is equal to the individual CPU speed multiplied by the number of online and offline logical CPUs.

QvsVmCapacity is the individual CPU speed multiplied by the number of online and offline virtual CPUs.

In all cases, the individual CPU speed is based on the MP factor for the number of online and offline physical CPUs.

Note that the capacity of a virtual server can change dynamically. One example of a dynamic capacity change is a CPU upgrade on demand of the underlying hardware. A second example is a dynamic change of the defined capacity limit for a logical partition. If an unauthorized program is interested in knowing about dynamic capacity changes, it must poll the virtual server ID and capacity query service. Given dynamic capacity changes are rare, a low polling rate should be sufficient.

Authorized programs interested in knowing about dynamic capacity changes can also listen for ENF signal 61. This ENF is signaled when a change in dynamic capacity occurs and provides the listener with the new capacity at each level in the hierarchy.

Return and reason codes

When processing is complete for the QVS SYSEVENT, the last byte of register 15 contains one of the following hexadecimal return codes:

Table 38. Return Codes for QVS	
Return Code	Meaning
00	Successful completion.
04	The parameter list is too small.

Chapter 21. TCBTOKEN — Request or translate the TTOKEN

Description

The TTOKEN is the 16-byte identifier of a task. Unlike a TCB address, each TTOKEN is unique within the IPL; the system does not reassign this same identifier to any other TCB.

The TCBTOKEN macro provides five mutually exclusive services depending on how you specify the TYPE parameter:

- TYPE=TOTTOKEN gives you the TTOKEN for the task associated with a specified TCB address.
- TYPE=TOTCB gives you the TCB address for a specified TTOKEN.
- TYPE=CURRENT gives you the TTOKEN for the current task.
- TYPE=PARENT gives you the TTOKEN for the task that attached the current task.
- TYPE=JOBSTEP gives you the TTOKEN for the job step task.

Typical situations when you would use TYPE=TOTTOKEN are:

- When you create a data space and want to assign ownership of the data space to a second task.

In this case, you know the TCB address for the second task, but you don't know its TTOKEN (for input to the DSPSERV CREATE macro). Use TYPE=TOTTOKEN to obtain the TTOKEN.

- When you want to delete a data space you do not own.

In this case, you know the TCB address for the other task, but you don't know its TTOKEN (for input to the DSPSERV DELETE macro). Use TYPE=TOTTOKEN to obtain the TTOKEN.

- When you want to know whether the owner of a data space still exists.

In this case, you know the TTOKEN for the owning task. If the system returns the TCB address in response to the TYPE=TOTCB parameter, the task still exists.

z/OS MVS Programming: Extended Addressability Guide describes STOKENs and TTOKENs.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Problem or supervisor state, any PSW key
Dispatchable unit mode:	For TOTTOKEN or TOTCB requests, the caller can be in task or SRB mode. For CURRENT, PARENT, and JOBSTEP requests, the caller must be in task mode.
Cross memory mode:	Any
AMODE:	31-bit
ASC mode:	Primary or AR
Interrupt Status:	Enabled or disabled for I/O and external interrupts
Locks:	For TOTTOKEN and TOTCB requests, the caller must hold the local lock or CML lock of the specified address space. For CURRENT, PARENT, and JOBSTEP requests, there is no requirement.

Environmental factor**Control parameters:****Requirement**

Can reside in the primary address space or in an address/data space that is addressable through a public entry on the caller's dispatchable unit access list (DU-AL)

Programming requirements

None.

Restrictions

None.

Register information

After the caller issues the macro, the macro might use some registers as work registers or might change the contents of some registers. When the macro returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the general purpose registers (GPRs) contain:

Register**Contents****0-1**

Used as work registers by the macro

2-13

Unchanged

14

Used as a work register by the macro

15

Return code

When control returns to the caller, the access registers (ARs) contain:

Register**Contents****0-1**

Used as work registers by the macro

2-13

Unchanged

14-15

Used as work registers by the macro

Performance implications

None.

Syntax

The standard form of the TCBTOKEN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.

Syntax	Description
<code> </code>	
<code> </code>	One or more blanks must precede TCBTOKEN.
<code> </code>	
TCBTOKEN	
<code> </code>	
<code> </code>	One or more blanks must follow TCBTOKEN.
<code> </code>	
TYPE=TOTTOKEN	Note: See Table 39 on page 211 for information about parameter usage with TYPE.
TYPE=TOTCB	
TYPE=CURRENT	
TYPE=PARENT	
TYPE=JOBSTEP	
<code> </code>	
<code>,TCB=tcb addr</code>	<i>tcb addr</i> : RX-type address or register (2) - (12).
<code> </code>	
<code>,TTOKEN=ttoken addr</code>	<i>ttoken addr</i> : RX-type address.
<code> </code>	
<code>,ASCB=ascb addr</code>	<i>ascb addr</i> : RX-type address or register (2) - (12).
<code>,STOKEN=stoken addr</code>	<i>stoken addr</i> : RX-type address.
<code> </code>	Default: Home address space.
<code> </code>	
<code>,RELATED=value</code>	<i>value</i> : Any valid macro parameter specification.
<code> </code>	

[Table 39 on page 211](#) shows how the parameters may be specified with the TYPE keywords.

Table 39. Usage of TCBTOKEN parameters with the TYPE parameter					
Parameters	TYPE= TOTTOKEN	TYPE= TOTCB	TYPE= CURRENT	TYPE= PARENT	TYPE= JOBSTEP
TCB	required	required	not valid	not valid	not valid
TTOKEN	required	required	required	required	required
ASCB	optional	optional	not valid	not valid	not valid
STOKEN	optional	not valid	not valid	not valid	not valid
RELATED	optional	optional	optional	optional	optional

Parameters

The parameters are explained as follows:

TYPE=TOTTOKEN**TYPE=TOTCB****TYPE=CURRENT****TYPE=PARENT****TYPE=JOBSTEP**

Specifies the type of TCB information requested, as follows:

TOTTOKEN

The system returns the TTOKEN of the task whose TCB address is specified in the TCB parameter. The TTOKEN is returned at the address specified by the TTOKEN parameter. If the task is the current task or an ancestor of the current task, instead of using the TCBTOKEN service, you may use the STCBTTKN field of the STCB data area associated with that task. If running in cross-memory mode, be aware that the TCB and STCB are in the home address space.

TOTCB

The system returns the TCB address for the task whose TTOKEN is specified in the TTOKEN parameter. The TCB address is returned at the address specified by the TCB parameter.

CURRENT

The system returns the TTOKEN of the currently active task. The TTOKEN is returned at the address specified by the TTOKEN parameter. Instead of using the TCBTOKEN service, you may use the STCBTTKN field of the STCB data area associated with the current task (for which the TCB address is in the PSATOLD field). If running in cross-memory mode, be aware that the TCB and STCB are in the home address space.

PARENT

The system returns the TTOKEN of the task that attached the currently active task. The TTOKEN is returned at the address specified by the TTOKEN parameter. Instead of using the TCBTOKEN service, you may use the STCBTTKN field of the STCB data area associated with the parent task (for which the TCB address is in the TCBOTC field of the TCB for the current task, for which the TCB address is in the PSATOLD field). Do not use the STCBTTKN approach if your task is the first in the address space (typically, the region control task); it will not be if your task is part of the jobstep program task tree. If running in cross-memory mode, be aware that the TCB and STCB are in the home address space.

JOBSTEP

The system returns the TTOKEN of the job step task associated with the currently active task. The TTOKEN is returned at the address specified by the TTOKEN parameter. Instead of using the TCBTOKEN service, you may use the STCBTTKN field of the STCB data area associated with the jobstep task associated with the current task (for which the TCB address is in the TCBJSTCB field of the TCB for the current task, for which the TCB address is in the PSATOLD field). If running in cross-memory mode, be aware that the TCB and STCB are in the home address space.

,TCB=*tcb addr*

Specifies the TCB address. For TYPE=TOTTOKEN, *tcb addr* contains the TCB address that is to be translated to a TTOKEN. For TYPE=TOTCB, *tcb addr* points to a fullword where the system returns the TCB address for the task whose TTOKEN is specified by the TTOKEN parameter.

,TTOKEN=*ttoken addr*

Specifies the address of the 16-byte TTOKEN. For TYPE=TOTTOKEN, TYPE=CURRENT, TYPE=PARENT, and TYPE=JOBSTEP, *ttoken addr* is the address at which the TTOKEN associated with the specified TCB is returned. For TYPE=TOTCB, *ttoken addr* is the address of the TTOKEN for the task whose TCB address is to be obtained.

,ASCB=*ascb addr***,STOKEN=*stoken addr***

Identifies the address space of the TCB. ASCB specifies the address of the fullword containing the ASCB address. STOKEN specifies the address of the 8-byte STOKEN that identifies the address space in which the TCB resides. If you do not specify either ASCB or STOKEN, TCBTOKEN uses the home address space by default.

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user and may be any valid coding values.

Abend codes

None.

Return codes

When TCBTOKEN returns control, register 15 contains one of the following hexadecimal return codes:

Table 40. Return codes for the TCBTOKEN macro	
Return code	Meaning and action
00	Meaning: TCBTOKEN services completed successfully. Action: None.
04	Meaning: The input STOKEN or TTOKEN does not represent a valid address space. Action: Ensure that you specify a valid token on the STOKEN or TTOKEN keywords.
08	Meaning: No local lock was held. Action: Obtain the local lock before issuing TCBTOKEN.
0C	Meaning: A local lock was held, but not the local lock of the associated address space. Action: Obtain the correct local lock before issuing TCBTOKEN.
10	Meaning: The TCB could not be referenced. Action: Ensure that the input TCB address specified on the TCB keyword is valid.
14	Meaning: The TCB did not pass the acronym check. Action: Ensure that the input TCB address specified on the TCB keyword is valid.
18	Meaning: The TCB has ended. The TCB control block has not been deleted yet. Action: None required.
1C	Meaning: The TCB associated with the TTOKEN represents a different task than when the TTOKEN was obtained. Action: None required.
20	Meaning: An unexpected error occurred. Action: Reissue the TCBTOKEN macro.
24	Meaning: The contents of access register 1, used to address the parameter list, were not valid. Action: Either change your program to run in primary mode or set access register 1 to zero.
28	Meaning: The parameter list is not valid. Action: Ensure that the parameter list address is valid and addressable in the calling program's key.
2C	Meaning: The ASCB address is the address of the wait ASCB. The system cannot obtain the TTOKEN. Action: Specify an ASCB address which is not the wait ASCB.
30	Meaning: The task is scheduled for termination, but has not yet terminated. The TCB control block has not been deleted yet. Action: None required.
34	Meaning: The caller is not running in task mode. This return code is valid only for TYPE=CURRENT, TYPE=PARENT, or TYPE=JOBSTEP. Action: Change your program to run in task mode.

Note: Return codes 04, 08, 0C, 1C, and 2C are valid only with TYPE=TOTTOKEN and TYPE=TOTCB.

Example 1

Obtain the TTOKEN for the task whose TCB address is specified in THEIR_TCB. The task resides in the address space whose ASCB address is specified in register 4. Store the returned TTOKEN in THEIR_TOKEN.

```
TCBTOKEN  TYPE=TOTTOKEN,TCB=THEIR_TCB,TTOKEN=THEIR_TTOKEN,ASCB=(4)
```

Example 2

Obtain the TTOKEN for the currently active task and store it in CURRENT_TTOKEN.

```
TCBTOKEN  TYPE=CURRENT,TTOKEN=CURRENT_TTOKEN
```

Example 3

Obtain the TCB address of the job step TCB and store it in JOBSTEP_TCB_ADDR.

```
TCBTOKEN  TYPE=JOBSTEP,TTOKEN=JOBSTEP_TTOKEN
TCBTOKEN  TYPE=TOTCB,TTOKEN=JOBSTEP_TTOKEN,TCB=JOBSTEP_TCB_ADDR
```

TCBTOKEN - List form

Use the list form of the TCBTOKEN macro together with the execute form of the macro for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form of the macro uses to store the parameters.

Syntax

The list form of the TCBTOKEN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede TCBTOKEN.
TCBTOKEN	
␣	One or more blanks must follow TCBTOKEN.
,RELATED= <i>value</i>	<i>value</i> : Any valid macro parameter specification.
,MF=L	

Parameters

The parameters are explained below:

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user and may be any valid coding values.

,MF=L

Specifies the list form of the TCBTOKEN macro.

TCBTOKEN - Execute form

Use the execute form of the TCBTOKEN macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

Syntax

The execute form of the TCBTOKEN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
	One or more blanks must precede TCBTOKEN.
TCBTOKEN	
	One or more blanks must follow TCBTOKEN.
TYPE=TOTTOKEN	Note: See Table 39 on page 211 for information about parameter usage with TYPE.
TYPE=TOTCB	
TYPE=CURRENT	
TYPE=PARENT	
TYPE=JOBSTEP	
,TCB= <i>tcb addr</i>	<i>tcb addr</i> : RX-type address or register (2) - (12).
,TTOKEN= <i>ttoken addr</i>	<i>ttoken addr</i> : RX-type address.
,ASCB= <i>ascb addr</i>	<i>ascb addr</i> : RX-type address or register (2) - (12).
,STOKEN= <i>stoken addr</i>	<i>stoken addr</i> : RX-type address.

Syntax	Description
	Default: Home address space.
,RELATED= <i>value</i>	<i>value</i> : Any valid macro parameter specification.
,MF=(E, <i>cntl addr</i>)	<i>cntl addr</i> : RX-type address or register (1) - (12).

Parameters

The parameters are the same as those for the standard form of the TCBTOKEN macro with the following addition:

,MF=(E,*cntl addr*)

Specifies the execute form of the TCBTOKEN macro. This form uses a remote parameter list. The *cntl addr* specifies the address of the remote parameter list that the list form of the macro generates.

Chapter 22. TCTL – Transfer control from an SRB routine

Description

The TCTL (transfer control) macro allows an SRB routine to exit from its processing and to pass control directly to a task.

Environment

Requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state and any PSW key
Dispatchable unit mode:	SRB
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O or external interrupts
Locks:	None held
Control parameters:	Must be in the caller's primary address space

Programming requirements

The caller must include the following mapping macros:

- IHAPSA
- CVT with DSECT=YES

Restrictions

None.

Input register information

If you are using the default for the TCB parameter, on input to the TCTL macro, general purpose register (GPR) 4 must contain the address of the TCB.

Output register information

The system does not return to the caller after invoking this macro, so register contents on exit from the macro are not applicable.

Performance implications

None.

Syntax

The TCTL macro is coded as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
	One or more blanks must precede TCTL.
TCTL	
	One or more blanks must follow TCTL.
TCB=(4)	Default: Register 4 contains TCB address.
TCB= <i>tcbaddr</i>	<i>tcbaddr</i> : A-type address or registers (2) - (12).

Parameters

The parameters are explained as follows:

TCB=(4)

TCB=*tcbaddr*

Specifies the task designated for dispatching. Register 4 is the default; if you use the default, you must ensure that register 4 contains the appropriate TCB address.

Note: The TCB resides in storage below 16 megabytes.

ABEND codes

070

See [z/OS MVS System Codes](#) for an explanation and programmer responses for this code.

Return and reason codes

The system does not return to the caller after this macro has been invoked, so return codes from the macro are not applicable.

Example

From SRB mode processing, terminate the SRB and give control to the task specified in register 4.

```
TCTL TCB=(4)
```


Chapter 23. TESTAUTH – Test authorization of caller

Description

The TESTAUTH macro is used on behalf of a privileged or sensitive function to verify that its caller is appropriately authorized.

TESTAUTH supports the authorized program facility (APF) - a facility that permits the identification of programs that are authorized to use restricted functions. In addition, TESTAUTH provides the capability for testing for system key 0-7 and supervisor state. An EUT FRR may not be in force for a caller using BRANCH=NO.

Environment

The requirements for the caller are:

- When BRANCH=NO

Environmental factor	Requirement
Minimum authorization:	Problem or supervisor state, any key
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
Asc mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control Parameters:	Must be in primary address space

- When BRANCH=YES

Note: When BRANCH=YES, the caller must include the CVT mapping macro.

Environmental factor	Requirement
Minimum authorization:	Supervisor state, any key
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
Asc mode:	Primary
Interrupt status:	No requirement
Locks:	Local lock held
Control Parameters:	Must be in primary address space

Programming requirements

None.

Restrictions

When using BRANCH=NO, the caller cannot have an EUT FRR established.

Input register information

Before issuing the TESTAUTH macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter or using it as a base register.

Output register information

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the ARs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The TESTAUTH macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede TESTAUTH.
TESTAUTH	
␣	One or more blanks must follow TESTAUTH.
FCTN= <i>fctn</i>	<i>fctn</i> : Decimal digit 0 or 1 or register (2) - (12).

Syntax	Description
	Default: FCTN=0 if STATE or KEY is specified. Otherwise, the default is FCTN=1.
,STATE=NO	Default: STATE=NO
,STATE=YES	
,KEY=NO	Default: KEY=NO
,KEY=YES	
,RBLEVEL=2	Default: RBLEVEL=2
,RBLEVEL=1	RBLEVEL is used only if KEY and/or STATE are specified; otherwise RBLEVEL is ignored.
,BRANCH=NO	Default: BRANCH=NO
,BRANCH=YES	

Parameters

The parameters are explained as follows:

FCTN=*fctn*

Specifies the authorization of a program to be checked through APF.

FCTN=0 specifies that APF-authorization is not checked.

FCTN=1 specifies that APF-authorization is checked.

,STATE=NO

,STATE=YES

Specifies whether or not (YES or NO) a check is to be made for supervisor/problem program state. (Supervisor state is authorized, problem program state is not authorized.)

,KEY=NO

,KEY=YES

Specifies whether or not (YES or NO) a check is to be made of the protection keys. (Protection keys 0-7 are authorized, protection keys 8-15 are not authorized.)

Note: TESTAUTH is used to test one or more of three conditions: FCTN, STATE, or KEY. If any of the requested conditions are tested favorably, a return code of zero is returned in register 15. If all of the requested conditions are tested unfavorably, the return code is set to 4.

,RBLEVEL=2

,RBLEVEL=1

Specifies whether the TESTAUTH caller is a type 2, 3, or 4 SVC (RBLEVEL=2) or a type 1 SVC (RBLEVEL=1). If the TESTAUTH caller is not an SVC, specify RBLEVEL=1. Specify RBLEVEL only if you also specify KEY and/or STATE; otherwise RBLEVEL is ignored.

,BRANCH=NO

,BRANCH=YES

Specifies a branch entry (YES) or an SVC entry (NO). If BRANCH=YES is specified, registers 2 and 3 are modified by the TESTAUTH routine. Only SVC routines can use BRANCH=YES.

ABEND codes

None.

Return codes

When control is returned, register 15 contains one of the following hexadecimal return codes:

Table 41. Return Codes for the SAMPLE Macro	
Return Code	Meaning and Action
00	Meaning: Task is authorized. Action: None.
04	Meaning: Task is not authorized. Action: None.

Example 1

Test jobstep for APF authorization.

```
TESTAUTH FCTN=1
```

Example 2

Test for APF authorization and supervisor state and do not check protection keys.

```
TESTAUTH STATE=YES,KEY=NO,FCTN=1
```

Chapter 24. TIMEUSED – Obtain accumulated CPU or vector time

Description

The TIMEUSED macro returns an 8-byte hexadecimal number in a doubleword storage area that you specify. The number is the total CPU or vector time which is used by the current TCB or SRB until you issue the macro. The format of the number is time-of-day (TOD) clock or microseconds time format.

If you use the SRBSTAT save and restore services, the number includes the interval between dispatch and save and between restore and TIMEUSED. It does not include the interval between save and restore. If you have not issued restore, the number includes only the interval between save and TIMEUSED.

TIMEUSED is also documented in *z/OS MVS Programming: Assembler Services Reference IAR-XCT*, but without the LINKAGE=BRANCH and ENCLAVE parameters. Those parameters are only available to authorized callers.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state and PSW key 0 when you specify LINKAGE=BRANCH. Supervisor or problem state and any PSW key when you specify LINKAGE=SYSTEM.
Dispatchable unit mode:	Task or SRB when LINKAGE=BRANCH. Task when LINKAGE=SYSTEM.
Cross memory mode:	PASN=HASN=SASN or PASN¬=HASN¬=SASN
AMODE:	31- or 64-bit
ASC mode:	When LINKAGE=BRANCH without ECT, ENCLAVE, and TIME_ON_CP, primary or secondary When LINKAGE=BRANCH with ECT, ENCLAVE, or TIME_ON_CP, primary When LINKAGE=SYSTEM, primary or access register (AR)
Interrupt status:	When you specify LINKAGE=BRANCH, enabled or disabled for I/O and external interrupts; otherwise, enabled for I/O and external interrupts.
Locks:	When you specify LINKAGE=BRANCH, any locks can be held, but none are required; otherwise, no locks can be held.
Control parameters:	Must be in the primary address space or be in an address/data space that is addressable through a public entry on the caller's dispatchable unit access list (DU-AL)

Programming requirements

None.

For information about programs in 64-bit addressing mode (AMODE 64), see *z/OS MVS Programming: Extended Addressability Guide*.

Restrictions

None.

Input register information

When you specify LINKAGE=BRANCH:

- For ENCLAVE=SUP, register 13 must contain the address of a 36-word save area.
- For TIME_ON_CP=YES, register 13 must contain the address of a 36-word save area.
- Otherwise, register 13 must contain the address of an 18-word save area.

You can provide the address by using standard linkage conventions.

Output register information

After the caller issues the macro, the macro might use some registers as work registers or might change the contents of some registers. When the macro returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. If the caller depends on these registers to contain the same value before and after they issue the macro, the caller must save these registers before they issue the macro. The caller restores them after the system returns control.

When control returns to the caller, the GPRs contain:

- For ENCLAVE=SUP:

64-bit Register	Contents
0	Time on standard CPs, adjusted for current dispatch.
1	Time on IBM System z9 [®] Integrated Information Processor and IBM System z10 [®] Integrated Information Processor (zIIP), adjusted for current dispatch
2	Time zIIP on standard CP, adjusted for current dispatch
3 - 13	Unchanged
14	Used as a work register by the macro
15	Return code in low 32 bits

- For TIME_ON_CP=YES:

64-bit Register	Contents
0	The total CPU time that is used up until you issue the macro, in TOD clock format, whether running on a standard CP, System z Application Assist Processor (zAAP), or System z Integrated Information Processor (zIIP)
1	The total CPU time on a standard CP used up until you issue the macro, in TOD clock format.
2	<ul style="list-style-type: none"> – Unchanged if OFFLOAD_ON_CP is not specified. – If OFFLOAD_ON_CP is specified, the total CPU time on a standard CP that was eligible for offload, up until the time you issue the macro, in TOD clock format.
3 - 13	Unchanged
14	Used as a work register by the macro

64-bit Register**Contents****15**

Return code in low 32 bits

- Otherwise:

Register**Contents****0 - 1**

Used as work registers by the system

2 - 13

Unchanged

14

Used as work registers by the macro

15

Return code

The access registers (AR) contain:

Register**Contents****0 - 1**

Used as work registers by the system

2 - 13

Unchanged

14 - 15

Used as work registers by the system

Performance implications

When your application uses TIMEUSED LINKAGE=SYSTEM without the CPU and VECTOR parameters (or can change to do so), consider use of the ECT parameter that gives access to the Extract-CPU-Time (ECT) facility that is available on IBM System z9 or later hardware.

- If your application runs on systems that support and do not support the ECT facility, you can use the ECT=COND parameter to check for availability of this facility. The ECT=COND parameter adds a small extra overhead when running on a system that does not support the ECT facility, but results in a much faster path when running on a system which does support the facility.
- If your application always runs on a system that supports the ECT facility, use ECT=YES without specifying the LINKAGE parameter. This provides better performance than using LINKAGE=SYSTEM,ECT=COND.

The TIMEUSED support to use the Extract-CPU-Time facility is available on z/OS V1R8 or later systems.

Note: When you use TIMEUSED with LINKAGE=BRANCH without the CPU parameter, the system automatically uses the ECT facility when it is available, without needing a runtime check.

Syntax

The TIMEUSED macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede TIMEUSED.
TIMEUSED	
␣	One or more blanks must follow TIMEUSED.

Syntax	Description
STORADR= <i>addr</i>	<i>addr</i> : RX-type address or register (2)-(12).
,LINKAGE=SYSTEM	Default: LINKAGE=BRANCH
,LINKAGE=BRANCH	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro parameter specification
,CPU=TOD	Default: CPU=TOD
,CPU=MIC	
,VECTOR=TOD	
,VECTOR=MIC	
,ECT=SYSTEM	Default: ECT=SYSTEM
,ECT=COND	
,ECT=YES	
,ENCLAVE=SUP	
,TIME_ON_CP=YES	
,OFFLOAD_TIME=YES	
,OFFLOAD_ON_CP=YES	

Parameters

The parameters are explained as follows:

STORADR=*addr*

When TIME_ON_CP, OFFLOAD_TIME, and OFFLOAD_ON_CP are not specified, STORADR=*addr* specifies the address of a doubleword area where the accumulated CPU or vector time is returned. When in AMODE 64 and invoking TIMEUSED with LINKAGE=SYSTEM or ECT=YES, the area might be in 64-bit storage; otherwise, it must be in 31-bit storage. The time interval is represented as an unsigned 64-bit binary number. If you specify CPU=TOD or VECTOR=TOD, bit 51 is the low-order bit of the interval value and equivalent to 1 microsecond. If you specify CPU=MIC or VECTOR=MIC, bit 63 is the low-order bit of the interval value and equivalent to 1 microsecond. STORADR is required except when ENCLAVE is specified. If ENCLAVE is specified, STORADR is not allowed.

When ECT=YES and one or more of TIME_ON_CP, OFFLOAD_TIME, and OFFLOAD_ON_CP are specified, STORADR=*addr* is required. This specifies the address of an 8-word area in 31-bit storage of the primary address space where one or more accumulated time values are returned. It is recommended that the area is on a doubleword boundary. Each time interval is represented as an unsigned 64-bit binary number. Bit 51 is the low-order bit of the interval value and equivalent to 1 microsecond.

On output where the return code is 0:

- Words 0-1 = Total time.
- Words 2-3 = Time on CP when TIME_ON_CP=YES.
- Words 4-5 = Offload time (unnormalized) when OFFLOAD_TIME=YES.
- Words 6-7 = Offload on CP when OFFLOAD_ON_CP=YES. Any subfield that is not requested to be returned is unpredictable.

,LINKAGE=SYSTEM**,LINKAGE=BRANCH**

Specifies the type of linkage used in TIMEUSED processing. LINKAGE=BRANCH indicates branch entry. You can specify or default to LINKAGE=BRANCH if you are a key zero supervisor state program running under a TCB or SRB. LINKAGE=SYSTEM indicates that the linkage is by nonbranch entry.

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information that is specified are at the discretion of the user and can be any valid coding values.

,CPU=TOD**,CPU=MIC****,VECTOR=TOD****,VECTOR=MIC**

Specifies that TIMEUSED return the total CPU or vector time in either TOD clock format (CPU=TOD or VECTOR=TOD) or in microseconds (CPU=MIC or VECTOR=MIC). You can specify CPU=MIC or VECTOR only if LINKAGE=SYSTEM.

,ECT=SYSTEM

Specifies that the system determines which instruction service to use. For LINKAGE=BRANCH, the system uses the Extract CPU Time instruction service when that service is available. For LINKAGE=SYSTEM, it will not use the Extract CPU Time instruction service.

,ECT=COND

Specifies that the system is conditionally to use the Extract CPU Time instruction service. If the service and instruction are available, the system uses that service. Otherwise, the system uses the regular TIMEUSED service. Output is in TOD format. Use only with LINKAGE=SYSTEM. Do not specify the CPU or VECTOR parameters. You must include the CVT, IHAECVT, and IHAPSA mapping macros.

,ECT=YES

Specifies that the system is unconditionally to use the Extract CPU Time instruction service. You must verify that the service and instruction are available (running on z/OS V1R8 or later, with bit FLCFECT on in byte FLCFACL3 in macro IHAPSA). Output is in TOD format. Do not specify the CPU, VECTOR, or LINKAGE parameters. You must include the CVT, IHAECVT, and IHAPSA mapping macros.

,ENCLAVE=SUP

Specifies that the system is to return ENCLAVE time which pertains to System z9 Integrated Information Processor (zIIP) usage, which is adjusted for the time spent within the current dispatch. Requires LINKAGE=BRANCH.

,TIME_ON_CP=YES

Returns CPU time on standard CP, in TOD clock format, for the current work unit.

- When TIME_ON_CP=YES is specified without the ECT=YES parameter, LINKAGE=BRANCH is required and ENCLAVE or ECT must not be specified.
- When TIME_ON_CP=YES is specified with the ECT=YES parameter, the invocation must be in task mode, requires STORADR, and can be specified along with either OFFLOAD_TIME=YES or OFFLOAD_ON_CP=YES, or both. You must include DSECTs CVT and IHAECVT. The function is available only if bit CVTECT1 in byte CVTOSLV8 of the CVT data area is on.

,OFFLOAD_TIME=YES

Returns CPU time on offload engines, in TOD clock format, for the current task. This time is unnormalized (it is in the units that apply to the offload processors). Requires the ECT=YES and STORADR parameters and can be specified along with TIME_ON_CP=YES or OFFLOAD_ON_CP=YES,

or both. You must include DSECTs CVT and IHAECVT. The function is available only if bit CVTECT1 in byte CVTOSLV8 of the CVT data area is on.

,OFFLOAD_ON_CP=YES

Returns CPU time on a standard CP that was eligible for offload, in TOD clock format, for the current task.

- When OFFLOAD_ON_CP=YES is specified without the ECT=YES parameter, LINKAGE=BRANCH is required and STORADR, ENCLAVE, or ECT must not be specified. If the invocation is in SRB mode, no data is returned. The function is available only if bit CVTOOCP in byte CVTOSLV8 of the CVT data area is on.
- When OFFLOAD_ON_CP=YES is specified with the ECT=YES parameter, the invocation must be in task mode, requires STORADR, and can be specified along with either TIME_ON_CP=YES or OFFLOAD_ON_CP=YES, or both. You must include DSECTs CVT and IHAECVT. The function is available only if bit CVTECT1 in byte CVTOSLV8 of the CVT data area is on.

Return codes

When control returns to the caller, GPR 15 contains one of the following hexadecimal return codes.

Table 42. Return Codes for the TIMEUSED Macro	
Return Code	Meaning and Action
00	Meaning: The service completed successfully. Action: None.
08	Meaning: Unexpected error Action: Retry the request.
0C	Meaning: The ENCLAVE=SUP or TIME_ON_CP=YES function is not available. No data is returned. Action: Avoid requesting ENCLAVE=SUP when bit CVTSUP in byte CVTOSLV4 is off. Avoid requesting TIME_ON_CP=YES when bit CVTTOCP in byte CVTOSLV4 is off.

Example 1

Using the unauthorized TIMEUSED service, request the total CPU time in TOD clock format to be stored at the address in register 2.

```
TIMEUSED    STORADR=(2) , LINKAGE=SYSTEM, CPU=TOD
```

Example 2

Using the unauthorized TIMEUSED service in task mode, request the total vector time in microseconds to be stored at the address in register 2.

```
TIMEUSED    STORADR=(2) , LINKAGE=SYSTEM, VECTOR=MIC
```

Example 3

Using the authorized TIMEUSED service, request the total CPU time in TOD clock format to be stored at the address in register 2.

```
TIMEUSED    STORADR=(2) , LINKAGE=BRANCH
```

Chapter 25. T6EXIT – Type 6 exit

Description

The T6EXIT macro returns control from a type 6 SVC. This exit macro can only be used in a type 6 SVC routine.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state and PSW key 0
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Disabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	None

Programming requirements

The caller must include the CVT mapping macro with DSECT=YES specified.

Restrictions

None.

Input register information

On input, general purpose register (GPR) 1 must point to a service request block (SRB) if RETURN=SRB is specified.

Output register information

For RETURN=CALLER, registers 0, 1, and 15 are returned from the type 6 SVC routine to the calling program (the issuer of the SVC). For RETURN=DISPATCH and RETURN=SRB, no registers are returned to the calling program.

Performance implications

None.

Syntax

The T6EXIT macro is written as follows:

Syntax	Description

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede T6EXIT.
T6EXIT	
b	One or more blanks must follow T6EXIT.
RETURN=CALLER	Default: RETURN=CALLER
RETURN=DISPATCH	
RETURN=SRB	

Parameter

The explanation of the RETURN parameter is as follows:

RETURN

Specifies how the type 6 SVC has chosen to exit, which is one of the following:

- CALLER specifies that the return is directly to the caller or issuer of the SVC. The contents of GPRs 0, 1, and 15 at the time of the T6EXIT are returned to the issuer of the SVC. CALLER is the default return option.
- DISPATCH specifies that the return should be to the system to dispatch other work. This function is for the use of routines that have suspended the current task. When the task resumes, the issuer of the type 6 SVC receives control at the instruction after the SVC.
- SRB specifies that the system should immediately dispatch an SRB. This SRB must:
 - Be initialized by the type 6 SVC.
 - Be pointed to by register 1.
 - Run in the same address space as the SVC. The SRB has the same format as an SRB dispatched through the SCHEDULE macro.

ABEND codes

None.

Return and reason codes

None.

Example

Terminate type 6 SVC processing and return control from the type 6 SVC to the caller of the SVC.

```
T6EXIT RETURN=CALLER
```

Chapter 26. UCBINFO – Return information from a UCB

Description

Use the UCBINFO macro to obtain information from a unit control block (UCB) for a specified device. The UCBINFO macro provides the following options:

DEVCOUNT

Returns a count of the UCBs for a device class or device group.

DEVINFO

Returns information about a device, particularly, why the device is offline. For the base UCB of a Parallel Access Volume (PAV), DEVINFO returns the number of alias UCBs that are defined, and the number that are usable. Also, the DEVINFO can return an indicator in the IOSDDEVI mapping macro reflecting whether the device is a Hyper Parallel Access Volume (HyperPAV) device.

GETCDR

Returns the Configuration Data Record (CDR) for a specific device-path from the Configuration Data Table (CDT).

HYPERPAVALIASES

Returns information for HyperPAV aliases that are configured in the same logical subsystem as the input device. The HYPERPAVALIASES function allows you to obtain selected information for each alias exposure of a Parallel Access Volume (PAV) device in HyperPAV mode. All alias exposures contained in the logical subsystem are returned in the output PAVAREA. The data returned by this function is mapped by the mapping macro IOSDPAVA and consists of a header and one or more entries.

PATHINFO

Returns information about the device path and type of channel path associated with the device.

PATHMAP

Returns information about the device path.

PRFXDATA

Obtains a copy of the UCB prefix extension segment.

PAVINFO

Returns information about the alias UCBs for a Parallel Access Volume (PAV) or a Hyper Parallel Access Volume (HyperPAV).

The options of the UCBINFO macro have the same environmental specifications, programming requirements, restrictions, register information, and performance implications described below, except where noted in the explanations of each option.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Problem state and any PSW key. If the UCBPTR keyword is used, Supervisor state or PSW key 0-7. For LINKAGE=BRANCH, all of the following: <ul style="list-style-type: none"> • Supervisor state with key 0 • 31-bit addressing mode • Primary ASC mode • Parameter list and any data areas it points to must be in fixed storage or disabled reference (DREF) storage.
Dispatchable unit mode:	Task or SRB
Cross memory mode:	Any PASN, any HASN, any SASN
AMODE:	24- or 31-bit
ASC mode:	Primary or access register (AR)
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	The caller may hold locks, but is not required to hold any
Control parameters:	Control parameters must be in the primary address space or, for AR-mode callers, must be in an address/data space that is addressable through a public entry on the caller's dispatchable unit access list (DU-AL).

Programming requirements

Before issuing the UCBINFO macro, you can issue the UCBSCAN macro to obtain either the UCBPTR or the device number, which you must provide as input to UCBINFO. [z/OS MVS Programming: Assembler Services Guide](#) Authorized callers must serialize (such as through pinning) the device against dynamic deletions when specifying any of the following:

- DEVINFO with the UCBPTR parameter
- GETCDR with the UCBPTR parameter
- HYPERPAVALIASES with the UCBPTR parameter
- PATHINFO with the UCBPTR parameter
- PATHMAP with the UCB pointer in the MAPAREA field.
- PRFXDATA with the UCBPTR parameter
- PAVINFO with the UCBPTR parameter

See [z/OS MVS Programming: Authorized Assembler Services Guide](#) for information about accessing and pinning UCBs.

The caller must include the appropriate mapping macro for the UCBINFO option being used:

Option

Mapping Macro

DEVCOUNT

None

DEVINFO

IOSDDEVI mapping macro

HYPERPAVALIASES

IOSDPAVA mapping macro

PATHINFO

IOSDPATH mapping macro

PATHMAP

IOSDMAP mapping macro

PAVINFO

IOSDPAVA mapping macro

PRFXDATA

IOSDUPI mapping macro

Restrictions

None.

Input register information

Before issuing the UCBINFO macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the GPRs contain:

Register**Contents****0**

A reason code; otherwise, used as a work register by the system

1

Used as a work register by the system

2-13

Unchanged

14

Used as a work register by the system

15

A return code

When control returns to the caller, the ARs contain:

Register**Contents****0-1**

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

UCBINFO DEVCOUNT

Use the UCBINFO DEVCOUNT macro to obtain a count of the UCBs for a device class.

Syntax

The standard form of the DEVCOUNT option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
	One or more blanks must precede UCBINFO.
UCBINFO	
	One or more blanks must follow UCBINFO.
DEVCOUNT	
,COUNT= <i>count addr</i>	<i>count addr</i> : RS-type address or register (2) - (12).
,GROUP=DEVICELASS	
,DEVCLASS=ALL	Default: ALL
,DEVCLASS=CHAR	
,DEVCLASS=COMM	
,DEVCLASS=CTC	
,DEVCLASS=DASD	
,DEVCLASS=DISP	
,DEVCLASS=TAPE	
,DEVCLASS=UREC	
,GROUP=OTHER	
,DEVGROU=PAVBASE	Default: PAVBASE
,DEVGROU=PAVALIAS	
,SUBCHANNELSET=ID	
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,SUBCHANNELSET=ALL	
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).

Syntax	Description
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

DEVCOUNT

Specifies that the system is to return a count of the UCBs.

,COUNT=*count addr*

Specifies the address of the fullword field that is to receive the count.

,GROUP=DEVICECLASS

GROUP specifies the grouping upon which the UCB count is based.

DEVICECLASS indicates that the UCB count is based on device classes.

,DEVICECLASS=ALL|CHAR|COMM|CTC|DASD|DISP|TAPE|UREC

Specifies the device class for which the corresponding UCBs are to be counted:

ALL

Counts UCBs for all device classes

CHAR

Counts UCBs for character reader device class

COMM

Counts UCBs for communications device class

CTC

Counts UCBs for channel to channel device class

DASD

Counts UCBs for direct access device class

DISP

Counts UCBs for display device class

TAPE

Counts UCBs for tape device class

UREC

Counts UCBs for unit record device class

,GROUP=OTHER

GROUP specifies the grouping upon which the UCB count is based.

OTHER indicates that the UCB count is not based on device classes.

,DEVGROUP=PAVBASE

,DEVGROUP=PAVALIAS

Specifies the device group for which the corresponding UCBs are to be counted.

- **PAVBASE**, counts UCBs for Parallel Access Volume (PAV) base UCBs.
- **PAVALIAS**, counts UCBs for Parallel Access Volume (PAV) alias UCBs.

,SUBCHANNELSET=ID

,SUBCHANNELSET=ALL

,SUBCHANNELSET=ID

Indicates the UCB count is based on one subchannel set. DEFAULT: ID

,SCHSET=schset addr

,SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the UCBINFO request is to be performed. DEFAULT: 0.

,SUBCHANNELSET=ALL

Indicates the UCB count is based on all subchannel sets. DEFAULT: ID

,IOCTOKEN=ioc token addr

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioc token addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that the system is to generate:

- **SYSTEM**: Specifies a Program Call (PC)
- **BRANCH**: Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=plistver

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2.

,RETCODE=retcode addr

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=rsncode addr

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO DEVCOUNT macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The DEVCOUNT function completed successfully. Action: None.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.
08	02	Meaning: Program error. The system could not access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is the Supervisor state or PSW key 0 - 7. Action: Ensure that you have met the environmental requirements for the macro and reissue the macro.
08	05	Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter. Action: Correct the IOCTOKEN parameter.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter the correct value on the SCHSET keyword.
0C	None	Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter. Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.

Example

To invoke UCBINFO to return a count of all DASD devices, code:

```

UCBINFO  DEVCOUNT, COUNT=CTAREA, DEVCLASS=DASD,          X
RETCODE=INFORTCD, RSNCODE=RSNCD
.
.
.
DS  0D
CTAREA DS  F
INFORTCD DS  F
RSNCD  DS  F

```

UCBINFO DEVCOUNT—List form

Use the list form of the DEVCOUNT option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros” on page 11](#) for further information.

The list form of the DEVCOUNT option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
	One or more blanks must precede UCBINFO.
UCBINFO	
	One or more blanks must follow UCBINFO.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of UCBINFO DEVCOUNT with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO DEVCOUNT macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBINFO DEVCOUNT—Execute form

Use the execute form of the DEVCOUNT option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the DEVCOUNT option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
DEVCOUNT	
,COUNT= <i>count addr</i>	<i>count addr</i> : RS-type address or register (2) - (12).
,GROUP=DEVICELASS	
,DEVCLASS=ALL	Default: ALL
,DEVCLASS=CHAR	
,DEVCLASS=COMM	
,DEVCLASS=CTC	
,DEVCLASS=DASD	
,DEVCLASS=DISP	
,DEVCLASS=TAPE	
,DEVCLASS=UREC	
,GROUP=OTHER	
,DEVGROU=PAVBASE	Default: PAVBASE
,SUBCHANNELSET=ID	
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0

Syntax	Description
,SUBCHANNELSET=ALL	
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Parameters

The parameters are explained under the standard form of UCBINFO DEVCOUNT with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO DEVCOUNT macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

UCBINFO DEVINFO

Use the UCBINFO DEVINFO macro to obtain information about a device, specifically, reasons why the device is offline.

If using a UCB copy, the user must pass the device number in DEVN. The caller can obtain the address of the UCB common segment by a UCBPTR parameter on a UCBLOOK macro. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

Syntax

The standard form of the DEVINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
DEVINFO	
,DEVIAREA= <i>deviarea addr</i>	<i>deviarea addr</i> : RX-type address or register (2) - (12).
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address. Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

DEVINFO

Specifies that the system is to return information about the specified device.

,DEVIAREA=deviarea addr

Specifies the address of a required 256-byte output field into which the system is to return information about the specified device. This field is mapped by the mapping macro IOSDDEVI.

,DEVN=devn addr

Specifies the address of a halfword that contains, in binary form, the device number of the device. The DEVN and UCBPTR parameters are mutually exclusive.

,SCHSET=schset addr

,SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the device information is to be obtained. DEFAULT: 0.

,UCBPTR=ucbptr addr

Specifies that address of a fullword that contains the address of the UCB common segment. The DEVN and UCBPTR parameters are mutually exclusive. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

,IOCTOKEN=ioctoken addr

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioctoken addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=plistver

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2

,RETCODE=retcode addr

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=rsncode addr

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO DEVINFO macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The DEVINFO function completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number specified in the DEVN parameter. Action: Correct the device number and reissue the macro.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.
08	02	Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is the Supervisor state or PSW key 0 - 7. Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.
08	03	Meaning: Program error. The UCB address provided by the caller does not represent a valid UCB. Action: Correct the UCB address and reissue the macro.
08	05	Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter. Action: Correct the IOCTOKEN parameter.
08	09	Meaning: Program error. An error occurred when the system attempted to reference the area specified by the DEVIAREA parameter. Action: Correct the address specified on the DEVIAREA parameter and reissue the macro.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter a valid value.
0C	None	Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter. Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.
28	None	Meaning: Program error. The device number or UCB address provided by the caller represents an alias UCB of a parallel access volume. For information about a parallel access volume, the caller must specify the base device number or base UCB. Action: Correct the DEVN or UCBPTR parameter and reissue the macro.

Example

To invoke UCBINFO to return device information, code:

```

        UCBINFO  DEVINFO,DEVIAREA=INFOAREA,DEVN=DEVNUM,          X
        RETCODE=INFORTCD
        .
        .
        .
        DS      0D
INFOAREA DS      CL256
INFORTCD DS      F
DEVNUM   DS      H

```

UCBINFO DEVINFO - List form

Use the list form of the DEVINFO option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros” on page 11](#) for further information.

The list form of the DEVINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2

Syntax	Description
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of UCBINFO DEVINFO with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO DEVINFO macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBINFO DEVINFO - Execute form

Use the execute form of the DEVINFO option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the DEVINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
DEVINFO	
,DEVIAREA= <i>deviarea addr</i>	<i>deviarea addr</i> : RX-type address or register (2) - (12).
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.

Syntax	Description
,SCHSET= <i>schset addr</i>	<i>schset addr</i> RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address. Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Parameters

The parameters are explained under the standard form of UCBINFO DEVINFO with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO DEVINFO macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

UCBINFO GETCDR

Use the UCBINFO GETCDR macro to get a Configuration Data Record (CDR) for a given device and path from the Configuration Data Table (CDT).

If using a UCB copy, the user must pass the device number in DEVN. The caller can obtain the address of the UCB common segment by a UCBPTR parameter on a UCBLOOK macro. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

Syntax

The standard form of the GETCDR option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
 	One or more blanks must precede UCBINFO.
UCBINFO	
 	One or more blanks must follow UCBINFO.
GETCDR	
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address. Note: Specify either DEVN or UCBPTR, but not both.
,PATHMASK= <i>pathmask addr</i>	<i>pathmask addr</i> : RS-type address or register (2) - (12).
,PATHMASK=0	Default: 0
,CDRAREA= <i>cdrarea addr</i>	<i>cdrarea addr</i> : RS-type address or register (2) - (12).
,CDRLLEN= <i>cdrlen addr</i>	<i>cdrlen addr</i> : RS-type address or register (2) - (12).
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	

Syntax	Description
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

,DEVN=*devn addr*

Specifies the name (RS-type), or address in register (2)-(12), of a halfword input which specifies the device number in binary of the device whose CDR is to be retrieved.

,SCHSET=*schset addr*

,SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the device information is to be obtained. DEFAULT: 0.

,UCBPTR=*ucbptr addr*

Specifies the name (RS-type), or address in register (2)-(12), of a 4 byte input that contains the address of the UCB common segment whose CDR is to be retrieved. The DEVN and UCBPTR parameters are mutually exclusive. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

,PATHMASK=*pathmask addr*

,PATHMASK=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional 8 bit input that contains the path mask of the device-path whose CDR is to be retrieved. This path mask maps to the UCBCHPID array. Only one bit can be set in the path mask. If the PATHMASK parameter is not specified, or is a 0, a CDR corresponding to the specified device and a path to that device is retrieved. DEFAULT: 0.

,CDRAREA=*cdrarea addr*

This parameter is a required output and specifies the name (RS-type), or address in register (2)-(12), of the work area which is to receive a copy of the CDR for the requested device-path. The caller must specify the CDRLLEN keyword to indicate the length of the CDRAREA.

,CDRLLEN=*cdrlen addr*

Specifies the name (RS-type), or address in register (2)-(12), of a required fullword input variable which specifies the length of the CDRAREA.

,IOCTOKEN=*ioctoken addr*

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in [z/OS MVS Programming: Assembler Services Reference ABE-HSP](#). If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioctoken addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=plistver

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2

,RETCODE=retcode addr

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=rsncode addr

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO GETCDR macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The GETCDR function completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number specified in the DEVN parameter. Action: Correct the device number and reissue the macro.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.
08	02	Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is Supervisor state or PSW key 0 - 7. Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
08	03	Meaning: Program error. The UCB address provided by the caller does not represent a valid UCB. Action: Correct the UCB address and reissue the macro.
08	05	Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter. Action: Correct the IOCTOKEN parameter.
08	07	Meaning: Program error. An error occurred when the system attempted to reference the area specified by the CDRAREA parameter. Action: Correct the address specified on the CDRAREA parameter and reissue the macro.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter a valid value.
0C	None	Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter. Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.
14	None	Meaning: The CDR was not retrieved. The requested CDR was not found in the CDT. Action: None.
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.

Example

To invoke UCBINFO to return a CDR for a device and path, code:

```

UCBINFO  GETCDR,DEVN=DEVNUM,                X
          PATHMASK=PATHMASK,CDRAREA=INFOAREA, X
          CDRLN=AREALEN,RETCODE=INFORTCD
          .
          .
          .
          DS  0D
DEVNUM   DS  H
PATHMASK DS  X
INFOAREA DS  CL256
AREALEN  DS  F
INFORTCD DS  F

```

UCBINFO GETCDR - List form

Use the list form of the GETCDR option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros” on page 11](#) for further information.

The list form of the GETCDR option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
GETCDR	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of UCBINFO GETCDR with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO GETCDR macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBINFO GETCDR - Execute form

Use the execute form of the GETCDR option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the GETCDR option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
GETCDR	
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,PATHMASK= <i>pathmask addr</i>	<i>pathmask addr</i> : RS-type address or register (2) - (12).
,PATHMASK=0	Default: 0
,CDRAREA= <i>cdrarea addr</i>	<i>cdrarea addr</i> : RS-type address or register (2) - (12).
,CDRLLEN= <i>cdrlen addr</i>	<i>cdrlen addr</i> : RS-type address or register (2) - (12).
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).

Syntax	Description
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Parameters

The parameters are explained under the standard form of UCBINFO GETCDR with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO GETCDR macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

UCBINFO HYPERPAVALIASES

Use the UCBINFO HYPERPAVALIASES macro to obtain information for each alias exposure of a Parallel Access Volume (PAV) in HyperPAV mode. All alias exposures contained in the logical subsystem for the input device are returned in the output PAVAREA. The data returned by this function is mapped by macro IOSDPAVA and consists of a header and one or more entries.

If the input device is not a HyperPAV device, a non-zero return code is returned. If using a UCB copy, the user must pass the device number in DEVN. The caller can obtain the address of the UCB common segment by a UCBPTR parameter on a UCBLOOK macro. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

Syntax

The standard form of the HYPERPAVALIASES option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
HYPERPAVALIASES	

Syntax	Description
,PAVAREA= <i>pavarea addr</i>	<i>pavarea addr</i> : RS-type address or register (2) - (12).
,PAVLEN= <i>pavlen addr</i>	<i>pavlen addr</i> : RS-type address or register (2) - (12).
,SCHINFO=NO YES	Default: NO
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr</i> : RS-type address. Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

,PAVAREA=*pavarea addr*

This parameter is required and is the name (RS-type), or address in register (2) - (12), of the work area which is to receive the PAV information. The caller must specify the PAVLEN keyword to indicate the length of the PAVAREA. The area is mapped by macro IOSDPAVA.

,PAVLEN=*pavlen addr*

This parameter is the name (RS-type), or address in register (2) - (12), of a required fullword input variable which specifies the length of the PAVAREA.

,SCHINFO=NO| YES

This parameter is an optional keyword input that indicates whether to also retrieve model dependent subchannel data for the device.

Note: Retrieving subchannel data can cause overhead since a Store Subchannel (STSCH) instruction must be issued to retrieve the data. Users who do not need this information might want to bypass this overhead by indicating NO for the SCHINFO keyword. DEFAULT: NO.

,SCHINFO=NO

Do not include model dependent subchannel data.

,SCHINFO=YES

Include model dependent subchannel data.

,DEVN=devn addr

Specifies the address of a halfword that contains, in binary form, the device number of the device.

,SCHSET=schset addr**,SCHSET=0**

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the device information is to be obtained. DEFAULT: 0.

,UCBPTR=ucbptr addr

Specifies that address of a fullword that contains the address of the UCB common segment. The DEVN and UCBPTR parameters are mutually exclusive. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

,IOCTOKEN=ioctoken addr

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in [z/OS MVS Programming: Assembler Services Reference ABE-HSP](#). If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioctoken addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM**,LINKAGE=BRANCH**

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION**,PLISTVER=MAX****,PLISTVER=plistver**

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To **code**, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2

,RETCODE=retcode addr

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=rsncode addr

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO HYPERPAVALIASES macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The HYPERPAVALIASES function completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number specified in the DEVN parameter. Action: Correct the device number and reissue the macro.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.
08	02	Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is Supervisor state or PSW key 0 - 7. Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.
08	03	Meaning: Program error. The UCB address provided by the caller does not represent a valid UCB. Action: Correct the UCB address and reissue the macro.
08	05	Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter. Action: Correct the IOCTOKEN parameter.
08	0A	Meaning: Program error. An error occurred when the system attempted to reference the area specified by the PAVAREA parameter. Action: Correct the address specified on the PAVAREA parameter and reissue the macro.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter a valid value.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
0C	None	Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter. Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.
30	01	Meaning: Program error. The device number provided by the caller is not a HyperPAV device. Action: Correct the DEVN parameter and reissue the macro.
30	02	Meaning: Program error. The work area specified with the PAVAREA parameter is not large enough to contain the minimum amount of data. No data is returned. Action: Increase the size of the specified work area and reissue the macro.
30	03	Meaning: Program error. The work area specified with the PAVAREA parameter is not large enough to contain an entry for each alias device. Action: Increase the size of the specified work area and reissue the macro.
34	01	Meaning: Environmental error. The input device is a HyperPAV device for which logical subsystem information does not currently exist. Action: Contact your system programmer.

Example

To invoke UCBINFO to return information about HyperPAV alias UCBs for a base device number, code:

```

UCBINFO  HYPERPAVALIASES,DEVN=DEVNUM,      X
         PAVAREA=INFOAREA,PAVLEN=AREALEN,    X
         RETCODE=INFORTCD
         .
         .
         .
DEVNUM   DS    0D
INFOAREA DS    H
AREALEN  DS   CL1024
INFORTCD DS    F

```

UCBINFO HYPERPAVALIASES - List form

Use the list form of the HYPERPAVALIASES option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros”](#) on page 11 for further information.

The list form of the HYPERPAVALIASES option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
HYPERPAVALIASES	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of UCBINFO HYPERPAVALIASES with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO HYPERPAVALIASES macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBINFO HYPERPAVALIASES - Execute form

Use the execute form of the HYPERPAVALIASES option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the HYPERPAVALIASES option of the UCBINFO macro is written as follows:

Syntax	Description

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
HYPERPAVALIASES	
,PAVAREA= <i>pavarea addr</i>	<i>pavarea addr</i> : RS-type address or register (2) - (12).
,PAVLEN= <i>pavlen addr</i>	<i>pavlen addr</i> : RS-type address or register (2) - (12).
,SCHINFO=NO YES	Default: NO
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Syntax	Description
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Parameters

The parameters are explained under the standard form of UCBINFO HYPERPAVALIASES with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO HYPERPAVALIASES macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

UCBINFO PATHINFO

Use the UCBINFO PATHINFO macro to obtain information about the device path and type of channel path associated with the device.

If using a UCB copy, the user must pass the device number in DEVN. The caller can obtain the address of the UCB common segment by a UCBPTR parameter on a UCBLOOK macro. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

Syntax

The standard form of the PATHINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
	One or more blanks must precede UCBINFO.
UCBINFO	
	One or more blanks must follow UCBINFO.
PATHINFO	
,PATHAREA= <i>patharea addr</i>	<i>patharea addr</i> : RX-type address or register (2) - (12).

Syntax	Description
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address. Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

PATHINFO

Specifies that the system is to return information about the device path and type of channel path for the specified device.

,PATHAREA=*patharea addr*

Specifies the address of the required 256-byte output field into which the system is to return information about the device path and type of channel path for the specified device. This field is mapped by the mapping macro IOSDPATH.

,DEVN=*devn addr*

Specifies the address of a halfword that contains, in binary form, the device number of the device. The DEVN and UCBPTR parameters are mutually exclusive.

,SCHSET=*schset addr*

,SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the system is to return information about the device path and type of channel path. DEFAULT: 0.

,UCBPTR=*uchptr addr*

Specifies the address of a fullword that contains the address of the UCB common segment. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7. The DEVN and UCBPTR parameters are mutually exclusive.

,IOCTOKEN=*ioctoken addr*

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in [z/OS MVS Programming: Assembler Services Reference ABE-HSP](#). If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioctoken addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM**,LINKAGE=BRANCH**

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance sensitive programs.

,PLISTVER=IMPLIED_VERSION**,PLISTVER=MAX****,PLISTVER=*plistver***

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2

,RETCODE=*retcode addr*

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=*rsncode addr*

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO PATHINFO macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The PATHINFO function completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number specified in the DEVN parameter. Action: Correct the device number and reissue the macro.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.
08	02	Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is the Supervisor state or PSW key 0 - 7. Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.
08	03	Meaning: Program error. The UCB address provided by the caller does not represent a valid UCB. Action: Correct the UCB address and reissue the macro.
08	05	Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter. Action: Correct the IOCTOKEN parameter.
08	08	Meaning: Program error. An error occurred when the system attempted to reference the area specified by the PATHAREA parameter. Action: Correct the address specified on the PATHAREA parameter and reissue the macro.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter a valid value.
0C	None	Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter. Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.
18	04	Meaning: System error. The subchannel is in permanent error and cannot be accessed. Action: Supply the return and reason codes to the appropriate IBM support personnel.
18	08	Meaning: Environmental error. The UCB is not connected to a subchannel. Action: Verify that there is a device at the device number associated with the subchannel, and reissue the macro.
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.

Example

To invoke UCBINFO to return device path and type of channel path information, code:

```

        UCBINFO  PATHINFO,PATHAREA=INFOAREA,DEVN=DEVNUM,      X
        RETCODE=INFORTCD
        .
        .
        .
        DS      0D
INFOAREA DS      CL256
INFORTCD DS      F
DEVNUM   DS      H

```

UCBINFO PATHINFO - List form

Use the list form of the PATHINFO option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros” on page 11](#) for further information.

The list form of the PATHINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of UCBINFO PATHINFO with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO PATHINFO macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBINFO PATHINFO - Execute form

Use the execute form of the PATHINFO option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the PATHINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
PATHINFO	
,PATHAREA= <i>patharea addr</i>	<i>patharea addr</i> : RX-type address or register (2) - (12).
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address. Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).

Syntax	Description
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Parameters

The parameters are explained under the standard form of UCBINFO PATHINFO with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO PATHINFO macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

UCBINFO PATHMAP

Use the UCBINFO PATHMAP macro to obtain information about the device path.

Syntax

The standard form of the PATHMAP option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	

Syntax	Description
<code>‡</code>	One or more blanks must follow UCBINFO.
<code>PATHMAP</code>	
<code>,MAPAREA=maparea addr</code>	<i>maparea addr</i> : RX-type address or register (2) - (12).
<code>,DEVN=devn addr</code>	<i>devn addr</i> : RS-type address or register (2) - (12).
<code>,DEVN=NONE</code>	Default: NONE
<code>,SCHSET=schset addr</code>	<i>schset addr</i> : RS-type address or register (2) - (12).
<code>,SCHSET=0</code>	Default: 0
<code>,IOCTOKEN=ioctoken addr</code>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
<code>,LINKAGE=SYSTEM</code>	Default: SYSTEM
<code>,LINKAGE=BRANCH</code>	
<code>,PLISTVER=IMPLIED_VERSION</code>	
<code>,PLISTVER=MAX</code>	Default: IMPLIED_VERSION
<code>,PLISTVER=plistver</code>	<i>plistver</i> : 2
<code>,RETCODE=retcode addr</code>	<i>retcode addr</i> : RX-type address or register (2) - (12).
<code>,RSNCODE=rsncode addr</code>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

PATHMAP

Specifies that the system is to return information about the device path for the specified device.

,MAPAREA=maparea addr

Specifies a required 40-byte field into which the system is to return information about the device path for the specified device. This field is mapped by the mapping macro IOSDMAP.

,DEVN=devn addr

,DEVN=NONE

Specifies the address of a halfword that contains, in binary form, the device number of the device.

If the caller does not specify an address on the DEVN parameter, or specifies DEVN=NONE, the caller must place the address of the UCB common segment into the fullword field within the MAPAREA DSECT that is assigned the name MAPUCB by mapping macro IOSDMAP. See [z/OS MVS Programming](#):

Authorized Assembler Services Guide for information about using UCBSCAN to obtain the address of the UCB.

If the caller codes the DEVN parameter, the MAPUCB field contains hexadecimal zeros when control returns to the caller.

,SCHSET=*schset addr*

,SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the information about the device path is to be returned. DEFAULT: 0.

,IOCTOKEN=*ioctoken addr*

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioctoken addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=*plistver*

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2

,RETCODE=*retcode addr*

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=*rsncode addr*

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO PATHMAP macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The PATHMAP function completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number specified in the DEVN parameter. Action: Correct the device number and reissue the macro.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.
08	02	Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is the Supervisor state or PSW key 0 - 7. Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.
08	03	Meaning: Program error. The UCB address provided by the caller does not represent a valid UCB. Action: Correct the UCB address and reissue the macro.
08	05	Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter. Action: Correct the IOCTOKEN parameter.
08	06	Meaning: Program error. An error occurred when the system attempted to reference the area specified by the MAPAREA parameter. Action: Correct the address specified for MAPAREA and reissue the macro.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter a valid value.
0C	None	Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter. Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.
10	04	Meaning: System error. The subchannel is in permanent error and cannot be accessed. Action: Supply the return and reason code to the appropriate IBM support personnel.
10	08	Meaning: Environmental error. The UCB is not connected to a subchannel. Action: Correct the UCB address supplied, and reissue the macro.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.

Example

To invoke UCBINFO to return device path information, code:

```

        UCBINFO  PATHMAP,MAPAREA=INFOAREA,DEVN=DEVNUM,      X
        RETCODE=INFORTCD
        .
        .
        .
        DS      0D
INFOAREA DS      CL256
INFORTCD DS      F
DEVNUM   DS      H

```

UCBINFO PATHMAP - List form

Use the list form of the PATHMAP option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros” on page 11](#) for further information.

The list form of the PATHMAP option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Syntax	Description

Parameters

The parameters are explained under the standard form of UCBINFO PATHMAP with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO PATHMAP macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBINFO PATHMAP - Execute form

Use the execute form of the PATHMAP option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the PATHMAP option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
PATHMAP	
,MAPAREA= <i>maparea addr</i>	<i>maparea addr</i> : RX-type address or register (2) - (12).
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RX-type address or register (2) - (12).
,DEVN=NONE	Default: NONE
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0

Syntax	Description
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Parameters

The parameters are explained under the standard form of the UCBINFO PATHMAP macro with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO PATHMAP macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

UCBINFO PAVINFO

Use the UCBINFO PAVINFO macro to obtain selected information applicable to each exposure (base and alias) of a Parallel Access Volume (PAV).

If using a UCB copy, the user must pass the device number in DEVN. The caller can obtain the address of the UCB common segment by a UCBPTR parameter on a UCBLOOK macro. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

Syntax

The standard form of the PAVINFO option of the UCBINFO macro is written as follows:

Syntax	Description

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
PAVINFO	
PAVINFOSUM=NO	Default: NO
PAVINFOSUM=YES	
,PAVAREA= <i>pavarea addr</i>	<i>pavarea addr</i> : RX-type address or register (2) - (12).
,PAVLEN= <i>pavarea addr</i>	<i>pavarea addr</i> : RX-type address or register (2) - (12).
,SCHINFO=NO	Default: NO
,SCHINFO=YES	
,EXTFORMAT=NO	Default: NO
,EXTFORMAT=YES	
,OUTVERSION= <i>outver</i>	Default: 3
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr</i>	<i>ucbptr</i> : RX-type address. Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM

Syntax	Description
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

PAVINFO

Obtain selected information that applies to each exposure of a Parallel Access Volume (PAV) device. The data returned by this function is mapped by the mapping macro IOSDPAVA and consists of a header and one or more entries. Depending on the input device, the following is returned:

- When the input device is a PAV-base, the first entry represents the base and each subsequent entry represents each of the bound PAV-alias devices associated with the base. Note that if the base has no bound PAV-aliases, then only the first entry is filled in.
- When the input is a non-PAV DASD device, only the first entry is filled in.
- When the input device is a PAV-alias or a non-DASD, a non-zero return code is returned.

PAVINFORMSUM=NO

PAVINFORMSUM=YES

Specifies whether to retrieve only a sum of channel measurement data and model dependent subchannel data for the base device and all of its aliases.

Note: The model dependent subchannel data is only retrieved if SCHINFO=YES.

NO

Do not just retrieve a total of channel measurement data and model dependent subchannel data for the base device and all of its aliases. This option causes a PAVA entry to be created for the base device and each of its aliases.

YES

Retrieve only a sum of channel measurement data and model dependent subchannel data for the base device and all of its aliases. This option causes the first PAVA entry to contain information on the base device, however, the measurement-related fields (such as PAVACMB, PAVASMDB, and PAVAECSMB) will contain totals for the base and all of its aliases.

,PAVAREA=*pavarea addr*

Specifies the address of a required output field into which the system will return information about the alias UCBs for the specified base device number or base UCB address. This field is mapped by the mapping macro IOSDPAVA.

,PAVLEN=*pavarea addr*

Specifies the address or a register containing the length of the area specified by the PAVAREA parameter.

,SCHINFO=NO

,SCHINFO=YES

This parameter specifies whether or not to retrieve model-dependent subchannel data (control unit busy time, switch busy time, and device busy time) for the device. If you issue this request from a system running on a z990 or higher processor, the system ignores the SCHINFO parameter, but still returns the device busy time.

NO

Do not retrieve model-dependent subchannel data for the device. Note that even if you specify NO on a z990 or higher processor, the service will still return the device busy time.

YES

Retrieve model-dependent subchannel data for the device, which includes control unit busy time, switch busy time, and device busy time. If you specify YES on a z990 or higher processor, the service will still return the device busy time.

,EXTFORMAT=NO

,EXTFORMAT=YES

This parameter specifies whether an extended format PAV area should be created. An extended format PAV area contains a length field in each entry that defines the actual length of the entry. This allows the PAV entry to be extended compatibly to add new information. A non-extended format PAV area contains entries which are fixed in size (60 bytes) and cannot be extended to contain new data. See the mapping macro IOSDPAVA for more information.

Note: The value specified for the EXTFORMAT keyword on the UCBINFO PAVINFO macro must match the value specified on the IOSDPAVA macro. Otherwise, your program may not work correctly.

NO

Create the non-extended format PAV area.

YES

Create the extended format PAV area.

,OUTVERSION=outver

Specifies the output version to be used when creating an extended format PAV area. The output version controls the size of the PAV entries that are returned. This parameter is used only if EXTFORMAT(YES) is specified; it is ignored for EXTFORMAT(NO) requests. If an output version that is less than 3 is specified, version 3 is used. If an output version that is higher than the currently supported version is specified, the highest supported version is used.

Note: Currently, version 3 is the only supported value.

,DEVN=devn addr

Specifies the address of a halfword that contains the base device number in binary form. The DEVN and UCBPTR parameters are mutually exclusive.

,SCHSET=schset addr

,SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the information that applies to each exposure of a Parallel Access Volume (PAV) device is to be obtained. DEFAULT: 0.

,UCBPTR=ucbptr addr

Specifies the address of a fullword that contains the address of the UCB common segment. The DEVN and UCBPTR parameters are mutually exclusive. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

,IOCTOKEN=ioctoken addr

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioctoken addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a program call (PC)
- **BRANCH:** Specifies a branch entry

LINKAGE=BRANCH is intended for performance sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=plistver

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value in the range of 1 - 3.

,RETCODE=retcode addr

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=rsncode addr

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO PAVINFO macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The PAVINFO function completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number specified in the DEVN parameter. Action: Correct the device number and reissue the macro.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
08	02	<p>Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is the Supervisor state or PSW key 0 - 7.</p> <p>Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.</p>
08	03	<p>Meaning: Program error.</p> <p>The UCB address provided by the caller does not represent a valid UCB.</p> <p>Action: Correct the UCB address and reissue the macro.</p>
08	05	<p>Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter.</p> <p>Action: Correct the IOCTOKEN parameter and reissue the macro.</p>
08	0A	<p>Meaning: Program error. An error occurred when the system attempted to reference the area specified by the PAVAREA parameter.</p> <p>Action: Correct the address specified on the PAVAREA parameter and reissue the macro.</p>
08	0B	<p>Meaning: The value specified on the SCHSET keyword is not valid.</p> <p>Action: Enter a valid value.</p>
0C	None	<p>Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter.</p> <p>Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.</p>
1C	01	<p>Meaning: Program error. The device number or UCB address provided by the caller specifies a device that is not a DASD or is a PAV alias device.</p> <p>Action: Correct the DEVN or UCBPTR parameter and reissue the macro.</p>
1C	02	<p>Meaning: Program error. The work area specified with the PAVAREA parameter is not large enough to contain the minimum amount of data. No data is returned.</p> <p>Action: Increase the size of the specified work area and reissue the macro.</p>
1C	03	<p>Meaning: Program error. The work area specified with the PAVAREA parameter is not large enough to contain an entry for each alias device.</p> <p>Action: Increase the size of the specified work area and reissue the macro.</p>
20	None	<p>Meaning: System error. An unexpected error occurred.</p> <p>Action: Supply the return code to the appropriate IBM support personnel.</p>

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
28	None	<p>Meaning: Program error. The device number or UCB address provided by the caller represents an alias UCB of a parallel access volume. The caller must specify the base device number or base UCB.</p> <p>Action: Correct the DEVN or UCBPTR parameter and reissue the macro.</p>

Example

To invoke UCBINFO to return information about alias UCBs for a base device number, code:

```

UCBINFO PAVINFO,DEVN=DEVNUM,PAVAREA=INFOAREA,PAVLEN=AREALEN,  X
      RETCODE=INFORTCD
      .
      .
      .
DEVNUM DS 0D
INFOAREA DS H
AREALEN DS CL256
INFORTCD DS F

```

To invoke UCBINFO to return information about alias UCBs for a base UCB, code:

```

UCBINFO PAVINFO,UCBPTR=UCBP,PAVAREA=INFOAREA,PAVLEN=AREALEN,  X
      RETCODE=INFORTCD
      .
      .
      .
UCBP DS 0D
INFOAREA DS A
AREALEN DS CL256
INFORTCD DS F

```

UCBINFO PAVINFO - List form

Use the list form of the PAVINFO option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

The list form of the PAVINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
	One or more blanks must precede UCBINFO.
UCBINFO	
	One or more blanks must follow UCBINFO.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION

Syntax	Description
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of UCBINFO PAVINFO with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO PAVINFO macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of X'0D', which forces the parameter list to a doubleword boundary.

UCBINFO PAVINFO - Execute form

Use the execute form of the PAVINFO option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the PAVINFO option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
PAVINFO	
PAVINFOSUM=NO	Default: NO
PAVINFOSUM=YES	

Syntax	Description
,PAVAREA= <i>pavarea addr</i>	<i>pavarea addr</i> : RX-type address or register (2) - (12).
,PAVLEN= <i>pavlen addr</i>	<i>pavlen addr</i> : RX-type address or register (2) - (12).
,SCHINFO=NO	Default: NO
,SCHINFO=YES	
,EXTFORMAT=NO	Default: NO
,EXTFORMAT=YES	
,OUTVERSION= <i>outver</i>	Default: 3
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RX-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RX-type address. Note: Specify either DEVN or UCBPTR, but not both.
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Syntax	Description

Parameters

The parameters are explained under the standard form of UCBINFO PAVINFO with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO PAVINFO macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

UCBINFO PRFXDATA

Use the UCBINFO PRFXDATA macro to obtain a copy of the UCB prefix extension segment.

If using a UCB copy, the user must pass the device number in DEVN. The caller can obtain the address of the UCB common segment by a UCBPTR parameter on a UCBLOOK macro. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7.

Syntax

The standard form of the PRFXDATA option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBINFO.
UCBINFO	
␣	One or more blanks must follow UCBINFO.
PRFXDATA	
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.

Syntax	Description
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

PRFXDATA

Specifies that the system is to obtain information from the UCB prefix extension segment.

,DEVN=*devn addr*

Specifies the address of a halfword that contains, in binary form, the device number of the device. The DEVN and UCBPTR parameters are mutually exclusive.

,SCHSET=*schset addr*

,SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the information from the UCB prefix extension segment is to be obtained.
DEFAULT: 0.

,UCBPTR=*ucbptr addr*

Specifies the address of a fullword that contains the address of the UCB common segment. The use of UCBPTR is restricted to callers in Supervisor state or PSW key 0 - 7. The DEVN and UCBPTR parameters are mutually exclusive.

,UCBPAREA=*ucbparea addr*

Specifies the address of a 48-character storage area into which the system copies the UCB prefix extension segment. The IOSDUP1 mapping macro maps the area.

,IOCTOKEN=*ioctoken addr*

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBINFO is invoked does not match the token whose address is supplied here, the system issues a return code to the caller.

If you set the input IOCTOKEN (specified by *ioctoken addr*) to binary zeros, UCBINFO sets IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=plistver

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2

,RETCODE=retcode addr

Specifies the address of a fullword field into which the system copies the return code from GPR 15.

,RSNCODE=rsncode addr

Specifies the address of a fullword field into which the system copies the reason code from GPR 0.

Return and reason codes

When the UCBINFO PRFXDATA macro returns control to your program, GPR 15 (or *retcode addr*, if you coded RETCODE) contains a return code, and GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: The PRFXDATA function completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number specified in the DEVN parameter. Action: Correct the device number and reissue the macro.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
08	02	Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. This might be due to using a keyword that requires authorization but the caller was not authorized, that is the Supervisor state or PSW key 0 - 7. Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.
08	03	Meaning: Program error. The UCB address provided by the caller does not represent a valid UCB. Action: Correct the UCB address and reissue the macro.
08	05	Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter. Action: Correct the IOCTOKEN parameter.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter a valid value.
0C	None	Meaning: Environmental error. The I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter. Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero.
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.

Example

To invoke UCBINFO to obtain a copy of the UCB prefix extension segment, code:

```

UCBINFO  PRFXDATA,DEVN=DEVNUM,UCBPAREA=UAREA,          X
         RETCODE=INFORTCD
         .
         .
         .
DEVNUM   DS    0D
UAREA    DS    H
INFORTCD DS    CL48

```

UCBINFO PRFXDATA - List form

Use the list form of the PRFXDATA option of the UCBINFO macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses to contain the parameters.

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros” on page 11](#) for further information.

The list form of the PRFXDATA option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : RX-type address
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of UCBINFO PRFXDATA with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBINFO PRFXDATA macro.

list addr is the name of a storage area to contain the parameters.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBINFO PRFXDATA - Execute form

Use the execute form of the PRFXDATA option of the UCBINFO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The execute form of the PRFXDATA option of the UCBINFO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : symbol. Begin <i>name</i> in column 1.

Syntax	Description
b	One or more blanks must precede UCBINFO.
UCBINFO	
b	One or more blanks must follow UCBINFO.
PRFXDATA	
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,SCHSET= <i>schset addr</i>	<i>schset addr</i> : RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12). Note: Specify either DEVN or UCBPTR, but not both.
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or address in register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Syntax	Description

Parameters

The parameters are explained under the standard form of UCBINFO PRFXDATA with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBINFO PRFXDATA macro.

list addr specifies the area that the system uses to contain the parameters.

COMPLETE, which is the default, specifies that the macro is to check for required parameters and supply defaults for omitted optional parameters.

Chapter 27. UCBLOOK — Obtain addresses of UCB segments

Description

The UCBLOOK macro obtains the address of the following for a given device number or volume serial number:

- The UCB common segment
- The UCB common extension segment
- The UCB prefix extension segment

The input device number may be specified as binary or EBCDIC, and may be a 3-digit or 4-digit number.

You can use UCBLOOK to locate any UCB segment, including a segment for a dynamic UCB. The caller must pin the UCB by means of the PIN parameter unless one of the following is true:

- The caller is running in an environment where dynamic I/O configuration changes cannot occur.
- The caller can otherwise guarantee that the UCB will not be deleted.

After the system returns the address of the UCB segment, and the caller is done processing the UCB, the caller must unpin the UCB. The caller can unpin the UCB by using the UCBPIN macro with the UNPIN parameter.

Note: The caller can optionally restrict the search to UCBs that are static and installation-static, have 3 digit device numbers, or are below 16 megabytes.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state or PKM keys 0-7 For LINKAGE=BRANCH, all of the following: <ul style="list-style-type: none"> • Supervisor state with PSW key 0 • 31-bit addressing mode • Primary ASC mode • Parameter list and any data areas it points to must be in fixed storage or, if the caller is disabled, in disabled reference (DREF) storage
Dispatchable unit mode:	Task or SRB
Cross memory mode:	Any PASN, any HASN, any SASN
AMODE:	24- or 31-bit
ASC mode:	Primary or access register (AR)
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	No requirement

Environmental factor**Requirement****Control parameters:**

Must be in the primary address space or be in an address/data space that is addressable through a public entry on the caller's dispatchable unit access list (DU-AL)

Programming requirements

If in AR mode, specify `SYSSTATE ASCENV=AR` before invoking the macro.

Restrictions

None.

Input register information

Before issuing the UCBLOOK macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register**Contents****0**

Reason code if GPR 15 contains a return code of 08; otherwise, used as a work register by the system

1

Used as a work register by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the access registers (ARs) contain:

Register**Contents****0-1**

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The standard form of the UCBLOOK macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBLOOK
UCBLOOK	
␣	One or more blanks must follow UCBLOOK
DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12).
,SCHSET= <i>xschset</i>	<i>xschset</i> RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
LDEVNCHAR= <i>xldevnchar</i>	<i>xldevnchar</i> : RS-type address or register (2) - (12).
DEVNCHAR= <i>devnchar addr</i>	<i>devnchar addr</i> : RS-type address or register (2) - (12).
VOLSER= <i>volser addr</i>	<i>volser addr</i> : RS-type address or register (2) - (12).
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12).
,UCBCXPTR= <i>ucbcxptr addr</i>	<i>ucbcxptr addr</i> : RS-type address or register (2) - (12).
,UCBPXPTR= <i>ucbpxptr addr</i>	<i>ucbpxptr addr</i> : RS-type address or register (2) - (12).
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,UCBPAREA=NONE	Default: NONE
,LOC=BELOW	Default: BELOW
,LOC=ANY	
SPECIAL=NO	Default: NO
SPECIAL=YES	
,PIN	
,NOPIN	Note: TEXT and PTOKEN are required with PIN and are not valid with NOPIN.
,TEXT= <i>text addr</i>	<i>text addr</i> : RX-type address

Syntax	Description
,PTOKEN= <i>ptoken addr</i>	<i>ptoken addr</i> : RS-type address or register (2) - (12).
,LASTING	Note: Optional with PIN; not valid with NOPIN.
,UNBOUND_ALIAS=NO	Default: NO
,UNBOUND_ALIAS=YES	
,DEVCLASS=DASD	Note: DEVCLASS is valid only with VOLSER= <i>volser addr</i>
,DEVCLASS=DASDTAPE	Default: DASDTAPE
,DEVCLASS=TAPE	
,DYNAMIC=NO	Default: NO
,DYNAMIC=YES	
,RANGE=3DIGIT	Default: 3DIGIT
,RANGE=ALL	
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN=NONE	Default: NONE
,LINKAGE=SYSTEM	Default SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

DEVN=devn addr

DEVNCHAR=devnchar addr

VOLSER=volser addr

LDEVNCHAR=xldevnchar

Specifies the address of an input field that identifies the device whose UCB address is to be obtained.

DEVN specifies the address of a halfword that contains, in binary form, the device number of the device whose UCB address is to be obtained.

DEVNCHAR specifies the address of a 4-character field that contains, in EBCDIC, the device number of the device whose UCB address is to be obtained.

VOLSER specifies the address of a 6-character field that contains, in EBCDIC, the volume serial number of the device whose UCB address is to be obtained.

LDEVNCHAR specifies the name (RS-type), or address in register (2)-(12), of a 5 character input that specifies the logical device number, in EBCDIC, of the device whose UCB address is to be obtained.

Note: A logical device number is represented by a 1-digit subchannel set id followed by the 4-digit device number, sdddd.

,SCHSET=xschset

SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for the device whose UCB address is to be obtained. DEFAULT: 0.

,UCBPTR=ucbptr addr

Specifies the address of a fullword field in which the address of the UCB common segment associated with the requested device (DEVN, DEVNCHAR, or VOLSER) will be returned.

Use the UCBOB structure in the IEFUCBOB mapping macro to map the UCB common segment.

,UCBCXPTR=ucbcxptr addr

Specifies the address of a fullword field in which the system returns the address of the UCB common extension segment associated with the specified device (DEVN, DEVNCHAR, LDEVNCHAR, or VOLSER). Use the IEFUCBOB mapping macro to map the UCB common extension segment.

,UCBPXPTR=ucbpxptr addr

Specifies the address of a fullword field in which the system returns the address of the UCB prefix extension segment associated with the specified device (DEVN, DEVNCHAR, LDEVNCHAR, or VOLSER). Use the IOSDUPFX mapping macro to map the UCB prefix extension segment.

,UCBPAREA=ucbparea addr

,UCBPAREA=NONE

Specifies the address of a 48-character storage area that will receive a copy of the UCB prefix extension segment. The copy of the UCB prefix extension segment is mapped by the IOSDUPI mapping macro.

,LOC=BELOW

,LOC=ANY

Specifies whether the search should be restricted to below 16 megabyte UCB (LOC=BELOW) or should also include above 16 megabyte UCBs (LOC=ANY).

SPECIAL=NO

SPECIAL=YES

Specifies whether the UCB is findable (SPECIAL=YES) or not (SPECIAL=NO). Special devices are those UCBs that represent devices that are not PAV-alias devices in the alternate subchannel set. The 3390S and 3390D device types are special devices.

,PIN

,NOPIN

Specifies whether the UCB is to be pinned to make it ineligible for deletion through dynamic I/O configuration changes. Pinning the UCB ensures that it cannot be deleted while the look-up process is taking place. The PIN parameter specifies that the UCB should be pinned, and NOPIN specifies that it should not. Programs that pin a UCB are also responsible for unpinning it once the UCB is no longer subject to processing. Use the UCBPIN macro with the UNPIN option to unpin the UCB.

,TEXT=text addr

Specifies the address of a 58-character input field containing text that documents the reason for the PIN request. If the pin request remains outstanding during a request for a configuration change that would delete this UCB, the text specified by the TEXT parameter will be displayed in a message identifying the reason for a configuration change failure.

,PTOKEN=ptoken addr

Specifies the address of an 8-character area that is to receive the pin token for the UCB. The caller must use the pin token when unpinning the UCB through the UCBPIN service.

,LASTING

Specifies that the UCB will not be unpinned automatically by the system at the time of termination of the task or address space with which the pin is associated.

When you code LASTING, the system cannot dynamically delete the UCB until your program issues UCBPIN with the UNPIN parameter.

,UNBOUND_ALIAS=NO**,UNBOUND_ALIAS=YES**

Specifies whether the scan should include unbound alias UCBs.

YES

Include unbound alias UCBs

NO

Do not include unbound alias UCBs

Note: The UNBOUND_ALIAS function is intended for IOS use only.

,DEVCLASS=DASD**,DEVCLASS=DASDTAPE****,DEVCLASS=TAPE**

Specifies the device class that is to be searched for the VOLSER look-up.

DASD

Searches UCBs for direct access device class

DASDTAPE

Searches UCBs for DASD and tape classes

TAPE

Searches UCBs for tape class

,DYNAMIC=NO**,DYNAMIC=YES**

Specifies if static or dynamic UCBs are to be looked at:

NO

Only static and installation-static UCBs

YES

Static, installation-static, and dynamic UCBs

,RANGE=3DIGIT**,RANGE=ALL**

Specifies whether the look-up should be restricted to UCBs with 3-digit device numbers (3DIGIT) or should include all UCBs (ALL).

,IOCTOKEN=ioctoken addr**,IOCTOKEN=NONE**

Specifies the address of a 48-character area that contains the MVS I/O configuration token that the caller supplies to UCBLOOK. Obtain this token by issuing the IOCINFO macro, which is described in [z/OS MVS Programming: Assembler Services Reference ABE-HSP](#). If the I/O configuration token that is current when UCBLOOK is invoked does not match the token whose address is supplied as input by *ioctoken addr*, the caller will be notified through a return code.

If the input IOCTOKEN (specified by *ioctoken addr*) is set to binary zeros, UCBLOOK will set IOCTOKEN to the current I/O configuration token.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that should be generated:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=plistver

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **2**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 2

,RETCODE=retcode addr

Specifies the fullword location where the system is to store the return code. The return code is also in GPR 15.

,RSNCODE=rsncode addr

Specifies the fullword location where the system is to store the reason code. The reason code is also in GPR 0.

ABEND codes

None.

Return and reason codes

When control returns from UCBLOOK, GPR 15 (and *retcode addr*, if you coded RETCODE) contains a return code and, for return code X'08', GPR 0 (and *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: Completed successfully. Action: None.
04	None	Meaning: Program error. No UCB exists for the device number or VOLSER specified as input. The contents of UCBPTR remain unchanged. Action: Correct the DEVN, DEVNCHAR, or VOLSER parameter. Also, make sure the parameter list was not overlaid.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
08	01	Meaning: Program error. An ALET in the parameter list is not valid. Action: Make sure the parameter list was not overlaid.
08	02	Meaning: Program error. An error occurred in accessing the caller's parameter list. Action: Make sure the parameter list was not overlaid.
08	04	Meaning: Program error. An error occurred in referencing the caller-supplied area for the UCB prefix extension segment. This reason code is valid only for callers using the UCBPAREA parameter. Action: Correct the UCBPAREA parameter.
08	05	Meaning: Program error. An error occurred in referencing the caller-supplied area for the IOCTOKEN. This reason code is valid only for callers using the IOCTOKEN keyword. Action: Correct the IOCTOKEN parameter.
08	0A	Meaning: Program error. An error occurred in referencing the caller-supplied area for the pin reason text. This reason code is valid only for callers using the TEXT parameter. Action: Correct the TEXT parameter.
08	0B	Meaning: The value specified on the SCHSET keyword is not valid. Action: Enter a valid value.
0C	None	Meaning: Program error. The UCB definition for the device specified in DEVN, DEVNCHAR, or VOLSER is not longer consistent with the UCB definition represented by the input I/O configuration token, or a DDR has occurred. This return code is valid only for callers using the IOCTOKEN parameter. Action: Change the IOCTOKEN parameter or change the program so that the token is correct.
20	None	Meaning: System error. An unexpected error occurred. Action: Supply the return code to the appropriate IBM support personnel.

UCBLOOK - List form

Use the list form of the UCBLOOK macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses for storing the parameters.

Syntax

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros.

The list form of the UCBLOOK macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBLOOK

Syntax	Description
UCBLOOK	
b	One or more blanks must follow UCBLOOK
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : symbol.
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string.
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of the UCBLOOK macro with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBLOOK macro.

The *list addr* parameter specifies the address of the storage area for the parameter list.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBLOOK - Execute form

Use the execute form of the UCBLOOK macro together with the list form for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

Syntax

The execute form of the UCBLOOK macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBLOOK

Syntax	Description
UCBLOOK	
b	One or more blanks must follow UCBLOOK
,SCHSET= <i>xschset</i>	<i>xschset</i> RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12).
DEVNCHAR= <i>devnchar addr</i>	<i>devnchar addr</i> : RS-type address or register (2) - (12).
VOLSER= <i>volser addr</i>	<i>volser addr</i> : RS-type address or register (2) - (12).
LDEVNCHAR= <i>xldevnchar</i>	<i>xldevnchar</i> RS-type address or register (2) - (12).
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12).
,UCBCXPTR= <i>ucbcxptr addr</i>	<i>ucbcxptr addr</i> : RS-type address or register (2) - (12).
,UCBPXPTR= <i>ucbpxptr addr</i>	<i>ucbpxptr addr</i> : RS-type address or register (2) - (12).
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,UCBPAREA=NONE	Default: NONE
,LOC=BELOW	Default: BELOW
,LOC=ANY	
,PIN	
,NOPIN	Note: TEXT and PTOKEN are required with PIN and are not valid with NOPIN.
,TEXT= <i>text addr</i>	<i>text addr</i> : RX-type address
,PTOKEN= <i>ptoken addr</i>	<i>ptoken addr</i> : RS-type address or register (2) - (12).
,LASTING	Note: Optional with PIN; not valid with NOPIN.
,UNBOUND_ALIAS=NO	Default: NO
,UNBOUND_ALIAS=YES	

Syntax	Description
,DEVCLASS=DASD	Note: DEVCLASS is valid only with VOLSER= <i>volser addr</i>
,DEVCLASS=DASDTAPE	Default: DASDTAPE
,DEVCLASS=TAPE	
,DYNAMIC=NO	Default: NO
,DYNAMIC=YES	
,RANGE=3DIGIT	Default: 3DIGIT
,RANGE=ALL	
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN=NONE	Default: NONE
,LINKAGE=SYSTEM	Default SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE
SPECIAL=NO	Default: NO
SPECIAL=YES	

Parameters

The parameters are explained under the standard form of the UCBLOOK macro with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBLOOK macro.

The *list addr* parameter specifies the address of the storage area for the parameter list. COMPLETE specifies that the system is to check for required parameters and supply defaults for optional parameters that were not specified.

Chapter 28. UCBPIN – Pinning or unpinning a UCB

Description

Pinning a UCB ensures that the UCB cannot be deleted while a program is in the process of looking at a UCB. Programs that pin a UCB are also responsible for unpinning it once the UCB is no longer subject to processing.

Authorized programs that obtain UCB addresses, either through UCB services or other means, can use the UCBPIN macro to pin and unpin UCBs. Pinning and unpinning should be done any time a UCB is used, unless one of the following is true:

- The caller is running in an environment where dynamic configuration changes cannot occur.
- The caller can otherwise guarantee that the UCB will not be deleted. (The device is allocated.)

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state or PKM keys 0-7. For LINKAGE=BRANCH, all of the following: <ul style="list-style-type: none"> • Supervisor state with key 0 • 31-bit addressing mode • Primary ASC mode • Parameter list and any data areas it points to must be in fixed storage or, if the caller is disabled, in disabled reference (DREF) storage.
Dispatchable unit mode:	Task or SRB
Cross memory mode:	PASN=HASN=SASN or PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary or access register (AR)
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	No requirement
Control parameters:	Must be in the primary address space or be in an address/data space that is addressable through a public entry on the caller's dispatchable unit access list (DU-AL)

Programming requirements

If the program is in AR mode, issue the SYSSTATE ASCENV=AR macro before UCBPIN. SYSSTATE ASCENV=AR tells the system to generate code appropriate for AR mode.

Restrictions

None.

Register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the general purpose registers (GPRs) contain:

Register Contents

0

Reason code if GPR 15 contains a return code of 08; otherwise, used as a work register by the system

1

Used as a work register by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the access registers (ARs) contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The standard form of the UCBPIN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBPIN
UCBPIN	
b	One or more blanks must follow UCBPIN

Syntax	Description
PIN	
UNPIN	Note: See the table following this diagram for valid parameter combinations.
,PTOKEN= <i>ptoken addr</i>	<i>ptoken addr</i> : RS-type address or register (2) - (12).
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12).
,TEXT= <i>text addr</i>	<i>text addr</i> : RX-type address
,LASTING	
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,TO= <i>xto</i>	<i>xto</i> : RS-type address or register (2) - (12).
,FROM= <i>xfrom</i>	<i>xfrom</i> : RS-type address or register (2) - (12).
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	

The following table shows how other parameters may be used with PIN and UNPIN.

Parameters	PIN	UNPIN
PTOKEN	required	required

Parameters	PIN	UNPIN
UCBPTR	required	not valid
TEXT	required	not valid
LASTING	optional	not valid
IOCTOKEN	optional	not valid
LINKAGE	optional	optional
RETCODE	optional	optional
RSNCODE	optional	optional

Parameters	PIN	UNPIN
PTOKEN	required	required
UCBPTR	required	not valid
TEXT	required	not valid
LASTING	optional	not valid
IOCTOKEN	optional	not valid
LINKAGE	optional	optional
RETCODE	optional	optional
RSNCODE	optional	optional
TO	not valid	not valid
FROM	not valid	not valid

Parameters

The parameters are explained as follows:

PIN

UNPIN

Specifies whether the UCB is to be pinned or unpinned.

,PTOKEN=*ptoken addr*

Specifies the address of an 8-character field used to contain the pin token. For PIN requests, PTOKEN specifies an output field that receives the pin token for the UCB that is to be pinned. For UNPIN requests, PTOKEN specifies an input field that contains the pin token for the UCB that is to be unpinned; this token must match the one that was returned on the corresponding PIN request. UCBPIN will reset PTOKEN to binary zeros if the UNPIN function is successful.

,UCBPTR=*ucbptr addr*

Specifies the address of a pointer containing the address of the UCB common segment for the UCB that is to be pinned.

,TEXT=*text addr*

Specifies the address of a 58-character input field containing text that documents the reason for the PIN request. If the pin request remains outstanding during a request for a configuration change that would delete this UCB, the text specified by the TEXT parameter will be displayed in a message identifying the reason for a configuration change failure.

,LASTING

Specifies that the UCB will not be unpinned automatically by the system at the time of termination of the task or address space with which the pin is associated.

When you code LASTING, the system cannot dynamically delete the UCB until your program issues UCBPIN with the UNPIN parameter.

,IOCTOKEN=*ioctoken addr*

Specifies the address of a 48-character area that contains the MVS I/O configuration token that you supply to UCBPIN. You can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBPIN is invoked does not match the token specified as input by *ioctoken addr*, the caller will be notified through a return code.

If the input IOCTOKEN (specified by *ioctoken addr*) is set to binary zeros, UCBPIN will set IOCTOKEN to the current I/O configuration token.

,RETCODE=*retcode addr*

Specifies the fullword location where the system is to store the return code. The return code is also in GPR 15.

,RSNCODE=*rsncode addr*

Specifies the fullword location where the system is to store the reason code. The reason code is also in GPR 0 if the return code is X'08'.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Specifies the type of call that the system is to generate:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

Return and reason codes

When control returns from UCBPIN, GPR 15 (and *retcode addr*, if you coded RETCODE) contains one of the following return codes:

Table 43. Return Codes for the UCBPIN Macro	
Hexadecimal Return Code	Meaning
00	Meaning: UCBPIN completed successfully. For PIN requests, the UCB has been pinned and the pin token has been returned in PTOKEN. For UNPIN requests, the UCB has been unpinned and PTOKEN has been reset to binary zeros.
08	<p>Meaning: There is an error in the caller's parameters, as explained by the hexadecimal reason code that accompanies this return code. The reason code is in GPR 0 (and in <i>rsncode addr</i>, if you coded RSNCODE).</p> <p>Reason Code Meaning</p> <p>01 An ALET in the parameter list is not valid; the caller might have inadvertently written over an area in the parameter list.</p> <p>02 An error occurred in accessing the caller's parameter list.</p> <p>03 The UCB address provided by the caller does not represent a valid UCB.</p> <p>04 The PTOKEN supplied as input on an UNPIN request does not represent a valid pin token.</p> <p>05 An error occurred in referencing the user-supplied work area for the IOCTOKEN. This reason code is valid only for callers using the IOCTOKEN keyword.</p> <p>0A An error occurred in referencing the user-supplied work area for the pin reason text. This reason code is valid only for callers using the TEXT keyword.</p>
0C	Meaning: The UCB definition is not consistent with the input configuration token, or a DDR has occurred. This return code is valid only for callers using the IOCTOKEN keyword.

Table 43. Return Codes for the UCBPIN Macro (continued)

Hexadecimal Return Code	Meaning
20	Meaning: An unexpected error occurred.

UCBPIN - List form

Use the list form of the UCBPIN macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses for storing the parameters.

Syntax

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros.

The list form of the UCBPIN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBPIN
UCBPIN	
␣	One or more blanks must follow UCBPIN
MF=(L, <i>list addr</i>)	<i>list addr</i> : Symbol.
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string.
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained as follows:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBPIN macro.

The *list addr* parameter specifies the address of the storage area for the parameter list.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBPIN - Execute form

Use the execute form of the UCBPIN macro together with the list form for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

Syntax

The execute form of the UCBPIN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBPIN
UCBPIN	
b	One or more blanks must follow UCBPIN
PIN	
UNPIN	Note: See the table following this diagram for valid parameter combinations.
,PTOKEN= <i>ptoken addr</i>	<i>ptoken addr</i> : RS-type address or register (2) - (12).
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12).
,TEXT= <i>text addr</i>	<i>text addr</i> : RX-type address
,LASTING	
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,TO= <i>xto</i>	<i>xto</i> : RS-type address or register (2) - (12).
,FROM= <i>xfrom</i>	<i>xfrom</i> : RS-type address or register (2) - (12).
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).

Syntax	Description
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,LINKAGE=SYSTEM	Default: SYSTEM
,LINKAGE=BRANCH	
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

The following table shows how other parameters may be used with PIN and UNPIN.

Parameters	PIN	UNPIN
PTOKEN	required	required
UCBPTR	required	not valid
TEXT	required	not valid
LASTING	optional	not valid
IOCTOKEN	optional	not valid
LINKAGE	optional	optional
RETCODE	optional	optional
RSNCODE	optional	optional
MF	required	required
TO	not valid	not valid
FROM	not valid	not valid

Parameters

The parameters are explained under the standard form of the UCBPIN macro with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBPIN macro.

The *list addr* parameter specifies the address of the storage area for the parameter list. COMPLETE specifies that the system is to check for required parameters and supply defaults for optional parameters that were not specified.

Chapter 29. UCBSCAN – Scan UCBs

Description

Use the UCBSCAN macro to scan unit control blocks (UCBs) and return a copy of a UCB or a UCB address on each invocation.

Two types of scans are available with UCBSCAN: A scan of all UCBs, and a scan of all UCBs within a particular device class. For each type of scan, the caller may optionally:

- Restrict the scan to UCBs defined as static or installation-static.
- Restrict the scan to UCBs with 3-digit device numbers.
- Restrict the scan to addresses of below 16 megabyte UCBs
- Request alias UCBs for a parallel access volume.
- Specify the device number with which the scan should begin.

UCBSCAN presents the UCBs in ascending device number order. UCBSCAN provides two options as follows:

COPY

On each invocation, UCBSCAN returns a copy of requested UCB segments and data in caller-supplied areas.

Address

On each invocation, UCBSCAN returns the address of the UCB, the address of requested UCB segments, and, optionally, a copy of the UCB prefix extension segment. The caller can specify whether the scan includes above 16 megabyte UCBs or only below 16 megabyte UCBs. The caller must pin and unpin the UCB unless one of the following is true:

- The caller is running in an environment where dynamic configuration changes cannot occur
- The caller can otherwise guarantee that the UCB will not be deleted.

See *z/OS MVS Programming: Authorized Assembler Services Guide* for information on pinning UCBs.

LINKAGE=BRANCH is intended for performance-sensitive programs.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	<p>For the COPY parameter: Problem state with any PSW key</p> <p>For the ADDRESS parameter: Supervisor state or PKM allowing key 0-7</p> <p>For the LINKAGE=BRANCH parameter, all of the following:</p> <ul style="list-style-type: none"> • Supervisor state with key 0 • 31-bit addressing mode • Primary ASC mode • Parameter list and any data areas it points to must be in fixed storage or, if the caller is disabled, in disabled reference (DREF) storage.
Dispatchable unit mode:	Task or SRB

Environmental factor	Requirement
Cross memory mode:	Any PASN, any HASN, any SASN.
AMODE:	24- or 31-bit.
ASC mode:	Primary or access register (AR).
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	The caller may hold locks, but is not required to hold any.
Control parameters:	Must be in the primary address space or, for AR-mode callers, must be in an address/data space that is addressable through a public entry on the caller's dispatchable unit access list (DU-AL).

Programming requirements

If in AR mode, issue SYSSTATE ASCENV=AR before issuing UCBSCAN.

Restrictions

None.

Input register information

Before issuing the UCBSCAN macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register

Contents

0

Reason code if GPR 15 contains a return code of 04 or 08; otherwise, used as a work register by the system

1

Used as a work register by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the access registers (ARs) contain:

Register

Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Parameters

The parameters are explained as follows:

COPY

Specifies that a copy of the UCB is to be obtained. See [z/OS HCD Planning](#) for a list of the MVS services that accept a UCB copy.

Note: When you issue UCBSCAN to obtain a UCB copy, the UCBID field in the copy is set to x'CC'.

,WORKAREA=workarea addr

Specifies the address of a 100-character work area used by the UCBSCAN service. The caller must initialize this work area to binary zeros before starting a UCB scan. On subsequent invocations of UCBSCAN within the same scan, the caller must leave the contents of this work area unchanged.

,UCBAREA=ucbarea addr

Specifies the address of a 48-character storage area that will receive a copy of the UCB common segment and the UCB device-dependent segment. See [z/OS HCD Planning](#) for a list of the MVS services that accept a UCB copy.

The caller does not need to initialize this area. Use the IEFUCBOB mapping macro to map the area. The contents of certain fields in the copy are:

- The UCBEXTP field contains either:
 - The address of the CMXTAREA, if CMXTAREA is below 16 MB
 - 0, if CMXTAREA is above 16 MB or if the CMXTAREA parameter is not specified
- The UCBNXUCB field is 0, because this field is not valid in the UCB copy.
- Address fields in the copy might not contain valid addresses, so do not use these addresses to reference the data areas they point to.

,CMXTAREA=cmxtarea addr

,CMXTAREA=NONE

Specifies the address of a 32-character storage area that will receive a copy of the UCB common extension segment. See [z/OS HCD Planning](#) for a list of the MVS services that accept a UCB copy and require this segment as part of a UCB copy.

Use the UCBCMEXT DSECT in the IEFUCBOB mapping macro to map the area. If the CMXTAREA area is below 16 MB, the UCBEXTP field in the UCBAREA area contains the address of the CMXTAREA area. If the CMXTAREA area is above 16 MB, the caller must explicitly supply the address of the CMXTAREA area because the UCBEXTP field will contain 0.

The UCBIEXT field contains 0 because this field is not valid in the UCB copy.

The UCBCLEXT field contains the address of the DCEAREA if the UCB has a device class extension and the caller specified the DCEAREA parameter. Otherwise, the field contains 0.

,UCBPAREA=ucbparea addr

,UCBPAREA=NONE

Specifies the address of a 48-character storage area that will receive a copy of the UCB prefix extension segment. This keyword is required if SUBCHANNELSET=ALL is specified. The area can be mapped by the IOSDUPI mapping macro.

,DCEAREA=dcearea addr

,DCEAREA=NONE

Specifies the address of a storage area that will receive a copy of the UCB device class extension segment. See [z/OS HCD Planning](#) for a list of the MVS services that accept a UCB copy and require this segment as part of a UCB copy.

Note: If DCEAREA=NONE is coded, then DCELEN=0 must be coded. If DCEAREA=NONE is defaulted, then DCELEN does not have to be coded.

,DCELEN=*length addr*

Specifies the address of a 2-byte field that contains the length of the area specified by DCEAREA. The length specified must be 1 through 256 bytes. DCELEN is required with DCEAREA.

,VOLSER=*volser addr*

,VOLSER=NONE

Specifies the address of a 6-character field that indicates, in EBCDIC, the volume serial number of the device for which a UCB copy is to be obtained.

,DEVNCHAR=*devnchar addr*

Specifies the address of a 4-character field that is to receive the EBCDIC device number associated with the UCB copy.

,DEVN=*devn addr*

,DEVN=0

Specifies (DEVN=*devn addr*) an input halfword that contains, in binary form, the device number with which the scan is to begin. The default, DEVN=0, starts the scan with the first UCB.

,SUBCHANNELSET=ID

,SUBCHANNELSET=ALL

,SUBCHANNELSET=ID

Indicates the UCB scan is based on one subchannel set. DEFAULT: ID

,SCHSET=*xschset*

SCHSET=0

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the UCB scan is to be performed. DEFAULT: 0.

,SUBCHANNELSET=ALL

Indicates the UCB scan is based on all subchannel sets. DEFAULT: ID

,LDEVNCHAR=*xldevnchar*

Indicates the name (RS-type), or address in register (2)-(12), of an optional 5 character output which is to contain the EBCDIC logical device number associated with the UCB copy.

Note: A logical device number is represented by the 1-digit subchannel set id followed by a 4-digit device number, sdddd.

,DYNAMIC=NO

,DYNAMIC=YES

Specifies whether the scan should be restricted to static and installation-static UCBs (DYNAMIC=NO) or should also include dynamic UCBs (DYNAMIC=YES).

,RANGE=3DIGIT

,RANGE=ALL

Specifies whether the scan should be restricted to UCBs with 3-digit device numbers (3DIGIT) or should also include UCBs with 4-digit device numbers (ALL).

,UNBOUND_ALIAS=NO

,UNBOUND_ALIAS=YES

,UNBOUND_ALIAS=ONLY

Specifies whether the scan should include unbound alias UCBs.

YES

Include unbound alias UCBs

NO

Do not include unbound alias UCBs

ONLY

Include only unbound alias UCBs

Note: The UNBOUND_ALIAS function is intended for IOS use only.

SPECIAL=NO**SPECIAL=YES****SPECIAL=ONLY**

Specifies whether the UCB is findable (SPECIAL=YES) or not (SPECIAL=NO). SPECIAL=ONLY should be used to scan for only special devices. Special devices are those UCBs that represent devices that are not PAV-alias devices in the alternate subchannel set. The 3390S and 3390D device types are special devices.

,DEVCLASS=ALL**,DEVCLASS=CHAR****,DEVCLASS=COMM****,DEVCLASS=CTC****,DEVCLASS=DASD****,DEVCLASS=DISP****,DEVCLASS=TAPE****,DEVCLASS=UREC**

Specifies the device class that is to be scanned:

ALL

Scans UCBs for all device classes

CHAR

Scans UCBs for character reader device class

COMM

Scans UCBs for communications device class

CTC

Scans UCBs for channel to channel device class

DASD

Scans UCBs for direct access device class

DISP

Scans UCBs for display device class

TAPE

Scans UCBs for tape device class

UREC

Scans UCBs for unit record device class

,DEVCID=devcid addr

Specifies the address of an 8-bit input field that contains the device class ID of the device class to be scanned. The value in this byte represents the third byte in the UCBTYP field of each device in the class.

If you specify DEVCID, only UCBs of the particular device class specified will be presented, and the DEVCLASS parameter is ignored.

,IOCTOKEN=ioctoken addr**,IOCTOKEN=NONE**

Specifies the address of a 48-character storage area that contains the MVS I/O configuration token. The caller can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBSCAN is invoked does not match the token whose address is supplied as input by *ioctoken addr*, the caller will be notified through a return code.

If the input IOCTOKEN (specified by *ioctoken addr*) is set to binary zeros, UCBSCAN will set IOCTOKEN to the current I/O configuration token at the start of the scan.

,LINKAGE=SYSTEM**,LINKAGE=BRANCH**

Specifies the type of call that should be generated:

- **SYSTEM:** Specifies a Program Call (PC)

- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION

,PLISTVER=MAX

,PLISTVER=plistver

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **1**, if you use the currently available parameters.

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 1

,RETCODE=retcode addr

Specifies the fullword location where the system is to store the return code. The return code is also in GPR 15.

,RSNCODE=rsncode addr

Specifies the fullword location where the system is to store the reason code. The reason code is also in GPR 0.

Return and reason codes

When control returns from USBSCAN, GPR 15 (and *retcode addr*, if you coded RETCODE) contains a return code and, for some return codes, GPR 0 (or *rsncode addr*, if you coded RSNCODE) contains a reason code.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: UCBSCAN completed successfully. Action: None.
04	01	Meaning: UCBSCAN processing ended. All UCBs that met the search criteria have been presented to the caller. The contents of UCBAREA are unchanged, and WORKAREA has been reset to binary zeros. Action: None.
08	01	Meaning: Program error. A caller in AR mode specified an ALET that was not valid. Action: Correct the ALET and reissue the macro. Possibly the caller wrote over an area in the parameter list; look for this error.
08	02	Meaning: Program error. An error occurred when the system tried to access the caller's parameter list. Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
08	03	<p>Meaning: Program error. An error occurred in referencing the caller-supplied area for the UCB copy; the area was specified in the UCBAREA parameter.</p> <p>Action: Correct the UCBAREA parameter.</p>
08	04	<p>Meaning: Program error. An error occurred in referencing the caller-supplied area for the UCB prefix extension segment data. This reason code is valid only for callers using the UCBPAREA parameter.</p> <p>Action: Correct the UCBPAREA parameter.</p>
08	05	<p>Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter.</p> <p>Action: Correct the IOCTOKEN parameter.</p>
08	08	<p>Meaning: Program error. An error occurred in referencing the caller-supplied work area specified in the WORKAREA parameter.</p> <p>Action: Correct the WORKAREA parameter.</p>
08	09	<p>Meaning: Program error. An error occurred in referencing the caller-supplied CMXTAREA area. This reason code is valid only for callers using the CMXTAREA parameter.</p> <p>Action: Correct the CMXTAREA parameter.</p>
08	0B	<p>Meaning: Program error. An error occurred in referencing the caller-supplied DCEAREA area. This reason code is valid only for callers using the DCEAREA parameter.</p> <p>Action: Correct the DCEAREA parameter.</p>
08	0C	<p>Meaning: Program error. The caller specified a volume serial number that is not valid. (Note that binary zeros are not considered valid.) This reason code is valid only for callers using the VOLSER parameter.</p> <p>Action: Correct the VOLSER parameter.</p>
08	0D	<p>Meaning: Program error. For the DCEAREA token, the caller specified a length that is negative, is zero, or exceeds 256 bytes. This reason code is valid only for callers using the DCELEN parameter.</p> <p>Action: Correct the DCELEN parameter.</p>
08	0E	<p>Meaning: The value specified on the SCHSET keyword is not valid.</p> <p>Action: Correct the SCHSET value.</p>
0C	None	<p>Meaning: Environmental error. The I/O configuration has changed, so that the I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter.</p> <p>Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero. Start the scan from the beginning.</p>
20	None	<p>Meaning: System error. An unexpected error occurred.</p> <p>Action: Supply the return code to the appropriate IBM support personnel.</p>

UCBSCAN COPY

Syntax

The standard form of the COPY function of the UCBSCAN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBSCAN.
UCBSCAN	
b	One or more blanks must follow UCBSCAN.
COPY	Default: COPY
,WORKAREA= <i>workarea addr</i>	<i>workarea addr</i> : RX-type address or register (2) - (12).
,UCBAREA= <i>ucbarea addr</i>	<i>ucbarea addr</i> : RX-type address or register (2) - (12).
,CMXTAREA= <i>cmxtarea addr</i>	<i>cmxtarea addr</i> : RX-type address or register (2) - (12).
,CMXTAREA=NONE	Default: NONE
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,UCBPAREA=NONE	Default: NONE
,DCEAREA= <i>dcearea addr</i>	<i>dcearea addr</i> : RX-type address or register (2) - (12).
,DCEAREA=NONE	Default: NONE
,DCELEN= <i>length addr</i>	<i>length addr</i> : RS-type address or register (2) - (12).
	Note: DCELEN is valid only with DCEAREA and is required with DCEAREA.
,VOLSER= <i>volser addr</i>	<i>volser addr</i> : RS-type address or register (2) - (12).
,VOLSER=NONE	Default: NONE
,DEVNCHAR= <i>devnchar addr</i>	<i>devnchar addr</i> : RS-type address or register (2) - (12).

Syntax	Description
,LDEVNCHAR= <i>xldevnchar</i>	<i>xldevnchar</i> : RS-type address or register (2) - (12).
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12).
,DEVN=0	Default: 0
,SUBCHANNELSET=ID	
,SCHSET= <i>xschset</i>	<i>xschset</i> RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,SUBCHANNELSET=ALL	
,DYNAMIC=NO	Default: NO
,DYNAMIC=YES	
,RANGE=3DIGIT	Default: 3DIGIT
,RANGE=ALL	
,UNBOUND_ALIAS=NO	Default: NO
,UNBOUND_ALIAS=YES	
,DEVCLASS=ALL	Default: ALL
,DEVCLASS=CHAR	
,DEVCLASS=COMM	
,DEVCLASS=CTC	
,DEVCLASS=DASD	
,DEVCLASS=DISP	
,DEVCLASS=TAPE	
,DEVCLASS=UREC	
,DEVCID= <i>devcid addr</i>	<i>devcid addr</i> : RS-type address
,DEVCID=0	Default: 0
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN=NONE	Default: NONE
,LINKAGE=SYSTEM	Default: LINKAGE=SYSTEM
,LINKAGE=BRANCH	

Syntax	Description
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 1
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

UCBSCAN COPY - List form

Use the list form of the UCBSCAN macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses for storing the parameters.

Syntax

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros”](#) on page 11 for further information.

The list form of the COPY function of the UCBSCAN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBSCAN.
UCBSCAN	
␣	One or more blanks must follow UCBSCAN.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 1
MF=(L, <i>list addr</i>)	<i>list addr</i> : Symbol.
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string.
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Syntax	Description

Parameters

The parameters are explained under that standard form of the UCBSCAN macro with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBSCAN macro.

The *list addr* parameter specifies the address of the storage area for the parameter list.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBSCAN COPY - Execute form

Use the execute form of the UCBSCAN macro together with the list form for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

Syntax

The execute form of the COPY function of the UCBSCAN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBSCAN.
UCBSCAN	
␣	One or more blanks must follow UCBSCAN.
COPY	Default: COPY
,WORKAREA= <i>workarea addr</i>	<i>workarea addr</i> : RX-type address or register (2) - (12).
,UCBAREA= <i>ucbarea addr</i>	<i>ucbarea addr</i> : RX-type address or register (2) - (12).
,CMXTAREA= <i>cmxtarea addr</i>	<i>cmxtarea addr</i> : RX-type address or register (2) - (12).

Syntax	Description
,CMXTAREA=NONE	Default: NONE
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,UCBPAREA=NONE	Default: NONE
,DCEAREA= <i>dcearea addr</i>	<i>dcearea addr</i> : RX-type address or register (2) - (12).
,DCEAREA=NONE	Default: NONE
,DCELEN= <i>length addr</i>	<i>length addr</i> : RS-type address or register (2) - (12).
	Note: DCELEN is valid only with DCEAREA and is required with DCEAREA.
,VOLSER= <i>volser addr</i>	<i>volser addr</i> : RS-type address or register (2) - (12).
,VOLSER=NONE	Default: NONE
,DEVNCHAR= <i>devnchar addr</i>	<i>devnchar addr</i> : RS-type address or register (2) - (12).
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12).
,DEVN=0	Default: 0
,SUBCHANNELSET=ID	
,SCHSET= <i>xschset</i>	<i>xschset</i> RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,SUBCHANNELSET=ALL	
,DYNAMIC=NO	Default: NO
,DYNAMIC=YES	
,RANGE=3DIGIT	Default: 3DIGIT
,RANGE=ALL	
,UNBOUND_ALIAS=NO	Default: NO
,UNBOUND_ALIAS=YES	
,UNBOUND_ALIAS=ONLY	
,DEVCLASS=ALL	Default: ALL
,DEVCLASS=CHAR	

Syntax	Description
,DEVCLASS=COMM	
,DEVCLASS=CTC	
,DEVCLASS=DASD	
,DEVCLASS=DISP	
,DEVCLASS=TAPE	
,DEVCLASS=UREC	
,DEVCID= <i>devcid addr</i>	<i>devcid addr</i> : RS-type address
,DEVCID=0	Default: 0
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN=NONE	Default: NONE
,LINKAGE=SYSTEM	Default: LINKAGE=SYSTEM
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 1
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE

Parameters

The parameters are explained under the standard form of the COPY function of the UCBSCAN macro with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBSCAN macro.

The *list addr* parameter specifies the address of the storage area for the parameter list.

COMPLETE specifies that the system is to check for required parameters and supply defaults for optional parameters that were not specified.

UCBSCAN ADDRESS

Syntax

The standard form of the ADDRESS function of the UCBSCAN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBSCAN.
UCBSCAN	
b	One or more blanks must follow UCBSCAN.
ADDRESS	Note: COPY is the default.
,WORKAREA= <i>workarea addr</i>	<i>workarea addr</i> : RX-type address or register (2) - (12).
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12).
,UCBCXPTR= <i>ucbcxptr addr</i>	<i>ucbcxptr</i> : RX-type address or register (2) - (12).
,UCBPXPTR= <i>ucbpxptr addr</i>	<i>ucbpxptr</i> : RX-type address or register (2) - (12).
,LOC=BELOW	Default: BELOW
,LOC=ANY	
,PIN	Note: TEXT and PTOKEN are required with PIN
,NOPIN	
,TEXT= <i>text addr</i> :	<i>text addr</i> : RX-type address
	Note: Required with PIN, not valid with NOPIN.
,PTOKEN= <i>ptoken addr</i> :	<i>ptoken addr</i> : RS-type address or register (2) - (12).
	Note: Required with PIN, not valid with NOPIN.

Syntax	Description
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,UCBPAREA=NONE	Default: NONE
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12).
,DEVN=0	Default: 0
,SUBCHANNELSET=ID	
,SCHSET= <i>xschset</i>	<i>xschset</i> RS-type address or register (2) - (12).
,SCHSET=0	Default: 0
,SUBCHANNELSET=ALL	
,DYNAMIC=NO	Default: NO
,DYNAMIC=YES	
,RANGE=3DIGIT	Default: 3DIGIT
,RANGE=ALL	
,UNBOUND_ALIAS=NO	Default: NO
,UNBOUND_ALIAS=YES	
,UNBOUND_ALIAS=ONLY	
,DEVCLASS=ALL	Default: ALL
,DEVCLASS=CHAR	
,DEVCLASS=COMM	
,DEVCLASS=CTC	
,DEVCLASS=DASD	
,DEVCLASS=DISP	
,DEVCLASS=TAPE	
,DEVCLASS=UREC	
,DEVCID= <i>devcid addr</i>	<i>devcid addr</i> : RS-type address
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN=NONE	Default: NONE
,LINKAGE=SYSTEM	Default: LINKAGE=SYSTEM

Syntax	Description
,LINKAGE=BRANCH	
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 1 - 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

ADDRESS

Specifies that a UCB address is to be obtained.

,WORKAREA=*workarea addr*

Specifies the address of a 100-character work area that will be used by the UCBSCAN service.

The caller must initialize this work area to binary zeros before starting a UCB scan. On subsequent invocations of UCBSCAN within the same scan, the caller must leave the contents of this work area unchanged.

,UCBPTR=*uchptr addr*

Specifies the address of a pointer in which the address of the UCB common segment for the next UCB that meets the search criteria will be returned.

Use the UCBOB structure in the IEFUCBOB mapping macro to map the UCB common segment.

,UCBCXPTR=*ucbcxptr addr*

Specifies the address of a fullword field in which the system will return the address of the UCB common extension. Use the IEFUCBOB mapping macro to map the UCB common extension segment.

,UCBPXPTR=*ucbpxptr addr*

Specifies the address of a fullword field in which the system will return the address of the UCB prefix extension. Use the IOSDUPFX mapping macro to map the UCB prefix extension segment.

,LOC=BELOW

,LOC=ANY

Specifies whether the scan should be restricted to below 16 megabyte UCBs (LOC=BELOW) or should also include above 16 megabyte UCBs (LOC=ANY).

,PIN

,NOPIN

Specifies whether the UCB is to be pinned to make it ineligible for deletion through the dynamic UCB process. Pinning the UCB ensures that it will not be deleted while the scan process is taking place. The PIN parameter specifies that the UCB should be pinned, and NOPIN specifies that it should not. Programs that pin a UCB are also responsible for unpinning it once the UCB is no longer subject to processing. Use the UCBPIN macro with the UNPIN option to unpin the UCB.

,TEXT=*text addr*

Specifies the address of a 58-character input field containing text that documents the reason for the PIN request. If the pin request remains outstanding during a request for a configuration change that would delete this UCB, the text specified by the TEXT parameter will be displayed in a message identifying the reason for a configuration change failure.

,PTOKEN=*ptoken addr*

Specifies the address of an 8-character area that is to receive the pin token for the UCB. The caller must use the pin token when unpinning the UCB.

,UCBPAREA=*ucbparea addr***,UCBPAREA=NONE**

Specifies the address of a 48-character storage area that will receive a copy of the UCB prefix extension segment. The area can be mapped by the IOSDUPI mapping macro.

,DEVN=*devn addr***,DEVN=0**

Specifies (DEVN=*devn addr*) an input halfword that contains, in binary form, the device number with which the scan is to begin. The default, DEVN=0, starts the scan with the first UCB.

,SUBCHANNELSET=ID**,SUBCHANNELSET=ALL****,SUBCHANNELSET=ID**

Indicates the UCB scan is based on one subchannel set. DEFAULT: ID

,SCHSET=*xschset***SCHSET=0**

Specifies the name (RS-type), or address in register (2)-(12), of an optional byte input that specifies a subchannel set for which the UCB scan is to be performed. DEFAULT: 0.

,SUBCHANNELSET=ALL

Indicates the UCB scan includes all subchannel sets. DEFAULT: ID

,DYNAMIC=NO**,DYNAMIC=YES**

Specifies whether the scan should be restricted to static and installation-static UCBs (DYNAMIC=NO) or should also include dynamic UCBs (DYNAMIC=YES).

,RANGE=3DIGIT**,RANGE=ALL**

Specifies whether the scan should be restricted to UCBs with 3-digit device numbers (3DIGIT) or should also include UCBs with 4-digit device numbers (ALL).

,UNBOUND_ALIAS=NO**,UNBOUND_ALIAS=YES****,UNBOUND_ALIAS=ONLY**

Specifies whether the scan should include unbound alias UCBs.

YES

Include unbound alias UCBs

NO

Do not include unbound alias UCBs

ONLY

Include only unbound alias UCBs

Note: The UNBOUND_ALIAS function is intended for IOS use only.

,DEVCLASS=ALL**,DEVCLASS=CHAR****,DEVCLASS=COMM****,DEVCLASS=CTC****,DEVCLASS=DASD****,DEVCLASS=DISP****,DEVCLASS=TAPE****,DEVCLASS=UREC**

Specifies the device class that is to be scanned:

ALL

Scans UCBs for all device classes

CHAR

Scans UCBs for character reader device class

COMM

Scans UCBs for communications device class

CTC

Scans UCBs for channel to channel device class

DASD

Scans UCBs for direct access device class

DISP

Scans UCBs for display device class

TAPE

Scans UCBs for TAPE device class

UREC

Scans UCBs for unit record device class

,DEVCID=devcid addr

Specifies an 8-bit input field used to supply the hexadecimal device class ID of the device class to be scanned. *devcid addr* specifies the address of the field.

If you specify DEVCID, only UCBs of the particular device class specified will be presented, and the DEVCLASS parameter is ignored.

,IOCTOKEN=ioctoken addr**,IOCTOKEN=NONE**

Specifies the address of a 48-character area that contains the MVS I/O configuration token that you supply to UCBSCAN. You can obtain this token by issuing the IOCINFO macro, which is described in *z/OS MVS Programming: Assembler Services Reference ABE-HSP*. If the I/O configuration token that is current when UCBSCAN is invoked does not match the token whose address is supplied as input by *ioctoken addr*, the caller will be notified through a return code.

If the input IOCTOKEN (specified by *ioctoken addr*) is set to binary zeros, UCBSCAN will set IOCTOKEN to the current I/O configuration token at the start of the scan.

,LINKAGE=SYSTEM**,LINKAGE=BRANCH**

Specifies the type of call that should be generated:

- **SYSTEM:** Specifies a Program Call (PC)
- **BRANCH:** Specifies a Branch entry

LINKAGE=BRANCH is intended for performance-sensitive programs.

,PLISTVER=IMPLIED_VERSION**,PLISTVER=MAX****,PLISTVER=plistver**

Specifies the version of the macro. PLISTVER determines which parameter list the system generates. PLISTVER is an optional input parameter on all forms of the macro, including the list form. When using PLISTVER, specify it on all macro forms used for a request and with the same value on all of the macro forms. The values are:

- **IMPLIED_VERSION**, which is the lowest version that allows all parameters specified on the request to be processed. If you omit the PLISTVER parameter, IMPLIED_VERSION is the default.
- **MAX**, if you want the parameter list to be the largest size currently possible. This size might grow from release to release and affect the amount of storage that your program needs.

If you can tolerate the size change, IBM recommends that you always specify PLISTVER=MAX on the list form of the macro. Specifying MAX ensures that the list-form parameter list is always long enough to hold all the parameters you might specify on the execute form; in this way, MAX ensures that the parameter list does not overwrite nearby storage.

- **1**, if you use only the following parameters:

- ADDRESS
- DEVCID
- DEVCLASS
- DEVN
- DYNAMIC
- IOCTOKEN
- LINKAGE
- LOC
- MF
- NOPIN
- PIN
- PLISTVER
- PTOKEN
- RANGE
- RETCODE
- RSNCODE
- TEXT
- UCBPAREA
- UCBPTR
- WORKAREA
- **2**, if you use any of the following parameters and parameters from *plistver* 1.
 - UCBCXPTR
 - UCBXPTR

To code, specify in this input parameter one of the following:

- IMPLIED_VERSION
- MAX
- A decimal value of 1 or 2

,RETCODE=retcode addr

Specifies the fullword location where the system is to store the return code. The return code is also in GPR 15.

,RSNCODE=rsncode addr

Specifies the fullword location where the system is to store the reason code. The reason code is also in GPR 0.

Return and reason codes

When control returns from UCBSCAN, GPR 15 (and *retcode addr*, if you coded RETCODE) contains one of the following return codes:

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
00	None	Meaning: UCBSCAN completed successfully. Action: None.

Hexadecimal Return Code	Hexadecimal Reason Code	Meaning and Action
04	01	<p>Meaning: UCBSCAN processing ended. All UCBs that met the search criteria have been presented to the caller. The value stored into the pointer for UCBPTR is unchanged, and the caller-supplied area specified in the WORKAREA parameter has been reset to binary zeros.</p> <p>Action: None.</p>
08	01	<p>Meaning: Program error. A caller in AR mode specified an ALET that was not valid.</p> <p>Action: Correct the ALET and reissue the macro. Possibly the caller wrote over an area in the parameter list; look for this error.</p>
08	02	<p>Meaning: Program error. An error occurred when the system tried to access the caller's parameter list.</p> <p>Action: Ensure that you have met the environmental requirements for the macro, and reissue the macro.</p>
08	04	<p>Meaning: Program error. An error occurred in referencing the caller-supplied area for the UCB prefix extension segment data. This reason code is valid only for callers using the UCBPAREA parameter.</p> <p>Action: Correct the UCBPAREA parameter.</p>
08	05	<p>Meaning: Program error. An error occurred when the system referenced the caller-supplied area specified in the IOCTOKEN parameter. This reason code is valid only for callers using the IOCTOKEN parameter.</p> <p>Action: Correct the IOCTOKEN parameter.</p>
08	08	<p>Meaning: Program error. An error occurred in referencing the caller-supplied work area specified in the WORKAREA parameter.</p> <p>Action: Correct the WORKAREA parameter.</p>
08	0A	<p>Meaning: Program error. An error occurred in referencing the caller-supplied area for the pin reason text (TEXT). This reason code is valid only for callers using the TEXT parameter.</p> <p>Action: Correct the TEXT parameter.</p>
08	0D	<p>Meaning: The value specified on the SCHSET keyword is not valid.</p> <p>Action: Correct the SCHSET value.</p>
0C	None	<p>Meaning: Environmental error. The I/O configuration has changed, so that the I/O configuration token supplied through the IOCTOKEN parameter is not current. This return code is valid only for callers using the IOCTOKEN parameter.</p> <p>Action: Obtain the current I/O configuration token by issuing an IOCINFO macro or by setting the input IOCTOKEN parameter in the UCBINFO macro to zero. Start the scan from the beginning.</p>
20	None	<p>Meaning: System error. An unexpected error occurred.</p> <p>Action: Supply the return code to the appropriate IBM support personnel.</p>

UCBSCAN ADDRESS - List form

Use the list form of the UCBSCAN macro together with the execute form for applications that require reentrant code. The list form of the macro defines an area of storage that the execute form uses for storing the parameters.

Syntax

This macro is an alternative list form macro, and requires a different technique for using the list form as compared to the conventional list form macros. See [“Alternative list form macros” on page 11](#) for further information.

The list form of the ADDRESS function of the UCBSCAN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede UCBSCAN.
UCBSCAN	
b	One or more blanks must follow UCBSCAN.
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 1 - 2
MF=(L, <i>list addr</i>)	<i>list addr</i> : symbol.
MF=(L, <i>list addr</i> , <i>attr</i>)	<i>attr</i> : 1- to 60-character input string.
MF=(L, <i>list addr</i> ,0D)	Default: 0D

Parameters

The parameters are explained under the standard form of the ADDRESS function of the UCBSCAN macro with the following exceptions:

MF=(L,*list addr*)

MF=(L,*list addr*,*attr*)

MF=(L,*list addr*,0D)

Specifies the list form of the UCBSCAN macro.

The *list addr* parameter specifies the address of the storage area for the parameter list.

attr is an optional 1- to 60-character input string, which can contain any value that is valid on an assembler DS pseudo-op. You can use this parameter to force boundary alignment of the parameter list. If you do not code *attr*, the system provides a value of 0D, which forces the parameter list to a doubleword boundary.

UCBSCAN ADDRESS - Execute form

Use the execute form of the UCBSCAN macro together with the list form for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

Syntax

The execute form of the ADDRESS function of the UCBSCAN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede UCBSCAN.
UCBSCAN	
␣	One or more blanks must follow UCBSCAN.
ADDRESS	Note: COPY is the default.
,WORKAREA= <i>workarea addr</i>	<i>workarea addr</i> : RX-type address or register (2) - (12).
,UCBPTR= <i>ucbptr addr</i>	<i>ucbptr addr</i> : RS-type address or register (2) - (12).
,UCBCXPTR= <i>ucbcxptr addr</i>	<i>ucbcxptr</i> : RX-type address or register (2) - (12).
,UCBPXPTR= <i>ucbpxptr addr</i>	<i>ucbpxptr</i> : RX-type address or register (2) - (12).
,LOC=BELOW	Default: BELOW
,LOC=ANY	
,PIN	Note: TEXT and PTOKEN are required with PIN
,NOPIN	
,TEXT= <i>text addr</i> :	<i>text addr</i> : RX-type address
	Note: Required with PIN, not valid with NOPIN.
,PTOKEN= <i>ptoken addr</i> :	<i>ptoken addr</i> : RS-type address or register (2) - (12).
	Note: Required with PIN, not valid with NOPIN.
,UCBPAREA= <i>ucbparea addr</i>	<i>ucbparea addr</i> : RX-type address or register (2) - (12).
,UCBPAREA=NONE	Default: NONE

Syntax	Description
,DEVN= <i>devn addr</i>	<i>devn addr</i> : RS-type address or register (2) - (12).
,DEVN=0	Default: 0
,SUBCHANNELSET=ID	
,SCHSET= <i>xschset</i> ,SCHSET=0 ,SUBCHANNELSET=ALL	<i>xschset</i> RS-type address or register (2) - (12). Default: 0
,DYNAMIC=NO	Default: NO
,DYNAMIC=YES	
,RANGE=3DIGIT	Default: 3DIGIT
,RANGE=ALL	
,UNBOUND_ALIAS=NO	Default: NO
,UNBOUND_ALIAS=YES	
,UNBOUND_ALIAS=ONLY	
,DEVCLASS=ALL	Default: ALL
,DEVCLASS=CHAR	
,DEVCLASS=COMM	
,DEVCLASS=CTC	
,DEVCLASS=DASD	
,DEVCLASS=DISP	
,DEVCLASS=TAPE	
,DEVCLASS=UREC	
,DEVCID= <i>devcid addr</i>	<i>devcid addr</i> : RS-type address
,IOCTOKEN= <i>ioctoken addr</i>	<i>ioctoken addr</i> : RX-type address or register (2) - (12).
,IOCTOKEN=NONE	Default: NONE
,LINKAGE=SYSTEM	Default: LINKAGE=SYSTEM
,LINKAGE=BRANCH	

Syntax	Description
,PLISTVER=IMPLIED_VERSION	
,PLISTVER=MAX	Default: IMPLIED_VERSION
,PLISTVER= <i>plistver</i>	<i>plistver</i> : 1 - 2
,RETCODE= <i>retcode addr</i>	<i>retcode addr</i> : RX-type address or register (2) - (12).
,RSNCODE= <i>rsncode addr</i>	<i>rsncode addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address or register (2) - (12).
,MF=(E, <i>list addr</i> ,COMPLETE)	Default: COMPLETE
SPECIAL=NO	Default: NO
SPECIAL=YES	
SPECIAL=ONLY	

Parameters

The parameters are explained under the standard form of the ADDRESS function of the UCBSCAN macro with the following exceptions:

,MF=(E,*list addr*)

,MF=(E,*list addr*,COMPLETE)

Specifies the execute form of the UCBSCAN macro.

The *list addr* parameter specifies the address of the storage area for the parameter list. COMPLETE specifies that the system is to check for required parameters and supply defaults for optional parameters that were not specified.

Chapter 30. VSMLIST – List virtual storage map

Description

The VSMLIST macro provides information about the allocation of virtual storage. The information is returned in a work area that you specify. The format of the work area is described under “Virtual Storage Management” in *z/OS MVS Programming: Authorized Assembler Services Guide*.

The following information can be requested:

- The ranges of virtual storage allocated to the SQA, by subpool, and the free space within those ranges
- The ranges of virtual storage allocated to the CSA, by subpool, and the free space within those ranges
- The ranges of CSA space that are unallocated
- The ranges of virtual storage allocated to the LSQA in the current address space, by subpool, and the free space within those ranges
- The ranges of virtual storage allocated to private area subpools, by TCB, and the free space within those ranges
- The ranges of private area that are unallocated.

For detailed information about virtual storage subpools, see “Virtual Storage Management” in *z/OS MVS Programming: Authorized Assembler Services Guide*.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	For LINKAGE=SYSTEM, problem state and PSW key 8-15. For LINKAGE=BRANCH, supervisor state and PSW key 0.
Dispatchable unit mode:	Task or SRB.
Cross memory mode:	Any PASN, any HASN, any SASN.
AMODE:	24- or 31-bit. All addresses must be 31-bit addresses.
ASC mode:	Primary.
Interrupt status:	Enabled or disabled for I/O and external interrupts.
Locks:	<ul style="list-style-type: none"> • For LINKAGE=SYSTEM, the caller may not hold a lock higher than the local lock. • For LINKAGE=BRANCH, see the LINKAGE parameter description for locking requirements.
Control parameters:	Must be in the primary address space. All input parameters, except for the TCB, can reside above 16 megabytes if the caller is running in 31-bit addressing mode. The TCB resides below 16 megabytes.

Programming requirements

All addresses are associated with the current address space.

You must set bytes 0-3 of the work area to zero before the first invocation of the macro for a given request.

Restrictions

None.

Input register information

The VSMLIST macro is sensitive to the SYSSTATE macro with the OSREL parameter

- If the caller has issued the SYSSTATE macro with the OSREL=ZOSV1R6 parameter (Version 1 Release 6 of z/OS or later) before issuing the VSMLIST macro, the caller does not have to place any information into any general purpose register (GPR) unless using it in register notation for a particular parameter, or using it as a base register.
- Otherwise, the caller must ensure that the following general purpose register contains the specified information:

Register Contents

13

The address of an 18-word save area

Output register information

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the ARs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

Syntax

The VSMLIST macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede VSMLIST.
VSMLIST	
␣	One or more blanks must follow VSMLIST.
SP=SQA	
SP=CSA	
SP=LSQA	
SP=PVT	
SP= <i>sp list addr</i>	<i>sp list addr</i> : RX-type address or register (0), (2) - (12)
,WKAREA=(<i>addr,length</i>)	<i>addr</i> : RX-type address or register (1) - (12)
	<i>length</i> : Symbol, decimal digit, or register (0), (2) - (12).
,TCB=(<i>tcb addr</i>)	Default: TCB address in PSATOLD.
,TCB=(<i>tcb addr</i> ,ALL)	<i>tcb addr</i> : RX-type address or register (0), (2) - (12).
,TCB=(, ALL)	Note: The TCB parameter is required only for SRB routines, if SP=PVT or SP= <i>sp list addr</i> and the list contains private area subpools.
,SPACE=ALLOC	Default: SPACE=ALLOC
,SPACE=FREE	Note: SPACE=UNALLOC can be specified only for SP=CSA or SP=PVT.
,SPACE=UNALLOC	
,LOC=24	Default: LOC=31
,LOC=31	
,REAL31	Default: REAL31
,REAL64	
,REALPGFMSZ	
,LINKAGE=SYSTEM	Default: LINKAGE=SYSTEM
,LINKAGE=BRANCH	

Syntax	Description
,PVTSP=ALL	Default: PVTSP=ALL
,PVTSP=OWNED	

Parameters

The parameters are explained as follows:

SP=SQA

SP=CSA

SP=LSQA

SP=PVT

SP=*sp list addr*

Specifies the storage areas for which information is requested. The following subpools are listed for the specified storage areas:

- SQA: 226, 239, 245, 247, 248
- CSA: 227, 228, 231, 241
- LSQA: 205, 215, 225, 255
- PVT: 0-127, 129-132, 229, 230, 236, 237, 244, 249, 251, 252

GETMAIN/FREEMAIN/STORAGE processing translates the original subpool numbers that were specified on the GETMAIN, FREEMAIN, or STORAGE macros to different subpool numbers as shown below:

Original Subpool Number	Translated Subpool Number
203-205	205
213-215	215
223-225	225
233-235, 253-255	255
0, 240, 250	0

VSMLIST reports the translated subpool numbers, not the original subpool numbers. In addition, VSMLIST does not report incorrect subpool numbers (subpool numbers greater than 255) or undefined subpool numbers.

If SP=*sp list addr* is specified, the user must supply the address of a subpool list. The first halfword of the list contains the number of entries in the list. Each of the following halfwords in the list contains a subpool number. If a valid subpool number appears more than once in the subpool list, it is reported only once.

,WKAREA=(*addr,length*)

Indicates the address and length of a user-supplied work area. The system uses this work area to hold the parameter list, control information, and data that is to be returned to the caller. The work area should begin on a word boundary and be a minimum of 4K bytes in length.

You must set bytes 0-3 of this work area to zero before the first invocation of VSMLIST for a specific request. See “Virtual Storage Management” in [z/OS MVS Programming: Authorized Assembler Services Guide](#) for a description of the work area.

,TCB=(tcb addr)
,TCB=(tcb addr,ALL)
,TCB=(,ALL)

Specifies the TCB associated with the virtual storage allocated to the private area subpools. The TCB must be located in the currently addressable address space. If ALL is specified, the storage associated with the TCB and all of its subtasks is reported.

Note:

1. If ALL is specified and the TCB is high in the task structure (for example, the TCB for RCT), more than one region could be listed. The regions in the private area are the RCT region, the V=V region, and the V=R region (for V=R jobs).
2. The TCB resides in storage below 16 megabytes.

,SPACE=ALLOC
,SPACE=FREE
,SPACE=UNALLOC

Specifies whether allocated, allocated and free, or unallocated storage is to be reported.

ALLOC indicates that the virtual addresses and lengths of blocks of storage allocated to the specific area are to be listed.

FREE indicates that in addition to the information supplied by ALLOC, the virtual addresses and lengths of free space within the allocated blocks are to be listed.

UNALLOC indicates that the virtual addresses and lengths of unallocated blocks of storage are to be listed. Both TCB and REAL are ignored when UNALLOC is specified.

Note: An allocated block of storage is a block that is a multiple of 4K in size and contains some storage that has been allocated via a GETMAIN or STORAGE macro. The free storage is the storage within an allocated block that has not been allocated via a GETMAIN or STORAGE macro. An unallocated block of storage is a block that is a multiple of 4K in size and contains no allocated storage.

,LOC=24
,LOC=31

Indicates whether information should be returned about virtual storage areas residing above and below 16 megabytes or only those residing below 16 megabytes. If LOC=31 is specified, information is returned for all storage areas below 2 gigabytes. If LOC=24 is specified, information is returned only for storage areas below 16 megabytes.

Note: Specifying LOC=BELOW is the same as specifying LOC=24. Specifying LOC=ANY is the same as specifying LOC=31. The old values are still supported, but IBM recommends using the newer values instead.

,REAL31
,REAL64
,REALPGFMSZ

Indicates that the high order bit and the 2 lower order bits of the address field of the allocated block descriptor should be set to show the value specified on the LOC parameter of the GETMAIN, STORAGE, or CPOOL macro invocation used to obtain that storage area. If the storage block was allocated using any LOC specification of GETMAIN or STORAGE, except for LOC=(*,24), one or more of these indicators are turned on. If the storage block was allocated using the LOC=(*,24) specification of GETMAIN or STORAGE, the indicators are turned off.

Note: The asterisk character (*) indicates that any of the allowable values for the first suboperand of the LOC keyword.

REAL31

If the storage block is backed in real 31-bit or 64-bit storage, the high bit indicator is on (one). If the storage block is backed in real 24-bit storage, the high bit indicator is off (zero). The low bit and second lowest bit indicators are always off.

REAL64

If the storage block is backed in real 64-bit storage, the low bit indicator is on (one) and the high bit indicator is off (zero). If the storage block is backed in real 31-bit storage, the high bit indicator is on (one) and the low bit indicator is off (zero). If the storage block is backed in real 24-bit storage, the high bit indicators are off (zero). The 2nd lowest bit indicator is always off (zero).

REALPGFMSZ

Specifies the following indicators:

- If the storage block was obtained with the PAGEFRAMESIZE1MB parameter, the second lowest bit indicator is on (one), the low bit indicator is on (one) and the high bit indicator is off (zero).
- If the storage block is backed in real 64-bit storage but was not obtained with the PAGEFRAMESIZE1MB parameter, the low bit indicator is on (one), the 2nd lowest bit indicator is off (zero) and the high bit indicator is off (zero).
- If the storage block is backed in real 31-bit storage, the high bit indicator is on (one), the low bit indicator is off (zero) and the 2nd lowest bit indicator is off (zero).
- If the storage block is backed in real 24-bit storage, the high bit indicator, the low bit indicator and the second lowest bit indicators are off (zero).

Note:

1. If REAL31, REAL64 and REALPGFMSZ are not specified, then none of these indicators are turned on.
2. The REAL31 parameter provides the same function as the deprecated REAL parameter, which is still supported by VSMLIST.

,LINKAGE=SYSTEM**,LINKAGE=BRANCH**

Indicates whether the VSMLIST routine uses a PC instruction (LINKAGE=SYSTEM) or branch entry (LINKAGE=BRANCH) for linkage and whether the VSMLIST routine provides serialization and recovery.

If LINKAGE=SYSTEM is specified, the VSMLIST routine provides linkage using a PC instruction and also provides recovery and serialization.

The caller's secondary ASID is preserved when a PC is issued.

Note: Serialization is not provided across calls to VSMLIST.

If LINKAGE=BRANCH is specified, the VSMLIST routine uses branch entry for linkage and does not provide recovery or serialization. Before issuing VSMLIST, provide serialization as follows:

- For LSQA or PVT requests, obtain the LOCAL lock.
- For SQA or CSA requests, issue the SETLOCK macro right before and right after the VSMLIST request, as follows:

```
SETLOCK OBTAIN,TYPE=VSMFIX,MODE=UNCOND
VSMLIST request
SETLOCK RELEASE,TYPE=VSMFIX
```

If your program is covered by a functional recovery routine (FRR) and the FRR receives control after SETLOCK OBTAIN has been issued and before SETLOCK RELEASE has been issued, your FRR must either issue SETLOCK RELEASE,TYPE=VSMFIX or must issue the SETLOCK and SETRP macros as follows:

```
SETLOCK TEST,TYPE=VSMFIX,BRANCH=(NOTHELD,NOVSMFIX)
SETRP FRELOCK=VSMFIX
NOVSMFIX DS 0H
```

Note:

1. Your program will be disabled for I/O and external interrupts from the time the SETLOCK OBTAIN completes until the SETLOCK RELEASE completes. See the descriptions of the SETLOCK and SETRP macros for additional usage information.

2. Your program and your FRR must not issue any of the following macros before issuing SETLOCK RELEASE,TYPE=VSMFIX:

- GETMAIN
- FREEMAIN
- STORAGE

,PVTSP=ALL

,PVTSP=OWNED

Indicates for each task, which subpool information will be returned.

ALL indicates that information is returned for subpools which are owned or shared by the task.

OWNED indicates that information is returned only for the subpools which are owned by the task.

ABEND codes

The VSMLIST macro might issue abend code X'C78'. For detailed abend code information, see [z/OS MVS System Codes](#).

Return and reason codes

When the VSMLIST macro returns control to your program, GPR 15 contains one of the following hexadecimal return codes:

Table 44. Return Codes for the VSMLIST Macro	
Return Code	Meaning and Action
0	<p>Meaning: Successful completion.</p> <p>Action: None.</p>
4	<p>Meaning: Partially successful completion. More information remains to be returned in the work area.</p> <p>Action: Reissue the macro to obtain additional information until a return code of 0 is returned in register 15. Do not change the value of bytes 0-3 of the work area before reissuing the macro.</p>
8	<p>Meaning: System error. The system encountered an error while scanning virtual storage management data areas. The information in the data area is valid, but incomplete. This return code is obtained only by users who specify LINKAGE=SYSTEM.</p> <p>Action: Notify system support personnel that there might be an error in virtual storage management's control structure. If there is a problem with VSM's control structure, the entire system will be adversely affected and you might need to wait until the problem is identified and resolved by support personnel. Support personnel should take a dump of the virtual storage management control structure to help identify the cause of the problem. If the problem appears to involve common storage, the contents of common storage should be dumped to view the VSM control structure. If the problem appears to involve private storage, private storage should be dumped.</p>
C	<p>Meaning: Program error. The system detected one of the following errors:</p> <ul style="list-style-type: none"> • The work area was too small. • An incorrect parameter was specified. • Incorrect control information was in the work area. <p>This return code is obtained only by users who specify LINKAGE=BRANCH. Users who specify LINKAGE=SYSTEM receive a X'C78' abend for these errors.</p> <p>Action: Ensure that the work area is at least 4096 bytes long. Verify that the work area is correctly defined and initialized and that parameters are specified properly. Verify that your program has not inadvertently modified the VSMLIST work area.</p>

Example 1

List the ranges of the allocated and free storage in the SQA. Specify the address of the VSM work area in register 2 and the length of the work area in register 3.

```
VSMLIST SP=SQA,SPACE=FREE,WKAREA=((2),(3))
```

Example 2

List the ranges of the allocated storage in the CSA. Specify the address of the work area in register 2 and the length of the work area in register 3. Provide branch entry linkage.

```
VSMLIST SP=CSA,SPACE=ALLOC,WKAREA=((2),(3)),LINKAGE=BRANCH
```

Example 3

List the ranges of unallocated storage in the private area. The variable X contains the address of the work area, which has a length of 4096 bytes.

```
VSMLIST SP=PVT,SPACE=UNALLOC,WKAREA=(X,4096)
```

Example 4

List the ranges of allocated storage, below 16 megabytes, in each of the subpools specified in the subpool list at location Y. The variable X contains the address of the work area, which has a length of 4096 bytes.

```
VSMLIST SP=Y,SPACE=ALLOC,WKAREA=(X,4096),LOC=BELOW
```

Chapter 31. VSMLOC – Verify virtual storage allocation

Description

The VSMLOC macro verifies that a given storage area has been allocated using the GETMAIN or STORAGE macros.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	For LINKAGE=SYSTEM, problem state and PSW key 8-15. For LINKAGE=BRANCH, supervisor state and PSW key 0.
Dispatchable unit mode:	Task or SRB.
Cross memory mode:	Any PASN, any HASN, any SASN.
AMODE:	24- or 31-bit. All addresses passed to VSMLOC must be 31-bit addresses.
ASC mode:	Primary.
Interrupt status:	For LINKAGE=SYSTEM, enabled or disabled for I/O and external interrupts. For LINKAGE=BRANCH, interrupt status depends on the area of storage for which information is requested. See the LINKAGE=BRANCH parameter for complete information.
Locks:	<ul style="list-style-type: none"> • For LINKAGE=SYSTEM with LSQA, PVT, or CPOOLLCL specified, you may hold only the local lock. • For LINKAGE=BRANCH, see the LINKAGE=BRANCH parameter for locking requirements.
Control parameters:	Must be in the primary address space

Programming requirements

- All addresses are associated with the current address space.
- The VSMLOC service does not provide serialization or recovery for callers specifying LINKAGE=BRANCH. Callers must provide serialization and recovery as described under the LINKAGE parameter description.
- The VSMLOC service provides serialization and recovery for callers specifying LINKAGE=SYSTEM.

Restrictions

None.

Input register information for LINKAGE=SYSTEM

The VSMLOC macro is sensitive to the SYSSTATE macro with the OSREL=ZOSV1R6 parameter

- If the caller has issued the SYSSTATE macro with the OSREL=ZOSV1R6 parameter (Version 1 Release 6 of z/OS or later) before issuing the VSMLOC macro, the caller does not have to place any information

into any general purpose register (GPR) unless using it in register notation for a particular parameter, or using it as a base register.

- Otherwise, the caller must ensure that the following general purpose register contains the specified information:

**Register
Contents**

13

The address of an 18-word save area

Output register information for LINKAGE=SYSTEM

When control returns to the caller, the GPRs contain:

**Register
Contents**

0

If GPR15 contains a value of zero, byte 3 contains the number of the subpool from which the specified storage area was obtained. Bytes 0-2 do not contain any relevant information.

If GPR15 contains a nonzero value, contains zero.

For detailed information about virtual storage subpools, see "Virtual Storage Management" in [z/OS MVS Programming: Authorized Assembler Services Guide](#).

1

Used as a work register by the system.

2-13

Unchanged.

14

Used as a work register by the system.

15

Return code.

When control returns to the caller, the access registers (ARs) contain:

**Register
Contents**

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Input register information for LINKAGE=BRANCH

The caller must ensure that the following general purpose register (GPR) contains the specified information:

**Register
Contents**

13

The address of an 18-word save area

Output register information for LINKAGE=BRANCH

When control returns to the caller, the GPRs contain:

Register Contents

0

If GPR15 contains a value of 0, byte 3 contains the number of the subpool from which the specified storage area was obtained. Bytes 0-2 do not contain any relevant information.

If GPR15 contains a nonzero value, contains zero.

For detailed information about virtual storage subpools, see “Virtual Storage Management” in [z/OS MVS Programming: Authorized Assembler Services Guide](#).

1-2

Used as work registers by the system

3-13

Unchanged.

14

Used as a work register by the system.

15

Return code.

When control returns to the caller, the ARs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

Syntax

The VSMLOC macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede VSMLOC.
VSMLOC	
b	One or more blanks must follow VSMLOC.

Syntax	Description
SQA	
CSA	
LSQA	
PVT	
CPOOLFIX	
CPOOLPAG	
CPOOLLCL	
,AREA=(<i>addr,length</i>)	<i>addr</i> : RX-type address or register (0) - (12).
	<i>length</i> : Symbol, decimal digit or register (0), (2) - (12). Use only with SQA, CSA, LSQA, and PVT.
,AREA=(<i>addr</i>)	<i>addr</i> : RX-type address or register (0) - (12). Use only with CPOOLFIX, CPOOLPAG, and CPOOLLCL.
,TCB= <i>addr</i>	
	<i>addr</i> : RX-type address or register (0) - (12). Can only be specified with PVT.
,LINKAGE=SYSTEM	Default: LINKAGE=SYSTEM
,LINKAGE=BRANCH	

Parameters

The parameters are explained as follows:

SQA

CSA

LSQA

PVT

CPOOLFIX

CPOOLPAG

CPOOLLCL

Used to verify that storage has been allocated.

SQA, CSA, LSQA, and PVT are used to verify that storage for SQA, CSA, LSQA, or PVT (private area storage) has been allocated in the current address space.

CPOOLFIX is used to verify that storage for a global fixed cell pool has been allocated. Users who obtain their storage from subpool 226, 227, 228, 239, or 245 should specify this keyword.

CPOOLPAG is used to verify that storage for a global pageable cell pool has been allocated. Users who obtain storage from subpool 231, 241, 247, or 248 should specify this keyword.

CPOOLLCL is used to verify that storage for a local cell pool has been allocated. Users who obtain storage from subpool 0-127, 129-132, 203-205, 213-215, 223-225, 229, 230, 233-237, 240, 249, or 250-255 should specify this keyword.

,AREA=(addr,length)

Indicates the start of the virtual storage area (*addr*) and the length of the virtual storage area (*length*) to be verified.

,AREA=(addr)

Indicates the start of the virtual storage area (*addr*) to be verified.

,TCB=addr

Indicates that VSMLOC is to place the address of the TCB associated with the verified storage in the register or storage area specified by the TCB parameter. If the return code from VSMLOC is not zero, the register or storage area specified by the TCB parameter is set to zero. The TCB parameter can be specified only with PVT.

,LINKAGE=SYSTEM

,LINKAGE=BRANCH

Indicates the type of linkage that VSMLOC is to use.

If LINKAGE=SYSTEM is specified, the VSMLOC routine uses a basic PC instruction for linkage.

The caller's secondary ASID is preserved when a basic PC is issued.

If LINKAGE=BRANCH is specified, the VSMLOC routine uses branch entry linkage. Before issuing VSMLOC, provide serialization as follows:

- For LSQA, CPOOLLCL, and PVT requests, obtain the LOCAL lock.
- For CSA, SQA, and CPOOLFIX requests, issue the SETLOCK macro right before and right after the VSMLOC request, as follows:

```
SETLOCK OBTAIN,TYPE=VSMFIX,MODE=UNCOND
VSMLOC request
SETLOCK RELEASE,TYPE=VSMFIX
```

If your program is covered by a functional recovery routine (FRR) and the FRR receives control after SETLOCK OBTAIN has been issued and before SETLOCK RELEASE has been issued, your FRR must either issue SETLOCK RELEASE,TYPE=VSMFIX or must issue the SETLOCK and SETRP macros as follows:

```
SETLOCK TEST,TYPE=VSMFIX,BRANCH=(NOTHELD,NOVSMFIX)
SETRP FRELOCK=VSMFIX
NOVSMFIX DS 0H
```

Note:

1. Your program will be disabled for I/O and external interrupts from the time the SETLOCK OBTAIN completes until the SETLOCK RELEASE completes. See the descriptions of the SETLOCK and SETRP macros for additional usage information.
 2. Your program and your FRR must not issue any of the following macros before issuing SETLOCK RELEASE,TYPE=VSMFIX:
 - GETMAIN
 - FREEMAIN
 - STORAGE
- For CPOOLPAG requests, issue the SETLOCK macro right before and right after the VSMLOC request, as follows:

```
SETLOCK OBTAIN,TYPE=VSMPAG,MODE=UNCOND
VSMLOC request
SETLOCK RELEASE,TYPE=VSMPAG
```

If your program is covered by a functional recovery routine (FRR) and the FRR receives control after SETLOCK OBTAIN has been issued and before SETLOCK RELEASE has been issued, your FRR must either issue SETLOCK RELEASE,TYPE=VSMPAG or must issue SETLOCK and SETRP macros as follows:

```
SETLOCK TEST,TYPE=VSMPAG,BRANCH=(NOTHELD,NOVSMPAG)
SETRP FRELOCK=VSMPAG
NOVSMPAG DS 0H
```

Note:

1. Your program will be disabled for I/O and external interrupts from the time the SETLOCK OBTAIN completes until the SETLOCK RELEASE completes. See the descriptions of the SETLOCK and SETRP macros for additional usage information.
2. Your program and your FRR must not issue any of the following macros before issuing SETLOCK RELEASE,TYPE=VSMPAG:
 - GETMAIN
 - FREEMAIN
 - STORAGE

ABEND codes

The VSMLOC macro might issue abend code X'C78'. For detailed abend code information, see [z/OS MVS System Codes](#).

Return and reason codes

When the VSMLOC macro returns control to your program, GPR 15 contains one of the following hexadecimal return codes:

Table 45. Return Codes for the VSMLOC Macro	
Return Code	Meaning and Action
0	<p>Meaning: Successful completion. The specified virtual storage area is allocated.</p> <p>Action: None.</p>
4	<p>Meaning: Possible program error. The specified virtual storage area is:</p> <ul style="list-style-type: none"> • Not allocated. • Overlaps free space. • Overlaps other subpools. <p>Action: This return code is not a program error if you have issued VSMLOC to determine whether the storage at the specified address is currently allocated and the system indicates that it is not. This return code signifies a program error if you expected the specified storage area to be allocated and the system reports one of the conditions listed above. If this is an error, you need to determine why the storage area is in the indicated state. Possible reasons include:</p> <ul style="list-style-type: none"> • The storage area address or length is not valid. • The storage has been freed by another program. • The storage was in a subpool that is automatically freed by the system and the system has freed the storage.
8	<p>Meaning: System error. The system encountered an error while scanning virtual storage management data areas. This return code is obtained only by users who specify LINKAGE=SYSTEM.</p> <p>Action: Notify system support personnel that there might be an error in virtual storage management's control structure. If there is a problem with VSM's control structure, the entire system will be adversely affected and you might have to wait until the problem is identified and resolved. System support personnel should request a dump of the virtual storage management control structure and contact IBM support. If the problem appears to involve common storage, the contents of common storage should be dumped to view the VSM control structure. If the problem appears to involve private storage, private storage should be dumped.</p>

Table 45. Return Codes for the VSMLOC Macro (continued)

Return Code	Meaning and Action
C	<p>Meaning: Program error. You have specified a parameter incorrectly. This return code is obtained only by users who specify LINKAGE=BRANCH. Users who specify LINKAGE=SYSTEM receive a X'C78' abend for this error.</p> <p>Action: Ensure that the virtual storage area you have specified does not exceed 2 gigabytes. Verify that you have coded the parameters as required.</p>
10	<p>Meaning: System error. Internal system error.</p> <p>Action: Record the return code and notify IBM support personnel.</p>

Example 1

Verify that the virtual storage, starting at the address given in register 2 and having a length specified in register 3, has been allocated in the SQA.

```
VSMLOC SQA,AREA=((2),(3))
```

Example 2

Verify that the 8-bytes of virtual storage starting at X have been allocated in the CSA. Use a PC instruction for linkage and let VSMLOC provide recovery and serialization.

```
VSMLOC CSA,AREA=(X,8),LINKAGE=SYSTEM
```

Example 3

Verify that the 8-bytes of virtual storage starting at the address specified in register 2 have been allocated in the LSQA. Use branch entry for linkage.

```
VSMLOC LSQA,AREA=((2),8),LINKAGE=BRANCH
```

Example 4

Verify that the virtual storage, starting at X and having a length specified in register 3, has been allocated in private area storage. Use branch entry for linkage.

```
VSMLOC PVT,AREA=(X,(3)),LINKAGE=BRANCH
```

Example 5

Verify that the 100 bytes of virtual storage starting at the address specified in register 1 have been allocated in private area storage. The address of the TCB associated with the storage verified is returned in register 4.

```
VSMLOC PVT,AREA=((1),100),TCB=(4),LINKAGE=BRANCH
```


Chapter 32. VSMREGN – Obtain private area region size

Description

The VSMREGN macro provides the virtual starting address and sizes of the private area user regions associated with a given TCB in the current address space. For more information about the user region, see *z/OS MVS Initialization and Tuning Guide*.

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Problem state and PSW key 8-15.
Dispatchable unit mode:	Task or SRB.
Cross memory mode:	Any PASN, any HASN, any SASN.
AMODE:	24- or 31-bit.
	All addresses passed to VSMREGN must be 31-bit addresses.
ASC mode:	Primary.
Interrupt status:	Enabled or disabled for I/O and external interrupts.
Locks:	<ul style="list-style-type: none"> If obtaining user region information for the currently active task by specifying its TCB address or by taking the default value for the TCB keyword, the caller is not required to hold any locks. Otherwise, the caller must hold the local lock of the currently addressable address space.
Control parameters:	Must be in the primary address space. All input parameters except for the TCB address can reside above 16 megabytes if the caller is running in 31-bit addressing mode. The TCB resides below 16 megabytes.

Programming requirements

None.

Restrictions

None.

Input register information

Before issuing the VSMREGN macro, the caller must ensure that the following general purpose registers (GPRs) contain the specified information:

Register
Contents

13

Address of a standard 72-byte save area

Output register information

When control returns to the caller, the GPRs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14

Used as a work register by the system

15

Return code

When control returns to the caller, the ARs contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

Syntax

The VSMREGN macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede VSMREGN.
VSMREGN	
␣	One or more blanks must follow VSMREGN.
WKAREA= <i>addr</i>	<i>addr</i> : RX-type address or register (0) - (12).
,TCB= <i>tcb addr</i>	<i>tcb addr</i> : RX-type address or register (0), (2) - (12).

Syntax	Description
	Default: (except for SRB routines) TCB address in PSATOLD.

Parameters

The parameters are explained as follows:

WKAREA=addr

Indicates the virtual address of a 16-byte work area, which is used by VSMREGN to return the requested information. The format of the work area is:

Bytes

Meaning

0-3

Virtual address of the region below 16 megabytes

4-7

Length of the region below 16 megabytes

8-11

Virtual address of the region above 16 megabytes

12-15

Length of the region above 16 megabytes

,TCB=tcb addr

Indicates the virtual address of the TCB to be used to identify the region (the region control task (RCT) region, the V=V region, or the V=R region). SRB routines and routines whose currently addressable address space is not the home address space must specify the TCB operand. They cannot use the default value.

ABEND codes

None.

Return and reason codes

When control returns from VSMREGN, GPR 15 always contains a return code of zero, indicating successful completion.

Example 1

Find the virtual address and length of the private area of the TCB whose address is in PSATOLD. Return the information in the work area whose address is given in register 2.

```
VSMREGN WKAREA=(2)
```

Example 2

Find the virtual address and length of the private area of the TCB specified in register 3. Return this information in the work area whose address is given in register 2.

```
VSMREGN WKAREA=(2) ,TCB=(3)
```

Example 3

Find the virtual address and length of the private area of the TCB whose address is X. Return this information in the work area whose address is given in register 2.

```
VSMREGN WKAREA=(2),TCB=X
```

Example 4

Find the virtual address and length of the private area of the TCB whose address is given in register 3. Return this information in the work area whose address is X.

```
VSMREGN WKAREA=X,TCB=(3)
```


Chapter 33. WAIT – Wait for one or more events

Description

The WAIT macro is used to tell the system that performance of the active task cannot continue until one or more specific events, each represented by a different event control block (ECB), have occurred. Bit 0 and bit 1 of each ECB must be set to zero before it is used.

The system takes the following action:

- For each event that has already occurred (each ECB is already posted), the count of the number of events is decreased by one.
- If the number of events is zero by the time the last event control block is checked, control is returned to the instruction following the WAIT macro.
- If the number of events is not zero by the time the last ECB is checked, control is not returned to the issuing program until sufficient ECBs are posted to bring the number to zero. Control is then returned to the instruction following the WAIT macro.

See [z/OS MVS Programming: Authorized Assembler Services Guide](#) for information on how to use the WAIT macro to serialize resources.

Environment

The requirements for callers of WAIT are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state or problem state, with any PSW key
Dispatchable unit mode:	Task
Cross memory mode:	One of the following: <ul style="list-style-type: none"> • For LINKAGE=SVC: PASN=HASN=SASN • For LINKAGE=SYSTEM: PASN=HASN=SASN or PASN¬=HASN¬=SASN
AMODE:	24- or 31- or 64-bit
RMODE:	Includes 64-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interruptions
Locks:	<ul style="list-style-type: none"> • For LINKAGE=SYSTEM: No locks held • For LINKAGE=SVC: No locks held, and no enabled unlocked task (EUT) functional recovery routines (FRR) established
Control parameters:	ECB and ECBLIST must be in the home address space.

Programming requirements

None.

Restrictions

When using LINKAGE=SVC (the default), the caller cannot have an EUT FRR established.

Input register information

Before issuing the WAIT macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

After the caller issues the macro, the system might use some registers as work registers or might change the contents of some registers. When the system returns control to the caller, the contents of these registers are not the same as they were before the macro was issued. Therefore, if the caller depends on these registers containing the same value before and after issuing the macro, the caller must save these registers before issuing the macro and restore them after the system returns control.

When control returns to the caller, the general purpose registers (GPRs) contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

When control returns to the caller, the access registers (AR) contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Performance implications

None.

Syntax

The WAIT macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede WAIT.
WAIT	
b	One or more blanks must follow WAIT.

Syntax	Description
<i>event nmbr</i> ,	<i>event nmbr</i> : Symbol, decimal digit, or register (0) or (2) - (12).
	Default: 1
	Value range: 0-255
ECB= <i>ecb addr</i>	<i>ecb addr</i> : RX-type address, or register (1) or (2) - (12).
ECBLIST= <i>ecb list addr</i>	<i>ecb list addr</i> : RX-type address, or register (1) or (2) - (12).
,LONG=NO	Default: LONG=NO
,LONG=YES	
,LINKAGE=SVC	Default: LINKAGE=SVC
,LINKAGE=SYSTEM	
,EUT=NOSAVE	Default: EUT=NOSAVE
,EUT=SAVE	
,RELATED= <i>value</i>	<i>value</i> : Any valid macro keyword specification.

Parameters

The parameters are explained as follows:

***event nmbr*,**

Specifies the number of events waiting to occur.

ECB=*ecb addr*

ECBLIST=*ecb list addr*

Specifies the address of an ECB on a fullword boundary or the address of a virtual storage area containing one or more consecutive fullwords on a fullword boundary. Each fullword contains the address of an ECB; the high order bit in the last fullword must be set to one to indicate the end of the list.

The ECB parameter is valid only if the number of events is specified as one or is omitted. The number of ECBs in the list specified by the ECBLIST form must be equal to or greater than the specified number of events.

If you specify ECBLIST, *ecb list addr* and all ECBs on the list must be in the home address space.

,LONG=NO

,LONG=YES

Specifies whether the task is entering a long wait (YES) or a regular wait (NO).

,LINKAGE=SVC

,LINKAGE=SYSTEM

Specifies whether the caller is in cross memory mode (LINKAGE=SYSTEM) or not (LINKAGE=SVC).

When the caller is not in cross memory mode (the primary, secondary, and home address spaces are the same), use LINKAGE=SVC. With this parameter, linkage is through an SVC instruction.

WAIT macro

When the caller is in cross memory mode (the primary, secondary, and home address spaces are not the same), use LINKAGE=SYSTEM. With this parameter, linkage is through a PC instruction. Note that the ECB must be in the home address space.

,EUT=NOSAVE

,EUT=SAVE

Specifies whether enabled unlocked task (EUT) FRRs, if present, should be preserved around the WAIT processing. Specify this keyword only if you specify LINKAGE=SYSTEM.

,RELATED=value

Specifies information used to self-document macros by “relating” functions or services to corresponding functions or services. The format and contents of the information specified are at the discretion of the user, and may be any valid coding values.

The RELATED parameter is available on macros that provide opposite services (for example, ATTACH/DETACH, GETMAIN/FREEMAIN, and LOAD/DELETE), and on macros that relate to previous occurrences of the same macros (for example, CHAP and ESTAE).

The RELATED parameter may be used, for example, as follows:

```
WAIT1    WAIT      1,ECB=ECB,RELATED=(RESUME1,
                  'WAIT FOR EVENT')
.
.
.
RESUME1  POST      ECB,0,RELATED=(WAIT1,
                  'RESUME WAITER')
```

Note: Each of these macros will fit on one line when coded, so there is no need for a continuation indicator.



CAUTION: A job step with all of its tasks in a WAIT condition is terminated upon expiration of the time limits that apply to it.

Example

You have previously initiated one or more activities to be completed asynchronously to your processing. As each activity was initiated, you set up an ECB in which bits 0 and 1 were set to zero. You now wish to suspend your task via the WAIT macro until a specified number of these activities have been completed.

Completion of each activity must be made known to the system via the POST macro. POST causes an addressed ECB to be marked complete. If completion of the event satisfies the requirements of an outstanding WAIT, the waiting task is marked ready and will be executed when its priority allows.

ABEND codes

The caller of WAIT might encounter one of the following abend codes:

- 101
- 201
- 301
- 401

See [z/OS MVS System Codes](#) for explanations and responses for these codes.

Return and reason codes

None.

Example 1

Wait for one event to occur (with a default count).

```

        WAIT    ECB=WAITECB
        .
        .
WAITECB DC      F'0'
```

Example 2

Wait for two events to occur.

```

        WAIT    2,ECBLIST=LISTECBS
        .
        .
LISTECBS DC      A(ECB1)
        DC      A(ECB2)
        DC      X'80'
        DC      AL3(ECB3)
```

Example 3

Enter a long wait for a task.

```

        WAIT    1,ECBLIST=LISTECBS, LONG=YES
        .
        .
        .
LISTECBS DC      A(ECB1)
        DC      A(ECB2)
        DC      X'80'
        DC      AL3(ECB3)
```


Chapter 34. WTL — Write to log

Description

Note: IBM recommends that you use the WTO macro with the MCSFLAG=HRDCPY parameter instead of WTL, because WTO supplies more data than WTL.

The WTL macro causes a message to be written to the system log (SYSLOG) or the operations log (OPERLOG) log stream depending on which one of these logs, or both, is active. The message can include any character that can be used in a C-type (character) DC statement, and is assembled as a variable-length record.

Note: When a message is recorded in SYSLOG, the exact format of the output of the WTL macro varies depending on the job entry subsystem (JES2 or JES3) that is being used, the output class that is assigned to the log at system initialization, and whether DLOG is in effect for JES3. See the *z/OS MVS System Messages* manuals for information on the format of logged messages.

z/OS JES3 Commands also contains information about the format of logged messages.

The description of the WTL macro follows. The WTL macro is also described in *z/OS MVS Programming: Assembler Services Reference IAR-XCT* (with the exception of the OPTION parameter).

Environment

The requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Problem state and any PSW key. For OPTION, APF-authorized with PSW key 0-7, or supervisor state
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	Must be in the primary address space

Programming requirements

None.

Restrictions

Message text cannot exceed 126 characters. If the message text exceeds 126 characters, truncation occurs after the 126th character.

Input register information

Before issuing the WTL macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the GPRs contain:

Register Contents

0

Reason code

1-14

Unchanged

15

Return code

When control returns to the caller, the access registers (ARs) contain:

Register Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

None.

Syntax

The standard form of the WTL macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede WTL.
WTL	
b	One or more blanks must follow WTL.
<i>'msg'</i>	<i>msg</i> : Up to 126 characters if OPTION=NOPREFIX is specified. Up to 128 characters if OPTION=PREFIX is specified.
,OPTION=PREFIX	Default: OPTION=NOPREFIX

Syntax	Description
,OPTION=NOPREFIX	

Parameters

The parameters are explained as follows:

'msg'

Specifies the message to be written to the system log and/or the operations log. The message must be enclosed in apostrophes, which will not appear in the log. The message can include any character that can be used in a C-type (character) DC statement, and is assembled as a variable-length record. See "Timing and Communication" in *z/OS MVS Programming: Assembler Services Guide* for a list of the printable EBCDIC characters passed to display devices or printers.

,OPTION=PREFIX

,OPTION=NOPREFIX

Specifies whether the WTL text contains a prefix identifying the system log record. If PREFIX is specified, the text already contains a prefix. If NOPREFIX is specified or if this parameter is omitted, a two-character prefix will be added by the system. The OPTION keyword is ignored by any program running in the JES3 primary address space.

ABEND codes

None.

Return and reason codes

When the WTL macro returns control to your program, GPR 15 contains a hexadecimal return code and GPR 0 contains a hexadecimal reason code. WTL issues a return code (either 00 or 04), with multiple reason codes for each. The return codes indicate the following:

- 00 - WTL wrote the message to the system log, the operations log, or both.
- 04 - WTL could not write the message to either the system log or the operations log.

Table 46. Return and Reason Codes for the WTL Macro		
Return Code	Reason Code	Meaning and Action
00	00	<p>Meaning: WTL processing completed successfully. The system logged the message in SYSLOG, and if OPERLOG was requested, the system logged the message in OPERLOG.</p> <p>Action: None.</p>
00	04	<p>Meaning: WTL processing completed successfully. The message was logged in the operations log (OPERLOG logstream). The system log was not active.</p> <p>Action: If you want the message logged in the system log, start the system log and rerun the program.</p>
00	08	<p>Meaning: WTL processing completed, but the message was only logged in the operations log because the WTL system log buffers are full.</p> <p>Action: Do one of the following, if you want subsequent messages logged in the system log:</p> <ul style="list-style-type: none"> • Enter a CONTROL M,LOGLIM command to change the allocated number of WTL system log buffers dynamically. • Change the LOGLIM value specifying the number of WTL system log buffers on the INIT statement in the CONSOLxx parmlib member. This value will take effect at the next IPL.

Table 46. Return and Reason Codes for the WTL Macro (continued)

Return Code	Reason Code	Meaning and Action
00	0C	<p>Meaning: WTL processing completed, but the message was only logged in the system log because the operations log was not active.</p> <p>Action: If you want the message logged in the operations log, start the operations log and rerun the program. This will also place the message in the system log.</p>
00	10	<p>Meaning: WTL processing completed, but the message was only logged in the system log. The message was not logged in the operations log stream because of a storage problem.</p> <p>Action: If you want the message logged in the operations log, retry the request. This will also place the message in the system log. If the problem persists, contact the IBM Support Center. Provide the return and reason code.</p>
04	04	<p>Meaning: System error. WTL processing was not successful. Recovery could not be established.</p> <p>Action: Retry the request. If the problem persists, record the return and reason code and supply it to the appropriate IBM support personnel.</p>
04	08	<p>Meaning: Environmental error. The system log and the operations log are not active.</p> <p>Action: Start the logs and rerun your program.</p>
04	0C	<p>Meaning: Environmental error. The WTL limit has been reached.</p> <p>Action: Do one of the following:</p> <ol style="list-style-type: none"> 1. Retry the request when the shortage is relieved. 2. Issue a CONTROL M,LOGLIM command to change the allocated number of WTL SYSLOG buffers. 3. Change the LOGLIM value on the INIT statement in the CONSOLxx member of SYS1.PARMLIB. This new value will take effect at the next IPL. <p>Note: If the problem is persistent, you might want to perform step 2 first and step 3 at the next IPL.</p>
04	10	<p>Meaning: System error. An internal error occurred. The system issues message IEE390I.</p> <p>Action: Contact the IBM Support Center. Provide the return and reason code.</p>
04	14	<p>Meaning: System error. The system encountered a (VSM) error. The system issues message IEE390I.</p> <p>Action: Contact the IBM Support Center. Provide the return and reason code.</p>
04	18	<p>Meaning: Environmental error. The message was not logged in either the system log or the operations log, because neither log is active.</p> <p>Action: Do one of the following:</p> <ul style="list-style-type: none"> • If you want to log the message in the operations log, start the operations log with the VARY OPERLOG,HARDCPY command and rerun the program. • If you want the message logged in the system log, start the system log (SYSLOG) with the VARY SYSLOG,HARDCPY command and rerun the program.

Table 46. Return and Reason Codes for the WTL Macro (continued)

Return Code	Reason Code	Meaning and Action
04	1C	<p>Meaning: Environmental error. The message was not logged in the system log, as requested, because the WTL limit has been reached. The operation log was not active at the time, so the message was not logged there either.</p> <p>Action: To log the message in the system log, do the following:</p> <ul style="list-style-type: none"> • Retry the request when the storage shortage has been relieved. • Issue a CONTROL M,LOGLIM command to change the allocated number of WTL SYSLOG buffers. • Change the LOGLIM value on the INIT statement in the CONSOLxx member of SYS1.PARMLIB. This new value will take effect at initialization. <p>If the problem persists, issue the CONTROL M,LOGLIM command first, and change the LOGLIM value in CONSOLxx at your next IPL.</p> <p>To log the message in the operations log, start the operations log and rerun the program.</p>
04	20	<p>Meaning: Environment error. The message was not logged in the operations log, as requested, because of storage problems. The system log was not active.</p> <p>Action: To log the message in the operations log, retry the request. If the problem persists, contact the IBM Support Center, providing the return and reason codes.</p> <p>To log the message in the system log also, start the system log and rerun the program.</p>
04	24	<p>Meaning: Environment error. The message was not logged in the system log because the WTL limit has been reached, and was not logged in the operation log because of storage problems.</p> <p>Action: To log the message in the operations log, retry the request. If the problem persists, contact the IBM Support Center, providing the return and reason codes.</p> <p>To log the message in the system log also, start the system log and rerun the program.</p>

Example 1

Write a message to the system log.

```
WTL    'THIS IS THE STANDARD FORMAT FOR THE WTL MACRO'
```

Example 2

Write a message to the system log specifying a prefix to identify the system log record.

```
WTL    'QL THIS FORMAT OF THE WTL USES THE OPTION KEYWORD',OPTION=PREFIX
```

Example 3

Build a parameter list for a message to be written to the system log.

```
LOGMSG    WTL    'FUNCTION XXX COMPLETE',MF=L
```

Example 4

Write a message constructed in the list form of WTL.

```
WTL    MF=(E,LOGMSG)
```

WTL - List form

The list form of the WTL macro is used to construct a control program parameter list. The message parameter must be provided in the list form of the macro. The OPTION keyword is not permitted on the list form of the WTL macro.

Syntax

The list form of the WTL macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede WTL.
WTL	
␣	One or more blanks must follow WTL.
'msg'	<i>msg</i> : Up to 126 characters.
,MF=L	

Parameters

The parameters are explained under the standard form of the WTL macro with the following exception:

,MF=L

Specifies the list form of the WTL macro.

WTL - Execute form

The execute form of the WTL macro uses a remote control program parameter list. The parameter list can be generated by the list form of WTL. You cannot modify the message in the execute form.

Syntax

The execute form of the WTL macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede WTL.

Syntax	Description
WTL	
b	One or more blanks must follow WTL.
MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address, or register (1) or (2) - (12).
,OPTION=PREFIX	Default: OPTION=NOPREFIX
,OPTION=NOPREFIX	

Parameters

The parameters are explained under the standard form of the WTL macro with the following exception:

MF=(E,*list addr*)

Specifies the execute form of the WTL macro.

list addr is the name of a storage area to contain the parameters.

Chapter 35. WTO — Write to operator

Description

Use the WTO macro to write a message to one or more operator consoles. See the information on communication in *z/OS MVS Programming: Authorized Assembler Services Guide* for more information on using WTO. *z/OS MVS Programming: Assembler Services Reference IAR-XCT* also contains information on WTO, except for the AREAID, MSGTYP, CONNECT, SYSNAME, JOBID, JOBNAME, LINKAGE, SYNCH, and WSPARM parameters.

Environment

If you code LINKAGE=SVC, requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	<ul style="list-style-type: none"> If you specify routing codes in the range 41-128, or specify more than 10 lines of text, or code the CONNECT, SYSNAME, JOBID, and JOBNAME parameters, you need a minimum authorization of either supervisor state with PSW key 0-7 or APF-authorized. For all other cases, you need a minimum authorization of problem state and any key.
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31- or 64-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts
Locks:	No locks held
Control parameters:	Must be in the primary address space.

If you code LINKAGE=BRANCH, the requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	One of the following, depending on the parameters you code: <ul style="list-style-type: none"> Supervisor state and PSW key 0 - 7. If you code the WSPARM parameter, supervisor state with PSW key 0.
Dispatchable unit mode:	Task or SRB.
Cross memory mode:	Any PASN, any HASN, any SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled or disabled for I/O and external interrupts
Locks:	The caller may hold locks, but is not required to hold any.
Control parameters:	Must be in the primary address space.

Programming requirements

Be aware of the following when coding the WTO macro:

- For a multiple-line message, you must clear register 0 on the first WTO issuance if the WTO is being issued from an authorized program. For WTOs issued from problem programs, any data in register 0 is ignored.
- You must clear register 0 before issuing a multiple-line WTO. The only exception is when you are using register 0 to pass a message identifier to connect multiple-line messages. However, in this case, IBM suggests you use the CONNECT parameter rather than register 0.
- If the caller is disabled or issues WTO with the WSPARM parameter, the WTO and LOADWAIT parameter lists must be in fixed storage.
- When using any parameter with an address, the data being referenced must be accessible by the caller issuing the WTO.
- If the list and execute forms of the WTO macro are in separate modules, both modules must be assembled or compiled with the same level of WTO.
- When coding a reentrant program, make sure the WTO parameter list is generated correctly. To ensure this, you must code the same parameters on both forms, only when you code one or more of the following parameters:

- TEXT=*text addr*
- CONNECT
- CONSID
- CONSNAME
- SYSNAME
- CART
- KEY
- TOKEN
- JOBNAME
- JOBID
- LINKAGE
- WSPARM

On the list form, code only the parameter and the equal sign; do not code a parameter value as well. For example,:

```
WTO 'text',CONSID=,MF=L
```

If you specify parameter values on the list form, the system issues an MNOTE and ignores the data.

- For any WTO parameters that allow a register specification, the value must be right-justified in the register.
- If WSPARM is not equal to zero, the wait state is loaded whether or not the message could be displayed or queued for hardcopy.
- If you specify the TEXT keyword for a multi-line WTO on the list form, you must omit *text addr* for each line, but include *line type*. If you specify *text addr*, the system ignores the data and issues an MNOTE. On the execute form, omit *line type* for each line, but include *text addr*.
- As of z/OS 1.4.2, to prevent parameter lists that are not valid from causing system errors, the WTO service records the errors as symptom records in LOGREC. One example of an invalid parameter list is an invalid combination of WTO parameters. The system might also issue a D23 abend for diagnostic purposes only; the program issuing the WTO is not abended. Message processing continues as far as possible using the invalid parameter list.

These invalid parameter list errors mean that some messages you once were able to process can no longer be processed; your program might also receive different return codes. However, in these cases, the symptom record is always issued, and the diagnostic D23 abend is issued if possible. IBM recommends that you correct all WTO errors, regardless of whether or not the message is actually displayed. For an example LOGREC symptom record, see [“Example 3”](#) on page 386.

If a dump is needed along with the diagnostic D23 abend to debug the problem, the following SLIP can be set to cause dumps to be taken:

```
SLIP SET,ENABLE,COMP=D23,ACTION=SVCD,END
```

Restrictions

- If an SRB-mode or cross-memory mode caller issues WTO without the JOBID or JOBNAME parameter, the resulting message may not contain a job ID or job name.
 - You should issue a synchronous message only in serious system emergencies.
- Important:** Use caution when specifying SYNCH=YES. If your installation has not specified a SYNCHDEST console group in the CNGRPxx member of parmlib, the system displays the WTO on the system console, located in the Operating System Messages task on the Hardware Management Console. The message is displayed for up to ten seconds and then control returns to the WTO issuer. All of the system's CPs *may be stopped* while the message is being displayed.
- There are two ways for authorized callers (supervisor state with PSW key 0-7) to issue multiple-line messages:
 1. You can issue a multiple-line WTO message of up to 255 lines with one WTO macro. If you are coding more than one multiple-line message, and you want to connect the messages (and you are not using the recommended CONNECT keyword on the WTO macro), you must ensure that the left-most three bytes of register 0 are set correctly:
 - For the first request (of up to 255 lines), these three bytes must be zero.
 - For subsequent requests, register 0 can contain the message identifier that the WTO service routine returns in register 1 after the first request. Note that you must left-justify the 24-bit identifier when you load it into register 0.
 2. The CONNECT parameter provides a way to connect multiple-line WTO messages. Therefore, an authorized caller actually can issue connect messages that total more than 255 lines.
 - A WTO message with ROUTCDE=11 is sent to the JES2 or JES3 system message data set (SYSMSG) unless LINKAGE=BRANCH is specified. In this case, the message is not sent. If you want the WTO to go to SYSMSG, use LINKAGE=SVC with ROUTCDE=11. Whether you issue LINKAGE=BRANCH or LINKAGE=SVC with ROUTCDE=11, the message appears in the JES2 or JES3 joblog.
 - The caller cannot have an EUT FRR established with LINKAGE=SVC. The caller can have an EUT FRR established with LINKAGE=BRANCH.
 - When using the LINKAGE=BRANCH parameter, the system does not automatically delete a WTO issued by a caller in SRB mode. A caller in SRB mode must issue the DOM macro to explicitly delete any action message when the calling program ends.
 - If you specify LINKAGE=BRANCH, WTO ignores any data in register 0. Therefore, if you are connecting lines of a multi-line WTO, and you specified LINKAGE=BRANCH, you cannot put the CONNECT ID in register 0. You must use the CONNECT keyword.
 - If you are connecting lines of a multi-line WTO, and the end line is not received within a certain time interval from the most recent connect request (the default set by IBM is 30 seconds), the message is truncated. Further attempts to connect to the message are rejected.
 - If you are connecting lines of a multi-line WTO, there is a limit of 65533 total lines allowed in the multi-line message. If you attempt to send more than 65533 total lines, an ABEND X'D23', reason code X'0051' occurs.

Input register information

Before issuing the WTO macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register

Contents

0

Used as a work register by the system.

1

Message identification number if the macro completed normally. You can use this number to delete the message when it is no longer needed. If you are using the CONNECT parameter to connect WTO messages, store this value in the 4-byte CONNECT field and set register 0 to zero before issuing the next WTO. Otherwise, register 1 is used as a work register by the system.

2-13

Unchanged.

14

Used as a work register by the system.

15

Return code.

When control returns to the caller, the access registers (ARs) contain:

Register

Contents

0-1

Used as work registers by the system

2-13

Unchanged

14-15

Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

SYNCH=YES causes the system to display the message, disable the issuing program *and system*, wait for up to ten seconds, and then synchronously return to the program. If your installation has not specified a SYNCHDEST console group in the CNGRPxx member of parmlib, the system displays the WTO on the system console, located in the Operating System Messages task on the Hardware Management Console. All of the system's CPs *may be stopped* while the message is being displayed (for up to ten seconds).

Syntax

The standard form of the WTO macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.

Syntax	Description																					
<code>_</code>	One or more blanks must precede WTO.																					
WTO																						
<code>_</code>	One or more blanks must follow WTO.																					
<code>'msg'</code>	<i>msg</i> : Up to 126 characters.																					
<code>('text')</code>	<i>text</i> : Up to 126 characters.																					
<code>('text',line type)</code>	<i>text addr</i> : RX-type address or register (2) - (12).																					
<code>('text',line type)...('text',line type)</code>	If you code ' <i>msg</i> ' or ' <i>text</i> '..., it must be the first parameter you code.																					
<code>TEXT=<i>text addr</i></code>																						
<code>TEXT=(<i>text addr,line type</i>)</code>																						
<code>TEXT=((<i>text addr,line type</i>),...(<i>text addr,line type</i>))</code>																						
	<p>The permissible <i>line type</i> values, text lengths, and maximum numbers of each line type are:</p> <table><tr><th>line type</th><th>text</th><th>maximum number</th></tr><tr><td>C</td><td>35 char</td><td>1 C type</td></tr><tr><td>L</td><td>71 char</td><td>2 L type</td></tr><tr><td>D</td><td>71 char</td><td>255 D type</td></tr><tr><td>DE</td><td>71 char</td><td>1 DE type</td></tr><tr><td></td><td>or</td><td></td></tr><tr><td>E</td><td>None</td><td>1 E type</td></tr></table> <p>The maximum total number of lines that can be coded in one instruction is 255.</p>	line type	text	maximum number	C	35 char	1 C type	L	71 char	2 L type	D	71 char	255 D type	DE	71 char	1 DE type		or		E	None	1 E type
line type	text	maximum number																				
C	35 char	1 C type																				
L	71 char	2 L type																				
D	71 char	255 D type																				
DE	71 char	1 DE type																				
	or																					
E	None	1 E type																				
<code>,ROUTCDE=(<i>routing code</i>)</code>	<i>routing code</i> : Decimal digit from 1 to 128. The <i>routing code</i> is one or more codes, separated by commas, or a hyphen to indicate a range.																					
<code>,DESC=(<i>descriptor code</i>)</code>	<i>descriptor code</i> : Decimal digit from 1 to 13. The <i>descriptor code</i> is one or more codes, separated by commas.																					
<code>,AREAID=<i>id char</i></code>	<i>id char</i> : Alphabetic character A - K, Z.																					

Syntax	Description
,MSGTYP=(<i>msg type</i>)	<p><i>msg type</i>: Any of the following</p> <p>N SESS,JOBNAMES</p> <p>Y SESS,STATUS</p> <p>SESS JOBNAMES,STATUS</p> <p>JOBNAMES SESS,JOBNAMES,STATUS</p> <p>STATUS</p> <p>Note: IBM recommends that you do not use MSGTYP=Y. See the MSGTYP explanation on page “,MSGTYP=(msg type)” on page 381 for more information.</p>
,MCSFLAG=(<i>flag name</i>)	<p><i>flag name</i>: Any combination of the following, separated by commas:</p> <p>CMD HRDCPY</p> <p>RESP NOCOPY</p> <p>REPLY NOTIME</p> <p>BRDCST</p>
,CONNECT= <i>connect field</i>	<p><i>connect field</i>: RX-type address or register (2) - (12).</p> <p>Note: CONNECT is mutually exclusive with the CONSID, CONSNAME, SYSNAME, and SYNCH=YES parameters.</p>
,CONSID= <i>console id</i>	<i>console id</i> : RX-type address or register (2) - (12).
,CONSNAME= <i>console name</i>	<i>console name</i> : RX-type address or register (2) - (12).
,SYSNAME= <i>system name</i>	<i>system name</i> : RX-type address or register (2) - (12).
,CART= <i>cmd/resp token</i>	<i>cmd/resp token</i> : RX-type address or register (2) - (12).
,KEY= <i>key</i>	<i>key</i> : RX-type address or register (2) - (12).
,TOKEN= <i>token</i>	<i>token</i> : RX-type address or register (2) - (12).
,JOBID= <i>job id</i>	<i>job id</i> : RX-type address or register (2) - (12).

Syntax	Description
,JOBNAME= <i>jobname</i>	<i>jobname</i> : RX-type address or register (2) - (12).
,LINKAGE=SVC	Default: SVC
,LINKAGE=BRANCH	
,SYNCH=NO	Default: NO
,SYNCH=YES	
,WSPARM=0	Default: 0
,WSPARM= <i>wait state addr</i>	<i>wait state addr</i> : RX-type address or register (2) - (12).

Parameters

The parameters are explained as follows:

'msg'

('text')

('text',line type)

('text',line type)...,'(text',line type)

TEXT=text addr

TEXT=(text addr,line type)

TEXT=((text addr,line type),...(text addr,line type))

Specifies the message or multiple-line message to be written to one or more operator consoles.

The *'msg'* parameter is used to write a single-line message to the operator. In the format, the message must be enclosed in single quotation marks, which do not appear on the console. It can include any character that can be used in a character (C-type) DC instruction.

To have single quotation marks appear in the message text, use two single quotation marks to get one to appear. For example, ' 'Message Off' ' would appear on a display as 'Message Off'. When a program issues a WTO macro, the system translates the text; only standard printable EBCDIC characters are passed to MCS-managed display devices. The EBCDIC characters that can be displayed are listed in *z/OS MVS Programming: Assembler Services Guide*. All other characters are replaced by blanks. Unless the console has dual-case capability, lowercase characters are displayed or printed as uppercase characters.

The message is assembled as a variable-length record. The parameters **TEXT=text addr** and **TEXT=(text addr,line type)** represent a 4-byte address of a message to be displayed that consists of a 2-byte message length followed by the message text. The 2-byte message length describes the length of the message text only. There are no boundary requirements.

The **('text')** and **(text addr,line type)** parameters are used to write a multiple-line message to the operator. For a problem-state program, the message can be up to ten lines long; the system truncates the message at the end of the tenth line. The ten-line limit does not include the control line (message IEE932I), as explained under line type C below. The ten-line limit only applies to unauthorized users; for authorized users, the message can be up to 255 lines each time WTO is issued.

Notes:

1. If the **('text')** parameter is coded without repetition, the message appears as a single-line message.

2. Specify all lines of a multiple-line WTO consistently with the message text or the TEXT keyword.
3. When coding the TEXT keyword for a multiple-line message:
 - Do not exceed the 71-character limit for the macro parameter value.
 - You can use the CONNECT parameter to connect subsequent lines of a multiple-line message if you cannot fit them into one macro invocation.
4. For a multiple-line message, you must clear register 0 on the first WTO issuance.

The line type defines the type of information contained in the 'text' field of each line of the message:

C

Indicates that the 'text' parameter is the text to be contained in the control line of the message. The control line normally contains a message title. C may only be coded for the first line of a multiple-line message. If this parameter is omitted and descriptor code 9 is coded, the system generates a control line (message IEE932I) containing only a message identification number. The control line remains static while you scroll through all the lines of a multi-line message displayed on an MCS console (provided that the message is displayed in an out-of-line display area). Control lines are optional.

L

Indicates that the 'text' parameter is a label line. Label lines contain message heading information; they remain static while you scroll through all the lines of a multi-line message displayed on an MCS console (provided that the message is displayed in an out-of-line display area). Label lines are optional. If coded, lines must either immediately follow the control line or another label line, or be the first line of the multiple-line message if there is no control line. Only two label lines may be coded per message. See “Embedding Label Lines in a Multi-line Message” in [z/OS MVS Programming: Authorized Assembler Services Guide](#) for additional information about how to include multiple label lines within a message.

D

Indicates that the 'text' parameter contains the information to be conveyed to the operator by the multiple-line message. The data lines are paged while you scroll through all the lines of a multi-line message displayed on an MCS console (provided that the message is displayed in an out-of-line display area).

DE

Indicates that the 'text' parameter contains the last line of information to be passed to the operator. Specify DE on the last line of text of the WTO. If there is no text on the last line, specify E.

E

Indicates that the previous line of text was the last line of text to be passed to the operator. The 'text' parameter, if any, coded with a line type of E is ignored. Specify E on the last line of the WTO if that line has no text. If the last line has text, specify DE.

,ROUTCDE=(routing code)

Specifies the routing code or codes to be assigned to the message.

The routing codes are:

Code

Meaning

1

Operator Action

The message indicates a change in the system status. It demands action by the primary operator.

2

Operator Information

The message indicates a change in system status. It does not demand action; rather, it alerts the primary operator to a condition that might require action.

This routing code is used for any message that indicates job status when the status is not requested specifically by an operator inquiry. It is also used to route processor and problem program messages to the system operator.

3

Tape Pool

The message gives information about tape devices, such as the status of a tape unit or reel, the disposition of a tape reel, or a request to mount a tape.

4

Direct Access Pool

The message gives information about direct access storage devices (DASD), such as the status of a direct access unit or volume, the disposition of a volume, or a request to mount a volume.

5

Tape Library

The message gives tape library information, such as a request by volume serial numbers for tapes for system or problem program use.

6

Disk Library

The message gives disk library information, such as a request by volume serial numbers for volumes for system or problem program use.

7

Unit Record Pool

The message gives information about unit record equipment, such as a request to mount a printer train.

8

Teleprocessing Control

The message gives the status or disposition of teleprocessing equipment, such as a message that describes line errors.

9

System Security

The message gives information about security checking, such as a request for a password.

10

System/Error Maintenance

The message gives problem information for the system programmer, such as a system error, an uncorrectable I/O error, or information about system maintenance.

11

Programmer Information

This is commonly referred to as write to programmer (WTP). The message is intended for the problem programmer. This routing code is used when the program issuing the message cannot route the message to the programmer through a system output (SYSOUT) data set. The message appears in the JESYSMSG data set. If the message is issued by a TSO user, the message is also sent to the TSO user's screen.

12

Emulation

The message gives information about emulation. (These message identifiers are not included in this publication.)

13-20

For customer use only.

21-28

For subsystem use only.

29

Disaster recovery.

30-40

For IBM use only.

41

The message gives information about JES3 job status.

42

The message gives general information about JES2 or JES3.

43-64

For JES use only.

65-96

Messages associated with particular processors.

97-128

Messages associated with particular devices.

If you omit the ROUTCDE, DESC, and CONSID or CONSNAME keywords, the system uses the routing code specified on the ROUTCODE keyword on the DEFAULT statement in the CONSOLxx member of SYS1.PARMLIB.

Note: Routing codes 1, 2, 3, 4, 7, 8, 10, and 42 cause hard copy of the message when display consoles are used, or more than one console is active. All other routing codes may go to hardcopy as a PARMLIB option or as a result of a VARY HARDCPY command.

,DESC=(descriptor code)

Specifies the message descriptor code or codes to be assigned to the message. Descriptor codes 1 through 6, 11 and descriptor code 12 are mutually exclusive. Codes 7 through 10, and 13, can be assigned in combination with any other code.

The descriptor codes are:

Code**Meaning****1****System Failure**

The message indicates an error that disrupts system operations. To continue, the operator must reIPL the system or restart a major subsystem. This causes the audible alarm to be issued.

Note:

- Descriptor code 1 messages are retained if the Action Message Retention Facility (AMRF) is active.
- Descriptor code 1 messages do not automatically roll off a console in RD mode.

2**Immediate Action Required**

The message indicates that the operator must perform an action immediately. The message issuer could be in a wait state until the action is performed or the system needs the action as soon as possible to improve performance. The task waits for the operator to complete the action. This causes the audible alarm to be issued.

Note:

- When an authorized program issues a message with descriptor code 2, a DOM macro *must* be issued to delete the message after the requested action is performed.
- Descriptor code 2 messages are retained if the Action Message Retention Facility (AMRF) is active.

- Descriptor code 2 messages do not automatically roll off a console in RD mode.

3**Eventual Action Required**

The message indicates that the operator must perform an action eventually. The task does not wait for the operator to complete the action.

If the task can determine when the operator has performed the action, the task should issue a DOM macro to delete the message when the action is complete.

Note: Descriptor code 3 messages are retained if the Action Message Retention Facility (AMRF) is active.

4**System Status**

The message indicates the status of a system task or of a hardware unit.

5**Immediate Command Response**

The message is issued as an immediate response to a system command. The response does not depend on another system action or task.

6**Job Status**

The message indicates the status of a job or job step.

7**Task-Related**

The message is issued by an application or system program. Messages with this descriptor code are deleted when the job step that issued them ends.

8**Out-of-Line**

The message, which is one line of a group of one or more lines, is to be displayed out-of-line. If a message cannot be displayed out-of-line because of the device being used, descriptor code 8 is ignored, and the message is displayed in-line with the other messages.

Note: Multiline messages directed at an OOL area and routed by either the UNKNIDS or INTIDS attributes are forced "inline".

9**Operator's Request**

The message is written in response to an operator's request for information by a DEVSERV, DISPLAY, or MONITOR command.

10**Not defined**

Descriptor code 10 is not currently in use.

11**Critical Eventual Action Required**

The message indicates that the operator must perform an action eventually, and the action is important enough for the message to remain on the display screen until the action is completed. The task does not wait for the operator to complete the action. This causes the audible alarm to be issued.

Avoid using this descriptor code for non-critical messages because the display screen could become filled.

If the task can determine when the operator has performed the action, the task should issue a DOM macro to delete the message when the action is complete.

Note:

- Descriptor code 11 messages are retained if the Action Message Retention Facility (AMRF) is active.
- Descriptor code 11 messages do not automatically roll off a console in RD mode.

12**Important Information**

The message contains important information that must be displayed at a console, but does not require any action in response.

13**Automation Information**

Indicates that this message was previously automated.

Action messages many have an * sign or @ sign displayed before the first character of the message. The * sign indicates that the WTO was issued by an authorized program. The @ sign indicates that the WTO was issued by an unauthorized program.

All WTO messages with descriptor codes 1, 2, or 11 are action messages that have an asterisk (*) sign displayed before the first character of the message. This indicates a need for operator action. These action messages cause the audible alarm to sound on operator consoles so-equipped. On operator consoles that support color, descriptor codes determine the color in which a message should be displayed. Colors can indicate the type of action you need to take depending on your installation setup. The colors used for different descriptor codes are described in [z/OS MVS System Commands](#).

The system holds messages with descriptor codes 1, 2, 3, or 11 until you delete them. When you no longer need messages with descriptor codes 1, 2, 3, or 11, you should delete those messages using the DOM macro. If messages with descriptor codes 1, 2, 3, or 11 also have descriptor code 7, the system deletes them automatically at task termination. For unauthorized issuers of WTOs, the system adds descriptor code 7 to all messages with descriptor code 1 or 2. The system also adds descriptor code 7 to all WTOs.

If descriptor code 7 is specified, the system deletes the message automatically when the job step that issued it ends.

The message processing facility (MPF) can suppress messages. For MPF to suppress messages, the hardcopy log must be active. The suppressed messages do not appear on any console; they do appear on the hardcopy log.

,AREAID=id char

Specifies a display area of the console screen on which a multiple-line message is to be written.

Valid area IDs are A through K and Z. A through K refer to out-of-line areas defined on an MCS console by the CONTROL A command. The character Z designates the message area (the screen's general message area, rather than a defined display area); it is assumed if nothing is specified. The areas are explained in [z/OS MVS System Commands](#).

Notes:

1. WTO ignores this keyword on single-line invocations.
2. When you specify AREAID, you must specify descriptor codes 8 and 9.
3. If you specify this parameter, the area could be overlaid by a currently running dynamic display. Support for queuing messages with descriptor code 8 is by console ID only. You must specify a console explicitly using the CONSID or CONSNAME parameters on WTO.
4. You can use the CONVCON macro to syntactically validate an area ID.

,MSGTYP=(msg type)

Specifies how the message is to be routed to consoles on which the MONITOR command is active. If you specify anything other than MSGTYP=N, which is the default, your message is routed according to your specification on MSGTYP.

For SESS, JOBNAMEs, or STATUS, the message is to be routed to the console that issued the MONITOR SESS, MONITOR JOBNAMEs, or MONITOR STATUS command, respectively. When the message type is identified by the operating system, the message is routed to those consoles that requested the information.

For Y, the message type describes what functions (MONITOR SESS, MONITOR JOBNAMEs, and MONITOR STATUS) are wanted. N, or omission of the MSGTYP parameter, indicates that the message is to be routed as specified in the ROUTCODE parameter. Y creates an area in the WTO parameter list in which you can set message type information if you are coding a WTO without any of the following parameters:

- KEY
- TOKEN
- CONSID
- CONSNAME
- TEXT
- CART
- LINKAGE
- SYNCH

IBM recommends that you do not use MSGTYP=Y.

,MCSFLAG=(flag name)

Specifies one or more flags whose meanings are shown below:

Table 47. MCSFLAG Flag Names	
Flag Name	Meaning
RESP	The WTO is an immediate command response.
REPLY	This WTO is a reply to a WTOR.
BRDCST	Broadcast the message to all active consoles.
HRDCPY	Queue the message for hardcopy only.
NOTIME	Do not append time to the message.
NOCPY	Do not queue the message for hardcopy.
CMD	The WTO is a recording of a system command issued for hardcopy log purposes.

Notes:

1. MCSFLAG=HRDCPY and SYNCH=YES are mutually exclusive.
2. Use DESC=5 rather than specifying MCSFLAG=RESP for WTO messages that are immediate command response.

,CONNECT=connect field

Specifies a field containing the 4-byte message ID of the previous WTO to which this WTO is to be connected. This message ID is obtained as an output parameter (returned in register 1) from the previous WTO. If a register is used, it contains the address of the message ID.

CONNECT is valid only for continuation of multiple-line messages. When you specify this parameter in the list form, code it as CONNECT= with nothing after the equal sign.

This parameter is mutually exclusive with the CONSID, CONSNAME, and SYSNAME parameters.

Note: If you specify LINKAGE=SVC, you can still use register 0, as mentioned at the beginning of the WTO macro description, to connect WTO messages. If you specify both register 0 and CONNECT, however, the system uses the CONNECT parameter. IBM suggests that you use the CONNECT parameter.

,CONSID=console id

Specifies a 4-byte field containing the ID of the console to receive a message.

Notes:

1. If you code the CONSID parameter using a register, the register must contain the console ID itself, rather than the address of the console ID.
2. When you code CONSID on the list form of WTO, code it as CONSID= with nothing after the equal sign.
3. CONSID is mutually exclusive with the CONNECT, CONSNAME, and SYSNAME parameters.

,CONSNAME=console name

Specifies an 8-byte field containing a 2- through 8-character name, left-justified and padded with blanks, of the console to receive a message. When you specify this parameter in the list form, code it as CONSNAME= with nothing after the equal sign.

This parameter is mutually exclusive with the CONSID, CONNECT, and SYSNAME parameters.

,SYSNAME=system name

Specifies an 8-byte input field containing a system name to be associated with this message. You should left-justify SYSNAME and pad with blanks.

The system name is that of the system from which the caller issues the WTO. When you specify this parameter in the list form, code it as SYSNAME= with nothing after the equal sign. If SYSNAME is omitted, the system uses the name of the system where the WTO is issued. IBM suggests that you avoid using the SYSNAME parameter.

This parameter is mutually exclusive with the CONNECT parameter.

,CART=cmd/resp token

Specifies an 8-character input field containing a command and response token to be associated with this message. The command and response token is used to associate user information with a command and its command response. You can supply any value as a command and response token. When you specify this parameter in the list form, code it as CART= with nothing after the equal sign.

,KEY=key

Specifies an input field containing an 8-byte key to be associated with this message. The key must be EBCDIC if used with the MVS DISPLAY R command for retrieval purposes, but it must not be “*”. The key must be left-justified, and padded on the right with blanks. If a register is used, it contains the address of the key. When you specify this parameter in the list form, code it as KEY= with nothing after the equal sign.

,TOKEN=token

Specifies an input field containing a 4-byte token to be associated with this message. This field is used to identify a group of messages that can be deleted by a DOM macro that includes TOKEN. The token must be unique within an address space and can be any value. When you specify this parameter in the list form, code it as TOKEN= with nothing after the equal sign.

Note: When you code the TOKEN parameter using a register, the register must contain the token itself, rather than the address of the token.

,JOBID=job id

Specifies an 8-byte input field containing an ID that identifies the issuer of the WTO message. When you specify this parameter in the list form, code it as JOBID= with nothing after the equal sign.

,JOBNAME=jobname

Specifies an 8-byte input field containing a name that identifies the issuer of the WTO message. You should left-justify JOBNAME and pad with blanks. When you specify this parameter in the list form, code it as JOBNAME= with nothing after the equal sign.

,LINKAGE=SVC**,LINKAGE=BRANCH**

Specifies how control is to pass to the WTO service.

LINKAGE=SVC indicates that the linkage is by a supervisor call. If LINKAGE is not specified, this is the default.

LINKAGE=BRANCH indicates that the linkage is by a branch-and-link. This parameter is used by programs that run at times when an SVC cannot be issued, and by programs that require the WTO request to be handled synchronously.

When you specify this parameter in the list form, code it as LINKAGE= with nothing after the equal sign.

If you specify LINKAGE=BRANCH, you cannot put the CONNECT value in register 0. You must use the CONNECT keyword.

,SYNCH=NO**,SYNCH=YES**

Specifies whether the WTO request processes synchronously with the caller.

SYNCH=NO, the default, indicates that the request is not processed synchronously.

SYNCH=YES indicates that the request is to be processed synchronously. This parameter is used in error and recovery environments, when normal message processing cannot be used. The message is sent to a console, where it is held on the screen for up to ten seconds, before control is returned to the caller. A copy of the message is queued for transcription to the hardcopy log.

If you specify SYNCH=YES:

- You must specify the parameter LINKAGE=BRANCH.
- The message text must be 14 lines or less.
- The following parameters are mutually exclusive: CONNECT, AREAID, and MCSFLAG=HRDCPY.

Important: Use caution when specifying SYNCH=YES. If your installation has not specified a SYNCHDEST console group in the CNGRPxx member of parmlib, the system displays the WTO on the system console, located in the Operating System Messages task on the Hardware Management Console. All of the system's CPs *may be stopped* while the message is being displayed (for up to ten seconds). See the "Display of Synchronous Messages" topic in [z/OS MVS Planning: Operations](#) for more information about how z/OS displays these messages.

Your installation can determine which consoles can receive synchronous messages by using the SYNCHDEST parameter in the CONSOLxx member of SYS1.PARMLIB. For additional information on the SYNCHDEST parameter, see [z/OS MVS Initialization and Tuning Reference](#).

,WSPARM=0**,WSPARM=wait state addr**

Specifies whether a wait state is associated with this message.

A value of zero indicates that there is no wait state associated with this message. If you do not specify WSPARM, this is the default.

A nonzero value indicates either the address of a LOADWAIT parameter list or a register containing a pointer to the parameter list. The LOADWAIT macro generates the LOADWAIT parameter list. When you specify this parameter in the list form, code it as WSPARM= with nothing after the equal sign.

This parameter requires the SYNCH=YES and LINKAGE=BRANCH parameters.

ABEND codes

WTO might abnormally terminate with abend code X' D23 '. See [z/OS MVS System Codes](#) for an explanation and programmer response for this code.

Return and reason codes

When the WTO macro returns control to your program, GPR 15 contains one of the following hexadecimal return codes.

Table 48. Return codes for the WTO macro	
Return Code	Meaning and Action
00	<p>Meaning: Processing completed successfully.</p> <p>Action: None.</p>
02	<p>Meaning: Processing was not completely successful. This could be due to inconsistent parameters given to WTO, or it could be an environmental problem.</p> <p>Action: A D23 abend has been issued for diagnostic purposes only. No dump has been taken; if a dump is needed, you must set a SLIP trap. Correct any inconsistencies in the WTO invocation.</p>
04	<p>Meaning: Program error. The length of text for a message line was not correct.</p> <p>Action:</p> <ul style="list-style-type: none"> • Make sure your text is properly referenced. If you are using the TEXT parameter, make sure it is pointing to valid data. • Make sure your message text is defined correctly. If you are using the TEXT parameter, make sure the first two bytes of data in the area pointed to by the TEXT parameter value contain the length of the message text. <p>In all cases, correct the problem and retry the request.</p>
08	<p>Meaning: Program error. The connecting message ID (passed in register 0 or as specified by the CONNECT parameter value) does not match any on the queue. The request was ignored.</p> <p>Action: Verify the connect ID value, correct the problem, and retry the request.</p>
18	<p>Meaning: Program error. The WPL was invalid and a symptom record was written to LOGREC to describe the error. The message was not processed.</p> <p>Action: Correct the WPL.</p>
30	<p>Meaning: Environmental error. For routing code 11, the required resource was not available and the request was ignored. For any other routing code, the request was processed.</p> <p>Action: Retry the request when the resource you need is available.</p>
40	<p>Meaning: Environmental error. WTO was issued with LINKAGE=BRANCH; insufficient storage was available to queue the message for delayed issue. If SYNCH=NO was specified, the message was not queued for delayed issue. If SYNCH=YES was specified, the message was delivered for display, but not queued for hardcopy.</p> <p>Action: If you want the message to be delivered to the destination you requested, reissue the request. If the message was an action message that was not displayed, a DOM request is not required.</p>
44	<p>Meaning: Environmental error. WTO was issued with LINKAGE=BRANCH, SYNCH=YES, or was issued during IPL processing; no usable console was available. The message was only queued for hardcopy.</p> <p>Action: If the message was issued during IPL, do not reissue the message. If after IPL and you want the message to be delivered to the destination you requested, reissue the request. If the message was an action message that was not displayed, a DOM request is not required.</p>
48	<p>Meaning: Environmental error. WTO was issued with LINKAGE=BRANCH, SYNCH=YES, or was issued during IPL processing; no usable console was available and insufficient storage was available to queue the message for delayed issue. The message was not delivered for display, nor queued for hardcopy.</p> <p>Action: If the message was issued during IPL, do not reissue the message. If after IPL and you want the message to be delivered to the destination you requested, reissue the request. If the message was an action message that was not displayed, a DOM request is not required.</p>
4C	<p>Meaning: Environmental error. WTO was issued with LINKAGE=BRANCH; no storage was available for the use of WTO processing. If WSPARM=0, no processing was done. If WSPARM does not equal zero, WTO loaded the wait state, but performed no other processing.</p> <p>Action: If you want the message to be delivered to the destination you requested, reissue the request. If the message was an action message that was not displayed, a DOM request is not required.</p>

Table 48. Return codes for the WTO macro (continued)

Return Code	Meaning and Action
50	Meaning: Environmental error. The message could not be fully processed because of insufficient space. The message might not appear in the hardcopy log and it might not be displayed on any consoles. Action: Retry the request.
54	Meaning: Environmental error. The message could not be fully processed because of a hardcopy failure. The message might not appear in the hardcopy log. Action: Issue a D C,HC to display any active hardcopy mediums. Verify that SYSLOG and OPERLOG are active and functioning correctly and then retry the request.
58	Meaning: Environmental error. The message could not be fully processed because of an error that occurred while sending it. The message might not appear in the hardcopy log and it might not be displayed on any consoles. Action: Retry the request.
5C	Meaning: Environmental error. The message could not be fully processed because of a failure freeing storage. The message might not appear in the hardcopy log and it might not be displayed on any consoles. Action: Retry the request.
60	Meaning: Environmental error. The message could not be fully processed because of an error that occurred while calculating its size. The message might not appear in the hardcopy log and it might not be displayed on any consoles. Action: Retry the request.
64	Meaning: Environmental error. The message could not be fully processed because of an error that occurred while building the message. The message might not appear in the hardcopy log and it might not be displayed on any consoles. Action: Retry the request.
68	Meaning: The WTO environment is not yet available. The message was not delivered for display, nor was it queued for hardcopy. Action: Issue the request again when WTO processing is available.

Example 1

Issue an important information message to a console whose name is defined in field MYCONS. This message is issued using the branch-entry option.

```

WTO      'USR123I DO NOT SUBMIT JOBS REQUESTING THREE OR MORE TAPX
        ES DURING FIRST SHIFT',
        DESC=(12),CONSNAME=MYCONS,LINKAGE=BRANCH,SYNCH=NO
.
.
.
MYCONS DC   CL8'SCHDCONS'
```

Example 2

Issue a multi-line message using the TEXT parameter. This is an important information message which does not have a timestamp and is not sent to the hardcopy log.

```

WTO      TEXT=((REMINDD1,D),(REMINDD2,D),(REMINDD3,DE)),          X
        DESC=(12),MCSFLAG=(NOTIME,NOCPY)
.
.
.
REMINDD1 DC  AL2(L'RMD1TXT)
RMD1TXT DC   C'USR003I REMINDER:  THE SYSTEM IS NOT AVAILABLE FOR USEX
              ON THIRD SHIFT'
REMINDD2 DC  AL2(L'RMD2TXT)
RMD2TXT DC   C'FOR SPECIAL REQUESTS CONTACT SYSTEM SUPPORT'
REMINDD3 DC  AL2(L'RMD3TXT)
RMD3TXT DC   C'CALL THE STATUS DESK FOR FURTHER INFORMATION'
```

Example 3

To prevent parameter lists that are not valid from causing system errors, the WTO service records the errors as symptom records in LOGREC. This is a sample symptom record:

```

THE SYMPTOM RECORD DOES NOT CONTAIN A SECONDARY SYMPTOM STRING.
FREE FORMAT COMPONENT INFORMATION:
KEY = F000      LENGTH = 000024 (0018)
+000      C9D5C3D6      D9D9C5C3      E340E6E3      D640C9D5      |INCORRECT WTO IN|
+010      E5D6C3C1      E3C9D6D5      |VOCATION        |
KEY = F000      LENGTH = 000010 (000A)
+000      C1E4E3C8      D6D9C9E9      C5C4      |AUTHORIZED      |
KEY = F000      LENGTH = 000009 (0009)
+000      C1E2C9C4      61F0F0F0      F1      |ASID/0001       |
KEY = F000      LENGTH = 000016 (0010)
+000      D1D6C2D5      C1D4C561      5CD4C1E2      E3C5D95C      |JOBNAME/*MASTER*|
KEY = F000      LENGTH = 000025 (0019)
+000      C9D5E5D6      D2C5D961      C9C5C5C3      C2F9F9F9      |INVOKER/IEECB999|
+010      4EF0F0F0      F0F4C5C4      F2      |+00004ED2      |
KEY = F000      LENGTH = 000032 (0020)
+000      C5D5C4D3      C9D5C540      C4C5E3C5      C3E3C5C4      |ENDLINE DETECTED|
+010      40C2C5C6      D6D9C540      E6D7D3D3      C9D5C5E2      | BEFORE WPLLINES|
KEY = F000      LENGTH = 000017 (0011)
+000      C3E4D9D9      C5D5E340      D3C9D5C5      61F0F0F0      |CURRENT LINE/000|
+010      F2      |2              |
KEY = F000      LENGTH = 000003 (0003)
+000      E6D7D3      |WPL            |
KEY = FF00      LENGTH = 000216 (00D8)
+000      00480050      F0F0F2F2      40C5D5C1      C2D3C5C4      |...&0022 ENABLED|
+010      4040F0F0      F2F340C5      D5C1C2D3      C5C44040      | 0023 ENABLED   |
+020      F0F0F2F4      40C5D5C1      C2D3C5C4      4040F0F0      |0024 ENABLED 00|
+030      F2F540C5      D5C1C2D3      C5C44040      F0F0F2F6      |25 ENABLED 0026|
+040      40C5D5C1      C2D3C5C4      0400007C      10000000      |ENABLED...@....|
+050      00000000      00000000      000004D2      00000000      |.....K....|
+060 LENGTH(0048) ==> ALL BYTES CONTAIN X'00'.
+090      00000000      40404040      40404040      00000000      |....          ....|
+0A0 LENGTH(0032) ==> ALL BYTES CONTAIN X'00'.
+0C0      00000000      2000C103      00103000      F0F0F2F7      |.....A.....0027|
+0D0      40C5D5C1      C2D3C5C4      |ENABLED        |
KEY = F000      LENGTH = 000010 (000A)
+000      D4C1D1D6      D940E3C5      E7E3      |MAJOR TEXT      |
KEY = F000      LENGTH = 000034 (0022)
+000      40C9C5C5      F7F3F5C9      40F1F74B      F2F74BF3      |IEE000I 17.27.3|
+010      F940C4E4      D4D4E840      C4C9E2D7      D3C1E840      |9 DUMMY DISPLAY |
+020      F2F3F4      |234            |

```

This symptom record indicates that this is a WTO error. It also indicates whether the WTO issuer was authorized. The symptom record also contains the following information:

- The ASID, job name, program name, and an offset into the program that issued the WTO. You can use this information to help identify the issuer.
- A description of the error.
- The message line number where the error was detected.
- The text of the first line, if the message is a multi-line WTO.

Once you diagnose the reason for the error, correct the WTO invocation to issue the message properly, or contact the owner of the application that is issuing the WTO to have it corrected.

WTO - List form

Use the list form of the WTO macro together with the execute form of the macro for applications that require reentrant code. The list form of the macro defines an area of storage, which the execute form of the macro uses to store the parameters.

Syntax

The list form of the WTO macro is written as follows:

Syntax	Description																					
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.																					
␣	One or more blanks must precede WTO.																					
WTO																						
␣	One or more blanks must follow WTO.																					
'msg'	<i>msg</i> : Up to 126 characters.																					
('text')	<i>text</i> : Up to 126 characters.																					
('text',line type)	Note: 1. If you code 'msg' or ('text'...), it must be the first parameter you code. 2. For a single-line WTO, the parameter value is not required on TEXT for the list form. Code only TEXT=. Then code TEXT= <i>text addr</i> on the execute form.																					
TEXT=																						
TEXT=((,line type),(,line type),... (,line type))																						
	The permissible <i>line types</i> , text lengths, and maximum numbers of each line type are shown below: <table><tr><td>line type</td><td>text</td><td>maximum number</td></tr><tr><td>C</td><td>35 char</td><td>1 C type</td></tr><tr><td>L</td><td>71 char</td><td>2 L type</td></tr><tr><td>D</td><td>71 char</td><td>255 D type</td></tr><tr><td>DE</td><td>71 char</td><td>1 DE type</td></tr><tr><td></td><td>or</td><td></td></tr><tr><td>E</td><td>None</td><td>1 E type</td></tr></table> The maximum total number of lines that can be coded in one instruction is 255.	line type	text	maximum number	C	35 char	1 C type	L	71 char	2 L type	D	71 char	255 D type	DE	71 char	1 DE type		or		E	None	1 E type
line type	text	maximum number																				
C	35 char	1 C type																				
L	71 char	2 L type																				
D	71 char	255 D type																				
DE	71 char	1 DE type																				
	or																					
E	None	1 E type																				
,ROUTCDE=(routing code)	<i>routing code</i> : Decimal digit from 1 to 128. The <i>routing code</i> is one or more codes, separated by commas, or a hyphen to indicate a range.																					
,DESC=(descriptor code)	<i>descriptor code</i> : Decimal digit from 1 to 13. The <i>desc code</i> is one or more codes, separated by commas.																					
,AREAID=id char	<i>id char</i> : Alphabetic character A - K, Z.																					

Syntax	Description
,MSGTYP=(<i>msg type</i>)	<p><i>msg type</i>: Any of the following</p> <p>N SESS,JOBNAMES</p> <p>Y SESS,STATUS</p> <p>SESS JOBNAMES,STATUS</p> <p>JOBNAMES SESS,JOBNAMES,STATUS</p> <p>STATUS</p> <p>Note: IBM recommends that you do not use MSGTYP=Y. See the MSGTYP explanation on page “,MSGTYP=(msg type)” on page 381 for more information.</p>
,MCSFLAG=(<i>flag name</i>)	<p><i>flag name</i>: Any combination of the following, separated by commas:</p> <p>CMD HRDCPY</p> <p>RESP NOCOPY</p> <p>REPLY NOTIME</p> <p>BRDCST</p>
,CONNECT=	Parameter value not required for list form. Code only ,CONNECT=. If you code CONNECT on the execute form of WTO, you must code the same parameter on the list form.
,CONSID=	Parameter value not required for list form. Code only ,CONSID= (or ,CONSNAME=). If you code CONSID (or CONSNAME) on the execute form of WTO, you must code the same parameter on the list form.
,CONSNAME=	
,SYSNAME=	Parameter value not required for list form. Code only ,SYSNAME=. If you code SYSNAME on the execute form of WTO, you must code the same parameter on the list form.
,CART=	Parameter value not required for list form. Code only ,CART=. If you code CART on the list form of WTO, you must code CART on the execute form.
,KEY=	Parameter value not required for list form. Code only ,KEY=. If you code KEY on the list form of WTO, you must code KEY on the execute form.

Syntax	Description
,TOKEN=	Parameter value not required for list form. Code only ,TOKEN=. If you code TOKEN on the list form of WTO, you must code TOKEN on the execute form.
,JOBID=	Parameter value not required for list form. Code only ,JOBID=. If you code JOBID on the list form of WTO, you must code JOBID on the execute form.
,JOBNAME=	Parameter value not required for list form. Code only ,JOBNAME=. If you code JOBNAME on the list form of WTO, you must code JOBNAME on the execute form.
,LINKAGE=	Parameter value not required for list form. Code only ,LINKAGE=. If you code LINKAGE on the list form of WTO, you must code LINKAGE on the execute form.
,SYNCH=NO	Default: NO
,SYNCH=YES	
,WSPARM=	Parameter value not required for list form. Code only ,WSPARM=. If you code WSPARM on the list form of WTO, you must code WSPARM on the execute form.
,MF=L	

Parameters

The parameters are explained under the standard form of the WTO macro with the following exception:

,MF=L

Specifies the list form of the WTO macro.

WTO - Execute form

Use the execute form of the WTO macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The message cannot be modified on the execute form of the macro if you code inline text ('msg' or ('text'...)) on the list form.

Syntax

The execute form of the WTO macro is written as follows:

Syntax	Description

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede WTO.
WTO	
␣	One or more blanks must follow WTO.
TEXT= <i>text addr</i>	
TEXT=((<i>text addr</i> ,),(<i>text addr</i> ,),...(<i>text addr</i> ,))	
	<i>text addr</i> : RX-type address or register (2) - (12). Note: 1. If you code TEXT= <i>text addr</i> on the execute form of WTO, you must code TEXT= on the list form. 2. If you specify inline text on the list form (' <i>msg</i> ' or (' <i>text</i> '...)), do not code the TEXT keyword on the execute form.
,CONNECT= <i>connect field</i>	<i>connect field</i> : RX-type address or register (2) - (12). If you code CONNECT on the execute form of WTO, you must code the same parameter on the list form.
,CONSID= <i>console id</i>	<i>console id</i> : RX-type address or register (2) - (12).
,CONSNAME= <i>console name</i>	<i>console name</i> : RS-type address or register (2) - (12).
	If you code CONSID (or CONSNAME) on the execute form of WTO, you must code the same parameter on the list form.
,SYSNAME= <i>system name</i>	<i>system name</i> : RS-type address or register (2) - (12). If you code SYSNAME on the execute form of WTO, you must code the same parameter on the list form.
,CART= <i>cmd/resp token</i>	<i>cmd/resp token</i> : RX-type address or register (2) - (12). If you code CART on the execute form of WTO, you must code CART on the list form.
,KEY= <i>key</i>	<i>key</i> : RS-type address or register (2) - (12). If you code KEY on the execute form of WTO, you must code KEY on the list form.

Syntax	Description
,TOKEN= <i>token</i>	<i>token</i> : RX-type address or register (2) - (12). If you code TOKEN on the execute form of WTO, you must code TOKEN on the list form.
,JOBID= <i>job id</i>	<i>job id</i> : RS-type address or register (2) - (12). If you code JOBID on the execute form of WTO, you must code JOBID on the list form.
,JOBNAME= <i>jobname</i>	<i>jobname</i> : RS-type address or register (2) - (12). If you code JOBNAME on the execute form of WTO, you must code JOBNAME on the list form.
,LINKAGE=SVC	Default: SVC
,LINKAGE=BRANCH	If you code LINKAGE on the execute form of WTO, you must code LINKAGE on the list form.
,SYNCH=NO	Default: NO
,SYNCH=YES	
,WSPARM=0	Default: 0
,WSPARM= <i>wait state addr</i>	<i>wait state addr</i> : RX-type address or register (2) - (12).
	If you code WSPARM on the execute form of WTO, you must code WSPARM on the list form.
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address, or register (1) - (12).

Parameters

The parameters are explained under the standard form of the WTO macro, with the following exception:

,MF=(E, *list addr*)

Specifies the execute form of the WTO macro.

list addr specifies the area that the system uses to store the parameters.

Example

Write a message with a prebuilt parameter list pointed to by register 1.

```
WTO      MF=(E, (1))
```


Chapter 36. WTOR – Write to operator with reply

Description

The WTOR macro causes a message requiring a reply to be written to one or more operator consoles and the hardcopy log. The macro also provides the information required by the system to return the reply to the issuing program. See *z/OS MVS Programming: Authorized Assembler Services Guide* for more information on using the WTOR macro.

The description of the WTOR macro follows. The WTOR macro is also described in *z/OS MVS Programming: Assembler Services Reference IAR-XCT*, with the exception of the MSGTYP, SYSNAME, JOBID, JOBNAME, LINKAGE, and SYNCH parameters.

Environment

If you code **LINKAGE=SVC**, the requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	One of the following, depending on the parameters you code: <ul style="list-style-type: none"> • Problem state and PSW key 0-7. • If you code the MSGTYP, SYSNAME, JOBID, JOBNAME, and SYNCH parameters, one of the following: <ul style="list-style-type: none"> – Supervisor state with PSW key 0-7 – APF-authorized
Dispatchable unit mode:	Task
Cross memory mode:	PASN=HASN=SASN
AMODE:	24- or 31- or 64-bit
ASC mode:	Primary
Interrupt status:	Enabled for I/O and external interrupts.
Locks:	No locks held
Control parameters:	Must be in the primary address space

If you code **LINKAGE=BRANCH**, the requirements for the caller are:

Environmental factor	Requirement
Minimum authorization:	Supervisor state with PSW key 0-7
Dispatchable unit mode:	Task or SRB
Cross memory mode:	Any PASN, any HASN, any SASN
AMODE:	24- or 31-bit
ASC mode:	Primary
Interrupt status:	Enabled or disabled for I/O and external interrupts.
Locks:	The caller may hold locks, but is not required to hold any.
Control parameters:	Must be in the primary address space.

Programming requirements

Be aware of the following when coding the WTOR macro:

- IBM recommends that you begin the parameter list for WTOR on a fullword boundary.
- If the caller is disabled, the WTOR parameter list, reply area, and reply ECB must be in fixed storage. In this case, LINKAGE=BRANCH and SYNCH=YES must be specified.
- If the list and execute forms of the WTOR macro are in separate modules, both modules must be assembled or compiled with the same level of WTOR.
- When you're coding a reentrant program, make sure the WTOR parameter list is generated correctly. To ensure this, you must code the same parameters on both forms, only when you code one or more of the following parameters:
 - RPLYISUR
 - CONSID
 - CONSNAME
 - SYSNAME
 - CART
 - KEY
 - TOKEN
 - JOBNAME
 - JOBID
 - LINKAGE

On the list form, code only the parameter and the equal sign; do not code a parameter value as well. If you specify parameter values on the list form, the system issues an MNOTE and ignores the data.

- For any WTOR keywords that allow a register specification, the value must be right-justified in the register.
- If you specify the TEXT keyword for a multi-line WTOR, you must code its parameters in the following way:
 - On the list form, omit *text addr* for each line, but include *line type*. If you specify *text addr*, the system ignores the data and issues an MNOTE.
 - On the execute form, omit *line type* for each line, but include *text addr*.
- To prevent parameter lists that are not valid from causing system errors, the WTOR service records the errors as symptom records in LOGREC. One example of an invalid parameter list is an invalid combination of WTOR parameters. The system may also issue a D23 abend for diagnostic purposes only; the program issuing the WTOR will not be abended. Message processing will continue as far as possible using the invalid parameter list.

Because of these invalid parameter list errors, you might notice that some messages that you once were able to process can no longer be processed; your program may also receive different return codes. However, in these cases, the symptom record will always be issued, and the diagnostic D23 abend will be issued if possible. IBM suggests that you correct all WTOR errors, regardless of whether or not the message is actually displayed. For an example LOGREC symptom record, see [“Example 3” on page 386](#) in the WTO description.

If a dump is needed along with the diagnostic D23 abend to debug the problem, the following SLIP can be set to cause dumps to be taken:

```
SLIP SET,ENABLE,COMP=D23,ACTION=SVCD,END
```

Restrictions

- The caller cannot have an EUT FRR established.

- If the LINKAGE=BRANCH parameter is specified, the SYNCH=YES parameter is required.
- You can issue a multi-line WTOR only if you specify LINKAGE=BRANCH, SYNCH=YES.
- Issue a synchronous message only if your program is in a state in which it cannot issue an ordinary WTOR (LINKAGE=SVC), and you must receive operator input before continuing.

Important: Use caution when specifying SYNCH=YES. If your installation has not specified a SYNCHDEST console group in the CNGRPxx member of parmlib, the system will display the WTOR on the system console, located in the Operating System Messages task on the Hardware Management Console. All of the system's CPs *may be stopped* while waiting for the operator to reply. See the "Display of Synchronous Messages" topic in [z/OS MVS Planning: Operations](#) for more information about how z/OS displays these messages.

Input register information

Before issuing the WTOR macro, the caller does not have to place any information into any register unless using it in register notation for a particular parameter, or using it as a base register.

Output register information

When control returns to the caller, the general purpose registers (GPRs) contain:

Register Contents

- 0**
Used as a work register by the system
- 1**
Message identification number if the macro completed normally (you can use this number to delete the message when it is no longer needed); otherwise, used as a work register by the system
- 2-13**
Unchanged
- 14**
Used as a work register by the system
- 15**
Return code

When control returns to the caller, the access registers (ARs) contain:

Register Contents

- 0-1**
Used as work registers by the system
- 2-13**
Unchanged
- 14-15**
Used as work registers by the system

Some callers depend on register contents remaining the same before and after issuing a service. If the system changes the contents of registers on which the caller depends, the caller must save them before issuing the service, and restore them after the system returns control.

Performance implications

SYNCH=YES causes the system to display the message, disable the issuing program *and system*, and then synchronously provide the reply to the program. If your installation has not specified a SYNCHDEST console group in the CNGRPxx member of parmlib, the system will display the WTOR on the system console, located in the Operating System Messages task on the Hardware Management Console. All of the system's CPs *may be stopped* while waiting for the operator to reply.

Syntax

The standard form of the WTOR macro is written as follows:

Syntax	Description																					
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.																					
 	One or more blanks must precede WTOR.																					
WTOR																						
 	One or more blanks must follow WTOR.																					
'msg',reply addr,reply length,ecb addr																						
('text',reply addr,reply length,ecb addr)																						
((('text',line type),...('text',line type)),reply addr, reply length,ecb addr																						
TEXT=(text addr,reply addr,reply length,ecb addr)																						
TEXT=((text addr,line type),reply addr, reply length,ecb addr)																						
TEXT=(((text addr,line type),...(text addr, line type)),reply addr,reply length,ecb addr)																						
	Note: If you code 'msg'... or ('text'...), it must be the first parameter you code.																					
	<i>msg</i> : Up to 122 characters.																					
	<i>text</i> : Up to 122 characters.																					
	<i>text addr</i> : RX-type address or register (2) - (12).																					
	<i>reply addr</i> : A-type address, or register (2) - (12).																					
	<i>reply length</i> : Symbol, decimal digit, or register (2) - (12). The minimum length is 1; the maximum length is 119.																					
	<i>ecb addr</i> : A-type address, or register (2) - (12). The permissible <i>line types</i> , text lengths, and maximum numbers are shown below: <table><tr><td>line type</td><td>text</td><td>maximum number</td></tr><tr><td>C</td><td>31 char</td><td>1 C type</td></tr><tr><td>L</td><td>66 char</td><td>2 L type</td></tr><tr><td>D</td><td>66 char</td><td>14 D type</td></tr><tr><td>DE</td><td>66 char</td><td>1 DE type</td></tr><tr><td></td><td>or</td><td></td></tr><tr><td>E</td><td>None</td><td>1 E type</td></tr></table> The maximum total of lines that can be coded in one instruction is 14.	line type	text	maximum number	C	31 char	1 C type	L	66 char	2 L type	D	66 char	14 D type	DE	66 char	1 DE type		or		E	None	1 E type
line type	text	maximum number																				
C	31 char	1 C type																				
L	66 char	2 L type																				
D	66 char	14 D type																				
DE	66 char	1 DE type																				
	or																					
E	None	1 E type																				

Syntax	Description
,ROUTCDE=(<i>routing code</i>)	<i>routing code</i> : Decimal digit from 1 to 128. The <i>routing code</i> is one or more codes, separated by commas, or a hyphen to indicate a range.
,DESC=(<i>descriptor code</i>)	<i>descriptor code</i> : Decimal number 7 or 13. If you code both 7 and 13, separate them with commas.
,MSGTYP=(<i>msg type</i>)	<p><i>msg type</i>: Any of the following:</p> <p>N SESS,JOBNAMES</p> <p>Y SESS,STATUS</p> <p>SESS JOBNAMES,STATUS</p> <p>JOBNAMES SESS,JOBNAMES,STATUS</p> <p>STATUS</p> <p>Note: IBM recommends that you do not use MSGTYP=Y. See the MSGTYP explanation on page “,MSGTYP=(<i>msg type</i>)” on page 401 for more information.</p>
,MCSFLAG=(<i>flag name</i>)	<p><i>flag name</i>: Any combination of the following, separated by commas:</p> <p>NOCPY HRDCPY</p> <p>RESP BRDCST</p> <p>REPLY NOTIME</p>
,RPLYISUR= <i>reply console</i>	<i>reply console</i> : RX-type address or register (2) - (12).
,CONSID= <i>console id</i>	<i>console id</i> : RX-type address or register (2) - (12).
,CONSNAME= <i>console name</i>	<i>console name</i> : RX-type address or register (2) - (12).
,SYSNAME= <i>system name</i>	<i>system name</i> : RX-type address or register (2) - (12).
,CART= <i>cmd/resp token</i>	<i>cmd/resp token</i> : RX-type address or register (2) - (12).

Syntax	Description
,KEY= <i>key</i>	<i>key</i> : RX-type address or register (2) - (12).
,TOKEN= <i>token</i>	<i>token</i> : RX-type address or register (2) - (12).
,JOBID= <i>job id</i>	<i>job id</i> : RX-type address or register (2) - (12).
,JOBNAME= <i>jobname</i>	<i>jobname</i> : RX-type address or register (2) - (12).
,LINKAGE=SVC	Default: SVC
,LINKAGE=BRANCH	
,SYNCH=NO	Default: NO
,SYNCH=YES	

Parameters

The parameters are explained as follows:

'msg',reply addr,reply length,ecb addr

('text',reply addr,reply length,ecb addr)

(('text',line type,...'text',line type),reply addr,reply length,ecb addr)

TEXT=(*text addr,reply addr,reply length,ecb addr*)

TEXT=((*text addr,line type*),*reply addr,reply length,ecb addr*)

TEXT=(((*text addr,line type*),...(*text addr, line type*)),*reply addr,reply length,ecb addr*)

Specifies the message or multiple-line message to be written to one or more operator consoles.

Use the *'msg'* parameter to write a single-line message to the operator. Enclose the message in apostrophes. The apostrophes do not appear on the console. You can include any character that can be used in a character (C-type) DC instruction.

To have apostrophes appear in the message text, use two apostrophes to get one to appear. For example, "Message Off" would appear on a display as 'Message Off'. When a program issues a WTOR macro, the system translates the text; only standard printable EBCDIC characters are passed to MCS-managed display devices. The EBCDIC characters that can be displayed are listed in "Timing and Communication" in *z/OS MVS Programming: Assembler Services Guide*. All other characters are replaced by blanks. Unless the console has dual-case capability, lowercase characters are displayed or printed as uppercase characters.

The message is assembled as a variable-length record. *text addr* represents a 4-byte address of a message to be displayed that consists of a 2-byte message length followed by the message text. The 2-byte message length describes the length of the message text only. There are no boundary requirements.

Use the parameters (*'text'*) and (*text addr,line type*) to write a multiple-line message to the operator. For an authorized program, the message can be up to fourteen lines long; the system truncates the message at the end of the fourteenth line. The fourteen-line limit does not include the control line (message IEE932I), as explained under line type C below.

Note:

1. You can issue a multi-line WTOR only if you specify SYNCH=YES. See the SYNCH parameter description for information about its use.
2. If you code the parameter ('*text*') without repetition, the message appears as a single-line message.
3. Specify all lines of a multiple-line WTOR consistently with the message text or the TEXT keyword. When coding the TEXT keyword for a multiple-line message, do not exceed the 66-character limit for the macro parameter value.

The line type defines the type of information contained in the 'text' field of each line of the message:

C

Indicates that the 'text' parameter is the text to be contained in the control line of the message. The control line normally contains a message title. C may be coded only for the first line of a multiple-line message. Control lines are optional.

L

Indicates that the 'text' parameter is a label line. Label lines contain message heading information. Label lines are optional. If coded, lines must either immediately follow the control line or another label line or be the first line of the multiple-line message if there is no control line. Only two label lines may be coded per message.

D

Indicates that the 'text' parameter contains the information to be conveyed to the operator by the multiple-line message.

DE

Indicates that the 'text' parameter contains the last line of information to be passed to the operator. Specify DE on the last line of text of the WTOR. If there is no text on the last line, specify E.

E

Indicates that the previous line of text was the last line of text to be passed to the operator. The 'text' parameter, if any, coded with a line type of E is ignored. Specify E on the last line of the WTOR if that line has no text. If the last line has text, specify DE.

Note: All WTOR messages are action messages. An indicator (* for authorized issuers or @ for unauthorized issuers) appears before the first character of an action message to indicate a need for operator action. Action messages will cause the audible alarm to sound on operator consoles so-equipped.

reply addr specifies the address in virtual storage of the area into which the system is to place the reply. The reply is left-justified at this address.

reply length specifies the maximum length, in bytes, of the reply message.

ecb addr specifies the address of the event control block (ECB) to be used by the system to indicate the completion of the reply. The ECB address must point to a fullword boundary. After the system receives the reply, the ECB appears as follows:

Offset	Length(bytes)	Contents
0	1	Completion code

Note: Use RPLYISUR to obtain the 4-byte console ID and console name of the console issuing the reply.

,ROUTCDE=(*routing code*)

Specifies the routing code or codes to be assigned to the message.

The routing codes are:

Code

Meaning

1

Operator Action

The message indicates a change in the system status. It demands action by the primary operator.

2

Operator Information

The message indicates a change in system status. It does not demand action; rather, it alerts the primary operator to a condition that might require action.

This routing code is used for any message that indicates job status when the status is not requested specifically by an operator inquiry. It is also used to route processor and problem program messages to the system operator.

3

Tape Pool

The message gives information about tape devices, such as the status of a tape unit or reel, the disposition of a tape reel, or a request to mount a tape.

4

Direct Access Pool

The message gives information about direct access storage devices (DASD), such as the status of a direct access unit or volume, the disposition of a volume, or a request to mount a volume.

5

Tape Library

The message gives tape library information, such as a request by volume serial numbers for tapes for system or problem program use.

6

Disk Library

The message gives disk library information, such as a request by volume serial numbers for volumes for system or problem program use.

7

Unit Record Pool

The message gives information about unit record equipment, such as a request to mount a printer train.

8

Teleprocessing Control

The message gives the status or disposition of teleprocessing equipment, such as a message that describes line errors.

9

System Security

The message gives information about security checking, such as a request for a password.

10

System/Error Maintenance

The message gives problem information for the system programmer, such as a system error, an uncorrectable I/O error, or information about system maintenance.

11

Programmer Information

This is commonly referred to as write to programmer (WTP). The message is intended for the problem programmer. This routing code is used when the program issuing the message cannot route the message to the programmer through a system output (SYSOUT) data set. The message appears in the JESYSMSG data set. If the message issuer is a TSO user, the message is also displayed on the TSO user's screen.

12**Emulation**

The message gives information about emulation. (These message identifiers are not included in this publication.)

13-20

For customer use only.

21-28

For subsystem use only.

29

Disaster recovery.

30-40

For IBM use only.

41

The message gives information about JES3 job status.

42

The message gives general information about JES2 or JES3.

43-64

For JES use only.

65-96

Messages associated with particular processors.

97-128

Messages associated with particular devices.

If you omit the ROUTCDE, and CONSID or CONSNAME keywords, the system uses the routing code specified on the ROUTCODE keyword on the DEFAULT statement in the CONSOLxx member of SYS1.PARMLIB. See *z/OS MVS Initialization and Tuning Reference* for information about CONSOLxx.

,DESC=(descriptor code)

Specifies the message descriptor code or codes to be assigned to the message. Valid descriptor codes for the WTOR macro are:

7

Retain action message for life-of-task

13

Message previously automated

All WTOR messages are action messages that have an asterisk (*) sign displayed before the first character (WTORs for unauthorized users have an "@" sign displayed before the first character). This indicates a need for operator action.

The system adds descriptor code 7 to all WTOR messages. The system holds all WTOR messages until one of the following events occurs:

- The system deletes the WTOR message when the reply is received.
- You delete the WTOR message using the DOM macro. You should delete any unanswered WTOR messages that are no longer current.
- The system deletes the WTOR message at task termination.

The message processing facility (MPF) can suppress messages. For MPF to suppress messages, the hardcopy log must be active. The suppressed messages do not appear on any console; they do appear on the hardcopy log.

,MSGTYP=(msg type)

Specifies how the message is to be routed to consoles on which the MONITOR command is active. If you specify anything other than MSGTYP=N, which is the default, your message is routed according to your specification on MSGTYP.

For SESS, JOBNAMES, or STATUS, the message is to be routed to the console that issued the MONITOR SESS, MONITOR JOBNAMES, or MONITOR STATUS command, respectively. When the message type is identified by the operating system, the message is routed to only those consoles that requested the information.

For Y or N, the message type describes what functions (MONITOR SESS, MONITOR JOBNAMES, and MONITOR STATUS) are desired. N, or omission of the MSGTYP parameter, indicates that the message is to be routed as specified in the ROUTCDE parameter. Y creates an area in the WTO parameter list in which you can set message type information if you are coding a WTOR without any of the following parameters:

- KEY
- TOKEN
- CONSID
- CONSNAME
- TEXT
- RPLYISUR
- CART
- LINKAGE
- SYNCH

IBM recommends that you do not use MSGTYP=Y.

,MCSFLAG=(flag name)

Specifies one or more flag names whose meanings are shown below:

<i>Table 49. MCSFLAG Flag Names</i>	
Flag Name	Meaning
RESP	The WTOR is an immediate command response.
REPLY	This is a reply to a WTOR.
BRDCST	Broadcast the message to all active consoles.
HRDCPY	Queue the message for hard copy only.
NOTIME	Do not append time to the message.
NOCPY	Do not queue the message for hard copy.

,RPLYISUR=reply console

Specifies a 12-byte field where the system will place the 8-byte console name and the 4-byte console ID of the console through which the operator replies to this message. When you specify this keyword in the list form, code it as RPLYISUR= with nothing after the equal sign.

,CONSID=console id

Specifies a 4-byte field containing the ID of the console to receive a message.

Note:

1. If you code the CONSID parameter using a register, the register must contain the console ID itself, rather than the address of the console ID.
2. When you code CONSID on the list form of WTOR, code it as CONSID= with nothing after the equal sign.
3. CONSID is mutually exclusive with the CONSNAME parameter.

,CONSNAME=console name

Specifies an 8-byte field containing a 2- through 8-character name, left-justified and padded with blanks, of the console to receive a message. This parameter is mutually exclusive with the CONSID

parameter. When you specify this keyword in the list form, code it as CONSNAME= with nothing after the equal sign.

,SYSNAME=system name

Specifies an 8-byte input field containing a system name to be associated with this message. You should left-justify SYSNAME and pad with blanks.

The system name is that of the system from which the caller issues the WTOR message. When you specify this parameter in the list form, code it as SYSNAME= with nothing after the equal sign. The system will, by default, set the system name to the system where the message is issued. IBM suggests that you avoid specifying SYSNAME.

,CART=cmd/resp token

Specifies an 8-byte field containing a command and response token to be associated with this message. You can specify any value as a command and response token. The command and response token is used to associate user information with a command and its command response. When you specify this keyword in the list form, code it as CART= with nothing after the equal sign.

,KEY=key

Specifies a field containing an 8-byte key to be associated with this message. The key must be EBCDIC if used with the MVS DISPLAY R command for retrieval purposes, but it must not be '*'. The key must be left-justified and padded on the right with blanks. If a register is used, it contains the address of the key. When this keyword is specified in the list form, it must be coded as KEY= with nothing after the equal sign.

,TOKEN=token

Specifies a field containing a 4-byte token to be associated with this message. This field is used to identify a group of messages that can be deleted by a DOM macro that includes TOKEN. The token must be unique within an address space, and can be any value. When you specify this keyword on the list form, code it as TOKEN= with nothing after the equal sign.

Note: When you code the TOKEN parameter using a register, the register must contain the token itself, rather than the address of the token.

,JOBID=job id

Specifies an 8-byte input field containing an ID that specifies the issuer of the WTOR message. When you specify this parameter in the list form, code it as JOBID= with nothing after the equal sign.

,JOBNAME=jobname

Specifies an 8-byte input field containing a name that specifies the issuer of the WTOR message. You should left-justify JOBNAME and pad with blanks. When you specify this parameter in the list form, code it as JOBNAME= with nothing after the equal sign.

,LINKAGE=SVC

,LINKAGE=BRANCH

Specifies how control is to pass to the WTOR service.

LINKAGE=SVC indicates the linkage is by a supervisor call. If LINKAGE is not specified, this is the default.

LINKAGE=BRANCH indicates the linkage is by a branch-and-link. You must use SYNCH=YES with this parameter. This parameter is used by programs that require the WTOR request to be handled synchronously.

When you specify this keyword in the list form, code it as LINKAGE= with nothing after the equal sign.

,SYNCH=NO

,SYNCH=YES

Specifies whether the WTOR request processes synchronously with the caller.

SYNCH=NO, the default, indicates that the request is not processed synchronously.

SYNCH=YES indicates the request is to be processed synchronously. This parameter is used in error and recovery environments, when normal message processing cannot be used. The message is sent to the console, and the reply is obtained immediately, before control is returned to the caller. Before

return, the *reply* and *reply length* are moved to the areas specified by the caller, and the *ecb* marked “complete.” Copies of the message and reply are queued for transcription to the hardcopy log.

If you specify SYNCH=YES:

- You must specify the parameter LINKAGE=BRANCH.
- Do not specify MCSFLAG=HRDCPY.
- Do not specify RPLYISUR

Important: Use caution when specifying SYNCH=YES. If your installation has not specified a SYNCHDEST console group in the CNGRPxx member of parmlib, the system will display the WTOR on the system console, located in the Operating System Messages task on the Hardware Management Console. All of the system’s CPs *may be stopped* while waiting for the operator to reply. See the "Display of Synchronous Messages" topic in [z/OS MVS Planning: Operations](#) for more information about how z/OS displays these messages.

Your installation can determine which consoles can receive synchronous messages by using the SYNCHDEST parameter in the CONSOLxx member of SYS1.PARMLIB. For additional information on the SYNCHDEST parameter, see [z/OS MVS Initialization and Tuning Reference](#).

ABEND codes

WTOR might abnormally terminate with abend code X'D23'. See [z/OS MVS System Codes](#) for an explanation and programmer response for this code.

Return and reason codes

When the WTOR macro returns control to your program, GPR 15 contains one of the following hexadecimal return codes.

Table 50. Return Codes for the WTOR Macro	
Return Code	Meaning and Action
00	<p>Meaning: Processing completed successfully.</p> <p>Action: None. Be sure to delete the message by issuing the DOM macro (if this is an action message or a WTOR).</p>
02	<p>Meaning: Processing was not completely successful. This might be caused by inconsistent parameters given to WTOR, or it could be an environmental problem.</p> <p>Action: A D23 abend has been issued for diagnostic purposes only. No dump has been taken; if a dump is needed, you must set a SLIP trap. Correct any inconsistencies in the WTOR invocation.</p>
04	<p>Meaning: Program error. The length of text for a message line was not correct.</p> <p>Action:</p> <ul style="list-style-type: none"> • Make sure your text is properly referenced. If you are using the TEXT parameter, make sure it is pointing to valid data. • Make sure your message text is defined correctly. If you are using the TEXT parameter, make sure the first two bytes of data in the area pointed to by the TEXT parameter value contain the length of the message text. <p>In all cases, correct the problem and retry the request.</p>
08	<p>Meaning: Program error. The connecting message ID (passed in register 0 or specified in the CONNECT parameter) does not match any on the queue. The request was ignored.</p> <p>Action: Verify the CONNECT ID value, correct the problem, and retry.</p>
18	<p>Meaning: Program error. The WPL was invalid and a symptom record was written to LOGREC to describe the error. The message was not processed.</p> <p>Action: Correct the WPL.</p>
30	<p>Meaning: Environmental error. For routing code 11, the required resource was not available; the request was ignored. For any other routing code, the request was processed.</p> <p>Action: Retry the request when the resource you need is available.</p>

Table 50. Return Codes for the WTOR Macro (continued)

Return Code	Meaning and Action
40	<p>Meaning: Environmental error. WTOR was issued with LINKAGE=BRANCH; insufficient storage was available to queue the message for delayed issue. If SYNCH=NO was specified, the message was not queued for delayed issue. If SYNCH=YES was specified, the message was delivered for display, but not queued for hardcopy.</p> <p>Action: If you want the message to be delivered to the destination you requested, reissue the request. If the message was not displayed, a DOM request is not required.</p>
44	<p>Meaning: Environmental error. WTOR was issued with LINKAGE=BRANCH, SYNCH=YES, or was issued during IPL processing; no usable console was available. The message was only queued for hardcopy.</p> <p>Action: If the message was issued during IPL, do not reissue the message. If after IPL and you want the message to be delivered to the destination you requested, reissue the request. If the message was not displayed, a DOM request is not required.</p>
48	<p>Meaning: Environmental error. WTOR was issued with LINKAGE=BRANCH, SYNCH=YES, or was issued during IPL processing; no usable console was available and insufficient storage was available to queue the message for delayed issue. The message was not delivered for display, nor queued for hardcopy.</p> <p>Action: If the message was issued during IPL, do not reissue the message. If after IPL and you want the message to be delivered to the destination you requested, reissue the request. If the message was not displayed, a DOM request is not required.</p>
4C	<p>Meaning: Environmental error. WTOR was issued with LINKAGE=BRANCH; no storage was available for the use of WTOR processing.</p> <p>Action: If you want the message to be delivered to the destination you requested, reissue the request. If the message was not displayed, a DOM request is not required.</p>
50	<p>Meaning: Environmental error. The message could not be fully processed because of insufficient space. The message might not appear in the hardcopy log and it might not be displayed on any consoles.</p> <p>Action: Retry the request.</p>
54	<p>Meaning: Environmental error. The message could not be fully processed because of a hardcopy failure. The message might not appear in the hardcopy log.</p> <p>Action: Issue a D C,HC to display any active hardcopy mediums. Verify that SYSLOG and OPERLOG are active and functioning correctly and then retry the request.</p>
58	<p>Meaning: Environmental error. The message could not be fully processed because of an error that occurred while sending it. The message might not appear in the hardcopy log and it might not be displayed on any consoles.</p> <p>Action: Retry the request.</p>
5C	<p>Meaning: Environmental error. The message could not be fully processed because of a failure freeing storage. The message might not appear in the hardcopy log and it might not be displayed on any consoles.</p> <p>Action: Retry the request.</p>
60	<p>Meaning: Environmental error. The message could not be fully processed because of an error that occurred while calculating its size. The message might not appear in the hardcopy log and it might not be displayed on any consoles.</p> <p>Action: Retry the request.</p>
64	<p>Meaning: Environmental error. The message could not be fully processed because of an error that occurred while building the message. The message might not appear in the hardcopy log and it might not be displayed on any consoles.</p> <p>Action: Retry the request.</p>
68	<p>Meaning: The WTO environment is not yet available. The message was not delivered for display, nor was it queued for hardcopy.</p> <p>Action: Issue the request again when WTO processing is available.</p>

Example 1

Issue a WTOR to the primary operator.

WTOR macro

```
L8      EQU      8
      .
      .
      .
      WTOR      'USR902A REPLY YES OR NO TO CONTINUE.' ,REPLY,L8,REPECB, X
              ROUTCDE=(1) ,RPLYISUR=CONINFO
      .
      .
      .
REPLY   DS       CL8
REPECB  DS       F
CONINFO DS       CL12
```

Example 2

Issue a WTOR with the TEXT parameter. The message is to go to a specific console whose name is in field TOCON.

```
R4      EQU      4
R5      EQU      5
LENG12  EQU      12
      .
      .
      .
      LA        R4,CATMSG
      LA        R5,TAPEAREA
      WTOR      TEXT=((R4),REPAREA,LENG12,TAPEECB),          X
              CONSNAME=TOCON,                                X
              RPLYISUR=(R5)
      .
      .
      .
CATMSG  DC        AL2(L'REP64)                                00011800
REP64   DC        C'USR922A INDICATE NUMBER OF TAPE DRIVES REQUIRED.'
TOCON   DC        CL8'TAPECON '
REPAREA DS        CL12
TAPEECB DS        F
TAPEAREA DS       CL12
```

Example 3

Issue a branch-entry WTOR.

```
C80     EQU      80
      .
      .
      .
      WTOR      'USR940I ENTER THE NAMES OF AFFECTED JOBS:' ,REPAR6,C80,JX
              OBSECB,RPLYISUR=JOBCONS,                        X
              ROUTCDE=(1) ,LINKAGE=BRANCH ,SYNCH=YES
      .
      .
      .
REPAR6  DS        CL80
JOBSECB DS        F
JOBCONS DS        CL12
```

Example 4

Issue a WTOR using the TEXT parameter with the list and execute forms of the macro. The console ID to which the message is to be queued is assumed to be in field MYCONID. On the TEXT parameter for the execute form, commas mark the positions of *reply addr* and *ecb addr*; for the list form, a comma marks the position of *reply length*.

```
R12     EQU      12
C50     EQU      50
      USING    *,R12
      .
      .
      .
      WTOR      MF=(E,M2,EXTENDED) ,TEXT=(MESSAGE,,C50,) ,CONSID=MYCONID, X
              RPLYISUR=MYCONAR
```

```

      .
      .
      .
M2      DS      0F
      WTOR      TEXT=( ,RAREA, ,MYECB) ,CONSID= ,ROUTCDE=(2) ,RPLYISUR= ,MF=L
MYCONID DS      F
RAREA   DS      CL50
MYECB   DS      F
MYCONAR DS      CL12
MESSAGE DC      AL2(L'MTEXT)
MTEXT   DC      C'USR930A REQUEST IS AMBIGUOUS. RESPECIFY DEVICE.'
      END

```

WTOR - List form

Use the list form of the WTOR macro together with the execute form of the macro for applications that require reentrant code. The list form of the macro defines an area of storage, which the execute form of the macro uses to store the parameters.

Syntax

The list form of the WTOR macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
b	One or more blanks must precede WTOR.
WTOR	
b	One or more blanks must follow WTOR.
'msg',reply addr,reply length,ecb addr	
('text',reply addr,reply length,ecb addr)	
((('text',line type,...,'text',line type),reply addr, reply length,ecb addr)	
TEXT=(,reply addr,reply length,ecb addr)	
TEXT=((,(line type),(line type),...,(line type)), reply addr,reply length,ecb addr)	
	<i>msg</i> : Up to 122 characters.
	<i>text</i> : Up to 122 characters.
	<i>reply addr</i> : A-type address.
	<i>reply length</i> : Symbol, decimal digit. The minimum length is 1; the maximum length is 119.
	<i>ecb addr</i> : A-type address.

Syntax	Description																					
	<p>The permissible <i>line types</i>, text lengths, and maximum numbers are shown below:</p> <table><tr><td>line type</td><td>text</td><td>maximum number</td></tr><tr><td>C</td><td>31 char</td><td>1 C type</td></tr><tr><td>L</td><td>66 char</td><td>2 L type</td></tr><tr><td>D</td><td>66 char</td><td>14 D type</td></tr><tr><td>DE</td><td>66 char</td><td>1 DE type</td></tr><tr><td></td><td>or</td><td></td></tr><tr><td>E</td><td>None</td><td>1 E type</td></tr></table> <p>The maximum total of lines that can be coded in one instruction is 14.</p>	line type	text	maximum number	C	31 char	1 C type	L	66 char	2 L type	D	66 char	14 D type	DE	66 char	1 DE type		or		E	None	1 E type
line type	text	maximum number																				
C	31 char	1 C type																				
L	66 char	2 L type																				
D	66 char	14 D type																				
DE	66 char	1 DE type																				
	or																					
E	None	1 E type																				
	<p>Note:</p> <ol style="list-style-type: none">1. If you code '<i>msg</i>'... or ('<i>text</i>'...), it must be the first parameter you code.2. If you do not code <i>reply addr</i> on the list form of WTOR, mark its position with a comma, and code <i>reply addr</i> on the execute form. The same is true for <i>reply length</i> and <i>ecb addr</i>.																					
,ROUTCDE=(<i>routing code</i>)	<i>routing code</i> : Decimal digit from 1 to 128. The <i>routing code</i> is one or more codes, separated by commas, or a hyphen to indicate a range.																					
,DESC=(<i>descriptor code</i>)	<i>descriptor code</i> : Decimal number 7 or 13. If you code both 7 and 13, separate them with commas.																					
,MSGTYP=(<i>msg type</i>)	<p><i>msg type</i>: Any of the following:</p> <p>N SESS,JOBNAMES</p> <p>Y SESS,STATUS</p> <p>SESS JOBNAMES,STATUS</p> <p>JOBNAMES SESS,JOBNAMES,STATUS</p> <p>STATUS</p> <p>Note: IBM recommends that you do not use MSGTYP=Y. See the MSGTYP explanation on page “,MSGTYP=(msg type)” on page 381 for more information.</p>																					

Syntax	Description
,MCSFLAG=(<i>flag name</i>)	<p><i>flag name</i>: Any combination of the following, separated by commas:</p> <p>NOCPY HRDCPY</p> <p>RESP BRDCST</p> <p>REPLY NOTIME</p>
,RPLYISUR=	Parameter value not required for list form. Code only ,RPLYISUR=. If you code RPLYISUR on the list form of WTOR, you must code RPLYISUR on the execute form.
,CONSID=	Parameter value not required for list form. Code only ,CONSID= (or ,CONSNAME=). If you code CONSID (or CONSNAME) on the list form of WTOR, you must code CONSID (or CONSNAME) on the execute form.
,CONSNAME=	
,SYSNAME=	Parameter value not required for list form. Code only ,SYSNAME=. If you code SYSNAME on the list form of WTOR, you must code SYSNAME on the execute form.
,CART=	Parameter value not required for list form. Code only ,CART=. If you code CART on the list form of WTOR, you must code CART on the execute form.
,KEY=	Parameter value not required for list form. Code only ,KEY=. If you code KEY on the list form of WTOR, you must code KEY on the execute form.
,TOKEN=	Parameter value not required for list form. Code only ,TOKEN=. If you code TOKEN on the list form of WTOR, you must code TOKEN on the execute form.
,JOBID=	Parameter value not required for list form. Code only ,JOBID=. If you code JOBID on the list form of WTOR, you must code JOBID on the execute form.

Syntax	Description
,JOBNAME=	Parameter value not required for list form. Code only ,JOBNAME=. If you code JOBNAME on the list form of WTOR, you must code JOBNAME on the execute form.
,LINKAGE=	Parameter value not required for list form. Code only ,LINKAGE=. If you code LINKAGE on the list form of WTOR, you must code LINKAGE on the execute form.
,SYNCH=NO	Default: NO
,SYNCH=YES	
,MF=L	

Parameters

The parameters are explained under the standard form of the WTOR macro with the following exception:

,MF=L

Specifies the list form of the WTOR macro.

WTOR - Execute form

Use the execute form of the WTOR macro together with the list form of the macro for applications that require reentrant code. The execute form of the macro stores the parameters into the storage area defined by the list form.

The message cannot be modified on the execute form of the macro if you code inline text ('msg'... or 'text'...) on the list form.

Syntax

The execute form of the WTOR macro is written as follows:

Syntax	Description
<i>name</i>	<i>name</i> : Symbol. Begin <i>name</i> in column 1.
␣	One or more blanks must precede WTOR.
WTOR	

Syntax	Description
<code>␣</code>	One or more blanks must follow WTOR.
<code>,reply addr,reply length,ecb addr</code>	
<code>TEXT=(text addr,reply addr,reply length,ecb addr)</code>	
<code>TEXT=(((text addr,),(text addr,...(text addr,)),reply addr,reply length,ecb addr)</code>	
	<i>reply addr</i> : RX-type address, or register (2) - (12).
	<i>reply length</i> : Symbol, decimal digit, or register (2) - (12).
	The minimum length is 1; the maximum length is 119.
	<i>ecb addr</i> : RX-type address, or register (2) - (12).
	<i>text addr</i> : RX-type address or register (2) - (12).
	Note: <ol style="list-style-type: none"> 1. If you code <i>reply addr,reply length,ecb addr</i>, it must be the first parameter you code and must be preceded by a comma. 2. If you specify inline text on the list form ('msg'... or ('text'...)), do not code the TEXT keyword on the execute form. 3. If you do not code <i>reply addr</i> on the execute form of WTOR, mark its position with a comma, and code <i>reply addr</i> on the list form. The same is true for <i>reply length</i> and <i>ecb addr</i>.
<code>,RPLYISUR=reply console</code>	<i>reply console</i> : RX-type address or register (2) - (12). If you code RPLYISUR on the execute form of WTOR, you must code RPLYISUR on the list form.
<code>,CONSID=console id</code>	<i>console id</i> : RX-type address or register (2) - (12).
<code>,CONSNAME=console name</code>	<i>console name</i> : RS-type address or register (2) - (12).

Syntax	Description
	If you code CONSID (or CONSNAME) on the execute form of WTOR, you must code the same parameter on the list form.
,SYSNAME= <i>system name</i>	<i>system name</i> : RS-type address or register (2) - (12).
	If you code SYSNAME on the execute form of WTOR, you must code the same parameter on the list form.
,CART= <i>cmd/resp token</i>	<i>cmd/resp token</i> : RX-type address or register (2) - (12).
	If you code CART on the execute form of WTOR, you must code CART on the list form.
,KEY= <i>key addr</i>	<i>key addr</i> : RS-type address or register (2) - (12).
	If you code KEY on the execute form of WTOR, you must code KEY on the list form.
,TOKEN= <i>token addr</i>	<i>token addr</i> : RX-type address or register (2) - (12).
	If you code TOKEN on the execute form of WTOR, you must code TOKEN on the list form.
,JOBID= <i>job id</i>	<i>job id</i> : RS-type address or register (2) - (12).
	If you code JOBID on the execute form of WTOR, you must code JOBID on the list form.
,JOBNAME= <i>jobname</i>	<i>jobname</i> : RS-type address or register (2) - (12).
	If you code JOBNAME on the execute form of WTOR, you must code JOBNAME on the list form.
,LINKAGE=SVC	Default: SVC

Syntax	Description
,LINKAGE=BRANCH	If you code LINKAGE on the execute form of WTOR, you must code LINKAGE on the list form.
,SYNCH=NO	Default: NO
,SYNCH=YES	
,MF=(E, <i>list addr</i>)	<i>list addr</i> : RX-type address, or register (1) - (12).
,MF=(E, <i>list addr</i> ,EXTENDED)	

Parameters

These parameters are explained under the standard form of the WTOR macro, with the following exceptions:

,*reply addr*,*reply length*,*ecb addr*

If you code *reply addr*, *reply length*, *ecb addr*, it must be the first parameter you code and must be preceded by a comma.

,MF=(E,*list addr*)

,MF=(E,*list addr*,EXTENDED)

Specifies the execute form of the WTOR macro.

list addr specifies the area that the system uses to store the parameters.

If you specify *reply addr*, *reply length*, or *ecb addr* on the execute form of WTOR, and any of the following parameters are also specified on the list and/or execute form, you must specify EXTENDED for the system to generate the parameter list correctly:

- KEY
- TOKEN
- CONSID
- CONSNAME
- TEXT
- RPLYISUR
- CART
- Any value of ROUTCDE higher than 16

Example

Write a message with a prebuilt parameter list pointed to by register 1.

```
WTOR      MF=(E,(1))
```

Appendix A. Accessibility

Accessible publications for this product are offered through [IBM Documentation \(www.ibm.com/docs/en/zos\)](http://www.ibm.com/docs/en/zos).

If you experience difficulty with the accessibility of any z/OS information, send a detailed message to the [Contact the z/OS team web page \(www.ibm.com/systems/campaignmail/z/zos/contact_z\)](http://www.ibm.com/systems/campaignmail/z/zos/contact_z) or use the following mailing address.

IBM Corporation
Attention: MHVRCFS Reader Comments
Department H6MA, Building 707
2455 South Road
Poughkeepsie, NY 12601-5400
United States

Notices

This information was developed for products and services that are offered in the USA or elsewhere.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive, MD-NC119
Armonk, NY 10504-1785
United States of America*

For license inquiries regarding double-byte character set (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

*Intellectual Property Licensing
Legal and Intellectual Property Law
IBM Japan Ltd.
19-21, Nihonbashi-Hakozakicho, Chuo-ku
Tokyo 103-8510, Japan*

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

This information could include missing, incorrect, or broken hyperlinks. Hyperlinks are maintained in only the HTML plug-in output for IBM Documentation. Use of hyperlinks in other output formats of this information is at your own risk.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

*IBM Corporation
Site Counsel
2455 South Road*

Poughkeepsie, NY 12601-5400
USA

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

All statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs. The sample programs are provided "AS IS", without warranty of any kind. IBM shall not be liable for any damages arising out of your use of the sample programs.

Terms and conditions for product documentation

Permissions for the use of these publications are granted subject to the following terms and conditions.

Applicability

These terms and conditions are in addition to any terms of use for the IBM website.

Personal use

You may reproduce these publications for your personal, noncommercial use provided that all proprietary notices are preserved. You may not distribute, display or make derivative work of these publications, or any portion thereof, without the express consent of IBM.

Commercial use

You may reproduce, distribute and display these publications solely within your enterprise provided that all proprietary notices are preserved. You may not make derivative works of these publications, or

reproduce, distribute or display these publications or any portion thereof outside your enterprise, without the express consent of IBM.

Rights

Except as expressly granted in this permission, no other permissions, licenses or rights are granted, either express or implied, to the publications or any information, data, software or other intellectual property contained therein.

IBM reserves the right to withdraw the permissions granted herein whenever, in its discretion, the use of the publications is detrimental to its interest or, as determined by IBM, the above instructions are not being properly followed.

You may not download, export or re-export this information except in full compliance with all applicable laws and regulations, including all United States export laws and regulations.

IBM MAKES NO GUARANTEE ABOUT THE CONTENT OF THESE PUBLICATIONS. THE PUBLICATIONS ARE PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, AND FITNESS FOR A PARTICULAR PURPOSE.

IBM Online Privacy Statement

IBM Software products, including software as a service solutions, ("Software Offerings") may use cookies or other technologies to collect product usage information, to help improve the end user experience, to tailor interactions with the end user, or for other purposes. In many cases no personally identifiable information is collected by the Software Offerings. Some of our Software Offerings can help enable you to collect personally identifiable information. If this Software Offering uses cookies to collect personally identifiable information, specific information about this offering's use of cookies is set forth below.

Depending upon the configurations deployed, this Software Offering may use session cookies that collect each user's name, email address, phone number, or other personally identifiable information for purposes of enhanced user usability and single sign-on configuration. These cookies can be disabled, but disabling them will also eliminate the functionality they enable.

If the configurations deployed for this Software Offering provide you as customer the ability to collect personally identifiable information from end users via cookies and other technologies, you should seek your own legal advice about any laws applicable to such data collection, including any requirements for notice and consent.

For more information about the use of various technologies, including cookies, for these purposes, see IBM's Privacy Policy at ibm.com/privacy and IBM's Online Privacy Statement at ibm.com/privacy/details in the section entitled "Cookies, Web Beacons and Other Technologies," and the "IBM Software Products and Software-as-a-Service Privacy Statement" at ibm.com/software/info/product-privacy.

Policy for unsupported hardware

Various z/OS elements, such as DFSMSdfp, JES2, JES3, and MVS, contain code that supports specific hardware servers or devices. In some cases, this device-related element support remains in the product even after the hardware devices pass their announced End of Service date. z/OS may continue to service element code; however, it will not provide service related to unsupported hardware devices. Software problems related to these devices will not be accepted for service, and current service activity will cease if a problem is determined to be associated with out-of-support devices. In such cases, fixes will not be issued.

Minimum supported hardware

The minimum supported hardware for z/OS releases identified in z/OS announcements can subsequently change when service for particular servers or devices is withdrawn. Likewise, the levels of other software products supported on a particular release of z/OS are subject to the service support lifecycle of those

products. Therefore, z/OS and its product publications (for example, panels, samples, messages, and product documentation) can include references to hardware and software that is no longer supported.

- For information about software support lifecycle, see: [IBM Lifecycle Support for z/OS \(www.ibm.com/software/support/systemsz/lifecycle\)](http://www.ibm.com/software/support/systemsz/lifecycle)
- For information about currently-supported IBM hardware, contact your IBM representative.

Programming interface information

This information is intended to help the customer to code macros that are available to authorized assembler language programs. This information documents intended programming interfaces that allow the customer to write programs to obtain services of z/OS.

Trademarks

IBM, the IBM logo, and [ibm.com](http://www.ibm.com) are trademarks or registered trademarks of International Business Machines Corp., registered in many jurisdictions worldwide. Other product and service names might be trademarks of IBM or other companies. A current list of IBM trademarks is available on the Web at [Copyright and Trademark information \(www.ibm.com/legal/copytrade.shtml\)](http://www.ibm.com/legal/copytrade.shtml).

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, Windows NT, and the Windows logo are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Index

A

- accessibility
 - contact IBM [415](#)
- addressing mode and the services [2](#)
- ALET qualification
 - of parameters [3](#)
- AR () mode
 - description [3](#)
- ASC (address space control) mode
 - defining [3](#)
- assistive technologies [415](#)
- authorization
 - testing caller [219](#)

C

- callable service
 - coding [14](#)
- caller
 - testing authorization [219](#)
- coding the callable services [14](#)
- coding the macros [11](#)
- contact
 - z/OS [415](#)
- continuation line [13](#)
- control access to a serially reusable resource [33](#)
- CPU time
 - obtaining accumulated [223](#)

E

- event
 - waiting for one or more [355](#)

F

- feedback [xxvii](#)
- functional recovery routine
 - setting up [27](#)

I

- IHATRBPL mapping macro [192](#), [193](#)
- IHATREPL mapping macro [193](#)

K

- keyboard
 - navigation [415](#)
 - PF keys [415](#)
 - shortcut keys [415](#)

L

- log

- log (*continued*)
 - writing [361](#)

M

- macro
 - coding [11](#)
 - forms [10](#)
 - level
 - selecting [1](#)
 - sample [12](#)
 - selecting level [1](#)
 - user parameter, passing [4](#)
 - X-macros
 - using [9](#)

N

- navigation
 - keyboard [415](#)

P

- parameter
 - setting return [45](#)
- process
 - putting in process-must-complete mode [109](#)
- process-must-complete mode [109](#)

Q

- query virtual server [205](#)
- QVS [205](#)

R

- RETRIEVE service
 - reason codes [171](#)
 - return codes [171](#)

S

- sending to IBM
 - reader comments [xxvii](#)
- service
 - ALET qualification [3](#)
 - summary [15](#)
- services
 - addressing mode [2](#)
 - ASC mode
 - defining [3](#)
 - using [1](#)
- SETFRR macro [27](#)
- SETLOCK macro [33](#)
- SETRP macro [45](#)
- shortcut keys [415](#)

- SJFREQ macro
 - RETRIEVE service [57](#), [60](#)
 - SWBTU_MERGE service [57](#), [64](#), [65](#)
 - TERMINATE service [58](#), [82](#)
 - VERIFY service [58](#), [71](#)
- SMF record, writing [85](#), [89](#)
- SMFEWTM, write SMF record [85](#)
- SMFWTM, write SMF record [89](#)
- SPIE macro [93](#)
- SPOST macro [99](#)
- SRB (service request block)
 - transferring control [217](#)
- SRB status [101](#)
- SRBSTAT macro [101](#)
- SRBTIMER macro [105](#)
- STATUS macro [109](#)
- storage
 - obtaining and releasing [115](#)
- STORAGE macro [115](#)
- subtask
 - starting and stopping [109](#)
- summary of changes
 - z/OS MVS Programming: Authorized Assembler Services Reference SET-WTO [xxix](#), [xxx](#)
- SUSPEND macro for RBs [141](#), [143](#)
- SUSPEND macro for SRBs [145](#)
- SVC exit
 - type 6 [229](#)
- SVCUPDTE macro [151](#)
- SWA manager
 - invoking in locate mode [161](#)
- SWAREQ macro [161](#)
- SWBTUREQ macro [167](#)
- SYNCH and SYNCHX macros [177](#), [185](#)
- synchronous exit
 - to a processing program [177](#)
- SYSEVENT macro [187](#)

T

- T6EXIT macro [229](#)
- TCBTOKEN macro
 - description [209](#)
- TCTL macro [217](#)
- TESTAUTH macro [219](#)
- time limit
 - establishing for system service [105](#)
- TIMEUSED macro [223](#)

U

- UCB (unit control block)
 - obtaining address [289](#)
 - pinning [301](#)
 - scanning [311](#)
 - unpinning [301](#)
- UCBINFO macro [231](#)
- UCBLOOK macro [289](#)
- UCBPIN macro [301](#)
- UCBSCAN macro [311](#)
- user interface
 - ISPF [415](#)
 - TSO/E [415](#)

- user parameter
 - passing [4](#)

V

- vector time
 - obtaining accumulated [223](#)
- virtual storage
 - map [335](#)
 - obtaining private area region size [351](#)
 - verifying allocation [343](#)
- VSMLIST macro [335](#)
- VSMLOC macro [343](#)
- VSMREGN macro [351](#)

W

- WAIT macro [355](#)
- write SMF records [85](#), [89](#)
- WTL macro [361](#)
- WTO macro [369](#)
- WTOR macro [393](#)

X

- X-macros
 - using [9](#)

Z

- z/OS MVS Programming: Authorized Assembler Services Reference SET-WTO
 - summary of changes [xxix](#), [xxx](#)



Product Number: 5650-ZOS

SA23-1375-50

