





Dewar positions

Recycling position



Measurement position



Lifting mechanism indicator	
 OK	Normal measurement position (green)
 Tension	Dewar cradle not secured (amber)
 Limit	Upper limit reached (amber)
 Fault	Contact service representative (red)
Elekta Neuromag	

- **never move** the Dewar while anybody or the chair is under the Dewar
- when **green** light is **blinking** = **recycling position**
- when **green** light is **on** = **measurement position**
(you can move the chair under the Dewar and anybody can take a seat)