

HCRTOS_blt1680多点电容触摸屏使用说明文档

1. 文档履历

版本号	日期	制/修订人	制/修订记录
1.0	2023.11.09	邱浩佳	新增说明

HCRTOS_blt1680多点电容触摸屏使用说明文档

- 1. 文档履历
- 2. 概述
 - 2.1 编写目的
 - 2.2 读者对象
- 3. 模块介绍
 - 3.1 设备树的配置
 - 3.2 menuconfig的配置
 - 3.2.1 i2c的开启
 - 3.2.2 blt1680触摸屏的开启
 - 3.2.3 测试命令的开启
 - 3.2.4 编译
 - 3.2.5 测试命令的使用
- 4. 模块测试用例与Sample Code
- 5. 模块调试方法
- 6. 常见问题

2. 概述

2.1 编写目的

介绍和指导如何在hcrtos上使用blt1680的多点电容触摸屏；

2.2 读者对象

hcartos的开发者和FAE工程师;

3. 模块介绍

1. blt1680触摸屏需要加载对应的固件才可以产生中断及正常使用，代码目录下的固件并不一定适用，需要联系原厂调试合适的固件；
2. 由于该触摸芯片出厂并不内置固件，所以在第一次使用时需要一定时间加载固件进去；
3. hcartos上blt1680不支持电源管理，即不支持睡眠模式；
4. 触摸芯片支持在一定时间没有触摸会进入低功耗模式，有触摸时会自动唤醒；
5. blt1680触摸芯片最大支持10点触摸，需要固件支持；

3.1 设备树的配置

```
1  i2c@1{
2      pinmux-active = <PINPAD_B02 3 PINPAD_B03 3>;    //i2c所使用的引脚及复用
    功能
3      devpath = "/dev/i2c1";    //i2c节点所生产的路径
4      baudrate = <100000>;    //i2c波特率
5      mode = "master";    //i2c模式，此处为master
6      status = "okay";    //okay代表开启
7  };
8
9  betterlife_ts@2c{
10     i2c_devpath = "/dev/i2c1";    //触摸屏所使用的i2c节点
11     i2c_addr = <0x2c>;    //触摸屏的7位设备地址
12     reset_gpio = <PINPAD_L24 0>;//触摸屏复位所使用的引脚
13     irq_gpio = <PINPAD_L27 0>;    //触摸屏中断所使用的引脚
14     // vdd_name = "vdd28";    //触摸屏所使用的电源管理，目前不支持
15     // virtualkeys = <80 900 120 44 240 900 120 44 400 900 120 44>;    //实
    体触摸按键，需要硬件支持
16     TP_MAX_X = <480>;    //触摸屏X坐标分辨率
17     TP_MAX_Y = <800>;    //触摸屏Y坐标分辨率
18     status = "okay";    //okay代表开启
19  };
```

3.2 menuconfig的配置

3.2.1 i2c的开启

```

1 Symbol: CONFIG_I2C_SCB_MASTER [=y]
2 Type : bool
3 Prompt: I2C SCB Master
4 Location:
5     -> Components
6     -> kernel (BR2_PACKAGE_KERNEL [=y])
7     -> Drivers
8 (1)     -> I2C Driver Support (CONFIG_I2C [=y])
9 Defined at i2c:18
10 Depends on: BR2_PACKAGE_KERNEL [=y] && CONFIG_I2C [=y]

```

3.2.2 blt1680触摸屏的开启

```

1 There is no help available for this option.
2 Symbol: CONFIG_HC_BLT1680 [=y]
3 Type : bool
4 Prompt: blt1680
5 Location:
6     -> Components
7     -> kernel (BR2_PACKAGE_KERNEL [=y])
8     -> Drivers
9         -> input event (CONFIG_DRV_INPUT [=y])
10            -> tp menu (CONFIG_TP [=y])
11 Defined at tp:13
12 Depends on: BR2_PACKAGE_KERNEL [=y] && CONFIG_DRV_INPUT [=y] && CONFIG_TP
    [=y]

```

3.2.3 测试命令的开启

```

1 There is no help available for this option.
2 Symbol: CONFIG_CMDS_INPUT [=y]
3 Type : bool
4 Prompt: input event operations
5 Location:
6     -> Components
7     -> Cmds (BR2_PACKAGE_CMDS [=y])
8 Defined at source:46
9 Depends on: BR2_PACKAGE_CMDS [=y] && CONFIG_DRV_INPUT [=y]

```

3.2.4 编译

```

1 make kernel-rebuild cmds-rebuild all

```

3.2.5 测试命令的使用

在串口控制终端输入：input -i1，这里的1代表event1；

```
1 hc1512a@dbb200# input -i1
2 ID:0, x:360, y:717, w:1
3 type:3, code:48, value:1
4 type:3, code:50, value:1
5 type:3, code:54, value:717
6 type:1, code:330, value:1
7 key 330 Pressed
```

4. 模块测试用例与Sample Code

介绍本模块相关的测试用例及相关Sample Code

```
1 #include <stdlib.h>
2 #include <poll.h>
3 #include <unistd.h>
4 #include <stddef.h>
5 #include <stdio.h>
6 #include <fcntl.h>
7 #include <sys/ioctl.h>
8 #include <hcuapi/input.h>
9 #include <kernel/lib/console.h>
10
11 #define BUF_SIZE 1024
12
13 static void print_help(void) {
14     printf("*****\n");
15     printf("input test cmds help\n");
16     printf("\tfor example : input_test -i1\n");
17     printf("\t'i' 1 means event1\n");
18     printf("*****\n");
19 }
20
21 static int input_test(int argc, char *argv[])
22 {
23     int fd;
24     struct input_event t;
25     struct pollfd pfd;
26     char input_buf[BUF_SIZE];
27     char *s = "/dev/input/event";
28
29     long tmp;
30     int x = 0, y = 0;
31     int event_num = -1;
32     char ch;
33     opterr = 0;
34     optind = 0;
35
```

```

36     while((ch = getopt(argc, argv, "hi:")) != EOF){
37         switch (ch) {
38             case 'h':
39                 print_help();
40                 return 0;
41             case 'i':
42                 tmp = strtoll(optarg, NULL, 10);
43                 event_num = tmp;
44                 break;
45             default:
46                 printf("Invalid parameter %c\r\n", ch);
47                 print_help();
48                 return -1;
49         }
50     }
51     if(event_num == -1)
52     {
53         print_help();
54         return -1;
55     }
56
57     sprintf(input_buf, "/dev/input/event%d", event_num);
58
59     fd = open(input_buf, O_RDONLY);
60     pfd.fd = fd;
61     pfd.events = POLLIN | POLLRDNORM;
62
63     if(fd < 0){
64         printf("can't open %s\n", input_buf);
65         return -1;
66     }
67
68     while (1) {
69         if (poll(&pfd, 1, -1) <= 0)
70             continue;
71
72         if (read(fd, &t, sizeof(t)) != sizeof(t))
73             continue;
74
75         printf("type:%d, code:%d, value:%ld\n", t.type, t.code,
76 t.value);
77     }
78
79     close(fd);
80
81     return 0;
82 }
83
84     CONSOLE_CMD(input, NULL, input_test, CONSOLE_CMD_MODE_SELF, "input test,
press power to exit test")

```

5. 模块调试方法

调试log宏BTL_DEBUG_SUPPORT的开启：

components/kernel/source/drivers/input/tp/blt1680/bl_chip_custom.h；

开启后会在初始化以及触摸时打印调试信息；

6. 常见问题

暂无；