

# User guide

Laura van Hees  
0769244

Frank van de Haterd  
0770475

Todor Kosev  
0771615

15 april 2012

# Inhoudsopgave

<b>1</b>	<b>Main window</b>	<b>3</b>
<b>2</b>	<b>Tuning the week programm</b>	<b>3</b>
2.1	Adding a time . . . . .	3
2.2	Editing a time . . . . .	3
2.3	Deleting a time . . . . .	3
2.4	Copying a programm to another day . . . . .	3
<b>3</b>	<b>Adjusting the temperatures</b>	<b>4</b>
<b>4</b>	<b>Override the week programm</b>	<b>4</b>
<b>5</b>	<b>Vacation mode</b>	<b>4</b>

# 1 Main window

The main window is the default screen that you will see when you start the application. This place allows you to easily override the current target temperature. (See "Override the week programm") You can see the current temperature, and underneath that you can see the current *target* temperature. This is usually the temperature defined at the "day and night temperature" menu. (See other section) By pressing on the *menu* button of *your device* you can open the main menu. Here you can select other menus where you can configure the thermostat.

You can use the *back* button of *your device* to navigate back in the menus.

# 2 Tuning the week programm

To tune the week programm, go to the main screen menu and choose the option: *week programm*. Here you see a list of days, choose the day you want to calibrate the programm for by clicking on it. Now you get a screen with a list of all the current settings and some buttons above and below it. To go to the next/previous day, press the arrows in the top of the screen.

## 2.1 Adding a time

To add a time so your list of settings press the add button. You get a new screen where you can set the time and day or night mode. To add this setting, press the add button at the bottom of the screen.

## 2.2 Editing a time

To edit a setting that is already in the list press this setting. You will then get the same screen as for adding a setting, but the current values are already filled in. Change the time and or mode and press apply to change the setting.

## 2.3 Deleting a time

To delete a setting that is already in the list press this setting to get to the edit setting screen. Now to delete the setting press the delete button and then the *yes* button in the pop-up warning.

## 2.4 Copying a programm to another day

To copy the programm of a day to another day go to the day-programm you want both days to have. Here click the copy button and select the day you want to copy the programm to. In the pop-up warning click yes to copy the programm, the old settings will be lost!

### 3 Adjusting the temperatures

To adjust the temperatures for the day and/or night mode go to the main menu screen and choose the option: "day and night temperature". In the next screen you can adjust the temperature settings for both the day and the night mode. When you are done adjusting press the save button to save the settings.

### 4 Override the week programm

To override any setting in the week programm, go to the main screen and adjust the temperature. The thermostat will then maintain the temperature you set it to until the next setting in the week programm. When that time is met the thermostat will continue with the week programm again. By pressing the *current programm* button, the thermostat will continue with the settings in its week programm.

### 5 Vacation mode

To apply vacation mode, go to the main screen menu and choose the option: *vacation mode*. In the screen that then opens, choose the temperature the thermostat should maintain during your vacation, set the switch to *on* and click apply. The vacation mode will then be active until you go to this menu again and set the switch to *off* again.