

Quickguide

Electrical Servicing



KUKA Roboter
KR C4

© Copyright 2011

KUKA Roboter GmbH
Zugspitzstraße 140
D-86165 Augsburg

Diese Dokumentation darf – auch auszugsweise – nur mit ausdrücklicher Genehmigung des Herausgebers vervielfältigt oder Dritten zugänglich gemacht werden.

Es können weitere, in dieser Dokumentation nicht beschriebene Funktionen in der Steuerung lauffähig sein. Es besteht jedoch kein Anspruch auf diese Funktionen bei Neulieferung bzw. im Servicefall.

Wir haben den Inhalt der Druckschrift auf Übereinstimmung mit der beschriebenen Hard- und Software geprüft. Dennoch können Abweichungen nicht ausgeschlossen werden, so dass wir für die vollständige Übereinstimmung keine Gewähr übernehmen. Die Angaben in dieser Druckschrift werden jedoch regelmäßig überprüft, und notwendige Korrekturen sind in den nachfolgenden Auflagen enthalten.

Technische Änderungen ohne Beeinflussung der Funktion vorbehalten.

Die KUKA Roboter GmbH übernimmt keinerlei Haftung für etwaige Fehler in technischen Informationen, die in den Schulungen mündlich oder schriftlich übermittelt werden oder in den Unterlagen enthalten sind. Ebenso wird keine Haftung für daraus resultierende Schäden und Folgeschäden übernommen.

Verantwortlich für diese Schulungsunterlage: College Development (WSC-IC)

This documentation or excerpts thereof may not be reproduced or disclosed to third parties without the express permission of the publishers.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in subsequent editions.

Subject to technical alterations without an effect on the function.

KUKA Roboter GmbH accepts no liability whatsoever for any errors in technical information communicated orally or in writing in the training courses or contained in the documentation. Nor will liability be accepted for any resultant damage or consequential damage.

Responsible for this training documentation: College Development (WSC-IC)

Contents – Electrics

Contents – Electrics	1
Safety for work on the control cabinet	3
Overview of the robot controller	4
Front view	4
Rear view	5
Connection panel – standard	6
Connection panel – variants	7
Handling the KUKA network connector	7
Overview of computer components	8
Control PC	8
Control PC interfaces	9
Bus systems	10
CCU – Cabinet Control Unit	11
CCU connections	11
CCU fuses	12
CCU LEDs	14
Power unit	17
KPP KUKA Power Pack connections	17
KPP KUKA Power Pack diagnostic LEDs	18
KSP KUKA Servo Pack connections	20
KSP KUKA Servo Pack diagnostic LEDs	21
RDC – Resolver Digital Converter	22
RDC connections	22
RDC diagnostic LEDs	23
Fastening of RDC and EDS	24
Servomotor	25
Power connector	25
Motor resolver connector	25
Encoder cable on the RDC	25
CSP – Controller System Panel	26
Overview	26
LED diagnosis	27
Battery	28
Polarity	28
Diagnosis	28

System safety	29
ProfiSafe – safe inputs and outputs	29
Safe inputs – robot safety	30
Safe outputs – robot safety	31
SIB – safe inputs and outputs	32
Interface X11, connector pin allocation	33
Standard SIB connections	34
Extended SIB connections	34
SIB LED diagnosis	35
Start-up / diagnosis	37
Start-up mode	37
KRCDiag	37
Diagnostic monitor	38
KLI network configuration	39
Configuring the system safety	40
Loading a WorkVisual project	41
Deploying a WorkVisual project	41
Calling the WorkVisual diagnosis	42
KUKA Recovery Tool (Option)	43

Safety for work on the control cabinet

DANGER

- When the main switch is turned **OFF**, as well as in “**Sleep mode**”, control cabinet components and also motor cables remain **energized**!
- Contact can lead to **death** or **serious physical injuries**!

WARNING

- Before work is started on live components, the **main switch** must be **turned off**!
- Secure the main switch **to prevent it from being turned on again**!
- Ensure that the system is de-energized!

WARNING

- The following components may remain energized (50-780 V) up to 5 minutes after the control cabinet has been switched off: KPP, KSP, intermediate circuit connecting cables

WARNING

- If power unit components are removed directly after shutdown, the heat sinks are likely to be hot!
- Risk of burns to the skin!




Always observe ESD guidelines when carrying out work on the control cabinet or other electronic components. All tools must be ESD-compliant!



Work on the control cabinet may only be performed by a qualified electrician!


Overview of the robot controller

Front view




Item	Description
1	Mains filter
2	Main switch
3	CSP (Controller System Panel)
4	Control PC
5	KPP drive power supply (with optional axis servos 7 to 8)
6	KSP drive controller for axes 4 to 6
7	KSP drive controller for axes 1 to 3
8	Brake filter
9	CCU (Cabinet Control Unit)
10	Contactors (optional)
11	Switch (optional)
12	Fuse element
13	Batteries
14	Connection panel
15	Housing
16	smartPAD

Rear view




Item	Description
1	Ballast resistors
2	Heat exchanger
3	External fan
4	Low-voltage power supply

Connection panel – standard



Item	Description
1	XS1 Power supply connection
2	Option
3	XS20 Motor connection, axes 1-6
4	Optional motor connection for external axes 7-8
5	Option
6	Option
7	Optional X11 interface
8	Option
9	Option
10	X19 smartPAD connection
11	X21 RDC connection
12	Option
13	PE1 Ground conductor to the robot
14	PE2 Ground conductor to main infeed

Connection panel – variants



Handling the KUKA network connector




Unplugging the network connector

1. Pull back the plastic lock
2. Press the spring clips together between thumb and forefinger
3. Unplug the connector to the rear


Overview of computer components

Control PC



Item	Description
1	Hard drive
2	Motherboard
3	PC interfaces
4	Processor heat sink
5	PC fan
6	PC power supply unit


Control PC interfaces



Item	Description
1	Connector X961, power supply 24 V DC
2	Connector X962, PC fan
3	LAN Dual NIC* – KUKA Controller Bus
4	LAN Dual NIC* – KUKA Line Interface
5	Field bus cards, slots 1 to 7
6	LAN Onboard – KUKA System Bus
7	8 USB 2.0 ports

* NIC = Network Interface Card


Bus systems



Bus	Description
KCB KUKA C ontroller B us	Connection of the drive circuit devices (RDC, KPP, KSP)
KSB KUKA S ystem B us	Connection of the smartPAD, RoboTeam, SIB
KEB KUKA E xtension B us	Connection of EtherCAT I/Os
KLI KUKA L ine I nterface	Connection of PLC, periphery, data archiving, diagnosis, RDP


Legend:

- RDC = Resolver-Digital Converter
- KPP = KUKA Power Pack
- KSP = KUKA Servo Pack
- PLC = Programmable Logic Controller
- NIC = Network Interface Card
- SIB = Safety Interface Board



CCU – Cabinet Control Unit

CCU connections




Item	Plug	Description
1	X14	External fan connection
2	X308	External power supply, safety circuit
3	X1700	Board connection
4	X306	smartPAD power supply
5	X302	SIB power supply
6	X3	KPP1 power supply
7	X29	EDS connection, memory card
8	X30	Ballast resistor temperature monitoring
9	X309	Main contactor 1 (HSn, HSRn)
10	X312	Main contactor 2 (HSn, HSRn)
11	X310	Spare (safe input 2/3, safe output 2/3)
12	X48	Safety Interface Board SIB
13	X31	Controller bus, KPC
14	X32	Controller bus, KPP
15	X311	Safe inputs, ZSE1, ZSE2, NHS
16	X28	Mastering test
17	X43	KUKA Service Interface (KSI)
18	X42	KUKA Operator Panel Interface smartPAD
19	X41	KUKA System Bus, KPC
20	X44	EtherCAT Interface (KUKA Extension Bus)
21	X47	Spare

Item	Plug	Description
22	X46	KUKA System Bus, RoboTeam
23	X45	KUKA System Bus, RoboTeam
24	X34	Controller bus, RDC
25	X33	Controller bus, spare
26	X25	Fast Measurement inputs 7-8
27	X23	Fast Measurement inputs 1-6
28	X11	Alarm contact for main switch
29	X26	Thermostatic switch for transformer
30	X27	Alarm contact for cooling unit
31	X5	KPP2 power supply
32	X22	Cabinet lighting
33	X4	KPC power supply
34	X307	CSP power supply
35	X12	USB
36	X15	Internal cabinet fan (optional)
37	X1	Infeed from low-voltage power supply
38	X301	24V without battery backup, spare
39	X6	24V without battery backup, optional
40	X305	Battery
41	X21	RDC power supply

CCU fuses


Item	Designation	Description	Fuse rating
1	F17.1	Contactor outputs 1-4 CCU	5 A
2	F17.2	CCU inputs	2 A
3	F17.3	CCU safe inputs	2 A
4	F17.4	CCU logic	2A
5	F306	smartPAD supply	2 A
6	F302	SIB power supply	5 A
7	F3.2	KPP1 logic without battery backup	7.5 A
8	F3.1	KPP1 brakes without battery backup	15 A
9	F5.2	KPP2 logic without battery backup	7.5 A
10	F5.1	KPP2 brakes without battery backup	15 A
11	F22	Cabinet lighting (optional)	2 A
12	F4.1	KPC with battery backup	10 A
13	F4.2	KPC fan with battery backup	2 A
14	F307	CSP power supply	2 A
15	F21	RDC power supply	2 A
16	F305	Battery infeed	15 A
17	F6	24 V without battery backup (optional)	2 A
18	F301	Without battery backup, spare	10 A 7A cont. load!
19	F15	Internal fan (optional)	2 A
20	F14	External fan	7.5 A
21	F308	Internal power supply External power supply, with battery backup	7.5 A



Do not exchange fuses when energized!

A defective fuse is indicated by a red LED next to the fuse. Once the cause of the fault has been eliminated, defective fuses must be replaced with fuses with the value specified in the operating instructions or printed on the module.

CCU LEDs



Item	Designation	Description	Remedy
1	Fuse LEDs	On = fuse defective Off = fuse OK	■ Exchange defective fuse
2	PWRS/3.3V	On = supply OK Off = no power supplied	■ Check fuse F17.3 ■ If the LED PWR/3.3V lights up, exchange the CCU module
3	STA2 Safety node B	Off = no supply Flashing at 1 Hz = normal state Flashing at 20 Hz = boot phase Flashing = fault code (internal)	■ Check fuse F17.3 ■ If the LED PWR/3.3 lights up, exchange the CCU module ----- ----- ■ Check cabling at X309, X310, X312; test by unplugging the cables at X309, X310, X312 and switching the controller off/on. ■ If the fault still occurs, exchange the module.

Item	Designation	Description	Remedy
4	STAS1 Safety node A	See item 3	See item 3
5	FSOE Safety protocol of the EtherCat connection	Off = not active On = operational Flashing = fault code (internal)	-----
6	27 V Voltage, main power supply unit, without battery backup	Off = no supply On = supply OK	▶ Check infeed at X1 (rated voltage 27.1 V) -----
7	PS1 Voltage, Power Supply 1 (short battery backup)	Off = no supply On = supply OK	▶ Check infeed at X1 (rated voltage 27.1 V) ■ Drive bus switched off (BusPowerOff state)
8	PS2 Voltage, Power Supply 2 (medium battery backup)	Off = no supply On = supply OK	■ Check infeed at X1 ■ Controller in Sleep mode -----
9	PS3 Voltage, Power Supply 3 (long battery backup)	Off = no supply On = supply OK	■ Check infeed at X1 -----
10	L/A KSB (SIB) L/A KCB (KPC) L/A KCB (KPP)	On = physical connection	-----
11	L/A L/A L/A	Off = no physical connection	-----
12	L/A L/A L/A	Flashing = data exchange	-----
13	PWR/3.3V Power for CIB	Off = no supply On = supply OK	■ Check fuse F17.3 ■ Jumper plug X308 present ■ Check fuse F308 ■ With external supply via X308: ▶ Check ext. supply voltage (rated voltage 24 V) -----
14	L/A L/A L/A	On = physical connection OK Off = no physical connection Flashing = data exchange	-----


Item	Designation	Description	Remedy
15	STA1 (CIB) µC I/O node	Off = no supply	<ul style="list-style-type: none"> Check fuse F17.3 If the LED PWR/3.3V lights up ► Exchange CCU
		Flashing at 1 Hz = normal state	-----
		Flashing at 10 Hz = boot phase	-----
		Flashing = fault code (internal)	<ul style="list-style-type: none"> Exchange CCU
16	STA1 (PMB) µC USB node	Off = no supply	<ul style="list-style-type: none"> Check infeed at X1 If the LED PWR/5V lights up ► Exchange CCU
		Flashing at 1 Hz = normal state	-----
		Flashing at 10 Hz = boot phase	-----
		Flashing = fault code (internal)	<ul style="list-style-type: none"> Exchange CCU
17	PWR/5V Supply for PMB	Off = no supply	<ul style="list-style-type: none"> Check infeed X1 (rated voltage 27.1 V)
		Flashing at 1 Hz = normal state	-----
		Flashing at 10 Hz = boot phase	-----
		Flashing = fault code (internal)	-----
18	STA2 FPGA node	Off = no supply	<ul style="list-style-type: none"> Check infeed at X1 If the LED PWR/3.3V lights up ► Exchange CCU
		Flashing at 1 Hz = normal state	-----
		Flashing at 10 Hz = boot phase	-----
		Flashing = fault code (internal)	► Exchange CCU
19	RUN SION EtherCat Safety nodes	On = operational	-----
		Off = Init (after switching on)	-----
		Flashing at 2.5 Hz = Pre-Op (intermediate state on start-up)	-----
		Single signal = Safe Op	-----
		Flashing at 10 Hz = boot (for firmware update)	-----
20	RUN CIB EtherCat ATµC I/O node	See item 19	See item 19

Power unit

NOTICE


- KPP and KSP modules have a SafetyID!
- Only one module may be exchanged at a time!

KPP KUKA Power Pack connections



Item	Plug	Description
1	X30	Brakes power supply OUT
2	X20	Drive bus OUT
3	X10	Control electronics power supply OUT
4	X7	Ballast resistor
5	X6	DC link OUT
6	X11	Control electronics power supply IN
7	X21	Drive bus IN
8	X34	Brakes power supply IN
9	X3	Motor connection 3, axis 8
10	X33	Brake connection 3, axis 8
11	X32	Brake connection 2, axis 7
12	X2	Motor connection 2, axis 7
13	-	Not used
14	X4	AC power supply connection and PE

KPP KUKA Power Pack diagnostic LEDs



Item	Description		
1	LED group: power supply		
	LED	LED	Meaning
	Off	Off	■ No power supply to the control electronics
	On	Off	■ Fault in the power supply
	Off	Flash-ing	■ Intermediate circuit voltage out of the permitted range
	Off	On	■ Intermediate circuit voltage within the permitted range

2	LED group: KPP device status		
	LED	LED	Meaning
	Off	Off	■ No power supply to the control electronics
	On	Off	■ Fault in the KPP
	Off	Flash-ing	■ No communication with the controller
	Off	On	■ Communication with the controller


3	LED group: drive bus status		
	LED	LED	Meaning
	Off	Off	■ No power supply to the control electronics
	On	Off	■ Fault in power supply
	Off	Flash- ing	■ Power supply not enabled
	Off	On	■ Power supply enabled

4,5	LED group: axis control		
	LED	LED	Meaning
	Off	Off	■ No power supply to the control electronics ■ Axis not present
	On	Off	■ Fault in the axis
	Off	Flash- ing	■ No servo enable
	Off	On	■ Servo enable

Other faults


No.	Meaning
1	Fault during the initialization phase
	<ul style="list-style-type: none"> ■ Middle axis control LEDs flashing ■ All other LEDs are off ■ Red axis control LED lit continuously ■ Green axis control LED flashes at 2 to 16 Hz, followed by a pause
2	Firmware fault during the initialization phase
	<ul style="list-style-type: none"> ■ Red device status LED on ■ Green device status LED dimmed

KSP KUKA Servo Pack connections



Item	Plug	Description
1	X30	Brakes power supply OUT
2	X20	Drive bus OUT
3	X10	Control electronics power supply OUT
4	X5	DC link OUT
5	X6	DC link IN
6	X11	Control electronics power supply IN
7	X21	Drive bus IN
8	X34	Brakes power supply IN
9	X3	Motor connection 3
10	X33	Connection, brake 3
11	X32	Connection, brake 2
12	X2	Motor connection 2
13	X31	Connection, brake 1
14	X1	Motor connection 1

KSP KUKA Servo Pack diagnostic LEDs




Item	Description		
1,4,5	LED group: axis control		
	LED	LED	Meaning
	Off	Off	<ul style="list-style-type: none"> No power supply to the control electronics Axis not present
	On	Off	<ul style="list-style-type: none"> Fault in the axis
	Off	Flashing	<ul style="list-style-type: none"> No servo enable
	Off	On	<ul style="list-style-type: none"> Servo enable

2	LED group: KSP device status		
	LED	LED	Meaning
	Off	Off	<ul style="list-style-type: none"> No power supply to the control electronics
	On	Off	<ul style="list-style-type: none"> Fault in the KSP
	Off	Flashing	<ul style="list-style-type: none"> No communication with the controller
	Off	On	<ul style="list-style-type: none"> Communication with the controller

3	LED group: drive bus status		
	LED	LED	Meaning
	Off	Off	<ul style="list-style-type: none"> No power supply to the control electronics
	On	Off	<ul style="list-style-type: none"> Fault in power supply
	Off	Flashing	<ul style="list-style-type: none"> Power supply not enabled
	Off	On	<ul style="list-style-type: none"> Power supply enabled

RDC – Resolver Digital Converter


RDC connections



Item	Plug	Description
1 → 8	X1 → X8	Resolver connection, axes 1 → 8
9	X13	EDS connection, memory card, RDC
10	X20	EMD connection
11	X19	KCB OUT
12	X18	KCB IN
13	X17	EMD power supply
14	X15	Power supply infeed
15	X16	Power supply OUT (next KCB device)

* **KCB** = KUKA Controller Bus, **EMD** = Electronic Mastering Device


RDC diagnostic LEDs



Item	Plug	Description
1	STA3	Motor temperature microcontroller
	<ul style="list-style-type: none"> Off = fault Flashing = fault code (internal) 	<ul style="list-style-type: none"> Flashing at 1 Hz = normal state
2	RUN	EtherCAT AT bus
	<ul style="list-style-type: none"> Off = Init Flashing at 2.5 Hz = Pre-Op Flashing = fault code (internal) 	<ul style="list-style-type: none"> On = normal state Single signal = Safe Op Flashing at 10 Hz = boot
3	L/A 1	Input of the KCB (X18)
	<ul style="list-style-type: none"> Off = no physical connection Flashing = data exchange active 	<ul style="list-style-type: none"> On = physical connection
4	L/A 2	Output of the KCB (X19)
	<ul style="list-style-type: none"> See item 3 	
5	L/A 3	Output of the KCB to the EMD (X20)
	<ul style="list-style-type: none"> See item 3 	
6	STA4	VMT μ C (voltage monitoring)
	<ul style="list-style-type: none"> Off = fault Flashing = fault code (internal) 	<ul style="list-style-type: none"> Flashing at 1 Hz = normal state

Item	Plug	Description
7	PWR/3.3V	RDC power supply
	<ul style="list-style-type: none"> Off = no voltage Power supply connected 	
8	FSOE	Safety protocol of EtherCat connection
	<ul style="list-style-type: none"> Off = not active On = operational Flashing = fault code (internal) 	
9	STA2	FPGA B integrated circuit
	<ul style="list-style-type: none"> Off = fault Flashing = fault code (internal) Flashing at 1 Hz = normal state 	
10	STA1	FPGA A integrated circuit
	<ul style="list-style-type: none"> See item 9 	
11	STA0	Configuration microcontroller
	<ul style="list-style-type: none"> See item 9 	


Fastening of RDC and EDS




Item	Fastening	Tightening torque
1 RDC	M6x10	2.0 Nm
2 EDS	M2.5 plastic nuts	0.1 Ncm

Servomotor


Power connector

	Pin-Pin	Resistance value	Designation
	1 → 2	0.17 Ω – 14 Ω	Winding U→V
	1 → 6	0.17 Ω – 14 Ω	Winding U→W
	2 → 6	0.17 Ω – 14 Ω	Winding V→W
	4 → 5	24 Ω - 80 Ω	Brake+/Brake-
	3		Ground

Motor resolver connector


	Pin-Pin	Resistance value	Designation
	1→2	30 Ω – 200 Ω	Stator winding 1
	11→12	30 Ω – 200 Ω	Stator winding 2
	10→7	20 Ω – 100 Ω	Rotor coil
	8→9	588 Ω at 25 °C 1000 Ω at 100 °C	Temperature sensor

Encoder cable on the RDC

	Pin - RDC	Designation
	1	Temp. sensor (connection A)
	2	Temp. sensor (connection B)
	3	Rotor coil
	4	Rotor coil
	5	Stator winding 1
	6	Stator winding 1
	7	Stator winding 2
	8	Stator winding 2







CSP – Controller System Panel





Overview



Item	Part	Color	Meaning
1	LED 1	Green	Operating LED
2	LED 2	White	Sleep LED
3	LED 3	White	Automatic LED
4	LED 6	Red	Error LED
5	LED 5	Red	Error LED
6	LED 4	Red	Error LED
7	USB 1	---	---
8	USB2	---	---
9	RJ45	---	KLI (KUKA Line Interface)


LED diagnosis

Function	Display	Description
CSP test		<ul style="list-style-type: none"> ■ CSP OK = after switching on, all the LEDs light up for 3 seconds.
Automatic mode		<ul style="list-style-type: none"> ■ LED 1 = On ■ LED 3 = On ▶ Controller is in Automatic mode
		<ul style="list-style-type: none"> ■ LED 1 = On ▶ Controller is not in Automatic mode
Sleep mode		<ul style="list-style-type: none"> ■ LED 2 flashes slowly ▶ Controller is in Sleep mode
		<ul style="list-style-type: none"> ■ LED 1 flashes slowly ▶ Controller is coming out of Sleep mode
ProfiNet Ping		<ul style="list-style-type: none"> ■ LED 1 = On ■ LED 5 flashes slowly ■ LED 4 flashes slowly ■ LED 6 flashes slowly ▶ ProfiNet ping is being executed

Display	Description	Remedy
	<ul style="list-style-type: none"> ■ LED 1 flashes slowly ■ LED 4 = On ▶ BIOS error 	<ul style="list-style-type: none"> ▶ Exchange the PC
	<ul style="list-style-type: none"> ■ LED 1 flashes slowly ■ LED 5 = On ▶ Timeout booting Windows or starting the PMS 	<ul style="list-style-type: none"> ▶ Exchange the HDD ▶ Reload the image
	<ul style="list-style-type: none"> ■ LED 1 flashes slowly ■ LED 6 = On ▶ Timeout waiting for RTS "RUNNING" 	<ul style="list-style-type: none"> ▶ Reload the image ▶ Run setup
	<ul style="list-style-type: none"> ■ LED 1 flashes slowly ▶ Timeout waiting for HMI Ready 	-----

Battery

Polarity



WARNING

A short-circuit or short to ground at the battery poles causes a very high short-circuit current. This short-circuit current can cause severe injury and substantial damage to property. It must be ensured that no short-circuit or short to ground is caused at the battery poles.

Diagnosis


Menu sequence:
System variable (ENUM):

Display → Variable → Single
\$ACCU_STATE

Status	Description
■ #CHARGE_OK	▶ Battery test was positive
■ #CHARGE_OK_LOW	▶ Battery test was positive ▶ The battery was still not fully charged after the maximum charging time
■ #CHARGE_UNKNOWN	▶ The battery is being charged ▶ Charging current has not yet dropped sufficiently ▶ Battery test not yet carried out
■ #CHARGE_TEST_NOK	▶ Battery test was negative
■ #CHARGE_NOK	▶ Battery test is not possible ▶ Battery was still not fully charged after the maximum charging time
■ #CHARGE_OFF	▶ No charging current available ▶ Either no battery present or battery defective

System safety

ProfiSafe – safe inputs and outputs



Designation	Meaning
NHB	▶ Emergency Stop
ZS	▶ Enabling
BAV	▶ Mode selection lock
AKB	▶ Disconnect operator panel
NHS	▶ E-Stop on cabinet (optional)
JR	▶ Mastering test (SafeOperation)
ZSE	▶ External enabling (optional)
HSR1	▶ Checkback, main contactor 1 (optional)
HSR2	▶ Checkback, main contactor 2 (optional)
HS1	▶ Main contactor 1
HS2	▶ Main contactor 2
POS[n]	▶ Position value, channel [n]
STO[n]	▶ Safe Torque off n
SBC[n]	▶ Safe Brake Control n


Safe inputs – robot safety

Input byte 0		
Bit	Signal	Description
0	RES	<ul style="list-style-type: none"> Reserved 1 ▶ The value 1 must be assigned to the input
1	NHE	<ul style="list-style-type: none"> Input for external E-Stop ▶ 0 = external E-Stop is active ▶ 1 = external E-Stop is not active
2	BS	<ul style="list-style-type: none"> Operator safety ▶ 0 = operator safety is not active, e.g. safety gate open ▶ 1 = operator safety is active
3	QBS	<ul style="list-style-type: none"> Acknowledgement of operator safety ▶ 0 = operator safety has not been acknowledged ▶ Edge 0 ▶ 1 = operator safety has been acknowledged
4	SHS1	<ul style="list-style-type: none"> Safety stop 1 (all axes) ▶ 0 = safety stop is active ▶ 1 = safety stop is not active
5	SHS2	<ul style="list-style-type: none"> Safety stop 2 (all axes) ▶ 0 = safety stop is active ▶ 1 = safety stop is not active
6	E2	<ul style="list-style-type: none"> E2 keyswitch (customer-specific signal for mode selection) ▶ 0 = E2 keyswitch is not active ▶ 1 = E2 keyswitch is active
7	E7	<ul style="list-style-type: none"> E7 keyswitch (customer-specific signal for mode selection) ▶ 0 = E2 keyswitch is not active ▶ 1 = E2 keyswitch is active
Input byte 1		
0	US2	<ul style="list-style-type: none"> US2 supply voltage Precondition: "by ProfiSafe" must be set under "Hardware options" – "Peripheral contactor" in the safety configuration ▶ 0 = switch off US2 ▶ 1 = switch off US2
1	SBH	<ul style="list-style-type: none"> Safe operational stop (all axes) ▶ 0 = safe operational stop is active ▶ 1 = safe operational stop is not active
2	RES	<ul style="list-style-type: none"> Reserved 11 ▶ The value 1 must be assigned to the input
3	RES	<ul style="list-style-type: none"> Reserved 12 ▶ The value 1 must be assigned to the input
4	RES	<ul style="list-style-type: none"> Reserved 13 ▶ The value 1 must be assigned to the input
5	RES	<ul style="list-style-type: none"> Reserved 14 ▶ The value 1 must be assigned to the input
6	RES	<ul style="list-style-type: none"> Reserved 15 ▶ The value 1 must be assigned to the input
7	SPA	<ul style="list-style-type: none"> Shutdown PROFIsafe Acknowledge ▶ 0 = confirmation is not active ▶ 1 = confirmation is active

Safe outputs – robot safety


Output byte 0		
Bit	Signal	Description
0	NHL	<ul style="list-style-type: none"> Local E-Stop (local E-Stop triggered) <ul style="list-style-type: none"> 0 = local E-Stop is active 1 = local E-Stop is not active
1	AF	<ul style="list-style-type: none"> Drives enable <ul style="list-style-type: none"> 0 = drives enable is not active 1 = drives enable is active
2	FF	<ul style="list-style-type: none"> Motion enable <ul style="list-style-type: none"> 0 = motion enable is not active 1 = motion enable is active
3	ZS	<ul style="list-style-type: none"> One of the enabling switches is in the center position <ul style="list-style-type: none"> 0 = enabling is not active 1 = enabling is active
4	RES	Reserved 5
5	EXT	<ul style="list-style-type: none"> The robot is in External mode <ul style="list-style-type: none"> 0 = External mode is not active 1 = External mode is active
6	T1	<ul style="list-style-type: none"> The robot is in Manual Reduced Velocity mode <ul style="list-style-type: none"> 0 = T1 mode is not active 1 = T1 mode is active
7	T2	<ul style="list-style-type: none"> The robot is in Manual High Velocity mode <ul style="list-style-type: none"> 0 = T2 mode is not active 1 = T2 mode is active
Output byte 1		
0	NHE	<ul style="list-style-type: none"> External E-Stop has been triggered <ul style="list-style-type: none"> 0 = external E-Stop is active 1 = external E-Stop is not active
1	BS	<ul style="list-style-type: none"> Operator safety <ul style="list-style-type: none"> 0 = operator safety is not assured 1 = operator safety is assured (input BS = 1 and, if configured, input QBS acknowledged)
2	SHS1	<ul style="list-style-type: none"> Safety stop 1 (all axes) <ul style="list-style-type: none"> 0 = safety stop 2 is not active 1 = safety stop 1 is active (safe state reached)
3	SHS2	<ul style="list-style-type: none"> Safety stop 2 (all axes) <ul style="list-style-type: none"> 0 = safety stop 2 is not active 1 = safety stop 1 is active (safe state reached)
4	RES	Reserved 13
5	RES	Reserved 14
6	PSA	<ul style="list-style-type: none"> PROFIsafe active <ul style="list-style-type: none"> 0 = robot controller on PROFIsafe bus is not active 1 = robot controller on PROFIsafe bus is active
7	SP	<ul style="list-style-type: none"> Shutdown PROFIsafe <ul style="list-style-type: none"> 0 = announcement of termination of connection is not active 1 = announcement of termination of connection is active

SIB – safe inputs and outputs




Desig.	Meaning
NHB	▶ E-Stop on operator panel
ZS	▶ Enabling
BAV	▶ Mode selection lock
AKB	▶ Disconnect operator panel
NHS	▶ E-Stop on cabinet (optional)
JR	▶ Mastering test (SafeOperation)
ZSE	▶ External enabling (optional)
HSR1	▶ Checkback, main contactor 1 (optional)
HSR2	▶ Checkback, main contactor 2 (optional)
HS1	▶ Main contactor 1
HS2	▶ Main contactor 2
NHE	▶ External E-Stop
BS	▶ Operator safety
QBS	▶ Ackn. operator safety
SH	▶ Safety stop SH, robot axes
SBH	▶ Safe operational stop
NHL	▶ Internal E-STOP
ZSG	▶ Enabling switch pressed
POS[n]	▶ Position value, channel [n]
STO[n]	▶ Safe Torque off [n]
SBC[n]	▶ Safe Brake Control [n]

Interface X11, connector pin allocation




Standard SIB connections



P	Plug	Description
1	X250	SIB power supply
2	X251	Power supply for other components
3	X252	Safe outputs
4	X253	Safe inputs
5	X254	Safe inputs
6	X259	KUKA System Bus
7	X258	KUKA System Bus


Extended SIB connections




P	Plug	Description
1	X260	Extended SIB power supply
2	X261	Power supply for other components
3	X265	Safe outputs 1 and 2
4	X264	Safe outputs 3 and 4
5	X266	Safe outputs 5 to 8
6	X262	Safe inputs
7	X263	Safe inputs
8	X268	KSB – KUKA System Bus
9	X269	KSB – KUKA System Bus

SIB LED diagnosis

Standard SIB LED overview



Extended SIB LED overview



S	E	Designation	Description	Remedy
1	5	L/A	<div>■ On = physical connection</div> <div>■ Off = no physical connection</div> <div>■ Flashing = data exchange</div>	-----
2	7	L/A	■ See item 1	-----
3	9	PWR_3V3 Power for the SIB	<div>■ Off = no power supply available</div> <div>■ On = supply present</div>	<div>▶ Check fuse F301</div> <div>▶ Jumper plug X308 present</div>
4	8	RUN EtherCat Safety node	<div>■ On = operational (normal state)</div> <div>■ Off = Init (after switching on)</div> <div>■ Flashing at 2.5 Hz = Pre-Op (intermediate state on start-up)</div> <div>■ Single signal = Safe Op</div> <div>■ Flashing at 10 Hz = boot for firmware update</div>	-----
5	6	STAS2 Safety node B	<div>■ Off = no power supply available</div> <div>■ Flashing at 1 Hz = normal state</div> <div>■ Flashing at 10 Hz = boot phase</div> <div>■ Flashing = fault code (internal)</div>	<div>▶ Check fuse F302</div> <div>▶ If the LED PWR_3V3 lights up, then exchange the SBI module</div>
6	3	FSOE EtherCat Safety	<div>■ Off = not active</div> <div>■ On = operational</div> <div>■ Flashing = fault code (internal)</div>	-----
7	2	STAS1 Safety node A	■ see STAS2	▶ see STAS2
8	4	PWR 3.3V	<div>■ On = power supply present</div> <div>■ Off = no power supply available</div>	<div>▶ Check fuse F302</div> <div>▶ If the LED PWR_3V3 lights up, then exchange the SBI module</div>
9	1	Fuse LED	<div>■ On = fuse defective</div> <div>■ Off = fuse OK</div>	▶ Exchange defective fuse

S= SIB Standard

E= SIB Extended

Start-up / diagnosis

Start-up mode



WARNING

- In start-up mode, the safety equipment is deactivated!
- Start-up mode must only be used for troubleshooting or for testing!

Procedure


- Log on as Expert: Menu sequence: **Configuration > User group > Log on > Expert**
- Start-up mode: Menu sequence: **Start-up > Service > Start-up mode**

KRCDiag

- is a diagnostic tool for bundling and saving fault profiles in a file
- Evaluation by the KUKA Hotline
- Additional generation of a screenshot of the current display on the HMI

Procedure

- Select the menu sequence: **File > Archive > USB or Network > KrcDiag.**
- Alternative menu sequence: **Diagnosis > KrcDiag**
- Gathering the information incl. file generation takes 5 minutes
Message: *Do you really want to archive the selected file(s)* > confirm with **Yes**
- File path: **C:\KUKA\KRCDiag\KRCDIAG_[date]T[time].zip**




Diagnostic monitor

- is used to analyze bus devices, bus components and networks.

Procedure

- Log on as Expert. Menu sequence:
Robot key > Configuration > User group > Log on > Expert
- Call the diagnostic monitor: Menu sequence:
Robot key > Diagnosis > Diagnostic monitor
- Select the device / bus device / network configuration to be analyzed
Pulldown menu (module) > select corresponding diagnosis
- Example: KSP module



The screenshot shows the 'Diagnostic monitor' window with the module 'ECat-Antriebsbus-KSP-Slave[1] (ECat.CTRLBUS.Slave[3])' selected in the dropdown. Below the dropdown is a table with three columns: Name, Value, and Unit. The table contains various diagnostic data points, with the last two rows highlighted by a dashed orange border.

Name	Value	Unit
Slave Vendor ID (Bus)	24776	--
Slave Produkt Code (Bus)	83	--
Slave Revision Nr. (Bus)	0	--
Slave Serien-Nummer (Bus)	0	--
Slave Name (Konfiguration)	KUKA Servo Pack A1-3 (KSP)	--
Slave: Physikalische Adresse (Bus)	1003	--
Slave: Physikalische Adresse (Konfig.)	1003	--
Alias Adresse (Bus)	0	--
Port-Status (Bus)	12339	--
Angeforderter Slave Status	OPERATIONAL	--
Aktueller Slave Status	OPERATIONAL	--
Slave Fehler-Bit gesetzt	OK	--
Linkmessages aktiviert	No	--
Fehler-Code	0	--

KLI network configuration

- In the standard version, the **KLI** is prepared for the **static** IP address **172.31.1.147** in **virtual 5** (virtual VLAN network 5)
- If **ProfiNet** is used in addition, **virtual 5** can be reserved for this
- WV, Windows, RDP, etc., are allocated to a separate, newly created **virtual 6** (DHCP)

Procedure (HMI):

- Log on as Expert. Menu sequence:
Robot key > Configuration > User group > Log on > Expert
- Menu sequence:
Start-up > Network configuration

virtual 5 – ProfiNet configuration	virtual 6 – Company network configuration																																																																		
<p>Network configuration</p> <p>Configured interfaces:</p> <ul style="list-style-type: none"> virtual5 (PROFINET) <ul style="list-style-type: none"> Queue virtual6 (Firmennetz) <ul style="list-style-type: none"> Queue <p>Interface properties:</p> <p>Interface designation: PROFINET</p> <p>Address type: Fixed IP address</p> <p>IP address: 172 . 31 . 1 . 147</p> <p>Subnet mask: 255 . 255 . 0 . 0</p> <p><input type="checkbox"/> Windows interface</p>	<p>Network configuration</p> <p>Configured interfaces:</p> <ul style="list-style-type: none"> virtual5 (PROFINET) <ul style="list-style-type: none"> Queue virtual6 (Firmennetz) <ul style="list-style-type: none"> Queue <p>Interface properties:</p> <p>Interface designation: Firmennetz</p> <p>Address type: Dynamic IP address</p> <p><input checked="" type="checkbox"/> Windows interface</p>																																																																		
<p>■ Fixed IP</p> <p>► Unique, fixed ProfiNet address</p>	<p>■ DHCP</p> <p>► Assignment of IP address via DHCP</p>																																																																		
<p>virtual 5 – Diagnostic monitor view</p> <p>Diagnostic monitor</p> <p>Module: Networkinterface (virtual5)</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> </tr> </thead> <tbody> <tr><td>Interface-ID</td><td>virtual5</td><td>--</td></tr> <tr><td>TX-Counter</td><td>2</td><td>--</td></tr> <tr><td>TX-Packeterrors</td><td>0</td><td>--</td></tr> <tr><td>RX-Counter</td><td>0</td><td>--</td></tr> <tr><td>RX-Packeterrors</td><td>0</td><td>--</td></tr> <tr><td>Link-status</td><td>--</td><td>--</td></tr> <tr><td>IP-Address</td><td>172.31.1.147</td><td>--</td></tr> <tr><td>MAC-address</td><td>00:19:99:74:14:51</td><td>--</td></tr> <tr><td>Subnetmask</td><td>255.255.0.0</td><td>--</td></tr> <tr><td>Protocols</td><td>IPV4,IPSTACK ARP,IPSTACK RARP,IPSTACK 802.1Q VLAN</td><td>--</td></tr> </tbody> </table>	Name	Value	Unit	Interface-ID	virtual5	--	TX-Counter	2	--	TX-Packeterrors	0	--	RX-Counter	0	--	RX-Packeterrors	0	--	Link-status	--	--	IP-Address	172.31.1.147	--	MAC-address	00:19:99:74:14:51	--	Subnetmask	255.255.0.0	--	Protocols	IPV4,IPSTACK ARP,IPSTACK RARP,IPSTACK 802.1Q VLAN	--	<p>virtual 6 – Diagnostic monitor view</p> <p>Diagnostic monitor</p> <p>Module: Networkinterface (virtual6)</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> </tr> </thead> <tbody> <tr><td>Interface-ID</td><td>virtual6</td><td>--</td></tr> <tr><td>TX-Counter</td><td>291</td><td>--</td></tr> <tr><td>TX-Packeterrors</td><td>0</td><td>--</td></tr> <tr><td>RX-Counter</td><td>1396</td><td>--</td></tr> <tr><td>RX-Packeterrors</td><td>0</td><td>--</td></tr> <tr><td>Link-status</td><td>--</td><td>--</td></tr> <tr><td>IP-Address</td><td>10.129.190.24</td><td>--</td></tr> <tr><td>MAC-address</td><td>00:19:99:74:14:51</td><td>--</td></tr> <tr><td>Subnetmask</td><td>255.255.255.0</td><td>--</td></tr> <tr><td>Protocols</td><td>IPSTACK IPV4,IPSTACK ARP,IPSTACK RARP,IPSTACK 802.1Q VLAN</td><td>--</td></tr> </tbody> </table>	Name	Value	Unit	Interface-ID	virtual6	--	TX-Counter	291	--	TX-Packeterrors	0	--	RX-Counter	1396	--	RX-Packeterrors	0	--	Link-status	--	--	IP-Address	10.129.190.24	--	MAC-address	00:19:99:74:14:51	--	Subnetmask	255.255.255.0	--	Protocols	IPSTACK IPV4,IPSTACK ARP,IPSTACK RARP,IPSTACK 802.1Q VLAN	--
Name	Value	Unit																																																																	
Interface-ID	virtual5	--																																																																	
TX-Counter	2	--																																																																	
TX-Packeterrors	0	--																																																																	
RX-Counter	0	--																																																																	
RX-Packeterrors	0	--																																																																	
Link-status	--	--																																																																	
IP-Address	172.31.1.147	--																																																																	
MAC-address	00:19:99:74:14:51	--																																																																	
Subnetmask	255.255.0.0	--																																																																	
Protocols	IPV4,IPSTACK ARP,IPSTACK RARP,IPSTACK 802.1Q VLAN	--																																																																	
Name	Value	Unit																																																																	
Interface-ID	virtual6	--																																																																	
TX-Counter	291	--																																																																	
TX-Packeterrors	0	--																																																																	
RX-Counter	1396	--																																																																	
RX-Packeterrors	0	--																																																																	
Link-status	--	--																																																																	
IP-Address	10.129.190.24	--																																																																	
MAC-address	00:19:99:74:14:51	--																																																																	
Subnetmask	255.255.255.0	--																																																																	
Protocols	IPSTACK IPV4,IPSTACK ARP,IPSTACK RARP,IPSTACK 802.1Q VLAN	--																																																																	

Configuring the system safety

- Selection of the robot safety during start-up.
 - Shown here on the HMI
-
- **Precondition:**
 - ▶ User group **Safety maintenance**
 - **Procedure:**
 - ▶ Menu sequence: **Configuration > Safety configuration**
 - ▶ Menu sequence: **Hardware options**
 - ▶ Selection of the customer interface **SIB** or **ProfiSafe**

Safety configuration

Robot	Serial number:	0
--------------	----------------	---

Safety controller	Default
	Version: 6C98F05D

Parameter data - set	Checksum:	EE3497C8	
	Last changed:	9/7/2011 11:59 AM	Change log
	Version:	1	

Machine data	Last changed:	9/7/2011 11:59 AM	View
---------------------	---------------	-------------------	------

Current configuration	Monitoring:	-	Hardware options
	Interface:	PROFINET	


Safety configuration

Hardware options

Customer interface	ProfiSafe
Input signal for peripheral contactor (US2)	not used
Operator safety acknowledgment	external unit


Loading a WorkVisual project

- **Precondition:**
 - ▶ **KR C4** and notebook with **WorkVisual** are within the same network
- **Procedure:**
 - ▶ Start **WorkVisual**
 - ▶ Menu sequence: **File > Open project**
 - ▶ Menu sequence: **Browse tab > Refresh** button
 - ▶ Select **Online project** and load it using the **Open** button



Deploying a WorkVisual project


- **Precondition:**
 - ▶ **KR C4** and notebook with **WorkVisual** are within the same network
 - ▶ The user profile **Expert** is activated on the KR C4
- **Procedure:**
 - ▶ The project to be deployed is open in **WorkVisual**
 - ▶ Menu sequence: **Extras tab > Install**
 - ▶ The **Project deployment** window is opened




- ▶ Check the **Cell** and **Target controller** via the "Change" buttons
- ▶ Click on the **Next** button
- ▶ Another window opens, and the project is complemented
- ▶ Click on the **Activate** button > project is deployed
- ▶ Additionally, the project must be confirmed on the **KR C4 HMI**

Calling the WorkVisual diagnosis

- **Precondition:**
 - ▶ KR C4 and notebook with **WorkVisual** are within the same network
- **Procedure:**
 - ▶ Window **Workspaces > Programming and configuration**




- ▶ Window **Cell view > Cell selection** – activate check box(es)
- ▶ **Online system information** is shown for the selected cells




- ▶ Toggle via the **Editors** tab between **System information editor**, **Diagnostic monitor**, **Trace configuration** and **Trace evaluation**
- Alternatively, directly via the icons displayed:



- **Examples:**



KUKA Recovery Tool (Option)



- **Precondition:**
- ▶ A bootable **KUKA USB stick** is required
 - ▶ **KUKA Recovery Tool** is installed on this USB stick
 - ▶ The following settings must be made first:

Path: **MODE > Controller.ini**

[KRCType]
Version=silent
Mode=0
Persistent=0

[HDDSize]
Partition_1=10000
Partition_2=5000

[DEBUG]
Debug=0

Variable	Description
Version	<ul style="list-style-type: none"> ■ GUI mode is executed if the program line is commented out ■ Silent mode is executed if the program line is activated Default: silent
Mode	<ul style="list-style-type: none"> ■ 0: Create hard drive image on the USB stick ■ 1: Restore hard drive image from the USB stick ■ 2: Restore master image from the hidden partition Default: 0
Persistent	<ul style="list-style-type: none"> ■ 0: Following program execution, the value set for Mode is reset to the default value ■ 1: Following program execution, the value set for Mode is retained, e.g. Mode=1 Default: 0

Path: NET > NetCon.ini**[NetUNC]**

1=\\backup1\transfer\

Description

- Only UNC network paths may be used. Drive letters are assigned automatically by the system
- Format: \\ Server_name\ Share_name

Path: NET > SetIPAddress.ini**[StaticIPAddress]**

IPAddress=xxx.xxx.xxx.xxx

Subnetmask=xxx.xxx.xxx.xxx

;Gateway=xxx.xxx.xxx.xxx

Value Description

IP address ■ Enter a permanent, static IP address if no DHCP address assignment is available

Subnet mask ■ Enter the subnet mask for the IP address

Gateway ■ IP address of a gateway, if present

Default: xxx.xxx.xxx.xxx = no static IP address / gateway

Path: Image

ImageName_C.wim

ImageName_D.wim

Description

- Folder for the KRC4 images
- In Silent mode, the most recent image is always restored.