

Publishers

Subscribers

/vehicle/status/control_mode

/vehicle/status/steering_status

/vehicle/status/velocity_Status

/vehicle/status/gear_status

/vehicle/status/hazard_lights_status

/vehicle/status/turn_indicators_status

⋮

Service server
/control/control_mode_request

microAutoware
Vehicle Interface

/control/command/control_cmd

/control/command/gear_cmd

/control/command/emergency_cmd

/control/command/turn_indicators_cmd

/control/command/hazard_lights_cmd

/control/command/actuation_cmd

⋮

Vehicle