

UXA-90 Light

Multipurpose Humanoid Robot

Maintenance Manual



(1) PROBLEMS

No	Details of problems			Code	Solution Code		
1	When UXA-90 does not move	Press "C" on the controller, or give the same order in other ways, but the robot does not move	Beep sound from the robot		1110	④⑤	
2			No beep sound from the robot	Operated by the remote controller	1121	③	
3				Operated by a PC	1122	②	
4		The robot does not move and no response while standing			1200	③	
5		The robot stops suddenly while playing motions			1300	⑦⑧	
6	When UXA-90 has malfunction	The robot moves suddenly when power is ON			2100	⑤	
7		The robot cannot stand up but moves only one leg when pressing "C" button			2200	①	
8		The robot can stand up but the upper body part does not move	After rebooting of the robot	All LEDs on the motors are blinking.	2301	⑤	
9				At least one LED is not blinking	2302	①	
10		The robot is in standing position	Falls down suddenly	Falls down with lifting a leg	2411	④	
11				Falls down without lifting a leg	2412	⑥	
12			An arm moves suddenly			2420	①
13		While playing motions	Abnormal movements			2510	①
14			Motors are shaking while playing motions			2520	⑥
15						2530	⑨

(2) SOLUTIONS

Code	Name	Solutions	Self-repair
①	Replace cables	Refer to Appendix 1 <Replace cables>	Δ
②	Check connection of PC	Refer to Appendix 2 <Check connection of PC>	O
③	Check connection of RF module	Refer to Appendix 4 <Check motors by SAM Programmer>	O
④	Check motors by SAM Programmer	Refer to Appendix 4 <Check motors by SAM Programmer>	O
⑤	Replace RED Interface board	Replace the RED Interface board in the robot	X
		Remove the chest cover to replace the RED board	
⑥	Replace motors	Replace specific motors having troubles	Δ
⑦	Rebooting	Turn off and on turn on all power of the robot	O
⑧	Re-download of motions	Re-download the robot's motion files by RB Tool	O
⑨	Check power	Check the power cable	O
		Check if the power is ON	

< Appendix 1 – Replace cables >

1. Introduction

UXA-90 Dance Robot has lots of movements on the both arm, therefore, all the cables on the arm parts need to be changed every 3 months. Total 6 cables are needed (3 cables for each arm).

Parts below are required.


- Cables (6pcs), 2mm hexagonal wrench.

2. Parts

- 1) SAM Motor: Servo motors using for UXA-90. The numbers in the red circles represent each servo motors.
- 2) Cable: Cables connecting each motor. The numbers in the white square represent each cable.




※ Use the thinnest and shortest cable for the arms.



3. How to replace cables (Both arms are symmetric so explain about the right arm only)

3.1. Replace cable 14 & 15

- 1) Unscrew 4 bolts and take out the frame on motors 13 and 15.



- 2) Take out cable 15 connecting motors 13 & 15 by hand.




- 3) Connect a new cable and assemble the frame in reverse order.



3.2. Replace cable 16 & 17


- 1) Unscrew 8 bolts under motors 15 & 17 to take out the frame.



- 2) Full down the frame as below.



- 3) Take out cables 16 & 17 by hand.



- 4) Connect a new cable and assemble the frame in reverse order.

3.3. Replace cables 18 & 19

- 1) Take out cables 18 & 19 by hand.



- 2) Connect a new cable in the same way.




< Appendix 2 – Check connection of PC >

※ Reference – Chapter 6.1 'RB Tool' on 'UXA-90 Operation Manual'

6.1 RB Tool (Robobuilder download tool)

6.1.1 Wired connection by USB cable.


- A. Prepare an USB cable.
- B. Connect a PC and the robot (SW Board) by the USB cable.
- C. Turn on UXA-90 in a sitting position.
- D. Run RB Tool software and connect the port. If the connection fails, refer to 2.USB Driver on 'UXA-90 Operation Manual'.



<RB Tool>

- E. Press 'C' on the remote controller UI on the SW to make the robot stand up.
- F. Press desired motion buttons on the remote controller UI to operate (Reference – 7.1 Remote Controller Key map on 'UXA-90 Operation Manual').

6.1.2 Wireless connection by RF-USB




- A. Connect RQ-USB2UART, RF-USB Socket and RF module. Use a twisted cable for this connection.
- B. Connect A to PC.
- C. Follow the same process from 'D' on <6.1.1 Wired connection by USB Cable>.


< Appendix 3 – Check connection of RF module >

※ Reference – 6.2 RF Mini Controller on 'UXA-90 Operation Manual'.

6.2 RF Mini Controller



- A. Insert a RF chip in the RF controller.
 - B. Turn on UXA-90 in a sitting position, and then turn on the controller.
 - C. Press 'C' button on the controller to make the robot stand up.
- ※ Press 'A' on the controller will make the robot stand up and pose the initial posture when the power supply is connected.



<Key map of RF controller>


- D. Run desired motions by the controller. (Reference – 7.1 Remote Controller Key Map)

< Appendix 4 – Check motors by SAM Programmer >


Before start

- ① The robot and PC are connected by USB cable.
- ② The robot is in a sitting position while power is ON.

1. Run 'SAM Programmer v0.990'.




2. Check [Connect through RBC] and then click [ScanPort] to connect to the robot.




3. [ClosePort] will appear after successful connection.

Check [AllBody] and then click [ScanUXA] to scan data of UXA-90.



4. Data of all the motors will be scanned if the robot is in a steady state. (Send a captured image as below to Robobuilder for analysis.)



5. If the robot has problems, a pop-up window will be shown as below. Press [OK] to proceed checking to find defective motors.

SAM Programmer v0.990

COM Port: COM3 Baudrate: 115200

ClosePort ScanPort

Connect through RBC

Command Pad

Model: 8-BIT

Target Position: 127

Command Execute

Received Data

00 00 00 00 06 20 15 0C 01 FE 06 05 16 00 05 05 00 00 00 06 20 15 0C 01 FE 06 05 0A 47

Setting & Programming

BasicSetting SpecialSetting QuickMode ActionCon GraphView MotionProgramming UXA90Test

ID	Pgain	Dgain	DrivMode	Load	CltTorg	BoundUp	BoundLow	FWver	Position
0	10	5	00	4000	3000	254	1	16A3	2121
1	10	5	00	4000	3000	254	1	16A3	2108
2	40	40	00	4000	3000	254	1	21A3	2017
3	40	40	00	4000	3000	254	1	21A3	2110
4	40	40	00	4000	3000	254	1	21A3	1077
5	40	40	00	4000	3000	254	1	21A3	2914
6	40	40	00	4000	3000	254	1	21A3	1687
7	40	40	00	4000	3000	254	1	21A3	2346
8	30	20	00	4000	3000	254	1	21A3	1867
9	30	20	00	4000	3000	254	1	21A3	1895
10	40	10	00	4000	3000	254	1	16A3	1777
11	40	10	00	4000	3000	254	1	16A3	2046
12	20	20	00	1000	2000	254	1	10A3	1548
13	20	20	00	1000	2000	254	1	10A3	2588
14	10	10	00	800	2700	254	1	10A3	2127
15	10	10	00	800	2700	254	1	10A3	1978
16	5	5	00	800	2700	254	1	0305	2022
17	5	5	00	800	2700	254	1	0305	2106
18	5	5	00	800	2700	254	1	0305	2816
19	5	5	00	800	2700	254	1	0305	1351
20									
21									
22									
23									
24									
25									
26									
27									

Try Again OK

Received Data

00 00 06 20 15 0C 01 FE 06 05 0A 47 05 0A 00 00 00 06 20 15 0C 01 FE 06 05 10 34 0A 0A 00 00 00 06 20 15 0C 01 FE 06 05 15 5C