










LED signals explained

-  System test mode active check documentation
-  Test successful – Tested larger type by pin numbers
-  Test successful – Tested smaller type by pin numbers
-  Test failed – Address decoder Nr. greens = address line
-  Test failed – Memory cell test. Nr. greens = Test pattern
-  Test failed – Row crosstalk or data retention fail
-  Test failed – Ground short on pin nr of green blinks
-  Fast red only – Config error (check DIP switches)
-  Test running – please wait takes up to 10sec