







# COMBINATION METER





# COMBINATION METER

## SERVICE HINTS

### B 1 BRAKE FLUID LEVEL SW

1-2 : CLOSED WITH FLOAT DOWN

### P 3 PARKING BRAKE SW

1-GROUND : CLOSED WITH PARKING BRAKE PEDAL DEPRESSED

### O 2 OIL PRESSURE SW

1-GROUND : CLOSED WITH OIL PRESSURE BELOW APPROX. **0.2KG/CM<sup>2</sup> (2.8PSI, 20KPA)**

### W 3 WATER TEMP. SENSOR

1-GROUND : APPROX. **226Ω (50°C, 122°F)**

APPROX. **25Ω (115°C, 239°F)**

### E 5 ENGINE OIL LEVEL WARNING SW

1-2 : CLOSED WITH FLOAT UP AND ENGINE OIL TEMP. AT BELOW APPROX. **55°C (131°F)**

OPEN WITH FLOAT DOWN AND ENGINE OIL TEMP. AT ABOVE APPROX. **60°C (140°F)**

### F21 FUEL SENDER

2-3 : APPROX. **3Ω** AT FUEL FULL

APPROX. **110Ω** AT FUEL EMPTY

### C12 (A), C13 (C), C14 (B) COMBINATION METER

(A) 1-GROUND : APPROX. **12 VOLTS** WITH IGNITION SW AT **ON** POSITION

(A) 2-GROUND : APPROX. **12 VOLTS** WITH IGNITION SW AT **ST** POSITION AND SHIFT LEVER AT **P** OR **N** RANGE

(A) 3-GROUND : APPROX. **12 VOLTS** WITH IGNITION SW AT **ON** POSITION

(A) 10-GROUND : ALWAYS CONTINUITY

(B) 10-GROUND : ALWAYS CONTINUITY

(C) 3-GROUND : ALWAYS APPROX. **12 VOLTS**

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
<b>A15</b>	<a href="#">24</a>	<b>D 1</b>	<a href="#">26</a>	<b>N 1</b>	<a href="#">25</a>
<b>B 1</b>	<a href="#">24</a>	<b>D19</b>	<a href="#">26</a>	<b>O 2</b>	<a href="#">25</a>
<b>C 5</b>	<a href="#">24</a>	<b>E 5</b>	<a href="#">24</a>	<b>P 3</b>	<a href="#">27</a>
<b>C12</b> A	<a href="#">26</a>	<b>F21</b>	<a href="#">28</a>	<b>S 1</b>	<a href="#">25</a>
<b>C13</b> C	<a href="#">26</a>	<b>I 2</b>	<a href="#">25</a>	<b>T11</b>	<a href="#">27</a>
<b>C14</b> B	<a href="#">26</a>	<b>J 1</b>	<a href="#">27</a>	<b>W 3</b>	<a href="#">25</a>
<b>C18</b>	<a href="#">26</a>	<b>J 2</b>	<a href="#">27</a>	<b>W 5</b>	<a href="#">27</a>

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
<b>7</b>	<a href="#">18</a>	R/B NO.7 (RIGHT SIDE OF J/B NO.1)

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
<b>1A</b>	<a href="#">18</a>	COWL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)
<b>1B</b>	<a href="#">18</a>	INSTRUMENT PANEL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)
<b>1G</b>	<a href="#">18</a>	COWL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)
<b>2A</b>	<a href="#">20</a>	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
<b>2B</b>	<a href="#">20</a>	COWL WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
<b>3A</b>	<a href="#">22</a>	INSTRUMENT PANEL WIRE AND J/B NO.3 (BEHIND THE INSTRUMENT PANEL CENTER)
<b>3D</b>		
<b>4A</b>		
<b>4B</b>		
<b>4C</b>	<a href="#">23</a>	COWL WIRE AND J/B NO.4 (BEHIND THE COMBINATION METER)
<b>4D</b>		



**A15 BLACK**

(W/ TRACTION CONTROL) **B 1 BLACK**

(W/O TRACTION CONTROL) **B 1 BLACK**

**C 5 BLACK**

**C12 (A)**



# COMBINATION METER

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA3	32	COWL WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF J/B NO.2)
EB1	32	ENGINE NO.2 WIRE AND ENGINE ROOM MAIN WIRE (RIGHT SIDE OF J/B NO.2)
EC1	32	ENGINE NO.4 WIRE, FOR ALTERNATOR AND ENGINE ROOM MAIN WIRE (RIGHT SIDE OF J/B NO.2)
IH1	34	INSTRUMENT PANEL WIRE AND COWL WIRE (J/B NO.1)
IH2	34	INSTRUMENT PANEL WIRE AND COWL WIRE (BEHIND GLOVE BOX)
IH3		
II1	34	INSTRUMENT PANEL WIRE AND FLOOR NO.1 WIRE (UNDER THE INSTRUMENT PANEL BRACE RH)
II2		
IL1	36	ENGINE WIRE AND COWL WIRE (UNDER THE GLOVE BOX)
IL2		
IL3		
BQ1	38	COWL WIRE AND FLOOR NO.2 WIRE (LEFT KICK PANEL)
BQ3		


 : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	32	FRONT SIDE OF RIGHT FENDER
EB	32	FRONT SIDE OF LEFT FENDER
ED	32	REAR SIDE OF CYLINDER HEAD LH
IE	34	LEFT KICK PANEL
IH	34	RIGHT KICK PANEL


 : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 20	32	ENGINE ROOM MAIN WIRE	I 57	36	COWL WIRE
E 65	32	ENGINE WIRE	I 58		
E100	32	COWL WIRE	I138	36	INSTRUMENT PANEL WIRE
E118			I142		
E119			I189	36	COWL WIRE
I 12	36		I190		
I 50					

C13 ③ ORANGE



C14 ⑧




C18



D 1 BLACK



(CANADA) D19



E 5




F21




I 2 BLACK



J 1



J 2



N 1 GRAY



O 2 GRAY




P 3



S 1 GRAY



T11



W 3 BLACK



W 5

