




C12 ⑧




C14 ①



C16 BLACK



F13




H 1 GRAY




H 2 GRAY




I17



J 1



HEADLIGHT (FOR USA)



SERVICE HINTS

HEADLIGHT RELAY

1-2 : CLOSED WITH LIGHT CONTROL SW AT **HEAD** POSITION OR DIMMER SW AT **FLASH** POSITION

C16 LIGHT CONTROL SW [COMB. SW]

13-11 : CLOSED WITH LIGHT CONTROL SW AT **HEAD** POSITION

C16 DIMMER SW [COMB. SW]

14-9 : CLOSED WITH DIMMER SW AT **FLASH** POSITION

12-9 : CLOSED WITH DIMMER SW AT **HIGH** OR **FLASH** POSITION

3-9 : CLOSED WITH DIMMER SW AT **LOW** POSITION



: PARTS LOCATION

CODE		SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C12	B	26	F13	24	I17	26
C14	A	26	H 1	24	J 1	27
C16		26	H 2	24		



: RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
5	20	R/B NO.5 (NEAR THE J/B NO.2)



: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
2A	20	ENGINE ROOM MAIN WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
2B	20	COWL WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)



: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA3	32	COWL WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF J/B NO.2)
IH1	34	INSTRUMENT PANEL WIRE AND COWL WIRE (J/B NO.1)



: GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	34	LEFT KICK PANEL
IF	34	INSTRUMENT PANEL BRACE LH
IH	34	RIGHT KICK PANEL



: SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 10	32	ENGINE ROOM MAIN WIRE	I 19	36	COWL WIRE
E 11			I 37		
E 25			I 38		
E 34			I 58		