

## SERVICE HINTS

### T17 (A) TELEPHONE TRANSCEIVER AND SPEAKER RELAY

- (A) 9-GROUND : ALWAYS APPROX. 12 VOLTS  
 (A) 10-GROUND : APPROX. 12 VOLTS WITH IGNITION SW AT **ACC** OR **ON** POSITION  
 (A) 11-GROUND : ALWAYS CONTINUITY

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
<b>C15</b>	<a href="#">26</a>	<b>R 4</b> A	<a href="#">27</a>	<b>T18</b> B	<a href="#">29</a>
<b>M 2</b>	<a href="#">29</a>	<b>R16</b>	<a href="#">29</a>		
<b>R 2</b> B	<a href="#">27</a>	<b>T17</b> A	<a href="#">29</a>		

## □ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
<b>1G</b>	<a href="#">18</a>	COWL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)
<b>2B</b>	<a href="#">20</a>	COWL WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
<b>4D</b>	<a href="#">23</a>	COWL WIRE AND J/B NO.4 (BEHIND THE COMBINATION METER)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS







CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
<b>EA3</b>	<a href="#">32</a>	COWL WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF J/B NO.2)
<b>II2</b>	<a href="#">34</a>	INSTRUMENT PANEL WIRE AND FLOOR NO.1 WIRE (UNDER THE INSTRUMENT PANEL BRACE RH)
<b>BQ2</b>	<a href="#">38</a>	COWL WIRE AND FLOOR NO.2 WIRE (LEFT KICK PANEL)
<b>BQ3</b>		
<b>BU1</b>	<a href="#">38</a>	REAR DOOR LH WIRE AND FLOOR NO.2 WIRE (LEFT CENTER PILLAR)
<b>BW2</b>	<a href="#">38</a>	FLOOR NO.1 WIRE AND FLOOR NO.2 WIRE (UNDER THE LEFT SIDE OF REAR SEAT CUSHION)
<b>BW3</b>		

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
<b>EB</b>	<a href="#">32</a>	FRONT SIDE OF LEFT FENDER

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
<b>I 91</b>	<a href="#">36</a>	COWL WIRE	<b>B 47</b>	<a href="#">38</a>	FLOOR NO.2 WIRE



# CELLULAR MOBILE TELEPHONE

