

New AirSync user onboarding

1. Enable New Aircraft Service on the AirSync account

1. Log into their AirSync user account
2. Go to Accounts (top)
3. Choose their account in the list
4. Go to Services (menu) > NGAFID (See screenshot below)
5. Choose to Enable Service
6. Option: "Enable New Aircraft by Default" (this will set it for any new aircraft added to AirSync)
7. Option: "Default Log Start" (Select "Full Log History" to give access to log history)
8. Option: "Enable all aircraft within this account" (Easiest option to enable all aircraft immediately)

NGAFID

☒ Enable Service

Options

☐ Enable New Aircraft by Default

Default Log Start

All Future Logs ▾

☐ Enable all aircraft within this account ⓘ

Submit

2. Provide the RIT development team with your AirSync account name.