



Circuit Diagrams Scrambler 1200 XC, Scrambler 1200 XE and Scrambler 1200 Steve McQueen Edition

This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.


All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.

© Triumph Motorcycles Ltd. 03.2021 Issue 1


This page intentionally left blank

Circuit Diagrams	Page
1 - Power Distribution Circuit	4
2 - Starter Motor Circuit	5
3 - Keyless Control Circuit	6
4 - Ignition Circuit	7
5 - ABS Circuit	8
6 - Brake Circuit	9
7 - Engine Management Circuit - ECM Power and Ground	10
8 - Engine Management Circuit - Pressure Sensors	11
9 - Engine Management Circuit - Temperature Sensors	12
10 - Engine Management Circuit - Switches	13
11 - Engine Management Circuit - Position Sensors	14
12 - Engine Management Circuit - Level Sensor	15
13 - Engine Management Circuit - Fuel Injection Components	16
14 - Engine Management Circuit - Throttle Control	17
15 - Engine Management Circuit - Cooling Fan	18
16 - Engine Management Circuit - Fuel Pump	19
17 - Instrument Circuit	20
18 - Lighting Circuit - Front	21
19 - Lighting Circuit - Rear - Standard	22
20 - Lighting Circuit - Rear - Multifunctional	23
21 - Lighting Circuit - Indicators	24
22 - Communication Network Circuit	25
23 - Horn Circuit	26
24 - Diagnostic Connector Circuit	27
25 - Accessories Circuit	28
26 - Heated Accessories Circuit	29
27 - Alarm Circuit	30
28 - Rider Information Circuit	31
29 - Ground Circuit	32


01 POWER DISTRIBUTION CIRCUIT




02 STARTER MOTOR CIRCUIT




03 KEYLESS CONTROL CIRCUIT




04 IGNITION CIRCUIT




05 ABS CIRCUIT





06 BRAKE CIRCUIT





07 ENGINE MANAGEMENTCIRCUIT - ECM POWER AND GROUND

















13 ENGINE MANAGEMENT CIRCUIT - FUEL INJECTION COMPONENTS




14 ENGINE MANAGEMENT CIRCUIT - THROTTLE CONTROL




15 ENGINE MANAGEMENT CIRCUIT - COOLING FAN




16 ENGINE MANAGEMENT CIRCUIT - FUEL PUMP




17 INSTRUMENT CIRCUIT




18 LIGHTING CIRCUIT - FRONT




19 LIGHTING CIRCUIT - REAR STANDARD




20 LIGHTING CIRCUIT - REAR MULTIFUNCTION







22 COMMUNICATIONS NETWORK CIRCUIT




23 HORN CIRCUIT




24 DIAGNOSTIC SOCKET CIRCUIT




25 ACCESSORIES CIRCUIT




26 HEATED ACCESSORIES CIRCUIT



27 ALARM CIRCUIT





29 EARTH CIRCUIT

