



Circuit Diagrams Speed Triple 1200 RS

This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.


© Triumph Motorcycles Ltd. 01.2022 Issue 1

This page intentionally left blank


TABLE OF CONTENTS

Circuit Diagrams	Page
1 - Power Distribution Circuit	4
2 - Starter Motor Circuit	5
3 - Keyless Control Circuit	6
4 - Ignition Circuit	7
5 - ABS Circuit	8
6 - Brake Circuit	9
7 - Chassis Control Circuit	10
8 - Engine Management Circuit - ECM Power and Ground	11
9 - Engine Management Circuit - Pressure Sensors	12
10 - Engine Management Circuit - Temperature Sensors	13
11 - Engine Management Circuit - Switches	14
12 - Engine Management Circuit - Position Sensors	15
13 - Engine Management Circuit - Level Sensor	16
14 - Engine Management Circuit - Fuel Injection Components	17
15 - Engine Management Circuit - Throttle Control	18
16 - Engine Management Circuit - Cooling Fan	19
17 - Engine Management Circuit - Fuel Pump	20
18 - Instrument Circuit	21
19 - Lighting Circuit - Front	22
20 - Lighting Circuit - Rear	23
21 - Lighting Circuit - Indicators	24
22 - Communication Network Circuit	25
23 - Horn Circuit	26
24 - Exhaust Butterfly Valve Actuator Motor	27
25 - Diagnostic Connector Circuit	28
26 - Accessories Circuit	29
27 - Heated Accessories Circuit	30
28 - Alarm Circuit	31
29 - Rider Information Circuit	32
30 - Ground Circuit	33


01 POWER DISTRIBUTION CIRCUIT




02 STARTER MOTOR CIRCUIT





03 KEYLESS CONTROL CIRCUIT




04 IGNITION CIRCUIT










07 CHASSIS CONTROL CIRCUIT




08 ENGINE MANAGEMENT CIRCUIT - ECM POWER AND GROUND










11 ENGINE MANAGEMENT CIRCUIT - SWITCHES










14 ENGINE MANAGEMENT CIRCUIT - FUEL INJECTION COMPONENTS









17 ENGINE MANAGEMENT CIRCUIT - FUEL PUMP





18 INSTRUMENT CIRCUIT







20 LIGHTING CIRCUIT - REAR






22 COMMUNICATIONS NETWORK CIRCUIT








24 EXHAUST BUTTERFLY VALVE ACTUATOR MOTOR




25 DIAGNOSTIC SOCKET CIRCUIT








28 ALARM CIRCUIT



29 RIDER INFORMATION CIRCUIT



30 EARTH CIRCUIT

