



## **Circuit Diagram Glossary**

### **Speed 400 and Scrambler 400 X**

This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.

© Triumph Motorcycles Ltd. 08.2023 Issue 1

This page intentionally left blank

TABLE OF CONTENTS

<b>Glossary of Circuit Diagram Symbols</b>	<b>1</b>
<b>Main Wiring Harness Electrical Connectors</b>	<b>2</b>

GLOSSARY OF CIRCUIT DIAGRAM SYMBOLS


The following is a description of the symbols and information found in the circuit diagram for this model.

NOTICE

Wire colours and connector pin references shown in the illustrations below are examples and maybe different from those shown in the circuit diagram for this model.

Components with a Fly Lead and an Inline Connector

51




The illustration shows an example of a component with a fly lead and an inline connector.

The component is represented by a white box, with fly lead wires leading to an inline connector.

Information provided with the component includes:

- The component reference number near to the component.
- A function reference for each terminal - located inside the component, adjacent to the connecting wire (given in English only).
- Wire colour references - located on each wire.

Components with an Integral Connector



7


The illustration shows an example of a component with an integral connector.

The component is identified by a white box, with a connector directly connected to the component.

Information provided with the component includes:

- The component reference number near to the component.
- A function reference for each terminal - located inside the component, adjacent to the connecting wire (given in English only).
- Wire colour references - located on each wire.

## Fuse Boxes



The illustration shows an example of a fuse box.

A fuse is a device that protects a circuit if a fault occurs. The fuse will 'blow' if a short circuit occurs, protecting that circuit from more damage.

Information provided with the fuse box includes:

- The fuse box name - located above the fuse box.
- A fuse number/location reference for each fuse - located above the fuse.
- A fuse rating (in Amps) for each fuse - located inside the fuse.
- A fuse box, terminal number and terminal block reference - located on each wire entering the fuse box.

In the above example, the fuse box, terminal number and terminal block references can be interpreted as follows:


- Fuse F1 is connected between terminals 1 and 3.
- Fuse F1 is a 15 amp (15A) fuse.

## Relays


A relay is an electromagnetic switch. To close the relay contacts and complete the circuit, an electromagnet in the relay is energised, which causes the relay contacts to close and make the circuit complete.

Relays are used when the electrical current is too high for a mechanical switch. This is usually when the switching must be done quickly to prevent arcing across the switch contacts. If a mechanical switch were used, the mechanical switch contacts would quickly burn away.

## Relays Connected with a Single Socket Connector




## Ring Terminals



The illustration shows the symbol used to identify a ring terminal (commonly used as ground points).

A reference number is provided near to the terminal.

## Shielded Wires



The illustration shows the symbol used to identify wires that are shielded against electromagnetic interference.


Examples of components that have shielded wires include:

- ABS wheel speed sensors
- Immobiliser antenna
- Throttle position sensor
- USB socket

The wire shielding is typically connected to ground.

## Glossary Of Circuit Diagram Symbols

## Splices




The illustration shows an example of a splice.

A splice is a hard cable joint where two or more cables are joined together in the wiring harness. A splice is a potential source of both open and short circuits.

A splice reference number prefixed with "SP" is located near to the splice symbol.


## Twisted Wires



The illustration shows the symbol used to indicate a pair of wires that are twisted together, for example: CAN circuit wires.







## Starter Motor Grounding

Starter motors fitted to Triumph motorcycles are connected to ground through the mating faces of the starter motor body and the crankcase.









MAIN WIRING HARNESS ELECTRICAL CONNECTORS

The table below shows the connector pin diagrams for each electrical connector on the main wiring harness for this model.

 <p>TP0331</p>	 <p>TP0326</p>
ABS modulator	ABS fuse box
 <p>TP0333</p>	 <p>TP0335</p>
Alarm	Battery positive terminal
 <p>TP0334</p>	 <p>TP0336</p>
Battery negative terminal	Diagnostic connector


Main Wiring Harness Electrical Connectors

 <p>TP0337</p>	 <p>TP0338</p>
Clutch switch	Left hand switch housing connector
 <p>TP0339</p>	 <p>TP0340</p>
Right hand switch housing connector	Coolant temperature sensor
 <p>TP0342</p>	 <p>TP0343</p>
Engine ground	Engine ECM connector







TP0345  
Front brake switch



TP0344  
Front ABS wheel speed sensor  
Rear ABS wheel speed sensor







TP0346  
Fuel injector 1




TP0347  
Fuel pump

Main Wiring Harness Electrical Connectors


 <p>TP0348</p> <p>Starter relay Fuel pump relay Headlight relay Cooling fan relay Main relay</p>	 <p>TP0350</p> <p>Gear Position Sensor and Crankshaft Angle Sensor</p>
 <p>TP0341</p> <p>ECM ground</p>	 <p>TP0351</p> <p>Headlight</p>




TP0352  
Horn positive  
Horn negative



TP0353  
Ignition coil 1




TP0354  
Ignition switch




TP0355  
Immobiliser ECM


Main Wiring Harness Electrical Connectors




TP0345  
Immobiliser antenna




TP0324  
Front left direction indicator  
Front right direction indicator  
Rear left direction indicator  
Rear right direction indicator



TP0330  
Instruments




TP0356  
Oxygen sensor, bank 1 sensor 1  
Oxygen sensor, bank 1 sensor 2




TP0349

Fuse box primary




TP0357

Manifold absolute pressure sensor  
Temperature and Manifold Absolute Pressure sensor



TP0358





Oil pressure sensor




TP0359


Purge valve

Main Wiring Harness Electrical Connectors


 <p>TP0360 Cooling fan 1</p>	 <p>TP0337 Rear brake switch</p>
 <p>TP0365 Regulator rectifier</p>	 <p>TP0361 Roll over sensor Side stand switch Rear light</p>




TP0362  
Starter solenoid connector



TP0342  
Starter solenoid



TP0363  
Throttle actuator motor/Throttle position sensor



TP0337  
USB socket