

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
103A	HEADLIGHT POSITION CONTROL
103B	INTEGRAL HEADLIGHT ADJUSTMENT ACTUATOR + FEED
107D	TELEPHONE RADIO CUT-OFF SIGNAL
107F	MULTIMEDIA MICROPHONE SIGNAL
107G	HANDS FREE TELEPHONE MICROPHONE +
107H	HANDS FREE TELEPHONE MICROPHONE -
107J	TELEPHONE MICROPHONE SCREENING
107W	DIAGNOSTIC SOCKET CANH MULTIMEDIA SIGNAL
107X	DIAGNOSTIC SOCKET CANL MULTIMEDIA SIGNAL
10F	DIPPED BEAM HEADLIGHTS > SIDE LIGHTS RELAY - CONTROL
122B	+ DIESEL PUMP GAS RECIRCULATION SOLENOID VALVE FEED
133B	INSTRUMENT PANEL CAN H SIGNAL > COMPUTER
133C	INSTRUMENT PANEL CAN L SIGNAL > COMPUTER
13AC	FOOTWELL LIGHTING TIMER + CONTROL
13E	INTERIOR LIGHTS - CONTROL > TIMER
141B	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 1 SIGNAL
141C	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 2 SIGNAL
141D	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 3 SIGNAL
141G	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 4 SIGNAL
141H	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL LINE 5 SIGNAL
141K	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 1 SIGNAL
141L	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 2 SIGNAL
141M	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 3 SIGNAL
141N	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 4 SIGNAL
141P	INFORMATION DISPLAY STEERING WHEEL MOUNTED CONTROL COLUMN 5 SIGNAL
14K	WINDSCREEN WIPER TIMER LOW SPEED + CONTROL
14L	WINDSCREEN WIPER TIMER HIGH SPEED + CONTROL
14M	WINDSCREEN WIPER PARK POSITION CONTROL > COMPUTER
14S	RAIN SENSOR SERIAL LINE SIGNAL
151C	EXTERIOR LEFT HAND REAR SENSOR SIGNAL
151E	PARKING AID WARNING LIGHT CONTROL
151H	EXTERIOR RIGHT HAND REAR SENSOR SIGNAL
151M	INTERIOR LEFT HAND REAR SENSOR SIGNAL
151Q	INTERIOR RIGHT HAND REAR SENSOR SIGNAL
151R	BUZZER +
151S	BUZZER CONTROL
151U	EXTERIOR + SENSOR
151V	EXTERIOR - SENSOR
151W	PARKING AID DEACTIVATION
153A	POWER ASSISTED STEERING CAN H SIGNAL
153B	POWER ASSISTED STEERING CAN L SIGNAL
15A	HEATED REAR SCREEN WARNING LIGHT CONTROL
15LP	PROTECTED HEATED REAR SCREEN + CONTROL
15M	HEATED REAR SCREEN RELAY - CONTROL
15RP	PROTECTED HEATED REAR VIEW MIRROR + CONTROL
164A	FIXED CORNERING LIGHTS SUPPLY
164B	- FIXED CORNERING LIGHT 1
164C	FRONT RIGHT-HAND FIXED CORNERING LIGHT CONTROL
164G	FRONT LEFT-HAND FIXED CORNERING LIGHT CONTROL
16A	WINDSCREEN WASHER PUMP + CONTROL
19E	MAIN BEAM HEADLIGHTS - CONTROL > DIMMER
1A	STARTER SOLENOID + CONTROL > RELAY
20AR	DEADLOCKING MOTOR CONTROL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
20AW	ONE-TOUCH DOOR LOCKING/UNLOCKING CONTROL
20BC	DRIVER'S DOOR / FUEL FILLER FLAP UNLOCKING MOTOR CONTROL
20BD	OPEN FRONT/REAR PASSENGER DOORS MOTOR CONTROL
20BH	DRIVER'S DOOR / FUEL FILLER FLAP LOCK MOTOR CONTROL
20BK	PASSENGER DOORS / REAR DOORS LOCKING MOTOR CONTROL
20D	ELECTRIC DOOR LOCKS CLOSE + CONTROL
20G	TAILGATE MOTOR OPEN CONTROL
20M	DOOR LOCKING LED
20S	TAILGATE MOTOR OPENING AUTHORISED FEED
20T	CHILD SAFETY LED - CONTROL
20U	LEFT HAND REAR DOOR DEADLOCKING - SIGNAL
20V	RIGHT HAND REAR DOOR DEADLOCKING - SIGNAL
20W	REAR DEADLOCKING MOTOR CONTROL
20X	FRONT DEADLOCKING MOTOR CONTROL
20Z	FRONT DEADLOCKING RELAY - CONTROL
21A	DRIVER'S ELECTRIC WINDOW UP CONTROL
21B	DRIVER'S ELECTRIC WINDOW DOWN CONTROL
21C	ONE-TOUCH ELECTRIC WINDOW NORMAL UP - CONTROL
21E	ONE-TOUCH ELECTRIC WINDOW NORMAL DOWN - CONTROL
21K	ANTI-PINCH SUNROOF/ELECTRIC WINDOW SERIAL LINE SIGNAL
22A	PASSENGER'S ELECTRIC WINDOW UP CONTROL
22B	PASSENGER'S ELECTRIC WINDOW DOWN CONTROL
22C	FRONT ELECTRIC WINDOW CONTROL 1
22D	FRONT ELECTRIC WINDOW CONTROL 2
23A	ELECTRIC WINDOW CONTROL > RIGHT-HAND REAR QUARTER LIGHT CLOSE
23B	ELECTRIC WINDOW DOWN CONTROL > RIGHT HAND REAR QUARTER LIGHT OPEN
23C	ELECTRIC WINDOW UP CONTROL > LEFT HAND REAR QUARTER LIGHT CLOSE
23D	ELECTRIC WINDOW DOWN CONTROL > LEFT HAND REAR QUARTER LIGHT OPEN
23E	REAR LOCKING FUNCTION RELAY COIL CONTROL
23EA	REAR ELECTRIC WINDOW RELAY CONTROL
23F	REAR ELECTRIC WINDOW CONTROL > REAR FUNCTIONS RELAY
23G	RIGHT HAND REAR ELECTRIC WINDOW CONTROL 1
23H	RIGHT HAND REAR ELECTRIC WINDOW CONTROL 2
23J	LEFT HAND REAR ELECTRIC WINDOW CONTROL 1
23K	LEFT HAND REAR ELECTRIC WINDOW CONTROL 2
24A	REAR SCREEN WASHER PUMP + CONTROL
26AA	KEYLESS VEHICLE DRIVER'S FRONT DOOR EXTERNAL AERIAL A SIGNAL
26AB	KEYLESS VEHICLE DRIVER'S SIDE FRONT DOOR EXTERNAL AERIAL B SIGNAL
26AC	KEYLESS VEHICLE FRONT PASSENGER DOOR EXTERNAL AERIAL A SIGNAL
26AD	KEYLESS VEHICLE FRONT RIGHT DOOR EXTERNAL AERIAL SIGNAL 2
26AG	KEYLESS VEHICLE DRIVER'S SIDE REAR DOOR EXTERNAL AERIAL A SIGNAL
26AH	KEYLESS VEHICLE DRIVER'S SIDE REAR DOOR EXTERNAL AERIAL B SIGNAL
26AK	KEYLESS VEHICLE REAR PASSENGER DOOR EXTERNAL AERIAL A SIGNAL
26AL	KEYLESS VEHICLE REAR PASSENGER DOOR EXTERNAL AERIAL B SIGNAL
26AM	KEYLESS VEHICLE BOOT LID EXTERNAL AERIAL A SIGNAL
26AN	KEYLESS VEHICLE BOOT LID EXTERNAL AERIAL SIGNAL2
26AP	KEYLESS VEHICLE LOCKING SIGNAL / DRIVER SIDE DOORS SWITCH
26AQ	KEYLESS VEHICLE LOCKING SIGNAL / PASSENGER SIDE DOORS SWITCH
26AR	KEYLESS VEHICLE LEVEL 2 LOCKING SIGNAL / BOOT LID SWITCH
26AT	KEYLESS VEHICLE INTERIOR AERIAL 1 SIGNAL 1
26AU	KEYLESS VEHICLE FRONT INTERIOR AERIAL SIGNAL 2
26AV	KEYLESS VEHICLE INTERIOR AERIAL 2 SIGNAL 1
26AW	KEYLESS VEHICLE INTERIOR AERIAL 2 SIGNAL 2

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
26AX	KEYLESS VEHICLE INTERIOR AERIAL 3 SIGNAL 1
26AY	KEYLESS VEHICLE CENTRAL INTERIOR AERIAL SIGNAL 2
26AZ	KEYLESS VEHICLE STEERING COLUMN LOCK CAN H SIGNAL
26BA	KEYLESS VEHICLE STEERING COLUMN LOCK CAN L SIGNAL
26BC	CARD LOCATION ELECTROLUMINESCENT DIODE CONTROL
26BD	UCH SYNCHRONISATION / CARD READER SIGNAL
26BG	UCH DATA / CARD READER SIGNAL
26BH	+ CARD READER
26BK	- CARD READER
26I	+ STEERING COLUMN LOCK
26J	CONTROL - SAFETY HALL SENSOR
26M	ENGINE RUNNING WARNING LIGHT CONTROL
26N	ENGINE START/STOP + SIGNAL
26P	DOOR HANDLE INFRARED SENSOR +
26Q	PASSENGER SIDE DOOR HANDLE INFRARED SENSOR SIGNAL
26S	DRIVER'S SIDE REAR HANDLE INFRARED SENSOR SIGNAL
26T	DRIVER'S HANDLE INFRARED SENSOR SIGNAL
26X	CLUTCH - SIGNAL
26Z	AUTOMATIC TRANSMISSION NEUTRAL + SIGNAL
27A	HANDBRAKE WARNING LIGHT - CONTROL
28A	OIL PRESSURE WARNING LIGHT - CONTROL
2N	ALTERNATOR SYNCHRONOUS BIT SIGNAL (CHARGE SIGNAL MANAGED BY UPC)
30A	BRAKE FLUID LEVEL WARNING LIGHT - CONTROL
32A	OIL LEVEL SENSOR SIGNAL 2
32B	OIL LEVEL SENSOR SIGNAL 1
32C	ENGINE PROTECTION UNIT / OIL LEVEL SENSOR SIGNAL 2
32D	UPC / OIL LEVEL SENSOR SIGNAL 1
34A	LEFT HAND REAR LOUDSPEAKER + SIGNAL
34AN	AM/FM AERIAL SIGNAL
34AO	RADIO SATELLITE L3 (LINE 3) SIGNAL
34AP	RADIO SATELLITE SIGNAL L0
34AQ	RADIO SATELLITE SIGNAL L1
34AR	RADIO SATELLITE SIGNAL L2
34AS	RADIO SATELLITE IN0 SIGNAL
34AT	RADIO SATELLITE IN1 SIGNAL
34AU	RADIO SATELLITE IN2 SIGNAL
34B	LEFT HAND REAR LOUDSPEAKER - SIGNAL
34C	RIGHT HAND REAR LOUDSPEAKER - SIGNAL
34D	RIGHT HAND REAR LOUDSPEAKER + SIGNAL
34E	RIGHT HAND FRONT LOUDSPEAKER + SIGNAL
34EC	RIGHT HAND LINE IN + SIGNAL
34EE	LEFT HAND LINE IN + SIGNAL
34EP	AM/FM1 RADIO SIGNAL
34ET	- LINE IN
34F	RIGHT HAND FRONT LOUDSPEAKER - SIGNAL
34G	LEFT HAND FRONT LOUDSPEAKER + SIGNAL
34GB	MULTIMEDIA 2 CAN H SIGNAL
34GC	MULTIMEDIA 2 CAN L SIGNAL
34H	LEFT HAND FRONT LOUDSPEAKER - SIGNAL
34HU	MULTIMEDIA WAKE-UP SIGNAL
34HY	MULTIMEDIA STOP/START CONTROL
34PE	C_BOX RIGHT HAND AUDIO + SIGNAL
34PG	C_BOX AUDIO - SIGNAL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
34PH	C_BOX LEFT-HAND AUDIO + SIGNAL
34PJ	C_BOX CONNECTION DETECTION SIGNAL
34TE	USB + SUPPLY
34TG	USB - SUPPLY
34TH	USB + SIGNAL
34TJ	USB - SIGNAL
36A	REAR WIPER + CONTROL
36C	REAR SCREEN WIPER PARK POSITION SWITCH - SIGNAL
36G	RELAYED REAR SCREEN WIPER + CONTROL
37AA	PRE-HEATER PLUG 2 CONTROL
37AB	PRE-HEATER PLUG 3 CONTROL
37AC	PRE-HEATER PLUG 4 CONTROL
37Z	PRE-HEATER PLUG 1 CONTROL
38AH	FAN MOTOR SPEED 1 + CONTROL
38AJ	FAN MOTOR SPEED 2 + CONTROL
38AK	FAN MOTOR SPEED 3 + CONTROL
38AL	FAN MOTOR SPEED 4 + CONTROL
38DA	HEATING FAN ASSEMBLY + CONTROL > AIR CONDITIONING PANEL
38DB	HEATER BLOWER + CONTROL > AIR CONDITIONING PANEL
38ES	AIR CONDITIONING WARNING LIGHT - CONTROL
38GX	SUN SENSOR SIGNAL
38GZ	INTERIOR TEMPERATURE SENSOR SIGNAL
38JA	RECIRCULATION MOTOR CONTROL 1
38JB	RECIRCULATION MOTOR CONTROL 2
38JN	SUN TEMPERATURE HUMIDITY SENSOR ZERO VOLTS
38JU	PASSENGER COMPARTMENT HEATING RESISTANCE CONTROL RELAY 1
38JV	PASSENGER COMPARTMENT HEATING RESISTANCE CONTROL RELAY 2PASSENGER
38KY	AIR DISTRIBUTION MOTOR B2 COIL CONTROL
38KZ	AIR DISTRIBUTION MOTOR A2 COIL CONTROL
38LA	AIR DISTRIBUTION MOTOR B1 COIL CONTROL
38LB	AIR DISTRIBUTION MOTOR A1 COIL CONTROL
38LC	AIR MIXER MOTOR B2 COIL CONTROL
38LD	AIR MIXER MOTOR A2 COIL CONTROL
38LG	AIR MIXER MOTOR B1 COIL CONTROL
38LH	AIR MIXER MOTOR A1 COIL CONTROL
38LL	PASSENGER COMPARTMENT HEATING RESISTANCE / RELAY 1 CONTROL
38LM	PASSENGER COMPARTMENT HEATING RESISTANCE CONTROL / RELAY 2
38LP	AIR CONDITIONING STOP/START CONTROL
38LQ	FAN ASSEMBLY SPEED 0 SIGNAL
38LR	PASSENGER COMPARTMENT FAN SET SPEED 2 CONTROL
38R	AIR CONDITIONING CLUTCH + CONTROL
38U	- REFRIGERANT GAS PRESSURE SENSOR
38W	AIR CONDITIONING REFRIGERANT GAS PRESSURE SENSOR -
38X	REFRIGERANT GAS PRESSURE SENSOR SIGNAL
38Y	REFRIGERANT GAS PRESSURE SENSOR +
39A	HEADLIGHT WASHER PUMP + CONTROL
39C	HEADLIGHT WASHER PUMP MOTOR CONTROL
39G	HEADLIGHT WASHERS RELAY 1 + CONTROL
39H	HEADLIGHT WASHERS RELAY 2 + CONTROL
3AA	INJECTION LOCKING RELAY COIL - CONTROL
3AAD	- AIR FLAP
3AAM	-PARTICLE FILTER DIFFERENTIAL PRESSURE SENSOR
3ABQ	AIR FLOW TEMPERATURE SIGNAL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
3AC	FUEL PUMP RELAY COIL - CONTROL
3ACN	TDC SENSOR/ENGINE SPEED + SIGNAL
3AGR	INJECTOR EXHAUST SOLENOID VALVE CONTROL
3AGX	CATALYTIC CONVERTER DOWNSTREAM TEMPERATURE SIGNAL
3AGY	-CATALYTIC CONVERTER DOWNSTREAM TEMPERATURE
3AHA	FUEL PUMP EXHAUST CONTROL RELAY
3AHK	ADDITIONAL HEATER RELAY 1 FAULT FINDING
3AHL	ADDITIONAL HEATER RELAY 2 FAULT FINDING
3AHN	+ DISCHARGE VALVE SOLENOID VALVE
3AJB	THROTTLE MOTOR + CONTROL
3AJC	THROTTLE MOTOR - CONTROL
3AT	TURBOCHARGER PRESSURE SOLENOID VALVE CONTROL
3B	AIR TEMPERATURE SENSOR + SIGNAL
3BB	CANISTER BLEED SOLENOID VALVE
3BG	ENGINE SPEED SIGNAL > TDC SENSOR
3BL	ENGINE SPEED > TDC SENSOR - SIGNAL
3BS	IGNITION COIL CONTROL
3C	COOLANT TEMPERATURE SENSOR + SIGNAL
3CE	IGNITION COIL 1 CONTROL
3CF	IGNITION COIL 2 CONTROL
3CG	IGNITION COIL 3 CONTROL
3CK	UNIT 2 SENSOR -
3CP	INJECTION COMPUTER CONTROL > IGNITION POWER MODULE 2-3
3CQ	CAMSHAFT SENSOR SIGNAL
3CR	INJECTOR 1 - CONTROL
3CS	INJECTOR 2 - CONTROL
3CT	INJECTOR 3 - CONTROL
3CU	INJECTOR 4 - CONTROL
3CV	INJECTOR 1 & 4 IGNITION COIL - CONTROL
3CW	INJECTOR 2 & 3 IGNITION COIL - CONTROL
3CX	EGR SOLENOID VALVE -
3CZ	INJECTION COMPUTER CONTROL > 1 4 IGNITION POWER MODULE
3DQ	PINKING SENSOR -
3DU	AIRFLOW SENSOR -
3DV	AIRFLOW SENSOR + SIGNAL
3DW	AIRFLOW SENSOR - SIGNAL
3EL	EGR POTENTIOMETER + SIGNAL
3EN	IGNITION COIL 4 CONTROL
3F	ATMOSPHERIC PRESSURE SENSOR SIGNAL
3FAB	FUEL TEMPERATURE + SIGNAL
3FB1	INJECTION + > PROTECTIVE RELAY
3FB2	INJECTION + > PROTECTIVE RELAY
3FF	PRE-HEATER RELAY - CONTROL
3FJ	INJECTION COMPUTER SENSOR -
3FX	CRUISE CONTROL ON>OFF - CONTROL
3FY	PRE-HEATER RELAY DIAGNOSTIC SIGNAL
3GC	EGR SENSOR +
3GD	EGR SENSOR -
3GF	UPSTREAM OXYGEN SENSOR HEATER - CONTROL
3GG	DOWNSTREAM OXYGEN SENSOR HEATER - CONTROL
3GH	UPSTREAM OXYGEN SENSOR EARTH
3GJ	DOWNSTREAM OXYGEN SENSOR EARTH
3GK	UPSTREAM OXYGEN SENSOR SIGNAL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
3GL	DOWNSTREAM OXYGEN SENSOR SIGNAL
3GM	AIR INTAKE SOLENOID VALVE - CONTROL
3GN	MANIFOLD PRESSURE SENSOR EARTH
3HE	COOLANT TEMPERATURE SIGNAL
3HI	FUEL PRESSURE CONTROL SOLENOID VALVE - CONTROL
3JA	ADDITIONAL HEATER 1 RELAY COIL CONTROL
3JAA	ADDITIONAL HEATER 2 RELAY COIL CONTROL
3JAB	ADDITIONAL HEATER 3 CONTROL RELAY
3JAC	CONTROL+ ADDITIONAL HEATER 4
3JB	ADDITIONAL HEATER PLUG 1 + CONTROL
3JC	ADDITIONAL HEATER PLUG 2 + CONTROL
3JD	ADDITIONAL HEATER PLUG 3 + CONTROL
3JK	COOLANT TEMPERATURE -
3JM	EGR SOLENOID VALVE -
3JQ	AIR TEMPERATURE -
3KJ	AIRFLOW +
3KQ	AIR TEMPERATURE SIGNAL
3KW	INJECTOR 1 CONTROL
3KX	INJECTOR 2 CONTROL
3KY	INJECTOR 3 CONTROL
3KZ	INJECTOR 4 CONTROL
3L	+ INJECTOR 1
3LA	+ INJECTOR 2
3LB	+ INJECTOR 3
3LC	+ INJECTOR 4
3LD	FUEL TEMPERATURE SENSOR -
3LG	ATMOSPHERIC PRESSURE SENSOR +
3LN	TURBOCHARGER PRESSURE SENSOR -
3LP	TURBOCHARGER PRESSURE SENSOR + SIGNAL
3LQ	TURBOCHARGER PRESSURE SENSOR +
3LR	+ LOAD POTENTIOMETER 1
3LS	LOAD POTENTIOMETER 1 + SIGNAL
3LT	- LOAD POTENTIOMETER 1
3LU	+ LOAD POTENTIOMETER 2
3LV	- LOAD POTENTIOMETER 2
3LW	LOAD POTENTIOMETER 2 + SIGNAL
3LX	RAIL FUEL PRESSURE SENSOR +
3LY	RAIL FUEL PRESSURE SENSOR + SIGNAL
3LZ	RAIL FUEL PRESSURE SENSOR -
3MG	TURBO PRESSURE SOLENOID VALVE - CONTROL
3MN	MOTORISED THROTTLE POTENTIOMETER + 5 VOLTS
3MO	MOTORISED THROTTLE POTENTIOMETER SENSOR -
3MP	MOTORISED THROTTLE POTENTIOMETER 1 SIGNAL
3MQ	MOTORISED THROTTLE POTENTIOMETER 2 SIGNAL
3MS	ENGINE CAN H SIGNAL
3MT	ENGINE CAN L SIGNAL
3N	FUEL PUMP +
3PB	COOLANT TEMPERATURE SENSOR - >AIR
3PC	CAMSHAFT SHIFTER CONTROL
3PD	SPEED LIMITER ON/OFF CONTROL
3PL	BANK A>B CAMSHAFT SENSOR EARTH
3QK	+ CAMSHAFT SENSOR SIGNAL
3S	PINKING SENSOR 1 + SIGNAL > FRONT

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
3SH	THROTTLE AIR TEMPERATURE -
3SM	MOTOR 2 CAN H SIGNAL
3SN	MOTOR 2 CAN L SIGNAL
3SV	INLET CAMSHAFT SENSOR SIGNAL
3SX	- INLET CAMSHAFT SENSOR
3SZ	VARIABLE INLET CAMSHAFT CONTROL
3TD	PARTICLE FILTER UPSTREAM TEMPERATURE SENSOR SIGNAL
3TG	PARTICLE FILTER DOWNSTREAM TEMPERATURE SENSOR SIGNAL
3TL	PARTICLE FILTER DIFFERENTIAL PRESSURE SIGNAL
3VD	DUAL MODE SOLENOID VALVE CONTROL
3VG	TURBOCHARGER COOLANT PUMP RELAY CONTROL
3VH	+ TURBOCHARGER BEARING COOLANT PUMP
3VL	- PILOT COOLANT THERMOSTAT CONTROL
3VM	AIR INTAKE FLAP FAULT FINDING
3VP	CONTROL + GAS RECIRCULATION MOTOR
3VQ	CONTROL - GAS RECIRCULATION MOTOR
3WT	WATER IN DIESEL DETECTION SENSOR SIGNAL
3XR	THROTTLE VALVE MOTOR RELAY CONTROL
3XS	+ / THROTTLE VALVE MOTOR RELAY CONTROL
3XT	-PARTICLE FILTER UPSTREAM TEMPERATURE SENSOR
3XU	-PARTICLE FILTER DOWNSTREAM TEMPERATURE SENSOR
3YC	- OIL VAPOUR REHEATER
3YD	+5 VOLTS TURBINE PRESSURE/PARTICLE FILTER DIFFERENTIAL
3YH	+ CAMSHAFT SHIFTER
3YL	- CAMSHAFT SENSOR
3ZQ	RAIL PRESSURE REGULATION + CONTROL
40A	DRIVER'S REAR VIEW MIRROR RIGHT>LEFT CONTROL
40B	PASSENGER REAR VIEW MIRROR UP/DOWN CONTROL
40C	DRIVER'S REAR VIEW MIRROR UP/DOWN CONTROL
40D	PASSENGER REAR VIEW MIRROR RIGHT>LEFT CONTROL
40E	REAR VIEW MIRROR MOTOR COMMON
40W	REAR-VIEW MIRROR FOLD IN CONTROL
40X	REAR-VIEW MIRROR FOLD OUT CONTROL
41A	FUEL LEVEL SENDER + SIGNAL
41B	FUEL LEVEL -
46CC	GPS NAVIGATION SIGNAL
46CD	NAVIGATION SOUND SIGNAL
46CE	RIGHT-HAND AUDIO NAVIGATION + SIGNAL
46CG	LEFT-HAND AUDIO NAVIGATION + SIGNAL
46CH	AUDIO NAVIGATION - SIGNAL
46CJ	NAVIGATION/RADIO AM/FM SIGNAL
47C	EXTERNAL TEMPERATURE SENSOR + SIGNAL
47D	EXTERNAL TEMPERATURE SENSOR ZERO VOLTS SIGNAL
47F	VEHICLE SPEED SIGNAL
47Z	EXTERNAL TEMPERATURE / DISPLAY SIGNAL
49B	FAN + CONTROL
49G	FAN HIGH SPEED RELAY + CONTROL
49R	FAN HIGH SPEED FEED
4AQ	ELECTRONIC STABILITY PROGRAM ON/OFF SWITCH - CONTROL
4BZ	YAW SENSOR TEST SIGNAL (DIRECTIONAL STABILITY)
4C	LEFT HAND FRONT WHEEL SENSOR SIGNAL
4CV	YAW SENSOR REFERENCE SIGNAL (DIRECTIONAL STABILITY)
4CW	YAW SENSOR SIGNAL (DIRECTIONAL STABILITY)

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
4CX	LATERAL ACCELERATION SENSOR SIGNAL
4CY	YAW SENSOR - (DIRECTIONAL STABILITY) > LATERAL ACCELERATION
4DM	ANTI-LOCK BRAKING SYSTEM UPPER CAN SIGNAL
4DN	ANTI-LOCK BRAKING SYSTEM LOWER CAN SIGNAL
4E	LEFT HAND FRONT WHEEL SENSOR +
4G	LEFT HAND REAR WHEEL SENSOR SIGNAL
4GJ	BRAKE LIGHTS ON CONTROL RELAY
4H	LEFT HAND REAR WHEEL SENSOR +
4M	RIGHT HAND FRONT WHEEL SENSOR SIGNAL
4N	RIGHT HAND FRONT WHEEL SENSOR +
4S	RIGHT HAND REAR WHEEL SENSOR SIGNAL
4T	RIGHT HAND REAR WHEEL SENSOR +
52D	DIGITAL CONTROL EARTH
52G	1-BIT DIGITAL CONTROL
52H	2-BIT DIGITAL CONTROL
52J	3-BIT DIGITAL CONTROL
55S	ENGINE SPEED SIGNAL
57AD	GEARBOX CONTROL SENSOR -
57AF	GEARBOX CONTROL SENSOR +
5A	BRAKE PEDAL SWITCH + SIGNAL
5AD	AUTOMATIC CLUTCH PRESSURE SWITCH - SIGNAL
5AE	AUTOMATIC CLUTCH ELECTRIC PUMP MOTOR + CONTROL
5AF	AUTOMATIC CLUTCH ELECTRIC PUMP UNIT RELAY COIL - CONTROL
5AN	AUTOMATIC CLUTCH POSITION SENSOR + SIGNAL
5AU	SEQUENCE SOLENOID VALVE +
5AV	SEQUENCE SOLENOID VALVE 1 -
5AW	SEQUENCE SOLENOID VALVE 2 -
5AX	SEQUENCE SOLENOID VALVE 3 -
5AY	SEQUENCE SOLENOID VALVE 4 -
5AZ	SEQUENCE SOLENOID VALVE 5 -
5BA	MODULATING SOLENOID VALVE +
5BB	SEQUENCE SOLENOID VALVE 6 -
5BC	PRESSURE SOLENOID VALVE 1 -
5BX	BRIDGING MODULATING SOLENOID VALVE
5DA	GEARBOX INPUT SPEED SENSOR + SIGNAL
5DB	GEARBOX INPUT SPEED SENSOR - SIGNAL
5DD	EXCHANGER FLOW SENSOR CONTROL SOLENOID VALVE +
5DG	MULTIFUNCTION SWITCH SIGNAL 2
5DH	MULTIFUNCTION SWITCH SIGNAL 3
5DJ	MULTIFUNCTION SWITCH SIGNAL 4
5DK	MULTIFUNCTION SWITCH - > AUTOMATIC TRANSMISSION COMPUTER
5DL	MODULATING SOLENOID VALVE 3
5DM	MODULATING SOLENOID VALVE 4
5DN	EXCHANGER FLOW SENSOR SOLENOID VALVE - CONTROL
5DU	GEAR LEVER LOCKING - CONTROL
5FA	ENGAGED POSITION SENSOR SIGNAL
5FB	SELECTION POSITION SENSOR SIGNAL
5FC	SELECTION SOLENOID VALVE 1
5FD	SELECTION SOLENOID VALVE 2
5FE	ENGAGED SOLENOID VALVE 1
5FF	ENGAGED SOLENOID VALVE 2
5FG	CLUTCH SOLENOID VALVE
5FI	GEAR LEVER - CONTROL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
5FJ	UPPER CONTACT MULTIFUNCTION PUSH BUTTON CONTROL
5FK	"STANDBY" CONTACT MULTIFUNCTION PUSH BUTTON CONTROL
5FL	NEUTRAL CONTACT MULTIFUNCTION PUSH BUTTON CONTROL
5FM	LOWER CONTACT MULTIFUNCTION PUSH BUTTON CONTROL
5GC	AUTOMATIC GEARBOX NEUTRAL POSITION LED SIGNAL
5H	N+1 PUSH BUTTON CONTROL
5HN	SENSOR EARTH
5HX	+ SENSOR FEED
5KB	INCREASE SPEED ONE-TOUCH CONTROL SIGNAL
5KC	DECREASE SPEED ONE-TOUCH CONTROL SIGNAL
5KH	- ONE-TOUCH CONTROL ON STEERING WHEEL FEED
5LN	STEERING WHEEL ONE-TOUCH CONTROL SIGNAL
5LP	+ ONE-TOUCH CONTROL ON STEERING WHEEL FEED
5LR	+ SENSORS / STEERING WHEEL ONE-TOUCH CONTROL FEED
5V	LINE PRESSURE SENSOR -
5W	LINE PRESSURE SENSOR + SIGNAL
5X	TRACTION CONTROL - CONTROL
60AF	PASSENGER'S SIDE SATELLITE + SIGNAL
60AG	DRIVER'S SIDE FRONT SATELLITE + SIGNAL
60AH	DRIVER'S SIDE SATELLITE - SIGNAL
60AJ	PASSENGER'S SIDE FRONT SATELLITE - SIGNAL
60AK	DRIVER'S LAP STRAP PRETENSIONER + CONTROL
60AL	DRIVER'S LAP STRAP PRETENSIONER - CONTROL
60AM	LEVEL 1 DRIVER'S FRONT AIR BAG + CONTROL
60AN	LEVEL 1 DRIVER'S FRONT AIR BAG - CONTROL
60AP	LEVEL 2 DRIVER'S FRONT AIR BAG + CONTROL
60AQ	LEVEL 2 DRIVER'S FRONT AIR BAG - CONTROL
60AR	DRIVER'S SIDE THORAX AIR BAG + CONTROL
60AS	- DRIVER'S SIDE THORAX AIR BAG CONTROL
60AV	DRIVER'S SIDE REAR INERTIA REEL PRETENSIONER + CONTROL
60AW	DRIVER'S SIDE REAR INERTIA REEL PRETENSIONER - CONTROL
60AZ	PASSENGER LAP BELT PRETENSIONER + CONTROL
60B	PASSENGER'S PRETENSIONER + SIGNAL
60BA	PASSENGER LAP BELT PRETENSIONER - CONTROL
60BB	PASSENGER'S SIDE THORAX AIR BAG + CONTROL
60BC	PASSENGER'S SIDE THORAX AIR BAG - CONTROL
60BG	PASSENGER'S SIDE REAR INERTIA REEL PRETENSIONER + CONTROL
60BH	PASSENGER'S SIDE REAR INERTIA REEL PRETENSIONER - CONTROL
60BP	DRIVER'S SEAT POSITION SIGNAL
60BY	DRIVER'S HEAD CURTAIN AIR BAG + CONTROL
60BZ	DRIVER'S HEAD CURTAIN AIR BAG - CONTROL
60C	PASSENGER'S PRETENSIONER _ SIGNAL
60CA	PASSENGER'S HEAD CURTAIN AIR BAG + CONTROL
60CB	PASSENGER'S HEAD CURTAIN AIR BAG - CONTROL
60CL	DRIVER'S SEAT POSITION EARTH
60D	DRIVER'S PRETENSIONER + SIGNAL
60DS	PASSENGER AIR BAG INHIBITOR KEY SIGNAL
60DT	- PASSENGER AIR BAG INHIBITOR KEY
60DU	DRIVER'S SEATBELT WARNING SIGNAL
60DV	DRIVER'S SEATBELT WARNING EARTH
60E	DRIVER'S PRETENSIONER - SIGNAL
60H	PASSENGER EURO BAG + SIGNAL
60K	PASSENGER'S FRONT AIR BAG LEVEL 1 - CONTROL

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
60PB	PASSENGER AIRBAG OFF WARNING LIGHT + FEED
60PC	PASSENGER AIRBAG OFF WARNING LIGHT CONTROL
64C	LEFT HAND TURN SIGNAL LIGHTS CONTROL
64D	RIGHT HAND TURN SIGNAL LIGHTS CONTROL
64F	HAZARD WARNING LIGHTS INDICATOR LIGHT + CONTROL
64Q	FLASHER UNIT TIMER - CONTROL
65A	BRAKE LIGHTS + CONTROL
65G	BRAKE LIGHT CONTROL > RELAY
66C	REVERSING LIGHTS FUSE + CONTROL
66H	REVERSING LIGHTS / ENGINE PROTECTION UNIT CONTROL
67A	HORN + CONTROL
79G	PASSENGER HEATED SEAT INDICATOR LIGHT + CONTROL
79L	RIGHT HAND HEATED SEAT RELAY + CONTROL
79M	DRIVER'S HEATED SEAT COVER CONTROL
79N	PASSENGER HEATED SEAT COVER CONTROL
79R	HEATER PAD 1 + FEED VIA DRIVER'S HEATER PAD 2
79S	HEATER PAD 1 + FEED VIA PASSENGER HEATER PAD 2
80A	BONNET SWITCH - SIGNAL
80T	ENGINE IMMOBILISER WARNING LIGHT - CONTROL
80X	TRANSPONDER AERIAL BUS (INTERFACE) SIGNAL
86D	DECLUTCH + SIGNAL
86G	CRUISE CONTROL PROGRAMMING CONTROL
86M	CRUISE CONTROL PROGRAMMING RETURN SIGNAL
87A	LEFT HAND REAR 1st POSITION SWITCH - SIGNAL
87B	RIGHT HAND REAR 1st POSITION SWITCH - SIGNAL
87F	VOICE SYNTHESISER RADIO CUT-OFF SIGNAL
87G	PASSENGER'S 1st POSITION SWITCH - SIGNAL
87H	DRIVER'S 1st POSITION SWITCH - SIGNAL
87T	BOOT LID POSITION SWITCH 1 SIGNAL
8E	+ FRONT LEFT-HAND FOG LIGHTS > RESISTANCE
8F	+ FRONT RIGHT-HAND FOG LIGHTS > RESISTANCE
96L	DRIVER'S SEATBELT REMINDER LIGHT CONTROL
9P	PROTECTED REAR FOG LIGHTS + CONTROL
A	+ AFTER IGNITION
AP10	PROTECTED + AFTER IGNITION BRAKE LIGHTS FUSE
AP11	PROTECTED + AFTER IGNITION REVERSING LIGHTS FUSE
AP15	PROTECTED + AFTER IGNITION ENGINE FUNCTIONS FUSE
AP25	PROTECTED + AFTER IGNITION AIR BAG FUSE
AP4	PROTECTED + AFTER IGNITION AUTOMATIC TRANSMISSION FUSE
APCB	+ AFTER IGNITION PROTECTED / COLUMN LOCK FUSE CONTACT CLOSED AT REST
APR1	AFTER IGNITION RELAY 1
APR2	AFTER IGNITION RELAY 2
BCP4	PROTECTED + BATTERY FEED CIRCUIT BREAKER MEMORY FUSE
BP11	PROTECTED + BATTERY FEED > PASSENGER COMPARTMENT 1
BP12	PROTECTED + BATTERY FEED > PASSENGER COMPARTMENT 2
BP13	PROTECTED + BATTERY FEED > PASSENGER COMPARTMENT 3
BP14	PROTECTED + BATTERY FEED > ABS
BP19	PROTECTED + BATTERY FEED > FLASHER UNIT TIMER
BP20	PROTECTED + BATTERY FEED HEADLIGHT WASHERS
BP23	PROTECTED + BATTERY FEED PASSENGER COMPARTMENT 4
BP25	PROTECTED + BATTERY FEED REAR SCREEN WIPER
BP3	PROTECTED + BATTERY FEED ELECTRIC DOOR LOCKING FUSE
BP32	PROTECTED + BATTERY FEED HORN FUSE

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
BP35	PROTECTED + BATTERY FEED PRE-HEATER UNIT FUSE
BP36	PROTECTED + BATTERY FEED > AUTOMATIC CLUTCH PUMP UNIT
BP39	PROTECTED + BATTERY FEED > AUTOMATIC CLUTCH COMPUTER
BP42	PROTECTED + BATTERY FEED > AUTOMATIC TRANSMISSION COMPUTER
BP44	PROTECTED + BATTERY FEED > INJECTOR POWER
BP48	PROTECTED + BATTERY FEED > ELECTRIC WINDOW
BP55	DRIVER'S ONE-TOUCH ELECTRIC WINDOW FUSE PROTECTED + BATTERY FEED
BP6	PROTECTED + BATTERY FEED > INTERIOR LIGHT
BP69	PROTECTED BATTERY FEED > INSTRUMENT PANEL > ECU +
BP7	PROTECTED + BATTERY FEED > FAN FUSE 1
BP70	PROTECTED + BATTERY FEED > PASSENGER'S ONE-TOUCH FRONT ELECTRIC WINDOW FUSE
BP77	BATTERY PROTECTED + FEED > UCH
BP78	BATTERY PROTECTED + FEED > FRONT CLUSTER LAMP RELAY
BP8	PROTECTED + BATTERY FEED > ANTI-LOCK BRAKING SYSTEM MOTOR
BP81	PROTECTED + BATTERY FEED > ELECTRIC POWER-ASSISTED STEERING
BP9	PROTECTED + BATTERY FEED ADDITIONAL HEATER FUSE
BP93	+ BATTERY PROTECTED SUNROOF
BPDA	PROTECTED + BATTERY FEED > ALTERNATOR STARTING
BPR1	+ BATTERY FEED > RELAY
BPR2	+ BATTERY > RELAY / AIR CONDITIONING / SEAT
BPS1	+ BATTERY SAFETY PROTECTED
BPT	PROTECTED + BATTERY FEED TIMER
BPT3	+ BATTERY PROTECTED / TIMED RELAY
CPD	PROTECTED RIGHT HAND DIPPED BEAM HEADLIGHT +
CPG	PROTECTED LEFT HAND DIPPED BEAM HEADLIGHT +
D	STARTER +
H61	RH FOG>TURN SIGNAL LIGHTS > LH REVERSING>TURN SIGNAL LIGHTS
H62	LH REVERSING>TURN SIGNAL LIGHTS > RH FOG>TURN SIGNAL LIGHTS
H7	REV COUNTER > TOP DEAD CENTRE > COIL > COMPUTER ALTERNATOR SIGNAL
HK	DIAGNOSTIC SIGNAL K
LPD	PROTECTED RIGHT HAND SIDE LIGHT +
LPDA	PROTECTED RIGHT HAND SIDE LIGHT +
LPG	PROTECTED LEFT HAND SIDE LIGHT +
LPGA	PROTECTED LEFT HAND SIDE LIGHT +
M	EARTH
MAH	ANTI-LOCK BRAKING SYSTEM ELECTRICAL EARTH
MAK	ADDITIONAL HEATING ELECTRICAL EARTH
MAR	FRONT RIGHT-HAND SIDE MEMBER ELECTRICAL EARTH
MAS	FRONT LEFT-HAND SIDE MEMBER ELECTRICAL EARTH
MAT	FRONT LEFT-HAND SIDE MEMBER ELECTRICAL EARTH 2
MC	GEARBOX ELECTRICAL EARTH
MCA	EARTH
MF	REAR RIGHT-HAND ELECTRICAL EARTH
MG	REAR LEFT-HAND ELECTRICAL EARTH
MH	ENGINE EARTH
MHB	FRONT LEFT-HAND SIDE MEMBER ELECTRICAL EARTH 3
MHC	FRONT LEFT-HAND SIDE MEMBER ELECTRICAL EARTH 4
MJ	RIGHT-HAND A-PILLAR ELECTRICAL EARTH
MK	LEFT-HAND A-PILLAR ELECTRICAL EARTH
ML	BATTERY ELECTRICAL EARTH
MT	RADIO ELECTRICAL EARTH
N	ELECTRONIC EARTH
NAM	UPPER LEFT-HAND CROSS MEMBER ELECTRONIC EARTH

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
NAP	TUNNEL ELECTRONIC EARTH
NC	LEFT-HAND A-PILLAR ELECTRICAL EARTH
NF	ENGINE EARTH
NH	ENGINE EARTH
NU	FRONT LEFT-HAND SIDE MEMBER ELECTRICAL EARTH 2
RPD	RIGHT HAND PROTECTED MAIN BEAM HEADLIGHT +
RPG	LEFT HAND PROTECTED MAIN BEAM HEADLIGHT +
S	+ ACCESSORIES FEED
S1	+ ACCESSORIES FEED THROUGH RELAY
S2	ACCESSORIES RELAY CONTROL
SP15	PROTECTED + ACCESSORIES FEED FUSE
SP17	PROTECTED + ACCESSORIES FEED > BRAKE LIGHTS FUSE
SP2	PROTECTED + ACCESSORIES > RADIO
SP3	PROTECTED + ACCESSORIES > HEATER
SP4G	CIGARETTE LIGHTER PROTECTED + ACCESSORIES FEED
SPB3	BATTERY + ACC FEED>FRONT PASSENGER ELECTRIC WINDOW PROTECTION SHUNT
SPB4	+ REAR RH AND LH ELECTRIC WINDOWS PROTECTION SHUNT BATT. + ACC FEED
TB1	PINKING SENSOR SCREENING BRAID
TB13	AM/FM AERIAL SHIELDING
TB37	LINE IN SHIELDED CABLE
TB39	AM/FM1 RADIO SHIELDING BRAID
TB41	GPS NAVIGATION SHIELDING BRAID
TB59	AUDIO C_BOX SHIELDED CABLE
TB81	NAVIGATION AUDIO SHIELDED CABLE
TB82	NAVIGATION/RADIO AM/FM SHIELDED CABLE