

LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
101	CIGARETTE LIGHTER
103	ALTERNATOR
104	STARTING SWITCH
105	MAIN ELECTROMAGNETIC HORN
107	BATTERY
108	IGNITION COIL
118	ANTI-LOCK BRAKING SYSTEM COMPUTER
119	AUTOMATIC TRANSMISSION COMPUTER
120	INJECTION COMPUTER
129	GEAR SELECTOR CONTROL
130	REAR RIGHT-HAND ELECTRIC WINDOW CONTROL
131	REAR LEFT-HAND ELECTRIC WINDOW CONTROL
133	PASSENGER'S SIDE ELECTRIC WINDOW CONTROL
134	ELECTRIC REAR-VIEW MIRROR CONTROL
135	REAR WINDOW WINDER LOCKING SWITCH
138	REAR RIGHT DOOR ELECTRIC LOCKING
139	REAR LEFT DOOR ELECTRIC LOCKING
140	DRIVER'S DOOR ELECTRIC LOCKING
141	CENTRAL LOCKING FOR PASSENGER DOOR
146	PINKING SENSOR 1
147	MANIFOLD PRESSURE SENSOR
149	TDC SENSOR
150	RIGHT REAR WHEEL SENSOR
151	LEFT REAR WHEEL SENSOR
152	RIGHT FRONT WHEEL SENSOR
153	LEFT FRONT WHEEL SENSOR
155	REVERSING LIGHTS SWITCH
156	HANDBRAKE SWITCH
160	BRAKE SWITCH
163	STARTER
164	COLD AIR BLOWER
165	LUGGAGE COMPARTMENT LIGHTING
166	RIGHT-HAND REGISTRATION PLATE LIGHTING
167	LEFT-HAND REGISTRATION PLATE LIGHTING
168	GLOVE COMPARTMENT LIGHT
171	AIR CONDITIONING CLUTCH
172	RIGHT REAR LIGHT
173	LEFT REAR LIGHT
174	RIGHT-HAND REAR FOG LIGHT
175	LEFT-HAND REAR FOG LIGHT
176	RIGHT FRONT FOGLIGHT
177	LEFT FRONT FOGLIGHT
188	COOLING FAN UNIT
189	RIGHT REAR SPEAKER
190	LEFT REAR SPEAKER
193	INJECTOR 1
194	INJECTOR 2
195	INJECTOR 3
196	INJECTOR 4
200	REAR SCREEN DE-ICING
201	REAR RIGHT-HAND WINDOW MOTOR
202	REAR LEFT-HAND WINDOW MOTOR
203	DRIVER'S WINDOW MOTOR

LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
204	PASSENGER ELECTRIC WINDOW MOTOR
205	PRESSURE SWITCH
207	BRAKE FLUID MIN LEVEL SENSOR
211	REAR SCREEN WIPER MOTOR
212	WINDSCREEN WIPER MOTOR
213	FRONT COURTESY LIGHT
219	HEADLIGHT WASHER PUMP
225	DIAGNOSTIC SOCKET
226	RIGHT-HAND HEADLIGHT
227	LEFT-HAND HEADLIGHT
234	FAN ASSEMBLY RELAY
239	DRIVER'S ELECTRIC REAR-VIEW MIRROR
240	PASSENGER ELECTRIC REAR-VIEW MIRROR
242	DOWNSTREAM OXYGEN SENSOR
243	OIL LEVEL SENSOR
244	WATER INJECTION TEMPERATURE SENSOR
245	EXTERNAL TEMPERATURE SENSOR
247	INSTRUMENT PANEL
257	PREHEATING UNIT
260	PASSENGER COMPARTMENT FUSE BOX AND RELAY
261	RADIO
262	COOLING FAN AND AIR CONDITIONING
267	RIGHT REPEATER
268	LEFT REPEATER
272	INJECTION AIR TEMPERATURE SENSOR
299	RELAY CONTROL PLATE
300	REAR CROSSMEMBER COURTESY LIGHT
304	SUNROOF
317	SUNROOF CONTROL
319	AIR CONDITIONING CONTROL PANEL
321	AIR CONDITIONING FAN ASSEMBLY RESISTOR
331	CRUISE CONTROL SWITCH
333	DRIVER'S SEAT BELT SWITCH
365	RIGHT-HAND TWEETER SPEAKER
366	LEFT-HAND FRONT TWEETER SPEAKER
369	TURBO BEARING COOLANT PUMP
371	PETROL VAPOUR ABSORBER
394	ELECTRIC AERIAL
414	WATER IN DIESEL SENSOR
418	PASSENGER COMPARTMENT TEMPERATURE SENSOR FAN
419	AIR CONDITIONING CONTROL UNIT
420	MIXING FLAP
436	TURBO PRESSURE SOLENOID VALVE
438	BONNET SWITCH
442	AUTOSUPPLY ALARM SIREN
469	MONITOR CONTROL
475	RECYCLING MOTOR
485	MULTIFUNCTION SWITCH
492	CARPHONE CONTROL UNIT
537	LEFT HEADLIGHT CORRECTOR MOTOR
538	RIGHT HEADLIGHT CORRECTOR MOTOR
560	TAILGATE OPENING CONTROL
562	HEADLIGHT ADJUSTMENT CONTROL

LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
573	ELECTRIC COOLANT PUMP RELAY
597	ENGINE AND RELAY FUSE BOX
639	RAISED BRAKE LIGHT
645	PASSENGER COMPARTMENT COMPUTER
653	CLOCK/EXTERNAL TEMPERATURE/CARPHONE DISPLAY ASSEMBLY
662	NAVIGATION COMPUTER
675	CLUTCH PEDAL SWITCH
677	FRONT AND REAR BI-DIRECTIONAL WASHER PUMP
679	RADIO INTERFERENCE SUPPRESSOR
680	PREHEATER PLUG 1
681	PREHEATER PLUG 2
682	PREHEATER PLUG 3
683	PREHEATER PLUG 4
703	ELECTRIC WINDOW RELAY
710	UNIT FUSE
724	AUTOMATIC CLUTCH PUMP UNIT
746	CYLINDER SENSOR
754	HYDRAULIC ELECTRIC INTERFACE
755	TRACTION CONTROL SWITCH
756	AIR BAG/PRETENSIONER COMPUTER
762	GEARBOX PUMP ASSEMBLY RELAY
777	POWER SUPPLY FUSE BOARD
781	RELATIVE PRESSURE SENSOR (AUTOMATIC GEARBOX)
789	HANDS-FREE MOBILE PHONE MICROPHONE
798	DUAL MODE SOLENOID VALVE
799	INJECTION AIR FLOW METER
833	FUEL PUMP AND SENDER UNIT
844	FUEL FILLER FLAP LOCKING MOTOR
845	NO. 2 PASSENGER AIR BAG
851	TYRE PRESSURE COMPUTER
877	RH MIXER MOTOR
886	AERIAL AMPLIFIER
887	UPSTREAM OXYGEN SENSOR
898	ADDITIONAL HEATER PLUG
921	ACCELERATOR POTENTIOMETER
953	WHEEL SPEED COMPUTER
971	"DP0" AUTOMATIC GEARBOX MODULE
979	OIL VAPOUR RECIRCULATION HOSE REHEATER
989	DISCHARGE BULB COMPUTER
1013	VARIABLE CAMSHAFT
1014	ENGINE COOLING LOW SPEED FAN RESISTANCE
1017	AUTOMATIC TRANSMISSION TURBINE SPEED SENSOR
1019	EXCHANGER FLOW LOCK-UP SOLENOID VALVE
1023	AIR CONDITIONING FAN OUTPUT MODULE
1032	FUEL MANIFOLD PRESSURE SENSOR
1033	PROTECTED POSITIVE BATTERY
1042	CENTRAL DOOR LOCKING RELAY
1050	CLUTCH SOLENOID VALVE
1051	ENGAGEMENT SOLENOID VALVE 1
1052	ENGAGEMENT SOLENOID VALVE 2
1053	SELECTION SOLENOID VALVE 1
1054	SELECTION SOLENOID VALVE 2
1055	ENGAGEMENT POSITION SENSOR

LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
1056	SELECTION POSITION SENSOR
1057	CLUTCH POSITION SENSOR
1058	GEAR SELECTOR SWITCH
1059	SEQUENTIAL GEARBOX PRESSURE SENSOR
1060	GEARBOX INPUT SPEED SENSOR
1066	FUEL TEMPERATURE SENSOR
1067	ADDITIONAL HEATING RELAY 1
1068	ADDITIONAL HEATING RELAY 2
1071	TURBOCHARGING PRESSURE SENSOR
1072	ADDITIONAL HEATER PLUG 2
1073	ADDITIONAL HEATER PLUG 3
1074	ADDITIONAL HEATER PLUG 4
1076	MOTORISED THROTTLE BODY
1077	CYLINDER 1 PENCIL COIL
1078	CYLINDER 2 PENCIL COIL
1079	CYLINDER 3 PENCIL COIL
1080	CYLINDER 4 PENCIL COIL 4
1081	CRUISE CONTROL LIMITER START STOP CONTROL
1082	KEYLESS VEHICLE CARD READER
1083	KEYLESS VEHICLE FRONT RIGHT HANDLE PRESENCE DETECTOR
1084	KEYLESS VEHICLE FRONT LEFT HANDLE PRESENCE DETECTOR
1085	KEYLESS VEHICLE REAR RIGHT HANDLE PRESENCE DETECTOR
1086	KEYLESS VEHICLE REAR LEFT HANDLE PRESENCE DETECTOR
1087	KEYLESS VEHICLE ENGINE STOP/START CONTROL BUTTON
1088	STEERING COLUMN ELECTRIC LOCK
1094	ANTI-LOCK BRAKING SYSTEM AND/OR ELECTRONIC STABILITY PROGRAM COMPUTER
1095	FRONT DRIVER'S SIDE LAP PRETENSIONER
1096	PASSENGER FRONT LAP PRETENSIONER
1103	FRONT DRIVER'S SIDE CHEST AIR BAG
1104	FRONT PASSENGER'S SIDE CHEST AIR BAG
1105	FUEL FLOW ACTUATOR
1106	ESP ON/OFF BUTTON
1107	CLUSTER SENSOR (YAW AND ACCELERATION SPEED)
1109	MANUAL GEARBOX NEUTRAL SENSOR/REVERSING LIGHTS
1111	INSULATION SENSOR
1113	ADDITIONAL PASSENGER COMPARTMENT HEATING
1115	WEIGHT DISTRIBUTION MOTOR
1118	FRONT PASSENGER FOOTWELL LIGHT
1119	DRIVER'S FOOTWELL LIGHT
1130	DRIVER'S FRONT SEAT POSITION SENSOR
1156	PASSENGER COMPARTMENT FAN ASSEMBLY 1
1173	ADDITIONAL HEATING RELAY CONTROL COMPUTER
1198	RAIL PRESSURE REGULATOR
1202	COOLANT GAS PRESSURE SENSOR
1208	RADIO AERIAL
1218	PARKING AID LEFT-HAND REAR OUTER DETECTION SENSOR
1219	PARKING AID REAR OUTER DETECTION SENSOR
1220	PARKING AID REAR INNER DETECTION SENSOR
1221	PARKING AID LEFT-HAND REAR INNER DETECTION SENSOR
1222	PARKING AID COMPUTER
1223	PARKING AID BUZZER
1232	ELECTRIC POWER ASSISTED STEERING SYSTEM
1249	DRIVER'S ADAPTIVE FRONT AIR BAG

LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
1265	CAMSHAFT INLET SENSOR
1287	PARTICLE FILTER UPSTREAM TEMPERATURE SENSOR
1288	PARTICLE FILTER DOWNSTREAM TEMPERATURE SENSOR
1290	PARTICLE FILTER DIFFERENTIAL PRESSURE SENSOR
1301	EGR SOLENOID VALVE BYPASS SOLENOID VALVE
1322	TAILGATE LOCK
1337	SWITCHING PROTECTION UNIT
1372	REAR HEIGHT SENSOR
1373	FRONT HEIGHT SENSOR
1374	DRIVER'S DOOR HANDS-FREE CARD DETECTION AERIAL
1375	PASSENGER FRONT DOOR HANDS-FREE CARD DETECTION AERIAL
1376	DRIVER'S SIDE REAR DOOR HANDS-FREE CARD DETECTION AERIAL
1377	PASSENGER RR DOOR HANDS-FREE CARD DETECTION AERIAL
1378	TAILGATE HANDS-FREE CARD DETECTION AERIAL
1385	STEERING WHEEL WARNING CONTROL
1390	HEADLIGHT ADJUSTMENT RHEOSTAT SWITCH
1391	CENTRAL LOCKING / HAZARD WARNING LIGHTS SWITCH
1396	FRONT INTERIOR HANDS-FREE CARD DETECTION AERIAL
1397	REAR INTERIOR HANDS-FREE CARD DETECTION AERIAL
1398	CENTRAL INTERIOR HANDS-FREE CARD DETECTION AERIAL
1409	BOOT LID LOCKING MICRO SWITCH
1415	RAIN / LIGHT SENSOR
1440	PARKING AID SWITCH
1441	PASSENGER AIR BAG DISABLING KEY
1458	PILOT COOLANT THERMOSTAT
1460	MOTORISED EGR SOLENOID VALVE
1461	AIR INTAKE FLAP
1474	AIR TEMPERATURE/ATMOSPHERIC PRESSURE SENSOR
1475	TURBOCHARGER CONTROL SOLENOID VALVE
1511	DRIVER'S REAR TWIN ELECTRIC WINDOWS CONTROL
1512	DRIVER'S FRONT TWIN ELECTRIC WINDOWS CONTROL
1513	RIGHT-HAND HEATED SEAT CONTROL
1514	LEFT-HAND HEATED SEAT CONTROL
1519	UNDER STEERING WHEEL CONTROLS
1531	PASSENGER COMPARTMENT FUSE AND RELAY BOX 2
1534	THROTTLE VALVE MOTOR RELAY
1548	DRIVER'S ANTI-SUBMARINING AIRBAG (ANTI-SLIDE CUSHION)
1549	FRONT PASSENGER ANTI-SUBMARINING AIRBAG (ANTI-SLIDE CUSHION)
1550	ADDITIONAL HEATER UNIT INTERFACE
1589	TURBO UPSTREAM TEMPERATURE SENSOR
1597	DRIVER'S SIDE FRONT SPEAKER
1598	PASSENGER SIDE FRONT SPEAKER
1601	SEAT BELT WARNING MODULE
1603	VARIABLE CAMSHAFT INLET
1618	TRANSPONDER RING
1620	FRONT LEFT-HAND SIDE SATELLITE (IMPACT SENSOR)
1621	FRONT RIGHT-HAND SIDE SATELLITE (IMPACT SENSOR)
1623	LEFT-HAND SIDE CURTAIN AIRBAG
1624	RIGHT-HAND SIDE CURTAIN AIRBAG
1625	FRONT LEFT-HAND INERTIA REEL PRETENSIONER
1626	FRONT RIGHT-HAND INERTIA REEL PRETENSIONER
1627	REAR LEFT-HAND INERTIA REEL PRETENSIONER
1628	REAR RIGHT-HAND INERTIA REEL PRETENSIONER

LIST OF COMPONENTS

COMPONENT CODES	COMPONENT TITLES
1645	DRIVER'S SEAT BASE HEATING PANEL (SEAT)
1646	DRIVER'S SEATBACK HEATING PANEL (SEAT)
1647	PASSENGER SEAT BASE HEATING PANEL (SEAT)
1648	PASSENGER SEATBACK HEATING PANEL (SEAT)
1649	DRIVER'S HEATED SEAT SUPPLY RELAY
1650	PASSENGER HEATED SEAT SUPPLY RELAY
1683	OPTIONAL RELAY UNIT
1714	MULTIPLEX LINE INTERFACE UNIT (MULTIPLEXING)
1750	INJECTION SOLENOID VALVE AT EXHAUST
1765	CATALYTIC CONVERTER DOWNSTREAM TEMPERATURE SENSOR
1874	MULTIFUNCTION AERIAL
1877	MULTIMEDIA ACCESSORIES SOCKET
1959	MULTIMEDIA AUDIO SOCKET (C BOX)
7501	DEAD WIRE 1 TRACK