

@andrew

[Home](#) [Tags](#) [Archives](#)

22 MAR'15









Programming Arduino Pro Mini with USBasp V2.0

By Andrew Berezovskyi

UPD 2016-05-14: Arduino Nano with CH340 ships from Aliexpress for less than \$2 – I recommend you buy it instead (unless you know what you're doing).

Do you really need to pay \$25 for an Arduino? Many of my friends have the original Arduino and they work great, but I wanted to see how cheap I can go. Initially, I purchased the SunFounder Starter Kit and it worked 100% as advertised. Today we'll see if we can get a fully featured Arduino under \$5.

Recently, I came across the dirt cheap Arduino Pro Mini clones and decided to buy one to see if it works! I also got the clone of the USBasp programmer:

	<p>New Pro Mini atmega328 5V 16M Replace ATmega128 Arduino Compatible Nano (200957063666)</p> <p>Estimated delivery Mon, Feb 16 - Fri, Mar 06 Tracking number: 01113498556</p>	<p>\$   </p> <p>ITEM PRICE: US \$2.59</p>
	<p>USBASP USBISP AVR Programmer Adapter 10 Pin Cable USB ATMEGA8 ATMEGA128 Arduino (310506909410)</p> <p>Estimated delivery Mon, Feb 16 - Fri, Mar 06 Tracking number: 01113498556</p>	<p>\$   </p> <p>ITEM PRICE: US \$2.28</p>

Finally, I had some time during the semester break to

First, you'll need to solder the pins onto the Pro Mini. I wanted to save some space and soldered the side pins to the bottom side. As a result, the board doesn't fit into the breadboard perfectly. So if you intend to use it mostly in a breadboard, take this into consideration. Additionally, some pins are duplicated, so you might not need to solder some pins at all.

top view

ISP10 (USBasp)


Kabel

Adapter

ISP6 (Arduino)



After plugging the USBasp into the USB port, you should see the blinking LED (programmed into Pro Mini at the factory) and the VCC should output the correct voltage (3.3V or 5V, depending on your version of Pro Mini):



Without the load (Pro Mini), USBasp outputs proper 5.00V

Finally, the computer part (I use Ubuntu 14.04 LTS). If you use Windows, get the driver from the [USBasp page](#). Change the following settings in the Arduino IDE:

- Under **Tools > Programmer**, select USBasp.
- Under **Tools > Board**, select your version of

Arduino Pro or Pro Mini.

Finally, you need to update your udev rules, otherwise you'll run into permission issues (more rules in [Arch Wiki](#)):

```
$ cat /etc/udev/rules.d/41-avrdude.rules
# USBasp Programmer rules
http://www.fischl.de/usbasp/
SUBSYSTEMS=="usb", ATTRS{idVendor}=="16c0",
ATTRS{idProduct}=="05dc", GROUP="andrew",
MODE="0666"
```

Now, load a sample sketch under **File > Examples > 01. Basics > Blink** and then use *Upload Using Programmer*. If you don't see any errors, congratulations! You might still encounter a warning similar to this:

```
avrdude: warning: cannot set sck period.
please check for usbasp firmware update.
```

It can be resolved by reprogramming the programmer itself, as described in the article [How to Update the Firmware on a USBasp V2.0](#). You will need another programmer for this, however.

If you are excited to continue hacking, but still looking for some inspiration, check out these resources:

- <http://www.instructables.com/>
- <http://makezine.com/projects/>
- <http://hackaday.io/>
- <http://dangerousprototypes.com/>
- <https://courses.cit.cornell.edu/ee476/ideas/EE476.project.ideas.html>

- <http://habrahabr.ru/hub/arduino/> (in Russian)

posted at 20:02 · 2015

Arduino programming electronics embedded

Comments

Comments

Community

1 Login ▾

♥ Recommend

↗ Share

Sort by Best ▾

Join the discussion...



Tom • a year ago

Hi , if i use pins 11,12,13 to programing ,then i can't change PinMode() in my program , it't right what i think about it ?

^ | ▾ • Reply • Share ▸



aldentas MOD → Tom • a year ago

Hi Tom, programmer switches the mode of the Arduino through the RST pin (you can read more on this at <https://www.arduino.cc/en/Tuto...> and <https://github.com/rsbohn/Ardu...> When you disconnect the cabling and reboot the Arduino, your code can use all I/O pins. If you solder the board to something, you might encounter additional complications (during programming).

^ | ▾ • Reply • Share ▸

✉ Subscribe

ⓓ Add Disqus to your site Add Disqus Add

Powered by Pelican. Template by Nevan Scott · Feed