

Setup Guide – Night Climate Scheduling

MaxAir incorporates an ability to setup a single schedule to control zones within a defined temperature range. A typical use would be as a night time schedule to ensure that the temperature remained within a 'comfortable' range.



From the 'One Touch' menu select 'Night Climate'.

The image shows the 'Night Climate' setup screen. At the top, there's an orange header with a clock icon, the text 'Night Climate', and the time '14:08'. Below the header, there's a section with a checked checkbox 'Enable Schedule'. Underneath, there are seven radio buttons for days of the week: 'Sun' (checked), 'Mon', 'Tue', 'Wed', 'Thu', 'Fri', and 'Sat' (checked). Below the days, there are two time input fields: 'Start Time' with '20:00' and 'End Time' with '06:00', each with a clock icon to its right. Below the times, there's a section titled 'Select Zone/s' with two radio buttons: 'Downstairs' and 'Upstairs' (checked). Below 'Upstairs', there are two horizontal sliders. The first slider is for 'Minimum Temperature: 16°' and the second is for 'Maximum Temperature: 18°'. Both sliders have a blue-to-red gradient bar and a circular orange handle. Below the sliders, there's a radio button for 'HotWater'. At the bottom, there are two buttons: 'Cancel' (blue) and 'Submit' (orange). At the very bottom, a status bar shows 'Outside: 7° C' and a cloud icon with the text 'Clouds - scattered clouds'.

The Night Climate schedule screen will be presented, the example below shows:

- An enabled schedule
- Operates Saturday and Sunday
- Operated between 2000 hours and 0600 hours (next day)
- Controls the Upstairs Zone
- Activates the zone when the temperature is between 16° and 18°C

Once the schedule has been configured, click on the 'Submit' button to save.



If an enabled Night Climate schedule exists then the status indicator will change from blue to red.