



Function Group Spec
**Remote Start, Extend Remote Start and
Cancel Remote Start**
Custom Scope

| | | |
|----------------------------------|---------------------------------------------------------------------|--|
| Document Type | Function Specification | |
| Template Version | 6.0 | |
| SysML Report Template Version | O Beta (11/6/2019) | |
| Document ID | Cellular Remote Start, Extend Remote Start & Cancel Remote Start | |
| Document Location | | |
| Document Owner | Audriene Bell | |
| Document Revision | FGS0 | |
| Document Status | v1.0 | |
| Date Issued | 2020-05-28 | |
| Date Revised | 2020-05-28 | |
| Document Classification | GIS1 Item Number: 27.60/35 | |
| | GIS2 Classification: Confidential | |

| | | | |
|-------------------|------|--------------------|------|
| Document Approval | | | |
| Name | Role | Email Confirmation | Date |
| | | | |
| | | | |

Auto-Generated by MagicDraw
Printed Copies are Uncontrolled



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

DISCLAIMER

This document contains Ford Motor Company Confidential information. Disclosure of the information contained in any portion of this document is not permitted without the expressed, written consent of a duly authorized representative of Ford Motor Company, Dearborn, Michigan, U.S.A.

Copyright, © 2016 Ford Motor Company

This document contains information developed and accumulated by and for FORD MOTOR COMPANY. As such, it is a proprietary document, which, if disseminated to unauthorized persons, would provide others with restricted information, data, or procedures not otherwise available, exposing the FORD MOTOR COMPANY to potential harm.

Employees and suppliers having custody of this specification or authorized to use it must be cognizant of its proprietary nature and ensure that the information herein is not made available to unauthorized persons.

FORD MOTOR COMPANY reserves the right to protect this work as an unpublished copyrighted work in the event of an inadvertent or deliberate unauthorized publication. FORD MOTOR COMPANY also reserves its rights under copyright laws to protect this work as a published work.








This document or portions thereof shall not be distributed outside FORD MOTOR COMPANY without prior written consent. Refer all questions concerning disclosure to the author(s) or to any duly authorized representative of Ford Motor Company.



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

CONTENTS

| | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|----|
| Disclaimer..... | 2 |
| Contents..... | 3 |
| 1 Introduction..... | 7 |
| 1.1 Document Purpose..... | 7 |
| 1.2 Document Scope..... | 7 |
| 1.3 Document Audience | 7 |
| 1.3.1 Stakeholder List..... | 7 |
| 1.4 Document Organization..... | 7 |
| 1.4.1 Document Context | 7 |
| 1.4.2 Document Structure..... | 7 |
| 1.5 Document Conventions | 8 |
| 1.5.1 Requirements Templates | 8 |
| 2 Function Group Description..... | 9 |
| 3 Functional Architecture..... | 10 |
| 3.1 Description..... | 10 |
| 3.2 Function List..... | 10 |
| 3.3 Signal List..... | 12 |
| 3.4 Assumptions..... | 12 |
| 4 Function Specifications..... | 13 |
| 4.1  1. Initiate Remote Start | 13 |
| 4.1.1 Function Overview | 13 |
| 4.1.2 Function Scope..... | 13 |
| 4.1.3 Function Interfaces..... | 13 |
| 4.1.4 Function Modeling..... | 14 |
| 4.1.5 Function Requirements | 14 |
| 4.2  2. Send Remote Start Request to Vehicle..... | 15 |
| 4.2.1 Function Overview | 15 |
| 4.2.2 Function Scope..... | 16 |
| 4.2.3 Function Interfaces..... | 16 |
| 4.2.4 Function Modeling..... | 16 |
| 4.2.5 Function Requirements | 17 |
| 4.3  3. Receive Remote Start Request In-Vehicle..... | 18 |
| 4.3.1 Function Overview | 18 |
| 4.3.2 Function Scope..... | 18 |
| 4.3.3 Function Interfaces..... | 19 |
| 4.3.4 Function Modeling..... | 19 |
| 4.3.5 Function Requirements | 20 |
| 4.4  4. Process Remote Start Request & Send Status In-Vehicle..... | 21 |
| 4.4.1 Function Overview | 21 |
| 4.4.2 Function Scope..... | 21 |
| 4.4.3 Function Interfaces..... | 21 |
| 4.4.4 Function Modeling..... | 22 |
| 4.4.5 Function Requirements | 22 |
| 4.5  5. Process Remote Start Request Status In-Vehicle..... | 23 |
| 4.5.1 Function Overview | 23 |
| 4.5.2 Function Scope..... | 23 |
| 4.5.3 Function Interfaces..... | 24 |
| 4.5.4 Function Modeling..... | 24 |
| 4.5.5 Function Requirements | 24 |
| 4.6  6. Send Remote Start Status Off-Board..... | 25 |
| 4.6.1 Function Overview | 25 |
| 4.6.2 Function Scope..... | 25 |
| 4.6.3 Function Interfaces..... | 26 |
| 4.6.4 Function Modeling..... | 27 |
| 4.6.5 Function Requirements | 27 |
| 4.7  7. Send Remote Start Status to Requester..... | 28 |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | | |
|--------|------------------------------------------------------------------------|----|
| 4.7.1 | Function Overview | 28 |
| 4.7.2 | Function Scope..... | 29 |
| 4.7.3 | Function Interfaces..... | 29 |
| 4.7.4 | Function Modeling..... | 30 |
| 4.7.5 | Function Requirements | 31 |
| 4.8 | 8. Display Remote Request Status | 31 |
| 4.8.1 | Function Overview | 31 |
| 4.8.2 | Function Scope..... | 31 |
| 4.8.3 | Function Interfaces..... | 32 |
| 4.8.4 | Function Modeling..... | 33 |
| 4.8.5 | Function Requirements | 33 |
| 4.9 | 9. Initiate Cancel Remote Start..... | 34 |
| 4.9.1 | Function Overview | 34 |
| 4.9.2 | Function Scope..... | 34 |
| 4.9.3 | Function Interfaces..... | 34 |
| 4.9.4 | Function Modeling..... | 35 |
| 4.9.5 | Function Requirements | 35 |
| 4.10 | 10. Send Cancel Remote Start Request to Vehicle | 37 |
| 4.10.1 | Function Overview | 37 |
| 4.10.2 | Function Scope..... | 37 |
| 4.10.3 | Function Interfaces..... | 37 |
| 4.10.4 | Function Modeling..... | 38 |
| 4.10.5 | Function Requirements | 38 |
| 4.11 | 11. Receive Cancel Remote Start Request In-Vehicle..... | 39 |
| 4.11.1 | Function Overview | 39 |
| 4.11.2 | Function Scope..... | 39 |
| 4.11.3 | Function Interfaces..... | 40 |
| 4.11.4 | Function Modeling..... | 40 |
| 4.11.5 | Function Requirements | 40 |
| 4.12 | 12. Process Cancel Remote Start Request & Send Status In-Vehicle | 41 |
| 4.12.1 | Function Overview | 41 |
| 4.12.2 | Function Scope..... | 41 |
| 4.12.3 | Function Interfaces..... | 42 |
| 4.12.4 | Function Requirements | 42 |
| 4.13 | 13. Process Cancel Remote Start Request Status In-Vehicle..... | 43 |
| 4.13.1 | Function Overview | 43 |
| 4.13.2 | Function Scope..... | 43 |
| 4.13.3 | Function Interfaces..... | 43 |
| 4.13.4 | Function Modeling..... | 44 |
| 4.13.5 | Function Requirements | 44 |
| 4.14 | 14. Send Cancel Remote Start Status Off-Board | 45 |
| 4.14.1 | Function Overview | 45 |
| 4.14.2 | Function Scope..... | 45 |
| 4.14.3 | Function Interfaces..... | 45 |
| 4.14.4 | Function Modeling..... | 46 |
| 4.14.5 | Function Requirements | 47 |
| 4.15 | 15. Send Cancel Remote Start Status to Requester..... | 48 |
| 4.15.1 | Function Overview | 48 |
| 4.15.2 | Function Scope..... | 48 |
| 4.15.3 | Function Interfaces..... | 49 |
| 4.15.4 | Function Modeling..... | 50 |
| 4.15.5 | Function Requirements | 50 |
| 4.16 | 16. Display Cancel Remote Start Request Status | 51 |
| 4.16.1 | Function Overview | 51 |
| 4.16.2 | Function Scope..... | 52 |
| 4.16.3 | Function Interfaces..... | 52 |
| 4.16.4 | Function Modeling..... | 53 |
| 4.16.5 | Function Requirements | 53 |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | | |
|--------|------------------------------|----|
| 4.17 | 17. Extend Remote Start..... | 53 |
| 4.17.1 | Function Overview | 53 |
| 4.17.2 | Function Scope..... | 54 |
| 4.17.3 | Function Interfaces..... | 54 |
| 4.17.4 | Function Modeling..... | 54 |
| 4.17.5 | Function Requirements | 55 |
| 5 | Open Concerns..... | 57 |
| 6 | Revision History | 58 |
| 7 | Appendix..... | 59 |
| 7.1 | Data Dictionary | 59 |
| 7.1.1 | Technical Signals..... | 59 |
| 7.1.2 | Logical Signals | 60 |
| 7.1.3 | Logical Parameters | 60 |
| 7.1.4 | Encoding Types..... | 60 |
| 7.2 | Glossary | 60 |
| 7.2.1 | Definitions..... | 61 |
| 7.2.2 | References | 61 |

List of Figures

| | |
|-------------------------------------------------------------------------------------------------------------------------------------------|----|
| Figure 1: Feature Function View..... | 10 |
| Figure 2: Functional Decomposition..... | 12 |
| Figure 3: Activity Diagram of “Cellular Remote Start” calling “1. Initiate Remote Start” | 13 |
| Figure 4: 1. Initiate Remote Start..... | 14 |
| Figure 5: Activity Diagram of “Cellular Remote Start” calling “2. Send Remote Start Request to Vehicle” .. | 16 |
| Figure 6: 2. Send Remote Start Request to Vehicle..... | 17 |
| Figure 7: Activity Diagram of “Cellular Remote Start” calling “3. Receive Remote Start Request In-Vehicle” | 19 |
| Figure 8: 3. Receive Remote Start Request In-Vehicle..... | 19 |
| Figure 9: Activity Diagram of “Cellular Remote Start” calling “4. Process Remote Start Request & Send Status In-Vehicle” | 21 |
| Figure 10: 4. Process Remote Start Request & Send Status In-Vehicle..... | 22 |
| Figure 11: Activity Diagram of “Cellular Remote Start” calling “5. Process Remote Start Request Status In-Vehicle”..... | 23 |
| Figure 12: 5. Process Remote Start Request Status In-Vehicle..... | 24 |
| Figure 13: Activity Diagram of “Cellular Remote Start” calling “6. Send Remote Start Status Off-Board” ... | 26 |
| Figure 14: 6. Send Remote Start Status Off-Board..... | 27 |
| Figure 15: Activity Diagram of “Cellular Remote Start” calling “7. Send Remote Start Status to Requester” | 29 |
| Figure 16: 7. Send Remote Start Status to Requester..... | 30 |
| Figure 17: Activity Diagram of “Cellular Remote Start” calling “8. Display Remote Request Status”..... | 32 |
| Figure 18: 8. Display Remote Request Status | 33 |
| Figure 19: Activity Diagram of “Cellular Remote Start” calling “9. Initiate Cancel Remote Start”..... | 34 |
| Figure 20: 9. Initiate Cancel Remote Start..... | 35 |
| Figure 21: Activity Diagram of “Cellular Remote Start” calling “10. Send Cancel Remote Start Request to Vehicle”..... | 37 |
| Figure 22: 10. Send Cancel Remote Start Request to Vehicle..... | 38 |
| Figure 23: Activity Diagram of “Cellular Remote Start” calling “11. Receive Cancel Remote Start Request In-Vehicle”..... | 39 |
| Figure 24: 11. Receive Cancel Remote Start Request In-Vehicle..... | 40 |
| Figure 25: Activity Diagram of “Cellular Remote Start” calling “12. Process Cancel Remote Start Request & Send Status In-Vehicle” | 42 |
| Figure 26: 12. Process Cancel Remote Start Request & Send Status In-Vehicle..... | 42 |
| Figure 27: Activity Diagram of “Cellular Remote Start” calling “13. Process Cancel Remote Start Request Status In-Vehicle” | 43 |
| Figure 28: 13. Process Cancel Remote Start Request Status In-Vehicle..... | 44 |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | |
|-------------------------------------------------------------------------------------------------------------------------|----|
| Figure 29: Activity Diagram of "Cellular Remote Start" calling "14. Send Cancel Remote Start Status Off-Board" | 45 |
| Figure 30: 14. Send Cancel Remote Start Status Off-Board..... | 47 |
| Figure 31: Activity Diagram of "Cellular Remote Start" calling "15. Send Cancel Remote Start Status to Requester" | 49 |
| Figure 32: 15. Send Cancel Remote Start Status to Requester | 50 |
| Figure 33: Activity Diagram of "Cellular Remote Start" calling "16. Display Cancel Remote Start Request Status" | 52 |
| Figure 34: 16. Display Cancel Remote Start Request Status..... | 53 |
| Figure 35: Activity Diagram of "Cellular Remote Start" calling "17. Extend Remote Start" | 54 |
| Figure 36: 17. Extend Remote Start..... | 55 |

List of Tables

| | |
|---------------------------------------------------------------------------------------|-------------------------------------|
| Table 1: Functions described in this specification..... | 7 |
| Table 2: List of Logical Functions | 12 |
| Table 4: Open Concerns (<i>Not supported by MagicDraw report generation.</i>) | 57 |
| Table 5: Definitions used in this document | Error! Bookmark not defined. |
| Table 6: Ford internal Documents..... | 61 |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

1 INTRODUCTION

1.1 Document Purpose

The Function (Group) Specification (FS) specifies an individual function / a group of functions.

To get more information about the concept of feature, function and component level abstraction refer to the [Ford RE Wiki](#).

1.2 Document Scope

The following set of functions from the [Global Feature & Function List](#) is described in this specification.

| Function ID | Function Name | Owner | Reference |
|-------------|------------------------------------------------------------------|-------------------------|-----------|
| F003414 | Cellular Remote Start, Extend Remote Start & Cancel Remote Start | Audriene Bell, abell101 | |

Table 1: Functions described in this specification

1.3 Document Audience

The FS is authored by the owners of the individual functions. All Stakeholders, i.e., all people who have a valid interest in the functions and their behavior should read and, if possible, review the FS. It needs to be guaranteed, that all stakeholders have access to the currently valid version of the FS.

#Hint: The FS template has the IP Classification "Proprietary" by default. IP Classification "Confidential" might be required in some cases, e.g. by Ford Functional Safety.

1.3.1 Stakeholder List

For the latest list of the feature stakeholder and their roles & responsibilities refer to [<Put VSEM Link here>](#).

#Hint: Refer to [Ford RE Wiki – Stakeholder List](#) on how to create a stakeholder list. The stakeholder list should be stored in VSEM in the pseudo folder "General Data Artifacts" of the corresponding function.

1.4 Document Organization

1.4.1 Document Context

Refer to the [Specification Structure page](#) in the [Ford RE Wiki](#) to understand how the FS relates to other Ford Requirements Documents and Specifications.

1.4.2 Document Structure

The structure of this document is explained below:

- Section 1** – Introduction how to use this document including responsibilities and requisite documents. Explains the terminology. Gives a clarification of the definitions, concepts and abbreviations used in the document.
- Section 2** – Function Group Description. Gives an overview and the purpose of the function group.
- Section 3** – Functional Architecture: Specifies the overall functional architecture of the function group
- Section 4** – Function Specifications: Specifies the logical functions of the function group in detail
- Section 5** – List of Open Concerns
- Section 6** – Revision history including a list of new or modified requirements. The requirements in this document are tagged, and this section contains different types of tables listing all, new, or changed requirements by their title and page no.
- Section 7** – Appendix: Presenting additional data mainly in a tabular form, e.g., a data dictionary

#Hint: All sections are mandatory, unless explicitly marked by the tag "#Classification" as "optional" or as applicable e.g. to certain domains like "Functional Safety".



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

1.5 Document Conventions

1.5.1 Requirements Templates

Each requirement, use case or scenario in this specification shall follow the corresponding template given in the document template *Specification_Macros.dotm* at [RE Wiki - Specification Templates](#).

1.5.1.1 Identification of Requirements

1.5.1.2 Requirements Attributes

The templates provided by *Specification_Macros.dotm* define a list of attributes for each requirement. This helps to classify the requirement. The attributes are explained at [RE Wiki - Requirements Attributes](#).



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

2 FUNCTION GROUP DESCRIPTION

#Classification: Function Group only (remove section, if only a single Function is specified in this document)

#Hint: Provide an overview / a description of the Function Group

This Function Group consists of all functions identified in a custom scope with the MagicDraw project **Remote Start, Extend Remote Start and Cancel Remote Start Function Specification**.



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

3 FUNCTIONAL ARCHITECTURE

#Classification: Function Group only (remove section, if only a single Function is specified in this document)

#Hint: The Functional Architecture shall reflect the result of the functional decomposition for a given feature or parts of it.

Refer to the [RE Wiki – Functional Decomposition](#) for some guidance on how to decompose a feature into functions, i.e., how to find the right functional partitioning for the function level. The functions shown here are those, which are specified in section 4 “Function Specifications”.

3.1 Description

#Hint: Provide some informal description of the characteristics of the chosen architecture. Also give some graphical representation of the Functional Architecture. Either SysML Internal Block diagrams or Data Flow Diagrams could be used to depict such a Functional Architecture.

#Link: [SysML – Internal Block Diagrams](#) or [RE Wiki - Data Flow Diagrams](#)

The Cellular Remote Start, Extend Remote Start & Cancel Remote Start functionality is described in this document and is broken down by function. Each function defines a portion of the message structure and how a command is sent from the Mobile App to VSDN/TMC to ECG-App to BCM and the return command response structure. The feature function, Cellular Remote Start calls upon each sub-function described in the function list to detail how the user can manually start, extend or cancel their vehicle.




Figure 1: Feature Function View

3.2 Function List



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| Function ID | Function Name | Function Description | ASIL |
|-------------|-------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| F003370 | <u>Cellular Remote Start</u> <<Feature Function>> | Cellular Remote Start Feature Function | |
| Fn1 | <u>1. Initiate Remote Start</u> <<System Function>> | The Initiate Remote Start function is called when the user selects the Remote Start button on the Mobile App initiating the request | |
| Fn2 | <u>2. Send Remote Start Request to Vehicle</u> <<System Function>> | The Send Remote Start Request to Vehicle function is called when the VSDN/TMC receives the Remote Start request | |
| Fn3 | <u>3. Receive Remote Start Request In-Vehicle</u> <<System Function>> | The Receive Remote Start Request In-Vehicle function is called when the ECG-App receives the Remote Start request from the VSDN/TMC | |
| Fn4 | <u>4. Process Remote Start Request & Send Status In-Vehicle</u> <<System Function>> | The Receive & Process Remote Start Request In-Vehicle is called when the BCM receives the Remote Start request and determines if the conditions are correct to process the request | |
| Fn5 | <u>5. Process Remote Start Request Status In-Vehicle</u> <<System Function>> | The Process Remote Start Request Status In-Vehicle is called when the BCM sends the status to the ECG-App | |
| Fn6 | <u>6. Send Remote Start Status Off-Board</u> <<System Function>> | The Send Remote Start Status Off-Board function is called when the ECG-App receives the Remote Start status from the BCM | |
| Fn7 | <u>7. Send Remote Start Status to Requester</u> <<System Function>> | The Send Remote Start Status to Requester when the VSDN/TMC sends the Remote Start status to the Mobile App | |
| Fn8 | <u>8. Display Remote Request Status</u> <<System Function>> | The Display Remote Request Status function is called when the VSDN/TMC sends the Remote Start status to the Mobile App | |
| Fn9 | <u>9. Initiate Cancel Remote Start</u> <<System Function>> | The Initiate Cancel Remote Start function is called when the user selects the Cancel Remote Start button on the Mobile App initiating the request | |
| Fn10 | <u>10. Send Cancel Remote Start Request to Vehicle</u> <<System Function>> | The Send Cancel Remote Start Request to Vehicle function is called when the VSDN/TMC receives the Cancel Remote Start request | |
| Fn11 | <u>11. Receive Cancel Remote Start Request In-Vehicle</u> <<System Function>> | The Receive Cancel Remote Start Request In-Vehicle function is called when the ECG-App receives the Cancel Remote Start request from the VSDN/TMC | |
| Fn12 | <u>12. Process Cancel Remote Start Request & Send Status In-Vehicle</u> <<System Function>> | The Receive & Process Cancel Remote Start Request In-Vehicle is called when the BCM receives the Cancel Remote Start request and determines if the conditions are correct to process the request | |
| Fn13 | <u>13. Process Cancel Remote Start Request Status In-Vehicle</u> <<System Function>> | The Process Cancel Remote Start Request Status In-Vehicle is called when the BCM sends the status to the ECG-App | |
| Fn14 | <u>14. Send Cancel Remote Start Status Off-Board</u> <<System Function>> | The Send Cancel Remote Start Status Off-Board function is called when the ECG-App receives the Remote Start status from the BCM | |
| Fn15 | <u>15. Send Cancel Remote Start Status to Requester</u> <<System Function>> | The Send Cancel Remote Start Status to Requester when the VSDN/TMC sends the Cancel Remote Start status to the Mobile App | |
| Fn16 | <u>16. Display Cancel Remote Start Request Status</u> <<System Function>> | The Display Remote Request Status function is called when the VSDN/TMC sends the Cancel Remote Start status to the Mobile App | |
| SFn1 | <u>17. Extend Remote Start</u> <<Subsystem Function>> | After a successful Remote Start request, the user shall have the option to increase the engine on duration timer and extend the Remote Start timer | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

Table 2: List of Logical Functions




Figure 2: Functional Decomposition

3.3 Signal List

Refer to the [Data Dictionary](#) - [Logical Signals](#).

3.4 Assumptions

- The user has installed and created a valid login account for the FORD/LINCOLN owner mobile app
- The user has registered an eligible vehicle VIN (defined as a VIN which is known to have an ECG installed and has sent a provisioning message to the VSDN / TMC)
- The user has completed the authorization process for the eligible vehicle VIN
- Swapping the ECG shall not affect vehicle remote controls



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4 FUNCTION SPECIFICATIONS

4.1 1. Initiate Remote Start

4.1.1 Function Overview

4.1.1.1 Description

Function is allocated to:

- Mobile App <<Logical>>

The Initiate Remote Start function is called when the user selects the Remote Start button on the Mobile App initiating the request

4.1.2 Function Scope

The “1. Initiate Remote Start” function is called by the following functions:

- “Cellular Remote Start”




Figure 3: Activity Diagram of “Cellular Remote Start” calling “1. Initiate Remote Start”

4.1.3 Function Interfaces

4.1.3.1 Logical Inputs

| Signal Name | Description |
|--------------------|-------------------------------------------------------------------------------------|
| TriggerRemoteStart | Usage in Function: User selects button on the Mobile App to trigger Remote Start |

4.1.3.2 Logical Outputs

| Signal Name | Description |
|--------------------|-----------------------------------------------------------------------------------|
| CellRemoteStartAPI | Usage in Function: The Mobile App sends a Remote Start API request to VSDN/TMC |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.1.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.1.4 Function Modeling

4.1.4.1 State Charts / Activity Diagrams / Sequence Diagrams / Decision Tables




Figure 4: 1. Initiate Remote Start

4.1.5 Function Requirements

4.1.5.1 Functional Requirements

4.1.5.1.1 Normal Operation

R_FNC_RS_001 Initiate Remote Start

The mobile app shall display a dedicated Remote Start button on the screen. The user shall press and hold the Remote Start button on the mobile app to initiate the remote start process.

| Requirement ID: R_FNC_RS_001 | | | | |
|-------------------------------------------|--|------------|--------|--------------------|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | Owner | | |
| Source Req. | | V&V Method | | |
| Type | | Priority | Status | |
| Reg. Template Version 6.0 | | | | End of Requirement |

R_FNC_RS_002 Remote Start Button HMI

The Remote Start button will be animated clockwise with a white line around the perimeter while being held.

| Requirement ID: R_FNC_RS_002 | | | | |
|------------------------------|--|------------|--------|--|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | Owner | | |
| Source Req. | | V&V Method | | |
| Type | | Priority | Status | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_003 Gray Out Other Command Buttons

All other remote control buttons shall be grayed out and not selectable when remote start button pressed.

Requirement ID: R_FNC_RS_003

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_004 Remote Start Command Sent to the VSDN/TMC

The mobile app shall send the request to the VSDN/TMC

Requirement ID: R_FNC_RS_004

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

4.1.5.1.2 Error Handling

R_FNC_RS_005 Mobile App Timeout

The mobile app shall wait for 120 seconds to receive a response from VSDN/TMC

Requirement ID: R_FNC_RS_005

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

4.2 📱 2. Send Remote Start Request to Vehicle

4.2.1 Function Overview

4.2.1.1 Description

Function is allocated to:

- 📱 VSDN/TMC <<Logical>>

The Send Remote Start Request to Vehicle function is called when the VSDN/TMC receives the Remote Start request



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.2.2 Function Scope

The – “2. Send Remote Start Request to Vehicle” function is called by the following functions:

- – [“Cellular Remote Start”](#)




Figure 5: Activity Diagram of “Cellular Remote Start” calling “2. Send Remote Start Request to Vehicle”

4.2.3 Function Interfaces

4.2.3.1 Logical Inputs

| Signal Name | Description |
|--------------------|-----------------------------------------------------------------------------------|
| CellRemoteStartAPI | Usage in Function: The Mobile App sends a Remote Start API request to VSDN/TMC |

4.2.3.2 Logical Outputs

| Signal Name | Description |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CellRemoteStartCommand | Usage in Function: Command sent from VSDN/TMC to initiate a Remote Start Sent to: <ul style="list-style-type: none">• 3. Receive Remote Start Request In-Vehicle |

4.2.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.2.4 Function Modeling

4.2.4.1 Activity Diagrams



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)




Figure 6: 2. Send Remote Start Request to Vehicle

4.2.5 Function Requirements

4.2.5.1 Functional Requirements

4.2.5.1.1 Normal Operation

R_FNC_RS_006 Remote Start Command Sent to the Vehicle

The VSDN/TMC shall send the command to the vehicle

| | | | |
|-------------------------------------------|--|------------|--------------------|
| Requirement ID: R_FNC_RS_006 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | |
| Status | | | |
| Req. Template Version 6.0 | | | End of Requirement |

R_FNC_RS_007 SMS Message

If the vehicle is in LPR mode, an SMS message is sent to the vehicle to wake the necessary nodes and process the command

| | | | |
|-------------------------------------------|--|------------|--------------------|
| Requirement ID: R_FNC_RS_007 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | |
| Status | | | |
| Req. Template Version 6.0 | | | End of Requirement |

4.2.5.1.2 Error Handling



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

R_FNC_RS_0011 Backend Timeout

The Command shall time out after 90 seconds from the moment the backend sent the command to the vehicle. This should be configurable

Requirement ID: R_FNC_RS_0011

| | | | | |
|---------------------|--|----------|------------|--|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |

[Reg. Template](#) Version 6.0

End of Requirement

4.3 3. Receive Remote Start Request In-Vehicle

4.3.1 Function Overview

4.3.1.1 Description

Function is allocated to:

- ECG-App <<Logical>>

The Receive Remote Start Request In-Vehicle function is called when the ECG-App receives the Remote Start request from the VSDN/TMC


4.3.1.2 Glossary

See Appendix for Definitions and Abbreviations.

4.3.2 Function Scope

The “3. Receive Remote Start Request In-Vehicle” function is called by the following functions:

- “Cellular Remote Start”





Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

Figure 7: Activity Diagram of “Cellular Remote Start” calling “3. Receive Remote Start Request In-Vehicle”

4.3.3 Function Interfaces

4.3.3.1 Logical Inputs

| Signal Name | Description |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CellRemoteStartCommand | Usage in Function: Command sent from VSDN/TMC to initiate a Remote Start Received from: <ul style="list-style-type: none">• 2. Send Remote Start Request to Vehicle |

4.3.3.2 Logical Outputs

| Signal Name | Description |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| EventCounter | Usage in Function: Event counter for remote start requests from cellular remote device Sent to: <ul style="list-style-type: none">• 4. Process Remote Start Request & Send Status In-Vehicle |
| CellRemoteStart | Usage in Function: CAN signal sent from ECG-App to BCM to initiate a Remote Start request |
| CellRemoteStartCode_Req | Usage in Function: Network Security Rolling Code for ECG signal requests Sent to: <ul style="list-style-type: none">• 4. Process Remote Start Request & Send Status In-Vehicle |

4.3.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.3.4 Function Modeling

4.3.4.1 Activity Diagram




Figure 8: 3. Receive Remote Start Request In-Vehicle



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.3.5 Function Requirements

4.3.5.1 Functional Requirements

4.3.5.1.1 Normal Operation

R_FNC_RS_008 ECG-App Stores Roll Code When Ignition On

The ECG-App shall store in volatile memory while the ignition is on the roll code received from the BCM

| Requirement ID: R_FNC_RS_008 | | | | |
|-------------------------------|---------|----------|--------------------|--|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Reg. Template | Version | 6.0 | End of Requirement | |

R_FNC_RS_009 ECG-App Saves Roll Code While Ignition Off

The ECG-App shall store in non-volatile memory while the ignition is off the the last four roll codes received from the BCM

| Requirement ID: R_FNC_RS_009 | | | | |
|-------------------------------|---------|----------|--------------------|--|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Reg. Template | Version | 6.0 | End of Requirement | |

R_FNC_RS_0010 Process Command

The ECG-App shall process the command and send it to the BCM along with the roll code and event counter

| Requirement ID: R_FNC_RS_0010 | | | | |
|-------------------------------|---------|----------|--------------------|--|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Reg. Template | Version | 6.0 | End of Requirement | |

R_FNC_RS_0012 Event Counter

An event counter counts the number of times a digital signal changes. When the ECG receives a request, it shall increment the event counter. When the remote request is sent, the ECG shall transmit the signal to the BCM and the event counter is incremented by one

| Requirement ID: R_FNC_RS_0012 | | | | |
|-------------------------------|--|--|------------|--|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| Type | Priority | Status |
|-------------------------------------------|----------|--------------------|
| Reg. Template Version 6.0 | | End of Requirement |

4.4 4. Process Remote Start Request & Send Status In-Vehicle

4.4.1 Function Overview

4.4.1.1 Description

Function is allocated to:

- BCM <<Logical>>

The Receive & Process Remote Start Request In-Vehicle is called when the BCM receives the Remote Start request and determines if the conditions are correct to process the request

4.4.1.2 Glossary

See Appendix for Definitions and Abbreviations.

4.4.2 Function Scope

The “4. Process Remote Start Request & Send Status In-Vehicle” function is called by the following functions:

- “Cellular Remote Start”




Figure 9: Activity Diagram of “Cellular Remote Start” calling “4. Process Remote Start Request & Send Status In-Vehicle”

4.4.3 Function Interfaces

4.4.3.1 Logical Inputs

| Signal Name | Description |
|-----------------|----------------------------------------------------------------------------------------------|
| CellRemoteStart | Usage in Function: CAN signal sent from ECG-App to BCM to initiate a Remote Start request |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

Received from:

-  [3. Receive Remote Start Request In-Vehicle](#)

4.4.3.2 Logical Outputs

No Logical Outputs specified.

4.4.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.4.4 Function Modeling

4.4.4.1 Activity Diagram




Figure 10: 4. Process Remote Start Request & Send Status In-Vehicle

4.4.5 Function Requirements

4.4.5.1 Functional Requirements

4.4.5.1.1 Normal Operation

R_FNC_RS_0013 Rolling Code

The CAN signal for the rolling code is transmitted to the BCM at a Remote Start request. The CAN signal for rolling code values transmitted by the BCM every one second in ignition on is RollCodeUnlock. The ECG monitors and stores the rolling code in non-volatile memory when the ignition is turned off. When a request to lock the doors is received, the ECG will transmit the rolling code stored in memory to the BCM only if it has been requested from VSDN / TMC. The BCM will then determine if the rolling code matches one of the last four codes that it published

| Requirement ID: R_FNC_RS_0013 | | | |
|-------------------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Reg. Template](#) Version 6.0

End of Requirement



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.4.5.1.2 Error Handling

R_FNC_RS_0014 Rolling Code Incorrect

If the roll code sent from the ECG-App to the BCM is incorrect, the request shall be rejected

| | | | |
|-------------------------------|--|--------------------|--|
| Requirement ID: R_FNC_RS_0014 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Status | |
| Priority | | | |
| Reg. Template Version 6.0 | | End of Requirement | |

4.5 5. Process Remote Start Request Status In-Vehicle

4.5.1 Function Overview

4.5.1.1 Description

Function is allocated to:

- BCM <<Logical>>

The Process Remote Start Request Status In-Vehicle is called when the BCM sends the status to the ECG-App

4.5.2 Function Scope

The “5. Process Remote Start Request Status In-Vehicle” function is called by the following functions:

- “Cellular Remote Start”




Figure 11: Activity Diagram of “Cellular Remote Start” calling “5. Process Remote Start Request Status In-Vehicle”



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.5.3 Function Interfaces

4.5.3.1 Logical Inputs

No Logical Inputs specified.

4.5.3.2 Logical Outputs

| Signal Name | Description |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteStartTimeRemaining_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires Sent to: <ul style="list-style-type: none">6. Send Remote Start Status Off-Board |
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Sent to: <ul style="list-style-type: none">6. Send Remote Start Status Off-Board |

4.5.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.5.4 Function Modeling

4.5.4.1 State Charts / Activity Diagrams / Sequence Diagrams / Decision Tables




Figure 12: 5. Process Remote Start Request Status In-Vehicle

4.5.5 Function Requirements

4.5.5.1 Functional Requirements

4.5.5.1.1 Normal Operation

R_FNC_RS_0015 Duration Timer Sent With Response

The BCM shall send the duration timer in its response to the ECG-App

| | |
|-------------------------------|--|
| Requirement ID: R_FNC_RS_0015 | |
| Rationale | |
| Acceptance Criteria | |
| Notes | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | | | |
|-------------------------------------------|----------|------------|--------------------|
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Req. Template Version 6.0 | | | End of Requirement |

R_FNC_RS_0016 BCM Sends Status of Command to ECG-App

The BCM shall send the status of the command to the ECG-App

| | | | |
|-------------------------------------------|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0016 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Req. Template Version 6.0 | | | End of Requirement |

R_FNC_RS_0017 BCM Sends Status of Engine to ECG-App

The BCM shall send the status of the engine once started to the ECG-App

| | | | |
|-------------------------------------------|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0017 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Req. Template Version 6.0 | | | End of Requirement |

4.6 6. Send Remote Start Status Off-Board

4.6.1 Function Overview

4.6.1.1 Description

Function is allocated to:

-  ECG-App <<Logical>>

The Send Remote Start Status Off-Board function is called when the ECG-App receives the Remote Start status from the BCM

4.6.2 Function Scope

The  – “6. Send Remote Start Status Off-Board” function is called by the following functions:

-  – “[Cellular Remote Start](#)”



4.6.3.1 Logical Inputs

4.6.3.2 Logical Outputs

Document Owner: Audriene Bell, abell101 Document ID: Cellular Remote Start, Extend Remote Start & Cancel Remote Start Function Spec
GIS1 Item Number: 27.60/35 Date Issued: 2020-05-28
GIS2 Classification: Confidential Page 26 of 62 Last Revised: 2020-05-28



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.6.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.6.4 Function Modeling

4.6.4.1 Activity Diagram




Figure 14: 6. Send Remote Start Status Off-Board

4.6.5 Function Requirements

4.6.5.1 Functional Requirements

4.6.5.1.1 Normal Operation

R_FNC_RS_0019 ECG-App Sends Status to VSDN/TMC

The ECG-App shall send the status of the command response and alert to VSDN/TMC

| Requirement ID: R_FNC_RS_0019 | | | |
|-------------------------------|----------|--------------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Reg. Template Version 6.0 | | End of Requirement | |

4.6.5.1.2 Error Handling

R_FNC_RS_0018 Retry Strategy

When the ECG-App sends the Remote Start/Cancel Remote Start request to the BCM, the ECG-App shall wait for 4 seconds (configurable time) to receive a response. If a response is not received within 4 seconds, the ECG-App shall send the request twice more



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

Requirement ID: R_FNC_RS_0018

| | | | |
|----------------------------|--|-----------------------|---------------|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |

[Req. Template](#) Version 6.0

End of Requirement

4.6.5.2 Non-Functional Requirements

R_FNC_RS_0020 BCM Response Time

The BCM shall process the request within 4 seconds

Requirement ID: R_FNC_RS_0020

| | | | |
|----------------------------|--|-----------------------|---------------|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_0021 Retry Due to No Response from BCM

If the BCM does not process the request within 4 seconds, the ECG shall retry sending the request 2 more times

Requirement ID: R_FNC_RS_0021

| | | | |
|----------------------------|--|-----------------------|---------------|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |

[Req. Template](#) Version 6.0

End of Requirement

4.7 7. Send Remote Start Status to Requester

4.7.1 Function Overview

4.7.1.1 Description

Function is allocated to:

-  VSDN/TMC <<Logical>>

The Send Remote Start Status to Requester when the VSDN/TMC sends the Remote Start status to the Mobile App

4.7.1.2 Glossary

See Appendix for Definitions and Abbreviations.



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.7.2 Function Scope

The – “7. Send Remote Start Status to Requester” function is called by the following functions:

- – “[Cellular Remote Start](#)”




Figure 15: Activity Diagram of “Cellular Remote Start” calling “7. Send Remote Start Status to Requester”

4.7.3 Function Interfaces

4.7.3.1 Logical Inputs

| Signal Name | Description |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Received from: <ul style="list-style-type: none">• 6. Send Remote Start Status Off-Board |
| RemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Remote Start Received from: <ul style="list-style-type: none">• 6. Send Remote Start Status Off-Board |
| RemoteStartTimeRemaining_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires Received from: <ul style="list-style-type: none">• 6. Send Remote Start Status Off-Board |

4.7.3.2 Logical Outputs

| Signal Name | Description |
|--------------------|-------------------------------------------------------------------------------------------------------------|
| RemoteStartAlert() | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Remote Start Sent to: |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | <ul style="list-style-type: none">8. Display Remote Request Status |
| RemoteDeviceFeedback_St() | Usage in Function: Remote start status Sent to: <ul style="list-style-type: none">8. Display Remote Request Status |
| RemoteStartTimeRemaining_St() | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires Sent to: <ul style="list-style-type: none">8. Display Remote Request Status |

4.7.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.7.4 Function Modeling

4.7.4.1 Activity Diagram




Figure 16: 7. Send Remote Start Status to Requester



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

4.7.5 Function Requirements

4.7.5.1 Functional Requirements

4.7.5.1.1 Normal Operation

R_FNC_RS_0022 Remote Start Alert

If the vehicle engine is started, the vehicle shall send an alert to the VSDN/TMC

| | | | |
|-------------------------------------------|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0022 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Reg. Template Version 6.0 | | | End of Requirement |

R_FNC_RS_0023 VSDN/TMC Sends Remote Start Status to Mobile App

VSDN/TMC shall send the status of the mobile app to indicate to the user that the vehicle has successfully remote started

| | | | |
|-------------------------------------------|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0023 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Reg. Template Version 6.0 | | | End of Requirement |

4.8 8. Display Remote Request Status

4.8.1 Function Overview

4.8.1.1 Description

Function is allocated to:

-  Mobile App <<Logical>>

The Display Remote Request Status function is called when the VSDN/TMC sends the Remote Start status to the Mobile App

4.8.2 Function Scope

The  – “8. Display Remote Request Status” function is called by the following functions:

-  – [“Cellular Remote Start”](#)



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)




Figure 17: Activity Diagram of “Cellular Remote Start” calling “8. Display Remote Request Status”

4.8.3 Function Interfaces

4.8.3.1 Logical Inputs

| Signal Name | Description |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Received from: <ul style="list-style-type: none">7. Send Remote Start Status to Requester |
| RemoteStartTimeRemaining_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires Received from: <ul style="list-style-type: none">7. Send Remote Start Status to Requester |
| RemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Remote Start Received from: <ul style="list-style-type: none">7. Send Remote Start Status to Requester |

4.8.3.2 Logical Outputs

| Signal Name | Description |
|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Output | Usage in Function: Mobile App messages displayed to the user |
| RemoteStartTimeRemaining_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires Sent to: <ul style="list-style-type: none">17. Extend Remote Start |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.8.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.8.4 Function Modeling

4.8.4.1 Activity Diagram




Figure 18: 8. Display Remote Request Status

4.8.5 Function Requirements

4.8.5.1 Functional Requirements

R_FNC_RS_0027 Countdown Timer & Button Transformation

The mobile app Start button shall change to Cancel, the extend button shall visible and the duration timer shall be shown

| | | | |
|-------------------------------------------|--|--------------------|--------|
| Requirement ID: R_FNC_RS_0027 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |
| Req. Template Version 6.0 | | End of Requirement | |

R_FNC_RS_0028 Success Message

The mobile app will display a success message when the Remote Start or Cancel Remote Start request is successful

| | | | |
|-------------------------------------------|--|--------------------|--------|
| Requirement ID: R_FNC_RS_0028 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |
| Req. Template Version 6.0 | | End of Requirement | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.9 9. Initiate Cancel Remote Start

4.9.1 Function Overview

4.9.1.1 Description

Function is allocated to:

- Mobile App <<Logical>>

The Initiate Cancel Remote Start function is called when the user selects the Cancel Remote Start button on the Mobile App initiating the request

4.9.2 Function Scope

The “9. Initiate Cancel Remote Start” function is called by the following functions:

- “Cellular Remote Start”




Figure 19: Activity Diagram of “Cellular Remote Start” calling “9. Initiate Cancel Remote Start”

4.9.3 Function Interfaces

4.9.3.1 Logical Inputs


| Signal Name | Description |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TriggerRemoteStart | Usage in Function: User selects button on the Mobile App |
| TriggerCancelRemoteStart | Usage in Function: User selects button on the Mobile App to trigger Cancel Remote Start Received from: <ul style="list-style-type: none">Activity Parameter Node: Input() |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.9.3.2 Logical Outputs

| Signal Name | Description |
|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CellRemoteStartAPI | Usage in Function: The Mobile App sends a Remote Start API request to VSDN/TMC |
| CancelCellRemoteStartAPI | Usage in Function: The Mobile App sends a Cancel Remote Start API request to VSDN/TMC Sent to: <ul style="list-style-type: none"> 10. Send Cancel Remote Start Request to Vehicle |

4.9.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.9.4 Function Modeling

4.9.4.1 Activity Diagram




Figure 20: 9. Initiate Cancel Remote Start

4.9.5 Function Requirements

4.9.5.1 Functional Requirements

4.9.5.1.1 Normal Operation

R_FNC_RS_0029 Cancel Remote Start Pre-Condition

The vehicle should be started remotely in order to send a Cancel Remote Start request

| | | | |
|-------------------------------------------|----------|--------------------|--|
| Requirement ID: R_FNC_RS_0029 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Req. Template Version 6.0 | | End of Requirement | |

R_FNC_RS_0030 Countdown Timer Expiry



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

The Remote Start shall be canceled by allowing the duration timer to expire

Requirement ID: R_FNC_RS_0030

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_0031 Initiate Cancel Remote Start

The user shall press and hold the Cancel Remote Start button on the mobile app to initiate the cancel remote start process

Requirement ID: R_FNC_RS_0031

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_0032 Cancel Remote Start Request Sent to VSDN/TMC

The mobile app shall send the Cancel Remote Start request to the VSDN/TMC

Requirement ID: R_FNC_RS_0032

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

4.9.5.1.2 Error Handling

R_FNC_RS_005 Mobile App Timeout

The mobile app shall wait for 120 seconds to receive a response from VSDN/TMC

Requirement ID: R_FNC_RS_005

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.10 10. Send Cancel Remote Start Request to Vehicle

4.10.1 Function Overview

4.10.1.1 Description

Function is allocated to:

- VSDN/TMC <<Logical>>

The Send Cancel Remote Start Request to Vehicle function is called when the VSDN/TMC receives the Cancel Remote Start request

4.10.2 Function Scope

The “10. Send Cancel Remote Start Request to Vehicle” function is called by the following functions:

- “Cellular Remote Start”




Figure 21: Activity Diagram of “Cellular Remote Start” calling “10. Send Cancel Remote Start Request to Vehicle”

4.10.3 Function Interfaces

4.10.3.1 Logical Inputs

| Signal Name | Description |
|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CancelCellRemoteStartAPI | Usage in Function: The Mobile App sends a Cancel Remote Start API request to VSDN/TMC Received from: <ul style="list-style-type: none">9. Initiate Cancel Remote Start |

4.10.3.2 Logical Outputs

| Signal Name | Description |
|-------------|-------------|
|-------------|-------------|



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CancelCellRemoteStartCommand | Usage in Function: Command sent from VSDN/TMC to initiate Cancel Remote Start Sent to: <ul style="list-style-type: none">11. Receive Cancel Remote Start Request In-Vehicle |
| CellRemoteStartCommand | Usage in Function: Command sent from VSDN/TMC to initiate a Remote Start |

4.10.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.10.4 Function Modeling

4.10.4.1 Activity Diagram




Figure 22: 10. Send Cancel Remote Start Request to Vehicle

4.10.5 Function Requirements

4.10.5.1 Functional Requirements

4.10.5.1.1 Normal Operation

R_FNC_RS_0033 Cancel Remote Start Command Sent to Vehicle

The VSDN/TMC shall send the command to the vehicle

| | | | |
|-------------------------------|----------|--------------------|--|
| Requirement ID: R_FNC_RS_0033 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Reg. Template Version 6.0 | | End of Requirement | |

R_FNC_RS_0034 Backend Timeout for Cancel Command



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

The Cancel Command shall time out after 90 seconds from the moment the backend sent the command to the vehicle. This should be configurable

| | | | |
|-------------------------------|--|--------------------|--------|
| Requirement ID: R_FNC_RS_0034 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |
| Reg. Template Version 6.0 | | End of Requirement | |

4.11 11. Receive Cancel Remote Start Request In-Vehicle

4.11.1 Function Overview

4.11.1.1 Description

Function is allocated to:

- ECG-App <<Logical>>

The Receive Cancel Remote Start Request In-Vehicle function is called when the ECG-App receives the Cancel Remote Start request from the VSDN/TMC

4.11.2 Function Scope

The “11. Receive Cancel Remote Start Request In-Vehicle” function is called by the following functions:

- “Cellular Remote Start”




Figure 23: Activity Diagram of “Cellular Remote Start” calling “11. Receive Cancel Remote Start Request In-Vehicle”




Function Specification


Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

4.11.3 Function Interfaces

4.11.3.1 Logical Inputs

| Signal Name | Description |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CancelCellRemoteStartCommand | Usage in Function: Command sent from VSDN/TMC to initiate Cancel Remote Start Received from: <ul style="list-style-type: none">•  10. Send Cancel Remote Start Request to Vehicle |

4.11.3.2 Logical Outputs

| Signal Name | Description |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CancelCellRemoteStart | Usage in Function: CAN signal sent from the ECG-App to the BCM to cancel remote start Sent to: <ul style="list-style-type: none">•  12. Process Cancel Remote Start Request & Send Status In-Vehicle |

4.11.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.11.4 Function Modeling

4.11.4.1 Activity Diagram



Figure 24: 11. Receive Cancel Remote Start Request In-Vehicle

4.11.5 Function Requirements

4.11.5.1 Functional Requirements

4.11.5.1.1 Normal Operation

R_FNC_RS_0036 Process Cancel Command

The ECG-App shall process the command and send it to the BCM along with the roll code and event counter

| | | | |
|-------------------------------|--|------------|--|
| Requirement ID: R_FNC_RS_0036 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| Type | Priority | Status |
|-------------------------------------------|----------|--------------------|
| Reg. Template Version 6.0 | | End of Requirement |

R_FNC_RS_0037 Event Counter: Cancel Remote Start

An event counter counts the number of times a digital signal changes. When the ECG receives a request, it shall increment the event counter. When the remote request is sent, the ECG shall transmit the signal to the BCM and the event counter is incremented by one

| | | | |
|-------------------------------------------|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0037 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |
| Reg. Template Version 6.0 | | | End of Requirement |

4.12 12. Process Cancel Remote Start Request & Send Status In-Vehicle

4.12.1 Function Overview

4.12.1.1 Description

Function is allocated to:


- BCM <<Logical>>

The Receive & Process Cancel Remote Start Request In-Vehicle is called when the BCM receives the Cancel Remote Start request and determines if the conditions are correct to process the request

4.12.2 Function Scope

The “12. Process Cancel Remote Start Request & Send Status In-Vehicle” function is called by the following functions:

- “Cellular Remote Start”





Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

Figure 25: Activity Diagram of “Cellular Remote Start” calling “12. Process Cancel Remote Start Request & Send Status In-Vehicle”

4.12.3 Function Interfaces

4.12.3.1 Logical Inputs

| Signal Name | Description |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CancelCellRemoteStart | Usage in Function: CAN signal sent from the ECG-App to the BCM to cancel remote start Received from: <ul style="list-style-type: none">11. Receive Cancel Remote Start Request In-Vehicle |

4.12.3.2 Logical Outputs

No Logical Outputs specified.

4.12.3.3 Activity Diagram



Figure 26: 12. Process Cancel Remote Start Request & Send Status In-Vehicle

4.12.4 Function Requirements

4.12.4.1 Functional Requirements

4.12.4.1.1 Normal Operation

R_FNC_RS_0038 BCM Receives Cancel Request from ECG-App

The BCM shall determine if conditions are correct to process the cancel request

| | | | | |
|----------------------------------------------|--|------------|--|--------|
| Requirement ID: R_FNC_RS_0038 | | | | |
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | Owner | | |
| Source Req. | | V&V Method | | |
| Type | | Priority | | Status |
| Reg. Template Version 6.0 End of Requirement | | | | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.13 13. Process Cancel Remote Start Request Status In-Vehicle

4.13.1 Function Overview

4.13.1.1 Description

Function is allocated to:

- BCM <<Logical>>

The Process Cancel Remote Start Request Status In-Vehicle is called when the BCM sends the status to the ECG-App

4.13.2 Function Scope

The “13. Process Cancel Remote Start Request Status In-Vehicle” function is called by the following functions:

- “Cellular Remote Start”




Figure 27: Activity Diagram of “Cellular Remote Start” calling “13. Process Cancel Remote Start Request Status In-Vehicle”

4.13.3 Function Interfaces

4.13.3.1 Logical Inputs

No Logical Inputs specified.

4.13.3.2 Logical Outputs

| Signal Name | Description |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteStartTimeRemainin g_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires Sent to: <ul style="list-style-type: none">14. Send Cancel Remote Start Status Off-Board |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteDeviceFeedback_Stat | Usage in Function: Remote start status Sent to: <ul style="list-style-type: none">14. Send Cancel Remote Start Status Off-Board |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|

4.13.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.13.4 Function Modeling

4.13.4.1 Activity Diagram




Figure 28: 13. Process Cancel Remote Start Request Status In-Vehicle

4.13.5 Function Requirements

4.13.5.1 Functional Requirements

4.13.5.1.1 Normal Operation

R_FNC_RS_0039 BCM Sends Status of Cancel Command to ECG-App

The BCM shall send the status of the cancel command to the ECG-App

| | | | | |
|-------------------------------------------|--|------------|--|--------------------|
| Requirement ID: R_FNC_RS_0039 | | | | |
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | Owner | | |
| Source Req. | | V&V Method | | |
| Type | | Priority | | Status |
| Reg. Template Version 6.0 | | | | End of Requirement |

R_FNC_RS_0040 BCM Sends Engine Off Status to ECG-App

The BCM shall send the status of the engine once started to the ECG-App

| | | | | |
|-------------------------------|--|------------|--|--------|
| Requirement ID: R_FNC_RS_0040 | | | | |
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | Owner | | |
| Source Req. | | V&V Method | | |
| Type | | Priority | | Status |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

Req. Template Version 6.0

End of Requirement

4.14 14. Send Cancel Remote Start Status Off-Board

4.14.1 Function Overview

4.14.1.1 Description

Function is allocated to:

- ECG-App <<Logical>>

The Send Cancel Remote Start Status Off-Board function is called when the ECG-App receives the Remote Start status from the BCM

4.14.2 Function Scope

The “14. Send Cancel Remote Start Status Off-Board” function is called by the following functions:

- “Cellular Remote Start”




Figure 29: Activity Diagram of “Cellular Remote Start” calling “14. Send Cancel Remote Start Status Off-Board”

4.14.3 Function Interfaces

4.14.3.1 Logical Inputs

| Signal Name | Description |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteStartTimeRemainin g_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires Received from: <ul style="list-style-type: none">13. Process Cancel Remote Start Request Status In-Vehicle |
| RemoteDeviceFeedback | Usage in Function: Remote start status |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteStartTimeRemaining | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires |
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Received from: <ul style="list-style-type: none">📄 13. Process Cancel Remote Start Request Status In-Vehicle |

4.14.3.2 Logical Outputs

| Signal Name | Description |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteStartTimeRemaining_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires |
| RemoteDeviceFeedback_St | |
| RemoteStartAlert | |
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Sent to: <ul style="list-style-type: none">📄 15. Send Cancel Remote Start Status to Requester |
| CancelRemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Cancel Remote Start Sent to: <ul style="list-style-type: none">📄 15. Send Cancel Remote Start Status to Requester |

4.14.3.3 Logical Parameters


Not supported by MagicDraw report generation.

4.14.4 Function Modeling

4.14.4.1 Use Cases

Not supported by MagicDraw report generation.

4.14.4.2 Activity Diagram





Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

Figure 30: 14. Send Cancel Remote Start Status Off-Board

4.14.5 Function Requirements

4.14.5.1 Functional Requirements

R_FNC_RS_0041 Send Cancel Remote Start Status Off-Board

The status of the request shall be sent from the vehicle to VSDN/TMC

| | | | | |
|-------------------------------------------|--|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0041 | | | | |
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Req. Template Version 6.0 | | | | End of Requirement |

4.14.5.1.1 Error Handling

R_FNC_RS_0018 Retry Strategy

When the ECG-App sends the Remote Start/Cancel Remote Start request to the BCM, the ECG-App shall wait for 4 seconds (configurable time) to receive a response. If a response is not received within 4 seconds, the ECG-App shall send the request twice more

| | | | | |
|-------------------------------------------|--|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0018 | | | | |
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Req. Template Version 6.0 | | | | End of Requirement |

R_FNC_RS_0042 Retry Due to No Response from BCM - Cancel Request

If the BCM does not process the request within 4 seconds, the ECG shall retry sending the request 2 more times

| | | | | |
|-------------------------------------------|--|----------|------------|--------------------|
| Requirement ID: R_FNC_RS_0042 | | | | |
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Req. Template Version 6.0 | | | | End of Requirement |

R_FNC_RS_0043 Retry Strategy for Cancel Request

When the ECG-App sends the Remote Start/Cancel Remote Start request to the BCM, the ECG-App shall wait for 4 seconds (configurable time) to receive a response. If a response is not received within 4 seconds, the ECG-App shall send the request twice more

| | | | | |
|-------------------------------|--|--|--|--|
| Requirement ID: R_FNC_RS_0043 | | | | |
|-------------------------------|--|--|--|--|



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | | | |
|-------------------------------------------|--|------------|--------------------|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |
| Reg. Template Version 6.0 | | | End of Requirement |

R_FNC_RS_0044 Cancel Remote Start Failure - Timer Non Zero Value

If the timer value is greater than zero, then the vehicle engine has not stopped and an error message shall be displayed on the Mobile App


| | | | |
|-------------------------------------------|--|------------|--------------------|
| Requirement ID: R_FNC_RS_0044 | | | |
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | | Priority | Status |
| Reg. Template Version 6.0 | | | End of Requirement |

4.15 15. Send Cancel Remote Start Status to Requester

4.15.1 Function Overview

4.15.1.1 Description

Function is allocated to:

-  VSDN/TMC <<Logical>>

The Send Cancel Remote Start Status to Requester when the VSDN/TMC sends the Cancel Remote Start status to the Mobile App

4.15.1.2 Glossary

See Appendix for Definitions and Abbreviations.

4.15.2 Function Scope

The  – “15. Send Cancel Remote Start Status to Requester” function is called by the following functions:

-  – “[Cellular Remote Start](#)”



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)




Figure 31: Activity Diagram of “Cellular Remote Start” calling “15. Send Cancel Remote Start Status to Requester”

4.15.3 Function Interfaces

4.15.3.1 Logical Inputs

| Signal Name | Description |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RemoteDeviceFeedback_St | Usage in Function: Remote start status |
| CancelRemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Cancel Remote Start Received from: <ul style="list-style-type: none">14. Send Cancel Remote Start Status Off-Board |
| RemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Remote Start |
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Received from: <ul style="list-style-type: none">14. Send Cancel Remote Start Status Off-Board |
| RemoteStartTimeRemaining_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires |



4.15.3.2 Logical Outputs

| Signal Name | Description |
|-------------------------|--------------------------------------------------------------------------------------------------------------------|
| RemoteDeviceFeedback_St | Usage in Function: Remote start status |
| CancelRemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Cancel Remote Start Sent to: |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

| | |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | <ul style="list-style-type: none">•  <u>16. Display Cancel Remote Start Request Status</u> |
| RemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Remote Start |
| RemoteStartTimeRemaining_St | Usage in Function: Countdown timer representing time in seconds remaining until Remote Start expires |
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Sent to: <ul style="list-style-type: none">•  <u>16. Display Cancel Remote Start Request Status</u> |

4.15.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.15.4 Function Modeling

4.15.4.1 Activity Diagram




Figure 32: 15. Send Cancel Remote Start Status to Requester

4.15.5 Function Requirements

4.15.5.1 Functional Requirements

4.15.5.1.1 Normal Operation

R_FNC_RS_0045 ECG-App Sends Status of Cancel Request to VSDN/TMC



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

The ECG-App shall send the status of the command response and alert to VSDN/TMC

Requirement ID: R_FNC_RS_0045

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_0046 Cancel Command Response Sent to VSDN/TMC

The vehicle shall process the request and send the cancel command response back to TMC/VSDN

Requirement ID: R_FNC_RS_0046

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_0047 Cancel Remote Start Alert

If the vehicle engine has stopped, the vehicle shall send an alert to the VSDN/TMC

Requirement ID: R_FNC_RS_0047

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

R_FNC_RS_0048 VSDN/TMC Sends Cancel Remote Start Status to Mobile App

VSDN/TMC shall send the status of the mobile app to indicate to the user that the vehicle has successfully remotely stopped

Requirement ID: R_FNC_RS_0048

| | | | |
|---------------------|----------|------------|--|
| Rationale | | | |
| Acceptance Criteria | | | |
| Notes | | | |
| Source | | Owner | |
| Source Req. | | V&V Method | |
| Type | Priority | Status | |

[Req. Template](#) Version 6.0

End of Requirement

4.16 16. Display Cancel Remote Start Request Status

4.16.1 Function Overview

4.16.1.1 Description



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

Function is allocated to:

- Mobile App <<Logical>>

The Display Remote Request Status function is called when the VSDN/TMC sends the Cancel Remote Start status to the Mobile App

4.16.2 Function Scope

The – “16. Display Cancel Remote Start Request Status” function is called by the following functions:

- – “[Cellular Remote Start](#)”




Figure 33: Activity Diagram of “Cellular Remote Start” calling “16. Display Cancel Remote Start Request Status”

4.16.3 Function Interfaces

4.16.3.1 Logical Inputs

| Signal Name | Description |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CancelRemoteStartAlert | Usage in Function: Signal sent from the VSDN/TMC to the vehicle to initiate Cancel Remote Start Received from: <ul style="list-style-type: none">• 15. Send Cancel Remote Start Status to Requester |
| RemoteDeviceFeedback_St | Usage in Function: Remote start status Received from: <ul style="list-style-type: none">• 15. Send Cancel Remote Start Status to Requester |

4.16.3.2 Logical Outputs

| Signal Name | Description |
|-------------|-----------------------------------------------------------------|
| Output | Usage in Function: Mobile App messages displayed to the user |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

4.16.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.16.4 Function Modeling

4.16.4.1 Use Cases

Not supported by MagicDraw report generation.

4.16.4.2 Activity Diagram




Figure 34: 16. Display Cancel Remote Start Request Status

4.16.5 Function Requirements

4.16.5.1 Functional Requirements

4.16.5.1.1 Normal Operation

R_FNC_RS_0049 Reset Buttons

All other remote buttons shall become available after the request is complete

| | | | | |
|-------------------------------------------|--|----------|------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Requirement ID: R_FNC_RS_0049 | | | | |
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | C5266070 https://www.testrail.ford.com/index.php ?/cases/view/5266070&group_by=cas s:section_id&group_order=desc&group _id=455386 |
| Type | | Priority | Status | |
| Reg. Template Version 6.0 | | | | End of Requirement |

4.17 17. Extend Remote Start

4.17.1 Function Overview

4.17.1.1 Description

Function is allocated to:



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

- Mobile App <<Logical>>

After a successful Remote Start request, the user shall have the option to increase the engine on duration timer and extend the Remote Start timer

4.17.2 Function Scope

The – “17. Extend Remote Start” function is called by the following functions:

- – “[Cellular Remote Start](#)”




Figure 35: Activity Diagram of “Cellular Remote Start” calling “17. Extend Remote Start”

4.17.3 Function Interfaces

4.17.3.1 Logical Inputs

| Signal Name | Description |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------|
| RemoteStartTimeRemainin g_St | Received from: <ul style="list-style-type: none">• 8. Display Remote Request Status |
| ExtendTimer | Received from: <ul style="list-style-type: none">• Activity Parameter Node: Input() |

4.17.3.2 Logical Outputs

No Logical Outputs specified.

4.17.3.3 Logical Parameters

Not supported by MagicDraw report generation.

4.17.4 Function Modeling

4.17.4.1 Activity Diagrams



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)




Figure 36: 17. Extend Remote Start

4.17.5 Function Requirements

4.17.5.1 Functional Requirements

4.17.5.1.1 Normal Operation

R_FNC_RS_0024 Extend Duration Timer

While the duration timer is still active, the user shall have the option to extend the engine on time before shutoff by selecting the extend button

| Requirement ID: R_FNC_RS_0024 | | | | |
|-------------------------------------------|--|----------|------------|--------------------|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Reg. Template Version 6.0 | | | | End of Requirement |

R_FNC_RS_0025 Duration Timer Settings

The duration timer shall be increased by a user-selected number of minutes. The user shall be able to set the value to 5, 10 or 15 minutes in Sync HMI

| Requirement ID: R_FNC_RS_0025 | | | | |
|-------------------------------------------|--|----------|------------|--------------------|
| Rationale | | | | |
| Acceptance Criteria | | | | |
| Notes | | | | |
| Source | | | Owner | |
| Source Req. | | | V&V Method | |
| Type | | Priority | Status | |
| Reg. Template Version 6.0 | | | | End of Requirement |

R_FNC_RS_0026 Maximum Duration Timer

The user shall be able to extend the remote start duration timer for a total of 30 minutes

| Requirement ID: R_FNC_RS_0026 | |
|-------------------------------|--|
| Rationale | |
| Acceptance Criteria | |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

| | | | |
|-------------------------------------------|--|----------|--------------------|
| Notes | | | |
| Source | | | Owner |
| Source Req. | | | V&V Method |
| Type | | Priority | Status |
| Req. Template Version 6.0 | | | End of Requirement |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

5 OPEN CONCERNS

#Hint: The following list presents open concerns, which have to be discussed or clarified over the course of the on-going requirements engineering.

| ID | Concern Description | e-Tracker / Reference | Responsible | Status | Solution |
|----|---------------------|-----------------------|-------------|--------|----------|
| 1 | | | | | |

Table 3: Open Concerns (Not supported by MagicDraw report generation.)



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

6 REVISION HISTORY

#Hint: A new version number is assigned to a document with a given revision each time it is checked in to Team Center (TCSE). After release of a revision, the document cannot be edited and no new versions can be created on that revision. When updating the document after that, a new revision has to be created and new versions on that revision will be created upon checking in.

| Revision | Author | Description | Sections Affected | Release Date |
|----------|---------------|------------------------------------------------|-------------------|--------------|
| 1.0 | Audriene Bell | - Creation of MagicDraw Function Specification | All | 5/28/2020 |



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

7 APPENDIX

7.1 Data Dictionary

7.1.1 Technical Signals

###TSG_RS_00001### CellRstrt_D_Rq

Signal from a cellular device requesting initiation or cancellation of remote start

| Init Default Value | | No_Request |
|---------------------------------|-----|---------------------|
| Encoding Type Name | | Remote_Start_Req_ET |
| Value (Discrete Encoding) | 0x0 | No_Request |
| | 0x1 | Remote_Start |
| | 0x2 | Remote_Cancel |
| | 0x3 | Not used |
| Unit | | |

###TSG_RS_00002### Remote_Device_Feedback

Signal providing information about Remote Start device

| Init Default Value | | Null |
|---------------------------------|-----|---------------------------|
| Encoding Type Name | | Remote_Device_Feedback_ET |
| Value (Discrete Encoding) | 0x0 | Null |
| | 0x1 | Acknowledge |
| | 0x2 | Starting |
| | 0x3 | Running |
| | 0x4 | Shutdown |
| | 0x5 | Not Used |
| | 0x6 | Not Used |
| | 0x7 | Not Used |
| Unit | | |

###TSG_RS_00003### CellRstrtRq_No_Actl

Event counter for remote start requests from cellular remote device

| Init Default Value | | 0 unitless |
|-----------------------------------|------------|----------------------|
| Encoding Type Name | | UnitlessValue8bit_ET |
| Value (Continuous Encoding) | Min Value | 0 |
| | Max Value | 255 |
| | Resolution | 1 |
| | Offset | 0 |
| Unit | | |

###TSG_RS_00004### RollCodeCell_No_Actl

Network Security Rolling Code for TCU signal requests

| Init Default Value | 0 Unitless |
|--------------------|------------|
|--------------------|------------|



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

| Encoding Type Name | | UnitlessValue8bit_ET |
|--------------------------------|------------|----------------------|
| Value (Continuous Encoding) | Min Value | 0 |
| | Max Value | 65535 |
| | Resolution | 1 |
| | Offset | 0 |
| Unit | | |

###TSG_RS_00005### Rstrt_T_Actl

Countdown timer representing time in seconds remaining until Remote Start expires (times out). Starting time is variable depending on the customer setting for duration

| Init Default Value | | 0 seconds |
|--------------------------------|------------|--------------|
| Encoding Type Name | | Time16bit_ET |
| Value (Continuous Encoding) | Min Value | 0 |
| | Max Value | 65535 |
| | Resolution | 1 |
| | Offset | 0 |
| Unit | | |

###TSG_RS_00006### PtWakeupActv1_B_Rq

This is a request from the CPP module to the Body control module to request that the PCM hardware wake-up is activated. This allows the PCM to wake-up and provide data to support the remote data request

| Init Default Value | | Off |
|------------------------------|-----|----------|
| Encoding Type Name | | OnOff_ET |
| Value (Discrete Encoding) | 0x0 | Off |
| | 0x1 | On |
| Unit | | |

7.1.2 Logical Signals

#Macro: [Add Ins -> Add Requirement macro](#) (select "Logical Signal" as type)

7.1.3 Logical Parameters

#Macro: [Add Ins -> Add Requirement macro](#) (select "Logical Parameter" as type)

7.1.4 Encoding Types

#Macro: [Add Ins -> Add Requirement macro](#) (select "Encoding Type" as type)

7.2 Glossary

#Hint: Terms, concepts and abbreviations used in the document shall be defined and illustrated here. Note that changes to terms and/or concepts described in this section tend to cause major updates to this document.

The tables below have feature specific definitions and abbreviations. For additional, non-feature specific terms please refer to the [RE Glossary](#)



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start (Command & Control)

7.2.1 Definitions

#Hint: The table below has definitions and abbreviations relevant for the functions in this document. For additional terms please refer to the [RE Glossary](#)

7.2.2 References

7.2.2.1 Ford Documents

List here all Ford internal documents, which are directly related to the feature.

| Reference | Title | Doc. ID | Document Location | Revision |
|----------------------|-----------------------------------------------------------------|---------|-------------------|----------|
| SRC1 | Control My Car v3 ECG SPSS v1.5 | | | |
| SRC2 | Control My Car Implementation Guide v1.5 | | | |
| SRC3 | ECG Common Functions SPSS v1.1 | | | |
| SRC4 | ECG-TCU Interface Power State Management ECG SPSS v1.0 | | | |
| SRC5 | Power Management ECG SPSS v2.0 | | | |
| SRC6 | Stolen Vehicle Services OnBoardClient SPSS v1.9 | | | |
| SRC7 | Embedded Modem Reset Server v2 SPSS v1.5 | | | |
| SRC8 | Body Control Module Functional Specification FS-LU5T-14B476-AAC | | | |
| SRC9 | Control My Car FTCP Profile | | | |

Table 4: Ford internal Documents



Function Specification

Cellular Remote Start, Extend Remote Start & Cancel Remote Start
(Command & Control)

Document ends here.