


### 2.1.3 ESE-REQ-205832/A-ESE Boundary View (BoA4.0)

### ESE Boundary View (BoA4.0)



## 2.2 Interface Requirements

### 2.2.1 Diagnostics

### 2.2.1.1 Fault Codes

#### 2.2.1.1.1 REQ-128322/B-E01B - Control Module Calibration Data #2 (ANC/ESE)

DTC	Condition	DTC Trigger	Fault Action	Configuration Associated
E01B54 Missing Calibration	Key in Run. Voltage is between 10 and 16 volts.	ESE/ANC is missing configuration file or file is corrupted.	ESE/ANC functionality will be disabled.	ESE/ANC = present
E01B57 Data Invalid/ Incompatible Software Component	Key in Run. Voltage is between 10 and 16 volts.	The installed ESE/ANC configuration is not compatible with config	ESE/ANC functionality will be disabled.	ESE/ANC = present
E01B04 Data System Internal Failure	Key in Run. Voltage is between 10 and 16 volts.	Internal fault detected which prevents initializing ESE/ANC	ESE/ANC functionality will be disabled.	ESE/ANC = present

#### 2.2.1.1.2 REQ-114769/B-C100 - LostCom 0x167 (CRANK) (Engine)

DTC	Condition	DTC Trigger	Fault Action	Configuration Associated
C10000	Last known Key in RUN. Voltage is between 10 and 16 volts. Last Known Ignition Stable Bit is Active.	Set when 0x167 is missing for more than five (5) seconds.	Radio will stop logging DTCs.	CGEA = 1.3

2.2.1.1.3 REQ-114761/B-9A01 - Left Front speaker

DTC	Condition	DTC Trigger	Fault Action	Configuration Associated
9A0111 – Short to Ground 9A0112 – Short to Battery 9A0113 – open 9A0101 – short across	Key in Run, ACC, or Delayed Acc. Voltage is between 10 and 16 volts.	ACM amp chip registers short to ground or short to battery.	ACM shuts down faulted Left Front speaker. Chimes will be unavailable in ACM.	Front Speaker = Internal Amp or Speaker1A2B = Speaker or Speaker and Tweeter

2.2.1.1.4 REQ-114762/B-9A02 - Right Front speaker

DTC	Condition	DTC Trigger	Fault Action	Configuration Associated
9A0211 – Short to Ground 9A0212 – Short to Battery 9A0213 – open 9A0201 – short across	Key in Run, ACC, or Delayed Acc. Voltage is between 10 and 16 volts.	ACM amp chip registers short to ground or short to battery.	ACM shuts down faulted Right Front speaker. Chimes will be unavailable in ACM.	Front Speaker = Internal Amp or Speaker2 A2B = Speaker or Speaker and Tweeter

2.2.1.1.5 REQ-114763/B-9A03 - Right Rear speaker

DTC	Condition	DTC Trigger	Fault Action	Configuration Associated
9A0311 – Short to Ground 9A0312 – Short to Battery 9A0313 – open 9A0301 – short across	Key in Run, ACC, or Delayed Acc. Voltage is between 10 and 16 volts.	ACM amp chip registers short to ground or short to battery.	ACM shuts down faulted Right Rear speaker. Chimes will be unavailable in ACM.	Rear Speaker = Internal Amp or Speaker3 A2B = Speaker or Speaker and Tweeter

2.2.1.1.6 REQ-114764/B-9A04 - Left Rear speaker

DTC	Condition	DTC Trigger	Fault Action	Configuration Associated
9A0411 – Short to	Key in Run, ACC, or Delayed Acc. Voltage is	ACM amp chip registers short to	ACM shuts down faulted Left Rear	Rear Speaker = Internal Amp or



Ground 9A0412 – Short to Battery 9A0413 – open 9A0401 – short across	between 10 and 16 volts.	ground or short to battery.	speaker. Chimes will be unavailable in ACM.	Speaker1 A2B = Speaker or Speaker and Tweeter
--	--------------------------	--------------------------------	---	--

### 2.2.1.2 Routines

#### 2.2.1.2.1 ESE-IR-REQ-092301/B-ROUTINE 0x3008 "Trigger process to select calibration"

Control Routine	0x3008
Control Routine Name	Trigger process to select calibration
Executable in Sessions	0x03
Security Levels Required to Run	0x03,
Routine Entry Criteria	ACU must be powered and in extended diag session. Level 3 security must be unlocked.
Routine Exit Criteria	Routine completes
Maximum Routine Run Time	200 (ms)
Can Restart While Running	no
Supported Sub Functions	0x01
Dependencies	ESE

This enables ESE and/or ANC feature, depends of module configuration.

#### 2.2.1.2.2 ESE-IR-REQ-018086/B-ROUTINE 0x601C "Transfer Function Test tone" (TcSE ROIN-293182)

Control Routine	0x601C
Control Routine Name	Tones Test
Control Routine Description	Generates ESE calibration tones.
Executable in Sessions	0x03
Security Levels Required to Run	
Routine Entry Criteria	ACU must be powered and switched on or in Idle Mode (HMI switched off, CAN active). Notes: The radio can be switched on/off by writing with service 2E to PID \$7215.
Routine Exit Criteria	Tones Test Completes. Receipt of RoutineControl with RoutineControlType = StopRoutine. Switch Radio Off
Maximum Routine Run Time	30000 (ms)
Can Restart While Running	no
Supported Sub Functions	0x01 0x02 0x03
Dependencies	ESE

Routine continues until completed as signaled by MBBM library.

### 2.2.1.3 Identifiers

#### 2.2.1.3.1 REQ-128316/A-Engine RPM (F40C)

DID Number (Hex)	DID Description	DID Short Name	DID Size (Bytes)	Datatype
F40C	Engine RPM		2	Unsigned Numeric