



- Default Password maybe 0000 or 1234
- We can change password by AT commands

IMPORTANT: Disconnect Rx & Tx pins while uploading sketch

→ for controller you may download bluetooth terminal app on android or can build your own app using MIT App Inventor

```
if (Serial.available() > 0)
{
  x = Serial.read();
  Serial.println(x);
}
```

} checks and read serial data received by HC-06

↓
Stores received data in 'x' variable