

### USART Software Auto Baud Rate Detection

## Introduction

This sample code demonstrates how to perform automatic USART baud rate detection through software control.

Applicable products:

Product series	AT32 Family
----------------	-------------

Main peripherals used:


Peripherals	USART
	TMR
	EXINT

# 1 Overview

This sample code demonstrates how to perform auto baud rate detection on USART through software control.

**Principle:**

By measuring the width of USART start bit, the software can calculate USART frequency division value so as to achieve auto baud rate detection.



*Note: During measurement stage, the first bit of the first byte sent by Host must be "1", that is, the first bit after the start bit must be 1. For example, the host can send 0xA1, 0x55, 0x33...*

**Follow the procedures below:**

- 1) Initialize TMR and EXINT
- 2) Monitor USART RX through EXINT. When there is a rising or falling edge, write down the current TMR value
- 3) When both edges (rising edge and falling edge) are generated, it indicates that the start bit measurement is finished
- 4) Wait for 1ms until the current byte is received.
- 5) Calculate the received data and the corresponding USART frequency division value
- 6) Send 0x55 as an acknowledgement indicating that the calibration is already complete.


*Note: This sample case uses TMR6, USART2 (PA2, PA3) as peripherals. If there is a need to use other serial interfaces or TMR, you can do it by modifying macro definitions in the code.*

## 2 Quick start

### 2.1 Hardware resources

- 1) AT-START-F437 board

Figure 1. AT-START-F437 V1.1 evaluation board



- 2) USB-to-serial interface tool

### 2.2 Software resources

- 1) SC0121\_SourceCode

*Note: All of projects are built based on Keil 5. For the need to run them in other compiling environments, user can make simple adjustments according to AT32xxx\_Firmware\_Library\_V2.x.x\project\at\_start\_xxx\templates.*

### 2.3 Example case

- 1) Connect the RX and TX of USB-to-serial interface to the TX (PA2) and RX(PA3) of USART2
- 2) Open "SourceCode\SC0121\_SourceCode\_V2.0.0\utilities\usart\_auto\_baud\_rate\_detection\mdk\_v5"
- 3) Compile code and download it to the evaluation board
- 4) Open the serial interface assistant on PC, select a serial interface and send 0x55
- 5) If PC can receive 0x55, it indicates that auto baud rate detection is successful.

### 3 Revision history

Table 1. Document revision history

Date	Revision	Changes
2023.09.22	2.0.0	Initial release

## IMPORTANT NOTICE – PLEASE READ CAREFULLY

Purchasers are solely responsible for the selection and use of ARTERY's products and services, and ARTERY assumes no liability whatsoever relating to the choice, selection or use of the ARTERY products and services described herein

No license, express or implied, to any intellectual property rights is granted under this document. If any part of this document deals with any third party products or services, it shall not be deemed a license granted by ARTERY for the use of such third party products or services, or any intellectual property contained therein, or considered as a warranty regarding the use in any manner of such third party products or services or any intellectual property contained therein.

Unless otherwise specified in ARTERY's terms and conditions of sale, ARTERY provides no warranties, express or implied, regarding the use and/or sale of ARTERY products, including but not limited to any implied warranties of merchantability, fitness for a particular purpose (and their equivalents under the laws of any jurisdiction), or infringement on any patent, copyright or other intellectual property right.

Purchasers hereby agree that ARTERY's products are not designed or authorized for use in: (A) any application with special requirements of safety such as life support and active implantable device, or system with functional safety requirements; (B) any aircraft application; (C) any aerospace application or environment; (D) any weapon application, and/or (E) or other uses where the failure of the device or product could result in personal injury, death, property damage. Purchasers' unauthorized use of them in the aforementioned applications, even if with a written notice, is solely at purchasers' risk, and Purchasers are solely responsible for meeting all legal and regulatory requirements in such use.

Resale of ARTERY products with provisions different from the statements and/or technical characteristics stated in this document shall immediately void any warranty grant by ARTERY for ARTERY's products or services described herein and shall not create or expand any liability of ARTERY in any manner whatsoever.

© 2023 Artery Technology -All rights reserved