

Adjusting the Seat Positions in Aventro Motors Vehicles

Overview

Proper seat adjustment is essential for driving comfort, safety, and visibility. Aventro Motors vehicles are equipped with manual and/or electronic seat adjustment controls, depending on the model and trim. This guide walks you through adjusting your seat position for the safest and most comfortable driving experience.

Steps for Adjusting the Seat Positions

1. Adjusting the Seat Distance from the Pedals

- Locate the seat adjustment lever under the front edge of the seat.
- Pull the lever up to unlock the seat.
- Slide the seat forward or backward until your feet reach the pedals comfortably while keeping a slight bend at your knees.
- Release the lever to lock the seat in position.
- Gently rock the seat to ensure it is securely locked.

2. Adjusting the Seat Height (if equipped)

- Locate the seat height adjustment lever or electronic control (usually on the side of the seat).
- For manual systems, pump the lever up or down.
- For electronic systems, use the corresponding switch to raise or lower the seat.
- Adjust until you have a clear view over the steering wheel and dashboard, with adequate headspace.

3. Adjusting the Seat Backrest Angle

- Find the seat backrest adjustment lever or rotary knob at the side of the seat.
- Lean forward slightly and pull or rotate the control to release the backrest.
- Adjust the backrest angle so you are sitting upright, with your shoulders touching the seatback.
- The ideal angle is slightly reclined for comfort, but never more than 30° from upright.
- Ensure the backrest is firmly locked in position before driving.

4. Adjusting the Headrest

- Hold both sides of the headrest.

- Press the adjustment button (usually at the base) and move the headrest up or down.
- The top of the headrest should be level with the top of your head.
- The headrest should be as close to the back of your head as possible for optimal safety.

5. Adjusting the Lumbar Support (if equipped)

- Use the lumbar support lever, dial, or electronic switch (side of seatback).
- Increase or decrease support as needed for comfort and spine alignment.
- Proper lumbar support helps reduce fatigue on long drives.

Tips for Safe Seat Adjustment

- Adjust your seat before starting the engine and while the car is stationary.
- Ensure all adjustments are firmly locked in place before driving.
- The distance between your chest and the steering wheel should be at least 25 cm (10 inches).
- Adjust the steering wheel if required, for optimal hand positioning.
- All passengers should also adjust their seats and headrests.

Troubleshooting

Issue	Possible Solution
Seat not moving	Check for obstructions under the seat.
Electronic controls not working	Check vehicle battery or fuses.
Seat does not lock in place	Re-engage lever or consult service center.
Headrest stuck	Press and hold release button firmly.

Need Assistance?

For in-depth troubleshooting or if you experience issues with seat adjustment mechanisms, contact your nearest **Aventro Service Center** or call Aventro Motors Customer Support at **+91 124 1234567**.

Drive safe, drive smart with Aventro!