

How to Handle “Engine Won’t Start” Issue

When your Aventura vehicle’s engine refuses to start, it can be frustrating. Use this step-by-step guide to help diagnose and resolve the problem, or to gather information before contacting an Aventura Service Center.

1. Check the Basics

- **Gear Position:** Ensure the car is in ‘Park’ (automatic) or ‘Neutral’ (manual).
 - **Steering Lock:** Gently turn the steering wheel while turning the key if steering is locked.
 - **Key/Start Button:** Switch ignition off and retry. For push-button start, press brake/clutch while starting.
-

2. Battery Check

- **Symptoms:** No lights/display, slow/absent cranking sounds, clicking noise.
 - **Actions:**
 - Inspect dashboard for dim or no lights.
 - Try using headlights or infotainment; if dim or off, battery may be the culprit.
 - If available, try jump-starting with a healthy battery.
 - For Electric variants: Ensure Battery Pack has adequate charge. Attempt Fast Charging if possible.
-

3. Fuel System Inspection

- **Low Fuel/Empty Tank:** Check fuel gauge and fill if necessary.
 - **Diesel Vehicles:** Ensure there’s no air lock or recent filter change.
 - **Hybrid/Electric:** Ensure main battery charge is sufficient.
-

4. Starter Motor & Electricals

- **Symptoms:** Single click or silence, even with good battery.
- **Actions:**
 - Check for blown fuses (refer to user manual location).
 - Test if interior lights stay bright when key is turned; if yes, suspect starter relay/motor.

5. Check Engine Warning Lights

- **Look for:** Engine/Malfunction lights on dashboard.
 - **Action:** If warning lights appear, note down symbol/color for service personnel.
-

6. Listen for Sounds

- **Rapid Clicking:** Battery/starter issues.
 - **Engine Cranking (but not starting):** Possible fuel, ignition, or electrical problems.
 - **No Sound at all:** Battery, ignition switch, or starter.
-

7. Check Engine Components

- **Loose Battery Terminals:** Tighten if needed.
 - **Corroded Terminals:** Clean carefully.
 - **Fuses:** Replace if blown (carry spare fuses if possible).
 - **Relays:** Swap with identical relays if available for testing.
 - **Security Systems:** Deactivate aftermarket alarms/immobilizers, if installed.
-

8. Call Aventro Roadside Assistance

- If the car still won't start after these checks, contact **Aventro Roadside Assistance**:
 - **Location:** Find nearest Aventro Service Center.
 - **Helpline:** +91 124 1234567