

Velvera Pad Series — Usage Guide

Getting Started

1. Unboxing and Setup

- **Included in the Box:** Velvera Pad, 33W/45W USB-C power adapter, USB-C cable, Quick Start Guide, SIM ejector tool (Pro models only)
- **Optional Accessories:** Velvera Pencil, Velvera Keyboard

Step-by-Step Setup:

1. **Power On:**
Press and hold the power button (right edge).
 2. **Language & Region:**
Follow on-screen prompts to select your language and region.
 3. **Wi-Fi/Network Connection:**
 - All models: Connect to Wi-Fi 6/6E.
 - Pad Pro: Optionally insert nano SIM for 5G cellular network.
 4. **Google Account Sign-In:**
Sign in to your Google account for Play Store and sync services.
 5. **System Updates:**
Allow Velvera UI to check for and install available updates.
-

2. Charging Your Tablet

- **Charging Port:** USB-C (bottom left edge)
 - **Supported Charging:**
 - Pad 11": Up to 33W fast charging, full charge ~2.5 hours
 - Pad Pro 12.9": Up to 45W ultra-fast charging, full charge ~2 hours
 - **Battery Tips:** Use the included adapter for optimal charging speed. Avoid letting the battery fully deplete for longer life.
-

Everyday Usage

3. Tablet Navigation

Action	Gesture/Button	Description
Home Screen	Swipe up from bottom or tap Home	Returns to main screen
App Switcher	Swipe up & hold, tap Recent Apps icon	View all open apps, switch or close apps
Back	Swipe from either side or tap Back	Returns to previous screen

Action	Gesture/Button	Description
Quick Settings	Swipe down from top right	Access Wi-Fi, Bluetooth, brightness, etc.
Notifications	Swipe down from top left	View messages, alerts, app notifications

4. Productivity & Multitasking

Multi-Window & Multitasking

- **Split Screen:**
Open Recents, tap app icon, choose “Split screen.” Select second app.
- **Floating Apps:**
Supported apps: Tap and hold from Recent Apps, drag to open as floating window (Pro models).
- **Wireless Dex Mode:**
(Pad Pro only) Enable from Quick Settings for a desktop-like interface on external displays.

Keyboard & Mouse Support

- Attach Ververa Keyboard magnetically; tablet auto-detects.
- Use Bluetooth mouse for enhanced productivity.

5. Stylus Functions (Ververa Pencil)

Function	How-To	Model Support
Pair & Charge	Snap Pencil to tablet edge (magnetic/wireless charging, Pro only)	All models
Notes & Drawing	Open Notes or any drawing app, begin writing or sketching	All models
Quick Annotate	Double tap Pencil (customizable in settings)	All models
Pressure Sensitivity	4096 levels (gradual shading, precision lines)	All models
Tilt Support	Supports artistic shading and edge effects	All models

6. Camera & Media

- **Open Camera App:** Tap Camera icon from Home/Apps.
 - **Main Camera Functions:**
 - **Photo/Video:** Standard, HDR, Portrait options (switch via bottom menu)
 - **Ultra-Wide:** (Pad Pro) Use toggle to switch rear lenses.
 - **Center Stage:** (Pad Pro) Keeps you centered during video calls.
 - **Gallery & Editing:** Photos save automatically; edit and share from Photos app.
-

7. Connectivity

Feature	How to Use / Access	Models
Wi-Fi 6/6E	Quick Settings > Wi-Fi icon; select network	All
5G Cellular	Insert SIM > Settings > Network & Internet	Pad Pro only
USB-C & Display	Connect USB peripherals, external displays (DisplayPort out)	Pad Pro models
Bluetooth	Pair in Settings > Bluetooth	All
Miracast	Quick Settings > Screen Cast	Pad Pro only

8. Security & Privacy

- **Face Unlock:**
Register via Settings > Security > Face Unlock (IR sensor on Pro).
 - **Fingerprint Unlock:**
(Pad Pro) Follow onscreen prompts under Settings > Security.
 - **App Permissions:**
Control per-app access in Settings > Apps & Permissions.
-

9. System & Software

- **System Updates:**
Settings > System > Updates
 - **Backup & Restore:**
Settings > System > Backup
 - **Parental Controls:**
Settings > Digital Wellbeing > Parental Controls
-

10. Troubleshooting & Support

Issue	Suggested Action
Tablet won't power on	Hold power for 8 seconds, then release; charge for 10 mins
Cannot connect to Wi-Fi	Toggle Wi-Fi, check password, restart router
Accessory not detected	Reattach accessory, check for updates; restart device
Rapid battery drain	Reduce screen brightness, close background apps
Software lag or freeze	Force restart; check for available updates
Need further help	Visit velvera.com/support or contact authorized service

Accessory Usage

- **Velvera Pencil:** Attach magnetically to edge for charging and pairing; use for drawing or note-taking.
- **Velvera Keyboard:** Align to connection pins; adjusts to multiple angles, integrated trackpad supports gestures.

Care & Maintenance

- Use soft, lint-free cloth to clean display.
- Avoid exposure to liquids, extreme heat, or direct sunlight.
- Store and charge tablet at room temperature when not in use.

Warranty & Support

- Standard 1-year limited warranty on device and accessories.
- Extended support and accidental damage protection plans available at purchase.

For detailed manuals, accessories, and support:
Visit www.velvera.com/support

Velvera — Powering your creativity, wherever you go.