

## Aventro Motors: How to Change a Tyre

Changing a flat tyre is a basic and essential automotive skill for every Aventro Motor car owner. This guide will walk you through:

- Steps to change a tyre
- Where the spare tyre and toolkit is found in all Aventro models
- General tips and safety instructions

---

### Where to Find the Spare Tyre & Toolkit in Aventro Models

Model Type	Common Location of Spare Tyre & Toolkit
Hatchback	Under the boot floor in the rear compartment
Sedan	Under the boot floor in the trunk
SUV	Under the boot floor or mounted underneath the rear of the car
(All Models)	Toolkit is usually secured next to the spare tyre or inside a side panel of the boot/trunk

**Note:** All variants (Petrol/Diesel/Electric/Hybrid) follow the same compartment arrangement.

---

### Steps to Change a Tyre

#### 1. Park Safely

- Pull over to a safe, flat location away from traffic.
- Turn on your hazard lights.
- Apply the handbrake.
- Place wheel wedges/blocks (if available) to prevent vehicle movement.

#### 2. Gather Tools

You will need: - Spare tyre (found as per table above) - Jack (usually in toolkit) - Lug wrench (in toolkit) - Wheel wedges/blocks (optional) - Vehicle owner's manual (for reference)

#### 3. Remove the Wheel Cover/Hubcap

- If your wheel has a cover, use the flat end of the wrench or the provided lever to gently pry it off.

#### **4. Loosen the Lug Nuts**

- Use the lug wrench to turn the lug nuts counter-clockwise.
- Loosen them slightly – do not remove fully at this stage.

#### **5. Lift the Vehicle with the Jack**

- Position the jack under the jacking point nearest to the flat tyre. Refer to your owner's manual for the exact point.
- Raise the vehicle until the flat tyre is about 6 inches above the ground.

#### **6. Remove the Lug Nuts and Tyre**

- Unscrew the lug nuts completely.
- Remove the flat tyre and set it aside.

#### **7. Mount the Spare Tyre**

- Line up the holes and push the spare onto the hub.
- Replace the lug nuts and tighten them by hand.

#### **8. Lower the Vehicle**

- Carefully lower the car with the jack until the tyre touches the ground firmly.
- Remove the jack.

#### **9. Tighten the Lug Nuts**

- Use the lug wrench to tighten the lug nuts in a star pattern to ensure even pressure.

#### **10. Replace the Hubcap or Wheel Cover (if applicable)**

- Place the hubcap back onto the wheel.

#### **11. Stow Equipment**

- Put the flat tyre, jack, and tools back in their compartments.
- Double check everything is secure.

---

### **Safety & Tips**

- Never change a tyre on a slope or close to traffic.
- Use hazard warning triangle if available.
- After installation, drive slowly and get the spare tyre pressure checked at the nearest Aventure Service Center.

- Some spare tyres are “space savers” and are not intended for long distances or high speeds.
- 

## Need Help?

Aventro offers **Roadside Assistance** across India. If you are unable to change the tyre, please contact your nearest:

- Aventro Service Center
  - Or call Aventro Roadside Assistance (see main service manual/contact card in your glove box)
- 

## Find Service Centers

- Mumbai: Andheri East
- Delhi: Okhla Industrial Area, Phase II
- Bengaluru: Electronic City
- Chennai: Guindy Industrial Estate
- Hyderabad: Banjara Hills
- Pune: Wakad
- Kolkata: Salt Lake, Sector V
- Ahmedabad: Vastrapur
- Jaipur: Mansarovar
- ... and many more across India!

For full list and directions, visit Aventro Motors Website.

---

**Drive safe with Aventro Motors!**