

# How to Open the Fuel Knob in Aventro Cars

Opening the fuel knob (fuel cap) on your Aventro vehicle is a simple process. Follow these steps to ensure safe and easy access when you need to refuel:

---

## Steps to Open the Fuel Knob

1. **Park & Switch Off the Engine**
    - Ensure your car is completely stopped and the engine is turned off.
    - Engage the parking brake for safety.
  2. **Locate the Fuel Knob Release Lever**
    - The fuel knob release lever is typically found:
      - On the driver's side floor, near the seat or door.
      - In some models, it may be on the dashboard or central console.
  3. **Pull the Release Lever**
    - Pull up or push the lever labelled with a **fuel pump icon**.
    - You may hear a click indicating the fuel lid has been released.
  4. **Exit the Car**
    - Step out of the vehicle and go to the side where the fuel lid (fuel door) is located.
  5. **Open the Fuel Lid**
    - Gently open the fuel lid.
    - You'll now see the fuel knob (fuel cap).
  6. **Turn and Remove the Fuel Knob**
    - Twist the fuel knob (cap) **anti-clockwise** to unscrew it.
    - Remove the cap and place it in a secure slot (usually on the lid itself or hold it carefully).
  7. **Refuel Safely**
    - Proceed with refueling as needed.
  8. **After Refueling**
    - Screw the fuel knob (cap) back on **clockwise** until you hear a click (to ensure it's sealed).
    - Close the fuel lid securely.
- 

## Additional Tips

- **If the Fuel Lid Doesn't Open:** Ensure the car is unlocked; some models require all doors to be unlocked before the lever works.
  - **Never Force the Cap:** If the knob is stuck, double-check that the release mechanism is fully engaged.
  - **Electric & Hybrid Models:** Always check specific instructions in the owner's manual for high-voltage safety precautions.
-

**Note:** If you have difficulty finding the lever or opening the cap, refer to your car's owner's manual or contact your nearest Aventro Service Center.

---