

Adjusting the Steering Wheel

Proper steering wheel adjustment is essential for comfortable and safe driving. Follow these steps to adjust your steering wheel for an optimal driving position.

Why Adjust the Steering Wheel?

- **Comfort:** Reduces fatigue during long drives.
 - **Control:** Ensures effective steering and better handling.
 - **Safety:** Ensures clear view of the instrument cluster and optimal airbag positioning.
-

Types of Steering Wheel Adjustments

Most Avento Motors vehicles come with either or both of the following:

- **Tilt Adjustment:** Allows the wheel to move up and down.
 - **Telescopic Adjustment:** Allows the wheel to move closer or farther from the driver.
-

Step-by-Step Guide

1. Park the Vehicle Safely

- Ensure the vehicle is on a flat surface and engage the parking brake.
- Turn off the engine for safety.

2. Locate the Adjustment Lever

- Look for the steering adjustment lever beneath or on the side of the steering column, usually beneath the wheel.

3. Release the Lever

- Pull (or push, depending on the model) the adjustment lever to unlock the steering wheel movement.

4. Adjust the Steering Wheel

- **Tilt:** Move the wheel up or down to a comfortable height.
- **Telescopic:** Pull the wheel towards you or push it away to set a comfortable distance.
- The steering wheel should not obstruct your view of the gauges.

5. Lock the Steering Wheel Position

- Once set, firmly push the adjustment lever back to the locked position.

6. Check Positioning

- With your back against the seat, extend your arms and rest your wrists on top of the wheel; your elbows should be slightly bent.
 - Ensure there is at least 25 cm (10 inches) between your chest and the wheel (important for airbag safety).
 - Confirm that all indicator lights and gauges are fully visible.
-

Tips

- Adjust your seat first before the steering wheel.
 - If your vehicle has a heated steering wheel or steering wheel memory settings, consult your owner's manual for additional features.
 - Never adjust the steering wheel while driving.
-

Troubleshooting

- **Stuck Lever:** Check for obstructions under/around the lever or consult your nearest Aventro Service Center.
 - **Loose Wheel:** Ensure the lever is locked; if the wheel remains loose, have it inspected by a professional.
-

For Further Assistance

If you encounter issues or need help with adjustments, visit your nearest Aventro Service Center or contact Aventro Motors Support:

- **Email:** info@aventromotors.com
 - **Phone:** +91 124 1234567
-

Drive safely and comfortably!