


Pamcrash Thickness Assignment


Introduction

- Process automation tool has been developed to assign component thickness to element thickness and vice-versa
- Support two thickness conversions
 1. Component to Element
 2. Element to Component



Launching

- Select File > Run > Tcl/Tk Script > Pam_thickness_assignment.tbc



User Guide

- Load the model in HM database
- **Case – 1 : Component to Element**
 - Component thickness (H – value) will be assigned to all the elements in a component
- **Case – 2 : Element to Component**
 - Tool collect same thickness elements in a component
 - Create new component for each thickness value with thickness included in name
 - Move same thickness elements to newly created component
 - Update element thickness (H-value) to 0.00

Pre-requisites

- Internet connection : Laptop/Desktop should be connected to internet
- Python installation : Python should be installed on your system
- Install python library : Execute "pip install pywin32" in windows command prompt. It is one time activity which install necessary python libraries

```
C:\Users\uday.sherikar>pip install pywin32
```