




INSTALLING ALTium


This tutorial is meant to set you up with the Altium Software. You will need to be on the UF network to properly install Altium using our method. If you are not currently on UF Wi-Fi, you can go to the following link to download a remote access VPN: <https://connect.ufl.edu/it/wiki/Pages/glvpn-anyconnect-install.aspx#mac-acinstall>.

1. Follow the below link and click on the .zip download:
<ftp://altiumdownload.ece.ufl.edu/pub/Altium%20Install/Altium%2019/Altium%2019%20zip/>
2. Once finished downloading, extract the files to whatever destination you want.
3. Once inside your destination folder, click on the AltiumDesigner19Setup.exe file.




4. Follow through the default installation settings as shown below.






5. Once installed and opened you should see the below screen:
6. Click on “Setup Private License Server”



7. Set up the screen as shown below:



The image shows a 'Private License Server Setup' dialog box. It has two sections: 'Primary server' and 'Secondary server'. Each section contains a 'Servers list' dropdown, a 'Server name' text box with a radio button for 'Use name', a 'Server address' text box with a radio button for 'Use address', and a 'Server port' text box with a 'Clear' button. In the 'Primary server' section, the 'Server name' is 'altium.ece.ufl.edu' and the 'Server port' is '9780'. At the bottom of the dialog are 'Search', 'OK', and 'Cancel' buttons.

8. If you did everything correctly, you should see the following screen:

